

# SDTU-01

2Megabit SDSL MODEM

xDSL SERIES

SDSL ATM  
Bridge / Router

## *User's Manual*

Revision: 2.0

# Table of Contents

- [1. Overview](#)..... 1
- [2. Features](#) ..... 1
- [3. Packaging](#) ..... 1
- [4. Appearance](#) ..... 2
- [5. Hardware Installation](#)..... 3
- [6. Management](#) ..... 4
- [7. Default values](#) ..... 5
- [8. Software Upgrade](#) ..... 6
- [Appendix A. Console Setup](#)..... 7
- [Appendix B. Command Line Interface](#)..... 8
- [Appendix C. Specifications](#) ..... 25
  - [Hardware Specifications](#)..... 25
  - [Software Specifications](#)..... 26

# Table of Figures

<a href="#">FIGURE 1: FRONT PANEL</a> .....	2
<a href="#">FIGURE 2: REAR PANEL</a> .....	2
<a href="#">FIGURE 3: HARDWARE INSTALLATIONS</a> .....	3
<a href="#">FIGURE 4: COMMAND TREE</a> .....	9

# Revision Marks

<b>Revision</b>	<b>Date</b>	<b>Notes</b>
V2.0	May 25, 2000	Software: 2.11B-H30.02-F45.108

## 1. Overview

The *SDTU-01/ET10* is an SDSL modem supporting ATM bridging with 4-port 10Base-T Ethernet hub. The SDSL front end provides symmetrical data rates from 144Kbps up to 2320Kbps in programmable rate steps of 8Kbps. The *SDTU-01/ET10* can be configured to inter-operate with SDSL DSLAM or to support Point-to-Point data transmission applications by flexible CO/RT configuration.

## 2. Features

- ✓ High Speed Symmetrical Data Transmission on Single Twisted Copper Pair Wire
- ✓ 2B1Q Line Coding
- ✓ Symmetrical Multi-rate data transmission from 144Kbps up to 2320Kbps
- ✓ RFC 1483 Bridging over ATM over SDSL
- ✓ 4-port 10Base-T Ethernet hub for PC/LAN
- ✓ High quality, simple operation, low power consumption
- ✓ Compatible and interoperable with major Central Office side SDSL DSLAM or Multi-service Access System
- ✓ Local OAM&P through command line interface via RS-232 Craft port
- ✓ Local Telnet through the Ethernet interface
- ✓ Remote Telnet through SDSL interface
- ✓ Supports point-to-point applications

## 3. Packaging

This package consists of the following items:

- ▶ The *SDTU-01/ET10* unit
- ▶ AC Adapter
- ▶ Installation and Operation Manual
- ▶ 9-pin to 9-pin serial configuration cable

## 4. Appearance

### Front Panel




Figure 1: Front Panel

### Rear Panel




Figure 2: Rear Panel

### 5. Hardware Installation

1. Connect the SDSL cable, (item 1) indicated in Figure 3, to the LINE port of RJ-11 socket.
2. Use a RJ-45 cable, (item 2) indicated in Figure 3, to connect the *SDTU-01/ET10* to the LAN or a PC with Ethernet adapter installed.

**Note:** Be sure to use RJ-45 cross-over cable when connecting to a hub.

3. Plug in the AC adapter to an AC power socket, then connect the DC jack, (item 3) indicated in Figure 3, the DC inlet of the *SDTU-01/ET10*.
4. Use a 9-pin RS-232 cable (item 4) indicated in Figure 3, to connect the Console Port to a serial port of a terminal such as PC with data terminal emulation software (Hyper Terminal) installed, in order to perform local management.




Figure 3: Hardware Installations

## 6. Management

*SDTU-01/ET10* supports simple, flexible and easy-to-operate methods for management purposes. The *SDTU-01/ET10* can be managed via the following paths, refer to Appendix B for detailed information.

- ✓ Console port – use the RS-232 cable for connecting *SDTU-01/ET10* to a console terminal or a PC running terminal emulation program, such as Hyper Terminal, see Appendix A for proper console setup.
- ✓ Local Ethernet Port – connect the Ethernet port to your local area network or to a PC directly, “*Telnet*” *SDTU-01/ET10* from any workstation on the LAN.
- ✓ SDSL port from remote site – while SDSL connection is in service, you may remotely “*Telnet*” *SDTU-01/ET10* from a workstation networking to the CO equipment.

**Note:** As operating SDSL modem requires technical know-how and experience, it is recommended that management of the *SDTU-01/ET10* be performed by qualified technical staff only.



## 7. Default values

*SDTU-01/ET10* is pre-configured with the following parameters; the user may also re-load the default parameters by selecting **Default** from the main menu.

### **LAN and VC setting**

Ethernet (local) IP: 192.168.2.1  
Subnet mask: 255.255.255.0  
Protocol: RFC1483, bridge Mode  
VPI/VCI: 8/35  
Spanning tree: disable  
Packet control: IP and PPPoE

### **WAN and SDSL**

Side selected: CPE (RT) side  
Auto Rate: disable  
Rate select: 2320Kbps  
Sign/Magnitude Bit Sequence: reverse  
Data Bit Polarity: Normal  
Scrambling: enable  
Idle-cell-sending: enable

## 8. Software Upgrade

You may easily upgrade the *SDTU-01/ET10*'s embedded software by obtaining the compressed upgrade kit, ZIP file, from the service provider then following the steps:

- ✓ Extract the ZIP file
- ✓ Connect *SDTU-01/ET10* via the local Ethernet port or remote SDSL link, make sure the *SDTU-01/ET10* Ethernet IP address is set and your terminal is properly configured so you can successfully “ping” *SDTU-01/ET10*.
- ✓ Under a DOS prompt, execute the command line “**xupgrade <IP address of SDTU-01/ET10>**”, for instance “**xupgrade 192.168.2.1**”.
- ✓ This upgrade process may take as long as 60 seconds.
- ✓ Then reboot *SDTU-01/ET10* with new software.

***NOTE: Strictly maintain stable power to SDTU-01/ET10 while upgrading software. If power fails during the upgrading process, contents in the memory could be destroyed and the system may hang. In such a case, you must call the dealer or system integrator for repair.***

## Appendix A. Console Setup

Connect the RS-232 console port to an ASCII data terminal or a PC with Windows serial Terminal mode of VT-100 (Hyper Terminal). To Start the Hyper-terminal, following the steps below:

1. Start "Hyper-terminal" program --
  - On Windows 98 or Windows NT: start Tool Bar → Program → Accessory → Hyper Terminal Group → Double Click Hypertrm.exe → Enter Connection Name → Select Icon → Click OK
2. Select COM port to communicate with *SDTU-01/ET10*
  - Choose direct to COM1 or COM2 → click OK
3. Set Port Properties --
  - ▶ Port Setting:
    - **Bit per second: 9600**
    - **Data bits: 8**
    - **Stop bits: 1**
    - **Parity bits: None**
    - **Flow Control: None**

## Appendix B. Command Line Interface

The command line interface allows you to change the SDSL, ATM and Ethernet parameters, and display the status as well. Some commands must be followed by parameters for proper configuration of the modem. Conventionally, there shall be a “**space**” between a command and its corresponding parameters.

The punctuation marks in the command line interface have their different meanings. The syntax < > means the parameters that are enclosed are **compulsory**, [ ] means that the parameters are **optional**, and | between parameters means **either....or**. In the **parameters section** “ “ means that the parameters are **Key Words**. Furthermore, after entering the password, the screen will show the prompt as > for command entry.

There are two hierarchical levels in the command line interface. The command tree below will show the user the hierarchical relationship and commands supported:

**Note 1:** When password is applied, the connection will time out after 3 minutes if there is no access to the modem. Password entering is necessary to resume connection.

**Note 2:** All settings will become effective only after being saved.




Figure 4: Command Tree

## COMMAND LINE INTERFACE CONVENTIONS

### HELP or ?

*Lists all commands at the current level menu and follow by simple description of each command*

Syntax: help

Parameters:

Example: > help

Syntax: ?

Parameters:

Example: > ?

### HELP <command> or ? <command>

*Display the description and usage of particular command in each level.*

Syntax: Help <command>

Parameters: command: Enter each command

Example: >sdsl> help terminal

Display the description and syntax of **terminal** command

Response: terminal -Configure the device to COE or CPE mode

Usage: terminal <coe>|<cpe>

> coe - COE mode is selected

> cpe - CPE mode is selected

Syntax: ? <command>

Parameters: command: Enter each command

Example: >sdsl> ? terminal

Display the description and syntax of **terminal** command

Response: terminal -Configure the device to COE or CPE mode

Usage: terminal <coe>|<cpe>

> coe - COE mode is selected

> cpe - CPE mode is selected

## HOME

*Go back to the upper level menu*

Syntax:        home

Parameters:

Example:      > home

## MAIN MENU COMMANDS:

default	lan	list	manage
ping	quick	r1483	restart
save	sdsl	show	ver

## DEFAULT

*Set all configuration to factory setting*

Syntax:        default

Parameters:

Example:      > default

Response:     Set to default successfully.

## LAN

*Enter to LAN menu. More commands under LAN menu, see detail after.*

Syntax:        lan

Parameters:

Example:      > lan

**LIST**

*Display the status for each enabled VC*

Syntax: list  
Parameters:

Example: > list

Response: Port ethernet  
0: Enabled TxPkts: 1 RxPkts: 0/0  
Port sdsl  
0: Enabled TxPkts: 56 RxPkts: 37/0 TxVPI/VCI:  
0/35 RxVPI/VCI: 0/35

Explanation: Information for Ethernet port:  
0 (Status of port number 1).....Enabled  
TxPkts (transmitted packets).....1  
RxPkts (received packets).....0/0 (correct/error)

Explanation: Information for SDSL port:  
0 (Status of port number 1).....enabled  
TxPkts (transmitted packets).....56  
RxPkts (received packets).....37/0 (correct/error)  
TxVPI/VCI (transmitted VC).....0/35  
RxVPI/VCI (received VC).....0/35

**MANAGE**

*Enter to MANAGE configuration menu. More commands under MANAGE menu, see detail after.*

Syntax: manage  
Parameters:

Example: > manage

**PING**

*Ping a specific IP address for testing purpose*

Syntax: ping <ipaddress>



Parameters: ipaddress: IP address, in the format of 4 decimals separated by dots

Example1: > ping xxx.xxx.xxx.xxx

Response: > ip: ping - reply received from xxx.xxx.xxx.xxx

Explanation: Successful ping

Example2: > ping 299.999

Response: > Invalid IP

Explanation: Invalid IP address

Example3: > ping xxx.xxx.xxx.xxx

Response: > ip: ping - no reply received

Explanation: Wrong IP address

## QUICK

*Enter a VC with RFC1483/bridge mode by an interactive user interface*

Syntax: quick

Parameters:

Example: > quick

Response: Please input vpi: 1[Enter]

Please input vci: 37[Enter]

Please choose package filter ( Any(a)/IP(i)/PPPOE(p) )

i [Enter]

Do you want to use spanning tree? <y/n>

y [Enter]

Configuration

MODE: Bridge

FUNCTION: R1483

Spanning Tree: Enable

#1 VPI VCI Packet filter

1. 1 37 IP

Do you want to preserve the configuration? <y/n>

y[Enter]

Type "save" to effect setting

### R1483

*Enter to R1483 menu. More commands under R1483 menu, see detail after.*

Syntax: r1483

Parameters:

Example: > r1483

### RESTART

*Reboot the SDSL modem*

Syntax: restart

Parameters:

Example: > restart

Response: NBfs5  
Helium Family PP flash boot 6.1.0.25 (22 October  
1999)  
(c) Copyright Virata 1999  
SDRAM size = 0x800000, type = 0x5  
Booting...  
>>  
System start...

### SAVE

*Save the configuration into flash memory, and restart modem*

Syntax: save

Parameters:

Example: > save

*Save configuration then restart modem*

### SDSL

*Enter to SDSL configuration menu. More commands under SDSL menu, see detail after.*

Syntax:	sdsl
Parameters:	
Example:	> dsdl

## SHOW

*Display the configuration of each enabled VC and Ethernet*

Syntax:	show
Parameters:	
Example:	> show

Response: Ethernet ip: 192.168.2.1  
Subnet mask: 255.255.255.0  
FUNCTION VPI VCI Spanning Pkt Filter  
Rfc1483 0 35 Disable ANY

Explanation: Information for Local Ethernet IP, subnet mask and each enabled VC

Ethernet IP (local).....192.168.2.1  
Subnet mask.....255.255.255.0  
Function (Protocol in use).....RFC1483  
VPI/VCI (Connected VC channel).....0/35  
Spanning (Spanning tree setting).....disable  
Pkt Filter (packet control).....Any  
(Allow to pass both IP and PPPOE packet.)  
  
(Note: IP – only allow to pass IP packet; PPPoE – only allow to pass PPPoE packet)

## VER

*Display the software version number*

Syntax:	ver
Parameters:	

Example: > ver

## **LAN MENU COMMANDS**

### **SETIP**

*Setup the IP address, and subnet mask for the Ethernet LAN connection*

Syntax:	setip <etherip>[<subnet mask>]
Parameters:	etherip: Ethernet IP address, in the format of 4 decimals separated by dot subnet mask: Subnet mask, the default is 255.255.255.0

Example: > lan> setip 192.168.2.32

*Set a new IP address = 192.168.2.32 and*

*Subnet mask is default = 255.255.255.0*

## **MANAGE MENU COMMANDS**

### **SETPASS**

*Change password*

Syntax:	setpass
Parameters:	Up to 18 alphanumeric characters. Upper case and lower case are different numbers.

Example 1: *For enabling a new password*

> manage> setpass

Response: The password is disabled!!

New Password: \*\*\*\*

Confirm password again: \*\*\*\*

Password has been changed and will be effective

only after save!

Saving configuration...Configuration saved.

Explanation: *You will be asked to key in new password and confirm the new password again.*

Example 2: *For changing old password:*

Response: 

```
> manage> setpass
Old Password: ****
New Password (press ENTER to disable): ****
Confirm password again: ****
Password has been changed!
```

Saving configuration...Configuration saved.

Explanation: *You will be asked to key in old password. Type the new password and confirm the new password again.*

Example 3: *For disabling old password:*

Response: 

```
> manage> setpass
Old Password: ****
New Password (press ENTER to disable):
Are you sure to disable password (y/n)?
The password has been disabled!
```

Saving configuration...Configuration saved.

Explanation: *You will be asked to key in old password and press enter to disable old password and confirm it again.*

## **R1483 MENU COMMANDS**

delpvc                      pfilter                      setpvc                      setspan

## DELPVC

*Disable a VC by giving a VPI and VCI numbers*

Syntax: `delpvc <all>[<vpi>]/<vci>`

Parameters: "all": disable all VCs

vpi: decimal value of VPI number, 0 to 127

vci: decimal value of VCI number, 0 to 1023

Example: `>r1483> delpvc 1/32`

*Disable VC=1/32 in configuration setting*

## PFILTER

*Packet filtering control on a specific VC*

Syntax: `pfilter [<vpi>]/<vci> <any|ip|pppoe>`

Parameters: vpi: decimal value of VPI number, 0 to 127. Defined by setpvc command previously

vci: decimal value of VCI number, 0 to 1023. Defined by setpvc command previously

"any": Allow to pass both IP and PPPOE packet

"ip": only allow to pass IP packet

"pppoe": only allow to pass PPPoE packet

Example: `>r1483> pfilter 1/32 ip`

*Configure VC 1/32 to filter IP packet only*

## SETPVC

*Enable a VC by giving the VCI and VPI numbers*

Syntax: `setpvc [<vpi>]/<vci>`

Parameters: vpi: decimal value of VPI number, 0 to 127

vci: decimal value of VCI number, 0 to 1023

Example: `>r1483> setpvc 1/32`

*Configure vpi=1 and vci= 32*

## SETSPAN

*Enable or disable Spanning Tree under Bridge mode for all enabled VC*

Syntax:	setspan <Enable> <Disable>
Parameters:	“Enable”: enable spanning tree “Disable”: disable spanning tree

Example: >r1483> setspan Disable  
*Disable spanning tree*

## SDSL MENU COMMANDS:

auto	cell	dbit	default
enable	rate	scramble	smbit
status	terminal	version	

## AUTO

*Enable auto-speed function to allow CPE to follow the speed of CO terminal or disable auto-speed function*

Syntax:	auto <disable> <enable>
Parameters:	“disable”: disable auto-baud rate function “enable”: enable auto-baud rate function

Example: >sdsl> auto enable  
*Enable auto-speed function.*

## CELL

*Enable or disable the idle-cell header*

Syntax:	cell <enable> <disable>
Parameters:	“enable”: enable idle-cell header “disable”: disable idle-cell header

Example: >sdsl> cell enable

## *Enable idle-cell header*

### **DBIT**

*Configure the SDSL data bit to normal or reverse polarity*

Syntax:        dbit <normal>|<reverse>

Parameters:    “normal”: configure data bit to normal polarity  
                  “reverse”: configure data bit to reverse polarity

Example:        >sdsl> dbit normal

*Configure data bit to normal polarity*

### **DEFAULT**

*Set SDSL configuration back to factory setting*

Syntax:        default

Parameters:

Example:        >sdsl> default

Response:      Set SDSL configuration back to factory setting

The default:

terminal       - cpe

auto           - disable

rate           - 2320

smbit          - reverse

dbit           - normal

scramble       - enable

cell           - enable

### **ENABLE**

*Activate the last updated SDSL parameters without saving and restarting system.*

Syntax:        enable



Parameters:

Example: >sdsl> enable

## RATE

*Manually configure the SDSL line rate*

Syntax: rate <n\*8>

Parameters: N\*8: 144 to 2320, decimal value of rate (Kbps), step by 8 Kbps; i.e. 160K = 20\*8K

Example 1: >sdsl> rate 160

*Set SDSL line rate to 160Kbps.*

Example 2: > sdsl> rate 155

Response: rate - Manually configure the SDSL line rate  
can use 144 <= (n\*8) <= 2320 K

## SCRAMBLE

*Enable/Disable scrambling on ATM cell*

Syntax: scramble <enable>|<disable>

Parameters: "enable": enable scrambling

"disable": disable scrambling

Example: >sdsl> scramble enable

*Enable scrambling on ATM cell*

## SMBIT

*Configure the sign/magnitude bit sequence*

Syntax: smbit <normal>|<reverse>

Parameters: "normal": normal sign/magnitude bit sequence

"reverse": reverse sign/magnitude bit sequence

Example: >sdsl> smbit normal

*Configure sign/magnitude bit to normal sequence*

## STATUS

*Display the configuration and status of current SDSL setting*

Syntax:        status  
Parameters:

Example:      >sdsl> status

Response:    Version: Ver 1.08 Date 15 May 2000

```
terminal      - cpe
auto          - disable
rate          - 2320
smbit         - reverse
dbit          - normal
scramble      - enable
cell          - enable
SDSL Module   -> enable
```

Status:

```
Bitpump F/W Version: 4.5
Bitpump: present
CO/RT Select: cpe
Auto Rate: disable
Rate: 2320
Sign/Magnitude Bit Sequence: reverse
Data Bit Polarity: normal
DSL Status: normal operation
Noise Margin: -16.0
```

Explanation: Information for SDSL configuration setting:

```
Version (SDSL driver version number).....Ver1.08
SDSL module (SDSL interface).....enable
(enable: normal operation, disable: malfunction)
```

Explanation: Information for SDSL line status:

```
Bitpump F/W version (SDSL firmware version
number).....4.5
Bitpump (status of chipset).....present
(present: normal operation, unrepresent: malfunction)
CO/RT select (terminal).....cpe
```

Auto rate (auto).....disable  
Rate (line rate).....2320Kbps  
Sign/magnitude bit sequence (smbit).....reverse  
Data bit polarity (dbit).....normal  
DSL status.....normal operation  
(normal operation: connected / during startup: without  
connection yet)  
Noise margin (noise margin after connection).....-16.0  
( “?” before connection)

### TERMINAL

*Configure modem to COE or CPE terminal*

Syntax:	terminal <coe> <cpe>
Parameters:	“coe”: central office equipment “cpe”: remote terminal

Example: >sdsl> terminal coe

*Configure unit as central office equipment, in order for  
point-to-point application*

### VERSION

*Display the SDSL firmware version*

Syntax:	version
Parameters:	

Example: >sdsl> version

## **Appendix C. Specifications**

### ***Hardware Specifications***

- LAN Interface
  - Type -- 10BaseT Ethernet, IEEE 802.3
  - Connector – 4 x RJ-45
- WAN -- SDSL Line I/F
  - Data Rate: 144Kbps to 2320Kbps
  - Rate adjustable step: 8Kbps
  - Line Code: 2B1Q
  - Line Impedance: 135  $\Omega$
  - Connection Loops: One Pair (2-wire)
  - Connector: RJ-11
- LED Indication
  - Power -- Green LED, indicate power status
  - Alarm -- Green LED, device error or operation in faulty status
  - Link -- Green LED, physical connection at LAN data link
  - Act -- Green LED, transmitting / receiving data over LAN data link.
  - WAN -- Green LED, SDSL data link status
  - Collision – Red LED, Ethernet collision indication
- OAM&P
  - Local: RS-232 Craft Port, Telnet via local Ethernet
  - Remote: SNMP, Telnet via SDSL
- Environment
  - Temperature: 0°C ~ 50°C
  - Humidity: 5% ~ 95%, NC

- 
- Physical Dimensions: (WxDxH) 220mm X 169mm X 40mm
- Electrical
  - AC Adapter: Input 110/220 VAC, 50/60Hz; Output 12VDC 1A
  - Power Consumption: Less than 10 Watts
- Safety -- UL & CE
  - EMC/EMI --
  - FCC
- Surge -- Meet IEC 1000-4-5 class 2

### ***Software Specifications***

- ATM
  - ATM Cell over SDSL, AAL5
  - 1 PVC for bridge
  - Support UBR & CBR
- Bridging
  - Transparent Bridging (IEEE 802.1D)
  - RFC 1483
  - Spanning Tree Protocol (IEEE 802.1D)
  - IP and/or PPPoE filtering
- Management
  - Telnet
  - SNMP MIB II
  - ILMI
  - TFTP