GUANTA COMPUTER INC.

QuantaMesh Layer 2/3/4 Managed Switch

User's Guide

Applicable Products

- * T5032-LY6
- * T3096-LY5

Edition April 2014



Comments... Suggestions... Corrections...

The User documentation Department would like to know your opinion on this manual. Your feedback helps us to optimize our documentation to suit your individual needs.

Fax forms for sending us your comments are included at the back of the manual.

There you will also find the addresses of the relevant User documentation Department.

Copyright and Trademarks

Copyright © 2014 Quanta Computer Inc.

All rights reserved.

Delivery subject to availability; right of technical modifications reserved.

All hardware and software names used are trademarks of their respective manufacturers.



Document History

Revision	Date	Remark
0.1	4/3/2014	First Edition
		-



CONTENTS

1		RODUCTION	10
	1.1	Product Overview	
	1.2	Features	12
	1.3	MANAGEMENT OPTIONS	14
	1.4	COMMAND LINE CONSOLE INTERFACE THROUGH THE SERIAL PORT OR TELNET	14
	1.5	SNMP-Based Management	15
2	INS [.]	TALLATION AND QUICK STARTUP	18
	2.1	PACKAGE CONTENTS	
	2.2	Switch Installation	
	2.3	INSTALLING THE SWITCH IN A RACK	20
	2.4	QUICK STARTING THE SWITCH	21
	2.5	System Information Setup	22
	2.5.	1 Quick Start up Software Version Information	
	2.5.	2 Quick Start up Physical Port Data	
	2.5.		
	2.5.		
	2.5.	5 Quick Start up Uploading from Switch to Out-of-Band PC	25
	2.5.		
	2.5.		
	2.5.	8 Quick Start up Factory Defaults	26
3	CON	NSOLE AND TELNET ADMINISTRATION INTERFACE	27
	3.1	LOCAL CONSOLE MANAGEMENT	27
	3.2	SET UP YOUR SWITCH USING CONSOLE ACCESS	
	3.3	SET UP YOUR SWITCH USING TELNET ACCESS	
	3.3.		
		A = A = A = A = A = A = A = A = A = A =	29
	3.3.		
4	3.3.		29
4	3.3.	2 Using the Service Port or Netowrk Interface for Remote Management	29 31
4	3.3. CON	2 Using the Service Port or Netowrk Interface for Remote Management	29 31 31
4	3.3. CON 4.1 4.2	2 Using the Service Port or Netowrk Interface for Remote Management MMAND LINE INTERFACE STRUCTURE AND MODE-BASED CLI CLI COMMAND FORMAT	29 31 31 32
-	3.3. CON 4.1 4.2	2 Using the Service Port or Netowrk Interface for Remote Management MMAND LINE INTERFACE STRUCTURE AND MODE-BASED CLI CLI COMMAND FORMAT CLI MODE-BASED TOPOLOGY ITCHING COMMANDS	29 31 32 34
-	3.3. CON 4.1 4.2 SWI 5.1	2 Using the Service Port or Netowrk Interface for Remote Management MMAND LINE INTERFACE STRUCTURE AND MODE-BASED CLI CLI COMMAND FORMAT CLI MODE-BASED TOPOLOGY ITCHING COMMANDS System Information and Statistics commands	29 31 32 34 34
-	3.3. COM 4.1 4.2 SWM 5.1 5.1.	2 Using the Service Port or Netowrk Interface for Remote Management MMAND LINE INTERFACE STRUCTURE AND MODE-BASED CLI CLI COMMAND FORMAT CLI MODE-BASED TOPOLOGY ITCHING COMMANDS System Information and Statistics commands	29 31 32 34 34 34
-	3.3. CON 4.1 4.2 SWI 5.1	2 Using the Service Port or Netowrk Interface for Remote Management MMAND LINE INTERFACE STRUCTURE AND MODE-BASED CLI CLI COMMAND FORMAT. CLI MODE-BASED TOPOLOGY ITCHING COMMANDS System Information and Statistics commands 1 show arp 2 show calendar	29 31 32 34 34 34 34 34 35
-	3.3. CON 4.1 4.2 SWI 5.1 5.1. 5.1.	 Using the Service Port or Netowrk Interface for Remote Management MMAND LINE INTERFACE STRUCTURE AND MODE-BASED CLI CLI COMMAND FORMAT CLI MODE-BASED TOPOLOGY INTCHING COMMANDS SYSTEM INFORMATION AND STATISTICS COMMANDS	29 31 32 34 34 34 34 35 36
-	3.3. CON 4.1 4.2 SWI 5.1 5.1. 5.1. 5.1.	 Using the Service Port or Netowrk Interface for Remote Management MMAND LINE INTERFACE STRUCTURE AND MODE-BASED CLI CLI COMMAND FORMAT CLI MODE-BASED TOPOLOGY INTCHING COMMANDS	
-	3.3. CON 4.1 4.2 SWI 5.1 5.1. 5.1. 5.1. 5.1.	 Using the Service Port or Netowrk Interface for Remote Management MMAND LINE INTERFACE STRUCTURE AND MODE-BASED CLI CLI COMMAND FORMAT CLI MODE-BASED TOPOLOGY INTCHING COMMANDS	29 31 32 34 34 34 35 36 38 38 39
-	3.3. CON 4.1 4.2 SWI 5.1 5.1. 5.1. 5.1. 5.1. 5.1.	 Using the Service Port or Netowrk Interface for Remote Management MMAND LINE INTERFACE STRUCTURE AND MODE-BASED CLI CLI COMMAND FORMAT. CLI MODE-BASED TOPOLOGY ITCHING COMMANDS SYSTEM INFORMATION AND STATISTICS COMMANDS show arp show calendar show process cpu show eventlog show running-config show sysinfo 	29 31 32 34 34 34 34 34 35 36 38 39 40
-	3.3. CON 4.1 4.2 SWN 5.1 5.1. 5.1. 5.1. 5.1. 5.1. 5.1. 5.1.	 Using the Service Port or Netowrk Interface for Remote Management	29 31 32 34 34 34 34 34 36 36 36 39 40 41
-	3.3. CON 4.1 4.2 SWN 5.1 5.1. 5.1. 5.1. 5.1. 5.1. 5.1. 5.1. 5.1.	 Using the Service Port or Netowrk Interface for Remote Management	29 31 32 34
-	3.3. CON 4.1 4.2 SWH 5.1 5.1.	 Using the Service Port or Netowrk Interface for Remote Management MMAND LINE INTERFACE STRUCTURE AND MODE-BASED CLI CLI COMMAND FORMAT	29 31 32 34 34 34 34 34 35 36 38 39 40 41 42 43
-	3.3. CON 4.1 4.2 SWI 5.1 5.1.	2 Using the Service Port or Netowrk Interface for Remote Management MMAND LINE INTERFACE STRUCTURE AND MODE-BASED CLI CLI COMMAND FORMAT. CLI MODE-BASED TOPOLOGY ITCHING COMMANDS SYSTEM INFORMATION AND STATISTICS COMMANDS 1 show arp 2 show calendar 3 show process cpu 4 show eventlog 5 show sysinfo 7 show system 8 show tech-support 9 show version	29 31 32 34 34 34 34 34 35 36 38 38 39 40 41 42 43 45
-	3.3. CON 4.1 4.2 SWI 5.1 5.1.	2 Using the Service Port or Netowrk Interface for Remote Management	29 31 32 34 34 34 34 34 34 34 34 34 36 38 39 40 41 43 45 46
-	3.3. CON 4.1 4.2 SWN 5.1 5.1.	2 Using the Service Port or Netowrk Interface for Remote Management MMAND LINE INTERFACE STRUCTURE AND MODE-BASED CLI CLI COMMAND FORMAT. CLI MODE-BASED TOPOLOGY ITCHING COMMANDS SYSTEM INFORMATION AND STATISTICS COMMANDS 1 show arp 2 show calendar 3 show ventlog 5 show ventlog 6 show sysinfo 7 show system 8 show tech-support 9 show version 10 show version 11 show command filter	29 31 32 34 34 34 34 34 35 36 36 36 36 39 40 41 42 45 46 47
-	3.3. CON 4.1 4.2 SWN 5.1 5.1.	2 Using the Service Port or Netowrk Interface for Remote Management VMAND LINE INTERFACE STRUCTURE AND MODE-BASED CLI CLI COMMAND FORMAT. CLI MODE-BASED TOPOLOGY ITCHING COMMANDS SYSTEM INFORMATION AND STATISTICS COMMANDS 1 show arp 2 show calendar 3 show ventlog 5 show ventlog 6 show sysinfo 7 show system 8 show tech-support 9 show version 10 show version 11 show command filter	29 31 32 34 34 34 34 34 34 34 34 36 36 36 36 36 36 36 36 40 41 42 43 45 46 48
-	3.3. CON 4.1 4.2 SWN 5.1 5.1.	2 Using the Service Port or Netowrk Interface for Remote Management MMAND LINE INTERFACE STRUCTURE AND MODE-BASED CLI CLI COMMAND FORMAT. CLI MODE-BASED TOPOLOGY ITCHING COMMANDS System INFORMATION AND STATISTICS COMMANDS 1 show arp 2 show calendar 3 show process cpu 4 show eventlog 5 show running-config 6 show sysinfo 7 show system 8 show tech-support 9 show hardware 10 show version 11 show loginsession 12 show command filter 13 Digital Optical Monitor DEVICE CONFIGURATION COMMANDS 1	29 31 32 34 34 34 34 34 35 36 36 38 39 40 41 42 43 45 46 48 50 50
-	3.3. CON 4.1 4.2 SWH 5.1 5.1. 5.2	2 Using the Service Port or Netowrk Interface for Remote Management MMAND LINE INTERFACE STRUCTURE AND MODE-BASED CLI CLI COMMAND FORMAT. CLI MODE-BASED TOPOLOGY ITCHING COMMANDS SYSTEM INFORMATION AND STATISTICS COMMANDS 1 show arp 2 show calendar 3 show process cpu 4 show eventlog 5 show running-config 6 show sysinfo 7 show system 8 show tech-support 9 show version 11 show loginsession 12 show command filter 13 Digital Optical Monitor DEVICE CONFIGURATION COMMANDS 1	29 31 32 34 34 34 34 34 35 36 36 38 39 40 41 42 43 45 46 48 50 50

5.2.4	Double VLAN commands	
5.2.5	GVRP and Bridge Extension	105
5.2.6	IGMP Snooping	
5.2.7	IGMP Snooping Querier	132
5.2.8	MLD Snooping	139
5.2.9	MLD Snooping Querier	153
5.2.10	Port Channel	160
5.2.11	Storm Control	176
5.2.12	L2 Priority	185
5.2.13	Port Mirror	187
5.2.14	Link State	190
5.2.15	Port Backup	193
5.2.16	Expandable Port Configuration	195
5.3 MA	NAGEMENT COMMANDS	
5.3.1	Network Commands	
5.3.2	Serial Interface Commands	
5.3.3	Telnet Session Commands	
5.3.4	SSH Client Session Commands	
5.3.5	SNMP Server Commands	
5.3.6	SNMP Trap Commands	
5.3.7	SNMP Inform Commands	
5.3.8	Secure Shell (SSH) Commands	
5.3.9	Management Security Commands	
5.3.10	DHCP Client Commands	
5.3.11	DHCPv6 Client Commands	
5.3.12	DHCP Relay Commands	
5.3.12	sFlow Commands	
5.3.13 5.3.14	Service Port Commands	
5.3.14 5.3.15	Time Range Commands	
	Command Scheduler Commands	
5.3.16		
	NNING TREE COMMANDS	
5.4.1	Show Commands	
5.4.2	Configuration Commands	
	TEM LOG MANAGEMENT COMMANDS	
5.5.1	Show Commands	
5.5.2	Configuration Commands	
	AIL ALERTING AND MAIL SERVER COMMANDS	
5.6.1	Show Commands	
5.6.2	Configuration Commands	
	IPT MANAGEMENT COMMANDS	-
5.7.1	script apply	
5.7.2	script delete	
5.7.3	script show	
5.7.4	script validate	
	R ACCOUNT MANAGEMENT COMMANDS	
5.8.1	Show Commands	
5.8.2	Configuration Commands	
	URITY COMMANDS	
5.9.1	Show Commands	
5.9.2	Configuration Commands	
5.9.3	Dot1x Configuration Commands	
5.9.4	Interface ConfigRadius Configuration Commands	371
5.9.5	TACACS+ Configuration Commands	
5.9.6	Port Security Configuration Commands	384

5.9.7	Denial Of Service Commands	388
5.10 CD	P (CISCO DISCOVERY PROTOCOL) COMMANDS	
5.10.1	Show Commands	
5.10.2	Configuration Commands	
5.11 SN	TP (SIMPLE NETWORK TIME PROTOCOL) COMMANDS	
5.11.1	Show Commands	
5.11.2	Configuration Commands	
	DP (LINK LAYER DISCOVERY PROTOCOL) COMMANDS	
5.12.1	Show Commands	
5.12.2	Configuration Commands	
0.22.2	P (VLAN TRUNKING PROTOCOL) COMMANDS	
5.13.1	Show Commands	
5.13.1	Configuration Commands	
	DTECTED PORTS COMMANDS	
5.14 PRC 5.14.1	Show Commands	
5.14.1 5.14.2		
	Configuration Commands TIC MAC FILTERING COMMANDS	
		-
5.15.1	Show Commands	
5.15.2	Configuration Commands	
	TEM UTILITIES	
5.16.1	clear	
5.16.2	сору	
5.16.3	delete	
5.16.4	dir	
5.16.5	whichboot	
5.16.6	boot-system	
5.16.7	ping	481
5.16.8	traceroute	
5.16.9	logging cli-command	486
5.16.10	calendar set	487
5.16.11	reload	487
5.16.12	configure	488
5.16.13	disconnect	488
5.16.14	hostname	489
5.16.15	quit	489
5.16.16	cablestatus	490
5.16.17	AutoInstall Commands	491
5.16.18	Capture CPU packet Commands	495
5.17 DH	CP SNOOPING COMMANDS	
5.17.1	Show Commands	501
5.17.2	Configuration Commands	
5.18 IP 9	Source Guard (IPSG) Commands	
5.18.1	Show Commands	
5.18.2	Configuration Commands	
	JAMIC ARP INSPECTION (DAI) COMMAND	
5.19.1	Show Commands	
5.19.2	Configuration Commands	
	FERENTIATED SERVICE COMMAND	
5.20	General Commands	
5.20.1	Class Commands	
5.20.2	Policy Commands	
5.20.3	Service Commands	
5.20.4 5.20.5	Service Commands	
	L COMMAND	
J.ZI AU		

5.21.1	Show Commands	
5.21.2	Configuration Commands	583
5.22 IPv	6 ACL COMMAND	593
5.22.1	Show Commands	593
5.22.2	Configuration Commands	595
5.23 Co	S (Class of Service) Command	599
5.23.1	Show Commands	599
5.23.2	Configuration Commands	604
5.24 Au	TO-VOICE OVER IP COMMANDS	610
5.24.1	Show Commands	611
5.24.2	Configuration Commands	612
5.25 ISC	SI Optimization Commands	613
5.25.1	Show Commands	613
5.25.2	Configuration Commands	615
5.26 Do	MAIN NAME SERVER RELAY COMMANDS	619
5.26.1	Show Commands	
5.26.2	Configuration Commands	
5.27 UD	LD COMMANDS	
5.27.1	Show command	630
5.27.2	Configuration Commands	
	JLTI CHASSIS LINK AGGREGATION COMMANDS	
5.28.1	Show Commands	
5.28.2	Configuration Commands	
	NTROL PLANE PROTECTION COMMANDS	
5.29.1	Show Commands	
5.29.2	Configuration Commands	
6 ROUTIN		
	IG COMMANDS	
	DRESS RESOLUTION PROTOCOL (ARP) COMMANDS	
		645
6.1 AD	DRESS RESOLUTION PROTOCOL (ARP) COMMANDS	645 645
6.1 AD <i>6.1.1</i> <i>6.1.2</i>	dress Resolution Protocol (ARP) Commands Show Commands	645 645 648
6.1 AD <i>6.1.1</i> <i>6.1.2</i>	DRESS RESOLUTION PROTOCOL (ARP) COMMANDS Show Commands Configuration Commands	645 645 648 653
6.1 AD <i>6.1.1</i> <i>6.1.2</i> 6.2 IP I	DRESS RESOLUTION PROTOCOL (ARP) COMMANDS Show Commands Configuration Commands ROUTING COMMANDS	
6.1 AD 6.1.1 6.1.2 6.2 IP I 6.2.1 6.2.2	DRESS RESOLUTION PROTOCOL (ARP) COMMANDS Show Commands Configuration Commands ROUTING COMMANDS Show Commands	
6.1 AD 6.1.1 6.1.2 6.2 IP I 6.2.1 6.2.2	DRESS RESOLUTION PROTOCOL (ARP) COMMANDS Show Commands Configuration Commands ROUTING COMMANDS Show Commands Configuration Commands	
 6.1 AD 6.1.1 6.1.2 6.2 IP I 6.2.1 6.2.2 6.3 OP 	DRESS RESOLUTION PROTOCOL (ARP) COMMANDS Show Commands Configuration Commands ROUTING COMMANDS Show Commands Configuration Commands EN SHORTEST PATH FIRST (OSPF) COMMANDS	
 6.1 AD 6.1.1 6.1.2 6.2 IP I 6.2.1 6.2.2 6.3 OP 6.3.1 6.3.2 	DRESS RESOLUTION PROTOCOL (ARP) COMMANDS Show Commands Configuration Commands ROUTING COMMANDS Show Commands Configuration Commands EN SHORTEST PATH FIRST (OSPF) COMMANDS Show Commands	
 6.1 AD 6.1.1 6.1.2 6.2 IP I 6.2.1 6.2.2 6.3 OP 6.3.1 6.3.2 	DRESS RESOLUTION PROTOCOL (ARP) COMMANDS	
 6.1 AD 6.1.1 6.1.2 6.2 IP I 6.2.1 6.2.2 6.3 OP 6.3.1 6.3.2 6.4 BO 	DRESS RESOLUTION PROTOCOL (ARP) COMMANDS	
 6.1 AD 6.1.1 6.1.2 6.2 IP I 6.2.1 6.2.2 6.3 OP 6.3.1 6.3.2 6.4 BO 6.4.1 6.4.2 	DRESS RESOLUTION PROTOCOL (ARP) COMMANDS	
 6.1 AD 6.1.1 6.1.2 6.2 IP I 6.2.1 6.2.2 6.3 OP 6.3.1 6.3.2 6.4 BO 6.4.1 6.4.2 	DRESS RESOLUTION PROTOCOL (ARP) COMMANDS	
 6.1 AD 6.1.1 6.1.2 6.2 IP I 6.2.1 6.2.2 6.3 OP 6.3.1 6.3.2 6.4 BO 6.4.1 6.4.2 6.5 IP I 6.5.1 	DRESS RESOLUTION PROTOCOL (ARP) COMMANDS	
 6.1 AD 6.1.1 6.2.2 6.2.1 6.2.2 6.3 OP 6.3.1 6.3.2 6.4 BO 6.4.1 6.4.2 6.5 IP I 6.5.1 6.5.2 	DRESS RESOLUTION PROTOCOL (ARP) COMMANDS	
 6.1 AD 6.1.1 6.1.2 6.2 IP I 6.2.1 6.2.2 6.3 OP 6.3.1 6.3.2 6.4 BO 6.4.1 6.4.2 6.5 IP I 6.5.1 6.5.2 6.6 RO 	DRESS RESOLUTION PROTOCOL (ARP) COMMANDS	
 6.1 AD 6.1.1 6.1.2 6.2 IP I 6.2.1 6.2.2 6.3 OP 6.3.1 6.3.2 6.4 BO 6.4.1 6.4.2 6.5 IP I 6.5.1 6.5.2 6.6 RO 6.6.1 	DRESS RESOLUTION PROTOCOL (ARP) COMMANDS	
 6.1 AD 6.1.1 6.1.2 6.2 IP I 6.2.1 6.2.2 6.3 OP 6.3.1 6.3.2 6.4 BO 6.4.1 6.4.2 6.5 IP I 6.5.1 6.5.2 6.6 RO 6.6.1 6.6.2 	DRESS RESOLUTION PROTOCOL (ARP) COMMANDS	
 6.1 AD 6.1.1 6.2 IP 6.2.1 6.2.2 6.3 OP 6.3.1 6.3.2 6.4 BO 6.4.1 6.4.2 6.5 IP 6.5.1 6.5.2 6.6 RO 6.6.1 6.6.2 6.7 RO 	DRESS RESOLUTION PROTOCOL (ARP) COMMANDS	
 6.1 AD 6.1.1 6.2.2 6.2 IP I 6.2.2 6.3 OP 6.3.1 6.3.2 6.4 BO 6.4.1 6.4.2 6.5 IP I 6.5.1 6.5.2 6.6 RO 6.6.1 6.6.2 6.7 RO 6.7.1 	DRESS RESOLUTION PROTOCOL (ARP) COMMANDS	
 6.1 AD 6.1.1 6.1.2 6.2 IP I 6.2.1 6.2.2 6.3 OP 6.3.1 6.3.2 6.4 BO 6.4.1 6.4.2 6.5 IP I 6.5.1 6.5.2 6.6 RO 6.6.1 6.6.2 6.7 RO 6.7.1 6.7.2 	DRESS RESOLUTION PROTOCOL (ARP) COMMANDS	
 6.1 AD 6.1.1 6.1.2 6.2 IP I 6.2.1 6.2.2 6.3 OP 6.3.1 6.3.2 6.4 BO 6.4.1 6.4.2 6.5 IP I 6.5.1 6.5.2 6.6 RO 6.6.1 6.6.2 6.7 RO 6.7.1 6.7.2 6.8 VL 	DRESS RESOLUTION PROTOCOL (ARP) COMMANDS	
 6.1 AD 6.1.1 6.1.2 6.2 IP I 6.2.1 6.2.2 6.3 OP 6.3.1 6.3.2 6.4 BO 6.4.1 6.4.2 6.5 IP I 6.5.1 6.5.2 6.6 RO 6.6.1 6.6.2 6.7 RO 6.7.1 6.7.2 6.8 VLI 6.8.1 	DRESS RESOLUTION PROTOCOL (ARP) COMMANDS	645 645 648 653 653 675 675 675 724 724 724 725 728 730 733 733 736 745 745 749 749
 6.1 AD 6.1.1 6.1.2 6.2 IP I 6.2.1 6.2.2 6.3 OP 6.3.1 6.3.2 6.4 BO 6.4.1 6.4.2 6.5 IP I 6.5.1 6.5.2 6.6 RO 6.6.1 6.6.2 6.7 RO 6.7.1 6.7.2 6.8 VLI 6.8.1 6.9 VIR 	DRESS RESOLUTION PROTOCOL (ARP) COMMANDS	
 6.1 AD 6.1.1 6.1.2 6.2 IP I 6.2.1 6.2.2 6.3 OP 6.3.1 6.3.2 6.4 BO 6.4.1 6.4.2 6.5 IP I 6.5.1 6.5.2 6.6 RO 6.6.1 6.6.2 6.7 RO 6.7.1 6.7.2 6.8 VLI 6.8.1 	DRESS RESOLUTION PROTOCOL (ARP) COMMANDS	

	6.10 Poli	CY BASED ROUTING (PBR) COMMANDS	763
	6.10.1	Show Commands	. 763
	6.10.2	Configuration Commands	. 765
	6.11 BOR	DER GATEWAY PROTOCOL (BGP) COMMANDS	778
	6.11.1	Show Commands	. 778
	6.11.2	Configuration Commands	. 798
7		CAST COMMANDS	819
	7.1 DIST	ANCE VECTOR MULTICAST ROUTING PROTOCOL (DVMRP) COMMANDS	819
	7.1.1	Show Commands	
	7.1.2	Configuration Commands	
	7.2 INTE	RNET GROUP MANAGEMENT PROTOCOL (IGMP) COMMANDS	
	7.2.1	Show Commands	
	7.2.2	Configuration Commands	
	7.3 MLC	COMMANDS	
	7.3.1	Show Commands	. 839
	7.3.2	Configuration Commands	
	7.4 Mul	TICAST COMMANDS	
	7.4.1	Show Commands	847
	7.4.2	Configuration Commands	. 853
	7.5 IPv4	PROTOCOL INDEPENDENT MULTICAST (PIM) COMMANDS	
	7.5.1	Show Commands	856
	7.5.2	Configuration Commands	. 863
	7.6 IPv6	PROTOCOL INDEPENDENT MULTICAST COMMANDS	871
	7.6.1	Show Commands	. 871
	7.6.2	Configuration Commands	. 878
	7.7 IGM	P Proxy Commands	886
	7.7.1	Show Commands	. 886
	7.7.2	Configuration Commands	. 890
	7.8 MLC	PROXY COMMANDS	892
	7.8.1	Show Commands	. 892
	7.8.2	Configuration Commands	. 896
8	IPV6 CON	/IMANDS	898
	8.1 TUN	NEL INTERFACE COMMANDS	898
	8.1.1	Show Commands	
	8.1.2	Configuration Commands	
	-	PBACK INTERFACE COMMANDS	
	8.2.1	Show Commands	
	8.2.2	Configuration Commands	
	8.3 IPv6	ROUTING COMMANDS	
	8.3.1	Show Commands	
	8.3.2	Configuration Commands	
	8.4 OSP	Fv3 Commands	930
	8.4.1	Show Commands	
	8.4.2	Configuration Commands	
		IG COMMANDS	
	8.5.1	Show Commands	972
	8.5.2	Configuration Commands	
	8.6 Rou	TING POLICY COMMANDS	
	8.6.1	Show Commands	
	8.6.2	Configuration Commands	
9	DATA CF	NTER BRIDGING COMMANDS	985
-			

GUANTA COMPUTER INC.

9.1 FI	P SNOOPING	
9.1.1	show dcb fip-snooping	
9.1.2	show fip-snooping enode	
9.1.3	show dcb fip-snooping session	
9.1.4	show dcb fip-snooping fcf	
9.1.5	show dcb fip-snooping vlan	
9.1.6	fip-snooping	
9.1.7	fip-snooping vlan	
9.2 Pr	RIORITY-BASED FLOW CONTROL	
9.2.1	show dcb priority-flow-control	
9.2.2	priority-flow-control mode	
9.2.3	priority-flow-control priority	
9.2.4	clear priority-flow-control statistics	
9.3 Er	NHANCED TRANSMISSION SELECTION (ETS)	
9.3.1	show dcb ets classofservice traffic-class-group	
9.3.2	show dcb ets traffic-class-group	
9.3.3	ets classofservice traffic-class-group	
9.3.4	ets traffic-class-group max-bandwidth	
9.3.5	ets traffic-class-group min-bandwidth	
9.3.6	ets traffic-class-group strict	
9.3.7	ets traffic-class-group weight	
9.4 E1	THERNET VIRTUAL BRIDGING	
9.4.1	show evb status	
9.4.2	show evb status	
9.4.3	show evb vsi-profile	
9.4.4	evb enable	
9.4.5	evb rte	
9.5 V	M TRACER COMMANDS	
9.5.1	Show Commands	
9.5.2	Configuration Commands	
	NFLOW COMMANDS	
	HOW COMMANDS	
10.1.1		
10.1.2		
10.1.3		
10.1.4	1 5	
10.1.5	show openflow table status	
	ONFIGURATION COMMANDS	
10.2.1	OpenFlow Instance	
10.2.2		
10.2.3	OpenFlow Controller	
10.2.4		
10.2.5	OpenFlow VLAN in Per-VLAN mode instance	
10.2.6	OpenFlow PORT in Per-PORT mode instance	
10.2.7		
10.2.8		
10.2.9	OpenFlow ignore-legacy-protocol	

1 Introduction

1.1 Product Overview

The QuantaMesh Top-of-Rack (ToR) Ethernet switch provides high performance, high availability and simplicity management. They are designed for adaptability and scalability for campus and data center. The hardware configuration of each product is listed in Table 1.

	Feature/Model	T5032-LY6	T3096-LY5	T3048-LY8
	10/100/1000 Mbps RJ-45 ports	-	-	-
	10G Base-T ports	-		-
Product	1 GbE SFP ports	-	-	-
Config	10 GbE SFP+ ports	-	96	48
	40 GbE QSFP ports	32	-	4+2(optional)
	100 GbE ports	-	-	-
	1 GbE SerDes downlinks	-	-	-
Switching bandwidth (data rate, full duplex)		2560Gbps	1920Gbps	1280/1440Gbps
	Console Port	1 (RJ-45 Type)	1 (RJ-45 Type)	1 (RJ-45 Type)
Special ports	Management Port	1 (10/100/1000Mbps)	1 (10/100/1000Mbps)	1 (10/100/1000Mbps)
	USB Port	1(USB2.0)	1(USB2.0)	1(USB2.0)
	Cooling Fans	3(hotswapable)	4(hotswapable)	3(hotswapable)
Fans/Air flow	Air Flow	Front-to-Rear or Rear-to-Front	Front-to-Rear or Rear-to-Front	Front-to-Rear or Rear-to-Front
Power/PS U	Hot-Swap PSU (redundant power)	1+1 AC-DC Redundant power supply(90-264 VAC input; 12VDC/36A Output)	1+1 AC-DC Redundant power supply(90-264 VAC input; 12VDC/62A Output)	1+1 AC-DC Redundant power supply(90-264 VAC input; 12VDC/36A Output)

Table 1. Product Configuration



Simplicity

The QuantaMesh switch can be managed through industry standard command-line interface (CLI) which reduces the training and operating costs. It supports Simple Network Management Protocol (SNMP) both from standard MIB and private MIB for network administrator to easily configure, monitor, and manage remotely. The Auto-installation feature implemented helps centralized management to simplify deployment of a truly plug-and-play experience. With the evolution from IPv4 to IPv6, the QuantaMesh switch is a IPv6 integrated management device.

High Availability

The QuantaMesh switch is designed for high availability from both hardware and software perspective. The key features include:

- 1+1 hot-swappable power supplies
- Out-of-band management supported
- 802.1D, 802.1w and 802.1s supported
- Up to 32 ports per link aggregation group (LACP) and up to 64 groups
- Multi-chassis LAG (MLAG) for preventing the risks of single point failure
- Up to 32 paths ECMP routing for load balancing and redundancy
- Virtual Router Redundancy Protocol (VRRP) supported

High-Performance L2/L3 access deployments

With the compact 1U form factor, high desity ports in the front panel, fron to back or back to front airflow design, the QuantaMesh switch is idea for top-of-rack deployments in high-performance, highly demanding data centers. The high switching capacity to be a powerful solution to aggregate high-performance servers in the data center.

Advance IPv4 and IPv6 Routing

The QuantaMesh switch is a full layer 2 and layer 3 routing switch that supports advanced IPv4 and IPv6 routing features such as RIP v1/v2, OSPF/ECMP, RIPng and OSPFv3. The multicast routing features for IGMP v1/v2/v3, DVMRP, PIM-DM.SM, MLD v1/v2 and PIM-DM6/SM6 are all supported.

Data Center Application

The QuantaMesh switch is an IEEE DCB-based switch delivering a high-performance solution to integrate server edge access. The key features include:

- Congestion Notification (CN, 802.1Qau)
- Enhanced Transmission Selection (ETS, 802.1Qaz)
- Priority-based Flow Control (PFC, 802.1Qbb)
- Data Center Bridging Extension (DCBX, 802.1Qaz)
- FCoE Initiation Protocol (FIP) snooping
- Ethernet Virtual Bridging (EVB, 802.1Qbg)

GUANTA COMPUTER INC.

1.2 Features

- IEEE 802.3z and IEEE 802.3x compliant Flow Control for all ethernet ports
- Supports 802.1D STP, 802.1S MSTP, and 802.1w Rapid Spanning Tree for redundant back up bridge paths
- Supports 802.1Q VLAN, Protocol-based VLAN, Subnet-based VLAN, MAC-based VLAN, Protected Port, Double VLAN, Voice VLAN, GVRP, GMRP, IGMP snooping, 802.1p Priority Queues, Port Channel, port mirroring
- Link Agregation (802.1ad LACP)
- Multi-chassis Link Aggregation (MLAG)
- Supports VTP (VLAN Trunking Protocol)
- Supports CDP
- Supports LLDP with potential communication problems detection
- Supports Port Security
- Multi-layer Access Control (based on MAC address, IP address, VLAN, Protocol, 802.1p, DSCP)
- Quality of Service (QoS) customized control
- AAA support
- 802.1x access control and RADIUS client support
- TACACS+ support
- UDLD support
- Error Disable Recovery support
- Supports DHCP Snooping
- Dynamic ARP Inspection (DAI) and IP Source Guard (IPSG)
- IP ARP support
- IP Routing support
- VLAN Routing support
- OSPF v2 and v3 support
- RIP v1/v2 and RIPng support
- BGP4 support
- Router Discovery Protocol support
- Virtual Router Redundancy Protocol (VRRP) support
- 32-way ECMP support
- /31 subnets support
- Source IP configuration support
- Poilcy Based Routing (PBR)
- IP Multicast support

- IGMP v1, v2, and v3 support
- DVMRP support
- Protocol Independent Multicast Dense Mode (PIM-DM) support for IPv4 and IPv6
- Protocol Independent Multicast Sparse Mode (PIM-SM) support for IPv4 and IPv6
- IPv6 function Supports DHCPv6 protocol, OSPFv3 protocol, Tunneling, loopback Provides to configure IPv6 rotuing interface, routing preference
- DHCP Client and Relay support
- IP Helper (BOOTP/DHCP Relay)
- DNS Client and Relay support
- Per-port bandwidth control
- iSCSI Optimization support
- Auto VoIP support
- SNMP v1, v2, v3 network management, RMON support
- CLI management support
- Fully configurable either in-band or out-of-band control via RS-232 console serial connection
- Telnet remote control console
- TraceRoute support
- Traffic Segmentation
- TFTP/FTP/SCP/SFTP upgrade
- SysLog support
- Email Alerting support
- Simple Network Time Protocol support
- SSH Secure Shell version 1 and 2 support
- SSL Secure HTTP TLS Version 1 and SSL version 3 support
- Auto Install support
- Fibre Channel Over Ethernet(FCoE) FIP Snooping
- Data Center Bridge (DCB) Enhanced Transmission Selection (ETS, IEEE 802.1Qaz) Priority Flow Control (PFC, IEEE 802.1Qbb)
- Data Center Bridge Exchange (DCBX, IEEE802.1Qaz)
- Ethenet Virtual Bridge (EVB) VEB/VEPA bridge support
- OpenFlow support
- Control Plane Protection (CoPP)

1.3 Management Options

The system may be managed by using one Service Ports through a Telnet, SNMP function and using the console port on the front panel through CLI command.

1.4 Command Line Console Interface through the Serial Port or Telnet

You can also connect a computer or terminal to the serial console port or use Telnet to access the Switch. The command-line-driven interface provides complete access to all switch management features.

1.5 SNMP-Based Management

You can manage the Switch with an SNMP-compatible console program. The Switch supports SNMP version 1.0, version 2.0, and version 3.0. The SNMP agent decodes the incoming SNMP messages and responds to requests with MIB objects stored in the database. The SNMP agent updates the MIB objects to generate statistics The Switch supports a comprehensive set of MIB extensions:

- RFC1493 Bridge
- RFC 2819 RMON-MIB
- RFC 2233 Interface MIB
- RFC 2618 (Radius-Auth-Client-MIB)
- RFC 2620 (Radius-Acc-Client-MIB)
- RFC 1724 (RIPv2-MIB)
- RFC 1850 (OSPF-MIB)
- RFC 1850 (OSPF-TRAP-MIB)
- RFC 2787 (VRRP-MIB)
- RFC 3289 DIFFSERV-DSCP-TC
- RFC 3289 DIFFSERV-MIB
- QoS-DIFFSERV-EXTENSIONS-MIB
- QoS-DIFFSERV-PRIVATE-MIB
- RFC 2674 802.1p
- RFC 2932 (IPMROUTE-MIB)
- Quanta Enterprise MIB
- ROUTING-MIB
- MGMD-MIB
- RFC 2934 PIM-MIB
- DVMRP-STD-MIB
- IANA-RTPROTO-MIB
- MULTICAST-MIB
- ROUTING6-MIB
- IEEE8021-PAE-MIB
- INVENTORY-MIB
- MGMT-SECURITY-MIB
- QoS-MIB
- QoS-ACL-MIB
- QoS-COS-MIB
- QoS-AUTOVOIP-MIB

GUANTA COMPUTER INC.

- QoS-DIFFSERV-PRIVATE-MIB
- QoS-ISCSI-MIB
- RFC 1907 SNMPv2-MIB
- RFC 2465 IPV6-MIB
- RFC 2466 IPV6-ICMP-MIB
- TACACS-MIB
- IGMP/MLD Snooping
- IGMP/MLD Layer2 Multicast
- QoS IPv6 ACL
- Voice VLAN
- Guest VLAN
- LLDP-MIB
- LLDP MED
- RFC 2925 (DISMAN-TRACEROUTE-MIB)
- RFC 2080 (RIPng)
- OSPFV3-MIB
- RFC 2571 SNMP-FRAMEWORK-MIB
- RFC 2572 SNMP-MPD-MIB
- RFC 2573 SNMP-NOTIFICATION-MIB
- RFC 2573 SNMP-TARGET-MIB
- RFC 2574 SNMP-USER-BASED-SM-MIB
- RFC 2576 SNMP-COMMUNITY-MIB
- RFC 2263 USM-TARGET-TAG-MIB
- RFC 3176 SFLOW-MIB
- IEEE8023-LAG-MIB (IEEE Std 802.3ad)
- RFC 2674 P-BRIDGE-MIB
- RFC 2674 Q-BRIDGE-MIB
- RFC 2737 ENTITY-MIB
- RFC 2863 IF-MIB
- RFC 3635 Etherlike-MIB
- PORTSECURITY-PRIVATE-MIB
- RADIUS-CLIENT-PRIVATE-MIB
- RFC 5060 PIM-STD-MIB
- RFC 5240 PIM-BSR-MIB
- RFC 3419 TRANSPORT-ADDRESS-MIB
- IANA-MAU-MIB



17

2 Installation and Quick Startup

2.1 Package Contents

Before you begin installing the Switch, confirm that your package contains the following items:

- One Layer 2/3/4 Managed ToR Switch
- Mounting kit: 2 mounting brackets and screws
- Four rubber feet with adhesive backing
- Redundant AC power cord


GUANTA COMPUTER INC.

2.2 Switch Installation

Installing the Switch Without the Rack

- 1. Install the Switch on a level surface that can safely support the weight of the Switch and its attached cables. The Switch must have adequate space for ventilation and for accessing cable connectors.
- 2. Set the Switch on a flat surface and check for proper ventilation. Allow at least 5 cm (2 inches) on each side of the Switch and 15 cm (6 inches) at the back for the power cable.
- 3. Attach the rubber feet on the marked locations on the bottom of the chassis.

The rubber feet are recommended to keep the unit from slipping.






2.3 Installing the Switch in a Rack

You can install the Switch in most standard 19-inch (48.3-cm) racks. Refer to the illustrations below.

- 1. Use the supplied screws to attach a mounting bracket to each side of the Switch.
- 2. Align the holes in the mounting bracket with the holes in the rack.
- 3. Insert and tighten two screws through each of the mounting brackets.



2.4 Quick Starting the Switch

- 1. Read the device Installation Guide for the connectivity procedure. In-band connectivity allows access to the Switch locally. From a remote workstation, the device must be configured with IP information (IP address, subnet mask, and default gateway).
- 2. Turn the Power ON.
- 3. Allow the device to load the software until the login prompt appears. The device initial state is called the default mode.
- 4. When the prompt asks for operator login, do the following:
 - Type the word **admin** in the login area. Since a number of the Quick Setup commands require administrator account rights, suggesting logging into an administrator account.
 - Do not enter a password because there is no password in the default mode.
 - Press the <Enter> key
 - The CLI Privileged EXEC mode prompt will be displayed.
 - Use "configure" to switch to the Global Config mode from Privileged EXEC.
 - Use "exit" to return to the previous mode.



2.5 System Information Setup

2.5.1 Quick Start up Software Version Information

Table 2-1. Quick Start up Software Version Information

Command	Details
show hardware	Allows the user to see the HW & SW version the device
	contains
	System Description - switch's model name
show version	Allows the user to see Serial Number, Part Number, and Model
	name
	See Linux kernel version, and operation software version
	See HW version

2.5.2 Quick Start up Physical Port Data

Command	Details
show Interface status [<slot port="">]</slot>	Displays the Ports slot/port
	Type - Indicates if the port is a special type of port
	Admin Mode - Selects the Port Control Administration State
	Physical Mode - Selects the desired port speed and duplex
	mode
	Physical Status - Indicates the port speed and duplex mode
	Link Status - Indicates whether the link is up or down
	Link Trap - Determines whether or not to send a trap when link status changes
	LACP Mode - Displays whether LACP is enabled or disabled on
	this port
	Flow Mode - Indicates the status of flow control on this port
	Cap. Status - Indicates the port capabilities during
	auto-negotiation

2.5.3 Quick Start up User Account Management

Table 2-3. Quick Start up User Account Management

Command	Details
show users	Displays all users that are allowed to access the switch
	User Access Mode - Shows whether the user is able to change
	parameters on the switch (Read/Write) or is only able to view (Read Only).
	As a factory default, admin has Read/Write access and guest
	has Read Only access. There can only be one Read/Write user
	and up to 5 Read Only users.
show loginsession	Displays all login session information
username <username> {passwd </username>	Allows the user to set passwords or change passwords needed
nopasswd}	to login
	A prompt will appear after the command is entered requesting
	the old password. In the absence of an old password leave the
	area blank. The operator must press enter to execute the command.
	The system then prompts the user for a new password then a
	prompt to confirm the new password. If the new password and
	the confirmed password match a message will be displayed.
	The user password should not be more than eight characters in
	length.
copy running-config startup-config	This will save passwords and all other changes to the device.
[filename]	If you do not save config, all configurations will be lost when a
	power cycle is performed on the switch or when the switch is
	reset.

2.5.4 Quick Start up IP Address

To view the network parameters the operator can access the device by the following three methods.

- Simple Network Management Protocol SNMP
- Telnet/SSH

Table 2-4. Quick Start up IP Address

Command	Details		
show ip interface	Displays the Network Configurations		
	Interface Status – Indicates whether the interface is up or		
	down.		
	IP Address - IP Address of the interface		
	Subnet Mask - IP Subnet Mask for the interface.		
	MAC Address - The MAC Address used for this in-band		
	connectivity		
	Network Configurations Protocol Current - Indicates which		
	network protocol is being used. Default is None.		
ip address	(Config)#interface vlan 1		
	(if-vlan 1)#ip address <ipaddr> <netmask></netmask></ipaddr>		
	(if-vlan 1)#exit		
	(Config)#ip default-gateway <gateway></gateway>		
	IP Address range from 0.0.0.0 to 255.255.255.255		
	Subnet Mask range from 0.0.0.0 to 255.255.255.255		
	Gateway Address range from 0.0.0.0 to 255.255.255.255		
	Displays all of the login session information		
show serviceport	Display the serviceport's network configurations		
	Interface Status – Indicates whether the interface is up or		
	down.		
	IP Address - IP Address of the interface. Default IP is 0.0.0.0		
	Subnet Mask - IP Subnet Mask for the interface. Default is		
	0.0.0.0		
	Default Gateway - The default Gateway for this interface.		
	Default value is 0.0.0.0		
	Burned in MAC Address - The Burned in MAC Address used for		
	out-of-band connectivity		
	Configured IPv4 Protocol - Indicates which network protocol is		
	being used. Default is DHCP.		
serviceport ip	(Config)#serviceport protocol none		
	(Config)#serviceport ip <ipaddr> <netmask> <gateway></gateway></netmask></ipaddr>		
	(Config)#		

2.5.5 Quick Start up Uploading from Switch to Out-of-Band PC

Table 2-3: Which offart up opiolating non ownen to out-on-band to (Amobelm)				
Command	Details			
copy startup-config xmodem	This starts the upload and displays the mode of uploading and			
<filename></filename>	the type of upload it is and confirms the upload is taking place.			
	For example:			
	If the user is using HyperTerminal, the user must specify where			
	the file is going to be received by the pc.			

Table 2-5. Quick Start up Uploading from Switch to Out-of-Band PC (XMODEM)

2.5.6 Quick Start up Downloading from Out-of-Band PC to Switch

Command	Details	
copy xmodem startup-config	Sets the download datatype to be an image or config file.	
<filename></filename>	The URL must be specified as: xmodem: filepath/ filename	
	For example:	
	If the user is using HyperTerminal, the user must specify which	
	file is to be sent to the switch. The Switch will restart	
	automatically once the code has been downloaded.	

2.5.7 Quick Start up Downloading from TFTP Server

Before starting a TFTP server download, the operator must complete the Quick Start up for the IPAddress.

Command	Details
copy <url> startup-config <filename></filename></url>	Sets the download datatype to be an image or config file.
	The URL must be specified as: tftp://ipAddr/filepath/fileName.
	The startup-config option downloads the config file using tftp
	and image option downloads the code file.

Table 2-7 Quick Start up Downloading from TFTP Server



2.5.8 Quick Start up Factory Defaults

Table 2-8 Quick Start up Factory Defaults

Command	Details
clear config	Enter yes when the prompt pops up to clear all the configurations made to the switch.
copy running-config startup-config [filename]	Enter yes when the prompt pops up that asks if you want to save the configurations made to the switch.
reload [warm]	Enter yes when the prompt pops up that asks if you want to reset the system. You can reset the switch or cold boot the switch; both work effectively. warm – indicates only switch application is restarted.

3 Console and Telnet Administration Interface

This chapter discusses many of the features used to manage the Switch, and explains many concepts and important points regarding these features. Configuring the Switch to implement these concepts is discussed in detail in chapter 6.

The command-line interface (CLI) provides a text-based way to manage and monitor the switch features. You can access the CLI by using a direct connection to the console port or by using a Telnet or SSH client. To access the switch by using Telnet or Secure Shell (SSH), the switch must have an IP address configured on either the service port or the network interface, and the management station you use to access the device must be able to ping the switch IP address. DHCP is enabled by default on the service port. It is disabled on the network interface.

3.1 Local Console Management

Local console management involves the administration of the Switch via a direct connection to the RS-232 DCE console port. This is an Out-of-band connection, meaning that it is on a different circuit than normal network communications, and thus works even when the network is down.

The local console management connection involves a terminal or PC running terminal emulation software to operate the Switch's built-in console program (see Chapter 6). Using the console program, a network administrator can manage, control, and monitor many functions of the Switch. Hardware components in the Switch allow it to be an active part of a manageable network. These components include a CPU, memory for data storage, other related hardware, and SNMP agent firmware. Activities on the Switch can be monitored with these components, while the Switch can be manipulated to carry out specific tasks.

3.2 Set Up your Switch Using Console Access

Out-of-band management requires connecting a terminal, such as a VT-100 or a PC running a terminal-emulation program (such as HyperTerminal, which is automatically installed with Microsoft Windows) to the RS-232 DCE console port of the Switch. Switch management using the RS-232 DCE console port is called *Local Console Management* to differentiate it from management done via management platforms, such as DView or HP OpenView.

Make sure the terminal or PC you are using to make this connection is configured to match these settings. If there are problems making this connection on a PC, make sure the emulation is set to VT-100 or ANSI. If you still don't see anything, try pressing **<Ctrl> + r** to refresh the screen.

First-time configuration must be carried out through a console, that is, either (a) a VT100-type serial data terminal, or (b) a computer running communications software set to emulate a VT100. The console must

27

be connected to the Diagnostics port. This is an RS-232 port with a 9-socket D-shell connector and DCE-type wiring. Make the connection as follows:

- Obtain suitable cabling for the connection. You can use a null-modem RS-232 cable or an ordinary RS-232 cable and a null-modem adapter. One end of the cable (or cable/adapter combination) must have a 9-pin D-shell connector suitable for the Diagnostics port; the other end must have a connector suitable for the console's serial communications port.
- 2. Power down the devices, attach the cable (or cable/adapter combination) to the correct ports, and restore power.
- 3. Set the console to use the following communication parameters for your terminal:
 - The console port is set for the following configuration:
 - Baud rate: 115,200
 - Data width: 8 bits
 - Parity: none
 - Stop bits: 1
 - Flow Control: none

A typical console connection is illustrated below:




Figure 3-1: Console Setting Environment

3.3 Set Up your Switch Using Telnet Access

Once you have set an IP address for your Switch, you can use a Telnet program (in a VT-100 compatible terminal mode) to access and control the Switch. Most of the screens are identical, whether accessed from the console port or from a Telnet interface.

3.3.1 Accessing the Switch CLI through the Network

Remote management of the switch is available through the service port or through the network interface. To use telnet, SSH, SNMP for swith management, the switch must be connected to the network, and you must know the IP or IPv6 address of the management interface. The switch has no IP address by default. The DHCP client on the service port is enabled, and the DHCP client on the network interface is disaled.

3.3.2 Using the Service Port or Netowrk Interface for Remote Management

The service port is a dedicated Ethernet port for out-of-band management. We recommend that you use the service port to manage the switch. Traffic on this port is segregated from operational network traffic on the switch ports and cannot be switched or routed to the operational network. Additonally, if the production network is experiencing problems, the service port still allows you to access the switch management interface and troubleshoot issues. Configuration options on the service port are limited, which makes it difficult to accidentally cut off management access to the switch.

Alternatively, you can choose to manage the switch through the production network, which is known as in-band management, Bacuse in-nbad management traffic is mixed in with production netowork traffic, it is subject to all of the filtering rules usually applied on a switched/routed port such as ACLs and VLAN tagging. You can access the in-band network management interface through a connection to any front-panel port.

3.3.2.1 Configuring Service Port Information

To disable DHCP/BootP and manually assign an IPv4 address, enter commands under Global Configuration mode:

serviceport protocol none

serviceport ip ipaddress netmask

For example, serviceport ip 192.168.2.22 255.255.255.0

To disable DHCP/BootP and manually assign an IPv6 address, enter commands under Global Configuration mode:

serviceport protocol none dhcp6

GUANTA COMPUTER INC.

serviceport ipv6 enable serviceport ipv6 address *address/prefix-length* serviceport ipv6 gateway *ipv6-address* To view the assigned or configured network address, use: show serviceport

To enable the DHCP/DHCPv6 client on the service port, use: serviceport protocol dhcp serviceport protocol dhcp6

To enable the BootP client on service port, use: serviceport protocol bootp

3.3.2.2 Configuring the In-Band Netowrk Interface

To use a DHCP server to obtain the IP address, subnet mask, and default gateway information, use:

interface vlan 1 ip address dhcp ipv6 address dhcp

To manually configure the IPv4 address, subnet mask, use:

interface vlan 1 ip address ipaddress netmask

To manually configure the IPv6 address, subnet mask, use:

interface vlan 1

ipv6 address address/prefix-length

4 Command Line Interface Structure and Mode-based CLI

The Command Line Interface (CLI) syntax, conventions, and terminology are described in this section. Each CLI command is illustrated using the structure outlined below.

4.1 CLI Command Format

Commands are followed by values, parameters, or both.

Example 1

ip address <ipaddr> <netmask> [<gateway>]

- ip address is the command name.
- <ipaddr> <netmask> are the required values for the command.
- [<gateway>] is the optional value for the command.

Example 2

snmp-server location <loc>

- snmp-server location is the command name.
- <loc> is the required parameter for the command.

Example 3

clear vlan

• clear vlan is the command name.

Command

The text in bold, non-italic font must be typed exactly as shown.

4.2 CLI Mode-based Topology

Parameters

Parameters are order dependent.

The text in bold italics should be replaced with a name or number. To use spaces as part of a name parameter, enclose it in double quotes like this: "System Name with Spaces".

Parameters may be mandatory values, optional values, choices, or a combination.

- <parameter>. The <> angle brackets indicate that a mandatory parameter must be entered in place of the brackets and text inside them.
- [parameter]. The [] square brackets indicate that an optional parameter may be entered in place of the brackets and text inside them.
- {choice1 | choice2}. The | indicates that only one of the parameters should be entered. The {} curly braces indicate that a parameter must be chosen from the list of choices.

Values

ipaddr This parameter is a valid IP address, made up of four decimal bytes ranging from 0 to 255. The default for all IP parameters consists of zeros (that is, 0.0.0.0). The interface IP address of 0.0.0.0 is invalid.

macaddr The MAC address format is six hexadecimal numbers separated by colons, for example 00:06:29:32:81:40.

areaid Area IDs may be entered in dotted-decimal notation (for example, 0.0.0.1). An area ID of 0.0.0.0 is reserved for the backbone. Area IDs have the same form as IP addresses, but are distinct from IP addresses. The IP network number of the sub-netted network may be used for the area ID.

routerid The value of <router id> must be entered in 4-digit dotted-decimal notation (for example, 0.0.0.1). A router ID of 0.0.0.0 is invalid.

slot/port This parameter denotes a valid slot number, and a valid port number. For example, 0/1 represents unit number 1, slot number 0 and port number 1. The <slot/port> field is composed of a valid slot number and a valid port number separated by a forward slash (/).

logical slot/port This parameter denotes a logical slot number, and logical port number assigned. This is applicable in the case of a port-channel (LAG). The operator can use the logical slot number, and the logical port number to configure the port-channel.

Conventions

Network addresses are used to define a link to a remote host, workstation, or network. Network addresses are shown using the following syntax:

Table 5-1. Network Address Syntax

Address Type	Format	Range
IPAddr	A.B.C.D	0.0.0.0 to 255.255.255.255
MacAddr	YY:YY:YY:YY:YY	hexidecimal digit pairs

Double quotation marks such as "System Name with Spaces" set off user defined strings. If the operator wishes to use spaces as part of a name parameter then it must be enclosed in double quotation marks.

Empty strings ("") are not valid user defined strings. Command completion finishes spelling the command when enough letters of a command are typed to uniquely identify the command word. The command may be executed by typing <enter> (command abbreviation) or the command word may be completed by typing the <tab> (command completion).

The value 'Err' designates that the requested value was not internally accessible. This should never happen and indicates that there is a case in the software that is not handled correctly.

The value of '-----' designates that the value is unknown.

Annotations

The CLI allows the user to type single-line annotations at the command prompt for use when writing test or configuration scripts and for better readability. The exclamation point ('!') character flags the beginning of a comment. The comment flag character can begin a word anywhere on the command line and all input following this character is ignored. Any command line that begins with the character '!' is recognized as a comment line and ignored by the parser.

Some examples are provided below:

! Script file for displaying the ip interface
! Display information about interfaces
show ip interface 0/1 !Displays the information about the first interface
! Display information about the next interface
show ip interface 0/2
! End of the script file

5 Switching Commands

5.1 System Information and Statistics commands

5.1.1 show arp

This command displays connectivity between the switch and other devices. The Address Resolution Protocol (ARP) cache identifies the MAC addresses of the IP stations communicating with the switch.

Syntax		
show arp	rp	

Default Setting

None

Command Mode

Privileged Exec

Display Message

MAC Address: A unicast MAC address for which the switch has forwarding and/or filtering information. The format is 6 two-digit hexadecimal numbers that are separated by colons. For example: 00:23:45:67:89:AB

IP Address: The IP address assigned to each interface.

Interface: Valid slot number and a valid port number.



5.1.2 show calendar

This command displays the system time.

Syntax

show calendar

Default Setting

None

Command Mode

Privileged Exec

Display Message

Current Time: displays system time



5.1.3 show process cpu

This command provides the percentage utilization of the CPU by different tasks.

Syntax			
show proc	cess cpu		



It is not necessarily the traffic to the CPU, but different tasks that keep the CPU busy

Default Setting

None

Command Mode

Privileged Exec

Display Message

The following shows example CLI display output for the command.

Memory Utilization Report

status bytes

free 250978304 alloc 275599360

CPU Utilization:

PID	Name	5 Secs	60 Secs	300 Secs
1030	osapiTimer	0.00%	0.02%	0.02%
1032	_interrupt_thread	0.00%	0.02%	0.02%
1034	bcmL2X.0	1.99%	2.10%	1.81%
1035	bcmCNTR.0	1.59%	1.42%	1.19%
1038	bcmLINK.0	2.99%	2.84%	2.44%
1040	bcmL2X.1	1.99%	2.09%	1.81%
1041	bcmCNTR.1	1.39%	1.40%	1.19%
1042	bcmLINK.1	2.99%	2.87%	2.45%
1043	bcmRX	0.19%	0.19%	0.16%

GUANTA COMPUTER INC.

1044	cpuUtilMonitorTask	0.19%	0.14%	0.11%
1046	tL7Timer0	0.00%	0.02%	0.01%
1054	simPts_task	0.00%	0.02%	0.01%
1058	Detecting SFP+ Modu	0.00%	0.02%	0.01%
1080	emWeb	0.00%	0.08%	0.06%
1085	StormCtrl Log Table	0.00%	0.03%	0.03%
1091	SNMPTask	1.79%	12.48%	37.44%
1101	dot1s_timer_task	0.19%	0.07%	0.04%
1118	sFlowTask	0.00%	0.09%	0.11%
1135	RMONTask	0.00%	0.12%	0.15%
1137	udldTask	0.00%	0.01%	0.01%
Total CP	U Utilization	15.37%	26.14%	49.21%

5.1.4 show eventlog

This command displays the event log, which contains error messages from the system, in the Primary Management System or in the specified unit. The event log is not cleared on a system reset.

Syntax		
show eve	entlog [unit]	

unit - The unit number of the remote system. The range is 1 to 8.



unit parameter is only support for stacking platform.

Default Setting

None

Command Mode

Privileged Exec

Display Message

File: The file in which the event originated.

Line: The line number of the event.

Task Id: The task ID of the event.

Code: The event code.

Time: The time this event occurred.



Event log information is retained across a switch reset.



5.1.5 show running-config

This command is used to display/capture the current setting of different protocol packages supported on switch. This command displays/captures only commands with settings/configurations with values that differ from the default value. The output is displayed in script format, which can be used to configure another switch with the same configuration.

When a script name is provided, the output is redirected to a configuration script. The option [all] will also enable the display/capture of all commands with settings/configurations that include values that are same as the default values. If the optional <scriptname> is provided with a file name extension of ".scr", the output will be redirected to a script file.

Syntax

show running-config [all | <scriptname>]

all - enable the display/capture of all commands with settings/configurations that include values that are same as the default values.

<scriptname> - redirect the output to the file <scriptname>.

Default Setting

None

Command Mode

Privileged Exec

5.1.6 show sysinfo

This command displays switch brief information and MIBs supported.

Syntax			
show sysin	fo		

Default Setting

None

Command Mode

Privileged Exec

Display Message

System Description: The text used to identify this switch.

System Name: The name used to identify the switch.

System Location: The text used to identify the location of the switch. May be up to 255 alpha-numeric characters. The factory default is blank.

System Contact: The text used to identify a contact person for this switch. May be up to 255 alphanumeric characters. The factory default is blank.

System Object ID: The manufacturing ID.

System Up Time: The time in days, hours and minutes since the last switch reboot.

Current SNTP Synchronized Time: The time which is synchronized from SNTP server.

5.1.7 show system

This command displays switch system information.

Syntax			
show sys	stem		

Default Setting

None

Command Mode

Privileged Exec

Display Message

System Description: Text used to identify this switch.

System Object ID: The manufacturing ID

System Information

System Up Time: The time in days, hours and minutes since the last switch reboot.

System Name: Name used to identify the switch.

System Location: Text used to identify the location of the switch. May be up to 255 alpha-numeric characters. The factory default is blank.

System Contact: Text used to identify a contact person for this switch. May be up to 255 alphanumeric characters. The factory default is blank.

MAC Address: The burned in MAC address used for in-band connectivity.

Protocol Current: Indicates which network protocol is being used. The options are bootp | dhcp | none.

DHCP Client Identifier TEXT: DCHP client identifier for this switch.



5.1.8 show tech-support

This command displays system and configuration information when you contact technical support. The output of the show tech-support command combines the output of the following commands: show version, show sysinfo, show interface status, show logging, show event log, show logging buffered, show trap log, show running config, ... etc.

Syntax			
show tech	h-support		

Default Setting

None

Command Mode

Privileged Exec



This command is only support on console port.

5.1.9 show hardware

This command displays inventory information for the switch.

Syntax				
show har	rdware			

Default Setting

None

Command Mode

Privileged Exec

Display Message

System Description: Text used to identify the product name of this switch.

Machine Type: Specifies the machine model as defined by the Vital Product Data.

Machine Model: Specifies the machine model as defined by the Vital Product Data.

Serial Number: The unique box serial number for this switch.

Label Revision Number: The label revision serial number of this switch is used for manufacturing purposes.

Part Number: Manufacturing part number.

Hardware Version: The hardware version of this switch. It is divided into four parts. The first byte is the major version and the second byte represents the minor version.

ADT7470_1: Sensor 1 Now Temperature: The temperature of sensor 1 of ADT7470.
ADT7470_1: Sensor 2 Now Temperature: The temperature of sensor 2 of ADT7470.
ADT7470_1: Sensor 3 Now Temperature: The temperature of sensor 3 of ADT7470.
ADT7470_1: Sensor 4 Now Temperature: The temperature of sensor 4 of ADT7470.

Depend on air flow FAN 1 – 4 connected ADT7470-1 or ADT7470-2:

Front-To-Back: (Connected ADT7470-1)

ADT7470_1: FAN 1 Status: Status of FAN1. It could be active or inactive.

ADT7470_1: FAN 2 Status: Status of FAN2. It could be active or inactive.

ADT7470_1: FAN 3 Status: Status of FAN3. It could be active or inactive.

Back-To-Front: (Connected ADT7470-2)

ADT7470_2: FAN 1 Status: Status of FAN1. It could be active or inactive.

ADT7470_2: FAN 2 Status: Status of FAN2. It could be active or inactive. ADT7470_2: FAN 3 Status: Status of FAN3. It could be active or inactive.

Switch Power+ y......Active/Inactive (The yth power supply information of switch 1).
Name: Name provided by Power Supply vendor.
Model: Model Number provided by Power Supply vendor.
Revision Number: Revision Number provided by Power Supply vendor.
Manufacturer Location: Location provided by Power Supply vendor.
Date of Manufacturing: Date of Manufacturing provided by Power Supply vendor.
Serial Number: Serial Number provided by Power Supply vendor.
Temperature 1:. Inner temperature 1 of Power Supply now
Temperature 2: Inner temperature 2 of Power Supply now
Fan Speed: Inner fan speed(rpm) of Power Supply now
Fan Duty: Inner fan duty(%) of Power Supply now



Below 10-Giga Interface information depend on plugging SFP+ Transceiver

Interface y: (The yth 10-Giga information of switch 1).

10 Gigabit Ethernet Compliance Codes: Transceiver's compliance codes.

Vendor Name: The SFP transceiver vendor name shall be the full name of the corporation, a commonly accepted abbreviation of the name of the corporation, the SCSI company code for the corporation, or the stock exchange code for the corporation.

Vendor Part Number: Part number provided by SFP transceiver vendor.

Vendor Serial Number: Serial number provided by vendor.

Vendor Revision Number: Revision level for part number provided by vendor.

Vendor Manufacturing Date: The vendor's manufacturing date.

Additional Packages: This displays the additional packages that are incorporated into this system.

5.1.10 show version

This command displays inventory information for the switch.

Syntax			
show ver	sion		

Default Setting

None

Command Mode

Privileged Exec

Display Message

System Description: Text used to identify the product name of this switch.

Machine Type: Specifies the machine model as defined by the Vital Product Data.

Machine Model: Specifies the machine model as defined by the Vital Product Data.

Serial Number: The unique box serial number for this switch.

FRU Number: The field replaceable unit number.

Part Number: Manufacturing part number.

Maintenance Level: The identification of the hardware change level.

Manufacturer: The two-octet code that identifies the manufacturer.

Burned In MAC Address: The burned-in universally administered MAC address of this switch.

Software Version: The platform.function.release. maintenance number of the code currently running on the switch.

Operating System: The operating system currently running on the switch.

Network Processing Device: Identifies the network processor hardware.

Additional Packages: A list of the optional software packages installed on the switch, if any. For example, QoS, Routing, IPv6, IPv6 Management, Multicast or Data Center.

5.1.11 show loginsession

This command displays current telnet and serial port connections to the switch.

Syntax				
show logi	insession			

Default Setting

None

Command Mode

Privileged Exec

Display Message

ID: Login Session ID

User Name: The name the user will use to login using the serial port or Telnet. A new user may be added to the switch by entering a name in a blank entry. The user name may be up to 8 characters, and is not case sensitive. Two users are included as the factory default, admin, and guest.

Connection From: IP address of the telnet client machine or EIA-232 for the serial port connection.

Idle Time: Time this session has been idle.

Session Time: Total time this session has been connected.

Session Type: Shows the type of session: telnet, serial port, SSH or HTTP/HTTPS.

5.1.12 show command filter

This command displays the information that begin/include/exclude/redirect the regular expression.

Syntax

show command [| {begin | include | exclude | redirect} <LINE>]

Default Setting

None

Command Mode

Privileged Exec

Display Message

command: Any show command of the CLI
begin: Begin with the line that matches
include: Include lines that match
exclude: Exclude lines that match
redirect: output the lines to the specified URL
<LINE>: Regular Expression

5.1.13 Digital Optical Monitor

5.1.13.1 show transceiver

This command displays Digital Optical Monitor information for the switch.

C.	ntax	
30	IIIdx	

show transceiver {interface [<slot/port>] [detail]}

Default Setting

None

Command Mode

Privileged Exec

Display Message

DOM Admin Mode: This displays the administrative mode of Digital Optical Monitor (DOM) for the system.

Polling Interval: Polling interval. The range of value is 300 to 1800.

Interface: Valid slot number and a valid port number.

Temperature: Internally measured module temperature from transceiver.

Voltage: Internally measured module supply voltage from transceiver.

Tx bias current: Internally measured module tx bias from transceiver.

Tx Power: Internally measured module tx power from transceiver.

Rx Power: Internally measured module rx power from transceiver.

5.1.13.2 monitoring

This command enables monitoring on all ports. The default value is disabled.

Syntax	
• • • • • • • • • • • • • • • • • • • •	

monitoring [interval <interval>] no monitoring [interval]

< interval> - Polling interval. The range of value is 300 to 1800.

no - This command disables monitoring on all ports.

Default Setting

Admin mode: Disable

Interval: 600 sec.

Command Mode

Transceiver Config

5.2 **Device Configuration Commands**

5.2.1 Interface

5.2.1.1 show interface status

This command displays the Port monitoring information for the system.

Syntax

show interface status [{<slot/port> | loopback <loopback-id> | port-channel <portchannel-id> | tunnel <tunnel-id> | vlan <vlan-id>}]

<slot/port> - is the desired interface number.

<loopback-id> - Disaplys information for the loopback interfaces. The range of the loopback ID is 0 to 7.

ortchannel-id> - Displays information for the port-channel interfaces. The range of the port-channel ID is 1 to 64.

<tunnel-id> - Displays information for the tunnel interfaces. The range of the tunnel ID is 0 to 7.

<vlan-id> - Displays information for the vlan interfaces. The range of the VLAN ID is 1 to 4093.

no parameter - Displays information for all interfaces.

Default Setting

None

Command Mode

Privileged Exec

Display Message

Intf: The physical slot and physical port.

Type: If not blank, this field indicates that this port is a special type of port. The possible values are:

Source: This port is a monitoring port.

PC Mbr: This port is a member of a port-channel (LAG).

Dest: This port is a probe port.

Admin Mode: Selects the Port control administration state. The port must be enabled in order for it to be allowed into the network. It may be enabled or disabled. The factory default is enabled.

Physical Mode: Selects the desired port speed and duplex mode. If auto-negotiation support is selected, then the duplex mode and speed will be set from the auto-negotiation process. Note that the port's maximum capability (full duplex 100M) will be advertised. Otherwise, this object will determine the port's duplex mode and transmission rate. The factory default is Auto.

Physical Status: Indicates the port speed and duplex mode.

Link Status: Indicates whether the Link is up or down.

Link Trap: This object determines whether to send a trap when link status changes. The factory default is enabled.

LACP Mode: Displays whether LACP is enabled or disabled on this port.

Flow Control Mode: Displays flow control mode. The possible values are:

Disable: This port is disabled flow control.

Enable: This port is enabled flow control.

Capabilities Status: Displays interface capabilities.

5.2.1.2 show interface counters

This command displays a summary of statistics for a specific interface or all interfaces.

Syntax

show interface counters [{<slot/port> | [port-channel <portchannel-id>]}]

<slot/port> - is the desired interface number.

<portchannel-id> - is the desired port-channel interface number. The range of the port-channel ID is 1 to 64.

no paramter - Displays statistics information for all interfaces.

Default Setting

None

Command Mode

Privileged Exec

Display Message

The display parameters when the argument is '<slot/port>' or port-channel are as follows:

Packets Received Without Error: The total number of packets (including broadcast packets and multicast packets) received by the processor.

Packets Received With Error: The number of inbound packets that contained errors preventing them from being deliverable to a higher-layer protocol.

Broadcast Packets Received: The total number of packets received that were directed to the broadcast address. Note that this does not include multicast packets.

Packets Transmitted Without Error: The total number of packets transmitted out of the interface.

Transmit Packets Errors: The number of outbound packets that could not be transmitted because of errors.

Collisions Frames: The best estimate of the total number of collisions on this Ethernet segment.

Time Since Counters Last Cleared: The elapsed time, in days, hours, minutes, and seconds since the statistics for this port were last cleared.

The display parameters if no argument is used are as follows:

Interface: The physical slot and physical port or the logical slot and logical port.

Packets Received Without Error: The total number of packets (including broadcast packets and multicast packets) received.

GUANTA COMPUTER INC.

Packets Received With Error: The number of inbound packets that contained errors preventing them from being deliverable to a higher-layer protocol.

Broadcast Packets Received: The total number of packets received that were directed to the broadcast address. Note that this does not include multicast packets.

Packets Transmitted Without Error: The total number of packets transmitted.

Transmit Packets Errors: The number of outbound packets that could not be transmitted because of errors.

Collisions Frames: The best estimate of the total number of collisions on this Ethernet segment.

Time Since Counters Last Cleared: The elapsed time, in days, hours, minutes, and seconds since the statistics for this port were last cleared.

This command displays detailed statistics for a specific port or for all CPU traffic based upon the argument.

Syntax

show interface counters detailed {<slot/port> | port-channel <portchannel-id> | switchport}

<slot/port> - is the desired interface number.

<portchannel-id> - is the desired port-channel interface number. The range of the port-channel ID is 1 to 64.

switchport - This parameter specifies whole switch or all interfaces.

Default Setting

None

Command Mode

Privileged Exec

Display Message

The display parameters when the argument is ' <slot/port>' or port-channel are as follows:

Total Packets Received (Octets): The total number of octets of data (including those in bad packets) received on the network (excluding framing bits but including FCS octets). This object can be used as a reasonable estimate of Ethernet utilization. If greater precision is desired, the etherStatsPkts and etherStatsOctets objects should be sampled before and after a common interval. The result of this equation is the value Utilization which is the percent utilization of the Ethernet segment on a scale of 0 to 100 percent.

Packets Received 64 Octets: The total number of packets (including bad packets) received that were 64 octets in length (excluding framing bits but including FCS octets).

Packets Received 65-127 Octets: The total number of packets (including bad packets) received that were between 65 and 127 octets in length inclusive (excluding framing bits but including FCS octets).

Packets Received 128-255 Octets: The total number of packets (including bad packets) received that were between 128 and 255 octets in length inclusive (excluding framing bits but including FCS octets).

Packets Received 256-511 Octets: The total number of packets (including bad packets) received that were between 256 and 511 octets in length inclusive (excluding framing bits but including FCS octets).

Packets Received 512-1023 Octets: The total number of packets (including bad packets) received that were between 512 and 1023 octets in length inclusive (excluding framing bits but including FCS octets).

Packets Received 1024-1518 Octets: The total number of packets (including bad packets) received that were between 1024 and 1518 octets in length inclusive (excluding framing bits but including FCS octets).

Packets Received > 1522 Octets: The total number of packets received that were longer than 1522 octets (excluding framing bits, but including FCS octets) and were otherwise well formed.

Packets RX and TX 64 Octets: The total number of packets (including bad packets) received that were 64 octets in length (excluding framing bits but including FCS octets).

Packets RX and TX 65-127 Octets: The total number of packets (including bad packets) received that were between 65 and 127 octets in length inclusive (excluding framing bits but including FCS octets).

Packets RX and TX 128-255 Octets: The total number of packets (including bad packets) received that were between 128 and 255 octets in length inclusive (excluding framing bits but including FCS octets).

Packets RX and TX 256-511 Octets: The total number of packets (including bad packets) received that were between 256 and 511 octets in length inclusive (excluding framing bits but including FCS octets).

Packets RX and TX 512-1023 Octets: The total number of packets (including bad packets) received that were between 512 and 1023 octets in length inclusive (excluding framing bits but including FCS octets).

Packets RX and TX 1024-1518 Octets: The total number of packets (including bad packets) received that were between 1024 and 1518 octets in length inclusive (excluding framing bits but including FCS octets).

Packets RX and TX 1519-1522 Octets: The total number of packets (including bad packets) received that were between 1519 and 1522 octets in length inclusive (excluding framing bits but including FCS octets).

Packets RX and TX 1523-2047 Octets: The total number of packets (including bad packets) received that were between 1523 and 2047 octets in length inclusive (excluding framing bits but including FCS octets).

Packets RX and TX 2048-4095 Octets: The total number of packets (including bad packets) received that were between 2048 and 4095 octets in length inclusive (excluding framing bits but including FCS octets).

Packets RX and TX 4096-9216 Octets: The total number of packets (including bad packets) received that were between 4096 and 9216 octets in length inclusive (excluding framing bits but including FCS octets).

Total Packets Received Without Errors

Unicast Packets Received: The number of subnetwork-unicast packets delivered to a higher-layer protocol.

Multicast Packets Received: The total number of good packets received that were directed to a multicast address. Note that this number does not include packets directed to the broadcast address.

Broadcast Packets Received: The total number of good packets received that were directed to the broadcast address. Note that this does not include multicast packets.

Total Packets Received with MAC Errors

Jabbers Received: The total number of packets received that were longer than 1518 octets (excluding framing bits, but including FCS octets), and had either a bad FCS with an integral number of octets (FCS Error) or a bad FCS with a non-integral number of octets (Alignment Error). Note that this definition of jabber is different than the definition in IEEE-802.3 section 8.2.1.5 (10BASE5) and section 10.3.1.4 (10BASE2). These documents define jabber as the condition where any packet exceeds 20 ms. The allowed range to detect jabber is between 20 ms and 150 ms.

Undersize Received: The total number of packets received that were less than 64 octets in length with GOOD CRC(excluding framing bits but including FCS octets).

Fragments Received: The total number of packets received that were less than 64 octets in length with ERROR CRC(excluding framing bits but including FCS octets).

Alignment Errors: The total number of packets received that had a length (excluding framing bits, but including FCS octets) of between 64 and 1518 octets, inclusive, but had a bad FCS with a non-integral number of octets.

FCS Errors: The total number of packets received that had a length (excluding framing bits, but including FCS octets) of between 64 and 1518 octets, inclusive, but had a bad FCS with an integral number of octets

Overruns: The total number of frames discarded as this port was overloaded with incoming packets, and could not keep up with the inflow.

Total Packets Transmitted (Octets)

Packets Transmitted 64 Octets: The total number of packets (including bad packets) received that were 64 octets in length (excluding framing bits but including FCS octets).

Packets Transmitted 65-127 Octets: The total number of packets (including bad packets) received that were between 65 and 127 octets in length inclusive (excluding framing bits but including FCS octets).

Packets Transmitted 128-255 Octets: The total number of packets (including bad packets) received that were between 128 and 255 octets in length inclusive (excluding framing bits but including FCS octets).

Packets Transmitted 256-511 Octets: The total number of packets (including bad packets) received that were between 256 and 511 octets in length inclusive (excluding framing bits but including FCS octets).

Packets Transmitted 512-1023 Octets: The total number of packets (including bad packets) received that were between 512 and 1023 octets in length inclusive (excluding framing bits but including FCS octets).

Packets Transmitted 1024-1518 Octets: The total number of packets (including bad packets) received that were between 1024 and 1518 octets in length inclusive (excluding framing bits but including FCS octets).

Packets Transmitted 1519-1522 Octets: The total number of packets (including bad packets) received that were between 1519 and 1522 octets in length inclusive (excluding framing bits but including FCS octets).

Max Info: The maximum size of the Info (non-MAC) field that this port will receive or transmit.

Total Packets Transmitted Successfully

Unicast Packets Transmitted: The total number of packets that higher-level protocols requested be transmitted to a subnetwork-unicast address, including those that were discarded or not sent.

Multicast Packets Transmitted: The total number of packets that higher-level protocols requested be transmitted to a Multicast address, including those that were discarded or not sent.

Broadcast Packets Transmitted: The total number of packets that higher-level protocols requested be transmitted to the Broadcast address, including those that were discarded or not sent.

Total Transmit Errors

FCS Errors: The total number of packets transmitted that had a length (excluding framing bits, but including FCS octets) of between 64 and 1518 octets, inclusive, but had a bad FCS with an integral number of octets

Tx Oversized: The total number of frames that exceeded the max permitted frame size. This counter has a max increment rate of 815 counts per sec. at 10 Mb/s.

Underrun Errors: The total number of frames discarded because the transmit FIFO buffer became empty during frame transmission.

Total Transmited Packets Discards

Single Collision Frames: A count of the number of successfully transmitted frames on a particular interface for which transmission is inhibited by exactly one collision.

Multiple Collision Frames: A count of the number of successfully transmitted frames on a particular interface for which transmission is inhibited by more than one collision.

Excessive Collisions: A count of frames for which transmission on a particular interface fails due to excessive collisions.

GVRP PDUs Received: The count of GVRP PDUs received in the GARP layer.

GVRP PDUs Transmitted: The count of GVRP PDUs transmitted from the GARP layer.

GVRP Failed and Registrations: The number of times attempted GVRP registrations could not be completed.

GMRP PDUs received: The count of GMRP PDUs received in the GARP layer.

GMRP PDUs Transmitted: The count of GMRP PDUs transmitted from the GARP layer.

GMRP Failed Registrations: The number of times attempted GMRP registrations could not be completed.

STP BPDUs Transmitted: Spanning Tree Protocol Bridge Protocol Data Units sent.

STP BPDUs Received: Spanning Tree Protocol Bridge Protocol Data Units received.

RSTP BPDUs Transmitted: Rapid Spanning Tree Protocol Bridge Protocol Data Units sent.

RSTP BPDUs Received: Rapid Spanning Tree Protocol Bridge Protocol Data Units received.

MSTP BPDUs Transmitted: Multiple Spanning Tree Protocol Bridge Protocol Data Units sent.

MSTP BPDUs Received: Multiple Spanning Tree Protocol Bridge Protocol Data Units received.

EAPOL Frames Received: The number of valid EAPOL frames of any type that have been received by this authenticator.

EAPOL Frames Transmitted: The number of EAPOL frames of any type that have been transmitted by this authenticator.

Time Since Counters Last Cleared: The elapsed time, in days, hours, minutes, and seconds since the statistics for this port were last cleared.

The display parameters when the argument is 'switchport' are as follows:

Total Packets Received (Octets): The total number of octets of data received by the processor (excluding framing bits but including FCS octets).

Packets Received Without Error: The total number of packets (including broadcast packets and multicast packets) received by the processor.

Unicast Packets Received: The number of subnetwork-unicast packets delivered to a higher-layer protocol.

Multicast Packets Received: The total number of packets received that were directed to a multicast address. Note that this number does not include packets directed to the broadcast address.

Broadcast Packets Received: The total number of packets received that were directed to the broadcast address. Note that this does not include multicast packets.

Receive Packets Discarded: The number of inbound packets which were chosen to be discarded even though no errors had been detected to prevent their being deliverable to a higher-layer protocol. A possible reason for discarding a packet could be to free up buffer space.

Octets Transmitted: The total number of octets transmitted out of the interface, including framing characters.

Packets Transmitted without Errors: The total number of packets transmitted out of the interface.

Unicast Packets Transmitted: The total number of packets that higher-level protocols requested be transmitted to a subnetwork-unicast address, including those that were discarded or not sent.

Multicast Packets Transmitted: The total number of packets that higher-level protocols requested be transmitted to a Multicast address, including those that were discarded or not sent.

Broadcast Packets Transmitted: The total number of packets that higher-level protocols requested be transmitted to the Broadcast address, including those that were discarded or not sent.

Transmit Packets Discarded: The number of outbound packets which were chosen to be discarded even though no errors had been detected to prevent their being deliverable to a higher-layer protocol. A possible reason for discarding a packet could be to free up buffer space.

Most Address Entries Ever Used: The highest number of Forwarding Database Address Table entries that have been learned by this switch since the most recent reboot.

Address Entries Currently in Use: The number of Learned and static entries in the Forwarding Database Address Table for this switch.

Maximum VLAN Entries: The maximum number of Virtual LANs (VLANs) allowed on this switch.

Most VLAN Entries Ever Used: The largest number of VLANs that have been active on this switch since the last reboot.

Static VLAN Entries: The number of presently active VLAN entries on this switch that have been created statically.

Dynamic VLAN Entries: The number of presently active VLAN entries on this switch that have been created by GVRP registration.

VLAN Deletes: The number of VLANs on this switch that have been created and then deleted since the last reboot.

Time Since Counters Last Cleared: The elapsed time, in days, hours, minutes, and seconds, since the statistics for this switch were last cleared.

5.2.1.3 show interface counters rate

This command displays a summary of port rate statistics for a specific interface or all interfaces.

show interface counters rate [{<slot/port> | [port-channel <portchannel-id>]}]

<slot/port> - is the desired interface number.

<portchannel-id> - is the desired port-channel interface number. The range of the port-channel ID is 1 to 64.

no paramter - Displays port rate statistics information for all interfaces.

Default Setting

None

Command Mode

Privileged Exec

Display Message

Interface: The physical slot and physical port or the logical slot and logical port.

Minutes: Load interval. The range of value is 30 seconds to 600 seconds.

Input rate: Average number of bits and packets received per second in the interval.

Output rate: Average number of bits and packets transmitted per second in the interval.



5.2.1.4 load-interval

The load-interval change the length of time for which data is used to compute load port rate statistics.

Syntax			
load-inter	rval <30-600>		
no load-ir	nterval		

<interval> - Load interval. The range of value is 30 seconds to 600 seconds.

no - This command will be back to 300 seconds load-interval on a port.

Default Setting

300

Command Mode

Interface Config

5.2.1.5 show interface switch

This command displays a summary of statistics for all CPU traffic.

Syntax

show interface switch

Default Setting

None

Command Mode

Privileged Exec

Display Message

Broadcast Packets Received: The total number of packets received that were directed to the broadcast address. Note that this does not include multicast packets.

Packets Received With Error: The number of inbound packets that contained errors preventing them from being deliverable to a higher-layer protocol.

Packets Transmitted Without Error: The total number of packets transmitted out of the interface.

Broadcast Packets Transmitted: The total number of packets that higher-level protocols requested to be transmitted to the Broadcast address, including those that were discarded or not sent.

Transmit Packet Errors: The number of outbound packets that could not be transmitted because of errors.

Address Entries Currently In Use: The total number of Forwarding Database Address Table entries now active on the switch, including learned and static entries.

VLAN Entries Currently In Use: The number of VLAN entries presently occupying the VLAN table.

Time Since Counters Last Cleared: The elapsed time, in days, hours, minutes, and seconds since the statistics for this switch were last cleared.

5.2.1.6 interface

This command is used to enter Interface configuration mode.

Syntax
Oymax

interface {<slot/port> | loopback <loopback-id> | port-channel <portchannel-id> | tunnel <tunnel-d> | vlan <vlan-id>}

<slot/port> - is the desired interface number.

<loopback-id> - is the desired loopback interface number. The range of loopback ID is 0 to 7.

cportchannel-id> - is the desired port-channel interface number. The range of port-channel ID is 1 to 64.

<tunnel-id> - is the desired tunnel interface number. The range of tunnel ID is 0 to 7.

<vlan-id> - is the desired vlan interface number. The range of VLAN ID is 1 to 4093.

Default Setting

None

Command Mode

Global Config

5.2.1.7 speed-duplex

This command is used to set the speed and duplex mode for the interface.



The 10-Giga interfaces could be configured to operate at 10-Giga or 1-Giga speed. Use 'speed-duplex 1000' to change the speed of 10-Giga port to 1G speed.

The speed of 40-Giga interfaces can not be changed by this command.

Syntax		
speed-du	luplex 1000	
no speed-	d-duplex 1000	

1000 – 1000 Mbps, only valid for 10G ports.

no - This command will be back to 10G speed from 1G speed on a port.

Default Setting

None

Command Mode

Interface Config



This command is used to set the speed and duplex mode for all interfaces.

Syntax				
speed-du	plex all 1000			
no speed	I-duplex all 1000			

1000 – 1000 Mbps, only valid for 10G ports.

all - This command represents all interfaces.

no - This command will be back to 10G speed from 1G speed for all 10G ports.

Default Setting

None

Command Mode

Global Config

5.2.1.8 negotiate

This command enables automatic negotiation on a port. The default value is enabled.



The 10-Giga and 40-Giga interfaces do not provide the following command.

Syntax	x	
negotiate no negoti	ate	
no negoti	gotiate	

no - This command disables automatic negotiation on a port.

Default Setting

Disable

Command Mode

Interface Config



This command enables automatic negotiation on all interfaces. The default value is enabled.

Syntax			
negotiate	all		
negotiate no negoti	ate all		

all - This command represents all interfaces.

no - This command disables automatic negotiation on all interfaces.

Default Setting

Disable

Command Mode

Global Config



5.2.1.9 capabilities

This command is used to set the capabilities on specific interface.



The 10-Giga and 40-Giga interfaces do not provide the following command.

Syntax

capabilities {{10 | 100 } {full-duplex | half-duplex}} | {1000 full-duplex } no capabilities {{10 | 100 } {full-duplex | half-duplex}} | {1000 full-duplex }

10 - 10BASE-T

100 - 100BASE-T

1000 - 1000BASE-T

full-duplex - Full duplex

half-duplex - Half duplex

no - This command removes the advertised capability with using parameter.

Default Setting

10G full-duplex for 10G ports

40G full-duplex for 40G ports

Command Mode

Interface Config

This command is used to set the capabilities on all interfaces.

Syntax

capabilities all {{10 | 100} {full-duplex | half-duplex}} | {1000 full-duplex } no capabilities all {{10 | 100} {full-duplex | half-duplex}} | {1000 full-duplex }

10 - 10BASE-T
100 - 100BASE-T
1000 - 1000BASE-T
full-duplex - Full duplex
half-duplex - Half duplex
all - This command represents all interfaces.

66



no - This command removes the advertised capability with using parameter

Default Setting

10 full/half duplex, 100 full/half duplex and 1000 full duplex for 1G ports.

10G full-duplex for 10G ports

40G full-duplex for 40G ports

Command Mode

Global Config



5.2.1.10 storm-control flowcontrol

This command enables 802.3x flow control for the switch.



802.3x flow control only applies to full-duplex mode ports. If PFC feature is enabled on the same interface, 802.3x flow control will be disabled internally.

Syntax storm-control flowcontrol no storm-control flowcontrol

no - This command disables 802.3x flow control for the switch.

Default Setting

Disabled

Command Mode

Global Config

This command enables 802.3x flow control for the specific interface.



802.3x flow control only applies to full-duplex mode ports. If PFC feature is enabled on the same interface, 802.3x flow control will be disabled internally.

Syntax

storm-control flowcontrol no storm-control flowcontrol

no - This command disables 802.3x flow control for the specific interface.

Default Setting

Disabled

Command Mode

Interface Config

5.2.1.11 shutdown

This command is used to disable a port.



Syntax		
shutdowr	n	
no shutdo	own	

no - This command enables a port.

Default Setting

Enabled

Command Mode

Interface Config

This command is used to disable all ports.

Syntax

shutdown all no shutdown all

all - This command represents all ports.

no - This command enables all ports.

Default Setting

Enabled

Command Mode

Global Config

5.2.1.12 description

This command is used to create an alpha-numeric description of the port.

Syntax					
description <desc< th=""><th>cription></th><th></th><th></th><th></th><th></th></desc<>	cription>				

no - This command removes the description of the port.

Default Setting

no description

None

Command Mode

Interface Config

5.2.1.13 **mdi**

This command is used to configure the physical port MDI/MDIX state.

Syntax		
medi (autolograpolograpol)		

mdi {auto|across|normal} no mdi

auto - This type is auto selecting cable type.

across - This type is only allowed the Across-over cable.

normal - This type is only allowed the Normal cable.

no - This command restore the port mode to Auto.

Default Setting

Auto

Command Mode

Interface Config



This command is not provided for the 10-Giga SFP+ interface and 40G QSFP interface.

70

5.2.2 L2 MAC Address and Multicast Forwarding Database Tables

5.2.2.1 show mac-addr-table

This command displays the forwarding database entries. If the command is entered with no parameter, the entire table is displayed. The administrator can enter a MAC Address to display the table entry for the requested MAC address and all entries following the requested MAC address.

Syntax

show mac-addr-table [{<macaddr> <vlan-id>}]

<macaddr> - enter a MAC Address to display the table entry for the requested MAC address.

<vlan-id> - VLAN ID (Range: 1 – 4093)

no parameter – Displays the entire table.

Default Setting

None

Command Mode

Privileged Exec

Display Message

Mac Address: A unicast MAC address for which the switch has forwarding and/or filtering information. The format is 6 or 8 two-digit hexadecimal numbers that are separated by colons, for example 01:23:45:67:89:AB. In an IVL system the MAC address will be displayed as 8 bytes. In an SVL system, the MAC address will be displayed as 6 bytes. **Note: This software version only supports IVL systems.**

Interface: The port on which this L2 MAC address was learned.

IfIndex: This object indicates the if Index of the interface table entry associated with this port.

Status: The status of this entry.

The meanings of the values are:

Static: The value of the corresponding instance was added by the system or a user when a static MAC filter was defined. It cannot be relearned.

Learned: The value of the corresponding instance was learned by observing the source MAC addresses of incoming traffic, and is currently in use.

Management: The value of the corresponding instance (system MAC address) is also the value of an existing instance of dot1dStaticAddress. It is identified with interface 3/1 and is currently used when enabling VLANs for routing.

Self: The value of the corresponding instance is the address of one of the switch's physical interfaces (the system's own MAC address).

GMRP Learned: The value of the corresponding instance was learned via GMRP and applies to Multicast.

71



Other: The value of the corresponding instance does not fall into one of the other categories.

5.2.2.2 show mac-addr-table count

This command displays the total forwarding database entries, the number of static and learnning mac address, and the max address available on the switch.

Syntax

show mac-addr-table count

Default Setting

None

Command Mode

Privileged Exec

Display Message

Address Entries Currently in Use: The number of active entry in FDB Table.

Dynamic Address count: The total learning mac addresses on the L2 MAC address Table.

Static Address (User-defined) count: The total user-defined addresses on the L2 MAC address Table.

Total MAC Addresses in use: This number of addresses are used on the L2 MAC address table.

Total MAC Addresses available: The switch supports max value on the L2 MAC address table.

5.2.2.3 show mac-addr-table interface

This command displays the forwarding database entries. The user can search FDB table by using interface number <slot/port>.

Syntax

show mac-addr-table interface {<slot/port> | port-channel <portchannel-id> | vlan <vlan-id>}

<slot/port> - Specifies the desired interface.

<portchannel-id> - Specifies the desired port-channel interface. The range of port-channel ID is 1 to 64.

<vlan-id> - Specifies the desired VLAN interface. The range of VLAN ID is 1 to 4093.

Default Setting

None

Command Mode

Privileged Exec

Display Message

Mac Address: A unicast MAC address for which the switch has forwarding and/or filtering information. The format is 6 or 8 two-digit hexadecimal numbers that are separated by colons, for example 01:23:45:67:89:AB. In an IVL system the MAC address will be displayed as 8 bytes. In an SVL system, the MAC address will be displayed as 6 bytes. **Note: This software version only supports IVL systems.**

VLAN ID: The vlan id of that mac address.

Status: The status of this entry.

The meanings of the values are:

Static: The value of the corresponding instance was added by the system or a user when a static MAC filter was defined. It cannot be relearned.

Learned: The value of the corresponding instance was learned by observing the source MAC addresses of incoming traffic, and is currently in use.

Management: The value of the corresponding instance (system MAC address) is also the value of an existing instance of dot1dStaticAddress. It is identified with interface 3/1 and is currently used when enabling VLANs for routing.

Self: The value of the corresponding instance is the address of one of the switch's physical interfaces (the system's own MAC address).

GMRP Learned: The value of the corresponding instance was learned via GMRP and applies to Multicast.

Other: The value of the corresponding instance does not fall into one of the other categories.

5.2.2.4 show mac-address-table gmrp

This command displays the GARP Multicast Registration Protocol (GMRP) entries in the Multicast Forwarding Database (MFDB) table.

Syntax

show mac-address-table gmrp

Default Setting

None

Command Mode

Privileged Exec

Display Message

MAC Address: A unicast MAC address for which the switch has forwarding and or filtering information. The format is 6 or 8 two-digit hexadecimal numbers that are separated by colons, for example 01:23:45:67:89:AB. In an IVL system the MAC address is displayed as 8 bytes.

Type: This displays the type of the entry. Static entries are those that are configured by the end user. Dynamic entries are added to the table as a result of a learning process or protocol.

Description: The text description of this multicast table entry.

Interfaces: The list of interfaces that are designated for forwarding (Fwd:) and filtering (Flt:).

5.2.2.5 show mac-address-table igmpsnooping

This command displays the IGMP Snooping entries in the Multicast Forwarding Database (MFDB) table.

Syntax

show mac-address-table igmpsnooping

Default Setting

None

Command Mode

Privileged Exec

Display Message

Mac Address: A unicast MAC address for which the switch has forwarding and/or filtering information. The format is 6 or 8 two-digit hexadecimal numbers that are separated by colons, for example 01:23:45:67:89:AB. In an IVL system the MAC address will be displayed as 8 bytes. In an SVL system, the MAC address will be displayed as 6 bytes. **Note: This software version only supports IVL systems.**

Type: This displays the type of the entry. Static entries are those that are configured by the end user. Dynamic entries are added to the table as a result of a learning process or protocol.

Description: The text description of this multicast table entry.

Interfaces: The list of interfaces that are designated for forwarding (Fwd:) and filtering (Flt:).

5.2.2.6 show mac-address-table multicast

This command displays the MFDB information. If the command is entered with no parameter, the entire table is displayed. This is the same as entering the *all* parameter. The user can display the table entry for one MAC Address by specifying the MAC address as an optional parameter.

show mac-address-table multicast [{<macaddr> <vlan-id>]]

<macaddr> - enter a MAC Address to display the table entry for the requested MAC address

<vlan-id> - VLAN ID (Range: 1 – 4093)

no parameter - Displays the entire table.

Default Setting

None

Command Mode

Privileged Exec

Display Message

Mac Address: A unicast MAC address for which the switch has forwarding and/or filtering information. The format is 6 or 8 two-digit hexadecimal numbers that are separated by colons, for example 01:23:45:67:89:AB. In an IVL system the MAC address will be displayed as 8 bytes. In an SVL system, the MAC address will be displayed as 6 bytes. **Note: This software version only supports IVL systems.**

Type: This displays the type of the entry. Static entries are those that are configured by the end user. Dynamic entries are added to the table as a result of a learning process or protocol.

Source: The component that is responsible for this entry in the Multicast Forwarding Database. Possible values are IGMP Snooping, GMRP, and Static Filtering.

Description: The text description of this multicast table entry.

Interfaces: The list of interfaces that are designated for forwarding (Fwd:) and filtering (Flt:).

Forwarding Interfaces: The resultant forwarding list is derived from combining all the component's forwarding interfaces and removing the interfaces that are listed as the static filtering interfaces.

5.2.2.7 show mac-address-table stats

This command displays the MFDB statistics.

Syntax

show mac-address-table stats

Default Setting

None

Command Mode

Privileged Exec

Display Message

Max MFDB Table Entries: This displays the total number of entries that can possibly be in the MFDB.

Most MFDB Entries Since Last Reset: This displays the largest number of entries that have been present in the Multicast Forwarding Database table. This value is also known as the MFDB high-water mark.

Current Entries: This displays the current number of entries in the Multicast Forwarding Database table.

77



5.2.2.8 show mac-addr-table agetime

This command displays the forwarding database address aging timeout.

Syntax

show mac-addr-table agetime

Default Setting

None

Command Mode

Privileged Exec

Display Message

Address Aging Timout: This displays the total number of seconds for Forwarding Database table.

5.2.2.9 mac-addr-table aging-time

This command configures the forwarding database address aging timeout in seconds.

Syntax

mac-addr-table aging-time <10-1000000> no mac-addr-table aging-time

<10-1000000> - aging-time (Range: 10-1000000) in seconds

no - This command sets the forwarding database address aging timeout to 300 seconds.

Default Setting

300

Command Mode

5.2.3 VLAN Management

5.2.3.1 show vlan

This command displays brief information on a list of all configured VLANs.

Syntax			
show vla	in		

Default Setting

None

Command Mode

Privileged Exec

Display Message

VLAN ID: There is a VLAN Identifier (vlanid) associated with each VLAN. The range of the VLAN ID is 1 to 4093.

VLAN Name: A string associated with this VLAN as a convenience. It can be up to 16 alphanumeric characters, including blanks. The default is blank. VLAN ID 1 is always named `Default`. This field is optional.

VLAN Type: Type of VLAN, which can be Default, (VLAN ID = 1), can be static (one that is configured and permanently defined), or Dynamic (one that is created by GVRP registration).

Interface(s): Indicates by slot id and port number which port belongs to this VLAN.

5.2.3.2 show vlan id

This command displays detailed information, including interface information, for a specific VLAN.

show vlan {id <vlanid> | name <vlanname>}

<vlanid> - VLAN ID (Range: 1 – 4093)

<vlanname> - vlan name (up to 32 alphanumeric characters)

Default Setting

None

Command Mode

Privileged Exec

Display Message

VLAN ID: There is a VLAN Identifier (VID) associated with each VLAN. The range of the VLAN ID is 1 to 4093.

VLAN Name: A string associated with this VLAN as a convenience. It can be up to 32 alphanumeric characters, including blanks. The default is blank. VLAN ID 1 is always named `Default`. This field is optional.

VLAN Type: Type of VLAN, which can be Default, (VLAN ID = 1), can be static (one that is configured and permanently defined), or Dynamic (one that is created by GVRP registration).

Interface: Indicates by slot id and port number which port is controlled by the fields on this line.

It is possible to set the parameters for all ports by using the selectors on the top line.

Current: Determines the degree of participation of this port in this VLAN. The permissible values are:

Include: This port is always a member of this VLAN. This is equivalent to registration fixed in the IEEE 802.1Q standard.

Exclude: This port is never a member of this VLAN. This is equivalent to registration forbidden in the IEEE 802.1Q standard.

Autodetect: Specifies to allow the port to be dynamically registered in this VLAN via GVRP. The port will not participate in this VLAN unless a join request is received on this port. This is equivalent to registration normal in the IEEE 802.1Q standard.

Configured: Determines the configured degree of participation of this port in this VLAN. The permissible values are:

Include: This port is always a member of this VLAN. This is equivalent to registration fixed in the IEEE 802.1Q standard.

Exclude: This port is never a member of this VLAN. This is equivalent to registration forbidden in the IEEE 802.1Q standard.

Autodetect: Specifies to allow the port to be dynamically registered in this VLAN via GVRP. The port will not participate in this VLAN unless a join request is received on this port. This is equivalent to registration normal in the IEEE 802.1Q standard.

Tagging: Select the tagging behavior for this port in this VLAN.

Tagged: Specifies to transmit traffic for this VLAN as tagged frames.

Untagged: Specifies to transmit traffic for this VLAN as untagged frames.

5.2.3.3 show vlan association mac

This command displays the VLAN associated with a specific configured MAC address. If no MAC address is specified, the VLAN associations of all the configured MAC addresses are displayed.

Cumto	
Synta	X

show vlan association mac [<macaddr>]

<macaddr> - Enter a MAC Address to display the table entry for the requested MAC address.

Default Setting

None

Command Mode

Privileged Exec

Display Message

MAC Address: A unicast MAC address for which the switch has forwarding and/or filtering information. The format is 6 or 8 two-digit hexadecimal numbers that are separated by colons, for example 01:23:45:67:89:AB. In an IVL system the MAC address will be displayed as 8 bytes. In an SVL system, the MAC address will be displayed as 6 bytes. **Note: This software version only supports IVL systems.**

VLAN ID: There is a VLAN Identifier (VID) associated with each VLAN. The range of the VLAN ID is 1 to 4093.

Priority: There is a priority for each MAC-based.



5.2.3.4 show vlan association subnet

This command displays the VLAN associated with a specific configured IP-Address and net mask. If no IP Address and net mask are specified, the VLAN associations of all the configured IP-subnets are displayed.

Syntax

show vlan association subnet [<ipaddr> <netmask>]

<ipaddr> - The IP address.

<netmask> - The subnet mask.

Default Setting

None

Command Mode

Privileged Exec

Display Message

IP Subnet: The IP address assigned to each interface.

IP Mask: The subnet mask.

VLAN ID: There is a VLAN Identifier (VID) associated with each VLAN. The range of the VLAN ID is 1 to 4093.

Priority: There is a priority for each IPsubnet-based.



5.2.3.5 show vlan internal usage

This command displays the VLAN assigned to port-based routing interfaces.

Syntax

show vlan internal usage

Default Setting

None

Command Mode

Privileged Exec

Display Message

Base VLAN ID: This is the Base VLAN ID for Internal allocation of VLANs to the routing interface.

Allocation Policy: Allocation Policy for VLAN ID in ascending or descending order.

VLAN: This is the Used Internal VLAN ID for the Interface.

Usage: This is the switch interface.

5.2.3.6 show protocol group

This command displays the Protocol-based VLAN information for either the entire system, or for the indicated group.

Syntax

show protocol group [<group-name>]

<group-name> - The group name of an entry in the Protocol-based VLAN table.

no parameter - Displays the entire table.

Default Setting

None

Command Mode

Privileged Exec

Display Message

Group Name: This field displays the group name of an entry in the Protocol-based VLAN table.

Group ID: This field displays the group identifier of the protocol group.

Protocol(s): This field indicates the type of protocol(s) for this group.

VLAN: This field indicates the VLAN associated with this protocol group.

Interface(s): This field lists the slot/port interface(s) that are associated with this protocol group.

5.2.3.7 show interface switchport

This command displays VLAN port information.

Syntax

show interface switchport [{<slot/port> | port-channel <portchannel-id>}]

<slot/port> - Interface number.

cportchannel-id> - port-channel interface number. The range of port-channel ID is 1 to 64.

no parameter – Display the entire table.

Default Setting

None

Command Mode

Privileged Exec

Display Message

Interface: Indicates by slot id and port number which port is controlled by the fields on this line. It is possible to set the parameters for all ports by using the selectors on the top line.

Port VLAN ID: The VLAN ID that this port will assign to untagged frames or priority tagged frames received on this port. The value must be for an existing VLAN. The factory default is 1.

Acceptable Frame Types: Specifies the types of frames that may be received on this port. The options are 'VLAN only' and 'Admit All'. When set to 'VLAN only', untagged frames or priority tagged frames received on this port are discarded. When set to 'Admit All', untagged frames or priority tagged frames received on this port are accepted and assigned the value of the Port VLAN ID for this port. With either option, VLAN tagged frames are forwarded in accordance to the 802.1Q VLAN specification.

Ingress Filtering: May be enabled or disabled. When enabled, the frame is discarded if this port is not a member of the VLAN with which this frame is associated. In a tagged frame, the VLAN is identified by the VLAN ID in the tag. In an untagged frame, the VLAN is the Port VLAN ID specified for the port that received this frame. When disabled, all frames are forwarded in accordance with the 802.1Q VLAN bridge specification. The factory default is disabled.

GVRP: May be enabled or disabled.

Mode: Indicates this interface is operating on Access mode or General mode.

Default Priority: The 802.1p priority assigned to untagged packets arriving on the port.

5.2.3.8 vlan database

This command is used to enter VLAN Interface configuration mode.

Syntax						
vlan data	base					

Default Setting

None

Command Mode

Global Config

5.2.3.9 vlan

This command creates a new VLAN and assigns it an ID. The ID is a valid VLAN identification number (ID 1 is reserved for the default VLAN). VLAN range is 2-4093.

Syntax

vlan <vlan-list> no vlan <vlan-list>

<vlan-list> - VLAN ID (Range: 2 – 4093) – separate non-consecutive IDs with ',' and no spaces and no zeros in between the range; Use '-' for range.

no - This command deletes an existing VLAN. The ID is a valid VLAN identification number (ID 1 is reserved for the default VLAN). VLAN range is 2-4093.

Default Setting

None

Command Mode

5.2.3.10 vlan name

This command changes the name of a VLAN. The name is an alphanumeric string of up to 32 characters, and the ID is a valid VLAN identification number. ID range is 1- 4093.

Syntax		
vlan nam	me <vlan-id> <newname></newname></vlan-id>	
no vlan n	name <vlan-id></vlan-id>	

<vlan-id> - VLAN ID (Range: 1 – 4093).

<newname> - Configure a new VLAN Name (up to 32 alphanumeric characters).

no - This command sets the name of a VLAN to a blank string. The VLAN ID is a valid VLAN identification number. ID range is 1-4093.

Default Setting

The name for VLAN ID 1 is always Default. The name for other VLANs is defaulted to a blank string.

Command Mode

VLAN database

5.2.3.11 vlan association mac

This command associates a MAC address to a VLAN.

Syntax

vlan association mac <macaddr> <vlan-id> [<priority>] no vlan association mac <macaddr>

<macaddr> - Enter a MAC Address to display the table entry for the requested MAC address.

<vland-id> - VLAN identification number. ID range is 1-4093.

< priority> - The priority value for untagged frames received. Valid priority value is 0 to 7.

no - This command removes the association of a MAC address to a VLAN.

Default Setting

None

Command Mode

5.2.3.12 vlan association subnet

This command removes the association of a MAC address to a VLAN.

Syntax
Symax

vlan association subnet <ipaddr> <netmask> <vlan-id> [<priority>] no vlan association subnet <ipaddr> <netmask>

<ipaddr> - The IP address.

<netmask> - The subnet mask.

<vland-id> - VLAN identification number. ID range is 1-4093.

<priority> - The priority value for untagged frames received. Valid priority value is 0 to 7.

no - This command removes association of a specific IP-subnet to a VLAN.

Default Setting

None

Command Mode

VLAN database

5.2.3.13 vlan makestatic

This command changes a dynamically created VLAN (one that is created by GVRP registration) to a static VLAN (one that is permanently configured and defined). The ID is a valid VLAN identification number. VLAN range is 2-4093.

Syntax

vlan makestatic <vlan-id>

<vlan-id> - VLAN ID (Range: 2 -4093).

Default Setting

None

Command Mode

5.2.3.14 protocol group

This command attaches a <vlan-id> to the protocol-based VLAN identified by <group-name>. A group may only be associated with one VLAN at a time, however the VLAN association can be changed.

Syntax			
protocol g	otocol group <group-name> <vlan-id></vlan-id></group-name>		
no protoc	protocol group <group-name> <vlan-id></vlan-id></group-name>		

<vlan-id> - VLAN ID (Range: 1 – 4093).

<group-name> - a VLAN Group Name (a character string of 1 to 16 characters).

no - This command removes the <vlanid> from this protocol-based VLAN group that is identified by this <group-name>.

Default Setting

None

Command Mode

5.2.3.15 switchport acceptable-frame-type

This command sets the frame acceptance mode per interface. For VLAN Only mode, untagged frames or priority frames received on this interface are discarded. For Admit All mode, untagged frames or priority frames received on this interface are accepted and assigned the value of the interface VLAN ID for this port. With either option, VLAN tagged frames are forwarded in accordance with the IEEE 802.1Q VLAN specification.

Syntax
Syntax

switchport acceptable-frame-type {tagged | all} no switchport acceptable-frame-type {tagged | all}

tagged - VLAN only mode.

all - Admit all mode.

no - This command sets the frame acceptance mode per interface to **Admit All**. For Admit All mode, untagged frames or priority frames received on this interface are accepted and assigned the value of the interface VLAN ID for this port. With either option, VLAN tagged frames are forwarded in accordance with the IEEE 802.1Q VLAN Specification.

Default Setting

Admit all

Command Mode

Interface Config

This command sets the frame acceptance mode for all interfaces. For VLAN Only mode, untagged frames or priority frames received on this interface are discarded. For Admit All mode, untagged frames or priority frames received on this interface are accepted and assigned the value of the interface VLAN ID for this port. With either option, VLAN tagged frames are forwarded in accordance with the IEEE 802.1Q VLAN specification.

Syntax

switchport acceptable-frame-type all {tagged | all} no switchport acceptable-frame-type all {tagged | all}

tagged - VLAN only mode.

all - One is for Admit all mode. The other one is for all interfaces.

no - This command sets the frame acceptance mode for all interfaces to **Admit All**. For Admit All mode, untagged frames or priority frames received on this interface are accepted and assigned the value of the interface VLAN ID for this port. With either option, VLAN tagged frames are forwarded in accordance with the IEEE 802.1Q VLAN Specification.

91



Default Setting

Admit all

Command Mode

5.2.3.16 switchport ingress-filtering

This command enables ingress filtering. If ingress filtering is disabled, frames received with VLAN IDs that do not match the VLAN membership of the receiving interface are admitted and forwarded to ports that are members of that VLAN.

Syntax		
switchpor	rt ingress-filtering	
no switch	nport ingress-filtering	

no - This command disables ingress filtering. If ingress filtering is disabled, frames received with VLAN IDs that do not match the VLAN membership of the receiving interface are admitted and forwarded to ports that are members of that VLAN.

Default Setting

Disabled

Command Mode

Interface Config

This command enables ingress filtering for all ports. If ingress filtering is disabled, frames received with VLAN IDs that do not match the VLAN membership of the receiving interface are admitted and forwarded to ports that are members of that VLAN.

Syntax

switchport ingress-filtering all no switchport ingress-filtering all

all - All interfaces.

no - This command disables ingress filtering for all ports. If ingress filtering is disabled, frames received with VLAN IDs that do not match the VLAN membership of the receiving interface are admitted and forwarded to ports that are members of that VLAN.

Default Setting

Disabled

Command Mode

5.2.3.17 switchport mode access

This command configures the an interface to be operated on VLAN access mode. In this mode, only one VLAN could be assigned to this interface. Use 'switchport access vlan <vlan-id>' to configure the access VLAN. In VLAN access mode, only the untagged packets are handled.

Syntax	
switchpor	rt mode access
no switch	nport mode access

no - This command sets the mode to General.

Default Setting

General Mode

Command Mode

Interface Config

5.2.3.18 switchport access vlan

This command configures the access VLAN ID for an interface if it is operated on access VLAN mode.

switchport access vlan <vlan-id> no switchport access vlan

<vlan-id> - VLAN ID (Range: 1 – 4093).

no - This command sets the access VLAN ID to 1.

Default Setting

1

Command Mode

Interface Config

5.2.3.19 switchport native vlan

This command changes the VLAN ID which will be assigned to untagged or priority tagged frames per interface.

Syntax	,
Synta	•

switchport native vlan <vlan-id> no switchport native vlan <vlan-id>

<vlan-id> - VLAN ID (Range: 1 – 4093).

no - This command sets the VLAN ID per interface to 1.

Default Setting

1

Command Mode

Interface Config

This command changes the VLAN ID which will be assigned to untagged or priority tagged frames for all interfaces.

Syntax

switchport native vlan all <vlan-id>

<vlan-id> - VLAN ID (Range: 1 – 4093).

all - All interfaces.

no - This command sets the VLAN ID for all interfaces to 1.

Default Setting

1

Command Mode

5.2.3.20 switchport allowed vlan

This command configures the degree of participation for a specific interface in a VLAN. The ID is a valid VLAN identification number, and the interface is a valid interface number.

C.,	
ЭV	ntax

switchport allowed vlan {add [tagged | untagged] | remove} <vlan-list>

<vlan-list> - VLAN ID (Range: 1 – 4093) – separate non-consecutive IDs with ',' and no spaces and no zeros in between the range; Use '-' for range.

add - The interface is always a member of this VLAN. This is equivalent to registration fixed.

tagged - All frames transmitted for this VLAN will be tagged.

untagged - All frames transmitted for this VLAN will be untagged.

remove - The interface is removed from the member of this VLAN. This is equivalent to registration forbidden.

Default Setting

None

Command Mode

Interface Config

This command configures the degree of participation for all interfaces in a VLAN. The ID is a valid VLAN identification number.

Syntax

switchport allowed vlan {add {tagged | untagged} | remove} all <vlan-id>

<vlan-id> - VLAN ID (Range: 1 - 4093).

all - All interfaces.

add - The interface is always a member of this VLAN. This is equivalent to registration fixed.

tagged - all frames transmitted for this VLAN will be tagged.

untagged - all frames transmitted for this VLAN will be untagged.

remove - The interface is removed from the member of this VLAN. This is equivalent to registration forbidden.

Default Setting

None

Command Mode

5.2.3.21 switchport tagging

This command configures the tagging behavior for a specific interface in a VLAN to enable. If tagging is enabled, traffic is transmitted as tagged frames. If tagging is disabled, traffic is transmitted as untagged frames. The ID is a valid VLAN identification number.

Syntax	
Syntax	

switchport tagging <vlan-list> no switchport tagging <vlan-list>

<vlan-list> - VLAN ID (Range: 1 – 4093) – separate non-consecutive IDs with ',' and no spaces and no zeros in between the range; Use '-' for range.

no - This command configures the tagging behavior for a specific interface in a VLAN to disabled. If tagging is disabled, traffic is transmitted as untagged frames. The ID is a valid VLAN identification number.

Default Setting

Disabled

Command Mode

Interface Config

This command configures the tagging behavior for all interfaces in a VLAN to be enabled. If tagging is enabled, traffic is transmitted as tagged frames. If tagging is disabled, traffic is transmitted as untagged frames. The ID is a valid VLAN identification number.

Syntax

switchport tagging all <vlan-id>

<vlan-id> - VLAN ID (Range: 1 – 4093).

all - All interfaces

no - This command configures the tagging behavior for all interfaces in a VLAN to disabled. If tagging is disabled, traffic is transmitted as untagged frames. The ID is a valid VLAN identification number.

Default Setting

Disabled

Command Mode

5.2.3.22 switchport forbidden vlan

This command used to configure forbidden VLANs.

Syntax
c yman

switchport forbidden vlan {add | remove} <vlan-list> no switchport forbidden

<vlan-list> - VLAN ID (Range: 1 – 4093) – separate non-consecutive IDs with ',' and no spaces and no zeros in between the range; Use '-' for range.

add - VLAND ID to add.

remove - VLAND ID to remove.

no - Remove the list of forbidden VLANs.

Default Setting

None

Command Mode

Interface Config

5.2.3.23 switchport priority

This command configures the default 802.1p port priority assigned for untagged packets for a specific interface.

Syntax

switchport priority <0-7>	
no switchport priority	

<0-7> - The range for the priority is 0 - 7.

no – This command restore the priority configuration to default value.

Default Setting

0

Command Mode

Interface Config

99

This command configures the port priority assigned for untagged packets for all ports presently plugged into the device. Any subsequent per port configuration will override this configuration setting.

Syntax

switchport priority all <0-7> no switchport priority all

<0-7> - The range for the priority is 0-7.

all - All interfaces

no - This command restores the priority value to default value for all interfaces.

Default Setting

0

Command Mode

Global Config

5.2.3.24 switchport protocol group

This command adds the physical interface to the protocol-based VLAN identified by <group-name>. A group may have more than one interface associated with it. Each interface and protocol combination can only be associated with one group. If adding an interface to a group causes any conflicts with protocols currently associated with the group, this command will fail, and the interface(s) will not be added to the group.

Syntax

switchport protocol group <group-name> no switchport protocol group <group-name>

<group-name> - a VLAN Group Name (a character string of 1 to 16 characters).

no - This command removes the interface from this protocol-based VLAN group that is identified by this <group-name>.

Default Setting

None

Command Mode

Interface Config

This command adds a protocol-based VLAN group to the system. The *group-name* is a character string of 1 to 16 characters. When it is created, the protocol group will be assigned a unique number that will be used to identify the group in subsequent commands.

Syntax

switchport protocol group <group-name> no switchport protocol group <group-name>

<group-name> - a VLAN Group Name (a character string of 1 to 16 characters).

no - This command removes the protocol-based VLAN group that is identified by this <group-name>.

Default Setting

None

Command Mode

Global Config

This command adds all physical interfaces to the protocol-based VLAN identified by *<group-name>*. A group may have more than one interface associated with it. Each interface and protocol combination can only be associated with one group. If adding an interface to a group causes any conflicts with protocols currently associated with the group, this command will fail, and the interface(s) will not be added to the group.

Syntax

switchport protocol group all <group-name> no switchport protocol group all <group-name>

<group-name> - a VLAN Group Name (a character string of 1 to 16 characters).

all - All interfaces.

no - This command removes all interfaces from this protocol-based VLAN group that is identified by this <group-name>.

Default Setting

None

Command Mode

This command adds the <protocol> to the protocol-based VLAN identified by <group-name>. A group may have more than one protocol associated with it. Each interface and protocol combination can only be associated with one group. If adding a protocol to a group causes any conflicts with interfaces currently associated with the group, this command will fail, and the protocol will not be added to the group. The possible values for protocol are *ip, arp,* and *ipx*.

Syntax

switchport protocol group add protocol <group-name> {ip | arp | ipx} no switchport protocol group add protocol <group-name> {ip | arp | ipx}

<group-name> - a VLAN Group Name (a character string of 1 to 16 characters).

ip - IP protocol.

arp - ARP protocol.

ipx - IPX protocol.

no - This command removes the *<protocol>* from this protocol-based VLAN group that is identified by this *<group-name>*. The possible values for protocol are *ip*, *arp*, and *ipx*.

Default Setting

None

Command Mode

5.2.4 Double VLAN commands

5.2.4.1 show dvlan-tunnel/ dot1q-tunnel

This command is used without the optional parameters to display all interfaces enabled for Double VLAN Tunneling. Use the optional parameters to display detailed information about Double VLAN Tunneling for the specified interface or all interfaces.

Syntax

show {dot1q-tunnel | dvlan-tunnel} [interface {<slot/port> | port-channel <portchannel-id>}]

<slot/port> - Specifies the desired interface.

cportchannel-id> - Specifies the desired port-channel interface. The range of port-channel ID is 1 to 64.

Default Setting

None

Command Mode

Privileged Exec

Display Message

Interfaces Enabled for DVLAN Tunneling: Valid interface(s) support(s) DVLAN Tunneling.

When using 'show {dot1q-tunnel|dvlan-tunnel} interface':

Interface: Valid slot and port number separated by forward slashes.

Mode: This field specifies the administrative mode through which Double VLAN Tunneling can be enabled or disabled. The default value for this field is disabled.

EtherType This field represents a 2-byte hex EtherType to be used as the first 16 bits of the DVLAN tunnel. There are three different EtherType tags. The first is 802.1Q, which represents the commonly used value of 0x8100. The second is vMAN, which represents the commonly used value of 0x88A8. If EtherType is not one of these two values, then it is a custom tunnel value, representingany value in the range of 0 to 65535.



5.2.4.2 switchport dvlan-tunnel/ dot1q-tunnel

This command is used to enable Double VLAN Tunneling on the specified interface.

-	
Sv	ntax

switchport {dvlan-tunnel | dot1q-tunnel} no switchport {dvlan-tunnel | dot1q-tunnel}

Default Setting

Disable

Command Mode

Interface Config

5.2.4.3 switchport dvlan-tunnel/ dot1q-tunnel ethertype

This command configures the ether-type for specific interface. The ether-type may have the values of *802.1Q*, *vMAN*, or *custom*. If the ether-type has a value of *custom*, the optional value of the custom ether type must be set to a value from 0 to 65535.

Syntax

switchport {dvlan-tunnel | dot1q-tunnel } [ethertype {802.1Q | custom <0-65535> | vman}] no switchport {dvlan-tunnel | dot1q-tunnel} [ethertype]

Default Setting

802.1Q

Command Mode

Interface Config



5.2.5 GVRP and Bridge Extension

5.2.5.1 show bridge-ext

This command displays Generic Attributes Registration Protocol (GARP) information.

Sy	ntax									
show bridge-ext										

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Message

GMRP Admin Mode: This displays the administrative mode of GARP Multicast Registration Protocol (GMRP) for the system.

GVRP Admin Mode: This displays the administrative mode of GARP VLAN Registration Protocol (GVRP) for the system.

5.2.5.2 show gvrp configuration

This command displays Generic Attributes Registration Protocol (GARP) information for one or all interfaces.

Syntax

show gvrp configuration [{<slot/port> | port-channel <portchannel-id>}]

<slot/port> - Specifies the desired interface.

cportchannel-id> - Specifies the port-channel interface. The range of port-channel ID is 1 to 64.

no parameter - All interfaces.

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Message

Interface: This displays the slot/port of the interface that this row in the table describes.

Join Timer: Specifies the interval between the transmission of GARP PDUs registering (or re-registering) membership for an attribute. Current attributes are a VLAN or multicast group. There is an instance of this timer on a per-Port, per-GARP participant basis. Permissible values are 10 to 100 centiseconds (0.1 to 1.0 seconds). The factory default is 20 centiseconds (0.2 seconds). The finest granularity of specification is 1 centisecond (0.01 seconds).

Leave Timer: Specifies the period of time to wait after receiving an unregister request for an attribute before deleting the attribute. Current attributes are a VLAN or multicast group. This may be considered a buffer time for another station to assert registration for the same attribute in order to maintain uninterrupted service. There is an instance of this timer on a per-Port, per-GARP participant basis. Permissible values are 20 to 600 centiseconds (0.2 to 6.0 seconds). The factory default is 60 centiseconds (0.6 seconds). The finest granularity of specification is 1 centisecond (0.01 seconds).

LeaveAll Timer: This Leave All Time controls how frequently LeaveAll PDUs are generated. A LeaveAll PDU indicates that all registrations will shortly be deregistered. Participants will need to rejoin in order to maintain registration. There is an instance of this timer on a per-Port, per-GARP participant basis. The Leave All Period Timer is set to a random value in the range of LeaveAll-Time to 1.5*LeaveAllTime. Permissible values are 200 to 6000 centiseconds (2 to 60 seconds). The factory default is 1000 centiseconds (10 seconds). The finest granularity of specification is 1 centisecond (0.01 seconds).

Port GVRP Mode: Indicates the GVRP administrative mode for the port. It may be enabled or disabled. If this parameter is disabled, Join Time, Leave Time, and Leave All Time have no effect. The factory default is disabled.

5.2.5.3 show gmrp configuration

This command displays Generic Attributes Registration Protocol (GARP) information for one or All interfaces.

Syntax

show gmrp configuration [{<slot/port> | port-channel <portchannel-id>}]

<slot/port> - Specifies the desired interface.

cportchannel-id> - Specifies the desired port-channel interface. The range of port-channel ID is 1 to 64.

no parameter - All interfaces.

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Message

Interface: This displays the slot/port of the interface that this row in the table describes.

Join Timer: Specifies the interval between the transmission of GARP PDUs registering (or re-registering) membership for an attribute. Current attributes are a VLAN or multicast group. There is an instance of this timer on a per-Port, per-GARP participant basis. Permissible values are 10 to 100 centiseconds (0.1 to 1.0 seconds). The factory default is 20 centiseconds (0.2 seconds). The finest granularity of specification is 1 centisecond (0.01 seconds).

Leave Timer: Specifies the period of time to wait after receiving an unregister request for an attribute before deleting the attribute. Current attributes are a VLAN or multicast group. This may be considered a buffer time for another station to assert registration for the same attribute in order to maintain uninterrupted service. There is an instance of this timer on a per-Port, per-GARP participant basis. Permissible values are 20 to 600 centiseconds (0.2 to 6.0 seconds). The factory default is 60 centiseconds (0.6 seconds). The finest granularity of specification is 1 centisecond (0.01 seconds).

LeaveAll Timer: This Leave All Time controls how frequently LeaveAll PDUs are generated. A LeaveAll PDU indicates that all registrations will shortly be deregistered. Participants will need to rejoin in order to maintain registration. There is an instance of this timer on a per-Port, per-GARP participant basis. The Leave All Period Timer is set to a random value in the range of LeaveAll-Time to 1.5*LeaveAllTime. Permissible values are 200 to 6000 centiseconds (2 to 60 seconds). The factory default is 1000 centiseconds (10 seconds). The finest granularity of specification is 1 centisecond (0.01 seconds).

Port GMRP Mode: Indicates the GMRP administrative mode for the port. It may be enabled or disabled. If this parameter is disabled, Join Time, Leave Time, and Leave All Time have no effect. The factory default is disabled.

107

5.2.5.4 show garp configuration

This command displays GMRP and GVRP configuration information for one or all interfaces.

Syntax

show garp configuration [{<slot/port> | port-channel <portchannel-id>}]

<slot/port> - Specifies the desired interface.

<portchannel-id> - Specifies the desired port-channel interface. The range of port-channel ID is 1 to 64.

no parameter - All interfaces.

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Message

Interface: This displays the slot/port of the interface that this row in the table describes.

GVRP Mode: Indicates the GVRP administrative mode for the port. It may be enabled or disabled. If this parameter is disabled, Join Time, Leave Time, and Leave All Time have no effect. The factory default is disabled.

GMRP Mode: Indicates the GMRP administrative mode for the port. It may be enabled or disabled. If this parameter is disabled, Join Time, Leave Time, and Leave All Time have no effect. The factory default is disabled.



5.2.5.5 bridge-ext gvrp

This command enables GVRP.

Syntax	
hridaa-av	t avro

bridge-ext gvrp no bridge-ext gvrp

no - This command disables GVRP.

Default Setting

Disabled

Command Mode

Global Config

5.2.5.6 bridge-ext gmrp

This command enables GARP Multicast Registration Protocol (GMRP) on the system. The default value is disabled.

Syntax

bridge-ext gmrp no bridge-ext gmrp

no - This command disables GARP Multicast Registration Protocol (GMRP) on the system.

Default Setting

Disabled

Command Mode

5.2.5.7 switchport gvrp

This command enables GVRP (GARP VLAN Registration Protocol) for a specific port.

Syntax	ĸ	
switchpor		
no switch	tchport gvrp	

no - This command disables GVRP (GARP VLAN Registration Protocol) for a specific port. If GVRP is disabled, Join Time, Leave Time, and Leave All Time have no effect.

Default Setting

Disabled

Command Mode

Interface Config

This command enables GVRP (GARP VLAN Registration Protocol) for all ports.

Syntax			
switchpo	rt gvrp all		
no switch	nport gvrp all		

all - All interfaces.

no - This command disables GVRP (GARP VLAN Registration Protocol) for all ports. If GVRP is disabled, Join Time, Leave Time, and Leave All Time have no effect.

Default Setting

Disabled

Command Mode



5.2.5.8 switchport gmrp

This command enables GMRP Multicast Registration Protocol on a selected interface. If an interface which has GMRP enabled is enabled for routing or is enlisted as a member of a port-channel (LAG), GMRP functionality will be disabled on that interface. GMRP functionality will subsequently be re-enabled if routing is disabled or port-channel (LAG) membership is removed from an interface that has GMRP enabled.

switchport gmrp no switchport gmrp	S	yntax							
			D						

no - This command disables GMRP Multicast Registration Protocol on a selected interface. If an interface which has GMRP enabled is enabled for routing or is enlisted as a member of a port-channel (LAG), GMRP functionality will be disabled on that interface. GMRP functionality will subsequently be re-enabled if routing is disabled or port-channel (LAG) membership is removed from an interface that has GMRP enabled.

Default Setting

Disabled

Command Mode

Interface Config

This command enables GMRP Multicast Registration Protocol on all interfaces. If an interface which has GMRP enabled is enabled for routing or is enlisted as a member of a port-channel (LAG), GMRP functionality will be disabled on that interface. GMRP functionality will subsequently be re-enabled if routing is disabled and port-channel (LAG) membership is removed from an interface that has GMRP enabled.

Syntax

switchport gmrp all	
no switchport gmrp all	

all - All interfaces.

no - This command disables GMRP Multicast Registration Protocol on all interfaces.

Default Setting

Disabled

Command Mode



5.2.5.9 garp timer

This command sets the GVRP join time per port and per GARP. Join time is the interval between the transmission of GARP Protocol Data Units (PDUs) registering (or re-registering) membership for a VLAN or multicast group.

This command has an effect only when GVRP and GMRP are enabled. The time is from 10 to 100 (centiseconds).

Syntax			
garp time	er join <10-100>		
no garp ti	imer join		

<10-100> - join time (Range: 10 – 100) in centiseconds.

no - This command sets the GVRP join time per port and per GARP to 20 centiseconds (0.2 seconds). This command has an effect only when GVRP and GMRP are enabled.

Default Setting

20 centiseconds (0.2 seconds)

Command Mode

Interface Config

This command sets the GVRP join time for all ports and per GARP. Join time is the interval between the transmission of GARP Protocol Data Units (PDUs) registering (or re-registering) membership for a VLAN or multicast group.

This command has an effect only when GVRP and GMRP are enabled. The time is from 10 to 100 (centiseconds).

Syntax

garp timer join all < 10-100 > no garp timer join all

<10-100> - join time (Range: 10 – 100) in centiseconds.

all - All interfaces.

no - This command sets the GVRP join time for all ports and per GARP to 20 centiseconds (0.2 seconds). This command has an effect only when GVRP and GMRP are enabled.

Default Setting



20 centiseconds (0.2 seconds)

Command Mode

Global Config

This command sets the GVRP leave time per port. Leave time is the time to wait after receiving an unregister request for a VLAN or a multicast group before deleting the VLAN entry. This can be considered a buffer time for another station to assert registration for the same attribute in order to maintain uninterrupted service. The time is from 20 to 600 (centiseconds).



This command has an effect only when GVRP and GMRP are enabled.

-
Syntax
Ojinar

garp timer leave < 20-600 > no garp timer leave

<20-600> - leave time (Range: 20 – 600) in centiseconds.

no - This command sets the GVRP leave time per port to 60 centiseconds (0.6 seconds).

Default Setting

60 centiseconds (0.6 seconds)

Command Mode

Interface Config

This command sets the GVRP leave time for all ports. Leave time is the time to wait after receiving an unregister request for a VLAN or a multicast group before deleting the VLAN entry. This can be considered a buffer time for another station to assert registration for the same attribute in order to maintain uninterrupted service. The time is from 20 to 600 (centiseconds).



This command has an effect only when GVRP and GMRP are enabled.

Syntax

garp timer leave all < 20-600 > no garp timer leave all

<20-600> - leave time (Range: 20 – 600) in centiseconds.

all - All interfaces.

113

no - This command sets the GVRP leave time for all ports to the default 60 centiseconds (0.6 seconds).

Default Setting

60 centiseconds (0.6 seconds)

Command Mode

Global Config

This command sets how frequently Leave All PDUs are generated per port. A Leave All PDU indicates that all registrations will be unregistered. Participants would need to rejoin in order to maintain registration. The value applies per port and per GARP participation. The time may range from 200 to 6000 (centiseconds).



This command has an effect only when GVRP and GMRP are enabled.

Syntax

garp timer leaveall < 200-6000 > no garp timer leaveall

<200-6000> - leave time (Range: 200 - 6000) in centiseconds.

no - This command sets how frequently Leave All PDUs are generated per port to 1000 centiseconds (10 seconds).

Default Setting

1000 centiseconds (10 seconds)

Command Mode

Interface Config

This command sets how frequently Leave All PDUs are generated for all ports. A Leave All PDU indicates that all registrations will be unregistered. Participants would need to rejoin in order to maintain registration. The value applies per port and per GARP participation. The time may range from 200 to 6000 (centiseconds).



This command has an effect only when GVRP and GMRP are enabled.

Syntax

garp timer leaveall all < 200-6000 > no garp timer leaveall all

<200-6000> - leave time (Range: 200 - 6000) in centiseconds.

all - All interfaces.

no - This command sets how frequently Leave All PDUs are generated for all ports to 1000 centiseconds (10 seconds).

Default Setting

1000 centiseconds (10 seconds)

Command Mode

5.2.6 IGMP Snooping

5.2.6.1 ip igmp snooping

The user can go to the CLI Global Configuration Mode to set IGMP Snooping on the system, use the **ip igmp snooping** global configuration command. Use the **no ip igmp snooping** to disable IGMP Snooping on the system.

Syntax		
ip igmp snooping no ip igmp snoop		

Default Setting

Disabled

Command Mode

Global Config

5.2.6.2 clear igmp snooping

The user can go to the CLI Privilege Exec to clear IGMP Snooping entries from the MFDB table, use the **clear igmp snooping** priviledge configuration command.

Syntax			
clear igm	p snooping		

Default Setting

None

Command Mode

Privilege Exec

5.2.6.3 ip igmp snooping interfacemode

The user can go to the CLI Global/Interface Configuration Mode to set IGMP Snooping on one interface or all interfaces, use the **ip igmp snooping interfacemode** global/interface configuration command. Use the **no ip igmp snooping interfacemode** disable IGMP Snooping on all interfaces.

Syntax

ip igmp snooping interfacemode all no ip igmp snooping interfacemode all ip igmp snooping interfacemode no ip igmp snooping interfacemode

Default Setting

None

Command Mode

Global Config

Interface Config

5.2.6.4 ip igmp snooping fast-leave

The user can go to the CLI Global/Interface Configuration Mode to set IGMP Snooping fast-leave admin mode on a selected interface or all interfaces, use the **ip igmpsnooping fast-leave** global/interface configuration command. Use the **no ip igmp snooping fast-leave** disable IGMP Snooping fast-leave admin mode.

Cuntox	
Syntax	

ip igmp snooping fast-leave no ip igmp snooping fast-leave

Default Setting

Disabled

Command Mode

Global Config

Interface Config

5.2.6.5 ip igmp snooping groupmembershipinterval

The user can go to the CLI Global/Interface Configuration Mode to set the IGMP Group Membership Interval time on one interface or all interfaces, use the **ip igmp snooping groupmembershipinterval**

<2-3600> global/interface configuration command. Use the no ip igmp snooping groupmembershipinterval return to default value 260.

Syntax

ip igmp snooping groupmembershipinterval <2-3600> no ip igmp snooping groupmembershipinterval

<2-3600> -- This value must be greater than the IGMPv3 Maximum Response time value. The range is 2 to 3600 seconds.

Default Setting

260

Command Mode

Global Config

Interface Config

5.2.6.6 ip igmp snooping mcrtrexpiretime

The user can go to the CLI Interface Global/Interface Configuration Mode to set the Multicast Router Present Expiration time for the system or on a particular interface, use the ip igmp snooping mcrtrexpiretime <0-3600> global/interface configuration command. Use the no ip igmp snooping mcrtrexpiretime to return to default value 0.

Syntax

ip igmp snooping mcrtrexpiretime <0-3600> no ip igmp snooping mcrtrexpiretime

<0-3600> - The range is 0 to 3600 seconds. A value of 0 indicates an infinite time-out, i.e. no expiration.

Default Setting

0

Command Mode

Global Config

Interface Config

5.2.6.7 ip igmp snooping mrouter interface

The user can go to the CLI Interface Configuration Mode to configure the interface as a multicast router-attached interface or configure the VLAN ID for the VLAN that has the multicast router attached mode enabled, use the **ip igmp snooping mrouter interface**|<vlanid> interface configuration command. Use the **no ip igmp snooping mrouter interface**|<vlan-id> disable multicast router attached mode for the interface or a VLAN.

SI	nt	a	Y

ip igmp snooping mrouter interface|<vlan-id> no ip igmp snooping mrouter interface|<vlan-id>

<vlan-id> - VLAN ID (Range: 1 – 4093).

Default Setting

None

Command Mode

Interface Config

5.2.6.8 set igmp

The user can go to the CLI VLAN database Mode to set IGMP Snooping on a particular VLAN, use the **set ipgm <vlan-id>** vlan configuration command. Use the **no set igmp <vlan-id>** to disable IGMP Snooping on a particular VLAN.

Syntax	
set igmp	<vlan-id></vlan-id>
no set igr	mp <vlan-id></vlan-id>

<vlan-id> - VLAN ID (Range: 1 – 4093).

Default Setting

Disabled

Command Mode

5.2.6.9 set igmp fast-leave

The user can go to the CLI VLAN Configuration Mode to set IGMP Snooping fast-leave admin mode on a particular VLAN, use the **set igmp fast-leave <vlan-id>** vlan configuration command. Use the **no set igmp fast-leave <vlan-id>** disable IGMP Snooping fast-leave admin mode.

Syntax

set igmp fast-leave <vlan-id> no set igmp fast-leave <vlan-id>

<vlan-id> - VLAN ID (Range: 1 – 4093).

Default Setting

Disabled

Command Mode



5.2.6.10 set igmp groupmembership-interval

The user can go to the CLI VLAN Configuration Mode to set the IGMP Group Membership Interval time on a particular VLAN, use the **set igmpgroupmembership-interval <vlan-id> <2-3600>** vlan configuration command. Use the **no set igmp groupmembership-interval <vlan-id>** return to default value 260.

Syntax	

set igmp groupmembership-interval <vlan-id> <2-3600> no set igmp groupmembership-interval <vlan-id>

<vlan-id> - VLAN ID (Range: 1 – 4093).

<2-3600> - The range of group membership interval time is 2 to 3600 seconds.

Default Setting

260

Command Mode

VLAN database

5.2.6.11 set igmp maxresponse

The user can go to the CLI Interface VLAN database Mode to set the IGMP Maximum Response time on a particular VLAN, use the **set igmp maxresponse <vlan-id> <1-25>** vlan configuration command. Use the **no set igmp maxresponse <vlan-id>** return to default value 10

Syntax

set igmp maxresponse <vlan-id> <1-25> no set igmp maxresponse <vlan-id>

<vlan-id> - VLAN ID (Range: 1 – 4093).

<1-25> - This value must be less than the IGMP Query Interval time value. The range is 1 to 25 seconds.

Default Setting

10

Command Mode

5.2.6.12 set igmp mcrtrexpiretime

The user can go to the CLI Interface VLAN Configuration Mode to set the Multicast Router Present Expiration time on a particular VLAN, use the **set igmp mcrtrexpiretime <vlan-id> <0-3600>** vlan configuration command. Use the **no set igmp mcrtrexpiretime <vlan-id>** to return to default value 0.

Syntax

set igmp mcrtrexpiretime <vlan-id> <0-3600> no set igmp mcrtrexpiretime <vlan-id>

<vlan-id> - VLAN ID (Range: 1 – 4093).

<0-3600> - The range of the Multicat Router Present Expire time is 0 to 3600 seconds

Default Setting

0

Command Mode

VLAN database

5.2.6.13 set igmp report-suppression

The user can go to the CLI VLAN Configuration Mode to set IGMP Snooping report-suppression admin mode on a particular VLAN, use the **set igmp report-suppression <vlan-id>** vlan configuration command. Use the **no set igmp report-suppression <vlan-id>** disable IGMP Snooping report-suppression admin mode.

Syntax

set igmp report-suppression <vlan-id> no set igmp report-suppression <vlan-id>

<vlan-id> - VLAN ID (Range: 1 - 4093).

Default Setting

Disable

Command Mode

5.2.6.14 set snoop-vlan-block

The user can go to the CLI VLAN Configuration Mode to set IGMP/MLD Snooping snoop-vlan-block admin mode on a particular VLAN, use the **set snoop-vlan-block <vlan-id>** vlan configuration command. Use the **no set snoop-vlan-block <vlan-id>** disable IGMP Snooping snoop-vlan-block admin mode.

Syntax

set snoop-vlan-block <vlan-id> no set snoop-vlan-block <vlan-id>

<vlan-id> - VLAN ID (Range: 1 – 4093).

Default Setting

Disable

Command Mode

VLAN database

5.2.6.15 ip igmp snooping static

The user can go to the Global Mode and add a port to multicast group, use the **ip igmp snooping static** Global command. The MAC address of the L2Mcast Group in the format 01:00:5e:xx:xx:xx.

Syntax

ip igmp snooping static <macaddr> vlan <vlan-id> interface {<slot/port> | port-channel <portchannel-id>} no ip igmp snooping static <macaddr> vlan <vlan-id> interface {<slot/port> | port-channel <portchannel-id>}

<vlan-id> - VLAN ID (Range: 1 – 4093).

<macaddr> - Static MAC address.

<slot/port> - Interface number.

<portchannel-id> - Port-channel interface number. The range of port-channel ID is 1 to 64.

Default Setting

None

Command Mode

5.2.6.16 ip igmp snooping router-alert-check

The user can go to the CLI Global Configuration Mode to set IGMP Snooping router-alert-check admin mode on the system, use the **ip igmpsnooping router-alert-check** global configuration command. Use the **no ip igmp snooping router-alert-check** disable IGMP Snooping router-alert-check admin mode.

Syntax	
--------	--

ip igmp snooping router-alert-check no ip igmp snooping router-alert-check

Default Setting

Disabled

Command Mode

Global Config

5.2.6.17 show ip igmp snooping

The user can go to the CLI Privilege Exec to get all of igmp snooping information, use the **show ip igmp snooping** Privilege command.

Syntax

show ip igmp snooping [interface <slot/port> | vlan <vlan-id> | port-channel <portchannel-id>]

<slot/port> - Interface number.

<vlan-id> - VLAN ID (Range: 1 – 4093).

<portchannel-id> - Port-channel interface number. The range of port-channel ID is 1 to 64.

Default Setting

None

Command Mode

Privilege Exec

Display Message

When the optional arguments <slot/port>, <portchannel-id> or <vlan-id> are not used, the command displays the following information.

Admin Mode: Indicates whether or not IGMP Snooping is active on the switch.

Interfaces Enabled for IGMP Snooping: Interfaces on which IGMP Snooping is enabled.

Multicast Control Frame Count: Displays the number of IGMP Control frames that are processed by the CPU.

IGMP Snooping Router-Alert check: Admin mode of IGMP Snooping Router-Alert check.

VLANs Enabled for IGMP Snooping: VLANs on which IGMP Snooping is enabled.

VLANs Block enabled for snooping: VLANs on which IGMP/MLD Snooping is blocked.

When you specify the <slot/port> or <portchannel-id> values, the following information displays.

IGMP Snooping Admin Mode: Indicates whether IGMP Snooping is active on the interface.

Fast Leave Mode: Indicates whether IGMP Snooping Fast Leave is active on the interface.

Group Membership Interval: Shows the amount of time in seconds that a switch will wait for a report from a particular group on a particular interface, which is participating on the interface, before deleting the interface from the entry. This value may be configured.

Multicast Router Expiry Time: Displays the amount of time to wait before removing an interface that is participating on the interface from the list of interfaces with multicast routers attached. The interface is removed if a query is not received. This value may be configured.

When you specify a value for <vlan-id>, the following information appears.

VLAN ID: VLAN Id

IGMP Snooping Admin Mode: Indicates whether IGMP Snooping is active on the VLAN.

Fast Leave Mode: Indicates whether IGMP Snooping Fast Leave is active on the VLAN.

Group Membership Interval: Shows the amount of time in seconds that a switch will wait for a report from a particular group on a particular interface, which is participating in the VLAN, before deleting the interface from the entry. This value may be configured.

Max Response Time: VLANs on which IGMP Snooping is enabled.

Multicast Router Expiry Time: Displays the amount of time to wait before removing an interface that is participating in the VLAN from the list of interfaces with multicast routers attached. The interface is removed if a query is not received. This value may be configured.

Report Suppression Mode: Admin mode of IGMP Snooping Report Suppression Mode.

Vian Block Mode: VLANs on which IGMP/MLD Snooping is blocked.

5.2.6.18 show ip igmp snooping mrouter interface

The user can go to the CLI Privilege Exec to display information about statically configured multicast router-attached interfaces, use the **show ip igmp snooping mrouter interface** Privilege command.

Syntax	
Oyntur.	

show ip igmp snooping mrouter interface {<slot/port> | port-channel <portchannel-id>}

<slot/port> - Interface number.

<portchannel-id> - Port-channel interface number. The range of port-channel ID is 1 to 64.

Default Setting

None

Command Mode

Privilege Exec

Display Message

Interface: Shows the interface on which multicast router information is being displayed.

Multicast Router Attached: Indicates whether multicast router is statically enabled on the interface.

5.2.6.19 show ip igmp snooping mrouter vlan

The user can go to the CLI Privilege Exec to display information about statically configured multicast router-attached interfaces, use the **show ip igmp snooping mrouter vlan** Privilege command.

Syntax	
Symax	

show ip igmp snooping mrouter vlan {<slot/port> | port-channel <portchannel-id>}

<slot/port> - Interface number.

<portchannel-id> - Port-channel interface number. The range of port-channel ID is 1 to 64.

Default Setting

None

Command Mode

Privilege Exec

Display Message

VLAN ID: Displays the list of VLANs of which the interface is a member.

Interface: Shows the interface on which multicast router information is being displayed.

5.2.6.20 show ip igmp snooping static

The user can go to the Privilege Exec to display IGMP snooping static information, use the **show ip igmp snooping static** Privilege command.

Syntax

show ip igmp snooping static

Default Setting

None

Command Mode

Privilege Exec

Display Message

VLAN: The VLAN ID used with the MAC address to fully identify packets you want L2Mcast Group.

MAC Address: The MAC address of the L2Mcast Group in the format 01:00:5e:xx:xx:xx.

Port: List the ports you want included into L2Mcast Group.

State: The active interface number belongs to this Multicast Group.

5.2.6.21 show mac-address-table igmpsnooping

The user can go to the CLI Privilege Exec to display the IGMP Snooping entries in the Multicast Forwarding Database (MFDB) table, use the **show mac-address-table igmpsnooping** Privilege command.

Syntax

show mac-address-table igmpsnooping

Default Setting

None

Command Mode

Privilege Exec

Display Message

MAC Address: A multicast MAC address for which the switch has forwarding or filtering information. The format is twodigit hexadecimal numbers that are separated by colons, for example 01:00:5e:67:89:AB.

Type: The type of entry, which is either static (added by the user) or dynamic (added to the table as a result of a learning process or protocol.)

Description: The text description of this multicast table entry.

Interfaces: The list of interfaces that are designated for forwarding (Fwd:) and filtering (Flt:).

5.2.6.22 show ip igmp snooping ssm entries

The user can go to the CLI Privilege Exec to display the IGMP Snooping ssm entries in the Source Specific Multicast Forwarding Database (MFDB) table, use the **show ip igmp snooping ssm entries** Privilege command.

Syntax

show ip igmp snooping ssm entries

Default Setting

None

Command Mode

Privilege Exec

Display Message

VLAN ID: The VLAN on which the entry is learned.

Group: The IP multicast group address.

Source Ip: The IP source address.

Source Filter Mode: The source filter mode (Include/Exclude) for the specified group.

Interfaces:

- If Source Filter Mode is "include ", specifies the list of interfaces on which a incoming packet is forwarded. If it's source IP address is equal to the current entry's Source, the destination IP address is equal to the current entry's Group and the VLAN ID on which it arrived is current entry's VLAN.
- 2) If Source Filter Mode is "Exclude", specifies the list of interfaces on which a incoming packet is forwarded. If it's source IP address is *not* equal to the current entry's Source, the destination IP address is equal to the current entry's Group and the VLAN ID on which it arrived is current entry's VLAN.

5.2.6.23 show ip igmp snooping ssm groups

The user can go to the CLI Privilege Exec to display the IGMP Snooping ssm groups in the Source Specific Multicast Forwarding Database (MFDB) table, use the **show ip igmp snooping ssm groups** Privilege command.

Syntax

show ip igmp snooping ssm groups

Default Setting

None

Command Mode

Privilege Exec

Display Message

VLAN ID: VLAN on which the IGMPv3 report is received.

Group: The IP multicast group address.

Interface: The interface on which the IGMP v3 report is received.

Reporter: The IP address of the host that sent the IGMPv3 report.

Source Filter Mode: The source filter mode (Include/Exclude) for the specified group.

Source Address List: List of source IP addresses for which source filtering is requested.

5.2.6.24 show ip igmp snooping ssm stats

The user can go to the CLI Privilege Exec to display the IGMP Snooping ssm stats in the Source Specific Multicast Forwarding Database (MFDB) table, use the **show ip igmp snooping ssm stats** Privilege command.

Syntax

show ip igmp snooping ssm stats

Default Setting

None

Command Mode

Privilege Exec

Display Message

Total Entries: The total number of entries that can possibly be in the IGMP snooping's SSMFDB.

Most SSM FDB Entries Ever Used: The largest number of entries that have been present in the IGMP snooping's SSMFDB.

Current Entries: The current number of entries in the IGMP snooping's SSMFDB.

5.2.7 IGMP Snooping Querier

5.2.7.1 ip igmp snooping querier

The user can go to the CLI Global Configuration Mode to set IGMP snooping querier admin mode, use the **ip igmp snooping querier** global configuration command. Use the **no ip igmp snooping querier** to disable.

Syntax	
	snooping querier
no ip igm	np snooping querier

Default Setting

Disabled

Command Mode

Global Config

5.2.7.2 ip igmp snooping querier address

The user can go to the CLI Global Configuration Mode to set IGMP snooping querier address, use the **ip igmp snooping querier address <ip-address>** global configuration command. Use the **no ip igmp snooping querier address** return to default value.

Syntax

ip igmp snooping querier address <ip-address> no ip igmp snooping querier address

<ip-address> - ip address

Default Setting

0.0.0.0

Command Mode

5.2.7.3 ip igmp snooping querier query-interval

The user can go to the CLI Global Configuration Mode to set IGMP snooping querier query interval, use the **ip igmp snooping querier query-interval <1-1800>** global configuration command. Use the **no ip igmp snooping querier query-interval** return to default value.

Syntax

ip igmp snooping querier query-interval <1-1800> no ip igmp snooping querier query-interval

<1-1800> - set IGMP snooping querier query interval

Default Setting

60

Command Mode

Global Config

5.2.7.4 ip igmp snooping querier querier-expiry-interval

The user can go to the CLI Global Configuration Mode to set IGMP snooping querier querier expiry interval, use the **ip igmp snooping querier querier-expiry-interval <60-300>** global configuration command. Use the **no ip igmp snooping querier query-interval** return to default value.

Syntax	
SVIITAX	

ip igmp snooping querier querier-expiry-interval <60-300> no ip igmp snooping querier querier-expiry-interval

<60-300> - set igmp querier timer expiry

Default Setting

125 seconds

Command Mode

5.2.7.5 ip igmp snooping querier version

The user can go to the CLI Global Configuration Mode to set IGMP snooping querier version, use the **ip igmp snooping querier version <1-2>** global configuration command. Use the **no ip igmp snooping querier version** return to default value.

Syntax

ip igmp snooping querier version <1-2> no ip igmp snooping querier version

<1-2> - set IGMP version of the querier

Default Setting

2

Command Mode

Global Config

5.2.7.6 ip igmp snooping querier vlan

The user can go to the CLI Global Configuration Mode to set IGMP snooping querier vlan admin mode, use the **ip igmp snooping querier vlan <vlan-id>** global configuration command. Use the **no ip igmp snooping querier vlan <vlan-id>** return to disable.

Syntax

ip igmp snooping querier vlan <vlan-id> no ip igmp snooping querier vlan <vlan-id>

<vlan-id> - VLAN ID (Range: 1 - 4093).

Default Setting

Disabled

Command Mode

5.2.7.7 ip igmp snooping querier vlan address

The user can go to the CLI Global Configuration Mode to set IGMP snooping querier vlan address, use the **ip igmp snooping querier vlan <vlan-id> address <ip-address>** global configuration command. Use the **no ip igmp snooping querier vlan <vlan-id> address** return to default value zero.

Syntax

ip igmp snooping querier vlan <vlan-id> address <ip-address> no ip igmp snooping querier vlan <vlan-id> address

<vlan-id> - VLAN ID (Range: 1 - 4093).

<ip-address> - ip address

Default Setting

0.0.0.0

Command Mode

Global Config

5.2.7.8 ip igmp snooping querier vlan election participate

The user can go to the CLI Global Configuration Mode to set IGMP snooping querier vlan election participate mode, use the **ip igmp snooping querier vlan election participate <vlan-id>** global configuration command. Use the **no ip igmp snooping querier vlan election participate <vlan-id>** return to disable.

Syntax

ip igmp snooping querier vlan election participate <vlan-id> no ip igmp snooping querier vlan election participate <vlan-id>

<vlan-id> - VLAN ID (Range: 1 - 4093).

Default Setting

Disabled

Command Mode

Global Config

5.2.7.9 show ip igmp snooping querier

This command display IGMP snooping querier global information on the system.

135

Syntax

show ip igmp snooping querier

Command Mode

Privilege Exec

Display Information

IGMP Snooping Querier Mode: Administrative mode for IGMP Snooping. The default is disable.

Querier Address: Specify the Snooping Querier Address to be used as source address in periodic IGMP queries. This address is used when no address is configured on the VLAN on which query is being sent.

IGMP Version: Specify the IGMP protocol version used in periodic IGMP queries.

Querier Query Interval: Specify the time interval in seconds between periodic queries sent by the snooping querier. The Query Interval must be a value in the range of 1 and 1800. The default value is 60.

Querier Expiry Interval: Specify the time interval in seconds after which the last querier information is removed. The Querier Expiry Interval must be a value in the range of 60 and 300. The default value is 125.

5.2.7.10 show ip igmp snooping querier vlan

This command display IGMP snooping querier vlan information on the system.

show ip igmp snooping querier vlan <vlan-id>

<vlan-id> - VLAN ID (Range: 1 - 4093).

Command Mode

Privilege Exec

Display Information

IGMP Snooping Querier Vlan Mode: Display the administrative mode for IGMP Snooping for the switch.

Querier Election Participation Mode: Displays the querier election participate mode on the VLAN. When this mode is disabled, up on seeing a query of the same version in the vlan, the snooping querier move to non querier state. Only when this mode is enabled, the snooping querier will participate in querier election where in the least ip address will win the querier election and operates as the querier in that VLAN. The other querier moves to non-querier state.

Querier Vlan Address: Displays the Snooping Querier Address to be used as source address in periodic IGMP queries sent on the specified VLAN.

Operational State: Specifies the operational state of the IGMP Snooping Querier on a VLAN.

Operational Version: Displays the operational IGMP protocol version of the querier.

137

5.2.7.11 show ip igmp snooping querier detail

This command display all of IGMP snooping querier information on the system.

Syntax	
Syntax	

show ip igmp snooping querier detail

Command Mode

Privilege Exec

Display Information

IGMP Snooping Querier Mode: Administrative mode for IGMP Snooping. The default is disable.

Querier Address: Specify the Snooping Querier Address to be used as source address in periodic IGMP queries. This address is used when no address is configured on the VLAN on which query is being sent.

IGMP Version: Specify the IGMP protocol version used in periodic IGMP queries.

Querier Query Interval: Specify the time interval in seconds between periodic queries sent by the snooping querier. The Query Interval must be a value in the range of 1 and 1800. The default value is 60.

Querier Expiry Interval: Specify the time interval in seconds after which the last querier information is removed. The Querier Expiry Interval must be a value in the range of 60 and 300. The default value is 120.

5.2.8 MLD Snooping

5.2.8.1 show ipv6 mld snooping

The user can go to the CLI Privilege Exec to get all of mld snooping information, use the **show ipv6 mld snooping** Privilege command.

Syntax

show ipv6 mld snooping [interface {<slot/port> | vlan <vlan-id> | port-channel <portchannel-id>}]

<slot/port> - Interface number.

<vlan-id> - VLAN ID (Range: 1 – 4093).

<portchannel-id> - Port-channel interface number. The range of port-channel ID is 1 to 64.

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Message

When the optional arguments <slot/port>, <portchannel-id> or <vlan-id> are not used, the command displays the following information.

Admin Mode: Indicates whether or not MLD Snooping is active on the switch.

Interfaces Enabled for MLD Snooping: Interfaces on which MLD Snooping is enabled.

Multicast Control Frame Count: Displays the number of MLD Control frames that are processed by the CPU.

VLANs Enabled for MLD Snooping: VLANs on which MLD Snooping is enabled.

VLANs Block enabled for snooping: VLANs on which IGMP/MLD Snooping is blocked.

When you specify the <slot/port> or <portchannel-id> values, the following information displays.

MLD Snooping Admin Mode: Indicates whether MLD Snooping is active on the interface.

Fast Leave Mode: Indicates whether MLD Snooping Fast Leave is active on the interface.

Group Membership Interval: Shows the amount of time in seconds that a switch will wait for a report from a particular group on a particular interface, which is participating on the interface, before deleting the interface from the entry. This value may be configured.

Multicast Router Expiry Time: Displays the amount of time to wait before removing an interface that is participating on the interface from the list of interfaces with multicast routers attached. The interface is removed if a query is not received. This value may be configured.

When you specify a value for <vlan-id>, the following information appears.

VLAN ID: VLAN ID.

MLD Snooping Admin Mode: Indicates whether MLD Snooping is active on the VLAN.

Fast Leave Mode: Indicates whether MLD Snooping Fast Leave is active on the VLAN.

Group Membership Interval: Shows the amount of time in seconds that a switch will wait for a report from a particular group on a particular interface, which is participating in the VLAN, before deleting the interface from the entry. This value may be configured.

Max Response Time: VLANs on which MLD Snooping is enabled.

Multicast Router Expiry Time: Displays the amount of time to wait before removing an interface that is participating in the VLAN from the list of interfaces with multicast routers attached. The interface is removed if a query is not received. This value may be configured.

Report Suppression Mode: Admin mode of MLD Snooping Report Suppression Mode.

Vian Block Mode: VLANs on which IGMP/MLD Snooping is blocked.

5.2.8.2 show ipv6 mld snooping mrouter interface

The user can go to the CLI Privilege Exec to display information about statically configured multicast router-attached interfaces, use the **show ipv6 mld snooping mrouter interface** Privilege command.

Syntax

show ipv6 mld snooping mrouter interface {<slot/port> | port-channel <portchannel-id>}

<slot/port> - Interface number.

<portchannel-id> - Port-channel interface number. The range of port-channel ID is 1 to 64.

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Message

Interface: Shows the interface on which multicast router information is being displayed.

Multicast Router Attached: Indicates whether multicast router is statically enabled on the interface.

140

5.2.8.3 show ipv6 mld snooping mrouter vlan

The user can go to the CLI Privilege Exec to display information about statically configured multicast router-attached interfaces, use the **show ipv6 mld snooping mrouter vlan** Privilege command.

-
Syntax
Oyman

show ipv6 mld snooping mrouter vlan {<slot/port> | port-channel <portchannel-id>}

<slot/port> - Interface number.

<portchannel-id> - Port-channel interface number. The range of port-channel ID is 1 to 64.

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Message

VLAN ID: Displays the list of VLANs of which the interface is a member.

Interface: Shows the interface on which multicast router information is being displayed.

5.2.8.4 show ipv6 mld snooping static

The user can go to the Privilege Exec to display MLD snooping static information, use the **show ipv6 mld snooping static** Privilege command.

Syntax

show ipv6 mld snooping static

Default Setting

None

Command Mode

Privilege Exec

User Exec

Display Message

VLAN: The VLAN ID used with the MAC address to fully identify packets you want L2Mcast Group.

MAC Address: The MAC address of the L2Mcast Group in the format 33:33:xx:xx:xx:xx.

Port: List the ports you want included into L2Mcast Group.

State: The active interface number belongs to this Multicast Group.

5.2.8.5 show mac-address-table mldsnooping

The user can go to the CLI Privilege Exec to display the MLD Snooping entries in the Multicast Forwarding Database (MFDB) table, use the **show mac-address-table mldsnooping** Privilege command.

Syntax

show mac-address-table mldsnooping

Default Setting

None

Command Mode

Privileged Exec

Display Message

MAC Address: A multicast MAC address for which the switch has forwarding or filtering information. The format is twodigit hexadecimal numbers that are separated by colons, for example 33:33:45:67:89:AB.

Type: The type of entry, which is either static (added by the user) or dynamic (added to the table as a result of a learning process or protocol.)

Description: The text description of this multicast table entry.

Interfaces: The list of interfaces that are designated for forwarding (Fwd:) and filtering (Flt:).

5.2.8.6 show ipv6 mld snooping ssm entries

The user can go to the CLI Privilege Exec to display the MLD Snooping ssm entries in the Source Specific Multicast Forwarding Database (MFDB) table, use the **show ipv6 mld snooping ssm entries** Privilege command.

Syntax

show ipv6 mld snooping ssm entries

Default Setting

None

Command Mode

Privilege Exec

Display Message

VLAN ID: The VLAN on which the entry is learned.

Group: The IPv6 multicast group address.

Source Ip: The IPv6 source address.

Source Filter Mode: The source filter mode (Include/Exclude) for the specified group.

Interfaces:

- 3) If Source Filter Mode is "include ", specifies the list of interfaces on which a incoming packet is forwarded. If it's source IP address is equal to the current entry's Source, the destination IP address is equal to the current entry's Group and the VLAN ID on which it arrived is current entry's VLAN.
- 4) If Source Filter Mode is "Exclude", specifies the list of interfaces on which a incoming packet is forwarded. If it's source IP address is *not* equal to the current entry's Source, the destination IP address is equal to the current entry's Group and the VLAN ID on which it arrived is current entry's VLAN.

5.2.8.7 show ipv6 mld snooping ssm groups

The user can go to the CLI Privilege Exec to display the MLD Snooping ssm groups in the Source Specific Multicast Forwarding Database (MFDB) table, use the **show ipv6 mld snooping ssm groups** Privilege command.

Syntax

show ipv6 mld snooping ssm groups

Default Setting

None

Command Mode

Privilege Exec

Display Message

VLAN ID: VLAN on which the MLDv2 report is received.

Group: The IPv6 multicast group address.

Interface: The interface on which the MLDv2 report is received.

Reporter: The IPv6 address of the host that sent the MLDv2 report.

Source Filter Mode: The source filter mode (Include/Exclude) for the specified group.

Source Address List: List of source IP addresses for which source filtering is requested.

5.2.8.8 show ipv6 mld snooping ssm stats

The user can go to the CLI Privilege Exec to display the MLD Snooping ssm stats in the Source Specific Multicast Forwarding Database (MFDB) table, use the **show ipv6 mld snooping ssm stats** Privilege command.

Syntax

show ipv6 mld snooping ssm stats

Default Setting

None

Command Mode

Privilege Exec

Display Message

Total Entries: The total number of entries that can possibly be in the MLD snooping's SSMFDB.

Most SSM FDB Entries Ever Used: The largest number of entries that have been present in the MLD snooping's SSMFDB.

Current Entries: The current number of entries in the MLD snooping's SSMFDB.

5.2.8.9 ipv6 mld snooping

The user can go to the CLI Global Configuration Mode to set MLD Snooping on the system , use the **ipv6 mld snooping** global configuration command. Use the **no ipv6 mld snooping** to disable MLD Snooping on the system.

Syntax

ipv6 mld s	snooping	
no ipv6 m	nld snooping	

Default Setting

Disabled

Command Mode

5.2.8.10 clear mld snooping

The user can go to the CLI Privilege Exec to clear MLD Snooping entries from the MFDB table, use the **clear mld snooping** priviledge configuration command.

Syntax

clear mld snooping

Default Setting

None

Command Mode

Privilege Exec

5.2.8.11 ipv6 mld snooping interfacemode

The user can go to the CLI Global/Interface Configuration Mode to set MLD Snooping on one interface or all interfaces, use the **ipv6 mld snooping interfacemode** to enable MLD snooping on global/interface. Use the **no ipv6 mld snooping interfacemode** to disable MLD Snooping on global/ interfaces.

Syntax

ipv6 mld snooping interfacemode [<all>] no ipv6 mld snooping interfacemode [<all>]

Default Setting

Disabled

Command Mode

Global Config

5.2.8.12 ipv6 mld snooping fast-leave

The user can go to the CLI Global/Interface Configuration Mode to set MLD Snooping fast-leave admin mode on a selected interface or all interfaces, use the **ipv6 mld snooping fast-leave** global/interface configuration command. Use the **no ipv6 mld snooping fast-leave** disable MLD Snooping fast-leave admin mode.

Svntax	

ipv6 mld snooping fast-leave no ipv6 mld snooping fast-leave

Default Setting

Disabled

Command Mode

Global Config

Interface Config

5.2.8.13 ipv6 mld snooping groupmembershipinterval

The user can go to the CLI Global/Interface Configuration Mode to set the MLD Group Membership Interval time on one interface or all interfaces, use the **ipv6 mld snooping groupmembershipinterval <2-3600>** global/interface configuration command. Use the **no ipv6 mld snooping groupmembershipinterval** return to default value 260.

Syntax

ipv6 mld snooping groupmembershipinterval <2-3600> no ipv6 mld snooping groupmembershipinterval

<2-3600> - The range of group membership interval time is 2 to 3600 seconds.

Default Setting

260

Command Mode

Global Config



5.2.8.14 ipv6 mld snooping mcrtrexpiretime

The user can go to the CLI Interface Global/Interface Configuration Mode to set the Multicast Router Present Expiration time for the system or on a particular interface, use the **ipv6 mld snooping mcrtrexpiretime <0-3600>** global/interface configuration command. Use the **no ipv6 mld snooping mcrtrexpiretime** to return to default value 0.

Syntax		
ipv6 mld	d snooping mcrtrexpiretime <0-3600>	
no ipv6 n	mld snooping mcrtrexpiretime	

<0-3600> - The range is 0 to 3600 seconds. A value of 0 indicates an infinite time-out, i.e. no expiration.

Default Setting

0

Command Mode

Global Config

Interface Config

5.2.8.15 ipv6 mld snooping mrouter interface

The user can go to the CLI Interface Configuration Mode to configure the interface as a multicast router-attached interface or configure the VLAN ID for the VLAN that has the multicast router attached mode enabled, use the **ipv6 mld snooping mrouter {interface | <vlan-id>}** interface configuration command. Use the **no ipv6 mld snooping mrouter {interface | <vlan-id>}** disable multicast router attached mode for the interface or a VLAN.

Syntax

ipv6 mld	snooping mrouter {interface <vlan-id>}</vlan-id>
no ipv6 m	nld snooping mrouter {interface <vlan-id>}</vlan-id>

<vlan-id> - VLAN ID (Range: 1 – 4093).

Default Setting

None

Command Mode

5.2.8.16 ipv6 mld snooping static

The user can go to the Global Mode and add a port to ipv6 multicast group, use the **ipv6 mld snooping static** Global command.

Cuntay
Syntax

ipv6 mld snooping static <macaddr> vlan <vlan-id> interface {<slot/port> | port-channel <portchannel-id>} no ipv6 mld snooping static <macaddr> vlan <vlan-id> interface {<slot/port> | port-channel <portchannel-id>}

<macaddr> - Static MAC address.

<vlan-id> - VLAN ID (Range: 1 – 4093).

<slot/port> - Interface number.

<portchannel-id> - Port-channel interface number. The range of port-channel ID is 1 to 64.

Default Setting

None

Command Mode

Global Config

5.2.8.17 set mld

The user can go to the CLI VLAN database Mode to set MLD Snooping on a particular VLAN, use the **set mld <vlan-id>** vlan configuration command. Use the **no set mld <vlan-id>** to disable MLD Snooping on a particular VLAN.

Syntax

set mld <	vlan-id>
no set ml	d <vlan-id></vlan-id>

<vlan-id> - VLAN ID (Range: 1 – 4093).

Default Setting

Disabled

Command Mode

VLAN database

5.2.8.18 set mld fast-leave

The user can go to the CLI VLAN Configuration Mode to set MLD Snooping fast-leave admin mode on a particular VLAN, use the **set mld fast-leave <vlan-id>** vlan configuration command. Use the **no set mld fast-leave <vlan-id>** disable MLD Snooping fast-leave admin mode.

Syntax

set mld fast-leave <vlan-id> no set mld fast-leave <vlan-id>

<vlan-id> - VLAN ID (Range: 1 – 4093).

Default Setting

Disabled

Command Mode

VLAN database

5.2.8.19 set mld groupmembership-interval

The user can go to the CLI VLAN Configuration Mode to set the MLD Group Membership Interval time on a particular VLAN, use the **set mld groupmembership-interval <vlan-id> <2-3600>** vlan configuration command. Use the **no set mld groupmembership-interval <vlan-id>** return to default value 260.

Syntax

set mld groupmembership-interval <vlan-id> <2-3600> no set mld groupmembership-interval <vlan-id>

<vlan-id> - VLAN ID (Range: 1 – 4093).

<2-3600> - The range of group membership interval time is 2 to 3600 seconds.

Default Setting

260

Command Mode

VLAN database

5.2.8.20 set mld maxresponse

The user can go to the CLI Interface VLAN database Mode to set the MLD Maximum Response time on a particular VLAN, use the **set mld max-response-time <vlan-id> <1-65>** vlan configuration command. Use the **no set mld max-response-time <vlan-id>** return to default value 10.

-
Syntax
Oymax

set mld max-response-time <vlan-id> <1-65> no set mld max-response-time <vlan-id>

<vlan-id> - VLAN ID (Range: 1 – 4093).

<1-65> - This value must be less than the MLD Query Interval time value. The range is 1 to 65 seconds.

Default Setting

10

Command Mode

VLAN database

5.2.8.21 set mld mcrtrexpiretime

The user can go to the CLI Interface VLAN Configuration Mode to set the Multicast Router Present Expiration time on a particular VLAN, use the **set mld mcrtrexpiretime <vlan-id> <0-3600>** vlan configuration command. Use the **no set mld mcrtrexpiretime <vlan-id>** to return to default value 0.

Syntax

set mld mcrtrexpiretime <vlan-id> <0-3600> no set mld mcrtrexpiretime <vlan-id>

<vlan-id> - VLAN ID (Range: 1 – 4093).

<0-3600> - The range is 0 to 3600 seconds. A value of 0 indicates an infinite time-out, i.e. no expiration.

Default Setting

0

Command Mode

VLAN database

5.2.9 MLD Snooping Querier

5.2.9.1 show ipv6 mld snooping querier

This command display MLD snooping querier global information on the system.

show ipv6 mld snooping querier

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Message

MLD Snooping Querier Mode: Specify the Snooping Querier Address to be used as source address in periodic MLD queries. This address is used when no address is configured on the VLAN on which query is being sent.

Querier Address: Specify the Snooping Querier Address to be used as source address in periodic MLD queries. This address is used when no address is configured on the VLAN on which query is being sent.

MLD Version: Specify the MLD protocol version used in periodic MLD queries.

Querier Query Interval: Specify the time interval in seconds between periodic queries sent by the snooping querier. The Query Interval must be a value in the range of 1 and 1800. The default value is 60.

Querier Expiry Interval: Specify the time interval in seconds after which the last querier information is removed. The Querier Expiry Interval must be a value in the range of 60 and 300. The default value is 60.

5.2.9.2 show ipv6 mld snooping querier vlan

This command display MLD snooping querier vlan information on the system.

show ipv6 mld snooping querier vlan <vlan-id>

<vlan-id> - VLAN ID (Range: 1 – 4093).

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Message

MLD Snooping Querier VIan Mode: Displays the querier election participate mode on the VLAN. When this mode is disabled, up on seeing a query of the same version in the vlan, the snooping querier move to non querier state. Only when this mode is enabled, the snooping querier will participate in querier election where in the least ip address will win the querier election and operates as the querier in that VLAN. The other querier moves to non-querier state.

Querier Election Participation Mode: Displays the querier election participate mode on the VLAN. When this mode is disabled, up on seeing a query of the same version in the vlan, the snooping querier move to non querier state. Only when this mode is enabled, the snooping querier will participate in querier election where in the least ip address will win the querier election and operates as the querier in that VLAN. The other querier moves to non-querier state.

Querier Vlan Address: Displays the Snooping Querier Address to be used as source address in periodic MLD queries sent on the specified VLAN.

Operational State: Specifies the operational state of the MLD Snooping Querier on a VLAN.

Operational Version: Displays the operational MLD protocol version of the querier.

5.2.9.3 show ipv6 mld snooping querier detail

This command display all of MLD snooping querier information on the system.

Syntax

show ipv6 mld snooping querier detail

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Message

MLD Snooping Querier Mode: Administrative mode for MLD Snooping. The default is disable

Querier Address: Specify the Snooping Querier Address to be used as source address in periodic MLD queries. This address is used when no address is configured on the VLAN on which query is being sent.

MLD Version: Specify the MLD protocol version used in periodic IGMP queries.

Querier Query Interval: Specify the time interval in seconds between periodic queries sent by the snooping querier. The Query Interval must be a value in the range of 1 and 1800. The default value is 60.

Querier Expiry Interval: Specify the time interval in seconds after which the last querier information is removed. The Querier Expiry Interval must be a value in the range of 60 and 300. The default value is 60.

5.2.9.4 ipv6 mld snooping querier

The user can go to the CLI Global Configuration Mode to set MLD snooping querier admin mode, use the **ipv6 mld snooping querier** global configuration command. Use the **no ipv6 mld snooping querier** to disable.

Syntax

ipv6 mld snooping querier no ipv6 mld snooping querier

Default Setting

Disabled

Command Mode

Global Config

5.2.9.5 ipv6 mld snooping querier address

The user can go to the CLI Global Configuration Mode to set MLD snooping querier address, use the **ipv6 mld snooping querier address <ipv6-address>** global configuration command. Use the **ipv6 mld snooping querier address <ipv6-address>** return to default value zero.

Syntax

ipv6 mld snooping querier address <ipv6-address> no ipv6 mld snooping querier address <ipv6-address>

<ipv6-address> - The IPv6 address of the MLD querier on the subnet the interface is associated with.

Default Setting

::

Command Mode

5.2.9.6 ipv6 mld snooping querier querier-interval

The user can go to the CLI Global Configuration Mode to set MLD snooping querier querier interval, use the **ipv6 mld snooping querier querier-interval <1-1800>** global configuration command. Use the **no ipv6 mld snooping querier query-interval** return to default value.

Syntax

ipv6 mld snooping querier querier-interval <1-1800> no ipv6 mld snooping querier querier-interval

<1-1800> - set MLD snooping querier query interval

Default Setting

60

Command Mode

Global Config

5.2.9.7 ipv6 mld snooping querier querier-expiry-interval

The user can go to the CLI Global Configuration Mode to set MLD snooping querier querier expiry interval, use the **ipv6 mld snooping querier querier-expiry-interval <60-300>** global configuration command. Use the **no ipv6 mld snooping querier querier-expiry-interval** return to default value.

C.	ntax
Jy	пах

ipv6 mld snooping querier querier-expiry-interval <60-300> no ipv6 mld snooping querier querier-expiry-interval

<60-300> - set igmp querier timer expiry

Default Setting

60

Command Mode

5.2.9.8 ipv6 mld snooping querier vlan

The user can go to the CLI Global Configuration Mode to set MLD snooping querier vlan admin mode, use the **ipv6 mld snooping querier vlan <vlan-id>** global configuration command. Use the **no ipv6 mld snooping querier vlan <vlan-id>** return to disable.

Syntax

ipv6 mld snooping querier vlan <vlan-id> no ipv6 mld snooping querier vlan <vlan-id>

<vlan-id> - VLAN ID (Range: 1 – 4093).

Default Setting

::

Command Mode

Global Config

5.2.9.9 ipv6 mld snooping querier vlan address

The user can go to the CLI Global Configuration Mode to set MLD snooping querier vlan address, use the **ipv6 mld snooping querier vlan <vlan-id> address <ip-address>** global configuration command. Use the **no ipv6 mld snooping querier vlan <vlan-id> address <ip-address>** return to default value zero.

Syntax

ipv6 mld snooping querier vlan <vlan-id> address <ipv6-address> no ipv6 mld snooping querier vlan <vlan-id> address <ipv6-address>

<vlan-id> - VLAN ID (Range: 1 – 4093).

<ipv6-address> - The IPv6 address will be used in the IPv6 header while sending out MLD queries on this VLAN.

Default Setting

Disabled

Command Mode

Global Config

158

5.2.9.10 ipv6 mld snooping querier vlan election participate

The user can go to the CLI Global Configuration Mode to set MLD snooping querier vlan election participate mode, use the **ipv6 mld snooping querier vlan election-participate <vlan-id>** global configuration command. Use the **no ipv6 mld snooping querier vlan election participate <vlan-id>** return to disable.

Svntax	
Svntax	

ipv6 mld snooping querier vlan election participate <vlan-id> no ipv6 mld snooping querier vlan election participate <vlan-id>

<vlan-id> - VLAN ID (Range: 1 – 4093).

Default Setting

Disabled

Command Mode

5.2.10 Port Channel

5.2.10.1 show interface port-channel

This command displays the capability of all port-channels (LAGs) on the device as well as a summary of individual port-channels.

Syntax

show interface port-channel brief

Default Setting

None

Command Mode

Privileged Exec

Display Message

For each port-channel the following information is displayed:

Channel ID: The field displays the port-channel's ID.

Port-Channel Name: This field displays the name of the port-channel.

Link State: This field indicates whether the link is up or down.

Trap Flag: This object determines whether or not to send a trap when link status changes. The factory default is enabled.

Type: This field displays the status designating whether a particular port-channel (LAG) is statically or dynamically maintained. The possible values of this field are Static, indicating that the port-channel is statically maintained; and Dynamic, indicating that the port-channel is dynamically maintained.

Mbr Ports: This field lists the ports that are members of this port-channel, in slot/port notation.

Active Ports: This field lists the ports that are actively participating in this port-channel.



This command displays an overview of a specified port-channel (LAG) on the switch.

Syntax

show interface port-channel <ID>

<ID> - The port-channel interface number. The range of port-channel ID is 1 to 64.

Default Setting

None

Command Mode

Privileged Exec

Display Message

Port Channel ID: The ID of this port-channel.

Channel Name: The name of this port-channel (LAG). You may enter any string of up to 15 alphanumeric characters.

Link State: Indicates whether the Link is up or down.

Admin Mode: May be enabled or disabled. The factory default is enabled.

Type: This field displays the status designating whether a particular port-channel (LAG) is statically or dynamically maintained. The possible values of this field are Static, indicating that the port-channel is statically maintained; and Dynamic, indicating that the port-channel is dynamically maintained.

Load Balance Option: This field displays the load-balance status whether a particular port-channel (LAG) is maintained.

Mbr Ports: A listing of the ports that are members of this port-channel (LAG), in slot/port notation. There can be a maximum of eight ports assigned to a given port-channel (LAG).

Device Timeout: This field displays the device timout value of actor and parter. The value of device timeout should be short(1 second) or long(30 seconds).

Port Speed: Speed of the port-channel port.

Port Active: This field lists the ports that are actively participating in the port-channel (LAG).



This command displays an overview of all port-channels (LAGs) on the switch.

^	
Syr	ntax

show interface port-channel

Default Setting

None

Command Mode

Privileged Exec

Display Message

Channel ID: The ID of this port-channel.

Channel Name: The name of this port-channel (LAG). You may enter any string of up to 15 alphanumeric characters.

Link: Indicates whether the Link is up or down.

Admin Mode: May be enabled or disabled. The factory default is enabled.

Type: This field displays the status designating whether a particular port-channel (LAG) is statically or dynamically maintained. The possible values of this field are Static, indicating that the port-channel is statically maintained; and Dynamic, indicating that the port-channel is dynamically maintained.

Mbr Ports: A listing of the ports that are members of this port-channel (LAG), in slot/port notation. There can be a maximum of eight ports assigned to a given port-channel (LAG).

Device Timeout: This field displays the device timeout value of actor and partner. The value of device timeout should be short(1 second) or long(30 seconds).

Port Speed: Speed of the port-channel port.

Port Active: This field lists the ports that are actively participating in the port-channel (LAG).



5.2.10.2 Interface port-channel

This command configures a new port-channel (LAG) with the specified ID. Display the information of this port-channel using the **show interface port-channel <portchannel-id>.**



Before including a port in a port-channel, set the port physical mode. See **speed** command.

Syntax

interface port-channel <portchannel-id> no interface port-channel <portchannel-id>

<portchannel-id> - The port-channel interface number to be created. The range of the port-channel ID is 1 to 64.

no - This command delete the specified port-channel.

Default Setting

None

Command Mode

Global Config

Command Usage

Max number of port-channels could be created by user are 64 and maximum number of members for each port-channel are 8.

5.2.10.3 port-channel adminmode all

This command sets every configured port-channel with the same administrative mode setting.

Syn	tav
Syn	ιαλ

port-channel adminmode all no port-channel adminmode all

no - This command disables a port-channel (LAG). The option **all** sets every configured port-channel with the same administrative mode setting.

Default Setting

Enabled

Command Mode

Global Config

5.2.10.4 staticcapability

This command enables the static function to support on specific port-channel (static link aggregations - LAGs) on the device. By default, the static capability for all of port-channels is disabled.

Syntax		
staticcapa	apability iccapability	

no - This command disables to support static function on specific port-channel on this device.

Default Setting

Disabled

Command Mode

5.2.10.5 port-channel linktrap

This command enables link trap notifications for the port-channel (LAG). The interface is a ID for a configured port-channel. The option **all** sets every configured port-channel with the same administrative mode setting.

-	
Syntax	,
Jynia/	۰

port-channel linktrap {<ID> | all} no port-channel linktrap {<ID> | all}

<ID> - The port-channel interface number. The range of the port-channel ID is 1 to 64.

all - all port-channel interfaces.

no - This command disables link trap notifications for the port-channel (LAG). The interface is a ID for a configured port-channel. The option **all** sets every configured port-channel with the same administrative mode setting.

Default Setting

Enabled

Command Mode

5.2.10.6 port-channel load-balance

This command for CLI will configured the mode of load balance on the all Port Channels. The parameter "src-mac | dst-mac | dst-src-mac | src-ip | dst-ip | dst-src-ip | enhanced" represent the mode used to be set for port-channel load balance.

Syntax

port-channel load-balance { src-mac | dst-mac | dst-src-mac | src-ip | dst-ip | dst-src-ip | enhanced} {<ID> | all} no port-channel load-balance {<ID> | all}

src-mac - Sets the mode on the source MAC address.

dst-mac - Sets the mode on the destination MAC address.

dst-src-mac - Sets the mode on the source and destination MAC addresses.

src-ip - Sets the mode on the source IP address.

dst-ip - Sets the mode on the destination IP address.

dst-src-ip - Sets the mode on the source and destination IP addresses.

enhanced - Set the mode on the source and destination MAC addresses if it is a L2 packet or on the source and destination IP addresses if it is a IP packet.

<ID> - The ID of the port-channel to be configured.

no - Restore the mode to be default value.

Default Setting

dst-src-ip

Command Mode

This command for CLI will configured the mode of load balance on the specific Port Channel. The parameter "**src-mac | dst-src-mac | src-ip | dst-ip | dst-src-ip | enhanced**" represent the mode used to be set for port-channel load balance.

Syntax

load-balance { src-mac | dst-mac | dst-src-mac | src-ip | dst-ip | dst-src-ip | enhanced } no load-balance

src-mac - Sets the mode on the source MAC address.

dst-mac - Sets the mode on the destination MAC address.

dst-src-mac - Sets the mode on the source and destination MAC addresses.

src-ip - Sets the mode on the source IP address.

dst-ip - Sets the mode on the destination IP address.

dst-src-ip - Sets the mode on the source and destination IP addresses.

enhanced - Set the mode on the source and destination MAC addresses if it is a L2 packet or on the source and destination IP addresses if it is a IP packet.

no - Restore the mode to be default value.

Default Setting

dst-src-ip

Command Mode



5.2.10.7 port-channel system priority

This command defines a system priority for the port-channel (LAG).

Syntax

port-channel system priority <priority-value>

<priority-value> - valid value 0-65535.

Default Setting

32768

Command Mode

Global Config

5.2.10.8 adminmode

This command enables a port-channel (LAG) members. The interface is a ID for a configured port-channel.

Syntax

adminmode no admin<u>mode</u>

no - This command disables a configured port-channel (LAG).

Default Setting

Enabled

Command Mode

5.2.10.9 lacp

This command enables Link Aggregation Control Protocol (LACP) on a port.

Syntax	
lacp no lacp	
no lacp	

no - This command disables Link Aggregation Control Protocol (LACP) on a port.

Default Setting

Enabled

Command Mode

Interface Config

This command enables Link Aggregation Control Protocol (LACP) on all ports.

Syntax	
lacp all no lacp al	
no lacp al	

all - All interfaces.

no - This command disables Link Aggregation Control Protocol (LACP) on all ports.

Default Setting

Enabled

Command Mode

5.2.10.10 lacp actor or lacp partner

This command set <actor | partner> admin key value of Link Aggregation Control Protocol (LACP) on a port.

Cuntor	
Syntax	Κ.

lacp <actor|partner> admin key <key-value> no lacp <actor|partner> admin key

<key-value>: 0-65535

no - This command restores <actor | partner> admin key value of Link Aggregation Control Protocol (LACP) on a port.

Default Setting

Interface Number

Command Mode

Interface Config

This command set <actor | partner> admin state value of Link Aggregation Control Protocol (LACP) on a port.

Syntax

lacp <actor|partner> admin state <individual | longtimeout | passive> no lacp <actor|partner> admin state <individual | longtimeout | passive>

individual - Set lacp admin state to individual. Use no form to set to aggregation.

longtimeout - Set lacp admin state longtimeout. Use no form to set to shorttimeout.

passive - Set lacp admin state passive. Use no form to set to active.

no - This command restores <actor | partner> admin state value of Link Aggregation Control Protocol (LACP) on a port.

Default Setting

no Individual (aggregation)

no longtimeout (shorttimeout)

no passive (active)

Command Mode

This command set <actor | partner> port priority value of Link Aggregation Control Protocol (LACP) on a port.

Syntax

lacp <actor|partner> port priority <priority-value> no lacp <actor|partner> port priority

<priority-value> - range 0-65535.

no - This command restores <actor | partner> port priority value of Link Aggregation Control Protocol (LACP) on a port.

Default Setting

128

Command Mode

Interface Config

This command set <actor | partner> system priority value of Link Aggregation Control Protocol (LACP).

Syntax

lacp <actor|partner> system priority <priority-value> no lacp <actor|partner> system priority

<priority-value> - range 0-65535.

no - This command restores <actor | partner> system priority value of Link Aggregation Control Protocol (LACP).

Default Setting

32768

Command Mode

This command set collector max-delay time of Link Aggregation Control Protocol (LACP) on a port-channel.

Syntax

lacp collector max-delay <delay-value> no lacp collector max-delay

<delay-value>: 0-65535

no - This command restores collector max-delay time of Link Aggregation Control Protocol (LACP) on a port-channel

Default Setting

0

Command Mode

Interface Config

5.2.10.11 lacp min-links

This command configures the minimum links for Link Aggregation.

Syntax

lacp min-links <1-32> no lacp

no - This command resotre the min-links to default value.

Default Setting

1

Command Mode

Interface Port-channel Config

Command Usage

The maximum number of members for each port-channel is 32. For T1048-LB9/T1048-LB9A, the maximum number of members is 8.

172

5.2.10.12 lacp fallback

This command configures the fallback feature for Link Aggregation.

Syntax			
lacp fallba	ack		
lacp fallback no lacp fallback			

no - This command resotre the fallback feature to default value.

Default Setting

Disabled

Command Mode

Interface Port-channel Config

5.2.10.13 lacp fallback timeout

This command configures the fallback timeout value for Link Aggregation.

Syntax

lacp fallback timeout <1-100> no lacp fallback

no - This command resotre the fallback feature to default value.

Default Setting

5

Command Mode

Interface Port-channel Config

5.2.10.14 channel-group

This command assigns and configures an interface to a port-channel (LAG) group. The interface is a ID of a configured port-channel.



Before adding a port to a port-channel, set the physical mode of the port. See '**speed**' command.

You can change the mode for an interface only if it is the only interface designated to the specified channel group. If you enter this command on an interface that is added to a channel with a different protocol (than the protocol you are entering), the command is rejected.

Syntax

channel-group <ID> mode {active | on} no channel-group <ID>

<ID> - Port-Channel Interface number. The range of the port-channel ID is 1 to 64.

active - Enables LACP unconditionally.

on - Enables static mode (Cisco EtherChannel-like).

no - Removes the interface from the specified channel group.

Default Setting

None

Command Mode

Interface Config

Command Usage

The maximum number of members for each port-channel is 32. For T1048-LB9/T1048-LB9A, the maximum number of members is 8.

5.2.10.15 delete-channel-group

This command deletes all configured ports from the port-channel (LAG). The interface is a ID of a configured port-channel.

Syntax

delete-channel-group <ID> all

<ID> - Port-channel Interface number. The range of the port-channel ID is 1 to 64.

all - All members for specific Port-channel.

Default Setting

None

Command Mode

5.2.11 Storm Control

5.2.11.1 show storm-control

This command is used to display broadcast storm control information.

Syntax	
show storm-control broadcast	
Default Setting	
None	
Command Mode	
Privileged Exec	
Display Message	
Intf: Displays interface number.	
Mode: Displays status of storm	control broadcast.
Rate: Displays rate in pps (pack	et per second) for storm control broadcast.

Action: Shutdown or send trap when storm is detected.

This command is used to display multicast storm control information.

show storm-control multicast

Default Setting

None

Command Mode

Privileged Exec

Display Message

Intf: Displays interface number.

Mode: Displays status of storm control multicast.

Rate: Displays rate in pps (packet per second) for storm control multicast.

Action: Shutdown or send trap when storm is detected.

This command is used to display unicast storm control information

Syntax

show storm-control unicast

Default Setting

None

Command Mode

Privileged Exec

Display Message

Intf: Displays interface number.

Mode: Displays status of storm control unicast.

Rate: Displays rate in pps (packet per second) for storm control unicast.

Action: Shutdown or send trap when storm is detected.

177

5.2.11.2 storm-control broadcast

This command enables broadcast storm recovery mode on the selected interface. If the mode is enabled, broadcast storm recovery with high threshold is implemented. The threshold implementation follows a percentage pattern. If the broadcast traffic on any Ethernet port exceeds the high threshold percentage (as represented in "Broadcast Storm Recovery Thresholds" table) of the link speed, the switch discards the broadcasts traffic until the broadcast traffic returns to the threshold percentage or less. The full implementation is depicted in the "Broadcast Storm Recovery Thresholds" table.

Syntax			
storm-cor	ntrol broadcast		
no storm-	no storm-control broadcast		

no - This command disables broadcast storm recovery mode on the selected interface. The threshold implementation follows a percentage pattern. If the broadcast traffic on any Ethernet port exceeds the high threshold percentage (as represented in "Broadcast Storm Recovery Thresholds" table) of the link speed, the switch discards the broadcasts traffic until the broadcast traffic returns to the threshold percentage or less. The full implementation is depicted in the "Broadcast Storm Recovery Thresholds" table.

Default Setting

Disabled

Command Mode

Interface Config

This command enables broadcast storm recovery mode on all interfaces.

Syntax				
storm-co	ontrol broadcast			

no storm-control broadcast

no - This command disables broadcast storm recovery mode on all interfaces.

Default Setting

Disabled

Command Mode

5.2.11.3 storm-control multicast

This command enables multicast storm recovery mode on the selected interface.

Syntax	
storm-cor	ntrol multicast
no storm-	-control multicast

no - This command disables multicast storm recovery mode on the selected interface.

Default Setting

None

Command Mode

Interface Config

This command enables multicast storm recovery mode on all interfaces.

Syntax

storm-control multicast no storm-control multicast

no - This command disables multicast storm recovery mode on all interfaces.

Default Setting

None

Command Mode

5.2.11.4 storm-control unicast

This command enables unicast storm recovery mode on the selected interface.

Syntax	
storm-co	ontrol unicast
no storm	-control unicast

no - This command disables unicast storm recovery mode on the selected interface.

Default Setting

None

Command Mode

Interface Config

This command enables unicast storm recovery mode on all interfaces.

Syntax		
storm-control unicast		
no storm-control unicast		

no - This command disables unicast storm recovery mode on all interfaces.

Default Setting

None

Command Mode



5.2.11.5 storm control action

This command configure what actions will be performed while the storm control is detected. The actions include shutdown the interfae and send a SNMP trap if the storm occurs.

Syntax

storm-control action {shutdown | trap} no storm-control {shutdown | trap}

shutdown – To shutdown the interface if the storm occurs.

trap – To send SNMP trap if the storm occurs.

no - This command disables unicast storm recovery mode on all interfaces.

Default Setting

None

Command Mode

Interface Config

5.2.11.6 switchport broadcast rate

This command will protect your network from broadcast storms by setting a threshold level for broadcast traffic on each port.

Syntax	,
Oyntax	١.

switchport broadcast rate <1-14880000>

<1-14880000> - Specify the threshold for broadcast traffic.

Note: pps (packet per second)

Default Setting

4160 for 10G interfaces

512 for 1G interfaces

Command Mode

Interface Config

This command will protect your network from broadcast storms by setting a threshold level for broadcast traffic on all ports.

Syntax

switchport broadcast all rate <1-14880000>

<1-14880000> - Specify the threshold for broadcast traffic.

all - This command represents all interfaces.

Note: pps (packet per second)

Default Setting

4160 for 10G interfaces

512 for 1G interfaces

Command Mode

5.2.11.7 switchport multicast rate

This command will protect your network from multicast storms by setting a threshold level for multicast traffic on each port.

Syntax	7

switchport multicast rate <1-14880000>

<1-14880000> - Specify the threshold for multicast traffic

Note: pps (packet per second)

Default Setting

4160 for 10G interfaces

512 for 1G interfaces

Command Mode

Interface Config

This command will protect your network from multicast storms by setting a threshold level for multicast traffic on all ports.

Syntax

switchport multicast all rate <1-14880000>

<1-14880000> - Specify the threshold for multicast traffic.

all - This command represents all interfaces.

Note: pps (packet per second)

Default Setting

4160 for 10G interfaces

512 for 1G interfaces

Command Mode

5.2.11.8 switchport unicast rate

This command will protect your network from unicast storms by setting a threshold level for unicast traffic on each port.

_	
Synta	ax

switchport unicast rate <1-14880000>

<1-14880000> - Specify the threshold for unicast traffic

Note: pps (packet per second)

Default Setting

4160 for 10G interfaces

512 for 1G interfacces

Command Mode

Interface Config

This command will protect your network from unicast storms by setting a threshold level for unicast traffic on all ports.

Syntax

switchport unicast all rate <1-14880000>

<1-14880000> - Specify the threshold for unicast traffic.

all - This command represents all interfaces.

Note: pps (packet per second)

Default Setting

4160 for 10G interfaces

512 for 1G interfaces

Command Mode

GUANTA COMPUTER INC.

5.2.12 L2 Priority

5.2.12.1 show queue cos-map

This command displays the class of service priority map on specific interface.

Syntax

show queue cos-map {<slot/port> | port-channel <portchannel-id>}

<slot/port> - Interface number.

<portchannel-id> - Port-channel interface number. The range of port-channel ID is 1 to 64.

Default Setting

None

Command Mode

Privileged Exec

Display Message

User Priority: Displays the 802.1p priority to be mapped.

Traffic Class: Displays internal traffic class to map the corresponding 802.1p priority.

5.2.12.2 queue cos-map

This command is used to assign class of service (CoS) value to the CoS priority queue.

Syntax	
ueue cos-map <priority> <queue-id></queue-id></priority>	
no queue cos-map	

<queue-id> - The queue id of the CoS priority queue (Range: 0 - 7).

<priority> - The CoS value that is mapped to the queue id (Range: 0 - 7).

no - Sets the CoS map to the default values.

Default Setting

priority	queue
0	1
1	0
2	0
3	1
4	2
5	2
6	3
7	3

Command Mode

Interface Config

5.2.13 Port Mirror

5.2.13.1 show monitor session

This command displays the Port monitoring information for the specified session.

Syntax
- ,

show monitor session <session-id>

<session-id> - session ID. The range of session ID is 1 to 4.

Default Setting

None

Command Mode

Privileged Exec

Display Message

Session ID: indicates the session ID.

Admin Mode: indicates whether the Port Monitoring feature is enabled or disabled. The possible values are enabled and disabled.

Dest. Port: is the slot/port that is configured as the probe port. If this value has not been configured, 'Not Configured' will be displayed.

Source Port: is the slot/port that is configured as the monitored port. If this value has not been configured, 'Not Configured' will be displayed.

Type: Direction in which source port configured for port mirroring. Types are tx for transmitted packets and rx for receiving packets.

5.2.13.2 monitor session

This command configures a probe port and a monitored port for monitor session (port monitoring). Use the source interface <slot/port> parameter to specify the interface to monitor. Use rx to monitor only ingress packets, or use tx to monitor only egress packets. If you do not specify an $\{rx \mid tx\}$ option, the destination port monitors both ingress and egress packets. Use the destination interface <slot/port> to specify the interface to receive the monitored traffic.

Syntax

monitor session <session-id> {source {interface {<slot/port> | port-channel <portchannel-id>} | vlan <vlan-id> | remote vlan <vlan-id>} [{rx | tx}] | destination {interface <slot/port> | remote vlan <vlan-id> reflector-port <slot/port>} | filter {ip access-group <acl-id/name> | mac access-group acl-name}} no monitor session <session-id> { source { interface {<slot/port> | port-channel <portchannel-id>} | vlan | remote vlan} | destination {interface | remote vlan}}

<slot/port> - Interface number.

<portchannel-id> - Port-channel interface number. The range of port-channel ID is 1 to 64.

<vlan-id> - VLAN ID

tx/rx – Use to monitor ingress packets or egress packets.

no - This command removes the probe port or the mirrored port from a monitor session (port monitoring).

Default Setting

None

Command Mode

Global Config

This command removes all configured probe ports and mirrored port.

Syntax

no monitor

Default Setting

None

Command Mode



5.2.13.3 monitor session mode

This command configures the mode parameter to enabled the administrative mode of the session. If enabled, the probe port monitors all the traffic received and transmitted on the physical monitored port.

Sunta	~
Syntax	x

monitor session <session-id> mode no monitor session <session-id> mode

<session-id> - Session ID.

no - This command disables port-monitoring function for a monitor session.

Default Setting

None

Command Mode

5.2.14 Link State

5.2.14.1 show link state

Show link state information.

Syntax

show link state

Command Mode

Global Config

Display Message

Admin Mode: the link state admin mode.

Group ID: The group ID for each displayed row.

Mode: This group was set which mode.

UpStream: Display such port was included to UpStream set.

DownStream: Display such port was included to DownStream set.

5.2.14.2 link state

Enable/Disable the link state admin mode. Use 'link state' to enable the admin mode of redundant function, and use no command to disable the function.

Create/Destroy the link state group. Use 'link state group' to create a group. Use no command to destroy the group.

Enable/Disable a link state group. Use link state group enable <group id> to enable individual group, and use no command to disable a group.

Syntax

link state [group | [enable <1-6>]] no link state [group <1-6> | [enable <1-6>]]

no - This command disables link state function.

Command Mode

5.2.14.3 link state group

Set upstream port or downstream port for a link state group. Use 'link state group <group id> upstream' to set the port to be monitored.

Synta	
Synta	x

link state group <1-6> {downstream | upstream} no link state group <1-6> {downstream | upstream}

no - This command disables link state group function.

Command Mode

Interface Config

5.2.15 Port Backup

5.2.15.1 show port-backup

Show port-backup information.

Syntax	
--------	--

show port-backup

Command Mode

Privileged EXEC

Display Message

Admin Mode: Indicates whether or not port-backup is active on the switch.

Group ID: The Group ID for each displayed row.

Mode: Indicates whether or not the group is active.

MAC Update: Indicates whether or not mac-move-update is enable on the group.

Active Port: Display the active port number.

Backup Port: Display the active port number.

Current Active Port: Display the current active port number.



5.2.15.2 port-backup

Enable/Disable the port backup admin mode. Use 'port-backup' to enable the admin mode of function, and use no command to disable the function.

Create/Destroy the port backup group. Use 'port-backup group' to create a group. Use no command to destroy the group.

Enable/Disable a port-backup group. Use 'port-backup group enable <group id> to enable individual group, and use no command to disable a group.

Enable/Disable a port-backup group support the mac-move-update. Use 'port-backup group <group id> mac-move-update to enable individual group, and use no command to disable a group.

Syntax

port-backup [group {enable <1 - 6> <1 - 6> [failback-time <0 - 60> mac-move-update]}]
no port-backup [group {enable <1 - 6> <1 - 6> [failback-time <0 - 60> mac-move-update]}]

no - This command disables port-backup function.

Command Mode

Global Config

5.2.15.3 port-backup group

Set active port or backup port for a port-backup group. Use 'port-backup group <group id> <active | backup>' to set the port to be configured active or configured backup port.

Syntax

port-backup group <1-6> {active | backup} no port-backup group <1-6> {active | backup}

no - This command disables port-backup group function.

Command Mode

Interface Config

5.2.16 Expandable Port Configuration

Expandable ports allow the administrator to configure a 40G port in either 4x10G mode or 1x40G mode. When the 40G port is operating in 4x10G mode, the port operates as four 10G ports, each on a separate lane. This mode requires the use of a suitable 4x10G to 1x40G pigtail cable. The mode of the expandable port takes place when the system boots, so if the mode is changed during the switch operation, the change does not take effect until the next boot cycle.

5.2.16.1 show interface port-mode

Use this command to display the hardware information for the 40G ports. The command displays the 40G interface and the corresponding 10G interfaces. A change on the configuration will be effective with the next boot of the switch.

Syntax

show interface port-mode [<slot/port>]

<slot/port> - Specify an 40G interface to display.

Command Mode

Privileged EXEC

Display Message

40G Interface: Indicates the interface number of 40G port.

10G Interfaces: Indicates the interface number of 10G ports.

Configured Mode: Indicates the configured mode of the 40G port. The mode should be 1x40G or 4x10G.

Oper Mode: Indicates the current operational mode of the 40G port. The mode should be 1x40G or 4x10G.

		Configured	Oper
40G Interface	10G Interfaces	Mode	Mode
0/49	0/53-56	4x10g	4x10g
0/50	0/57-60	1x40g	1x40g
0/51	0/61-64	1x40g	1x40g
0/52	0/65-68	1x40g	1x40g



5.2.16.2 port-mode

Use this command to configure a 40G QSFP port in either 4x10G mode or 1x40G mode. After the mode is changed, it will not take effect immediately until the next boot cycle.

Syntax			
port-mod	e {1x40g 4x10g}		

1x40g - Configure the port as a single 40G port using four lanes.

4x10g – Configure the port as a four 10G ports, each on a separate lane. This mode requires the use of a suitable 4x10G to 1x40G pigtail cable..

no - This command resets to the default value. The default value is 1x40g.

Command Mode

Interface Config

GUANTA COMPUTER INC.

5.3 Management Commands

5.3.1 Network Commands

5.3.1.1 show ip interface

This command displays configuration settings associated with the switch's network interface. The network interface is the logical interface used for in-band connectivity with the switch via any of the switch's front panel ports. The configuration parameters associated with the switch's network interface do not affect the configuration of the front panel ports through which traffic is switched or routed.

Syntax					
show ip ir	nterface				

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Message

VLAN ID: Indicates whether the VLAN ID is used for this vlan interface.

Interface: Indicates whether the interface number for this interface.

Interface Status: Indicates whether the interface is up or down.

IP Address: The IP address of the interface. The factory default value is 0.0.0.0

Subnet Mask: The IP subnet mask for this interface. The factory default value is 0.0.0.0

MAC Address: The MAC address used for in-band connectivity.

Network Configuration Protocol Current: Indicates which network protocol is being used. The options are bootp | dhcp | none.

197

5.3.1.2 show ip filter

This command displays management IP filter status and all designated management stations.

Syn	itax							
sho	w ip fi	lter						

Default Setting

None

Command Mode

Privileged Exec

Display Message

Manegement IP Filter Address Table: The admin mode status for IP filter.

Index: The index of stations.

IP Address: The IP address of stations that are allowed to make configuration changes to the Switch.

5.3.1.3 mtu

This command sets the maximum transmission unit (MTU) size (in bytes) for physical and port-channel (LAG) interfaces. For the standard implementation, the range of <1518-12288> is a valid integer between 1518-12288.

Syntax						
mtu <151	mtu <1518-12288>					
no mtu						

<1518-12288> - Max frame size (Range: 1518 - 12288).

no - This command sets the default maximum transmission unit (MTU) size (in bytes) for the interface.

Default Setting

1518

Command Mode

Interface Config

5.3.1.4 interface vlan

This command is used to create a vlan interface and enter Interface-vlan configuration mode.

Syntax
Syntax

interface vlan <vlan-id>

<vlan-id> - VLAN ID (Range: 1 - 4093).

Default Setting

None

Command Mode

Global Config

5.3.1.5 ip address

This command sets the IP Address, and subnet mask. The IP Address and the gateway must be on the same subnet.

Syntax

ip address <ipaddr> <netmask> no ip address

<ipaddr> - IP address

<netmask> - Subnet Mask

no - Restore the default IP address and Subnet Mask

Default Setting

IP address: 0.0.0.0

Subnet Mask: 0.0.0.0

Command Mode

Interface-Vlan Config

Command Usage

Once the IP address is set, the VLAN ID's value will be assigned to management VLAN.

5.3.1.6 ip default-gateway

This command sets the IP Address of the default gateway.

Synta	vc
Synta	an

ip default-gateway <gateway> no ip default-gateway

< gateway > - IP address of the default gateway

no - Restore the default IP address of the default gateway

Default Setting

IP address: 0.0.0.0

Command Mode

Global Config

5.3.1.7 ip address dhcp

This command specifies the network configuration protocol to be used. If you modify this value, the change is effective immediately.

Syntax

ip address dhcp [restart]

<dhcp> - Obtains IP address from DHCP.

<restart> - To restart the DHCP process.

Default Setting

None

Command Mode

Interface-Vlan Config

5.3.1.8 ip filter

This command is used to enable the IP filter function.

Syntax	
ip filter no ip filter	
no ip filter	r

no – Disable ip filter.

Default Setting

Disabled

Command Mode

Global Config

This command is used to set an IP address to be a filter.

Syntax

ip filter <name> {ipv4 | ipv6} <ipAddr> [<mask>] no ip filter <name>

<name> - The name of the IP filter.

<ipAddr> - Configure a IP address to the filter.

<mask> - Specifies the mask for a range filter.

no - Remove this IP address from filter.

Default Setting

None

Command Mode

5.3.2 Serial Interface Commands

5.3.2.1 show line console

This command displays serial communication settings for the switch.

Syntax	
show line co	console

Default Setting

None

Command Mode

Privileged Exec

Display Message

Serial Port Login Timeout (minutes): Specifies the time, in minutes, of inactivity on a Serial port connection, after which the Switch will close the connection. Any numeric value between 0 and 160 is allowed, the factory default is 5. A value of 0 disables the timeout.

Baud Rate: The default baud rate at which the serial port will try to connect. The available values are 1200, 2400, 4800, 9600, 19200, 38400, 57600, and 115200 bauds.

Character Size: The number of bits in a character. The number of bits is always 8.

Flow Control: Whether Hardware Flow-Control is enabled or disabled. Hardware Flow Control is always disabled.

Stop Bits: The number of Stop bits per character. The number of Stop bits is always 1.

Parity: The Parity Method used on the Serial Port. The Parity Method is always None.

Password Threshold: When the logon attempt threshold is reached on the console port, the system interface becomes silent for a specified amount of time before allowing the next logon attempt. (Use the silent time command to set this interval.) When this threshold is reached for Telnet, the Telnet logon interface closes.

Silent Time (sec): Use this command to set the amount of time the management console is inaccessible after the number of unsuccessful logon attempts exceeds the threshold set by the password threshold command.

Terminal Length: The columns per page for terminal serial port.



5.3.2.2 line console

This command is used to enter Line configuration mode

Syntax						
line conso	ole					

Default Setting

None

Command Mode

Global Config

5.3.2.3 baudrate

This command specifies the communication rate of the terminal interface. The supported rates are 1200, 2400, 4800, 9600, 19200, 38400, 57600, 115200.

Syntax

baudrate {1200 | 2400 | 4800 | 9600 | 19200 | 38400 | 57600 | 115200} no baudrate

no - This command sets the communication rate of the terminal interface to 115200.

Default Setting

115200

Command Mode

Line Config

203

5.3.2.4 exec-timeout

This command specifies the maximum connect time (in minutes) without console activity. A value of 0 indicates that a console can be connected indefinitely. The time range is 0 to 160.

_	
Sy	ntax

Г

exec-timeout <0-160>

<0-160> - max connect time (Range: 0 -160), 0: forever.

no - This command sets the maximum connect time (in minutes) without console activity to 5.

Default Setting

5

Command Mode

Line Config

5.3.2.5 password-threshold

This command is used to set the password instruction threshold limiting the number of failed login attempts.

Syntax

password-threshold <0-120> no password-threshold

<threshold> - max threshold (Range: 0 - 120).

no - This command sets the maximum value to the default.

Default Setting

3

Command Mode

Line Config

5.3.2.6 silent-time

This command uses to set the amount of time the management console is inaccessible after the number of unsuccessful logon tries exceeds the threshold value.

Syntax	

silent-time <0-65535>

<0-65535> - silent time (Range: 0 - 65535) in seconds.

no - This command sets the maximum value to the default.

Default Setting

0

Command Mode

Line Config

5.3.2.7 terminal length

This command uses to configure the columns per page for the management console.

-	
Syntax	
Oymax	

terminal-length <0 | 5-48>

<0 | 5-48> - Columns per page (Range: 0 or 5 - 48).

no - This command sets the value to the default.

Default Setting

24

Command Mode

Line Config



5.3.3 Telnet Session Commands

5.3.3.1 telnet

This command establishes a new outbound telnet connection to a remote host.

C.	mi	ov	
31	/110	ax	

telnet <ip-address|hostname> [port] [debug] [line]

<ip-address|hostname> - A hostname or a valid IP address.

port - A valid decimal integer in the range of 0 to 65535, where the default value is 23.

debug - Display current enabled telnet options.

line - Set the outbound telnet operational mode as 'linemode', where by default, the operational mode is 'character mode'.

Default Setting

None

Command Mode

Privileged Exec

User Exec

5.3.3.2 show line vty

This command displays telnet settings.

Syntax

show line vty

Default Setting

None

Command Mode

Privileged Exec

Display Message

Remote Connection Login Timeout (minutes): This object indicates the number of minutes a remote connection session is allowed to remain inactive before being logged off. A zero means there will be no timeout. May be specified as a number from 0 to 160. The factory default is 5.

Maximum Number of Remote Connection Sessions: This object indicates the number of simultaneous remote connection sessions allowed. The factory default is 5.

206

GUANTA COMPUTER INC.

Allow New Telnet Sessions: Indicates that new telnet sessions will not be allowed when set to no. The factory default value is yes.

Telnet Server Admin Mode: The telnet server admin mode status. The factory default is enable.

Password Threshold: When the logon attempt threshold is reached on the console port, the system interface becomes silent for a specified amount of time before allowing the next logon attempt. (Use the silent time command to set this interval.) When this threshold is reached for Telnet, the Telnet logon interface closes.

Terminal Length: The columns per page for terminal vty port.

5.3.3.3 line vty

This command is used to enter vty (Telnet) configuration mode.

Syntax	
line vty	

Default Setting

None

Command Mode

5.3.3.4 exec-timeout

This command sets the remote connection session timeout value, in minutes. A session is active as long as the session has been idle for the value set. A value of 0 indicates that a session remains active indefinitely. The time is a decimal value from 0 to 160.



Changing the timeout value for active sessions does not become effective until the session is reaccessed. Any keystroke will also activate the new timeout duration.

Syntax	
exec-time	eout <1-160>
no exec-t	timeout

<sec> - max connect time (Range: 1 -160).

no - This command sets the remote connection session timeout value, in minutes, to the default.

Default Setting

5

Command Mode

Line Vty

5.3.3.5 password-threshold

This command is used to set the password instruction threshold limited for the number of failed login attempts.

Syntax

password-threshold <0-120> no password-threshold

<threshold> - max threshold (Range: 0 - 120).

no - This command sets the maximum value to the default.

Default Setting

3

Command Mode

Line Vty

5.3.3.6 terminal length

This command uses to configure the columns per page for the vty session.

-	
Syntax	
Syntax	

terminal-length <0 | 5-48>

<0 | 5-48> - Columns per page (Range: 0 or 5 - 48).

no - This command sets the value to the default.

Default Setting

24 Command Mode

Line Vty

5.3.3.7 maxsessions

This command specifies the maximum number of remote connection sessions that can be established. A value of 0 indicates that no remote connection can be established. The range is 0 to 5.

Syntax

maxsessions <0-5> no maxsessions

<0-5> - max sessions (Range: 0 - 5).

no - This command sets the maximum value to be 5.

Default Setting

5

Command Mode

Line Vty

5.3.3.8 server enable

This command enables/disables telnet server. If telnet server is enabled, all telnet sessions can be established until there are no more sessions available. If telnet server is disabled, all telnet sessions are closed.

Syntax	
server en	nable
no server	r enable

no - This command disables telnet server. If telnet server is disabled, all telnet sessions are droped.

Default Setting

Enabled

Command Mode

Line Vty

5.3.3.9 sessions

This command regulates new telnet sessions. If sessions are enabled, new telnet sessions can be established until there are no more sessions available. If sessions are disabled, no new telnet sessions are established. An established session remains active until the session is ended or an abnormal network error ends it.

Syntax	x	
sessions	ns	
no sessio	sions	

no - This command disables telnet sessions. If sessions are disabled, no new telnet sessions are established.

Default Setting

Enabled

Command Mode

Line Vty



5.3.3.10 telnet sessions

This command regulates new outbound telnet connections. If enabled, new outbound telnet sessions can be established until it reaches the maximum number of simultaneous outbound telnet sessions allowed. If disabled, no new outbound telnet session can be established. An established session remains active until the session is ended or an abnormal network error ends it.

Syntax			
telnet sea	ssions		
no telnet	sessions		

no - This command disables new outbound telnet connections. If disabled, no new outbound telnet connection can be established.

Default Setting

Enabled

Command Mode

Global Config

5.3.3.11 telnet maxsessions

This command specifies the maximum number of simultaneous outbound telnet sessions. A value of 0 indicates that no outbound telnet session can be established.

Syntax

telnet ma	xsessions <0-5>		
no maxse	essions		

<0-5> - max sessions (Range: 0 - 5).

no - This command sets the maximum value to be 5.

Default Setting

5

Command Mode



5.3.3.12 telnet exec-timeout

This command sets the outbound telnet session timeout value in minute.



Changing the timeout value for active sessions does not become effective until the session is reaccessed. Any keystroke will also activate the new timeout duration.

Syntax

telnet exec-timeout <1-160> no telnet exec-timeout

<1-160> - max connect time (Range: 1 -160).

no - This command sets the remote connection session timeout value, in minutes, to the default.

Default Setting

5

Command Mode

5.3.3.13 show telnet

This command displays the current outbound telnet settings.

Syntax			
show teln	net		

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Message

Outbound Telnet Login Timeout (in minutes) Indicates the number of minutes an outbound telnet session is allowed to remain inactive before being logged off. A value of 0, which is the default, results in no timeout.

Maximum Number of Outbound Telnet Sessions Indicates the number of simultaneous outbound telnet connections allowed.

Allow New Outbound Telnet Sessions Indicates whether outbound telnet sessions will be allowed.

5.3.4 SSH Client Session Commands

5.3.4.1 **ssh**

This command establishes a new outbound ssh connection to a remote host.

Syntax

ssh <ip-address|hostname> <username> { [port <port-id>] [protocol <protocollevel>] | [protocol <protocollevel>] [port <port-id>]}

<ip-address|hostname> - A hostname or a valid IP address.

<username> - user account.

<port-id> - A valid decimal integer in the range of 1 to 65535, where the default value is 22.

collevel> - SSH Protocol Level (Version) 1 or 2.

Default Setting

None

Command Mode

Privileged Exec

Display Message

Connected to 192.168.2.200, use ~. to terminate connection.



5.3.4.2 sshc sessions

This command regulates new outbound ssh connections. If enabled, new outbound ssh sessions can be established until it reaches the maximum number of simultaneous outbound ssh sessions allowed. If disabled, no new outbound ssh session can be established. An established session remains active until the session is ended or an abnormal network error ends it.

Syntax		
sshc sessions no sshc sessions		

no - This command disables new outbound ssh connections. If disabled, no new outbound ssh connection can be established.

Default Setting

Enabled

Command Mode

Global Config

5.3.4.3 sshc maxsessions

This command specifies the maximum number of simultaneous outbound ssh sessions. A value of 0 indicates that no outbound ssh session can be established.

Syntax

sshc maxs	sessions <0-5>			
no maxses	ssions			

<0-5> - max sessions (Range: 0 - 5).

no - This command sets the maximum value to be 5.

Default Setting

5

Command Mode

5.3.4.4 sshc exec-timeout

This command sets the outbound ssh session timeout value in minute.



Changing the timeout value for active sessions does not become effective until the session is reaccessed. Any keystroke will also activate the new timeout duration.

Syntax

sshc exec-timeout <1-160> no sshc exec-timeout

<1-160> - max connect time (Range: 1 -160).

no - This command sets the remote connection session timeout value, in minutes, to the default.

Default Setting

5

Command Mode

Global Config

5.3.4.5 **show sshc**

This command displays the current outbound sshc settings.

Syntax		
show sshc		Ì

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Message

Outbound SSH Login Timeout (in minutes) Indicates the number of minutes an outbound ssh session is allowed to remain inactive before being logged off. A value of 0, which is the default, results in no timeout.

Maximum Number of Outbound SSH Sessions Indicates the number of simultaneous outbound ssh connections allowed.

Allow New Outbound SSH Sessions Indicates whether outbound ssh sessions will be allowed.

5.3.5 SNMP Server Commands

5.3.5.1 show snmp

This command displays SNMP community information and SNMP trap/inform receivers. Trap/Inform messages are sent across a network to an SNMP Network Manager. These messages alert the manager to events occurring within the switch or on the network. Six trap/inform receivers are simultaneously supported.

Six communities are supported. You can add, change, or delete communities. The switch does not have to be reset for changes to take effect.

The SNMP agent of the switch complies with SNMP versions 1, 2c, and 3 (for more about the SNMP specification, see the SNMP RFCs). The SNMP agent sends traps through TCP/IP to an external SNMP manager based on the SNMP configuration (the trap receiver and other SNMP community parameters).

Syntax			
show snmp			

Default Setting

None

Command Mode

Privileged Exec

Display Message

Community-String: The community string to which this entry grants access. A valid entry is a case-sensitive alphanumeric string of up to 20 characters. Each row of this table must contain a unique community name.

Community-Access: The access level for this community string.

Group Name: The community this mapping configures.

View Name: The view this community has access to.

IP Address: Access to this community is limited to this IP address.

Target Address: An IP address (or portion thereof) from which this device will accept SNMP packets with the associated community.

Type: The type of message that will be sent, either traps or informs.

Community: The community traps will be sent to.

Version: The version of SNMP the trap will be sent as.

SNMP v1 – Uses SNMP v1 to send traps to the receiver.

SNMP v2 – Uses SNMP v2 to send traps to the receiver.

SNMP v3 - Uses SNMP v3 to send traps to the receiver.

UDP Port: The UDP port the trap or inform will be sent to.

Filter name: The filter the traps will be limited by for this host.

TO Sec: The number of seconds before informs will time out when sending to this host.

Retries: The number of times informs will be sent after timing out.

Username: The user this mapping configures.

Security Level: The authentication and encryption level for snmpv3.

NoAuth-N - no authentication checksum and no encryption algorithm assigned.

 ${\bf Auth\text{-}NoP}-\text{md5}$ or sha authentication checksum assigned and no encryption algorithm assigned.

Auth-Pri – md5 or sha authentication checksum and des encryption algorithm assigned.

5.3.5.2 snmp-server sysname

This command sets the name of the switch. The range for name is from 1 to 255 alphanumeric characters.

Syntax

snmp-server sysname <name>

<name> - Range is from 1 to 255 alphanumeric characters.

Default Setting

None

Command Mode

Global Config

5.3.5.3 snmp-server location

This command sets the physical location of the switch. The range for name is from 1 to 255 alphanumeric characters.

Syntax

snmp-server location <loc>

<loc> - range is from 1 to 255 alphanumeric characters.

Default Setting

None

Command Mode



5.3.5.4 snmp-server contact

This command sets the organization responsible for the network. The range for contact is from 1 to 255 alphanumeric characters.

C,	nta	v
31	IIId	X

snmp-server contact <con>

<con> - Range is from 1 to 255 alphanumeric characters.

Default Setting

None

Command Mode

5.3.5.5 snmp-server community

This command adds (and names) a new SNMP community, and optionally sets the access mode, allowed IP address, and create a view for the community.



Community names in the SNMP community table must be unique. If you make multiple entries using the same community name, the first entry is kept and processed and all duplicate entries are ignored.

Syntax

snmp-server community <community-string> [ipaddress <ipaddress> | ro | rw | su | view <viewname>] no snmp-server community <community-string>

<community-string> - A name associated with the switch and with a set of SNMP managers that manage it with a specified privileged level. The length of community-name can be up to 20 case-sensitive characters.

<ro | rw | su> - The access mode of the SNMP community, which can be public (Read-Only/RO), private (Read-Write/RW), or Super User (SU).

<ip><ipaddress> - The associated community SNMP packet sending address and is used along with the client IP mask value to denote a range of IP addresses from which SNMP clients may use that community to access the device. A value of 0.0.0.0 allows access from any IP address. Otherwise, this value is ANDed with the mask to determine the range of allowed client IP addresses.

<viewname> - The name of the view to create or update.

no - This command removes this community name from the table. The name is the community name to be deleted.

Default Setting

Two default community names:

• public, with read-only permissions, a view name of Default, and allows access from all IP addresses.

• private, with read/write permissions, a view name of Default, and allows access from all IP addresses.

Command Mode

Global Config

5.3.5.6 snmp-server community-group

This command configures a community access string to permit access via the SNMPv1 and SNMPv2c protocols.

221

Syntax

snmp-server community-group <community-string> <group-name> [ipaddress <ip-address>]

<community-string> - The community which is created and then associated with the group. The range is 1 to 20 characters.

<group-name> - The name of the group that the community is associated with. The range is 1 to 30 characters.

<ip-address> - Optionally, the IPv4 address that the community may be accessed from.

Default Setting

None

Command Mode

Global Config

5.3.5.7 show snmp engineid

This command displays the currently configured SNMP engineID.

Syntax

show snmp engineid

Default Setting

None

Command Mode

Privileged Exec

Display Message

Local SNMP EngineID: The current configuration of the displayed SNMP engineID.



5.3.5.8 snmp-server engineID

This command configures snmp engineID on the local device.



Changing the engineID will invalidate all SNMP configuration that exists on the box.

Syntax

snmp-server engineID local {<engine-id> | default} no snmp-server engineID remote <ipAddr|ipv6Addr> <engineid-string>

<engine-id> - A hexadecimal string identifying the engine-id. Engine-id must be an even length in the range of 6 to 32 hexadecimal characters.

default - Sets the engine-id to the default string, based on the device MAC address.

no - This command removes snmp engineID.

Default Setting

The engineID is configured automatically, based on the device MAC address.

Command Mode

Global Config

5.3.5.9 show snmp filters

This command displays the configured filters used when sending traps.

Syntax

show snmp filters [<filter-name>]

Default Setting

None

Command Mode

Privileged Exec

Display Message

Name: The filter name for this entry.

OID Tree: The OID tree this entry will include or exclude.

Type: Indicates if this entry includes or excludes the OID Tree.



QuantaMesh | Switching Commands

224

5.3.5.10 snmp-server filter

This command creates a filter entry for use in limiting which traps will be sent to a host.

Syntax	
• ,	

snmp-server filter <filter-name> <oid-tree> [excluded | included]

<filter-name> - The label for the filter being created. The range is 1 to 30 characters.

<oid-tree> - The OID subtree to include or exclude from the filter. Subtrees may be specified by numerical (1.3.6.2.4) or keywords (system), and asterisks may be used to specify a subtree family (1.3.*.4).

excluded - The tree is excluded from the filter.

included - The tree is included in the filter.

Default Setting

None

Command Mode

Global Config

5.3.5.11 show snmp user

This command displays the currently configured SNMPv3 users.

_		
S	yntax	2

show snmp user [<username>]

Default Setting

None

Command Mode

Privileged Exec

Display Message

Name: The name of the user.

Group Name: The group that defines the SNMPv3 access parameters.

Auth Method: The authentication algorithm configured for this user.

Privilege Method: The encryption algorithm configured for this user.

Remote Engine ID: The engineID for the user defined on the client machine.



QuantaMesh | Switching Commands

226

5.3.5.12 snmp-server user

This command creates an SNMPv3 user for access to the system.

Syntax

snmp-server user <name> <group-name> [remote <engine-idstring>] {[auth-md5 <password> | auth-md5-key <md5-key> | auth-sha <password> | auth-sha-key <sha-key>] [priv-des <password> | priv-des-key <des-key>]}

<name> - The username the SNMPv3 user will connect to the switch as. The range is 1 to 30 characters.

<group-name> - The name of the group the user belongs to. The range is 1 to 30 characters.

<engineid-string> - The engine-id of the remote management station that this user will be connecting from. The range is 5 to 32 characters.

password> - password The password the user will use for the authentication or encryption mechanism. The range is 1 to 32 characters.

md5-key - A pregenerated MD5 authentication key. The length is 32 characters.

sha-key - A pregenerated SHA authentication key. The length is 48 characters.

des-key - A pregenerated DES encryption

no - This command removes snmp user.

Default Setting

None

Command Mode

Global Config

5.3.5.13 show snmp group

This command displays the configured groups.

Syntax

show snmp group [<groupname>]

Default Setting

None

Command Mode

Privileged Exec

Display Message

Name: The name of the group.

Security Model: Indicates which protocol can access the system via this group.

Security Level: Indicates the security level allowed for this group.

Read View: The view this group provides read access to.

Write View: The view this group provides write access to.

Notify View: The view this group provides trap access to.



QuantaMesh | Switching Commands

229

5.3.5.14 snmp-server group

This command creates an SNMP access group.

Syntax

snmp-server group <group-name> [v1 | v2 | v3] {[read <readview>] | [write <writeview>] | [context <contextprefix>] | [notify <notifyview>]}

<group-name> - The group name to be used when configuring communities or users. The range is 1 to 30 characters.

v1 - This group can only access via SNMPv1.

v2 - This group can only access via SNMPv2c.

v3 - This group can only access via SNMPv3.

<readview> - The view this group will use during GET requests. The range is 1 to 30 characters.

<writeview> - The view this group will use during SET requests. The range is 1 to 30 characters.

<contextprefix> - The SNMPv3 context used during access. Applicable only if SNMPv3 is selected.

<notifyview> - The view this group will use when sending out traps. The range is 1 to 30 characters.

no - This command removes the specified group.

Default Setting

Generic groups are created for all versions and privileges using the default views.

Command Mode

Global Config

5.3.5.15 show snmp views

This command displays the currently configured views.

Syntax

show snmp views [<viewname>]

Default Setting

None

Command Mode

Privileged Exec

Display Message

Name: The view name for this entry.

OID Tree: The OID tree that this entry will include or exclude.

Type: Indicates if this entry includes or excludes the OID tree.

5.3.5.16 snmp-server view

This command creates or modifies an existing view entry that is used by groups to determine which objects can be accessed by a community or user.

Syntax
Oyntax

snmp-server view <view-name> <oid-tree> [excluded | included]

<view-name> - The label for the view being created. The range is 1 to 30 characters.

<oid-tree> - The OID subtree to include or exclude from the view. Subtrees may be specified by numerical (1.3.6.2.4) or keywords (system), and asterisks may be used to specify a subtree family (1.3.*.4).

excluded - The tree is excluded from the view.

included - The tree is included in the view.

no - This command removes the specified view.

Default Setting

Views are created by default to provide access to the default groups.

Command Mode



5.3.6 SNMP Trap Commands

5.3.6.1 snmp-server host <host-addr> traps

This command configures traps to be sent to the specified host.

Syntax	
Oymax	

snmp-server host <host-addr> traps version {1 <community> | 2 <community> | 3 <username> [auth | noauth | priv]} [filter <filtername>] [udp-port <1-65535>] no snmp-server host <host-addr>

<host-addr> - The IPv4 or IPv6 address of the host to send the trap to.

<community> - Community string sent as part of the notification. The range is 1 to 20 characters.

version 1 - Sends SNMPv1 traps.

version 2 - Sends SNMPv2 traps.

version 3 - Sends SNMPv3 traps.

<username> - Username of SNMPv3.

auth - Enables authentication but not encryption.

noauth - No authentication or encryption. This is the default.

priv - Enables authentication and encryption.

<filtername> - The filter name to associate with this host. Filters can be used to specify which traps aresent to this host. The range is 1 to 30 characters.

<udp-port> - The SNMP Trap receiver port. The default is port 162.

no - This command deletes trap receivers.

Default Setting

None

Command Mode

Global Config

5.3.6.2 show trapflags

This command displays trap conditions. Configure which traps the switch should generate by enabling or disabling the trap condition. If a trap condition is enabled and the condition is detected, the switch's SNMP agent sends the trap to all enabled trap receivers. The switch does not have to be reset to implement the changes. Cold and warm start traps are always generated and cannot be disabled.

Syntax

show trapflags

Default Setting

None

Command Mode

Privileged Exec

Display Message

Authentication Flag: May be enabled or disabled. The factory default is enabled. Indicates whether authentication failure traps will be sent.

Link Up/Down Flag: May be enabled or disabled. The factory default is enabled. Indicates whether link status traps will be sent.

Multiple Users Flag: May be enabled or disabled. The factory default is enabled. Indicates whether a trap will be sent when the same user ID is logged into the switch more than once at the same time (either via telnet or serial port).

Spanning Tree Flag: May be enabled or disabled. The factory default is enabled. Indicates whether spanning tree traps will be sent.

ACL Traps: May be enabled or disabled. The factory default is disabled. Indicates whether ACL traps will be sent.

BGP Traps: May be enabled or disabled. The factory default is disabled. Indicates whether BGP traps will be sent.

DVMRP Traps: May be enabled or disabled. The factory default is disabled. Indicates whether DVMRP traps will be sent.

OSPFv2 Traps: May be enabled or disabled. The factory default is disabled. Indicates whether OSPF traps will be sent.

PIM Traps: May be enabled or disabled. The factory default is disabled. Indicates whether PIM traps will be sent.

Transceiver Traps: May be enabled or disabled. The factory default is disabled. Indicates whether Transceiver traps will be sent.

234

5.3.6.3 snmp trap link-status

5.3.6.3.1 snmptrap link-status

This command enables link status traps by interface.



This command is valid only when the Link Up/Down Flag is enabled. See 'snmpserver enable traps linkmode' command.

Syntax snmptrap link-status

no snmptrap link-status

no - This command disables link status traps by interface.

Default Setting

Disabled

Command Mode

Interface Config

5.3.6.3.2 snmptrap link-status all

This command enables link status traps for all interfaces.



This command is valid only when the Link Up/Down Flag is enabled. See 'snmpserver enable traps linkmode' command.

Syntax

snmp trap link-status all no snmp trap link-status all

all - All interfaces.

no - This command disables link status traps for all interfaces.

Default Setting

Disabled

Command Mode



5.3.6.4 snmp-server enable traps

This command enables the acl trap.

Syntax	
--------	--

snmp-server enable traps acl-trapflags no snmp-server enable traps acl-trapflags

no - This command disables the acl trap.

Default Setting

Disabled

Command Mode

Global Config

This command enables the Authentication trap.

Syntax

snmp-server enable traps authentication no snmp-server enable traps authentication

no - This command disables the Authentication trap.

Default Setting

Enabled

Command Mode

Global Config

This command enables the BGP trap.

Syntax

snmp-server enable traps bgp state-changes limited no snmp-server enable traps bgp state-changes limited

no - This command disables the BGP trap.

236

Default Setting

Disabled

Command Mode

Global Config

This command enables the DVMRP trap.

Syntax

snmp-server enable traps dvmrp no snmp-server enable traps dvmrp

no - This command disables the DVMRP trap.

Default Setting

Disabled

Command Mode

Global Config

This command enables Link Up/Down traps for the entire switch. When enabled, link traps are sent only if the Link Trap flag setting associated with the port is enabled (see 'snmp trap link-status' command).

Syntax

snmp-server enable traps linkmode no snmp-server enable traps linkmode

no - This command disables Link Up/Down traps for the entire switch.

Default Setting

Enabled

Command Mode

This command enables Multiple User traps. When the traps are enabled, a Multiple User Trap is sent when a user logs in to the terminal interface (EIA 232 or telnet) and there is an existing terminal interface session.

Syntax

snmp-server enable traps multiusers no snmp-server enable traps multiusers

no - This command disables Multiple User trap.

Default Setting

Enabled

Command Mode

Global Config

This command enables OSPF traps.

Syntax

snmp-server enable traps ospf {all | errors {all | authentication-failure | bad-packet | config-error | virtauthentication-failure | virt-bad-packet | virt-config-error } | if-rx {all | if-rx-packet } | lsa {all | lsa-maxage | lsa-originate } | overflow {all | lsdb-overflow | lsdb-approaching-overflow } | retransmit {all | packets | virt-packets } | rtb {all, rtb-entry-info } | state-change {all | if-state-change | neighbor-state-change | virtif-statechange | virtneighbor-state-change }} no snmp-server enable traps ospf {all | errors {all | authentication-failure | bad-packet | config-error | virtauthentication-failure | virt-bad-packet | virt-config-error } | if-rx {all | if-rx-packet | lsa {all | lsa-maxage | lsa-originate } | overflow {all | lsdb-overflow | lsdb-approaching-overflow } | retransmit {all | packets | virt-packets } | rtb {all, rtb-entry-info } | state-change {all | if-state-change | neighbor-state-change | virtif-statechange | virtneighbor-state-change | lsa-originate | lsa {all | lsa-maxage | lsa-originate } | overflow {all | lsdb-overflow | lsdb-approaching-overflow } | retransmit {all | packets | virt-packets } | rtb {all, rtb-entry-info } | state-change {all | if-state-change | neighbor-state-change | virtif-statechange | virtneighbor-state-change }

no - This command disables OSPF trap.

Default Setting

Disabled

Command Mode

This command enables PIM traps.

Syntax

snmp-server enable traps pim no snmp-server enable traps pim

no - This command disables PIM trap.

Default Setting

Disabled

Command Mode

This command enables the sending of new root traps and topology change notification traps.

Syntax

snmp-server enable traps stpmode no snmp-server enable traps stpmode

no - This command disables the sending of new root traps and topology change notification traps.

Default Setting

Enabled

Command Mode

Global Config

This command enables the transceiver trap.

Syntax

snmp-server enable traps transceiver no snmp-server enable traps transceiver

no - This command disables the transceiver trap.

Default Setting

Disabled

Command Mode

Global Config

This command enables the violation trap.

Syntax

snmp-server enable traps violation no snmp-server enable traps violation

no - This command disables the violation trap.

Default Setting



Disabled

Command Mode

Global Config

5.3.6.5 show snmp source-interface

This command displays the configured global source interface used for the SNMP client. The IP address of the selected interface is used as source IP for all communications with the server.

Syntax

show snmp source-interface

Default Setting

None

Command Mode

Privileged Exec

Display Message

SNMP trap Client Source Interface: The interface configured as the source interface for the SNMP trap/inform client.

SNMP trap Client IPv4 Address: The IP address configured on the SNMP client source interface.

5.3.6.6 snmptrap source-interface

Use this command in Global configuration mode to configure the global source-interface (Source IP address) for all SNMP communications between the SNMP client and the server. This command takes effect for both SNMP trap and inform client.

Syntax

snmptrap source-interface {<slot/port> | loopback <loopback-id> | tunnel <tunnel-id> | vlan <vlan-id>} no snmptrap source-interface

<slot/port> - Specifies the interface to use as the source interface.

<loopback-id> - Specifies the loopback interface to use as the source interface. The range of the loopback ID is 0 to 7.

<tunnel-id> - Specifies the tunnel interface to use as the source interface. The range of the tunnel ID is 0 to 7.

<vlan-id> - Specifies the VLAN interface to use as the source interface. The range of VLAN ID is 1 to 4093.

no - This command removes the global source-interface for all SNMP communication between the SNMP client and the server.

Default Setting

None

Command Mode

5.3.7 SNMP Inform Commands

5.3.7.1 snmp-server host <host-addr> informs

This command configures informs to be sent to the specified host.

Syntax

snmp-server host <host-addr> informs version {2 <community> | 3 <username> [auth | noauth | priv]} [filter <filtername>] [udp-port <1-65535>] [retries <0-255>] [timeout <1-300>] no snmp-server host <host-addr>

<host-addr> - The IPv4 or IPv6 address of the host to send the inform to.

<community> - Community string sent as part of the notification. The range is 1 to 20 characters.

version 1 - Sends SNMPv1 informs.

version 2 - Sends SNMPv2 informs.

version 3 - Sends SNMPv3 informs.

<username> - Username of SNMPv3.

auth - Enables authentication but not encryption.

noauth - No authentication or encryption. This is the default.

priv - Enables authentication and encryption.

<filtername> - The filter name to associate with this host. Filters can be used to specify which informs aresent to this host. The range is 1 to 30 characters.

<udp-port> - The SNMP Inform receiver port. The default is port 162.

<retries> - The number of times to resend an Inform. The default is 3 attempts. The range is 0 to 255 retries.

<timeout> - The number of seconds to wait for an acknowledgement before resending the Inform. The default is 15 seconds. The range is 1 to 300 seconds.

no - This command deletes inform receivers.

Default Setting

None

Command Mode

Secure Shell (SSH) Commands

5.3.8.1 show ip ssh

This command displays the SSH settings.

Syntax						
show ip ssh						

Default Setting

None

Command Mode

Privileged Exec

Display Message

Administrative Mode: This field indicates whether the administrative mode of SSH is enabled or disabled.

Protocol Levels: The protocol level may have the values of version 1, version 2, or both versions.

SSH Sessions Currently Active: This field specifies the current number of SSH connections.

Max SSH Sessions Allowed: The maximum number of inbound SSH sessions allowed on the switch.

SSH Timeout: This field is the inactive timeout value for incoming SSH sessions to the switch.

Keys Present: Indicates whether the SSH RSA and DSA key files are present on the device.

Key Generation in Progress: Indicates whether RSA or DSA key files generation is currently in progress.

5.3.8.2 ip ssh

This command is used to enable SSH.

Syntax	
ip ssh no ip ssh	
no ip ssh	

no - This command is used to disable SSH.

Default Setting

Enabled

Command Mode

Global Config

5.3.8.3 ip ssh protocol

This command is used to set or remove protocol levels (or versions) for SSH. Either SSH1 (1), SSH2 (2), or both SSH 1 and SSH 2 (1 and 2) can be set.

Syntax

ip ssh protocol <protocollevel1> [protocollevel2]

<protocollevel1 - 2> - The protocol level can be set to SSH1, SSH2 or to both SSH 1 and SSH 2.

Default Setting

SSH1 and SSH2

Command Mode

5.3.8.4 ip ssh maxsessions

This command specifies the maximum number of SSH connection sessions that can be established. A value of 0 indicates that no ssh connection can be established. The range is 0 to 5.

Syntax		
ip ssh maxsessions <0-5>		
no ip ssh	no ip ssh maxsessions	

<0-5> - maximum number of sessions.

no - This command sets the maximum number of SSH connection sessions that can be established to the default value.

Default Setting

5

Command Mode

Global Config

5.3.8.5 ip ssh timeout

This command sets the SSH connection session timeout value, in minutes. A session is active as long as the session has been idle for the value set. A value of 0 indicates that a session remains active indefinitely. The time is a decimal value from 0 to 160. Changing the timeout value for active sessions does not become effective until the session is reaccessed. Any keystroke will also activate the new timeout duration.

Syntax				
ip ssh tim	meout <1-160>			
no ip ssh	no ip ssh timeout			

<1-160> - timeout interval in seconds.

no - This command sets the SSH connection session timeout value, in minutes, to the default. Changing the timeout value for active sessions does not become effective until the session is reaccessed. Any keystroke will also activate the new timeout duration.

Default Setting

5

Command Mode



5.3.9 Management Security Commands

5.3.9.1 crypto certificate generate

This commands is used to generation self-signed certificate for HTTPS.

Syntax		
crypto certificate generate		
no crypto certificate generate		

no- This command is used to delete the HTTPS certificate file from the device, regardless of whether they are self-signed or download from an outside source.

Default Setting

None

Command Mode

Global Config

5.3.9.2 crypto key generate

This command is used to generate an RSA or DSA key pair for SSH.

Syntax

crypto key generate {RSA | DSA} no crypto key generate {RSA | DSA}

no- This command is used to delete the RSA or DSA key from the device.

Default Setting

None

Command Mode

5.3.10 DHCP Client Commands

5.3.10.1 ip dhcp restart

This command is used to initiate a BOOTP or DCHP client request.

Syntax				
ip dhcp re	estart			

Default Setting

None

Command Mode

Global Config

5.3.10.2 ip dhcp client-identifier

This command is used to specify the DCHP client identifier for this switch. Use the **no** form to restore to default value.

Syntax

ip dhcp client-identifier {text <text> | hex <hex>} no ip dhcp client-identifier

<text> - A text string. (Range: 1-32 characters).

<hex> - The hexadecimal value (00:00:00:00:00:00).

no - This command is used to restore to default value.

Default Setting

A text string : "Default"

Command Mode

5.3.11 DHCPv6 Client Commands

5.3.11.1 ipv6 address dhcp

This command specifies the network of IPv6 configuration protocol to be used . If you modify this value, the change is effective immediately.

Syntax

ipv6 address dhcp [restart]

<dhcp> - Obtains IPv6 address from DHCPv6.

<restart> - To restart the DHCPv6 process.

Default Setting

None

Command Mode

Interface-Vlan Config

Interface Config

5.3.11.2 serviceport protocol

This command specifies the service port configuration protocol to be used. If you modify this value, the change is effective immediately.

Syntax	
Syntax	

serviceport protocol {bootp | dhcp | dhcp6 | none [dhcp6]}

<bootp> - Obtains IP address from BOOTP.

<dhcp> - Obtains IP address from DHCP.

<dhcp6> - Obtains IPv6 address from DHCPv6.

<none> - Obtains IP address by setting configuration.

<none dhcp6> - Obtains IPv6 address by setting configuration.

Default Setting

None

Command Mode

Global Config

5.3.11.3 serviceport protocol dhcp6 restart

This command is used to initiate a DHCPv6 client request by service port interface.

Syntax

serviceport protocol dhcp6 restart

Default Setting

None

Command Mode

5.3.12 DHCP Relay Commands

5.3.12.1 show bootpdhcprelay

This command is used to display the DHCP relay agent configuration information on the system.

Syntax			
show bootpdhcprelay			

Default Setting

None

Command Mode

Privileged Exec

Display Message

Maximum Hop Count - The maximum number of Hops a client request can go without being discarded.

Minimum Wait Time (Seconds) - The Minimum time in seconds. This value will be compared to the time stamp in the client's request packets, which should represent the time since the client was powered up. Packets will only be forwarded when the time stamp exceeds the minimum wait time.

Admin Mode - Administrative mode of the relay. When you select 'enable' BOOTP/DHCP requests will be forwarded to the IP address you entered in the 'Server IP address' field.

Circuit Id Option Mode - This is the Relay agent option which can be either enabled or disabled. When enabled Relay Agent options will be added to requests before they are forwarded to the server and removed from replies before they are forwarded to clients.

Requests Received - The total number of BOOTP/DHCP requests received from all clients since the last time the switch was reset.

Requests Relayed - The total number of BOOTP/DHCP requests forwarded to the server since the last time the switch was reset.

Packets Discarded - The total number of BOOTP/DHCP packets discarded by this Relay Agent since the last time the switch was reset.

5.3.12.2 bootpdhcprelay maxhopcount

This command is used to set the maximum relay agent hops for BootP/DHCP Relay on the system.

Syr	tav
Syr	ιιαλ

bootpdhcprelay maxhopcount <1-16> no bootpdhcprelay maxhopcount

<1-16> - maximum number of hops. (Range: 1-16).

no - This command is used to reset to the default value.

Default Setting

4

Command Mode

5.3.13 sFlow Commands

5.3.13.1 show sflow agent

The user can go to the CLI Privilege Exec to get the sFlow agent information, use the **show sflow agent** Privilege command.

Syntax	
show sfl	ow agent

Default Setting

None

Command Mode

Privilege Exec

Display Message

sFlow Version: Uniquely identifies the version and implementation of this MIB.

IP Address: The IP address associated with this agent.

5.3.13.2 show sflow pollers

The user can go to the CLI Privilege Exec to get the sFlow polling instances created on the switch, use the **show sflow pollers** Privilege command.

Syntax			
show sflo	ow pollers		

Default Setting

None

Command Mode

Privilege Exec

Display Message

Poller Data Source: The sFlowDataSource (slot/port) for this sFlow sampler. This agent will support Physical ports only.

Receiver Index: The sFlowReceiver associated with this sFlow counter poller.

Poller Interval: The number of seconds between successive samples of the counters associated with this data source.

5.3.13.3 show sflow receivers

The user can go to the CLI Privilege Exec to get the configuration information related to the sFlow receivers, use the **show sflow receivers** Privilege command.

Syntax

show sflow receivers

Default Setting

None

Command Mode

Privilege Exec

Display Message

Receiver Index: The sFlow Receiver associated with the sampler/poller.

Owner String: The identity string for receiver, the entity making use of this sFlowRcvrTable entry.

Time Out: The time (in seconds) remaining before the receiver is released and stops sending samples to sFlow receiver.

Max Datagram Size: The maximum number of bytes that can be sent in a single sFlow datagram.

Port: The destination Layer4 UDP port for sFlow datagrams.

IP Address: The sFlow receiver IP address.

5.3.13.4 show sflow samplers

The user can go to the CLI Privilege Exec to get the sFlow sampling instances created on the switch, use the **show sflow samplers** Privilege command.

Syntax

show sflow samplers

Default Setting

None

Command Mode

Privilege Exec

Display Message

Sampler Data Source: The sFlowDataSource (slot/port) for this sFlow sampler. This agent will support Physical ports only.

Receiver Index: The sFlowReceiver configured for this sFlow sampler.

Packet Sampling Rate: The statistical sampling rate for packet sampling from this source.

Max Header Size: The maximum number of bytes that should be copied from a sampled packet to form a flow sample.

5.3.13.5 show sflow rate

Use this command to display the sFlow traffic rate summary on the switch.

show sflow rate interface [<slot/port>]

<slot/port> - An interface number.

no parameter - All interfaces.

Command Mode

Privilege Exec

Display Message

Octets Received Rate	The number of octets rate received on the interface including framing characters.
Unicast Packets Received Rate	The number of unicast packets rate delivered by this sub-layer to a higher sub-layer.
Multicast Packets Received Rate	The number of multicast packets rate delivered by this sub-layer to a higher sub-layer.
Broadcast Packets Received Rate	The number of broadcast packets rate delivered by this sub-layer to a higher sub-layer.
Discarded Packets Received Rate	The number of inbound packets rate which were chosen to be discarded.
Errors Received Rate	The number of the counter rate IfInErrors.
Unknown Protocols Packets Received Rate	The number of packets rate received via the interface which were discarded because of an unknown or unsupported protocol.
Octets Transmitted Rate	The total number of octets rate transmitted out of the interface, including framing characters.
Unicast Packets Transmitted Rate	The total number of unicast packets rate that higher-level protocols requested be transmitted.
Multicast Packets Transmitted Rate	The total number of multicast packets rate that higher-level protocols requested be transmitted.
Broadcast Packets Transmitted Rate	The total number of broadcast packets rate that higher-level protocols requested be transmitted.

5.3.13.6 show sflow source-interface

The user can go to the CLI Privilege Exec to get the configured source interface for sFlow, use the **show** sflow source-interface Privilege command.

Syntax

show sflow source-interface

Default Setting

None

Command Mode

Privilege Exec

Display Message

sFlow Client Source interface: The interface ID of the physical or logical interface configured as the sFlow client source interface.

sFlow Client Source IPv4 Address: The IP address of the interface configured as the sFlow client source interface.

5.3.13.7 set sflow rate

The user can go to the CLI Interface Configuration Mode to set sampling rate, use the **sflow rate <0-3600>** interface configuration command. Use the **no sflow rate** return to default value zero.

Syntax			
sflow rate <0-3600>			
no sflow r	o sflow rate		

Default Setting

0

Command Mode



5.3.13.8 set sflow maximum header size

The user can go to the CLI Interface Configuration Mode to set maximum header size, use the **sflow maximum-header <20-256>** interface configuration command. Use the **no sflow maximum-header** return to default value 128.

Syntax

sflow sampler maxheadersize <20-256> no sflow sampler maxheadersize

Default Setting

128

Command Mode

Interface Config

5.3.13.9 set sflow maximum datagram size

The user can go to the CLI Global Configuration Mode to set maximum datagram size, use the **sflow receiver <index> maxdatagram <200-9116>** global configuration command. Use the **no sflow receiver <index> maxdatagram** return to default value 1400.

Syntax

sflow receiver <index> maxdatagram <200-9116> no sflow receiver <index> maxdatagram

Default Setting

1400

Command Mode

Global Config

5.3.13.10 set sflow receiver

The user can go to the CLI Global Configuration Mode to create a receiver session, use the **sflow receiver <index> owner <owner> {notimeout | timeout <timeout>}** global configuration command. Use the **no sflow receiver <index>** to remove the session.

Syntax

sflow receiver <index> owner <owner> {notimeout | timeout <timeout>} no sflow receiver <index>

Default Setting

None

Command Mode

5.3.13.11 set sflow receiver address

The user can go to the CLI Global Configuration Mode to set receiver ip address, use the **sflow receiver <index> ip <ip> global configuration command.** Use the **no sflow receiver <index> ip** to clear collector ip address.

Syntax

sflow receiver <index> ip <ip> no sflow receiver <index> ip

Default Setting

None

Command Mode

5.3.13.12 set sflow receiver port

The user can go to the CLI Global Configuration Mode to set collector UDP port, use the **sflow receiver** <**index> port <1-65535>** global configuration command. Use the **no sflow collector-port** return to default UDP port 6343.

Syntax

sflow receiver <index> port <1-65535> no sflow receiver <index> port

Default Setting

6343

Command Mode

Global Config

5.3.13.13 set sflow interval

The user can go to the CLI Interface Configuration Mode to set polling interval, use the **sflow poller interval <0-86400>** interface configuration command. Use the **no sflow poller interval** return to default value zero.

Syntax

sflow poller interval <0-86400> no sflow poller interval

Default Setting

0

Command Mode

Interface Config

5.3.13.14 set sflow sampler index

The user can go to the CLI Interface Configuration Mode to configure a new sFlow sampler instance, use the **sflow sampler <index>** interface configuration command. Use the **no sflow sampler** return to default setting.

Syntax		
sflow sampler <index></index>		
no sflow :	o sflow sampler	

Default Setting

None

Command Mode

Interface Config

5.3.13.15 set sflow poller index

The user can go to the CLI Interface Configuration Mode to configure a new sFlow poller instance, use the **sflow poller <index>** interface configuration command. Use the **no sflow poller** return to default setting.

Syntax

sflow poller <index> no sflow poller

Default Setting

None

Command Mode

Interface Config



5.3.13.16 Set sflow source-interface

Use this command to specify the physical or logical routing interface to use as the sFlow client source interface. If configured, the address of source interface is used for all sFlow communications between the sFlow receiver and the sFlow client. Otherwise there is no change in behavior. If the configured interface is down, the sFlow client falls back to normal behavior. User can go to the CLI Interface Configuration Mode to configure a new sFlow source interface, use the **sflow source-interface** global configuration command. Use the **no sflow source-interface** remove the source interface setting

Syntax

sflow source-interface {<slot/port> | loopback <loopback-id> | tunnel <tunnel-id> | vlan <vland-id>} no sflow source-interface

<slot/port> - Specifies the interface to use as the source interface.

<loopback-id> - Specifies the loopback interface to use as the source interface. The range of the loopback ID is 0 to 7.

<tunnel-id> - Specifies the tunnel interface to use as the source interface. The range of the tunnel ID is 0 to 7.

<vlan-id> - Specifies the VLAN interface to use as the source interface. The range of the VLAN ID is 1 to 4093.

Default Setting

None

Command Mode

5.3.14 Service Port Commands

5.3.14.1 show serviceport

This command displays service port configuration information.

yntax		
show serviceport		

Default Setting

None

Command Mode

Privileged Exec

Display Message

Interface Status: Indicates whether the interface is up or down.

IP Address: The IP address of the interface. The factory default value is 0.0.0.0.

Subnet Mask: The IP subnet mask for this interface. The factory default value is 0.0.0.0.

Default Gateway: The default gateway for this IP interface. The factory default value is 0.0.0.0.

IPv6 Administrative Mode: Whether enabled or disabled. Default value is enabled.

IPv6 Prefix is: The IPv6 address and length. Default is Link Local format.

IPv6 Default Router: The default gateway address on the service port. The factory default value is an unspecified address.**Configured IPv4 Protocol:** Indicate what IPv4 network protocol was used on the last, or current power-up cycle, if any.

Configured IPv6 Protocol: Indicate what IPv6 network protocol was used on the last, or current power-up cycle, if any.

IPv6 AutoConfig Mode: Whether enabled or disabled. Default value is disabled.

IPv6 Link-local Scope ID: The scope ID for this interface

Burned In MAC Address: The burned in MAC address used for in-band connectivity.

5.3.14.2 show serviceport ndp

This command displays IPv6 Neighbor entries.

Syntax

show serviceport ndp

Default Setting

None

Command Mode

Privileged Exec

Display Message

IPv6 Address: Specifies the IPv6 address of neighbor or interface.

MAC Address: Specifies MAC address associated with an interface.

isRtr:. Specifies router flag.

Neighbor State:

Incmp - Address resolution is being performed on the entry. A neighbor solicitation message has been sent to the solicited-node multicast address of the target, but the corresponding neighbor advertisement message has not yet been received.

Reach - Positive confirmation was received within the last Reachable Time milliseconds that the forward path to the neighbor was functioning properly. While in REACH state, the device takes no special action as packets are sent.

Stale - More than ReachableTime milliseconds have elapsed since the last positive confirmation was received that the forward path was functioning properly. While in STALE state, the device takes no action until a packet is sent.

Delay - More than ReachableTime milliseconds have elapsed since the last positive confirmation was received that the forward path was functioning properly. A packet was sent within the last DELAY_FIRST_PROBE_TIME seconds. If no reachability confirmation is received within DELAY_FIRST_PROBE_TIME seconds of entering the DELAY state, send a neighbor solicitation message and change the state to PROBE.

Probe - A reachability confirmation is actively sought by resending neighbor solicitation messages every RetransTimer milliseconds until a reachability confirmation is received.

Age Updated: Time since the address was confirmed to be reachable.

5.3.14.3 serviceport ip

This command sets the IP address, the netmask and the gateway of the network management port.

Syntax

serviceport ip <ipaddr> <netmask>

<ipaddr> - The user manually configures IP address for this switch.

<netmask> - The user manually configures Subnet Mask for this switch.

Default Setting

None

Command Mode

Global Config

5.3.14.4 serviceport protocol

This command specifies the network management port configuration protocol. If you modify this value, the change is effective immediately. If you use the bootp parameter, the switch periodically sends requests to a BootP server until a response is received. If you use the dhcp parameter, the switch periodically sends requests to a DHCP server until a response is received. If you use the none parameter, you must configure the network information for the switch manually.

Syntax

serviceport protocol {none | bootp | dhcp | dhcp6}

- none Configure the network information for the switch manually.
- **bootp** Periodically sends requests to a BootP server until a response is received.
- dhcp Periodically sends requests to a DHCP server until a response is received.
- dhcp6 Periodically sends requests to a DHCPv6 server until a response is received.

Default Setting

None

Command Mode

5.3.14.5 serviceport ipv6 enable

Use this command to enable IPv6 operation on the service port.

Sy	ntax

serviceport ipv6 enable no serviceport ipv6 enable

no - This command is disable IPv6 operation on the service port.

Default Setting

None

Command Mode

5.3.14.6 serviceport ipv6 address

Use this command to configure IPv6 global addressing (i.e. Default routers) information for the service port.

Syntax	
--------	--

serviceport ipv6 address <address>/<prefix-length> [eui64] no serviceport ipv6 address [<address>/<prefix-length>]

no - This command remove all IPv6 prefixes on the service port interface.

<address>: IPv6 prefix in IPv6 global address format.

<prefix-length>: IPv6 prefix length value.

[eui64]: Formulate IPv6 address in eui64 address format.



Multiple IPv6 prefixes can be configured for the service port.

Default Setting

None

Command Mode



5.3.14.7 serviceport ipv6 gateway

Use this command to configure IPv6 gateway (i.e. Default routers) information for the service port.

serviceport ipv6 gateway <gateway-address> no serviceport ipv6 gateway

<gateway-address>: Gateway address in IPv6 global or link-local address format.

no - This command remove IPv6 gateways on the service port interface.



Only a single IPv6 gateway address can be configured for the service port. There may be a combination of IPv6 prefixes and gateways that are explicitly configured and those that are set through auto-address configuration with a connected IPv6 router on their service port interface.

Default Setting

None

Command Mode

5.3.15 Time Range Commands

Time-based ACLs allow one or more rules within an ACL to be based on time. Each ACL rule within an ACL except for the implicit deny all rule can be configured to be active and operational only during a specific time period. The time range commands allow you to define specific times of the day and week in order to implement time-based ACLs. The time range is identified by a name and can then be referenced by an ACL rule defined with in an ACL.

5.3.15.1 Show Commands

5.3.15.1.1 show time-range

Use this command to display a time range and all the absolute/periodic time entries that are defined for the time range. Use the name parameter to identify a specific time range to display. When name is not specified, all the time ranges defined in the system are displayed.

Syntax

show time-range [<name>]

<name> - time-range name.

Default Setting

None

Command Mode

Privileged Exec

Display Message

Number of Time Ranges: Number of time ranges configured in the system.

Time Range Name: Name of the time range.

Time Range Status: Status of the time range (active/inactive).

Absolute start: Start time and day for absolute time entry.

Absolute end: End time and day for absolute time entry.

Periodic Entries: Number of periodic entries in a time-range.

Periodic start: Start time and day for periodic entry.

Periodic end: End time and day for periodic entry.

5.3.15.2 Configuration Commands

5.3.15.2.1 time-range

Use this command to enable or disable the time range Admin mode.

Syntax		
time-rang	time-range	
no time-ra	no time-range	

no - This command sets the time-range Admin mode to disalbe.

Default Setting

None

Command Mode

Global Config

5.3.15.2.2 time-range <name>

Use this command to create a time range identified by name, consisting of one absolute time entry and/or one or more periodic time entries. The name parameter is a case-sensitive, alphanumeric string from 1 to 31 characters that uniquely identifies the time range. An alpha-numeric string is defined as consisting of only alphabetic, numeric, dash, underscore, or space characters.

If a time range by this name already exists, this command enters Time-Range config mode to allow updating the time range entries

Syntax

time-range <name> no time-range <name>

<name> - The time range name.

no - This command deletes a time-range identified by name.

Default Setting

None

Command Mode



5.3.15.2.3 absolute

Use this command to add an absolute time entry to a time range. Only one absolute time entry is allowed per time-range. The time parameter is based on the currently configured time zone.

The [start time date] parameters indicate the time and date at which the configuration that referenced the time range starts going into effect. The time is expressed in a 24-hour clock, in the form of hours:minutes. For example, 8:00 is 8:00 am and 20:00 is 8:00 pm. The date is expressed in the format day month year. If no start time and date are specified, the configuration statement is in effect immediately.

The [end time date] parameters indicate the time and date at which the configuration that referenced the time range is no longer in effect. The end time and date must be after the start time and date. If no end time and date are specified, the configuration statement is in effect indefinitely.

Syntax

absolute { [start time date] [end time date] } no absolute

no - This command deletes the absolute time entry in the time range.

Default Setting

None

Command Mode

Time-Range Config



5.3.15.2.4 periodic

Use this command to add a periodic time entry to a time range. The time parameter is based off of the currently configured time zone.

The first occurrence of the days-of-the-week argument is the starting day(s) from which the configuration that referenced the time range starts going into effect. The second occurrence is the ending day or days from which the configuration that referenced the time range is no longer in effect. If the end days-of-the-week are the same as the start, they can be omitted

This argument can be any single day or combinations of days: Monday, Tuesday, Wednesday, Thursday, Friday, Saturday, Sunday. Other possible values are:

- daily Monday through Sunday
- weekdays Monday through Friday
- weekend Saturday and Sunday

If the ending days of the week are the same as the starting days of the week, they can be omitted. The first occurrence of the time argument is the starting hours:minutes which the configuration that referenced the time range starts going into effect. The second occurrence is the ending hours:minutes at which the configuration that referenced the time range is no longer in effect.

The hours:minutes are expressed in a 24-hour clock. For example, 8:00 is 8:00 am and 20:00 is 8:00 pm.

Syntax

periodic {days-of-the-week time} to {[days-of-the-week] time} no periodic {days-of-the-week time} to {[days-of-the-week] time}

no - This command deletes a periodic time entry from a time range.

Default Setting

None

Command Mode

Time-Range Config

5.3.16 Command Scheduler Commands

The Command Scheduler feature provides the ability to schedule some EXEC command-line interface (CLI) commands to run at specific calendar dates and times or at specified intervals. Command Scheduler has two basic processes. One or more policy list is configured containing lines of fully-qualified EXEC CLI to be run at the same time or interval. Each scheduled occurrence can be set to run once only or on a recurring basis.

5.3.16.1 Configuration Commands

5.3.16.1.1 Command Scheduler Occurrences

An occurrence for Command Scheduler is defined as a scheduled event. Policy lists are configured to run after a period of time since the scheduling was set, or at a specified calendar date and time.

```
kron occurrence <name> at <hh:mm> {[<1-31> <month> <year> | <DAY> of week] {oneshot |
recurring}}
kron occurrence <name> in <ddd:hh:mm> {oneshot | recurring}
no kron occurrence <name>
```

at - Indicates that the occurrence is to run at a specified calendar date and time.

in – Indicates that the occurrence is to run after a specified time interval.

<hh:mm> - Number of hours : Number of minutes.

<ddd:hh:mm> - Number of days : Number of hours : Number of munites.

<1-31><month><year> - Specifies the calendar date.

<DAY> - Day of week name.

oneshot - Indicates that the occurrence is to run only one time. After the occurrence has run, the configuration will be removed.

recurring – Indicates that occurrence is to run on a recurring basis.

no - This command deletes a occurrence entry.

Default Setting

None

Command Mode

Global Config

274

5.3.16.1.2 Command Scheduler Policy-list

Policy lists consist of one or more lines of fully-quanlified EXEC CLI commands. All commands in a policy list are executed when the policy list is run by Command Scheduler using the kron occurrence command. The policy list is run in the order in which it was configured.

One policy-list could be allowed to add to one occurrence.

list <name></name>				
t <name></name>				
ĺ	list <name> t <name></name></name>	ist <name> t <name></name></name>	ist <name> t <name></name></name>	ist <name> t <name></name></name>

<name> - Specifies the policy-list name which is to be used in the occurrence.

no - This command deletes the policy-list.

Default Setting

None

Command Mode

Global Config

Specify the EXEC CLI commands to a policy list. Maximum 16 EXEC CLI commands could be added into a policy-list.

Syntax

cli <LINE> <LINE> <LINE> ...

Default Setting

None

Command Mode

Kron-policy Config Mode

5.3.16.1.3 Occurrences and Policy-list

To associate the policy-list with a occurrence. When the occurrence is fired, the policy-list will be executed. Maximum 16 policy-lists could be added into an occurrence.

Syntax		
policy-list	st <name></name>	
no policy-	y-list <name></name>	

<name> - Specifies the policy-list name which is to be run when the occurrence fires.

no - This command remove the policy-list from a occurrence entry.

Default Setting

None

Command Mode

Kron-occurrence Config Mode

5.4 Spanning Tree Commands

This section provides detailed explanation of the spanning tree commands. The commands are divided into two functional groups:

- Show commands display spanning tree settings, statistics, and other information.
- Configuration Commands configure features and options of the switch. For every configuration command there is a show command that displays the configuration setting.

5.4.1 Show Commands

5.4.1.1 show spanning-tree

This command displays spanning tree settings for the common and internal spanning tree. The following details are displayed.

Syntax

show spanning-tree

Default Setting

None

Command Mode

Privileged Exec

Display Message

Bridge Priority: Configured value.

Bridge Identifier: The MAC Address for the Bridge from which the Bridge Identifiers used by the Spanning Tree Algorithm and Protocol.

Time Since Topology Change: In seconds.

Topology Change Count: Number of times changed.

Topology Change in progress: Boolean value of the Topology Change parameter for the switch indicating if a topology change is in progress on any port assigned to the common and internal spanning tree.

Designated Root: The Bridge Identifier of the Root Bridge for the spanning tree instance identified by the MSTID.

Root Path Cost: Value of the Root Path Cost parameter for the common and internal spanning tree.

Root Port Identifier: The Root Port for the spanning tree instance identified by the MSTID.

Bridge Max Age: Maximum message age.

Bridge Max Hops: The maximum number of hops for the spanning tree.

Max Tx Hold Count: The max value of bridge tx hold count for the spanning tree.

277

Bridge Forwarding Delay: A timeout value to be used by all Bridges in the Bridged LAN. The value of Forward Delay is set by the Root.

Hello Time: The time interval between the generations of Configuration BPDUs.

Bridge Hold Time: Minimum time between transmissions of Configuration Bridge Protocol Data Units (BPDUs).

CST Regional Root: The Bridge Identifier of the current CST Regional Root.

Regional Root Path Cost: The path cost to the regional root.

Associated FIDs: List of forwarding database identifiers currently associated with this instance.

Associated VLANs: List of VLAN IDs currently associated with this instance.

5.4.1.2 show spanning-tree interface

This command displays the settings and parameters for a specific switch port within the common and internal spanning tree. The <slot/port> is the desired switch port. The following details are displayed on execution of the command.

Syntax

show spanning-tree interface {<slot/port> | port-channel <portchannel-id>}

<**slot/port> -** is the desired interface number.

cportchannel-id> - is the desired port-channel interface number. The range of port-channel ID is 1 to 64.

Default Setting

None

Command Mode

Privileged Exec

Display Message

Hello Time: The hello time value. Not Configured means using default value.

Port Mode: The administration mode of spanning tree.

BPDU Guard: Enabled or disabled.

ROOT Guard: Enabled or disabled.

LOOP Guard: Enabled or disabled.

TCN Guard: Enabled or disabled.

BPDU Filter Mode: Enabled or disabled.

BPDU Flood Mode: Enabled or disabled.

Auto Edge: True or false.

Port Up Time Since Counters Last Cleared: Time since the port was reset, displayed in days, hours, minutes, and seconds.

STP BPDUs Transmitted: Spanning Tree Protocol Bridge Protocol Data Units sent.

STP BPDUs Received: Spanning Tree Protocol Bridge Protocol Data Units received.

RSTP BPDUs Transmitted: Rapid Spanning Tree Protocol Bridge Protocol Data Units sent.

RSTP BPDUs Received: Rapid Spanning Tree Protocol Bridge Protocol Data Units received.

MSTP BPDUs Transmitted: Multiple Spanning Tree Protocol Bridge Protocol Data Units sent.

MSTP BPDUs Received: Multiple Spanning Tree Protocol Bridge Protocol Data Units received.

5.4.1.3 show spanning-tree vlan

This command displays the association between a VLAN and a multiple spanning tree instance. The <vlan-id> corresponds to an existing VLAN ID.

Syntax

show spanning-tree vlan <vlan-id>

<vlan-id> - VLAN ID (Range: 1 - 4093).

Default Setting

None

Command Mode

Privileged Exec

Display Message

VLAN Identifier: displays VLAN ID.

Associated Instance: Identifier for the associated multiple spanning tree instance or "CST" if associated with the common and internal spanning tree.

5.4.1.4 show spanning-tree mst

This command displays settings and parameters for the specified multiple spanning tree instance. The instance <0-4094> is a number that corresponds to the desired existing multiple spanning tree instance ID. The following details are displayed.

Syntax

show spanning-tree mst detailed <0-4094>

<0-4094> - multiple spanning tree instance ID.

Default Setting

None

Command Mode

Privileged Exec

Display Message

MST Instance ID: The multiple spanning tree instance ID.

MST Bridge Priority: The bridge priority of current MST.

MST Bridge Identifier: The bridge ID of current MST.

Time Since Topology Change: In seconds.

Topology Change Count: Number of times the topology has changed for this multiple spanning tree instance.

Topology Change in Progress: Value of the Topology Change parameter for the multiple spanning tree instance.

Designated Root: Identifier of the Regional Root for this multiple spanning tree instance.

Root Path Cost: Path Cost to the Designated Root for this multiple spanning tree instance.

Root Port Identifier: Port to access the Designated Root for this multiple spanning tree instance

Associated FIDs: List of forwarding database identifiers associated with this instance.

Associated VLANs: List of VLAN IDs associated with this instance.

This command displays summary information about all multiple spanning tree instances in the switch. On execution, the following details are displayed.

Syntax

show spanning-tree mst summary

Default Setting

None

Command Mode

Privileged Exec

Display Message

MST Instance ID List: List of multiple spanning trees IDs currently configured.

For each MSTID: The multiple spanning tree instance ID.

Associated FIDs: List of forwarding database identifiers associated with this instance.

Associated VLANs: List of VLAN IDs associated with this instance.

This command displays the detailed settings and parameters for a specific switch port within a

particular multiple spanning tree instance. The instance <mstid> is a number that corresponds to the desired existing multiple spanning tree instance. The <slot/port> is the desired switch port.

Syntax

show spanning-tree mst port detailed <0-4094> {<slot/port> | port-channel <portchannel-id>}

<0-4094> - multiple spanning tree instance ID.

<slot/port> - is the desired interface number.

ortchannel-id> - is the desired port-channel interface number. The range of port-channel ID is 1 to 64.

Default Setting

None

Command Mode

Privileged Exec

Display Message

MST Instance ID: The multiple spanning tree instance ID.

Port Identifier: The unique value to identify a port on that Bridge.

282

Port Priority: The priority of the port within the MST.
Port Forwarding State: Current spanning tree state of this port.
Port Role: Indicate the port role is root or designate.
Auto-calculate Port Path Cost: Indicate the port auto-calculate port path cost.
Port Path Cost: Configured value of the Internal Port Path Cost parameter.
Designated Root: The Identifier of the designated root for this port.
Designated Port Cost: Path Cost offered to the LAN by the Designated Port.
Designated Bridge: Bridge Identifier of the bridge with the Designated Port.

If 0 (defined as the default CIST ID) is passed as the <0-4094>, then this command displays the settings and parameters for a specific switch port within the common and internal spanning tree. The <slot/port> is the desired switch port. In this case, the following are displayed.

Port Identifier: The port identifier for this port within the CST.

Port Priority: The priority of the port within the CST.

Port Forwarding State: The forwarding state of the port within the CST.

Port Role: The role of the specified interface within the CST.

Auto-calculate Port Path Cost: Indicate the port auto-calculate port path cost

Port Path Cost: The configured path cost for the specified interface.

Auto-calculate External Port Path Cost - Displays whether the external path cost is automatically calculated (Enabled) or not (Disabled). External Path cost will be calculated based on the link speed of the port if the configured value for External Port Path Cost is zero.

External Port Path Cost - The External Path Cost of the specified port in the spanning tree.

Designated Root: Identifier of the designated root for this port within the CST.

Designated Port Cost: Path Cost offered to the LAN by the Designated Port.

Designated Bridge: The bridge containing the designated port.

Designated Port Identifier: Port on the Designated Bridge that offers the lowest cost to the LAN.

Topology Change Acknowledgement: Value of flag in next Configuration Bridge Protocol Data Unit (BPDU) transmission indicating if a topology change is in progress for this port.

Hello Time: The hello time in use for this port.

Edge Port: The configured value indicating if this port is an edge port.

Edge Port Status: The derived value of the edge port status. True if operating as an edge port; false otherwise.

Point To Point MAC Status: Derived value indicating if this port is part of a point to point link.

CST Regional Root: The regional root identifier in use for this port.

CST Port Cost: The configured path cost for this port.

Transitions Into Loop Inconsistent State: The count number of transitions into loop inconsistent state.

283

Transitions Out Of Loop Inconsistent State: The count number of transitions out of loop inconsistent state.

This command displays the settings of one or all ports within the specified multiple spanning tree instance. The parameter <0-4094> indicates a particular MST instance. The parameter {<slot/port>} indicates the desired switch port.

If 0 (defined as the default CIST ID) is passed as the <0-4094>, then the status summary is displayed for one or all ports within the common and internal spanning tree.

Syntax

show spanning-tree mst port summary <0-4094> [{<slot/port> | active | port-channel <portchannel-id>}]

<0-4094> - multiple spanning tree instance ID.

<slot/port> - is the desired interface number.

active - All active interfaces.

cportchannel-id> - is the desired port-channel interface number. The range of port-channel ID is 1 to 64.

no parameter - All interfaces.

Default Setting

None

Command Mode

Privileged Exec

Display Message

MST Instance ID: The MST instance associated with this port.

Interface: The interface being displayed.

STP Mode: Indicate STP mode.

Type: Currently not used.

STP State: The forwarding state of the port in the specified spanning tree instance.

Port Role: The role of the specified port within the spanning tree.

Desc: The port in loop inconsistence state will display "*LOOP_Inc".

5.4.1.5 show spanning-tree summary

This command displays spanning tree settings and parameters for the switch. The following details are displayed on execution of the command.

Syntax

show spanning-tree summary

Default Setting

None

Command Mode

Privileged Exec

Display Message

Spanning Tree Adminmode: Enabled or disabled.

Spanning Tree Forward BPDU: Enabled or disabled

Spanning Tree Version: Version of 802.1 currently supported (IEEE 802.1s, IEEE 802.1w, or IEEE 802.1d) based upon the Force Protocol Version parameter.

BPDU Guard Mode: Enabled or disabled.

BPDU Filter Mode: Enabled or disabled.

BPDU Uplinkfast Mode: Enabled or disabled.

Configuration Name: TConfigured name.

Configuration Revision Level: Configured value.

Configuration Digest Key: Calculated value.

Configuration Format Selector: Configured value.

MST Instances: List of all multiple spanning tree instances configured on the switch.

5.4.1.6 show spanning-tree brief

This command displays spanning tree settings for the bridge. In this case, the following details are displayed.

Syntax

show spanning-tree brief

Default Setting

None

Command Mode

Privileged Exec

Display Message

Bridge Priority: Configured value.

Bridge Identifier: The bridge ID of current Spanning Tree.

Bridge Max Age: Configured value.

Bridge Max Hops: Configured value.

Bridge Hello Time: Configured value.

Bridge Forward Delay: Configured value.

Bridge Hold Time: Minimum time between transmission of Configuration Bridge Protocol Data Units (BPDUs).

5.4.2 Configuration Commands

5.4.2.1 spanning-tree

This command sets the spanning-tree operational mode to be enabled.

Syntax			
spanning	j-tree		
no spann	ning-tree		

no - This command sets the spanning-tree operational mode to be disabled. While disabled, the spanning-tree configuration is retained and can be changed, but is not activated.

Default Setting

Disabled

Command Mode

Global Config

5.4.2.2 spanning-tree protocol-migration

This command enables BPDU migration check on a given interface. The **all** option enables BPDU migration check on all interfaces.

Syntax

spanning-tree protocol-migration {<slot/port> | port-channel <portchannel-id> | all} no spanning-tree protocol-migration {<slot/port> | port-channel <portchannel-id> | all}

<slot/port> - is the desired interface number.

ortchannel-id> - is the desired interface number. The range of port-channel ID is 1 to 4.

all - All interfaces.

no - This command disables BPDU migration check on a given interface. The **all** option disables BPDU migration check on all interfaces.

Default Setting

None

Command Mode

5.4.2.3 spanning-tree configuration

This command sets the Configuration Identifier Name for use in identifying the configuration that this switch is currently using. The <name> is a string of at most 32 alphanumeric characters.

Syntax	
spanning	g-tree configuration name <name></name>
no spann	ning-tree configuration name

<name> - is a string of at most 32 alphanumeric characters.

no - This command resets the Configuration Identifier Name to its default.

Default Setting

The base MAC address displayed using hexadecimal notation as specified in IEEE 802 standard.

Command Mode

Global Config

This command sets the Configuration Identifier Revision Level for use in identifying the configuration that this switch is currently using. The Configuration Identifier Revision Level is a number in the range of 0 to 65535.

Syntax

spanning-tree configuration revision <0-65535> no spanning-tree configuration revision

<value> - Revision Level is a number in the range of 0 to 65535.

no - This command sets the Configuration Identifier Revision Level for use in identifying the configuration that this switch is currently using to the default value, that is, 0.

Default Setting

0

Command Mode

5.4.2.4 spanning-tree mode

This command sets the Force Protocol Version parameter to a new value. The Force Protocol Version can be one of the following:

- 1. stp ST BPDUs are transmitted rather than MST BPDUs (IEEE 802.1d functionality supported)
- 2. rstp RST BPDUs are transmitted rather than MST BPDUs (IEEE 802.1w functionality supported)
- 3. mstp MST BPDUs are transmitted (IEEE 802.1s functionality supported)

Syntax

spanning	-tree mode {stp rstp mstp}
no spanni	ing-tree mode

no - This command sets the Force Protocol Version parameter to the default value, that is, mstp.

Default Setting

mstp

Command Mode

Global Config

5.4.2.5 spanning-tree forward-time

This command sets the Bridge Forward Delay parameter to a new value for the common and internal spanning tree. The forward-time value is in seconds within a range of 4 to 30, with the value being greater than or equal to "(Bridge Max Age / 2) + 1".

Syntax	
spanning-tree forward-time <4-30>	
no spanning-tree forward-time	

<4-30> - forward time value (Range: 4 – 30).

no - This command sets the Bridge Forward Delay parameter for the common and internal spanning tree to the default value, that is, 15.

Default Setting

15

Command Mode

Global Config

289

5.4.2.6 spanning-tree max-age

This command sets the Bridge Max Age parameter to a new value for the common and internal spanning tree. The max-age value is in seconds within a range of 6 to 40, with the value being less than or equal to "2 times (Bridge Forward Delay - 1)" and greater than or equal to "2 times (Bridge Hello Time + 1)".

Syntax	
spanning	g-tree max-age <6-40>
no spanning-tree max-age	

<6-40> - the Bridge Max Age value (Range: 6 - 40).

no - This command sets the Bridge Max Age parameter for the common and internal spanning tree to the default value, that is, 20.

Default Setting

20

Command Mode

Global Config

5.4.2.7 spanning-tree max-hops

This command sets the MSTP Max Hops parameter to a new value for the common and internal spanning tree. The max-hops value is in a range of 6 to 40.

Syntax

spanning-tree max-hops <6-40> no spanning-tree max-hops

<6-40> - the Maximum hops value (Range: 6-40).

no - This command sets the Bridge Max Hops parameter for the common and internal spanning tree to the default value.

Default Setting

20

Command Mode

5.4.2.8 spanning-tree hold-count

This command sets the Bridge Tx Hold Count parameter to a new value for the common and internal spanning tree. The Tx Hold Count value is in a range of 1 to 110.

Syntax	
spanning	-tree hold-count <1-10>
no spanning-tree hold-count	

<1-10> - the Maximum hold-count value (Range: 1-110).

no - This command sets the Bridge Tx Hold Count parameter for the common and internal spanning tree to the default value.

Default Setting

6

Command Mode

Global Config

5.4.2.9 spanning-tree mst

This command adds a multiple spanning tree instance to the switch. The instance <1-4094> is a number within a range of 1 to 4094 that corresponds to the new instance ID to be added. The maximum number of multiple instances supported is 4.

Syntax	
Oyman	

spanning	-tree mst instance <1-4094>
no spann	ning-tree mst instance <1-4094>

<1-4094> - multiple spanning tree instance ID.

no - This command removes a multiple spanning tree instance from the switch and reallocates all VLANs allocated to the deleted instance to the common and internal spanning tree. The instance <1-4094> is a number that corresponds to the desired existing multiple spanning tree instance to be removed.

Default Setting

None

Command Mode



This command sets the bridge priority for a specific multiple spanning tree instance. The instance <mstid> is a number that corresponds to the desired existing multiple spanning tree instance. The priority value is a number within a range of 0 to 61440 in increments of 4096.

If 0 (defined as the default CIST ID) is passed as the <mstid>, then this command sets the Bridge Priority parameter to a new value for the common and internal spanning tree. The bridge priority value again is a number within a range of 0 to 61440. The twelve least significant bits will be masked according to the 802.1s specification.

This will cause the priority to be rounded down to the next lower valid priority.

Syntax

spanning-tree mst priority <0-4094> <0-61440> no spanning-tree mst priority <0-4094>

<0-4094> - multiple spanning tree instance ID.

<0-61440> - priority value (Range: 0 – 61440).

no - This command sets the bridge priority for a specific multiple spanning tree instance to the default value, that is, 32768. The instance <0-4094> is a number that corresponds to the desired existing multiple spanning tree instance.

If 0 (defined as the default CIST ID) is passed as the <0-4094>, then this command sets the Bridge Priority parameter for the common and internal spanning tree to the default value, that is, 32768.

Default Setting

32768

Command Mode

Global Config

This command adds an association between a multiple spanning tree instance and a VLAN. The VLAN will no longer be associated with the common and internal spanning tree. The instance <0-4094> is a number that corresponds to the desired existing multiple spanning tree instance. The <1-4093> corresponds to an existing VLAN ID.

Syntax

spanning-tree mst vlan <0-4094> <vlan-list> no spanning-tree mst vlan <0-4094> <vlan-list>

<0-4094> - multiple spanning tree instance ID. <vlan-list> - VLAN ID (Range: 1 – 4093). **no** - This command removes an association between a multiple spanning tree instance and a VLAN. The VLAN will again be associated with the common and internal spanning tree. The instance <0-4094> is a number that corresponds to the desired existing multiple spanning tree instance. The <1-4093> corresponds to an existing VLAN ID.

Default Setting

None

Command Mode

Global Config

This command sets the Path Cost or Port Priority for this port within the multiple spanning tree instance or in the common and internal spanning tree. If the <1-4094> parameter corresponds to an existing multiple spanning tree instance, then the configurations are done for that multiple spanning tree instance. If however 0 (defined as the default CIST ID) is passed as the <1-4094>, then the configurations are performed for the common and internal spanning tree instance.

If the 'cost' token is specified, this command sets the path cost for this port within a multiple spanning tree instance or the common and internal spanning tree instance, depending on the <1-4094> parameter. The pathcost can be specified as a number in the range of 1 to 200000000 or auto. If "auto" is specified, the pathcost value will be set based on Link Speed.

Syntax

spanning-tree mst <1-4094> cost {<1-200000000> | auto} no spanning-tree mst <1-4094> cost

<1-4094> - multiple spanning tree instance ID.

no - This command sets the Path Cost or Port Priority for this port within the multiple spanning tree instance or in the common and internal spanning tree to the respective default values. If the <1-4094> parameter corresponds to an existing multiple spanning tree instance, then the configurations are done for that multiple spanning tree instance. If however, 0 (defined as the default CIST ID) is passed as the <1-4094>, then the configurations are performed for the common and internal spanning tree instance.

If the 'cost' token is specified, this command sets the path cost for this port within a multiple spanning tree instance or the common and internal spanning tree instance, depending on the <1-4094> parameter, to the default value, that is, a pathcost value based on the Link Speed.

Default Setting

Cost : auto

Command Mode

Interface Config



This command sets the Path Cost or Port Priority for this port within the multiple spanning tree instance or in the common and internal spanning tree. If the <1-4094> parameter corresponds to an existing multiple spanning tree instance, then the configurations are done for that multiple spanning tree instance. If however 0 (defined as the default CIST ID) is passed as the <1-4094>, then the configurations are performed for the common and internal spanning tree instance.

If the 'port-priority' token is specified, this command sets the priority for this port within a specific multiple spanning tree instance or the common and internal spanning tree instance, depending on the <1-4094> parameter. The port-priority value is a number in the range of 0 to 240 in increments of 16.

Syntax

spanning-tree mst <1-4094> port-priority <0-240> no spanning-tree mst <1-4094> port-priority

<1-4094> - multiple spanning tree instance ID.

no - This command sets the Path Cost or Port Priority for this port within the multiple spanning tree instance or in the common and internal spanning tree to the respective default values. If the <1-4094> parameter corresponds to an existing multiple spanning tree instance, then the configurations are done for that multiple spanning tree instance. If however, 0 (defined as the default CIST ID) is passed as the <1-4094>, then the configurations are performed for the common and internal spanning tree instance.

If the 'port-priority' token is specified, this command sets the priority for this port within a specific multiple spanning tree instance or the common and internal spanning tree instance, depending on the <1-4094> parameter, to the default value, that is, 128.

Default Setting

port-priorty : 128

Command Mode

Interface Config

5.4.2.10 spanning-tree port mode

This command sets the Administrative Switch Port State for this port to enabled.

Cunto	
Synta	х

spanning-tree port mode no spanning-tree port mode

no - This command sets the Administrative Switch Port State for this port to disabled.

Default Setting

Disabled

Command Mode

Interface Config

This command sets the Administrative Switch Port State for all ports to enabled.

Syntax

spanning-tree port mode all no spanning-tree port mode all

all - All interfaces.

no - This command sets the Administrative Switch Port State for all ports to disabled.

Default Setting

Disabled

Command Mode

5.4.2.11 spanning-tree auto-edge

This command sets the auto-edge for this port to enabled.

Syntax	
Syntax	

Г

spanning-tree auto-edge no spanning-tree auto-edge

no - This command sets the auto-edge for this port to disabled.

Default Setting

Disabled

Command Mode

Interface Config

5.4.2.12 spanning-tree edgeport

This command sets the edguport function to Enabled or Disabled on this switch.

Syntax

spanning-tree edgeport no spanning-tree edgeport

no - This command sets the Edgeport function to the default value, that is Enabled.

Default Setting

Enabled

Command Mode

This command specifies that this port is an Edge Port within the common and internal spanning tree. This will allow this port to transition to Forwarding State without delay.

Syntax		
spanning	y-tree edgeport	
no spann	no spanning-tree edgeport	

no - This command specifies that this port is not an Edge Port within the common and internal spanning tree.

Default Setting

None

Command Mode

Interface Config

This command sets the Edgeport BPDU Filter enable/disable parameter for sending/receiving BPDUs on this switch. This command only works on dot1d mode.

Syntax

spanning-tree edgeport bpdufilter no spanning-tree edgeport bpdufilter

no - This command sets the Edgeport BPDU Filter to the default value, that is Disabled.

Default Setting

Disabled

Command Mode

This command sets the Edgeport BPDU Guard enable/disable parameter for accepting BPDUs on this switch. This command only works on dot1d mode.

Syntax	
spanning-t	ree edgeport bpdugi

_

spanning-tree edgeport bpduguard no spanning-tree edgeport bpduguard

no - This command sets the Edgeport BPDU Guard to the default value, that is, Disabled.

Default Setting

Disabled

Command Mode

Global Config

This command sets the Edgeport BPDU Filter enable/disable parameter for sending/receiving BPDUs on this interface. This command only works on dot1d mode.

Syntax

spanning-tree bpdufilter no spanning-tree bpdufilter

no - This command sets the Edgeport BPDU Filter to the default value, that is Disabled.

Default Setting

Disabled

Command Mode

Interface Config

This command sets the Edgeport BPDU Guard enable/disable parameter for accepting BPDUs on this interface. This command only works on dot1d mode.

Syntax		
spanning-t	ree bpduguard	
no spannir	no spanning-tree bpduguard	

no - This command sets the Edgeport BPDU Guard to the default value, that is, Disabled.

Default Setting

Disabled

Command Mode

Interface Config

5.4.2.13 spanning-tree uplinkfast

This command sets the Uplink Fast parameter to a new value on this switch. This command only works on dot1d mode.

Syntax

spanning-tree uplinkfast no spanning-tree uplinkfast

no - This command sets the Uplink Fast parameter to the default value, that is Disabled.

Default Setting

Disabled

Command Mode

5.4.2.14 spanning-tree guard {loop|none|root}

This command sets the Guard Mode parameter to a new value on this interface.

Syntax

spanning-tree guard {loop|none|root} no spanning-tree guard

loop –This command sets the Guard Mode to loop guard on this interface.

none – This command sets the Guard Mode to none.

root – This command sets the Guard Mode to root guard on this interface.

no - This command sets the Guard Mode to the default value, that is none.

Default Setting

None

Command Mode

Interface Config

5.4.2.15 spanning-tree tcnguard

This command sets the TCN Guard parameter to prevent a port from propagating topology change notifications.

Syntax		
spanning	-tree tcnguard	
no spanni	ing-tree tcnguard	

no - This command sets the tcnguard parameter to the default value, that is Disabled.

Default Setting

Disabled

Command Mode

Interface Config

GUANTA COMPUTER INC.

5.5 System Log Management Commands

5.5.1 Show Commands

5.5.1.1 show logging

This command displays logging.

Syntax

show logging

Default Setting

None

Command Mode

Privileged Exec

Display Message

Logging Client Local Port The port on the collector/relay to which syslog messages are sent

CLI Command Logging The mode for CLI command logging.

Console Logging The mode for console logging.

Console Logging Severity Filter The minimum severity to log to the console log. Messages with an equal or lower numerical severity are logged.

Buffered Logging The mode for buffered logging.

Syslog Logging The mode for logging to configured syslog hosts. If set to disable logging stops to all syslog hosts.

Terminal Monitor The mode for terminal logging.

Terminal Logging Severity Filter The minimum severity to log to the terminal log. Messages with an equal or lower numerical severity are logged.

Log Messages Received The number of messages received by the log process. This includes messages that are dropped or ignored

Log Messages Dropped The number of messages that could not be processed.

Log Messages Relayed The number of messages that are relayed.

Logging Client Source Interface The interface configured as the source interface for the syslog client.

Logging Client Source IPv4 Address The IP address configured on the syslog client source interface.

5.5.1.2 show logging buffered

This command displays the message log maintained by the switch. The message log contains system trace information.

Syntax

show logging buffered

Default Setting

None

Command Mode

Privileged Exec

Display Message

Message: The message that has been logged.



Message log information is not retained across a switch reset.

5.5.1.3 show logging traplog

This command displays the trap log maintained by the switch.

The trap log contains a maximum of 256 entries that wrap.

Syntax

show logging traplogs

Default Setting

None

Command Mode

Privileged Exec

Display Message

Number of Traps since last reset: The number of traps that have occurred since the last reset of this device.

Trap Log Capacity: The maximum number of traps that could be stored in the switch.

Log: The sequence number of this trap.

System Up Time: The relative time since the last reboot of the switch at which this trap occurred.

302

Trap: The relevant information of this trap.



Trap log information is not retained across a switch reset.

5.5.1.4 show logging hosts

This command displays all configured logging hosts.

Syntax

show logging hosts

Default Setting

None

Command Mode

Privileged Exec

Display Message

Index: used for deleting.

IP Address: IP Address of the configured server.

Severity: The minimum severity to log to the specified address.

Port Server Port Number: This is the port on the local host from which syslog messages are sent.

Status: The state of logging to configured syslog hosts. If the status is disable, no logging occurs.

5.5.2 Configuration Commands

5.5.2.1 logging buffered

This command enables logging to in-memory log where up to 128 logs are kept.

Syntax			
logging buf no logging l			

no - This command disables logging to in-memory log.

Default Setting

None

Command Mode

Global Config

This command enables wrapping of in-memory logging when full capacity reached. Otherwise when full capacity is reached, logging stops.

Syntax	
	puffered wrap
no loggin	ng buffered wrap

no - This command disables wrapping of in-memory logging when full capacity reached.

Default Setting

None

Command Mode

5.5.2.2 logging console

This command enables logging to the console.

logging console [<severitylevel> | <0-7>] no logging console

[<severitylevel> | <0-7>] - The value is specified as either an integer from 0 to 7 or symbolically through one of the following keywords: emergency (0), alert (1), critical (2), error (3), warning (4), notice (5), informational (6), debug (7).

no - This command disables logging to the console.

Default Setting

None

Command Mode

Global Config

5.5.2.3 logging monitor

This command enables logging to the terminal monitor.

Syntax

logging monitor [<severitylevel> <0-7>]</severitylevel>	
no logging monitor	

[<severitylevel> | <0-7>] - The value is specified as either an integer from 0 to 7 or symbolically through one of the following keywords: emergency (0), alert (1), critical (2), error (3), warning (4), notice (5), informational (6), debug (7).

no - This command disables logging to the terminal monitor.

Default Setting

None

Command Mode

5.5.2.4 terminal monitor

This command enables logging for the terminal session.

Syntax			
terminal r	monitor		
no termin	al monitor		

no - This command disables logging for the terminal session.

Default Setting

None

Command Mode

Privileged Exec

5.5.2.5 logging host

This command enables logging to a host where up to eight hosts can be configured.

Syntax

logging host <hostaddress> [<port>] [[<severitylevel> | <0-7>]]

<hostaddress> - IP address of the log server.

<port> - Port number.

[<severitylevel> | <0-7>] - The value is specified as either an integer from 0 to 7 or symbolically through one of the following keywords: emergency (0), alert (1), critical (2), error (3), warning (4), notice (5), informational (6), debug (7).

Default Setting

None

Command Mode

This command disables logging to hosts.

Syntax

logging host remove <hostindex>

<hostindex> - Index of the log server.

Default Setting

None

Command Mode

Globla Config

This command reconfigures the IP address of the log server.

Syntax

logging host reconfigure <hostindex> <hostaddress>

<hostindex> - Index of the log server.

<hostaddress> - New IP address of the log server.

Default Setting

None

Command Mode

5.5.2.6 logging syslog

This command enables syslog logging.

Syntax

logging syslog no logging syslog

no - Disables syslog logging.

Default Setting

None

Command Mode

Globla Config

This command sets the local port number of the LOG client for logging messages.

Syntax

logging syslog port <portid> no logging syslog port

no - Resets the local logging port to the default.

Default Setting

None

Command Mode

Use this command to specify the physical or logical interface to use as the Syslog client source interface. If configured, the address of source interface is used for all Syslog communications between the Syslog server and the Syslog client. Otherwise there is no change in behavior. If the configured interface is down, the Syslog client falls back to normal behavior.

Syntax

logging syslog source-interface {<slot/port> | loopback <loopback-id> | tunnel <tunnel-id> | vlan <vlan-id>}

no logging syslog source-interface

<slot/port> - Specifies the interface to use as the source interface.

<loopback-id> - Specifies the loopback interface to use as the source interface. The range of the loopback ID is 0 to 7.

<tunnel-id> - Specifies the tunnel interface to use as the source interface. The range of the tunnel ID is 0 to 7.

<vlan-id> - Specifies the VLAN interface to use as the source interface. The range of VLAN ID is 1 to 4093.

no – To remove the configured source interface for all Syslog communications between the Syslog client and the server.

Default Setting

None

Command Mode



5.5.2.7 clear logging buffered

This command clears all in-memory log.

Syntax

clear logging buffered

Default Setting

None

Command Mode

5.6 Email Alerting and Mail Server Commands

Email Alert is an extension of the logging system. This feature can immediately send urgent log messages to a specified mail address by email. It also can send non-urgent log messages created in a specified interval to a specified address. If there is no buffer to keep non-urgent log messages in the specified interval, the log messages will be sent and cleared.

5.6.1 Show Commands

5.6.1.1 Show logging email config

This command displays information about the email alert configuration.

Syntax

show logging email config

Default Setting

None

Command Mode

Privileged Exec

Display Message

Email Alert Logging The administrative status of the feature: enabled or disabled.

Email Alert Form Address The email address of the sender (the switch).

Email Alert Urgent Severity Level The lowest severity level that considered urgent. Messages of this type are sent immediately.

Email Alert Non Urgent Severity Level The lowest severity level that is considered non-urgent. Messages of this type, up to the urgent level, are collected and sent in a batch email. Log messages that are less severe are not sent in an email message at all.

Email Alert Trap Severity Level The lowest severity level at which traps are logged.

Email Alert Notification Period The amount of time to wait between non-urgent messages.

Email Alert To Address Table The configured email recipients.

Email Alert Subject Table The subject lines included in urgent and non-urgent messages.

For Msg Type urgent, subject is The configured email subject for sending urgent messages.

For Msg Type non-urgent, subject is The configured email subject for sending non-urgent messages.

5.6.1.2 Show logging email statistics

This command displays email alerting statistics.

Syntax

show logging email statistics

Default Setting

None

Command Mode

Privileged Exec

Display Message

Email Alert Operation Status The operational status of the email alerting feature.

No of Email Failures The number of email messages that have attempted to be sent but were unsuccessful.

No of Email Sent The number of email messages that were sent from the switch since the counter was cleared.

Time Since Last Email Sent The amount of time that has passed since the last email was sent from the switch.

5.6.1.3 Show mail server config

This command displays information about email server configuration.

Syntax	
how mail-server config	

Default Setting

None

Command Mode

Privileged Exec

Display Message

No of mail servers configured The number of SMTP servers configured on the switch.

Email Alert Mail Server Address The IPv4/IPv6 address or DNS hostname of the configured SMTP server.

Email Alert Mail Server Port The TCP port the switch uses to send email to the SMTP server.

Email Alert Security Protocol The security protocol the switch uses to authenticate with the SMTP server.

Email Alert Username The username the switch uses to authenticate with the SMTP server.

Email Alert Password The password the switch uses to authenticate with the SMTP server.

5.6.2 Configuration Commands

5.6.2.1 Logging email

This command enables email alerting and sets the lowest serverity level for which log messages are emailed. If you specify a severity level, log messages at or above this severity level, but below the urgent severity level, are emailed in a non-urgent manner by collecting them together until the log time expires. You can specify the *severitylevel* value as either an integer from 0 to 7 or symbolically through one of the following keywords: emergency(0), alert(1), critical(2), error(3), warning(4), notice(5), info(6), or debug(7).

Syntax

logging email [{urgent | non-urgent} {<severity> | none}] no logging email [{urgent | non-urgent}]

urgent - Specify the severity level for the urgent messsages. The logging messages' severity is lower than urgent severity level will be treated as urgent message and the logging message will be sent immediately in a single email message if the email logging is enabled.

non-urgent - Specify the severity level for the non-urgent messsages. The log messages at or above this severity level, but below the urgent servrity level, are emailed in a non-urgent manner.

none - Do not send logging messages if urgent or non-urgent severity level is set to none.

no parameter - Indicates that to enable the logging email feature.

no - This command restore the setting to default value.

Default Setting

Email logging is disabled

Urgent severity level is alert

Non-urgent severity level is warning

Command Mode

This command is used to configure how frequently non-urgent email messages are sent. Non-urgent messages are collected and sent in a batch email at the specified interval. The valid range is every 3- to 1440 minutes.

Syntax

logging email logtime <interval> no logging email logtime

<interval> - Specify how frequently non-urgent email messages are sent. The valid interval is 30 to 1440 minutes.

no - This command resets the non-urgent log time to the default value.

Default Setting

30 minutes

Command Mode

Global Config

This command is used to configure the email address to which messages are sent. The message types supported are urgent, non-urgent, and both. For each supported severity level, multiple email addresses can be configured.

Syntax

logging email message-type {both | urgent | non-urgent} to-addr <to-addr> no logging email message-type {both | urgent | non-urgent} to-addr <to-addr>

<to-addr> - Specify a standard email address, for example admin@yourcompany.com.

no - This command removes the configured to-addr field of email.

Default Setting

None

Command Mode

This command is used to configure the email source address (the address of the sender, i.e., switch) to which messages are sent.

Syntax

logging email from-addr <from-address> no logging email from-addr

<from-address> - Specify a standard email address for the source address of the email, for
example admin@yourcompany.com.

no - This command removes the configured email source address.

Default Setting

None

Command Mode

Global Config

This command is used to configure the subject line of the email for the specified type.

Syntax

logging email message-type {both | urgent | non-urgent} subject <subject> no logging email message-type {both | urgent | non-urgent} subject <subject>

<subject> - Specify the subject line of the email. The length of the subject is 1 to 255 characters.

no - This command removes the configured email subject for the specified message type and restores it to the default email subject.

Default Setting

For urgent, the default subject is "Urgent Log Messages"

For non-urgent, the default subject is "Non Urgent Log Messages"

Command Mode



This command is used to reset the email alerting statistics.

Syntax

clear logging email statistics

Default Setting

None

Command Mode

Privileged EXEC

5.6.2.2 Mail Server configuration

To configure the parameters for SMTP server to which the switch sends email alert messages and changes the mode to Mail Server Configuration mode.

Syntax	
	rer { <ipaddress> <ipv6address> <hostname> }</hostname></ipv6address></ipaddress>
no mail-s	erver

no - This command removes the specified SMTP server from the configuration.

Default Setting

None

Command Mode

Global Config

To configure the email alerting security protocol by enabling the switch to use TLSv1/STARTTLS authentication with the SMTP Server. If the TLSv1/STARTTLS mode is enabled on the switch but the SMTP server does not support TLSv1/STARTTLS mode, no email is sent to the SMTP server.

Syntax

security { none | tlsv1 | starttls }

none - no security protocol is used.

tlsv1 - To use tlsv1 as security protocol to authenticate with the SMTP server

starttls - To use starttls as security protocol to authenticate with the SMTP server.

no - This command resets the security protocol back to default value.

Default Setting

none

Command Mode

Mail-Server Config

To configure the TCP port to use for communication with the SMTP server. The recommended port for TLSv1 is 465, STARTTLS is 587 and for no security (i.e. none) it is 25. However, any nonstandard port in the range 1 to 65535 is also allowed.

Syntax			
port <1-6	65535>		

<1-65535> - Specify the TCP port number to be used to send the email log messages. Generally, security protocol TLSv1 uses 465, STARTTLS uses 587 and no security uses 25.

no - This command resets the TCP port to the default value of the current configured security protocol.

Default Setting

25

Command Mode

Mail-Server Config

This command is used to configure the loging ID the switch uses to authenticate with the SMTP server.

Syntax			
username	e <username></username>		

<username> - Mail server username configuration. The length of username could be 1 to 32 characters.

no - This command resets the username to the default value. The default username is admin.

Default Setting

admin

Command Mode

Mail-Server Config

This command is used to configure the password the switch uses to authenticate with the SMTP server.

C.,	nta	v
Зy	πα	^

password {0 | 7} <password>

- <0> Passowrd should be 1 to 32 characters in plain text format.
- <1> Passowrd must be 64 characters in encrypted form.
- **no** This command resets the password to the default value. The default password is admin.

Default Setting

admin

Command Mode

Mail-Server Config

5.7 Script Management Commands

5.7.1 script apply

This command applies the commands in the configuration script to the switch. The apply command backs up the running configuration and then starts applying the commands in the script file. Application of the commands stops at the first failure of a command.

Syntax

script apply <scriptname>

<scriptname> - The name of the script to be applied.

Default Setting

None

Command Mode

Privileged Exec

5.7.2 script delete

This command deletes a specified script or all the scripts presented in the switch.

Syntax

script delete {<scriptname> | all}

<scriptname> - The name of the script to be deleted.

all - Delete all scripts presented in the switch.

Default Setting

None

Command Mode

5.7.2.1 script list

This command lists all scripts present on the switch as well as the total number of files present.

Syntax			
script list			

Default Setting

None

Command Mode

Privileged Exec

Display Message

Configuration Script Name: The filename of the script file.

Size(Bytes): The size of the script file.

5.7.3 script show

This command displays the content of a script file.

Syntax

script show <scriptname>

<scriptname> - Name of the script file.

Default Setting

None

Command Mode



5.7.4 script validate

This command displays the content of a script file.

C.	(nta)	,
3	/nta>	•

script validate <scriptname>

<scriptname> - Name of the script file.

Default Setting

None

Command Mode



5.8 User Account Management Commands

5.8.1 Show Commands

5.8.1.1 show users

This command displays the configured user names and their settings. This command is only available for users with readwrite privileges. The SNMPv3 fields will only be displayed if SNMP is available on the system.

Syntax			
show use	ers		

Default Setting

None

Command Mode

Privileged Exec

Display Message

User Name: The name the user will use to login using the serial port, Telnet. A new user may be added to the switch by entering a name in a blank entry. The user name may

be up to eight characters, and is not case sensitive. Two users are included as the factory

default, admin, and guest.

User Access Mode: Shows whether the operator is able to change parameters on the switch (Read/Write) or is only able to view them (Read Only). As a factory default, admin has Read/Write access and guest has Read Only access. There can only be one Read/Write user and up to five Read Only users.

SNMPv3 AccessMode: This field displays the SNMPv3 Access Mode. If the value is set to **Read-Write**, the SNMPv3 user will be able to set and retrieve parameters on the system. If the value is set to **ReadOnly**, the SNMPv3 user will only be able to retrieve parameter information. The SNMPv3 access mode may be different from the CLI.

SNMPv3 Authentication: This field displays the authentication protocol to be used for the specified login user.

SNMPv3 Encryption: This field displays the encryption protocol to be used for the specified login user.

324

5.8.1.2 show users account information

The user can go to the CLI Privilege Exec to get all of user information, use the **show users accounts** Privilege command.

Syntax

show users accounts

Default Setting

None

Command Mode

Privileged Exec

Display Message

User Name: The local user account's user name.

Privilege: The user's privilege level. The range of privilege level is 1 to 15. Access mode for privilege level 15 is read/write, the others is read-only.

Password Aging: Indicates number of days, since the password was configured, until the password expires.

Password Expiration Date: The current password expiration date in date format.

Lockout: Indicates whether the user account is locked out (true or false).

5.8.1.3 show passwords configuration

Use this command to display the configured password management settings.

Syntax

show passwords configuration

Default Setting

None

Command Mode

Privileged Exec

Display Message

Minimum Password Length: Minimum number of characters required when changing passwords.

Password History: Number of passwords to store for reuse prevention.

Password Aging: Length in days that a password is valid.

325

GUANTA COMPUTER INC.

Lockout Attempts: Number of failed password login attempts before lockout.

Password Strength Check: The user to configure passwords that comply with the strong password configuration.

Minimum Password Uppercase Letters: Minimum number of uppercase characters required when changing passwords.

Minimum Password Lowercase Letters: Minimum number of lowercase characters required when changing passwords.

Minimum Password Numeric Characters: Minimum number of numeric characters required when changing passwords.

Minimum Password Special Characters: Minimum number of special characters required when changing passwords.

Maximum Password Repeated Characters: Maximum number of characters cannot repeated when changing passwords.

Maximum Password Consecutive Characters: Maximum number of characters cannot consecutive when changing passwords.

Minimum Password Character Classes: Valid range for user passwords.

Password Exclude Keywords: The password to be configured should not contain the keyword mentioned in this field.

5.8.1.4 Show password result

Use this command to display the last password set result information.

Syntax

show passwords result

Default Setting

None

Command Mode

Privileged Exec

Display Message

Last User Whose Password Is Set: Shows the name of the user with the most recently set password.

Password Strength Check: Shows whether password strength checking is enabled.

Last Password Set Result: Shows whether the attempt to set a password was successful. If the attempt failed, the reason for the failure is include.

326

5.8.2 Configuration Commands

5.8.2.1 username

This command adds a new user (account) if space permits. The default privilege level is 1. The account <username> can be up to eight characters in length. The name may be comprised of alphanumeric characters as well as the dash ('-') and underscore ('_'). The <username> is not case-sensitive. Six user names can be defined.

This command changes the password of an existing operator. User password should not be more than eight characters in length. If a user is authorized for authentication or encryption is enabled, the password must be eight alphanumeric characters in length. The username and password are not case-sensitive. When a password is changed, a prompt will ask for the operator's former password. If none, press enter.

Syntax

username <username> {passwd <0|7> <password> | nopasswd | level <level>} no username <username>

<username> - is a new user name (Range: up to 8 characters).

<0|7> - 0 means the password is plain-text. 7 means the password is encrypted. When 7 is used, the password must be exactly 128 hexadeciaml characters in length. Maximum plain-text password length is 64 characters.

no - This command removes a user name created before.

nopassword - This command sets the password of an existing operator to blank. When a password is changed, a prompt will ask for the operator's former password. If none, press enter.

- The user level. Level 0 can be assigned by a level 15 user to another user to suspend that user's access. Range 0-15. Enter access level 1 for Read Access or 15 for Read/Write Access. If not specified where it is optional, the privilege level is 1.

i

The admin user account cannot be deleted.

Default Setting

No password

Command Mode

5.8.2.2 Unlock a locked user account

The user can go to the CLI Global Configuration Mode to unlock a locked user account, use the **username <name> unlock** global configuration command.

Syntax	
Oyman	

username <username> unlock

<name> - is a user name (Range: up to 8 characters).

Default Setting

None

Command Mode

Global Config

5.8.2.3 username snmpv3 authentication

This command specifies the authentication protocol to be used for the specified login user. The valid authentication protocols are **none**, **md5** or **sha**. If **md5** or **sha** are specified, the user login password will be used as the snmpv3 authentication password. The <username> is the login user name for which the specified authentication protocol will be used.

Syntax

username snmpv3 authentication <username> {none | md5 | sha} no username snmpv3 authentication <username>

<username> - is the login user name.

md5 - md5 authentication method.

sha - sha authentication method.

none - no use authentication method.

no - This command sets the authentication protocol to be used for the specified login user to **none**. The <username> is the login user name for which the specified authentication protocol will be used.

Default Setting

No authentication

Command Mode

5.8.2.4 username snmpv3 encryption

This command specifies the encryption protocol and key to be used for the specified login user. The valid encryption protocols are **none** or **des**. The **des** protocol requires a **key**, which can be specified on the command line. The **key** may be up to 16 characters. If the **des** protocol is specified but a key is not provided, the user will be prompted to enter the key. If **none** is specified, a key must not be provided. The <u style="text-align: center;">user name for which the specified encryption protocol will be used.

Syntax

username snmpv3 encryption <username> {none | des [<key>]} no username snmpv3 encryption <username>

<username> - is the login user name.

des - des encryption protocol.

none - no encryption protocol.

<key> - A key 128 alphanumeric characters in length.

no - This command sets the encryption protocol to **none**. The <username> is the login user name for which the specified encryption protocol will be used.

Default Setting

No encryption

Command Mode

5.8.2.5 Set the password aging

If the passwords aging is set, the local user will be prompted to change it before logging in again when the local user's password expires.

The user can go to the CLI Global Configuration Mode to set the password aging, use the **passwords** aging <1-365> Global configuration command. Use the **no passwords aging** return to default value 0.

Syntax		
-	rds aging <1-365> words aging	

<1-365> - Number of days until password expires.

Default Setting

0, no aging

Command Mode

Global Config

5.8.2.6 Set the password history

Use this command to set the number of previous passwords that shall be stored for each user account. If password history is set, the local user will not be able to reuse any password stored in password history when the local user changes his or her password.

The user can go to the CLI Global Configuration Mode to set the password history, use the **passwords** history <0-10> Global configuration command. Use the **no passwords** history return to default value 0.

Syntax

passwords history <0-10> no passwords history

<0-10> - Number of passwords to be used in password history check.

Default Setting

0

Command Mode

5.8.2.7 Set the password lock-out count

Use this command to strengthen the security of the switch by locking user accounts that have failed login due to wrong passwords. When a lockout count is configured, a user that is logged in must enter the correct password within that count. Otherwise the user will be locked out from further switch access. Only a user with read/write access can re-activate a locked user account. The user can go to the CLI Global Configuration Mode to set the password lock-out count, use the **passwords lock-out <1-5>** Global configuration command. Use the **no passwords lock-out** to return to default value 0.

Syntax		
password	ds lock-out <1-5>	
no passw	words lock-out	

<1-5> - the number of password failures before account lock.

Default Setting

0

Command Mode

Global Config

5.8.2.8 Set the minimum password length

The user can go to the CLI Global Configuration Mode to set the minimum password length, use the **passwords min-length <8-64>** Global configuration command. Use the **no passwords min-length** return to default value 8.

Syntax

passwords min-length <8-64> no passwords min-length

Default Setting

8

Command Mode

5.8.2.9 Set the password strength policy enforcement.

The user can go to the CLI Global Configuration Mode to set the password strength policy enforcement, use the **passwords strength-check** Global configuration command. Use the **no passwords strength-check** return to default disable.

Syntax

passwords strength-check no passwords strength-check

Default Setting

Disable

Command Mode

Global Config

5.8.2.10 Set the password strength maximum.

The user can go to the CLI Global Configuration Mode to set the password strength, use the **passwords strength maximum {consecutive-characters | repeated} [<0-15>]** Global configuration command. Use the **no passwords strength maximum {consecutive-characters | repeated}** return to default value 0.

Syntax

passwords strength maximum {consecutive-characters | repeated} [<0-15>] no passwords strength maximum {consecutive-characters | repeated}

Default Setting

0

Command Mode

5.8.2.11 Set the password strength minimum.

The user can go to the CLI Global Configuration Mode to set the password strength, use the **passwords** strength minimum {character-classes | lowercase-letters | numeric-characters | special-characters | uppercase-letters} [<0-15>] Global configuration command. Use the no passwords strength minimum {character-classes | lowercase-letters | numeric-characters | special-characters | uppercase-letters} return to default value 2.

Syntax	
Syntax	

passwords strength minimum {character-classes | lowercase-letters | numeric-characters | special-characters | uppercase-letters} [<0-15>] no passwords strength minimum {character-classes | lowercase-letters | numeric-characters | special-characters | uppercase-letters}

Default Setting

2

Command Mode

Global Config

5.8.2.12 Set the password strength exclude-keyword.

The user can go to the CLI Global Configuration Mode to set the password strength, use the **passwords** strength exclude-keyword <keyword> Global configuration command. Use the **no passwords** strength exclude-keyword <keyword> return to default none.

Syntax

passwords strength exclude-keyword <keyword> no passwords strength exclude-keyword <keyword>

Default Setting

None

Command Mode

5.9 Security Commands

5.9.1 Show Commands

5.9.1.1 show users authentication

This command displays all users and all authentication login information. It also displays the authentication login list assigned to the default user.

Syntax

show users authentication

Default Setting

None

Command Mode

Privileged Exec

Display Message

User: This field lists every user that has an authentication login list assigned.

System Login: This field displays the authentication login list assigned to the user for system login.

802.1x: This field displays the authentication login list assigned to the user for 802.1x port security.

5.9.1.2 show authentication methods

This command displays the ordered authentication methods for all authentication login lists.

Syntax

show authentication methods

Default Setting

None

Command Mode

Privileged Exec

Display Message

Login Authentication Method Lists: This displays the authentication login listname. Enable Authentication Method Lists: This displays the authentication enable listname.

5.9.1.3 show authentication users

This command displays information about the users assigned to the specified authentication login list. If the login is assigned to non-configured users, the user "default" will appear in the user column.

Syntax

show authentication users <listname>

listname> - the authentication login listname.

Default Setting

None

Command Mode

Privileged Exec

Display Message

User Name: This field displays the user assigned to the specified authentication login list.

Component: This field displays the component (User or 802.1x) for which the authentication login list is assigned.

0

5.9.1.4 show accounting

Use this command to display ordered methods for accounting lists.

Syntax				
show acc	counting			
Default Se	etting			

None

Command Mode

Privileged Exec

Display Message

Number of Accounting Notifications sent at beginning of an EXEC session:	0	
Errors when sending Accounting Notifications beginning of an EXEC session:	0	
Number of Accounting Notifications at end of an EXEC session:	0	
Errors when sending Accounting Notifications at end of an EXEC session:	0	
Number of Accounting Notifications sent at beginning of a command execution:	0	
Errors when sending Accounting Notifications at beginning of a command execut	tion:	(
Number of Accounting Notifications sent at end of a command execution:	0	
Errors when sending Accounting Notifications at end of a command execution:	0	

5.9.1.5 show accounting methods

Use this command to display configured accounting method lists.

Syntax

show accounting methods

Default Setting

None

Command Mode

Privileged Exec

5.9.1.6 show dot1x

This command is used to show the status of the dot1x Administrative mode.

Syntax		
show dot	t1x	

Default Setting

None

Command Mode

Privileged Exec

Display Message

Administrative mode: Indicates whether authentication control on the switch is enabled or disabled.

VLAN Assignment Mode: Indicates whether assignment of an authorized port to a RADIUS assigned VLAN is allowed (enabled) or not (disabled).

Dynamic VLAN Creation Mode: Indicates whether the switch can dynamically create a RADIUS-assigned VLAN if it does not currently exist on the switch.

Monitor Mode: Indicates whether the Dot1x Monitor mode on the switch is enabled or disabled.

5.9.1.7 show dot1x authentication-history

This command is used to display the Dot1x Authentication History Log for the specified port or all ports.

Syntax

show dot1x authentication-history <all | <slot/port>>

Default Setting

None

Command Mode

Privileged Exec

Display Message

Time Stamp: The exact time at which the event occurs.

Interface: Physical Port on which the event occurs.

MAC-Address: The supplicant/client MAC address.

VLANID: The VLAN assigned to the client/port on authentication.

Auth Status: The authentication status.

5.9.1.8 show dot1x client

This command is used to display client information.

Syntax

show dot1x clients [<slot/port>]

<**slot/port> -** is the desired interface number.

no parameter - All interfaces.

Default Setting

None

Command Mode

Privileged Exec

Display Message

Clients Authenticated using Monitor Mode: Indicates the number of the Dot1x clients authenticated using Monitor mode.

Clients Authenticated using Dot1x: Indicates the number of Dot1x clients authenticated using 802.1x authentication process.

Logical Interface: The logical port number associated with a client.

Interface: The physical port to which the supplicant is associated.

User Name: The user name used by the client to authenticate to the server.

Supp MAC Address: The supplicant device MAC address.

Session Time: The time since the supplicant is logged on.

VLAN Id: The VLAN assigned to the port.

VLAN Assigned: The reason the VLAN identified in the VLAN ID field has been assigned to the port. Possible values are RADIUS, Unauthenticated VLAN, Monitor Mode, or Default. When the VLAN Assigned reason is Default, it means that the VLAN was assigned to the port because the P-VID of the port was that VLAN ID.

Session Timeout: This value indicates the time for which the given session is valid. The time period in seconds is returned by the RADIUS server on authentication of the port. This value is valid for the port only when the port-control mode is not MAC-based.

Session Termination Action: This value indicates the action to be taken once the session timeout expires. Possible values are Default and Radius-Request. If the value is Default, the session is terminated and client details are cleared. If the value is Radius-Request, then a reauthentication of the client is performed.

5.9.1.9 show dot1x detail

This command is used to show a summary of the global dot1x configuration and the detailed dot1x configuration for a specified port.



show dot1x detail <slot/port>

<slot/port> - is the desired interface number.

Default Setting

None

Command Mode

Privileged Exec

Display Message

Port: The interface whose configuration is displayed

Protocol Version: The protocol version associated with this port. The only possible value is 1, corresponding to the first version of the dot1x specification.

PAE Capabilities: The port access entity (PAE) functionality of this port. Possible values are Authenticator or Supplicant.

Control Mode - The configured control mode for this port. Possible values are force-unauthorized, force-authorized, auto and mac-based.

Authenticator PAE State: Current state of the authenticator PAE state machine. Possible values are Initialize, Disconnected, Connecting, Authenticating, Authenticated, Aborting, Held, ForceAuthorized, and ForceUnauthorized.

Backend Authentication State: Current state of the backend authentication state machine. Possible values are Request, Response, Success, Fail, Timeout, Idle, and Initialize.

Quiet Period: The timer used by the authenticator state machine on this port to define periods of time in which it will not attempt to acquire a supplicant. The value is expressed in seconds and will be in the range of 0 to 65535.

Transmit Period: The timer used by the authenticator state machine on the specified port to determine when to send an EAPOL EAP Request/Identity frame to the supplicant. The value is expressed in seconds and will be in the range of 1 to 65535.

Guest VLAN ID: The guest VLAN identifier configured on the interface.

Guest VLAN Period: The timer used by authenticator state machine on this port.

Supplicant Timeout: The timer used by the authenticator state machine on this port to timeout the supplicant. The value is expressed in seconds and will be in the range of 1 to 65535.

Server Timeout: The timer used by the authenticator on this port to timeout the authentication server. The value is expressed in seconds and will be in the range of 1 to 65535.

Maximum Requests: The maximum number of times the authenticator state machine on this port will retransmit an EAPOL EAP Request/Identity before timing out the supplicant. The value will be in the range of 1 to 10.

UANTA COMPUTER INC.

Vian ID: The VLAN assigned to the port by the radius server.

VLAN Assigned Reason: The reason the VLAN identified in the VLAN-assigned field has been assigned to the port. Possible values are RADIUS, Unauthenticated VLAN, Guest VLAN, default, and Not Assigned. When the VLAN Assigned Reason is 'Not Assigned't, it means that the port has not been assigned to any VLAN by dot1x.

Reauthentication Period: The timer used by the authenticator state machine on this port to determine when reauthentication of the supplicant takes place. The value is expressed in seconds and will be in the range of 1 to 65535.

Reauthentication Enabled: Indicates if reauthentication is enabled on this port. Possible values are True or False.

Key Transmission Enabled: Indicates if the key is transmitted to the supplicant for the specified port. Possible values are True or False.

Control Direction: Indicates the control direction for the specified port or ports. Possible values are both or in.

Maximum Users - The maximum number of clients that can get authenticated on the port in the MAC-based dot1x authentication mode.

Unauthenticated VLAN ID - Indicates the unauthenticated VLAN configured for this port.

Session Timeout - Indicates the time for which the given session is valid. The time period in seconds is returned by the RADIUS server on authentication of the port.

Session Termination Action - This value indicates the action to be taken once the session timeout expires. Possible values are Default, Radius-Request. If the value is Default, the session is terminated the port goes into unauthorized state. If the value is Radius-Request, then a reauthentication of the client authenticated on the port is performed.

5.9.1.10 show dot1x statistics

This command is used to show a summary of the global dot1x configuration and the dot1x statistics for a specified port.

Syntax

show dot1x statistics <slot/port>

<slot/port> - is the desired interface number.

Default Setting

None

Command Mode

Privileged Exec

Display Message

Port: The interface whose statistics are displayed.

PAE Capabilities: The port access entity (PAE) functionality of this port. Possible values are Authenticator or Supplicant.

EAPOL Frames Received: The number of valid EAPOL frames of any type that have been received by this authenticator.

EAPOL Frames Transmitted: The number of EAPOL frames of any type that have been transmitted by this authenticator.

EAPOL Start Frames Received: The number of EAPOL start frames that have been received by this authenticator.

EAPOL Logoff Frames Received: The number of EAPOL logoff frames that have been received by this authenticator.

Last EAPOL Frame Version: The protocol version number carried in the most recently received EAPOL frame.

Last EAPOL Frame Source: The source MAC address carried in the most recently received EAPOL frame.

EAP Response/Id Frames Received: The number of EAP response/identity frames that have been received by this authenticator.

EAP Response Frames Received: The number of valid EAP response frames (other than resp/id frames) that have been received by this authenticator.

EAP Request/Id Frames Transmitted: The number of EAP request/identity frames that have been transmitted by this authenticator.

EAP Request Frames Transmitted: The number of EAP request frames (other than request/identity frames) that have been transmitted by this authenticator.

Invalid EAPOL Frames Received: The number of EAPOL frames that have been received by this authenticator in which the frame type is not recognized.

342

EAP Length Error Frames Received: The number of EAPOL frames that have been received by this authenticator in which the frame type is not recognized.

5.9.1.11 show dot1x summary

This command is used to show a summary of the global dot1x configuration and summary information of the dot1x configuration for a specified port or all ports.

Syntax

show dot1x summary [<slot/port>]

<**slot/port> -** is the desired interface number.

no parameter - All interfaces.

Default Setting

None

Command Mode

Privileged Exec

Display Message

Interface: The interface whose configuration is displayed.

Control Mode: The configured control mode for this port. Possible values are force-unauthorized / force-authorized / auto / mac-based.

Operating Control Mode: The control mode under which this port is operating. Possible values are authorized / unauthorized.

Reauthentication Enabled: Indicates whether re-authentication is enabled on this port.

Port Status: Indicates if the key is transmitted to the supplicant for the specified port.

5.9.1.12 show dot1x users

This command displays 802.1x port security user information for locally configured users.

Γ	
l	Syntax

show dot1x users <slot/port>

<**slot/port> -** is the desired interface number.

Default Setting

None

Command Mode

Privileged Exec

Display Message

User: Users configured locally to have access to the specified port.

5.9.1.13 show radius

This command is used to display the various RADIUS configuration items for the switch.

Syntax			
show rad	lius		

Default Setting

None

Command Mode

Privileged Exec

Display Message

Number of Configured Authentication Servers: The number of RADIUS Authentication servers that have been configured.

Number of Configured Accounting Servers: The number of RADIUS Accounting servers that have been configured.

Number of Named Authentication Server Groups: The number of configured named RADIUS Authentication server groups.

Number of Named Accounting Server Groups: The number of configured named RADIUS Accounting server groups.

Number of Retransmits: The configured value of the maximum number of times a request packet is retransmitted.

Timeout Duration: The configured timeout value, in seconds, for request re-transmissions.

Dead Time: The configured timeout value, in mins, for the time duration after a RADIUS sever is found non-responsive or dead.

RADIUS Accounting Mode: A global parameter to indicate whether the accounting mode for all the servers is enabled or not.

RADIUS Attribute 4 Mode: A global parameter to indicate whether the NAS-IP-Address attribute has been enabled to use in RADIUS requests.

RADIUS Attribute 4 Value: A global parameter that specifies the IP address to be used in the NAS-IP-Address attribute to be used in RADIUS requests.

RADIUS Attribute 95 Mode: A global parameter to indicate whether the NAS-IPv6-Address attribute has been enabled to use in RADIUS requests.

RADIUS Attribute 95 Value: A global parameter that specifies the IPv6 address to be used in the NAS-IP-Address attribute to be used in RADIUS requests.

5.9.1.14 show radius accounting

This command is used to display the configured RADIUS accounting mode, accounting server, and the statistics for the configured accounting server.

Syntax	
SVIITAX	

show radius accounting [{<ipaddr | ipv6addr | hostname> | name <servername> | statistics {<ipaddr| ipv6addr | hostname> | name <servername>}}]

<ipaddr | ipv6addr | hostname> - is an IPv4/v6 Address or hostname.

Default Setting

None

Command Mode

Privileged Exec

Display Message

If you do not specify any parameters, then only the accounting mode and the RADIUS accounting server details are displayed.

RADIUS Accounting Mode: Enabled or disabled

Host Address: The configured IP address of the RADIUS accounting server

Port: The port in use by the RADIUS accounting server

Secret Configured: Yes or No

If the optional token ' ipaddr| ipv6addr| hostname ' or name <servername> is included.

RADIUS Accounting Server IP Address: IP Address of the configured RADIUS accounting server.

RADIUS Accounting Server Name: The name of the configured RADIUS accounting server.

RADIUS Accounting Mode: Enabled or disabled

Port: The port in use by the RADIUS accounting server.

Secret Configured: Yes or No Boolean value indicating whether this server is configured with a secret.

If the optional token 'statistics <ipaddr| ipv6addr | hostname>' is included, the statistics for the configured RADIUS accounting server are displayed. The IP address parameter must match that of a previously configured RADIUS accounting server. The following information regarding the statistics of the RADIUS accounting server is displayed.

RADIUS Accounting Server Host Address: IP Address of the configured RADIUS accounting server

GUANTA COMPUTER INC.

Round Trip Time: The time interval in centiseconds, between the most recent Accounting-Response and the Accounting-Request that matched it from the RADIUS accounting server.

Requests: The number of RADIUS Accounting-Request packets sent to this accounting server. This number does not include retransmissions.

Retransmission: The number of RADIUS Accounting-Request packets retransmitted to this RADIUS accounting server.

Responses: The number of RADIUS packets received on the accounting port from this server.

Malformed Responses: The number of malformed RADIUS Accounting-Response packets received from this server. Malformed packets include packets with an invalid length. Bad authenticators and unknown types are not included as malformed accounting responses.

Bad Authenticators: The number of RADIUS Accounting-Response packets containing invalid authenticators received from this accounting server.

Pending Requests: The number of RADIUS Accounting-Request packets sent to this server that have not yet timed out or received a response.

Timeouts: The number of accounting timeouts to this server.

Unknown Types: The number of RADIUS packets of unknown types, which were received from this server on the accounting port.

Packets Dropped: The number of RADIUS packets received from this server on the accounting port and dropped for some other reason.

5.9.1.15 show radius servers

This command is used to display items of the configured RADIUS servers.

Syntax

show radius servers [{<ipaddr | ipv6addr | hostname> | name <servername>}]

Default Setting

None

Command Mode

Privileged Exec

Display Message

RADIUS Server Name: The Name of the authenticating server.

RADIUS Server IP Address: The IP address or host name of the authenticating server.

Current Server IP Address: The '*' symbol preceeding the server host address specifies that the server is currently active.

Number of Retransmits: The configured value of the maximum number of times a request packet is retransmitted.

Timeout Duration: The configured timeout value, in seconds, for request re-transmissions.

Dead Time: The configured timeout value, in mins, for the time duration after a RADIUS sever is found non-responsive or dead.**RADIUS Accounting Mode:** A global parameter to indicate whether the accounting mode for all the servers is enabled or not.

RADIUS Attribute 4 Mode: A global parameter to indicate whether the NAS-IP-Address attribute has been enabled to use in RADIUS requests.

RADIUS Attribute 4 Value: A global parameter that specifies the IP address to be used in the NAS-IP-Address attribute to be used in RADIUS requests.

RADIUS Attribute 95 Mode: A global parameter to indicate whether the NAS-IPv6-Address attribute has been enabled to use in RADIUS requests.

RADIUS Attribute 95 Value: A global parameter that specifies the IPv6 address to be used in the NAS-IP-Address attribute to be used in RADIUS requests.

Port: The port in use by this server

Type: Primary or secondary

Secret Configured: Yes / No

Message Authenticator: The message authenticator attribute configured for the radius server.

5.9.1.16 show radius statistics

This command is used to display the statistics for RADIUS or configured server. To show the configured RADIUS server statistic, the IP Address specified must match that of a previously configured RADIUS server. On execution, the following fields are displayed.

Syntax

show radius statistics {<ipaddr|ipv6addr|hostname> | name <servername> }

<ipaddr|ipv6addr|hostname> - is an IPv4/v6 Address or a hostname.

Default Setting

None

Command Mode

Privileged Exec

Display Message

If you do not specify the IP address, then only Invalid Server Address field is displayed. Otherwise other listed fields are displayed.

RADIUS Server Name: The Name of the authenticating server.

Server Host Address - IP address or hostname of the Server.

Round Trip Time - The time interval, in hundredths of a second, between the most recent Access-Reply, Access - Challenge and the Access-Request that matched it from the RADIUS authentication server.

Access Requests - The number of RADIUS Access-Request packets sent to this server. This number does not include retransmissions.

Access Retransmission - The number of RADIUS Access-Request packets retransmitted to this RADIUS authentication server.

Access Accepts - The number of RADIUS Access-Accept packets, including both valid and invalid packets, which were received from this server.

Access Rejects - The number of RADIUS Access-Reject packets, including both valid and invalid packets, which were received from this server.

Access Challenges - The number of RADIUS Access-Challenge packets, including both valid and invalid packets, which were received from this server.

Malformed Access Responses - The number of malformed RADIUS Access-Response packets received from this server. Malformed packets include packets with an invalid length. Bad authenticators or signature attributes or unknown types are not included as malformed access responses.

Bad Authenticators - The number of RADIUS Access-Response packets containing invalid authenticators or signature attributes received from this server.

Pending Requests - The number of RADIUS Access-Request packets destined for this server that have not yet timed out or received a response.

Timeouts - The number of authentication timeouts to this server.

Unknown Types - The number of RADIUS packets of unknown types, which were received from this server on the authentication port.

Packets Dropped - The number of RADIUS packets received from this server on the authentication port and dropped for some other reason.

5.9.1.17 show radius source-interface

This command is used to display the configured global source interface details used for a RADIUS client. The IP address of the selected interface is used as source IP for all communications with the server.

Syntax

show radius source-interface

Default Setting

None

Command Mode

Privileged Exec

Display Message

RADIUS Client Source Interface: The interface to use as the source interface for RADIUS client.

RADIUS Client Source IPv4 Address: The IP address of the interface configured as the RADIUS client source interface.

5.9.1.18 show tacacs

This command display configured information and statistics of a TACACS+ server.

Syntax

show tacacs [<ipaddr|ipv6Addr|hostname>]

<ipaddr|ipv6Addr|hostname> - is an IPv4/v6 Address or a hostname.

Default Setting

None

Command Mode

Privileged Exec

Display Message

Host address - The IP address or hostname of the configured TACACS+ server.

Port: Shows the configured TACACS+ server port number.

Timeout: Shows the timeout in seconds for establishing a TCP connection.

Priority: Shows the preference order in which TACACS+ servers are contacted. If a server connection fails, the next highest priority server is contacted.

5.9.1.19 show tacacs source-interface

This command is used to display the configured global source interface details used for a RADIUS client. The IP address of the selected interface is used as source IP for all communications with the server.

Syntax

show tacacs source-interface

Default Setting

None

Command Mode

Privileged Exec

Display Message

TACACS Client Source Interface: The interface to use as the source interface for TACACS client.

TACACS Client Source IPv4 Address: The IP address of the interface configured as the TACACS client source interface.

5.9.1.20 show port-security

This command shows the port-security settings for the entire system.

S	/n	tax

show port-security

Default Setting

None

Command Mode

Privileged Exec

Display Message

Port Security Administration Mode: Port lock mode for the entire system.

5.9.1.21 show port-security interface

This command shows the port-security settings for a particular interface or all interfaces.

show port-security { <slot/port> | all | port-channel < portchannel-id >}

<**slot/port> -** is the interface number.

cportchannel-id> - is the desired port-channel ID. The port-channel ID is range from 1 to 64.

Default Setting

None

Command Mode

Privileged Exec

Display Message

Intf Interface Number.

Admin Mode Port Locking mode for the Interface.

Dynamic Limit Maximum dynamically allocated MAC Addresses.

Static Limit Maximum statically allocated MAC Addresses.

Violation Trap Mode Whether violation traps are enabled.

Sticky Mode Whether sticky mode is enabled.

Violation Shutdown Whether violation shutdowns are enabled.

5.9.1.22 show port-security dynamic

This command shows the dynamically locked MAC addresses for port.

Syntax
• • • • • • • •

show port-security dynamic <slot/port>

<slot/port> - is the interface number.

Default Setting

None

Command Mode

Privileged Exec

Display Message

MAC address Dynamically locked MAC address.

5.9.1.23 show port-security static

This command shows the statically locked MAC addresses for port.

C	vr	^	2	~	
0	VI	11	a	Ā.	

show port-security static <slot/port>

<slot/port> - is the interface number.

Default Setting

None

Command Mode

Privileged Exec

Display Message

Number of static MAC addresses configured: Number of static MAC addresses configured.

Statically configured MAC Address: Statically locked MAC address.

VLAN ID: Vlan ID of the Statically configured MAC Address.

Sticky: Sticky mode of the Statically configured MAC Address.

5.9.1.24 show port-security violation

This command displays the source MAC address of the last packet that was discarded on a locked port.

Syntax
O j max

show port-security violation { <slot/port> | port-channel <portchannel-id>}

<**slot/port> -** is the interface number.

cportchannel-id> - is the desired port-channel ID. The port-channel ID is range from 1 to 64.

Default Setting

None

Command Mode

Privileged Exec

Display Message

MAC address MAC address of discarded packet on locked ports.

GUANTA COMPUTER INC.

5.9.2 Configuration Commands

5.9.2.1 aaa authentication login <method>

This command creates an authentication login list. The **listname>** is up to 12 alphanumeric characters and is not case sensitive. Up to 5 authentication login lists can be configured on the switch.

If the authentication login list does not exist, a new authentication login list is first created and then the authentication methods are set in the authentication login list. The possible method values are enable, line, local, radius, noneand tacacs.

The value of **local** indicates that the user's locally stored ID and password are used for authentication. The value of **radius** indicates that the user's ID and password will be authenticated using the RADIUS server. The value of **none** indicates that the user is never authenticated. The value of **tacacs** indicates that the user's ID and password will be authenticated using the TACACS.

To authenticate a user, the authentication methods in the user's login will be attempted in order until an authentication attempt succeeds or fails.



The default login list included with the default configuration cannot be changed.

Syntax

aaa authentication login <listname> { enable | line | local | none | radius | tacacs} no aaa authentication login <listname>

no - This command deletes the specified authentication login list. The attempt to delete will fail if any of the following conditions are true:

- 1. The login list name is invalid or does not match an existing authentication login list
- 2. The specified authentication login list is assigned to any user or to the nonconfigured user for any component.
- 3. The login list is the default login list included with the default configuration and was not created using 'config authentication login create'. The default login list cannot be deleted.

Default Setting

None

Command Mode



5.9.2.2 aaa accounting

Use this command in Global config mode to create an accounting method list for either user EXEC sessions or for user-executed commands. This list is identified by **default** or a user-specified **list_name**. Accounting records, when enabled for a line-mode, can be sent at both the beginning and at the end (**start-stop**) or only at the end (**stop-only**). If **none** is specified, then accounting is disabled for the specified list. If **tacacs** is specified as the accounting method, accounting records are notified to a TACACS+ server. If **radius** is the specified accounting method, accounting records are notified to a RADIUS server.

- i
- A maximum of five Accounting Method lists can be created for each exec and commands type.
- The same list-name can be used for both exec and commands accounting type.
- AAA Accounting for commands with RADIUS as the accounting method is not supported.

Syntax

aaa accounting {exec | commands} {default | <list_name>} { start-stop | stop-only | none} method1 [method2...]

no aaa accounting {exec | commands} {default | <list_name>}

exec - Provide accounting for a user EXEC terminal sessions.

commands - Provide accounting for all user executed commands.

default - The default list of methods for accounting services.

start-stop - Send a start accounting notice at the beginning of a process and a stop accounting notice at the end of a process.

stop-only - Sends a stop accounting notice at the end of the requested user process.

none - Disables accounting services on this line.

method - Use either TACACS or RADIUS server for accounting purposes.

no - This command deletes the accounting method list.

Default Setting

None

Command Mode

Global Config

5.9.2.3 accounting

Use this command in Line Configuration mode to apply the accounting method list to a line config (console/telnet/ssh).

Syntax

accounting {exec | commands} {default | <list_name>} no accounting

exec – Causes accounting for an EXEC session.

commands – This causes accounting for each command execution attempt. If a user is enabling accounting for exec mode for the current line-configuration type, the user will be logged out.

default - The default Accounting List.

listname> - Enter a string of not more than 15 characters.

no - This command removes accounting from a Line Configuration mode.

Default Setting

None

Command Mode

Line Configuration Mode

5.9.2.4 username defaultlogin

This command assigns the authentication login list to use for non-configured users when attempting to log in to the system. This setting is overridden by the authentication login list assigned to a specific user if the user is configured locally. If this value is not configured, users will be authenticated using local authentication only.

Syntax

username defaultlogin <listname>

listname> - an authentication login list.

Default Setting

None

Command Mode

5.9.2.5 username login

This command assigns the specified authentication login list to the specified user for system login. The **<username>** must be a configured **<username>** and the **<listname>** must be a configured login list.

If the user is assigned a login list that requires remote authentication, all access to the interface from all CLI, and telnet sessions will be blocked until the authentication is complete.



The login list associated with the 'admin' user cannot be changed to prevent accidental lockout from the switch.

Syntax

username login <user> <listname>

<user> - is the login user name.

listname> - an authentication login list.

Default Setting

None

Command Mode



5.9.3 Dot1x Configuration Commands

5.9.3.1 dynamic-vlan

This command enable dot1x dynamic vlan creation configuration.

Syntax		
dot1x dyr	dot1x dynamic-vlan enable	
no dot1x	dynamic-vlan enable	

Default Setting

None

Command Mode

Global Config

5.9.3.2 dot1x port-control

This command sets the authentication mode to be used on all ports. The control mode may be one of the following.

force-unauthorized: The authenticator PAE unconditionally sets the controlled port to unauthorized.

force-authorized: The authenticator PAE unconditionally sets the controlled port to authorized.

auto: The authenticator PAE sets the controlled port mode to reflect the outcome of the authentication exchanges between the supplicant, authenticator, and the authentication server.

mac-based: The authenticator PAE sets the controlled port mode to reflect the outcome of the authentication exchanges between the supplicant, authenticator, and the authentication server on a per supplicant basis.

Syntax

dot1x port-control all {auto | force-authorized | force-unauthorized | mac-based} no dot1x port-control all

all - All interfaces.

no - This command sets the authentication mode to be used on all ports to 'auto'.

Default Setting

auto

Command Mode

Global Config

This command sets the authentication mode to be used on the specified port. The control mode may be one of the following.

force-unauthorized: The authenticator PAE unconditionally sets the controlled port to unauthorized.

force-authorized: The authenticator PAE unconditionally sets the controlled port to authorized.

auto: The authenticator PAE sets the controlled port mode to reflect the outcome of the authentication exchanges between the supplicant, authenticator, and the authentication server.

mac-based: The authenticator PAE sets the controlled port mode to reflect the outcome of the authentication exchanges between the supplicant, authenticator, and the authentication server on a per supplicant basis.

Syntax

dot1x port-control {auto | force-authorized | force-unauthorized | mac-based} no dot1x port-control

no - This command sets the authentication mode to be used on the specified port to 'auto'.

Default Setting

auto

Command Mode

5.9.3.3 dot1x system-auth-control

This command is used to enable the dot1x authentication support on the switch. By default, the authentication support is disabled. While disabled, the dot1x configuration is retained and can be changed, but is not activated.

-
Syntax
Syntax

dot1x system	m-auth-control [monitor]
no dot1x sys	stem-auth-control [monitor]

no - This command is used to disable the dot1x authentication support on the switch.

Default Setting

Disabled

Command Mode

Global Config

5.9.3.4 dot1x user

This command adds the specified user to the list of users with access to the specified port or all ports. The <username> parameter must be a configured user.

Syntax

dot1x user <user> {<slot/port> | all} no dot1x user <user> {<slot/port> | all}

<user> - Is the login user name.

<slot/port> - Is the desired interface number.

all - All interfaces.

no - This command removes the user from the list of users with access to the specified port or all ports.

Default Setting

None

Command Mode

5.9.3.5 dot1x guest vlan

This command configures the Guest VLAN capability on the interface. The command specifies an active VLAN as an IEEE 802.1x guest VLAN.

Syntax
Syntax
Oyncan

dot1x guest- vlan <vlan-id> no dot1x guest-vlan

no - This command disables the Guest VLAN capability on this interface.

Default Setting

Disabled

Command Mode

Interface Config

5.9.3.6 dot1x max-req

This command sets the maximum number of times the authenticator state machine on this port will transmit an EAPOL EAP Request/Identity frame before timing out the supplicant. The <1-10> value must be in the range 1 - 10.

Syntax		
dot1x ma	ax-req <1-10>	
no dot1x	<max-req< th=""><td></td></max-req<>	

<1-10> - maximum number of times (Range: 1 - 10).

no - This command sets the maximum number of times the authenticator state machine on this port will transmit an EAPOL EAP Request/Identity frame before timing out the supplicant to the default value, that is, 2.

Default Setting

2

Command Mode

5.9.3.7 dot1x max-user

This command configures the maximum users to a specified port, The system's default maximum users of an interface has no limitation. If '**no dot1x max-users**' command is executed, the system will reset the maximum users to infinity. If the maximum users is specified or modified, the system should use the new one.

Syntax		
	dot1x max-user <count></count>	
no dot1x	max-user	

<count> - maximum users (Range: 1 – 48).

no - This command sets the system will reset the maximum users to infinity

Default Setting

48

Command Mode

Interface Config

5.9.3.8 dot1x pae

This command set the PAE capability mode on the specified port.

Syntax

dot1x pae <authenticator| supplicant>

Default Setting

authenticator

Command Mode

5.9.3.9 dot1x re-authentication

This command enables re-authentication of the supplicant for the specified port.

Syntax

dot1x re-authentication no dot1x re-authentication

no - This command disables re-authentication of the supplicant for the specified port.

Default Setting

Disabled

Command Mode

Interface Config

5.9.3.10 dot1x supplicant max-start

This command configure the maximum number of Start EAPOL messages to be sent in the absence of Authenticator.

Syntax

dot1x supplicant max-start <1-10> no dot1x supplicant max-start

Default Setting

3

Command Mode



5.9.3.11 dot1x supplicant port-control

This command set the authentication mode on the specified port.

Syntax

dot1x supplicant port-control < auto| force-authorized|force-unauthorized> no dot1x supplicant port-control

Default Setting

auto

Command Mode

Interface Config

5.9.3.12 dot1x supplicant timeout auth-period

This command configure the auth period value.

Syntax

dot1x supplicant timeout auth-period <seconds>
no dot1x supplicant timeout auth-period

<seconds> - Range: 1-65535.

Default Setting

30

Command Mode

5.9.3.13 dot1x supplicant timeout held-period

This command configure the held period value.

Syntax

dot1x supplicant timeout held-period <seconds> no dot1x supplicant timeout held -period

<seconds> - Range: 1-65535.

Default Setting

60

Command Mode

Interface Config

5.9.3.14 dot1x supplicant timeout start-period

This command configure the start period value.

Syntax

dot1x supplicant timeout start-period <seconds>
no dot1x supplicant timeout start-period

<seconds> - Range: 1-65535.

Default Setting

30

Command Mode

5.9.3.15 dot1x supplicant user

This command configure Supplicant user.

Syntax

dot1x supplicant user <user> no dot1x supplicant user <user>

Default Setting

None

Command Mode

Interface Config

5.9.3.16 dot1x timeout

This command sets the value, in seconds, of the timer used by the authenticator state machine on this port. Depending on the token used and the value (in seconds) passed; various timeout configurable parameters are set. The following tokens are supported.

guest-vlan-period: The time, in seconds, for which the authenticator waits to see if any EAPOL packets are received on a port before authorizing the port and placing the port in the guest vlan (if configured). The guest vlan timer is only relevant when guest vlan has been configured on that specific port.

reauth-period: Sets the value, in seconds, of the timer used by the authenticator state machine on this port to determine when re-authentication of the supplicant takes place. The reauth-period must be a value in the range 1 - 65535.

quiet-period: Sets the value, in seconds, of the timer used by the authenticator state machine on this port to define periods of time in which it will not attempt to acquire a supplicant. The quiet-period must be a value in the range 0 - 65535.

tx-period: Sets the value, in seconds, of the timer used by the authenticator state machine on this port to determine when to send an EAPOL EAP Request/Identity frame to the supplicant. The quiet-period must be a value in the range 1 - 65535.

supp-timeout: Sets the value, in seconds, of the timer used by the authenticator state machine on this port to timeout the supplicant. The supp-timeout must be a value in the range 1 - 65535.

server-timeout: Sets the value, in seconds, of the timer used by the authenticator state machine on this port to timeout the authentication server. The supp-timeout must be a value in the range 1 - 65535.

369

Syntax

dot1x timeout {guest-vlan-period | quiet-period | reauth-period | server-timeout | supp-timeout | tx-period} <seconds> no dot1x timeout { guest-vlan-period | quiet-period | reauth-period | server-timeout | supp-timeout | tx-period}

<seconds> - Value in the range guest-vlan-period: 1-300 reauth-period: 1-65535 quiet-period: 0-65535 tx-period: 1-65535 supp-timeout: 1-65535 server-timeout: 1-65535

no - This command sets the value, in seconds, of the timer used by the authenticator state machine on this port to the default values. Depending on the token used, the corresponding default values are set.

Default Setting

guest-vlan-period: 90 seconds

reauth-period: 3600 seconds

quiet-period: 60 seconds

tx-period: 30 seconds

supp-timeout: 30 seconds

server-timeout: 30 seconds

Command Mode

Interface Config

370

5.9.3.17 dot1x unauthenticated-vlan

This command configure Unauthenticated VLAN for the port.

Syntax

dot1x unauthenticated-vlan <vlan-id> no dot1x unauthenticated-vlan

Default Setting

0

Command Mode

5.9.4 Interface Config

Radius Configuration Commands

5.9.4.1 radius accounting mode

This command is used to enable the RADIUS accounting function.

Syntax	
Syntax	

radius accounting mode no radius accounting mode

no - This command is used to set the RADIUS accounting function to the default value - that is, the RADIUS accounting function is disabled.

Default Setting

Disabled

Command Mode

Global Config

5.9.4.2 authorization network radius

Use this command to enable the switch to accept VLAN assignment by the radius server.

authorization network radius no authorization network radius

no - Use this command to disable the switch to accept VLAN assignment by the radius server.

Default Setting

Disabled

Command Mode

5.9.4.3 radius server attribute 4

This command to set the NAS-IP address for the radius server.

Synta	ах
Cynte	~

radius server attribute 4 [<ipaddr>] no radius server attribute 4

no - use this command to reset the NAS-IP address for the radius server.

Default Setting

None

Command Mode

Global Config

5.9.4.4 radius server attribute 95

This command to set the NAS-IPv6 address for the radius server.

Syntax

radius server attribute 95 [ipv6 address] no radius server attribute 95

no – use this command to reset the NAS-IPv6 address for the radius server.

Default Setting

None

Command Mode

5.9.4.5 radius server dead-time

This command cnfiguresradius server dead time.

Syntax		
radius se	rver dead-time <minutes></minutes>	

no radius server dead-time

minutes - Set radius server dead time (minutes). Range 0 - 2000.

no - This command is used to set dead time to the default value.

Default Setting

0

Command Mode

Global Config

5.9.4.6 radius server host

This command is used to configure the RADIUS authentication and accounting server.

If the **'auth'** token is used, the command configures the IP address to use to connect to a RADIUS authentication server. Up to 3 servers can be configured per RADIUS client. If the maximum number of configured servers is reached, the command will fail until one of the servers is removed by executing the **no** form of the command. If the optional **<port>** parameter is used, the command will configure the UDP port number to use to connect to the configured RADIUS server. In order to configure the UDP port number, the IP address must match that of a previously configured RADIUS authentication server. The port number must lie between 1 - 65535, with 1812 being the default value.

If the **'acct'** token is used, the command configures the IP address to use for the RADIUS accounting server. Only a single accounting server can be configured. If an accounting server is currently configured, it must be removed from the configuration using the no form of the command before this command succeeds. If the optional **<port>** parameter is used, the command will configure the UDP port to use to connect to the RADIUS accounting server. The IP address specified must match that of a previously configured accounting server. If a port is already configured for the accounting server then the new port will replace the previously configured value. The port must be a value in the range 1 - 65535, with 1813 being the default value.

Syntax

radius server host {acct | auth} <ipaddr| ipv6addr|hostname> [name <servername>] [port <port>] no radius server host {acct | auth} <ipaddr| ipv6addr|hostname>

<ipaddr| ipv6addr|hostname > - is a IPv4/IPv6 address or a hostname.

<servername> - Server name

<port> - Port number (Range: 1 – 65535)

no - This command is used to remove the configured RADIUS authentication server or the RADIUS accounting server. If the 'auth' token is used, the previously configured RADIUS authentication server is removed from the configuration. Similarly, if the 'acct' token is used, the previously configured RADIUS accounting server is removed from the configuration. The <ipaddr> parameter must match the IP address of the previously configured RADIUS authentication / accounting server.

Default Setting

None

Command Mode

Global Config

5.9.4.7 radius sever key

This command is used to configure the shared secret between the RADIUS client and the RADIUS accounting / authentication server. Depending on whether the **'auth'** or **'acct'** token is used, the shared secret will be configured for the RADIUS authentication or RADIUS accounting server. The IP address provided must match a previously configured server. When this command is executed, the secret will be prompted. The secret must be an alphanumeric value not exceeding 20 characters.

Syntax

radius server key {acct | auth} <ipaddr|ipv6addr|hostname> [encrypted <password>]

<ipaddr|ipv6addr| hostname > - is a IPv4/IPv6 address or hostname.

<password> is the password in encrypted format.

Default Setting

None

Command Mode

5.9.4.8 radius server retransmit

This command sets the maximum number of times a request packet is re-transmitted when no response is received from the RADIUS server. The retries value is an integer in the range of 1 to 15.

Syntax	
radius se	erver retransmit <retries></retries>
no radius server retransmit	

<retries> - the maximum number of retransmit times (Range: 1 - 15).

no - This command sets the maximum number of times a request packet is re-transmitted, when no response is received from the RADIUS server, to the default value, that is, 4.

Default Setting

4

Command Mode

Global Config

5.9.4.9 radius server timeout

This command sets the timeout value (in seconds) after which a request must be retransmitted to the RADIUS server if no response is received. The timeout value is an integer in the range of 1 to 30.

radius server timeout <seconds> no radius server timeout

<seconds> - the maximum timeout (Range: 1 - 30).

no - This command sets the timeout value (in seconds) after which a request must be retransmitted to the RADIUS server if no response is received, to the default value, that is, 5.

Default Setting

5

Command Mode

5.9.4.10 radius server msgauth

This command enables the message authenticator attribute for a specified server.

radius server msgauth <ipaddr| ipv6addr| hostname >

<ipaddr| ipv6addr| hostname > - is a IPv4/v6 address or hostname.

Default Setting

None

Command Mode

Global Config

5.9.4.11 radius server primary

This command is used to configure the primary RADIUS authentication server for this RADIUS client. The primary server is the one that is used by default for handling RADIUS requests. The remaining configured servers are only used if the primary server cannot be reached. A maximum of three servers can be configured on each client. Only one of these servers can be configured as the primary. If a primary server is already configured prior to this command being executed, the server specified by the IP address specified used in this command will become the new primary server. The IP address must match that of a previously configured RADIUS authentication server.

Syntax

radius server primary <ipaddr| ipv6addr| hostname>

<ipaddr | ipv6addr | hostname > - is a IPv4/v6 address or a hostname.

Default Setting

None

Command Mode

Global Config

5.9.4.12 radius source-interface

Use this command to specify the physical or logical interface to use as the RADIUS client source interface (Source IP address). If configured, the address of source interface is used for all RADIUS

communications between the RADIUS server and the RADIUS client. The selected source-interface IP address is used for filling the IP header of RADIUS management protocol packets. This allows security device (firewalls) to identify the source packets coming from the specific switch.

If a source-interface is not specified, the primary IP address of the originating (outbound) interface is used as the source address. If the configured interface is down, the RADIUS client falls back to its default behavior.

Syntax
c yman

radius source-interface {<slot/port> | loopback <loopback-id> | vlan <vlan-id>}

<slot/port> - Specifies the interface to use as the source interface.

<loopback-id> - Specifies the loopback interface to use as the source interface. The range of the loopback ID is 0 to 7.

<vlan-id> - Specifies the VLAN interface to use as the source interface. The range of VLAN ID is 1 to 4093.

Default Setting

None

Command Mode

5.9.5 TACACS+ Configuration Commands

5.9.5.1 tacacs-server host

This command is used to enable /disable TACACS+ function and to configure the TACACS+ server IP address. The system has not any TACACS+ server configured for its initialization and support 5 TACACS+ servers.

Syntax

tacacs-server host <ipAddr | ipv6Addr | hostname> no tacacs-server host <ipAddr | ipv6Addr | hostname>

<ipAddr|ipv6Addr|hostname> - The IPv4/v6 address or hostname of the TACACS+ server.

no - This command is used to remove all of configuration.

Default Setting

None

Command Mode

Global Config

5.9.5.2 tacacs-server key

This command is used to configure the TACACS+ authentication and encryption key.

S	yr	nta	ax
-			~~

tacacs-server key [<key-string>|encrypted <key-string>] no tacacs-server key

Note that the length of the secret key is up to 128 characters.

< key-string > - The valid value of the key.

encrypted - the key string is encrypted.

no - This command is used to remove the TACACS+ server secret key.

Default Setting

None

Command Mode

This command is used to configure the TACACS+ authentication and encryption key.

Syntax
Officar

key [<key-string> | encrypted <key-string>]

Note that the length of the secret key is up to 128 characters.

< key-string > - The valid value of the key.

encrypted - the key string is encrypted.

Default Setting

None

Command Mode

TACACS Host Config

This command is used to configure the TACACS+ authentication host port.

Syntax
Syntax

port [<port-number>]

ort-number> - The valid port number. Range (0 – 65535)>

Default Setting

49

Command Mode

TACACS Host Config

This command is used to configure the TACACS+ authentication host priority.

Syntax

priority [<priority>]

<priority> - The valid priority number. Range (0 – 65535)>

Default Setting

0

Command Mode

TACACS Host Config

This command is used to configure the TACACS+ connection timeout value.

timeout [<timeout>]

<timeout> - The connection timeout value. Max timeout (Range: 1 to 30).

Default Setting

5

Command Mode

TACACS Host Config

5.9.5.3 tacacs-server keystring

This command is used to configure the TACACS+ authentication and encryption key in re-confirm format.

Syntax

tacacs-server keystring

Default Setting

None

Command Mode

Global Config

5.9.5.4 tacacs-server timeout

This command is used to configure the TACACS+ connection timeout value.

Syntax

tacacs-server timeout [<timeout>] no tacacs-server timeout

<timeout> - The connection timeout value. Max timeout (Range: 1 to 30).

no - This command is used to reset the timeout value to the default value.

Default Setting

5

Command Mode

5.9.5.5 tacacs-server source-interface

Use this command in Global config mode to configure the source interface (Source IP address) for TACACS+ server configuration. The selected source-interface IP address is used for filling the IP header of management protocol packets. This allows security devices (firewalls) to identify the source packets coming from the specific switch.

If a source-interface is not specified, the primary IP address of the originating (outbound) interface is used as the source address.

Syntax

tacacs-server source-interface {<slot/port> | loopback <loopback-id> | vlan <vlan-id>} no tacacs-server source-interface

<slot/port> - Specifies the interface to use as the source interface.

<loopback-id> - Specifies the loopback interface to use as the source interface. The range of the loopback ID is 0 to 7.

<vlan-id> - Specifies the VLAN interface to use as the source interface. The range of VLAN ID is 1 to 4093.

no - Use this command to remove the global source interface for all TACACS+ communications between the TACACS+ client and the server.

Default Setting

None

Command Mode



5.9.6 Port Security Configuration Commands

5.9.6.1 port-security

This command enables port locking at the system level (Global Config) or port level (Interface Config).

Syntax					
port-secu	urity				
no port-s	security				

Default Setting

None

Command Mode

Global Config

Interface Config

5.9.6.2 port-security max-dynamic

This command sets the maximum of dynamically locked MAC addresses allowed on a specific port.

port-security max-dynamic [<0-600>] no port-security max-dynamic

no - This command resets the maximum of dynamically locked MAC addresses allowed on a specific port to its default value.

Default Setting

600

Command Mode

5.9.6.3 port-security max-static

This command sets the maximum number of statically locked MAC addresses allowed on a specific port.

Syntax	,
Syntax	•

port-security max-static [<0-20>] no port-security max-static

no - This command resets the maximum number of statically locked MAC addresses allowed on a specific port to its default value.

Default Setting

20

Command Mode

Interface Config

5.9.6.4 port-security mac-address

This command adds a MAC address to the list of statically locked MAC addresses.

0	
S	yntax

port-security mac-address <mac-addr> <1-4093> no port-security mac-address <mac-addr> <1-4093>

<1-4093> - VLAN ID

<mac-addr> - The statically locked MAC address.

no - This command removes a MAC address from the list of statically locked MAC addresses.

Default Setting

None

Command Mode



5.9.6.5 port-security mac-address move

This command converts dynamically locked MAC addresses to statically locked addresses.

Syntax

port-security mac-address move

Default Setting

None

Command Mode

Interface Config

5.9.6.6 port-security mac-address sticky

This command enables sticky mode Port MAC Locking on a port.

Syntax

port-security mac-address sticky [<mac-addr> <1-4093>] no port-security mac-address sticky

<1-4093> - VLAN ID

<mac-addr> - The statically locked MAC address.

no - This command disable sticky mode Port MAC Locking on a port.

Default Setting

None

Command Mode

Global Config

5.9.6.7 port-security violation shutdown

This command configures the port violation shutdown mode. Once the violation happens, the interface will be shutdown.



port-security violation shutdown no port-security violation

no - This command restore violation mode to be default.

Default Setting

None

Command Mode

5.9.7 Denial Of Service Commands

5.9.7.1 Show Commands

5.9.7.1.1 show dos-control

This command displays the Denial of Service configurations for the entire system.

Syntax

show dos-control

Default Setting

None

Command Mode

Privileged Exec

Display Message

TCP Fragment Mode: May be enabled or disabled. The factory default is disabled. Min TCP Hdr Size: The range is 0-255. The factory default is 20. ICMPv4 Mode: May be enabled or disabled. The factory default is disabled. Max ICMPv4 Payload Size: The range is 0-16376. The factory default is 512. ICMPv6 Mode: May be enabled or disabled. The factory default is disabled. Max ICMPv6 Payload Size: The range is 0-16376. The factory default is 512. ICMP Fragment Mode: May be enabled or disabled. The factory default is disabled. TCP Port Mode: May be enabled or disabled. The factory default is disabled. **UDP Port Mode:** May be enabled or disabled. The factory default is disabled. SIPDIP Mode: May be enabled or disabled. The factory default is disabled. SMACDMAC Mode: May be enabled or disabled. The factory default is disabled. TCP FIN&URG&PSH Mode: May be enabled or disabled. The factory default is disabled. TCP Flag&Sequence Mode: May be enabled or disabled. The factory default is disabled. TCP SYN Mode: May be enabled or disabled. The factory default is disabled. TCP SYN&FIN Mode: May be enabled or disabled. The factory default is disabled. First Fragment Mode: May be enabled or disabled. The factory default is disabled. TCP Fragment Offset Mode: May be enabled or disabled. The factory default is disabled.

5.9.7.2 Configuration Commands

5.9.7.2.1 dos-control sipdip

This command enables Source IP Address = Destination IP Address (SIP=DIP) Denial of Service protection. If the mode is enabled, Denial of Service prevention is active for this type of attack. If packets ingress with SIP=DIP, the packets will be dropped if the mode is enabled.

Syntax	x	
dos-contr	ontrol sipdip	
no dos-co	s-control sipdip	

no - This command disables Source IP Address = Destination IP Address (SIP=DIP) Denial of Service prevention.

Default Setting

Disabled

Command Mode

Global Config

5.9.7.2.2 dos-control tcpfrag

This command enables Minimum TCP Header Size Denial of Service protection. If the mode is enabled, Denial of Service prevention is active for this type of attack. If packets ingress having a TCP Header Size smaller then the configured value, the packets will be dropped if the mode is enabled. The default is disabled. If you enable dos-control tcpfrag, but do not provide a Minimum TCP Header Size, the system sets that value to 20.

Syntax	
dos-conti	rol tcpfrag [<0-255>]
no dos-co	control tcpfrag

<0-255> - This command sets minimum TCP header length

no - This command sets Minimum TCP Header Size Denial of Service protection to the default value of disabled.

Default Setting

Disabled, 20

Command Mode

5.9.7.2.3 dos-control firstfrag

This command enables IP First Fragment Denial of Service protection. If the mode is enabled, Denial of Service prevention is active for this type of attack. If packets ingress having More Fragments(MF) equal to 1 and coorperate with other DoS options, the packets will be dropped if the mode is enabled.

Syntax				
dos-contr	ol firstfrag			
no dos-co	ontrol firstfrag			

no - This command disabled IP First Fragment Denial of Service protection.

Default Setting

Disabled

Command Mode

Global Config

5.9.7.2.4 dos-control tcpflag

This command enables TCP Flag Denial of Service protections. If the mode is enabled, Denial of Service prevention is active for this type of attacks. If packets ingress having TCP Flag SYN set and a source port less than 1024 or having TCP Control Flags set to 0 and TCP Sequence Number set to 0 or having TCP Flags FIN, URG, and PSH set and TCP Sequence Number set to 0 or having TCP Flags SYN and FIN both set, the packets will be dropped if the mode is enabled.

Syntax
dos-control tcpflag
no dos-control tcpflag

no - This command sets disables TCP Flag Denial of Service protections.

Default Setting

Disabled

Command Mode

5.9.7.2.5 dos-control l4port

This command enables L4 Port Denial of Service protections. If the mode is enabled, Denial of Service prevention is active for this type of attack. If packets ingress having Source TCP/UDP Port Number equal to Destination TCP/UDP Port Number, the packets will be dropped if the mode is enabled.



Some applications mirror source and destination L4 ports - RIP for example uses 520 for both. If you enable dos-control l4port, applications such as RIP may experience packet loss which would render the application inoperable.

Syntax	x	
dos-contr	ontrol l4port	
no dos-co	s-control I4port	

no - This command disables L4 Port Denial of Service protections.

Default Setting

Disabled

Command Mode

Global Config

5.9.7.2.6 dos-control tcpport

This command enables the TCP L4 source = destination port number (Source TCP Port = Destination TCP Port) Denial of Service protection. If the mode is enabled, Denial of Service prevention is active for this type of attack. If packets ingress with Source TCP Port =Destination TCP Port, the packets will be dropped if the mode is enabled.

Syntax		
dos-contr	ntrol tcpport	
no dos-co	-control tcpport	

no - This command disables the TCP L4 source = destination port number (Source TCP Port =Destination TCP Port) Denial of Service protection.

Default Setting

Disabled

Command Mode

5.9.7.2.7 dos-control udpport

This command enables the UDP L4 source = destination port number (Source UDP Port = Destination UDP Port) Denial of Service protection. If the mode is enabled, Denial of Service prevention is active for this type of attack. If packets ingress with Source UDP Port =Destination UDP Port, the packets will be dropped if the mode is enabled.

Syntax		
dos-contr	trol udpport	
no dos-co	control udpport	

no - This command disables the UDP L4 source = destination port number (Source UDP Port =Destination UDP Port) Denial of Service protection.

Default Setting

Disabled

Command Mode

Global Config

5.9.7.2.8 dos-control icmpv4

This command enables Maximum ICMPv4 Payload Size Denial of Service protections. If the mode is enabled, Denial of Service prevention is active for this type of attack. If ICMP Echo Request (PING) packets ingress having a payload size greater than the configured value, the packets will be dropped if the mode is enabled.

Syntax			
dos-contr	ol icmpv4		
no dos-co	ontrol icmpv4		

no - This command disables Maximum ICMPv4 Payload Size Denial of Service protections.

Default Setting

Disabled

Command Mode

5.9.7.2.9 dos-control icmpv6

This command enables Maximum ICMPv6 Payload Size Denial of Service protections. If the mode is enabled, Denial of Service prevention is active for this type of attack. If ICMP Echo Request (PING) packets ingress having a payload size greater than the configured value, the packets will be dropped if the mode is enabled.

Syntax		
dos-contr	ntrol icmpv6	
no dos-co	-control icmpv6	

no - This command disables Maximum ICMPv6 Payload Size Denial of Service protections.

Default Setting

Disabled

Command Mode

Global Config

5.9.7.2.10 dos-control icmpv4

This command enables Maximum ICMPv4 Payload Size Denial of Service protections. If the mode is enabled, Denial of Service prevention is active for this type of attack. If ICMPv4 Echo Request (PING) packets ingress having a payload size greater than the configured value, the packets will be dropped if the mode is enabled.

Syntax

dos-contro	ol icmpv4 [<0-16376>]
no dos-co	ntrol icmpv4

<0-16376> - This command sets maximum ICMPv4 payload size.

no - This command resets the Maximum ICMPv4 Payload Size Denial of Service protections to its default value.

Default Setting

512

Command Mode

5.9.7.2.11 dos-control icmpv6

This command enables Maximum ICMPV6 Payload Size Denial of Service protections. If the mode is enabled, Denial of Service prevention is active for this type of attack. If ICMPV6 Echo Request (PING) packets ingress having a payload size greater than the configured value, the packets will be dropped if the mode is enabled.

Syntax			
dos-contr	rol icmpv6 [<0-16376>]		
no dos-co	ontrol icmpv6		

<0-16376> - This command sets maximum ICMPV6 payload size.

no - This command resets the Maximum ICMPV6 Payload Size Denial of Service protections to its default value.

Default Setting

512

Command Mode

Global Config

5.9.7.2.12 dos-control icmpfrag

This command enables the ICMP Fragment Denial of Service protection. If the mode is enabled, Denial of Service prevention is active for this type of attack. If packets ingress has fragmented ICMP packets, the packets will be dropped if the mode is enabled.

Syntax			
dos-contr	ol icmpfrag		
no dos-co	ontrol icmpfrag		

no - This command disables the ICMP Fragment Denial of Service protection.

Default Setting

Disabled

Command Mode

5.9.7.2.13 dos-control smacdmac

This command enables the Source MAC address = Destination MAC address (SMAC=DMAC) Denial of Service protection. If the mode is enabled, Denial of Service prevention is active for this type of attack. If packets ingress with SMAC=DMAC, the packets will be dropped if the mode is enabled.

Syntax						
dos-control smacdmac						
no dos-co	no dos-control smacdmac					

no - This command disables the Source MAC address = Destination MAC address (SMAC=DMAC) Denial of Service protection.

Default Setting

Disabled

Command Mode

Global Config

5.9.7.2.14 dos-control tcpfinurgpsh

This command enables the TCP FIN and URG and PSH and SEQ=0 checking Denial of Service protections. If the mode is enabled, Denial of Service prevention is active for this type of attack. If packets ingress having TCP FIN, URG, and PSH all set and TCP Sequence Number set to 0, the packets will be dropped if the mode is enabled.

Syntax

- [dos-control tcpfinurgpsh			
- Ľ				
- 1	dos-control tcpfinurgpsh			

no - This command disables the TCP FIN and URG and PSH and SEQ=0 checking Denial of Service protections.

Default Setting

Disabled

Command Mode

5.9.7.2.15 dos-control tcpflagseq

This command enables the TCP Control Flags=0 and SEQ=0 checking Denial of Service protections. If the mode is enabled, Denial of Service prevention is active for this type of attack. If packets ingress having TCP Control Flags set to 0 and TCP Sequence Number set to 0, the packets will be dropped if the mode is enabled.

Syntax				
dos-control tcpflagseq				
no dos-co	os-control tcpflagseq			

no - This command disables the TCP Control Flags=0 and SEQ=0 checking Denial of Service protections.

Default Setting

Disabled

Command Mode

Global Config

5.9.7.2.16 dos-control tcpsyn

This command enables the TCP SYN and L4 source port = 0-1023 Denial of Service protection. If the mode is enabled, Denial of Service prevention is active for this type of attack. If packets ingress having TCP flag SYN set and an L4 source port from 0 to 1023, the packets will be dropped if the mode is enabled.

Syntax				
dos-control tcpsyn				
no dos-control tcpsyn				

no - This command disables the TCP SYN and L4 source port = 0-1023 Denial of Service protection.

Default Setting

Disabled

Command Mode



5.9.7.2.17 dos-control tcpsynfin

This command enables the TCP SYN and FIN Denial of Service protection. If the mode is enabled, Denial of Service prevention is active for this type of attack. If packets ingress having TCP flags SYN and FIN set, the packets will be dropped if the mode is enabled.

Syntax	
dos-control tcpsynfin	
no dos-control tcpsynfin	

no - This command disables the TCP SYN & FIN Denial of Service protection.

Default Setting

Disabled

Command Mode

Global Config

5.9.7.2.18 dos-control tcpoffset

This command enables the TCP Fragment Offset Denial of Service protection. If the mode is enabled, Denial of Service prevention is active for this type of attack. If packets ingress having TCP Header Offset equal to one (1), the packets will be dropped if the mode is enabled.

-	
Syntax	

dos-control tcpoffset no dos-control tcpoffset

no - This command disables the TCP Fragment Offset Denial of Service protection.

Default Setting

Disabled

Command Mode



5.9.7.2.19 dos-control all

This command enables the Denial of Service protection checks globally.

Syntax				
dos-contr	rol all			
no dos-co	ontrol all			

no - This command disables the Denial of Service protection checks globally.

Default Setting

Disabled

Command Mode



5.10 CDP (Cisco Discovery Protocol) Commands

5.10.1 Show Commands

5.10.1.1 show cdp

This command displays the CDP configuration information.

Syntax			
show cdp	р		

Default Setting

None

Command Mode

Privileged Exec

Display Message

CDP Admin Mode: CDP enable or disable

CDP Holdtime (sec): The length of time a receiving device should hold the L2 Network Switch CDP information before discarding it

CDP Transmit Interval (sec): A period of the L2 Network Switch to send CDP packet

Ports: Port number vs CDP status

CDP: CDP enable or disable

5.10.1.2 show cdp neighbors

This command displays the CDP neighbor information.

Syntax

show cdp neighbors

Default Setting

None

Command Mode

Privileged Exec

Display Message

Device Id: Identifies the device name in the form of a character string.

Local Intf: The CDP neighbor information receiving port.

Holdtime: The length of time a receiving device should hold CDP information before discarding it.

Capability: Describes the device's functional capability in the form of a device type, for example, a switch.

Platform: Describes the hardware platform name of the device, for example, Quanta the L2 Network Switch.

Port Id: Identifies the port on which the CDP packet is sent.

5.10.1.3 show cdp neighbors detail

This command displays the CDP neighbor detail information.

Syntax

show cdp neighbors detail

Default Setting

None

Command Mode

Privileged Exec

Display Message

Device Id: Identifies the device name in the form of a character string.

Entry Address(es): The L3 addresses of the interface that has sent the update.

Platform: Describes the hardware platform name of the device, for example, Quanta the L2 Network Switch.

Capability: Describes the device's functional capability in the form of a device type, for example, a switch.

Local Interface: The CDP neighbor information receiving port.

Port Id: Identifies the port on which the CDP packet is sent.

Holdtime: The length of time a receiving device should hold CDP information before discarding it.

Management Address: The first address of IP address which can use management address connect to switch.

5.10.1.4 show cdp traffic

This command displays the CDP traffic counters information.

Syntax
Syntax

show cdp traffic

Default Setting

None

Command Mode

Privileged Exec

Display Message

Incoming packet number: Received legal CDP packets number from neighbors.

Outgoing packet number: Transmitted CDP packets number from this device.

Error packet number: Received illegal CDP packets number from neighbors.

5.10.2 Configuration Commands

5.10.2.1 cdp

This command is used to enable CDP Admin Mode.

Syntax	
cdp no cdp	
no cdp	

no - This command is used to disable CDP Admin Mode.

Default Setting

Enabled

Command Mode

Global Config

5.10.2.2 cdp run

This command is used to enable CDP on a specified interface.

Syntax			
cdp run no cdp ru			
no cdp ru	un		

no - This command is used to disable CDP on a specified interface.

Default Setting

Enabled

Command Mode

Interface Config

This command is used to enable CDP for all interfaces.

Syntax	
cdp run all no cdp run all	
no cdp run all	

all - All interfaces.

no - This command is used to disable CDP for all interfaces.

Default Setting

Enabled

Command Mode

Global Config

5.10.2.3 cdp timer

This command is used to configure an interval time (seconds) of the sending CDP packet.

Syntax			
cdp timer <5-2	254>		
no cdp timer			

<5-254> - interval time (Range: 5 – 254).

no - This command is used to reset the interval time to the default value.

Default Setting

60

Command Mode

5.10.2.4 cdp holdtime

This command is used to configure the hold time (seconds) of CDP.

ĺ	
	Syntax

cdp holdtime <10-255>

<10-255> - interval time (Range: 10 – 255).

no - This command is used to hold time to the default value.

Default Setting

180

Command Mode

5.11 SNTP (Simple Network Time Protocol) Commands

5.11.1 Show Commands

5.11.1.1 show sntp

This command displays the current time and configuration settings for the SNTP client, and indicates whether the local time has been properly updated.

Syntax	ĸ	
show snt	sntp	

Default Setting

None

Command Mode

Privileged Exec

Display Message

Last Update Time Time of last clock update.

Last Unicast Attempt Time Time of last transmit query (in unicast mode).

Last Attempt Status Status of the last SNTP request (in unicast mode) or unsolicited message (in broadcast mode).

Broadcast Count Current number of unsolicited broadcast messages that have been received and processed by the SNTP client since last reboot.

Multicast Count Current number of unsolicited multicast messages that have been received and processed by the SNTP client since last reboot.

Time Zone Time zone configured.

This command displays SNTP client settings.

Syntax

show sntp client

Default Setting

None

Command Mode

Privileged Exec

Display Message

Client Supported Modes Supported SNTP Modes (Broadcast, Unicast, or Multicast).

SNTP Version The highest SNTP version the client supports.

Port SNTP Client Port

Client Mode: Configured SNTP Client Mode.

Unicast Poll Interval Poll interval value for SNTP clients in seconds as a power of two.

Poll Timeout (Seconds) Poll timeout value in seconds for SNTP clients.

Poll Retry Poll retry value for SNTP clients.

Broadcast Poll Interval Poll interval value for SNTP clients in seconds as a power of two.

Multicast Poll Interval Poll interval value for SNTP clients in seconds as a power of two.

This command displays configured SNTP servers and SNTP server settings.

Syntax			
show snt	o server		

Default Setting

None

Command Mode

Privileged Exec

Display Message

Server IP Address IP Address of configured SNTP Server

Server Type Address Type of Server.

Server Stratum Claimed stratum of the server for the last received valid packet.

Server Reference ID Reference clock identifier of the server for the last received valid packet.

Server Mode SNTP Server mode.

Server Maximum Entries Total number of SNTP Servers allowed.

Server Current Entries Total number of SNTP configured.

For each configured server:

IP Address IP Address of configured SNTP Server.

Address Type Address Type of configured SNTP server.

Priority IP priority type of the configured server.

Version SNTP Version number of the server. The protocol version used to query the server in unicast mode.

Port Server Port Number

Last Attempt Time Last server attempt time for the specified server.

Last Update Status Last server attempt status for the server.

Total Unicast Requests Number of requests to the server.

Failed Unicast Requests Number of failed requests from server.

5.11.1.2 show sntp source-interface

Use this command to display the SNTP client source interface configured on the switch.

Syntax

show sntp source-interface

Default Setting

None

Command Mode

Privileged Exec

Display Message

SNTP Client source Interface The interface ID of the physical or logical interface configured as the SNTP client source interface.

SNTP Client Source IPv4 Address The IP address of the interface configured as the SNTP client source interface.



5.11.2 Configuration Commands

5.11.2.1 sntp broadcast client poll-interval

This command will set the poll interval for SNTP broadcast clients in seconds as a power of two where <poll-interval> can be a value from 6 to 10.

Syntax
Cyntax

sntp broadcast client poll-interval <6-10> no sntp broadcast client poll-interval

<6-10> - The range is 6 to 10.

no - This command will reset the poll interval for SNTP broadcast client back to its default value.

Default Setting

6

Command Mode

5.11.2.2 sntp client mode

This command will enable Simple Network Time Protocol (SNTP) client mode and optionally setting the mode to either broadcast, multicast, or unicast.

Syntax	
sntp client mode [broadcast unicast multicast] no sntp client mode	

no - This command will disable Simple Network Time Protocol (SNTP) client mode.



The SNTP IPv4 multicast address is 224.0.1.1. The SNTP IPv6 multicast address is ff05::101.

IPv6 address doesn't support broadcast mode.

Default Setting

None

Command Mode

Global Config

5.11.2.3 sntp client port

This command will set the SNTP client port id and polling interval in seconds.

Syntax

sntp client port <portid> no sntp client port

ortid> - SNTP client port id.

no - Resets the SNTP client port id.

Default Setting

The default portid is 123.

Command Mode



QuantaMesh | Switching Commands

411

5.11.2.4 sntp unicast client poll-interval

This command will set the poll interval for SNTP unicast clients in seconds.

Syntax		
sntp unica	icast client poll-interval <6-10>	

no sntp unicast client poll-interval

<6-10> - Polling interval. It's 2^(value) seconds where value is 6 to 10.

no - This command will reset the poll interval for SNTP unicast clients to its default value.

Default Setting

The default value is 6.

Command Mode

Global Config

5.11.2.5 sntp unicast client poll-timeout

This command will set the poll timeout for SNTP unicast clients in seconds.

Syntax

sntp unicast client poll-timeout <poll-timeout> no sntp unicast client poll-timeout

< poll-timeout > - Polling timeout in seconds. The range is 1 to 30.

no - This command will reset the poll timeout for SNTP unicast clients to its default value.

Default Setting

The default value is 5.

Command Mode

5.11.2.6 sntp unicast client poll-retry

This command will set the poll retry for SNTP unicast clients in seconds.

Syntax

sntp unicast client poll-retry <poll-retry> no sntp unicast client poll-retry

< poll-retry> - Polling retry in seconds. The range is 0 to 10.

no - This command will reset the poll retry for SNTP unicast clients to its default value.

Default Setting

The default value is 1.

Command Mode

5.11.2.7 sntp server

This command configures an SNTP server (with a maximum of three) where the server address can be an ip address or a domain name and the address type either IPv4, IPv6, dnsv6 or dns. The optional priority can be a value of 1-3, the version is a value of 1-4, and the port id is a value of 1-65535.

Syntax

sntp server <ipaddress/ipv6address/domain-name> <addresstype> [<1-3> [<version> [<portid>]]] no sntp server remove <ipaddress/ipv6address/domain-name>

<ipaddress/ipv6address/domain-name > - IPv4 or IPv6 address or domain name of the SNTP server.

<addresstype > - The address type is ipv4 or ipv6 or dns or dnsv6.

<1-3> - The range is 1 to 3.

<version> - The range is 1 to 4.

ortid> - The range is 1 to 65535.

no - This command deletes an server from the configured SNTP servers.

Default Setting

None

Command Mode

5.11.2.8 sntp clock timezone

This command sets the time zone for the switch's internal clock.

Syntax

sntp clock timezone <name> <0-12> <0-59> {before-utc | after-utc}

<name> - Name of the time zone, usually an acronym. (Range: 1-15 characters)

<0-12> - Number of hours before/after UTC. (Range: 0-12 hours)

<0-59> - Number of minutes before/after UTC. (Range: 0-59 minutes)

before-utc - Sets the local time zone before (east) of UTC.

after-utc - Sets the local time zone after (west) of UTC.

Default Setting

Taipei 08:00 After UTC

Command Mode

Global Config

5.11.2.9 sntp multicast client poll-internal

This command will set the poll interval for SNTP multicast clients in seconds.

Syntax

sntp multicast client poll-interval <poll-interval> no sntp multicast client poll-interval

<poll-interval> - Polling interval. It's 2^(value) seconds where the range of value is 6 to 10.

no - This command will reset the poll interval for SNTP multicast client to its default value.

Default Setting

The default value is 6.

Command Mode

5.11.2.10 sntp source-interface

Use this command to specify the physical or logical interface to use as the SNTP client source interface. If configured, the address of source interface is used for all SNTP communications between the SNTP server and the SNTP client. Otherwise, there is no change in behavior. If the configured interface is down, the SNTP client falls back to its default behavior.

Syntax

sntp source-interface {<slot/port> | loopback <loopback-id> | tunnel <tunnel-id> | vlan <vlan-id>} no sntp source-interface

<slot/port> - Specifies the port to use as the source interface.

<loopback-id> - Specifies the loopback interface to use as the source interface. The range of the loopback ID is 0 to 7.

<tunnel-id> - Specifies the tunnel interface to use as the source interface. The range of the tunnel ID is 0 to 7.

<vlan-id> - Specifies the VLAN interface to use as the source interface. The range of the VLAN ID is 1 to 4093.

no - This command will reset the SNTP source interface to its default settings.

Default Setting

None

Command Mode

5.12 LLDP (Link Layer Discovery Protocol) Commands

5.12.1 Show Commands

5.12.1.1 show lldp

This command uses to display a summary of the current LLDP configuration.

Syntax		
show lldp	dp	

Default Setting

None

Command Mode

Privileged Exec

Display Message

Transmit Interval: Shows how frequently the system transmits local data LLDPDUs, in seconds.

Transmit Hold Multiplier: Shows the multiplier on the transmit interval that sets the TTL in local data LLDPDUs.

Reinit Delay: Shows the delay before re-initialization, in seconds.

Notification Interval: Shows how frequently the system sends remote data change notifications, in seconds.

Transmit Delay: Shows how frequently the system transmits local data LLDPDUs after a change is made in a TLV (type, length, or value) element in LLDP, in seconds.

5.12.1.2 show lldp interface

This command uses to display a summary of the current LLDP configuration for a specific interface or for all interfaces.

Syntax

show Ildp interface [<slot/port>]

<slot/port> - Configs a specific interface.

Default Setting

None

Command Mode

Privileged Exec

Display Message

Interface: Shows the interface in a slot/port format.

Link: Shows whether the link is up or down.

Transmit: Shows whether the interface transmits LLDPDUs.

Receive: Shows whether the interface receives LLDPDUs.

Notify: Shows whether the interface sends remote data change notifications.

TLVs: Shows whether the interface sends optional TLVs in the LLDPDUs. The TLV codes can be 0 (Port Description), 1 (System Name), 2 (System Description), or 3 (System Capability).

Mgmt: Shows whether the interface transmits system management address information in the LLDPDUs.

5.12.1.3 show lldp statistics

This command uses to display the current LLDP traffic and remote table statistics for a specific interface or for all interfaces.

Syntax

show lldp statistics [<slot/port>]

<slot/port> - Configs a specific interface.

Default Setting

None

Command Mode

Privileged Exec

Display Message

Last Update: Shows the amount of time since the last update to the remote table in days, hours, minutes, and seconds.

Total Inserts: Total number of inserts to the remote data table.

Total Deletes: Total number of deletes from the remote data table.

Total Drops: Total number of times the complete remote data received was not inserted due to insufficient resources.

Total Ageouts: Total number of times a complete remote data entry was deleted because the Time to Live interval expired.

The table contains the following column headings:

Interface: Shows the interface in slot/port format.

Tx Total: Total number of LLDP packets transmitted on the port.

Rx Total: Total number of LLDP packets received on the port.

Discards: Total number of LLDP frames discarded on the port for any reason.

Errors: The number of invalid LLDP frames received on the port.

Ageout: Total number of times a complete remote data entry was deleted for the port because the Time to Live interval expired.

TLV Discards: Shows the number of TLVs discarded

TLV Unknowns: Total number of LLDP TLVs received on the port where the type value is in the reserved range, and not recognized.

TLV MED: Total number of LLDP TLVs received on the port where the type value is 127 and OUI type is 00-12-BB.

TLV 802.1: Total number of LLDP TLVs received on the port where the type value is 127 and OUI type is 00-80-C2.

419

TLV 802.3: Total number of LLDP TLVs received on the port where the type value is 127 and OUI type is 00-12-0F.

5.12.1.4 show lldp remote-device

This command uses to display summary information about remote devices that transmit current LLDP data to the system. You can show information about LLDP remote data received on all ports or on a specific port.

Syntax

show lldp remote-device [<slot/port>]

<slot/port> - Displays a specific interface.

Default Setting

None

Command Mode

Privileged Exec

Display Message

Local Interface: Identifies the interface that received the LLDPDU from the remote device.

Rem ID: Shows the ID of the remote device.

Chassis ID: The ID that is sent by a remote device as part of the LLDP message, it is usually a MAC address of the device.

Port ID: Shows the port number that transmitted the LLDPDU.

System Name: Shows the system name of the remote device.

5.12.1.5 show lldp remote-device detail

This command uses to display detailed information about remote devices that transmit current LLDP data to an interface on the system.

Syntax

show lldp remote-device detail <slot/port>

<slot/port> - Displays a specific interface.

Default Setting

None

Command Mode

Privileged Exec

Display Message

Local Interface: Identifies the interface that received the LLDPDU from the remote device.

Remote Identifier: An internal identifier to the switch to mark each remote device to the system.

Chassis ID Subtype: Shows the type of identification used in the Chassis ID field.

Chassis ID: Identifies the chassis of the remote device.

Port ID Subtype: Identifies the type of port on the remote device.

Port ID: Shows the port number that transmitted the LLDPDU.

System Name: Shows the system name of the remote device.

System Description: Describes the remote system by identifying the system name and versions of hardware, operating system, and networking software supported in the device.

Port Description: Describes the port in an alpha-numeric format. The port description is configurable.

System Capabilities Supported: Indicates the primary function(s) of the device.

System Capabilities Enabled: Shows which of the supported system capabilities are enabled.

Management Address: For each interface on the remote device with an LLDP agent, lists the type of address the remote LLDP agent uses and specifies the address used to obtain information related to the device.

Time To Live: Shows the amount of time (in seconds) the remote device's information received in the LLDPDU should be treated as valid information.

MAC/PHY Configuration/Status

Auto-Negetitation: Identifies the auto-negotiation support and current status of the remote device.

PMD Auto-Negetitation: The duplex and bit-rate capability of the port of the remote device.

Operational MAU Type: Displays the MAU type. The MAU performs physical layer functions, including digital data conversion from the Ethernet interfaces' collision detection and bit injection into the network.

Power Via MDI

MDI Power Support: The MDI power capabilities and status.

PSE Power Pair: Indicates the way of feeding the voltage to the data cable.

Power Class: PoE power class.

Link Aggregation

Aggregation Status: Indicates the link aggregation capabilities and the current aggregation status.

Aggregation Port Id: Aggregated port identifier.

Maximum Frame Size: Shows the maximum frame size capability of the implemented MAC and PHY of the remote device.

Port VLAN Identity: Shows the PVID of the connected port of the remote device.

Protocol VLAN

Status: Indicates the port and protocol VLAN capability and status.

ID: The PPVID number for the port of the remote device.

VLAN Name: Shows the name of the VLAN which the connected port is in.

Protocol Identity: Shows the particular protocols that are accessible through the port of the remote device.

5.12.1.6 show lldp local-device

This command uses to display summary information about the advertised LLDP local data. This command can display summary information or detail for each interface.

Syntax
Symax

show lldp local-device [<slot/port>]

<slot/port> - Displays a specific interface.

Default Setting

None

Command Mode

Privileged Exec

Display Message

Interface: Identifies the interface in a slot/port format.

Port ID: Shows the port ID associated with this interface.

Port Description: Shows the port description associated with the interface.

5.12.1.7 show lldp local-device detail

This command uses to display detailed information about the LLDP data a specific interface transmits.

Syntax

show lldp local-device detail <slot/port>

<slot/port> - Displays a specific interface.

Default Setting

None

Command Mode

Privileged Exec

Display Message

Interface: Identifies the interface that sends the LLDPDU.

Chassis ID Subtype: Shows the type of identification used in the Chassis ID field.

423

Chassis ID: Identifies the chassis of the local device.

Port ID Subtype: Identifies the type of port on the local device.

Port ID: Shows the port number that transmitted the LLDPDU.

System Name: Shows the system name of the local device.

System Description: Describes the local system by identifying the system name and versions of hardware, operating system, and networking software supported in the device.

Port Description: Describes the port in an alpha-numeric format.

System Capabilities Supported: Indicates the primary function(s) of the device.

System Capabilities Enabled: Shows which of the supported system capabilities are enabled.

Management Address: Lists the type of address and the specific address the local LLDP agent uses to send and receive information.

MAC/PHY Configuration/Status

Auto-Negetitation: Identifies the auto-negotiation support and current status of the local device.

PMD Auto-Negetitation: The duplex and bit-rate capability of the port of the local device.

Operational MAU Type: Displays the MAU type. The MAU performs physical layer functions, including digital data conversion from the Ethernet interfaces' collision detection and bit injection into the network.

Power Via MDI

MDI Power Support: The MDI power capabilities and status.

PSE Power Pair: Indicates the way of feeding the voltage to the data cable.

Power Class: PoE power class.

Link Aggregation

Aggregation Status: Indicates the link aggregation capabilities and the current aggregation status.

Aggregation Port Id: Aggregated port identifier.

Maximum Frame Size: Shows the maximum frame size capability of the implemented MAC and PHY of the remote device.

Port VLAN Identity: Shows the PVID of the connected port of the local device.

VLAN Name: Shows the name of the VLAN which the connected port is in.

Protocol Identity: Shows the particular protocols that are accessible through the port of the local device.



5.12.1.8 show lldp med

The user can go to the CLI Privilege Exec to display a summary of the current LLDP-MED configuration, use the **show lldp med** Privilege command.

	Syntax											
show lldp med												

Default Setting

None

Command Mode

Privileged Exec

Display Message

Fast Start Repeat Count: Specifies the number of LLDP PDUs that will be transmitted when the protocol is enabled. The range is from (1 to 10). Default value of fast repeat count is 3.

Device Class: Specifies local device's MED Classification. There are four different kinds of devices, three of them represent the actual end points (classified as Class I Generic [IP Communication Controller etc.], Class II Media [Conference Bridge etc.], Class III Communication [IP Telephone etc.]). The fourth device is Network Connectivity Device, which is typically a LAN Switch/Router, IEEE 802.1 Bridge, IEEE 802.11 Wireless Access Point etc.

5.12.1.9 show lldp med interface

The user can go to the CLI Privilege Exec to d display a summary of the current LLDP-MED configuration for a specific interface, use the **show lldp med interface [</slot/port>]** Privilege command.

Syntax

show lldp med interface [<slot/port>]

<slot/port> - Displays a specific interface.

Default Setting

None

Command Mode

Privileged Exec

Display Message

Interface: Specifies all the ports on which LLDP-MED can be configured.

Link: Specifies the link status of the ports whether it is Up/Down.

configMED: Specifies the LLDP-MED mode is enabled or disabled on this interface.

OperMED: Specifies the LLDP-MED TLVs are transmitted or not on this interface

ConfigNotify: Specifies the LLDP-MED topology notification mode of the interface.

TLVsTx: Specifies the LLDP-MED transmit TLV(s) that are included

5.12.1.10 show lldp med local-device detail

The user can go to the CLI Privilege Exec to display detailed information about the LLDP-MED data, use the **show lldp med local-device detail <slot/port>** Privilege command.

• •		
	Syntax	
SVIITAX	SVIITAX	

show Ildp med local-device detail <slot/port>

<slot/port> - Displays a specific interface.

Default Setting

None

Command Mode

Privileged Exec

Display Message

Interface: Identifies the interface.

Network Policies Specifies if network policy TLV is present in the LLDP frames.

Media Policy Application Type: Specifies the application type. Types of application types are unknown, voicesignaling, guestvoice, guestvoicesignalling, softphonevoice, videoconferencing, streammingvideo, vidoesignalling. Each application type that is received has the VLAN id, priority, DSCP, tagged bit status and unknown bit status. A port may receive one or many such application types. If a network policy TLV has been transmitted only then would this information be displayed.

Vian ID: Specifies the VLAN id associated with a particular policy type.

Priority: Specifies the priority associated with a particular policy type.

DSCP: Specifies the DSCP associated with a particular policy type.

Unknown: Specifies the unknown bit associated with a particular policy type.

Tagged: Specifies the tagged bit associated with a particular policy type.

Inventory Specifies if inventory TLV is present in LLDP frames.

Hardware Rev: Specifies hardware version.

Firmware Rev: Specifies Firmware version.

Software Rev: Specifies Software version.

Serial Num: Specifies serial number.

Mfg Name: Specifies manufacturers name.

Model Name: Specifies model name.

Asset ID: Specifies asset id.

Location Specifies if location TLV is present in LLDP frames.

Subtype: Specifies type of location information.

Info: Specifies the location information as a string for given type of location id.

Extended POE Specifies if local device is a PoE device.

Device Type: Specifies power device type.

Extended POE PSE Specifies if extended PSE TLV is present in LLDP frame.

Available: Specifies available power sourcing equipment's power value in tenths of watts on the port of local device.

Source: Specifies power source of this port.

Priority: Specifies PSE port power priority.

Extended POE PD Specifies if extended PD TLV is present in LLDP frame.

Required: Specifies required power device power value in tenths of watts on the port of local device.

Source: Specifies power source of this port.

Priority: Specifies PD port power priority.

5.12.1.11 show lldp med remote-device

The user can go to the CLI Privilege Exec to d display the summary information about remote devices that transmit current LLDP-MED data to the system. use the **show lldp med remote-device** [<slot/port>] Privilege command.

Syntax

show lldp med remote-device [<slot/port>]

Default Setting

None

Command Mode

Privileged Exec

Display Message

Interface: Specifies the list of all the ports on which LLDP-MED is enabled.

Remote ID: An internal identifier to the switch to mark each remote device to the system.

Device Class: Specifies local device's MED Classification. There are four different kinds of devices, three of them represent the actual end points (classified as Class I Generic [IP Communication Controller etc.], Class II Media [Conference Bridge etc.], Class III Communication [IP Telephone etc.]). The fourth device is Network Connectivity Device, which is typically a LAN Switch/Router, IEEE 802.1 Bridge, IEEE 802.11 Wireless Access Point etc.



5.12.1.12 show lldp med remote-device detail

The user can go to the CLI Privilege Exec to d display detailed information about remote devices that transmit current LLDP-MED data to an interface on the system, use the **show lldp med remote-device detail** *<slot/port>* Privilege command.

Syntax

show lldp med remote-device detail <slot/port>

Default Setting

None

Command Mode

Privileged Exec

Display Message

Term Definition:

Capabilities: Specifies the supported and enabled capabilities that was received in MED TLV on this port.

MED Capabilities Supported: Specifies supported capabilities that was received in MED TLV on this port.

MED Capabilities Enabled: Specifies enabled capabilities that was received in MED TLV on this port.

Device Class: Specifies device class as advertised by the device remotely connected to the port.

Network Policies Specifies if network policy TLV is received in the LLDP frames on this port.

Media Policy Application Type: Specifies the application type. Types of application types are unknown, voicesignaling, guestvoice, guestvoicesignalling, softphonevoice, videoconferencing, streammingvideo, vidoesignalling. Each application type that is received has the VLAN id, priority, DSCP, tagged bit status and unknown bit status. A port may receive one or many such application types. If a network policy TLV has been receive on this port only then would this information be displayed.

Vian ID: Specifies the VLAN id associated with a particular policy type.

Priority: Specifies the priority associated with a particular policy type.

DSCP: Specifies the DSCP associated with a particular policy type.

Unknown: Specifies the unknown bit associated with a particular policy type.

Tagged: Specifies the tagged bit associated with a particular policy type.

Inventory Specifies if inventory TLV is received in LLDP frames on this port.

Hardware Rev: Specifies hardware version of the remote device.

Firmware Rev: Specifies Firmware version of the remote device.
Software Rev: Specifies Software version of the remote device.
Serial Num: Specifies serial number of the remote device.
Mfg Name: Specifies manufacturers name of the remote device.
Model Name: Specifies model name of the remote device.
Asset ID: Specifies asset id of the remote device.

Location Specifies if location TLV is received in LLDP frames on this port.Subtype: Specifies type of location information.Info: Specifies the location information as a string for given type of location id.

Extended POE Specifies if remote device is a PoE device. Device Type: Specifies remote device's PoE device type connected to this port.

Extended POE PSE Specifies if extended PSE TLV is received in LLDP frame on this port.
Available: Specifies the remote ports PSE power value in tenths of watts.
Source: Specifies the remote ports PSE power source.
Priority: Specifies the remote ports PSE power priority.

Extended POE PD Specifies if extended PD TLV is received in LLDP frame on this port.
Required: Specifies the remote port's PD power requirement.
Source: Specifies the remote port's PD power source.
Priority: Specifies the remote port's PD power priority.

5.12.1.13 show lldp dcbx

The user can go to the CLI Privilege Exec to d display the local Data Center Bridging Capability Exchange (DCBX) control status of an interface on the system, use the **show lldp dcbx interface** [<*slot/ports]* Privilege command.

Syntax

show lldp dcbx interface [<slot/port> [detail]]

Default Setting

None

Command Mode

Privileged Exec

Display Message

Is configuration source selected: Is any interface configured configuration source or not. Configuration source port: Which interfaces are configured as configuration source. Interface: Specifies all the ports on which DCBX can be configured. Status: Specifies the DCBX status of the interfaces. Role: Specifies the DCBX role on the interfaces. Version: Specifies the DCBX version on the interfaces. DCBX Tx: Total number of transmitted DCBX TLV(s) on the interfaces. DCBX Rx: Total number of received DCBX TLV(s) on the interfaces. DCBX Error: Total number of error DCBX TLV(s) on the interfaces. uknown TLV: Total number of unknown DCBX TLV(s) on the interfaces. DCBX operational status: Specifies the DCBX status of the interface. Configured DCBX version: Specifies the DCBX version on this interface. Peer DCBX version: Specifies the DCBX version of the peer device. Peer MAC: Specifies the MAC address of the peer device. Peer Description: Specifies the description of the peer device. Auto-configuration Port Role: Specifies the DCBX role on this interface. Peer Is configuration Source: Is peer device configured configuration source or not. Error counters: Total number of error DCBX TLV(s) on this interface as following. ETS incompatible configuration: Total number of ETS incompatible configuration on this interface. PFC incompatible configuration: Total number of PFC incompatible configuration on this interface.

Disappearing neighbor: Total number of Disappearing neighbor on this interface.

Multiple neighbors detected: Total number of Multiple neighbors detected on this interface.

5.12.1.14 show lldp tlv-select

The user can go to the CLI Privilege Exec to d display the DCBX TLV configuration of an interface on the system, use the **show lldp tlv-select interface** [<*slot/port>]* Privilege command.

Syntax

show lldp tlv-select interface [<slot/port>]

Default Setting

None

Command Mode

Privileged Exec

Display Message

Interface: Specifies all the ports on which DCBX TLV can be configured.

ETS Config: Specifies the DCBX ets-configuration TLV status of the interfaces.

ETS Recommend: Specifies the DCBX DCBX ets-recommendation TLV on the interfaces.

PFC: Specifies the DCBX priority flow control TLV on the interfaces.

App priority: Specifies the DCBX application-priority TLV on the interfaces.

5.12.1.15 show lldp remote-comparison

The user can go to the CLI Privilege Exec to d display LLDP comparison between remote & local interface on the system, use the **show lldp remote-comparison** [<*slot/port>]* Privilege command.

Syntax

show lldp remote-comparison [<slot/port>]

Default Setting

None

Command Mode

Privileged Exec

Display Message

LLDP Comparison: Specifies all the difference of TLVs between remote interface & local interface.

5.12.2 Configuration Commands

5.12.2.1 Ildp notification

This command uses to enable remote data change notifications.

Syntax		
lldp notific no lldp no	fication notification	

no - This command is used to disable notifications.

Default Setting

Disbaled

Command Mode

Interface Config

5.12.2.2 Ildp notification-interval

This command is used to configure how frequently the system sends remote data change notifications. The <interval-seconds> parameter is the number of seconds to wait between sending notifications. The valid interval range is 5-3600 seconds.

IIdp notification-interval <interval-seconds> no IIdp notification-interval

<interval-seconds> - Configures the number of seconds to wait between sending notifications.

no - This command is used to return the notification interval to the default value.

Default Setting

5

Command Mode

5.12.2.3 Ildp receive

This command uses to enable the LLDP receive capability.

Syntax			
lldp recei	ve		
no lldp re	eceive		

no - This command is used to return the reception of LLDPDUs to the default value.

Default Setting

Disabled

Command Mode

Interface Config

5.12.2.4 Ildp transmit

This command uses to enable the LLDP advertise capability.

Syntax	
Ildp transmit no Ildp transmit	
no Ildp transmit	

no - This command is used to return the local data transmission capability to the default.

Default Setting

Disabled

Command Mode



5.12.2.5 Ildp transmit-mgmt

This command uses to include transmission of the local system management address information in the LLDPDUs.

Syntax	x	
lldp trans	ansmit-mgmt	
no lldp tra	o transmit-mgmt	

no - This command is used to cancel inclusion of the management information in LLDPDUs.

Default Setting

None

Command Mode

Interface Config

5.12.2.6 Ildp transmit-tlv

This command is used to specify which optional type length values (TLVs) in the 802.1AB basic management set are transmitted in the LLDPDUs. Use sys-name to transmit the system name TLV. To configure the system name, please refer to "snmp-server" command. Use sys-descto transmit the system description TLV. Use sys-cap to transmit the system capabilities TLV. Use port-desc to transmit the port description TLV. To configure the port description, please refer to "description" command. Use org-spec to transmit the organization specific TLV.

Syntax

lldp transmit-tlv [sys-desc] [sys-name] [sys-cap] [port-desc] [org-spec] no lldp transmit-tlv [sys-desc] [sys-name] [sys-cap] [port-desc] [org-spec]

no - This command is used to remove an optional TLV from the LLDPDUs. Use the command without parameters to remove all optional TLVs from the LLDPDU.

Default Setting

None

Command Mode



5.12.2.7 Ildp timers

This command is used to set the timing parameters for local data transmission on ports enabled for LLDP. The <interval-seconds> determines the number of seconds to wait between transmitting local data LLDPDUs. The range is 1-32768 seconds. The <hold-value> is the multiplier on the transmit interval that sets the TTL in local data LLDPDUs. The multiplier range is 2-10. The <reinit-seconds> is the delay before re-initialization, and the range is 1-0 seconds.

Syntax

Ildp timers [interval <interval-seconds>] [hold <hold-value>] [reinit <reinit-seconds>]
no Ildp timers [interval] [hold] [reinit]

<interval-seconds> - Configures the number of seconds to wait between transmitting local data LLDPDUs

<hold-value> - Configures the multiplier on the transmit interval that sets the TTL in local data LLDPDUs

<reinit-seconds> - Configures the delay before re-initialization

no - This command is used to return any or all timing parameters for local data transmission on ports enabled for LLDP to the default values.

Default Setting

Interval-seconds 30

Hold-value 4

Reinit-seconds 2

Command Mode

5.12.2.8 Ildp tx-delay

This command is used to set the timing parameters for data transmission delay on ports enabled for LLDP. The <delay-seconds> determines the number of seconds to wait between transmitting local data LLDPDUs. The range is 1-8192 seconds.

Syntax	
lldp tx-de no lldp tx	elay <delay-seconds></delay-seconds>
	(-delay

no - This command is used to return return the transmit delay to the default value.

Default Setting

2

Command Mode

Global Config

5.12.2.9 Ildp med

The user can go to the CLI Interface Configuration Mode to set MED to enable, use the **IIdp med** Interface configuration command. Use the **no IIdp med** to disable med function.

Syntax			
lldp med no lldp m			
no lldp m	ied		

Default Setting

Disabled

Command Mode

5.12.2.10 Ildp med confignotification

The user can go to the CLI Interface Configuration Mode to set all the ports to send the topology change notification, use the **IIdp med confignotification** Interface configuration command. Use the **no IIdp med confignotification** to disable notifications.

Syntax

Ildp med confignotification no Ildp med confignotification

Default Setting

Disabled

Command Mode

5.12.2.11 Ildp med transmit-tlv

The user can go to the CLI Interface Configuration Mode to set Type Length Values (TLVs) in the LLDP MED, use the **IIdp med transmit-tlv [capabilities] [ex-pd] [ex-pse] [inventory]** [location][network-policy] Interface configuration command. Use the **no IIdp med transmit-tlv** [capabilities] [ex-pd] [ex-pse] [inventory] [location][network-policy] to remove the TLVs.

Ildp med transmit-tlv [capabilities] [ex-pd] [ex-pse] [inventory] [location] [network-policy] no Ildp med transmit-tlv [capabilities] [ex-pd] [ex-pse] [inventory] [location] [network-policy]

capabilities -Transmit the LLDP capabilities TLV.

ex-pd - Transmit the LLDP extended PD TLV.

ex-pse - Transmit the LLDP extended PSE TLV.

inventory - Transmit the LLDP inventory TLV.

location - Transmit the LLDP location TLV.

network-policy - Transmit the LLDP network policy TLV.

Default Setting

None

Command Mode

5.12.2.12 IIdp med all

The user can go to the CLI Global Configuration Mode to set LLDP-MED on all the ports, use the **IIdp med all** Global configuration command. Use the **no IIdp med all** to disable LLDP-MED on all the ports.

Syntax			
lldp med a	all		
no lldp me	ed all		

Default Setting

Disabled

Command Mode

Global config

5.12.2.13 Ildp med confignotification all

The user can go to the CLI Global Configuration Mode to set all the ports to send the topology change notification, use the **IIdp med confignotification all** Global configuration command. Use the **no IIdp med confignotification all** to remove all the ports to send the topology change notification.

Syntax

Ildp med confignotification all no Ildp med confignotification all

Default Setting

None

Command Mode



5.12.2.14 IIdp med faststartrepeatcount

The user can go to the CLI Global Configuration Mode to set the fast start repeat count, use the **IIdp med faststartrepeatcount** Global configuration command. Use the **no IIdp med faststartrepeatcount** to return the default value 3.

Syntax

Ildp med faststartrepeatcount <1-10> no Ildp med faststartrepeatcount

Default Setting

3

Command Mode

5.12.2.15 Ildp med transmit-tlv all

The user can go to the CLI Global Configuration Mode to set Type Length Values (TLVs) in the LLDP-MED, use the **IIdp med transmit-tlv all [capabilities] [ex-pd] [ex-pse] [inventory][location]** [network-policy]Global configuration command. Use the no IIdp med transmit-tlv all [capabilities] [ex-pd] [ex-pse] [inventory] [location] [network-policy] to remove Type Length Values (TLVs) in the LLDP-MED

Syntax

lldp med transmit-tlv all [capabilities] [ex-pd] [ex-pse] [inventory] [location] [network-policy] no lldp med transmit-tlv all [capabilities] [ex-pd] [ex-pse] [inventory] [location] [network-policy]

capabilities - Transmit the LLDP capabilities TLV.

ex-pd - Transmit the LLDP extended PD TLV.

ex-pse - Transmit the LLDP extended PSE TLV.

inventory - Transmit the LLDP inventory TLV.

location - Transmit the LLDP location TLV.

network-policy - Transmit the LLDP network policy TLV.

Default Setting

None

Command Mode

Global Config

5.12.2.16 Ildp dcbx version

This command is used to configure DCBX protocol version. Use the **no lldp dcbx version** to reset the value to default.

Syntax

Ildp dcbx version <auto | cee | cin | ieee> no Ildp dcbx version

auto - Configure the switch to auto detect the peer DCBX version.

cee - Configure the switch to operate according to standard cee 1.06.

- cin Configure the switch to operate according to DCBX standard CIN 1.0 .
- ieee Configure the switch to operate according to standard IEEE 802.1Qaz.



Default Setting

auto

Command Mode

Global Config

5.12.2.17 Ildp dcbx port-role

The user can go to the CLI Interface Configuration Mode to configure DCBX auto configuration port role by using the **IIdp dcbx port-role** Interface configuration command. Use the **no IIdp dcbx port-role** to reset this function to default.

Syntax

Ildp dcbx port-role <auto-down | auto-up | configuration-source | manual> no Ildp dcbx port-role

auto-down - Configure interface as auto-down stream.

auto-up - Configure interface as auto-up stream.

configuration-source - Configure interface as configuration source.

manual - Configure interface as manual port.

Default Setting

manual

Command Mode

5.12.2.18 Ildp tlv-select

This command is used to configure IIdp to transmit-tlv DCBX TLV(s). Use the **no IIdp tlv-select** to disable this function.

Syntax

Ildp tlv-select dcbxp [application-priority | ets-config | ets-recommend | pfc] no Ildp tlv-select dcbxp

application-priority - Include DCBX application-priority TLV.

ets-config - Include DCBX ets-configuration TLV.

ets-recommend - Include DCBX ets-recommendation TLV.

pfc - Include DCBX priority flow control TLV.

Default Setting

manual

Command Mode

Interface Config, Global Config

5.13 VTP (VLAN Trunking Protocol) Commands

5.13.1 Show Commands

5.13.1.1 show vtp counters

This command displays the VTP packet statistics.

Syntax

show vtp counters

Default Setting

None

Command Mode

Privileged Exec

Display Message

Summary advertisements received: Number of summary advertisements received by this switch on its trunk ports.

Subset advertisements received: Number of subset advertisements received by this switch on its trunk ports.

Request advertisements received: Number of advertisement requests received by this switch on its trunk ports.

Summary advertisements transmitted: Number of summary advertisements sent by this switch on its trunk ports.

Subset advertisements transmitted: Number of subset advertisements sent by this switch on its trunk ports.

Request advertisements transmitted: Number of advertisement requests sent by this switch on its trunk ports.

Number of config revision errors: Number of revision errors.

Number of config digest errors: Number of MD5 digest errors.

446



5.13.1.2 show vtp password

This command displays the VTP domain password.

C.	/ntax
51	ntax/

show vtp password

Default Setting

None

Command Mode

Privileged Exec

Display Message

VTP Password: Displays the VTP domain password.

5.13.1.3 show vtp status

This command displays the VTP domain status.

Syntax]		
show vtp	status		

Default Setting

None

Command Mode

Privileged Exec

Display Message

VTP Status: Indicates whether VTP is enabled or disabled.

VTP Version: Displays the VTP version operating on the switch.

Configuration Revision: Displays the current configuration revision number on this switch.

Maximum VTP supported VLANs: Maximum number of VLANs supported locally.

VTP support VLAN number: Number of existing VLANs.

VTP Operating Mode: Displays the VTP operating mode, which can be server, client, or transparent.

VTP Domain Name: Displays the name that identifies the administrative domain for the switch.

VTP Pruning Mode: Displays whether pruning is enabled or disabled.

VTP V2 Mode: Displays if VTP version 2 mode is enabled. By default, all VTP version 2 switches operate in version 1 mode.

MD5 digest: Displays the checksum values for the VTP domain status.

Configuration last modified: Displays the time stamp of the last configuration modification and the IP address of the switch that caused the configuration change to the database.

Local updater ID: Displays the Local updater ID for the VTP domain status.

5.13.1.4 show vtp trunkport

This command displays the VTP trunkport status.

Syntax

show vtp trunkport

Default Setting

None

Command Mode

Privileged Exec

Display Message

Port: Displays the interface number.

Trunkport: Displays the trukport status (enable or disable) on the interface number.

448

5.13.2 Configuration Commands

5.13.2.1 **vtp**

This command uses to configure global VTP administrative mode.

Syntax	
vtp no vtp	
no vtp	

no - This command disables global VTP administrative mode.

Default Setting

Disabled

Command Mode

5.13.2.2 vtp domain

This command uses to set VTP administrative domain name.

<string> - Configures the string for domain name. (maximum length 32 bytes)

 ${\bf no}$ - This command resets the domain name to NULL.

The system disables the VTP for its initialization.

The maximum length of administrative domain name is 32 bytes.

The system's default administrative domain name is NULL.

Default Setting

None Command Mode Global Config

5.13.2.3 vtp mode

This command uses to set VTP device mode. There are theree modes you can configure, **Client**, **Server**, and **Transparent**.

Syntax	
Syntax	

vtp mode { client | server | transparent } no vtp mode

<client> - This command set client mode for VTP.
<server> - This command set server mode for VTP.
<transparent> - This command set transparent mode for VTP.
no - This command resets the VTP mode to default value.

Default Setting

Server

Command Mode

Global Config

5.13.2.4 vtp version

Use the no vtp version to reset the VTP version number to default value..

yntax	
p version <1-2>	
o vtp version	

no - This command resets the VTP version to default value.

Default Setting

1

Command Mode

5.13.2.5 vtp password

This command uses to configure the VTP administrative domain password.

Syntax			
vtp passv	word <password></password>		
no vtp pa	issword		

<password> - Configures VTP administrative domain password.(Max. length 64 bytes)

no - This command resets the VTP domain password to default value.

Default Setting

None

Command Mode

Global Config

5.13.2.6 vtp pruning

This command uses to configure the adminstrative domain to permit pruning

Syntax	
vtp pruning no vtp pruning	

no - This command resets the pruning mode to default value.

Default Setting

Disabled

Command Mode

5.13.2.7 vtp trunkport

This command uses to configure the adminstrative domain trunk port for all of interfaces.

Syntax	c l	
vtp trunkp	hkport all	
no vtp tru	trunkport all	

no - This command resets the adminstrative domain trunk port to default value.

Default Setting

Disabled

Command Mode

Global Config

This command uses to configure the adminstrative domain trunk port on specific interfaces.

Syntax		
vtp trunkp	port	
no vtp tru	Jnkport	

no - This command resets the adminstrative domain trunk port to default value.

Default Setting

Disabled

Command Mode

5.14 **Protected Ports Commands**

5.14.1 Show Commands

5.14.1.1 show switchport protected

This command displays the status of all the interfaces, including protected and unprotected interfaces.

Syntax

show switchport protected [<0-2>]

Default Setting

None

Command Mode

Privileged Exec

Display Message

Name: An name of the protected port group.

Member Ports: List of ports, which are configured as protected for the group identified with <groupid>. If no port is configured as protected for this group, this field is blank.



5.14.1.2 show interface switchport protected

This command displays the status of the interface (protected/unprotected) under the groupid.

Syntax

show interface switchport protected <slot/port> <groupid>

Default Setting

None

Command Mode

Privileged Exec

Display Message

Name: An name of the protected port group.

Protected: Indicates whether the interface is protected or not. It shows TRUE or FALSE. If the group is a multiple groups then it shows TRUE in Group <groupid>.

5.14.2 Configuration Commands

5.14.2.1 switchport protected

This command used to modify a protected port group name. The <groupid> parameter identifies the set of protected ports. Use the name <name> pair to assign a name to the protected port group. The name can be up to 32 alphanumeric characters long, including blanks. The default is blank.



Port protection occurs within a single switch. Protected port configuration does not affect traffic between ports on two different switches. No traffic forwarding is possible between two protected ports.

Syntax

switchport protected <0-2> name <name> no switchport protected <0-2> name

<name> - Assigns a name to the protected port group.

no - Remove a name from the protected port group.

Default Setting

None

Command Mode

Global Config

This command uses to add an interface to a protected port group. The <groupid> parameter identifies the set of protected ports to which this interface is assigned. You can only configure an interface as protected in one group.

Syntax

switchport protected <0-2> no switchport protected <0-2>

no - This command uses to configure a port as unprotected.

Default Setting

None

Command Mode

5.15 Static MAC Filtering Commands

5.15.1 Show Commands

5.15.1.1 show mac-addr-table static

This command displays the Static MAC Filtering information for all Static MAC Filters. If you select <all>, all the Static MAC Filters in the system are displayed. If you supply a value for <macaddr>, you must also enter a value for <vlan-id>, and the system displays Static MAC Filter information only for that MAC address and VLAN.

Syntax

show mac-addr-table static [<macaddr> <vlan-id>]

<macaddr> - Static MAC address.

<vlah.id> - VLAN ID. The range of VLAN ID is 1 to 4093.

Default Setting

None

Command Mode

Privileged Exec

Display Message

MAC Address: Is the MAC Address of the static MAC filter entry.

VLAN ID: Is the VLAN ID of the static MAC filter entry.

Source Port(s): Indicates the source port filter set's slot and port(s).

5.15.2 Configuration Commands

5.15.2.1 macfilter

This command adds a static MAC filter entry for the MAC address <macaddr> on the VLAN <vlan-id>. The value of the <macaddr> parameter is a 6-byte hexadecimal number in the format of b1:b2:b3:b4:b5:b6.

The restricted MAC Addresses are: 00:00:00:00:00:00, 01:80:C2:00:00:00 to 01:80:C2:00:00:0F, 01:80:C2:00:00:20 to 01:80:C2:00:00:21, and FF:FF:FF:FF:FF:FF. The <vlan-id> parameter must identify a valid VLAN. You can create up to 100 static MAC filters.

Syntax

macfilter <macaddr> <vlan-id> no macfilter <macaddr> <vlan-id>

<macaddr> - Specified a 6-byte hexadecimal number in the format of b1:b2:b3:b4:b5:b6.

<vlan-id> - VLAN ID. The range of VLAN ID is 1 to 4093.

no - This command removes all filtering restrictions and the static MAC filter entry for the MAC address <macaddr> on the VLAN <vlan-id>.

Default Setting

None

Command Mode

5.15.2.2 macfilter addsrc

This command adds the interface to the source filter set for the MAC filter with the MAC address of <macaddr> and VLAN of <vlan-id>. The <macaddr> parameter must be specified as a 6-byte hexadecimal number in the format of b1:b2:b3:b4:b5:b6. The <vlan-id> parameter must identify a valid VLAN.

Cuntor	
Syntax	x

macfilter addsrc <macaddr> <vlan-id> no macfilter addsrc <macaddr> <vlan-id>

<macaddr> - Specified a 6-byte hexadecimal number in the format of b1:b2:b3:b4:b5:b6.

<vlan-id> - VLAN ID. The range of VLAN ID is 1 to 4093.

no - This command removes a port from the source filter set for the MAC filter with the MAC address of <macaddr> and VLAN of <vlan-id>.

Default Setting

None

Command Mode

5.15.2.3 macfilter addsrc all

This command adds all interfaces to the source filter set for the MAC filter with the MAC address of <macaddr> and <vlan-id>. You must specify the <macaddr> parameter as a 6-byte hexadecimal number in the format of b1:b2:b3:b4:b5:b6. The <vlan-id> parameter must identify a valid VLAN.

Sv	'n	t:	Y	

macfilter addsrc all <macaddr> <vlan-id> no macfilter addsrc all <macaddr> <vlan-id>

<macaddr> - Specified a 6-byte hexadecimal number in the format of b1:b2:b3:b4:b5:b6.

<vlan-id> - VLAN ID. The range of VLAN ID is 1 to 4093.

no - This command removes all interfaces to the source filter set for the MAC filter with the MAC address of <macaddr> and VLAN of <vlan-id>.

Default Setting

None

Command Mode

5.16 System Utilities

5.16.1 clear

5.16.1.1 clear arp

This command causes all ARP entries of type dynamic to be removed from the ARP cache.

Syntax	
clear arp	þ

Default Setting

None

Command Mode

Privileged Exec

5.16.1.2 clear traplog

This command clears the trap log.

Syntax			
clear trap	olog		

Default Setting

None

Command Mode



5.16.1.3 clear eventlog

This command is used to clear the event log, which contains error messages from the system.

Syntax										
clear eve	entlo	og								

Default Setting

None

Command Mode

Privileged Exec

5.16.1.4 clear logging buffered

This command is used to clear the message log maintained by the switch. The message log contains system trace information.

Syntax

clear logging buffered

Default Setting

None

Command Mode



5.16.1.5 clear config

This command resets the configuration to the factory defaults without powering off the switch. The switch is automatically reset when this command is processed. You are prompted to confirm that the reset should proceed.

Syntax	x	
clear con	config	

Default Setting

None

Command Mode

Privileged Exec

5.16.1.6 clear pass

This command resets all user passwords to the factory defaults without powering off the switch. You are prompted to confirm that the password reset should proceed.

Syntax		
clear pas	S	

Default Setting

None

Command Mode



5.16.1.7 clear counters

This command clears the stats for a specified <slot/port> or for all the ports or for the entire switch based upon the argument.

Syntax

clear counters [<slot/port> | port-channel <portchannel-id> | all]

<**slot/port> -** is the desired interface number.

<portchannel-id> - is the desired port-channel ID. The port-channel ID is range from 1 to 64.

all - All interfaces.

Default Setting

None

Command Mode

Privileged Exec

5.16.1.8 clear dns

This command sets the DNS configuration to default value. The command will only clear the DNS statistics(used option command **counter**) or only clear all entries from the DNS cache(used option command **cache**).

Syntax

clear dns [counter | cache]

counter - this command clear the DNS statistics.

cache - this command clear all entries from the DNS cache.

Default Setting

None

Command Mode

5.16.1.9 clear cdp

This command is used to clear the CDP neighbors information and the CDP packet counters.

Syntax	x l	
clear co	dp [traffic]	

traffic - this command is used to clear the CDP packet counters.

Default Setting

None

Command Mode

Privileged Exec

5.16.1.10 clear vlan

This command resets VLAN configuration parameters to the factory defaults.

Syntax				
clear vlar	า			

Default Setting

None

Command Mode



5.16.1.11 clear igmp snooping

This command clears the tables managed by the IGMP Snooping function and will attempt to delete these entries from the Multicast Forwarding Database.

Syntax

clear igmp snooping

Default Setting

None

Command Mode

Privileged Exec

5.16.1.12 clear port-channel

This command clears all port-channels (LAGs).

Syntax

clear port-channel

Default Setting

None

Command Mode

5.16.1.13 clear ip filter

This command is used to clear all ip filter entries.

Syntax	2																				
clear ip fi	filte	filte	te	er																	

Default Setting

None

Command Mode

Privileged Exec

5.16.1.14 clear dot1x authentication-history

This command resets the 802.1x authenticaiton-history.

Syntax

clear dot1x authentication-history [<slot/port>]

<slot/port> - is the desired interface number.

Default Setting

None

Command Mode



5.16.1.15 clear dot1x statistics

This command resets the 802.1x statistics for the specified port or for all ports.

clear dot1x statistics {all | <slot/port>}

<slot/port> - is the desired interface number.

all - All interfaces.

Default Setting

None

Command Mode

Privileged Exec

5.16.1.16 clear radius statistics

This command is used to clear all RADIUS statistics.

Syntax
Syman

clear radius statistics

Default Setting

None

Command Mode



5.16.1.17 clear domain-list

This command is used to clear all entries domain names for incomplete host names.

Syntax					

clear domain-list

Default Setting

None

Command Mode

Privileged Exec

5.16.1.18 clear hosts

This command is used to clear all static host name-to-address mapping.

Syntax			
clear ho	sts		

Default Setting

None

Command Mode



5.16.1.19 clear port-security dynamic address

This command is used to clear the Dynamic MAC address by using the specified port (**interface** <**slot/port**>) or mac address (**address** <**mac-addr**>).

Syntax

clear port-security dynamic {address <mac-addr> | interface <slot/port> }

<mac-addr> - mac address you want to remove.

<slot/port> - mac address learning on this interface will be removed.

Default Setting

None

Command Mode

Privileged Exec

5.16.1.20 clear ip arp-cache

This command causes all ARP entries of type dynamic to be removed from the ARP cache. If

the gateway keyword is specified, the dynamic entries of type gateway are purged as well. If interface keyword is specified, he dynamic entries of that interface on the ARP cache Table are purged.

Syntax

clear ip arp-cache [gateway | interface {<slot/port> | vlan <vlan-id>}]

<slot/port> - Interface number.

<vlan-id> - The VLAN interface number. The range of VLAN ID is 1 to 4093.

Default Setting

None

Command Mode

5.16.1.21 clear lldp statistics

This command will use to reset all LLDP statistics.

Syntax

clear IIdp statistics

Default Setting

None

Command Mode

Privileged Exec

5.16.1.22 clear lldp remote-data

This command will use to delete all information from the LLDP remote data table.

Syntax

clear IIdp remote-data

Default Setting

None

Command Mode



5.16.1.23 enable passwd

This command changes Privileged EXEC password.

Syntax

enable passwd 0 <password>

0 - Plain text password

Default Setting

None

Command Mode

Global Config.

5.16.1.24 enable passwd encrypted

This command allows the administrator to transfer the enable password between devices without having to know the password. The *<password>* parameter must be exactly 128 hexidecimal characters.

Syntax

enable passwd 7 <password>

7 - entrypted password

Default Setting

None

Command Mode

Global Config.



5.16.1.25 clear ipv6 neighbors

This command will use to clear all entries IPv6 neighbor table or an entry on a specific interface. Use the <slot/port> parameter to specify the interface.

Syntax

clear ipv6 neighbors [{<slot/port> | vlan <vlan-id>]

<slot/port> - Specify the interface.

<vlan-id> - Specifies the VLAN interface. The range of the VLAN ID is 1 to 4093.

Default Setting

None

Command Mode

Privileged Exec

5.16.1.26 clear ipv6 statistics

This command will use to clear IPv6 statistics for all interfaces or for a specific interface, including loopback and tunnel interfaces. IPv6 statistics display in the output of the show ipv6 traffic command. If you do not specify an interface, the counters for all IPv6 traffic statistics reset to zero.

Syntax

clear ipv6 statistics [{<slot/port> | loopback <loopback-id> | tunnel <tunnel-id> | vlan <vlan-id>}]

<slot/port> - Specify the interface.

<loopback-id > - Specify loopback Interface ID. Range 0 -7.

<tunnel-id > - Specify the Tunnel ID. Range 0 -7.

<vlan-id> - Specifies the VLAN interface. The range of the VLAN ID is 1 to 4093.

Default Setting

None

Command Mode

Privileged Exec

5.16.1.27 clear ipv6 dhcp

This command will use to clear DHCPv6 statistics for all interfaces or for a specific interface. Use the <slot/port> parameter to specify the interface.

Syntax

clear ipv6 dhcp {statistics | interface {<slot/port> | vlan <vlan-id>} statistics}

<slot/port> - Specify the interface.

<vlan-id> - Specifies the VLAN interface. The range of the VLAN ID is 1 to 4093.

Default Setting

None

Command Mode



5.16.2 copy

This command uploads and downloads to/from the switch. Local URLs can be specified using tftp or xmodem. The following can be specified as the source file for uploading from the switch: startup config (startup-config), event log (eventlog), message log (msglog) and trap log (traplog). A URL is specified for the destination.

The command can also be used to download the startup config or code image by specifying the source as a URL and destination as startup-config or image respectively.

The command can be used to the save the running config to flash by specifying the source as running-config and the destination as startup-config {*filename*}.

The command can also be used to download ssh key files as sshkey-rsa, sshkey-rsa2, and sshkey-dsa and http secure-server certificates as sslpem-root, sslpem- server, sslpem-dhweak, and sslpem-dhstrong.

5.16.2.1 Upload file from switch

Syntax

copy startup-config <url> <sourcefilename> copy {errorlog | log | traplog | cpu-pkt-capture} <url> copy script <sourcefilename> <url> copy image <filename> <url>

where <url>={xmodem | tftp://ipaddr/path/file | ftp://user:pass@ipaddr/path/file}

<sourcefilename> - The filename of a configuration file or a script file.

<url> - xmodem, tftp://ipaddr/path/file or ftp://user:pass@ipaddr/path/file.

errorlog - error crash dump Log file.

log - message Log file.

traplog - trap Log file.

cpu-pkt-capture - The CPU packets capture file.

<filename> - Operation code file name.

Default Setting

None

Command Mode

5.16.2.2 Download file to switch

Syntax

copy <url> startup-config <destfilename> copy <url> image <destfilename> copy <url> {sshkey-rsa1 | sshkey-rsa2 | sshkey-dsa} copy <url> {sslpem-root | sslpem-server | sslpem-dhweak | sslpem-dhstrong} copy <url> script <destfilename>

where <url>={xmodem | tftp://ipaddr/path/file | ftp://user:pass@ipaddr/path/file }

<destfilename> - name of the image file or the script file.

<url> - xmodem, tftp://ipaddr/path/file or ftp://user:pass@ipaddr/path/file.</rl>

sshkey-rsa1 - SSH RSA1 Key file.

sshkey-rsa2 - SSH RSA2 Key file.

sshkey-dsa - SSH DSA Key file.

sslpem-root - Secure Root PEM file.

sslpem-server - Secure Server PEM file.

sslpem-dhweak - Secure DH Weak PEM file.

sslpem-dhstrong - Secure DH Strong PEM file.

Default Setting

None

Command Mode

5.16.2.3 Write running configuration file into flash or remote server

Syntax				
copy running-config startup-config [filename]				
copy running-config <url></url>				

<filename> - name of the configuration file.

<url> - xmodem, tftp://ipaddr/path/file or ftp://user:pass@ipaddr/path/file.

Default Setting

None

Command Mode

Privileged Exec

5.16.2.4 This command upload or download the pre-login banner file

Syntax				
copy cliba	anner <url></url>			
copy <url< th=""><th>anner <url> l> clibanner</url></th><td></td><th></th><th></th></url<>	anner <url> l> clibanner</url>			
no clibani	ner			

<url> - xmodem, tftp://ipaddr/path/file or ftp://user:pass/ipaddr/path/file.</rl>

no - Delete CLI banner.

Default Setting

None

Command Mode



5.16.3 delete

This command is used to delete a configuration or image file.

Syntax			
delete <fi< th=""><th>ilename></th><th></th><th></th></fi<>	ilename>		

<filename> - name of the configuration or image file.

Default Setting

None

Command Mode



5.16.4 dir

This command is used to display a list of files in Flash memory.

Syntax			
dir [config] opcode [<filename>]]</filename>		

<filename> - name of the configuration or image file.

config - configuration file.

opcode - run time operation code.

Default Setting

None

Command Mode

Privileged Exec

Display Message

Column Heading	Description
date	The date that the file was created.
file name	The name of the file.
file type	File types: Boot-Rom, Operation Code, and Config file.
startup	Shows if this file is used when the system is started.
size	The length of the file in bytes.



5.16.5 whichboot

This command is used to display which files were booted when the system powered up.

Syntax			
whichboo	ot		

Default Setting

None

Command Mode

Privileged Exec

5.16.6 boot-system

This command is used to specify the file or image used to start up the system.

Syntax

boot-system {config | opcode} <filename>

<filename> - name of the configuration or image file.

config - configuration file.

opcode - run time operation code.

Default Setting

None

Command Mode



5.16.7 ping

5.16.7.1 ping <ipaddress|host>

This command checks if another computer is on the network and listens for connections. To use this command, configure the switch for network (in-band) connection. The source and target devices must have the ping utility enabled and running on top of TCP/IP. The switch can be pinged from any IP workstation with which the switch is connected through the default VLAN (VLAN 1), as long as there is a physical path between the switch and the workstation. The terminal interface sends, three pings to the target station.

Syntax

ping <ipaddress|hostname> count <0-20000000> [size <32-512>] ping <ipaddress|hostname> size <32-512> [count <0-20000000>]

< ipaddress|hostname> - a host name or an IP address.

<0-20000000> - number of pings (Range: 0 - 20000000). Note that 0 means infinite.

<size> - packet size (Range: 32 - 512).

Default Setting

Count = 5

Size = 32

Command Mode



5.16.7.2 ping ipv6 <ipv6-address|hostname>

This command use to determine whether another computer is on the network. To use the command, configure the switch for network (in-band) connection. The source and target devices must have the ping utility enabled and running on top of TCP/IP. The switch can be pinged from any IP workstation with which the switch is connected through the default VLAN (VLAN 1), as long as there is a physical path between the switch and the workstation. The terminal interface sends three pings to the target station. Use the <ipv6-address> parameter to ping an interface by using the global IPv6 address of the interface, or use the <hostname> parameter to ping a interface by using the hostname of the target. Use the optional size keyword to specify the size of the ping packet.

Syntax

ping ipv6 <ipv6-address|hostname> [size <datagram-size>]

<ipv6-address|hostname> - A global IPv6 address or valid hostname.

<datagram-size> - Datagram size. Range 48 - 2048.

Default Setting

None

Command Mode

Privileged Exec

482



5.16.7.3 ping ipv6 interface

This command use to determine whether another computer is on the network. To use the command, configure the switch for network (in-band) connection. The source and target devices must have the ping utility enabled and running on top of TCP/IP. The switch can be pinged from any IP workstation with which the switch is connected through the default VLAN (VLAN 1), as long as there is a physical path between the switch and the workstation. The terminal interface sends three pings to the target station. Use the interface keyword to ping an interface by using the link-local address. You can use a loopback, tunnel, or logical interface as the source. Use the optional size keyword to specify the size of the ping packet.

Syntax

ping ipv6 interface {<slot/port> | serviceport | switchport | tunnel <tunnel-id>} | loopback <loopback-id>} {<link-local-address>} [size <datagram-size>]

<slot/port> - Specify the interface.

<tunnel-id > - Specify the Tunnel ID. Range 0 -7.

<loopback-id > - Specify loopback Interface ID. Range 0 -7.

k-local-address> - Specify link-local address.

<ipv6-address> - Specify the IPv6 address of the device.

<datagram-size> - Datagram size. Range 48 - 2048.

Default Setting

None

Command Mode

5.16.8 traceroute

5.16.8.1 traceroute

Use the traceroute command to discover the routes that packets actually take when traveling to their destination through the network on a hop-by-hop basis. Traceroute continues to provide a synchronous response when initiated from the CLI.

Syntax

traceroute <ipaddr|hostname> [initTtl <initTtl>] [maxTtl <maxTtl>] [interval <interval>] [count <count>]

<ipaddr|hostname> - The IP address or destination host you want to trace.

<initTtl> - The Use initTtl to specify the initial time-to-live (TTL), the maximum number of router hops between the local and remote system. Range is 1 to 255.

<maxTtl> - Use maxTtle to specify the maximum TTL. Range is 1 to 255.

<interval> - Use interval to specify the time between probes, in seconds. Range is 1 to 60 seconds.

<count> - Use the optional count parameter to specify the number of probes to send for each TTL value. Range is 1 to 10 probes.

Default Setting

None

Command Mode

Previledge Mode

5.16.8.2 traceroute ipv6

This command is used to discover the routes that packets actually take when traveling to their destination through the network on a hop-by-hop basis. The <ipv6-address|hostname> parameter must be a valid IPv6 address|hostname.

Syntax

traceroute ipv6 <ipv6-address|hostname > [initTtl <initTtl>] [maxTtl <maxTtl>] [interval <interval>] [count <count>]

<ipv6-address|hostname> - A valid IPv6 address or hostname.

<ipaddr> - The IP address or destination host you want to trace.

<initTtl> - The Use initTtl to specify the initial time-to-live (TTL), the maximum number of router hops between the local and remote system. Range is 1 to 255.

<maxTtl> - Use maxTtle to specify the maximum TTL. Range is 1 to 255.

<interval> - Use interval to specify the time between probes, in seconds. Range is 1 to 60 seconds.

<count> - Use the optional count parameter to specify the number of probes to send for each TTL value. Range is 1 to 10 probes.

Default Setting

None

Command Mode



5.16.9 logging cli-command

This command enables the CLI command Logging feature. The Command Logging component enables the switch to log all Command Line Interface (CLI) commands issued on the system.

Syntax

logging cli-command

Default Setting

None

Command Mode

Global Config

5.16.10 calendar set

This command is used to set the system clock.

Syntax

calendar set <mm/dd/yyy> <hh:mm:ss>

<mm/dd/yyyy> - Date Time <mm/dd/yyyy> format. (Month <1-12>. Day <1-31>. Year <2000-2037><hh:mm:ss> - hh in 24-hour format (Range: 0 - 23), mm (Range: 0 - 59), ss (Range: 0 - 59)

Default Setting

None

Command Mode

Privileged Exec

5.16.11 reload

This command resets the switch without powering it off. Reset means that all network connections are terminated and the boot code executes. The switch uses the stored configuration to initialize the switch. You are prompted to confirm that the reset should proceed. A successful reset is indicated by the LEDs on the switch.

Syntax			
reload [<w< th=""><th>varm>]</th><th></th><th></th></w<>	varm>]		

<warm> - To only restart the operation software without rebooting whole system.

Default Setting

None

Command Mode



5.16.12 configure

This command is used to activate global configuration mode.

Syntax		
configure		

Default Setting

None

Command Mode

Privileged Exec

5.16.13 disconnect

This command is used to close a telnet session.

Syntax

disconnect {<0-58> | all}

<0-58> - telnet session ID.

all - all telnet sessions.

Default Setting

None

Command Mode



5.16.14 hostname

This command is used to set the prompt string.

Syntax
c ymax

hostname <prompt_string>

<prompt_string> - Prompt string.

Default Setting

Quanta

Command Mode

Global Config

5.16.15 quit

This command is used to exit a CLI session.

Syntax		
quit		

Default Setting

None

Command Mode

5.16.16 cablestatus

This command returns the status of the specified port.

Syntax	
Syntax	

cablestatus <slot/port>

<slot/port> - Interface Number.

Default Setting

None

Command Mode

Privileged Exec

Display Message

Cable Status: One of the following statuses is returned:

Normal: The cable is working correctly.

Open: The cable is disconnected or there is a faulty connector.

Short: There is an electrical short in the cable.

Cable Test Failed: The cable status could not be determined. The cable may in fact be working.

Cable Length: If this feature is supported by the PHY for the current link speed, the cable length is displayed as a range between the shortest estimated length and the longest estimated length. Note that if the link is down and a cable is attached to a 10/100 Ethernet adapter, then the cable status may display as Open or Short because some Ethernet adapters leave unused wire pairs unterminated or grounded. Unknown is displayed if the cable length could not be determined.

5.16.17 AutoInstall Commands

The AutoInstall feature enables the automatic update of the image and configuration of the switch. This feature enables touchless or low-touch provisioning to simplify switch configuration and imaging.

AutoInstall includes the following support:

- Downloading an image from TFTP server using DHCP option 125. The image update can
 result in a downgrade or upgrade of the firmware on the switch.
- Automatically downloading a configuration file from a TFTP server when the switch is booted with no saved configuration file.

When the switch boots, it attempts to obtain an IP address from a network DHCP server. The response from the DHCP server includes the IP address of the TFTP server where the image and configuration flies are located.

After acquiring an IP address and the additional relevant information from the DHCP server, the switch downloads the image file or configuration file from the TFTP server. A downloaded image is utomatically installed. A downloaded configuration file is saved to non-volatile memory

5.16.17.1 Show Commands

5.16.17.1.1 show autoinstall

This command displays the current status of the AutoInstall process.

Syntax

show autoinstall

Default Setting

None

Command Mode

Privileged Exec

Display Message

AutoInstall Operation: Displays the autoinstall operation is started or stoped.

AutoInstall Persistent Mode: Displays the autoinstall persistently for next reboot cycle.

AutoSave Mode: Displays the autoinstall persistently for next reboot cycle.

AutoReboot Mode: Displays the auto-save of downloaded configuration.

AutoUpgrade Mode: Displays the upgrade mode, which is used to allow to download the newer image.

AutoInstall Retry Count: Retry Count The number of times the switch has attempted to contact the TFTP server during the current AutoInstall session.

5.16.17.2 AutoInstall State: The status of the current or most recently completed AutoInstall session.Configuration Commands

5.16.17.2.1 boot-system autoinstall

Use this command to operationally start or stop the AutoInstall process on the switch. The command is non-persistent and is not saved in the startup or running configuration file.

Syntax

boot-system autoinstall { start | stop }

Default Setting

None

Command Mode

Privileged Exec

Display Message

None

5.16.17.2.2 boot-system host autoinstall

Use this command to enable AutoInstall on the switch for the next reboot cycle. The command does not change the current behavior of AutoInstall and saves the command to NVRAM.

Syntax

boot-system host autoinstall no boot-system host autoinstall

no - Use this command to disable AutoInstall for the next reboot cycle.

Default Setting

None

Command Mode

Privileged Exec

Display Message

None

5.16.17.2.3 boot-system host autosave

Use this command to automatically save the downloaded configuration file to the startup-config file on the switch. When autosave is disabled, you must explicitly save the downloaded configuration to non-volatile memory. If the switch reboots and the downloaded configuration has not been saved, the AutoInstall process begins, if the feature is enabled.

boot-system host autosave no boot-system host autosave

no - Use this command to disable automatically saving the downloaded configuration on the switch.

Default Setting

None

Command Mode

Privileged Exec

Display Message

None

5.16.17.2.4 boot-system host autoreboot

Use this command to allow the switch to automatically reboot after successfully downloading an image. When auto reboot is enabled, no administrative action is required to activate the image and reload the switch.

This command only work on the autoupgrade is enable.

Syntax boot-system host autoreboot no boot-system host autoreboot

no - Use this command to prevent the switch from automatically rebooting after the image is downloaded by using the AutoInstall feature.

Default Setting

None

Command Mode

Privileged Exec

Display Message

None

5.16.17.2.5 boot-system host upgrade

Use this command to allow the switch only to upgrade the newer image version.

Syntax

boot-system host upgrade no boot-system host upgrade

no - Use this command to disable this function.

Default Setting

None

Command Mode

Privileged Exec

Display Message

None

5.16.17.2.6 boot-system host retrycount

Use this command to set the number of attempts to download a configuration file from the TFTP server.

Syntax

boot-system host retrycount <1-3>

Default Setting

3

Command Mode

Privileged Exec

Display Message

None



5.16.18 Capture CPU packet Commands

5.16.18.1 Show commands

5.16.18.1.1 show capture

Use this command to display packets captured and save to RAM, It is possible to capture and save into RAM, packets that are received or transmitted through the CPU. A maximum 128 packets can be saved into RAM per capturing session. A maximum 128 bytes per packet can be saved into the RAM. If a packet holds more than 128 bytes, only the first 128 bytes are saved; data more than 128 bytes is skipped and cannot be displayed in the CLI.

Capturing packets is stopped automatically when 128 packets are captured and have not yet been displayed during a capture session. Captured packets are not retained after a reload cycle.

Syntax	
show cap	ture [packets]

<packets> - Specifies this parameter to display the captured packets on the CLI.

Default Setting

None

Command Mode

Privileged Exec

Display Message

Operational Status: Displays capture status.

Current Capturing Type: Displays the current capturing type. Possible types are Line, File, and Remote.

Capturing Traffic Mode: Displays the capturing traffic mode. Possible modes are Rx, Tx, or Tx/Rx.

Line Wrap Mode: Displays the line wrap mode for Line capturing type. Default is disabled.

RPCAP Listening Port: Displays the pcap listening port number. Default listening port number is 2002.

RPCAP dump file size (KB): Disaply the capture packet file size. Default file size is 512KB.

Capturing Interface: Display the capturing interface.

5.16.18.2 Configuration Command

5.16.18.2.1 capture start

Use this command to manually start capturing CPU packets for packets for trace. The packet capture operates in three modes: capture file, remote capture and capture line.

This command is not persistent across a reboot cycle.

. .	
Synta	аx

capture start [{all | received | transmit}]

<all> - Specifies all to capture packets for both transmitted and received packets.

<received> - Specifies received to capture only received packets.

<transmit> - Specifies transmit to capture only transmitted packets.

Default Setting

None

Command Mode

Privileged Exec

5.16.18.2.2 capture stop

Use this command to manually stop capturing CPU packets for packets for trace.

Syntax			
capture s	stop		

Default Setting

None

Command Mode

5.16.18.2.3 Capture packet to file, remote or line

Use this command to configure packet capture options. This command is persistent across a reboot cycle.

Syntax	
capture {	file remote line}

file – In the capture file mode, the captured packets are stored in a file on Flash. The maximum file size defaults to 512KB. The switch can transfer the file to a TFTP server via TFTP, FTP via CLI. The file is formatted in pcap format, is name cpu-pkt-capture.pcap, and can be examined using network analyzer tools such as Wireshark or Ethereal. Starting a file capture automatically terminates any remote capture sessions and line captureing. After the packet capture is activated, the capture proceeds until the capture file reaches its maimum size, or until the capture is stopped manually using CLI command "capture stop".

Remote – In the remote capture mode, the captured packets are redirected in real time to an external PC running the wireshark tool for Microsoft Windows. A packet capture server runs on the switch side and sends the captured packets via a TCP connection to the Wireshark tool. The remote capture can be enabled or disable using the CLI. There should be a Windows PC with the Wireshark tool to display the captured file. When using the remote capture mode, the switch does not sotre any captured data locally on its file system.

You can configure the IP port number for connecting Wireshark to the switch. The default port number is 2002. If a firewall is installed between the Wireshark PC and the switch, then these ports must be allowed to pass through the firewall.

If the client successfully connects to the switch, the CPU packets are sent to the client PC, then Wireshark receives the packets and displays them. This continues until the session is terminated by either end.

line – In the capture line mode, the captured packets are saved into the RAM and can be displayed on the CLI. Starting a line capture automatically terminates any remote capture dession and capturing into a file. There is a maximum 128 packets of maximum 128 btes that can be captured and displayed in Line mode.

Default Setting

Remote

Command Mode

Global Config



5.16.18.2.4 capture remote port

Use this command to configure file capture options. This command is persistent across a reboot cycle.

Synta	~
Synta	x

capture remote [port <port-id>]

<port-id> - Configure the listening port for remote Wireshark tool. The range of port ID is 1024 to 49151.

Default Setting 2002 Command Mode Global Config

5.16.18.2.5 capture file size

Use this command to configure file capture options. This command is persistent across a reboot cycle.

Syntax			
capture fi	ile [size <file-size>]</file-size>		

<file-size> - Configure the file size in KB. The range of file size is 2 to 512KB.

Default Setting 512 Command Mode Global Config



5.16.18.2.6 capture line warp

This command enables wrapping of captured packets in line mode when the captured packets reaches full capacity. This command is persistent across a reboot cycle.

yntax	
apture line [wrap]	
o capture line wrap	

Default Setting

Disable

Command Mode

Global Config

5.17 **DHCP Snooping Commands**

DHCP snooping is a security feature that monitors DHCP messages between a DHCP client and DHCP servers to filter harmful DHCP messages and to build a bindings database of {MAC address, IP address, VLAN ID, port} tuples that are considered authorized. You can enable DHCP snooping globally and on specific VLANs, and configure ports within the VLAN to be trusted or untrusted. DHCP servers must be reached through trusted ports.

The DHCP snooping binding table contains the MAC address, IP address, lease time, binding type, VLAN number, and interface information that corresponds to the local untrusted interfaces of a switch; it does not contain information regarding hosts interconnected with a trusted interface. An untrusted interface is an interface that is configured to receive messages from outside the network or firewall. A trusted interface is an interface that is configured to receive only messages from within the network.

DHCP snooping acts like a firewall between untrusted hosts and DHCP servers. It also gives you a way to differentiate between untrusted interfaces connected to the end-user and trusted interfaces connected to the DHCP server or another switch.

DHCP snooping enforces the following security rules:

- DHCP packets from a DHCP server (DHCPOFFER, DHCPACK, DHCPNAK, DHCPRELEASEQUERY) are dropped if received on an untrusted port.
- DHCPRELEASE and DHCPDECLINE messages are dropped if for a MAC address in the snooping database, but the binding's interface is other than the interface where the message was received.
- On untrusted interfaces, the switch drops DHCP packets whose source MAC address does not match the client hardware address. This feature is a configurable option.

The hardware identifies all incoming DHCP packets on ports where DHCP snooping is enabled. DHCP snooping is enabled on a port if (a) DHCP snooping is enabled globally, and (b) the port is a member of a VLAN where DHCP snooping is enabled. On untrusted ports, the hardware traps all incoming DHCP packets to the CPU. On trusted ports, the hardware forwards client messages and copies server messages to the CPU so that DHCP snooping can learn the binding.

You can enable the switch to operate as a DHCP Layer 2 relay agent to relay DHCP requests from clients to a Layer 3 relay agent or server. The Circuit ID and Remote ID can be added to DHCP requests relayed from clients to a DHCP server. This information is included in DHCP Option 82, as specified in sections 3.1 and 3.2 of RFC3046.

5.17.1 Show Commands

5.17.1.1 show ip dhcp snooping

This command displays the DHCP Snooping global configurations and per port configurations.

Syntax	
show ip c	dhcp snooping

Default Setting

None

Command Mode

Privileged Exec

Display Message

Interface: The interface for which data is displayed.

Trusted: If it is enabled, DHCP snooping considers the port as trusted. The factory default is disabled.

Log Invalid Pkts: If it is enabled, DHCP snooping application logs invalid packets on the specified interface.

5.17.1.2 show ip dhcp snooping binding

This command displays the DHCP Snooping binding entries. To restrict the output, use the following options:

- Dynamic: Restrict the output based on DCHP snooping.
- Interface: Restrict the output based on a specific interface.
- Static: Restrict the output based on static entries.
- VLAN: Restrict the output based on VLAN.

Syntax

show ip dhcp snooping binding [{static | dynamic}] [interface <slot/port>] [vlan id]

Default Setting

None

Command Mode

Privileged Exec

Display Message

MAC Address: Displays the MAC address for the binding that was added. The MAC address is the key to the binding database.

IP Address: Displays the valid IP address for the binding rule.

VLAN: The VLAN for the binding rule.

Interface: The interface to add a binding into the DHCP snooping interface.

Type: Binding type; statically configured from the CLI or dynamically learned.

Lease (Secs): he remaining lease time for the entry.



5.17.1.3 show ip dhcp snooping database

This command displays the DHCP Snooping configuration related to the database persistency.

Syntax

show ip dhcp snooping database

Default Setting

None

Command Mode

Privileged Exec

Display Message

Agent URL: Bindings database agent URL.

Write Delay: The maximum write time to write the database into local or remote.

Abort Timer: The maximum time to abort the database transfer process.

5.17.1.4 show ip dhcp snooping statistics

This command lists statistics for DHCP Snooping security violations on untrusted ports.

Syntax

show ip dhcp snooping statistics

Default Setting

None

Command Mode

Privileged Exec

Display Message

Interface: The IP address of the interface in slot/port format.

MAC Verify Failures: Represents the number of DHCP messages that were filtered on an untrusted interface because of source MAC address and client HW address mismatch.

Client Ifc Mismatch: Represents the number of DHCP release and Deny messages received on the different ports than learned previously.

DHCP Server Msgs Rec'd: Represents the number of DHCP server messages received on untrusted ports.

5.17.1.5 show ip dhcp snooping information all

This command display the summary of DHCP Option-82 configuration.



show ip dhcp snooping information all

Default Setting

None

Command Mode

5.17.1.6 show ip dhcp snooping information stats interface

This command display statistics specific to DHCP Option-82 configuration interface.

Syntax

show ip dhcp snooping information stats interface [<slot/port>]

<slot/port> - Interface number.

Default Setting

None

Command Mode

Privileged Exec

5.17.1.7 show ip dhcp snooping information agent-option vlan

This command display the DHCP Option-82 configuration specific to VLAN.

Syntax

show ip dhcp snooping information agent-option vlan <vlan-list>

<vlan-list> - Specifies VLAN ID in a list. The range of VLAN ID is 1 to 4093.

Default Setting

None

Command Mode

5.17.1.8 show ip dhcp snooping information vlan

This command display the DHCP Option-82 configuration specific to VLAN.

Syntax

show ip dhcp snooping information vlan <vlan-list>

<vlan-list> - Specifies VLAN ID in a list. The range of VLAN ID is 1 to 4093.

Default Setting

None

Command Mode

Privileged Exec

5.17.1.9 show ip dhcp snooping information circuit-id vlan

This command display the DHCP Option-82 circuit-id configuration specific to VLAN.

Syntax

show ip dhcp snooping information circuit-id vlan <vlan-list>

<vlan-list> - Specifies VLAN ID in a list. The range of VLAN ID is 1 to 4093.

Default Setting

None

Command Mode

5.17.1.10 show ip dhcp snooping information remote-id vlan

This command display the DHCP Option-82 remote-id configuration specific to VLAN.

Syntax

show ip dhcp snooping information remote-id vlan <vlan-list>

<vlan-list> - Specifies VLAN ID in a list. The range of VLAN ID is 1 to 4093.

Default Setting

None

Command Mode

Privileged Exec

5.17.1.11 show ip dhcp snooping information interface

This command display DHCP Option-82 configuration interface.

Syntax

show ip dhcp snooping information interface [<slot/port>]

<slot/port> - Specifies the interface number.

Default Setting

None

Command Mode

5.17.2 Configuration Commands

5.17.2.1 ip dhcp snooping

This command enables the DHCP Snooping globally.

Syntax	
ip dhcp sno no ip dhcp	

no - This command disables the DHCP Snooping globally.

Default Setting

Disabled

Command Mode

Global Config

5.17.2.2 ip dhcp snooping vlan

This command enables the DHCP Snooping on a list of comma-separated VLAN ranges.

ip dhcp snooping vlan <vlan-list> no ip dhcp snooping vlan <vlan-list>

<vlan-list> - Specifies VLAN ID in a list. The range of VLAN ID is 1 to 4093.

no - This command disables the DHCP Snooping on VLANs.

Default Setting

Disabled

Command Mode

5.17.2.3 ip dhcp snooping verify mac-address

This command enables the verification of the source MAC address with the client hardware address in the received DCHP message.

Syntax	,
Synca/	٤.

ip dhcp snooping verify mac-address no ip dhcp snooping verify mac-address

no - This command disables the verification of the source MAC address with the client hardware address.

Default Setting

Disabled

Command Mode

Global Config

5.17.2.4 ip dhcp snooping database

This command configures the persistent location of the DHCP Snooping database. This can be local or a remote file on a given IP machine.

Syntax

ip dhcp snooping database {local|tftp://hostIP/filename}

Default Setting

Local

Command Mode

5.17.2.5 ip dhcp snooping database write-delay

This command configures the interval in seconds at which the DHCP Snooping database will be persisted. The interval value ranges from 15 to 86400 seconds.

Syntax		Syntax
--------	--	--------

ip dhcp snooping database write-delay <in seconds> no ip dhcp snooping database write-delay

no - This command sets the write delay value to the default value.

Default Setting

300 seconds

Command Mode

Global Config

5.17.2.6 ip dhcp snooping database timeout

This command configures the DHCP snooping bindings store timeout in <15> to <86400> seconds. 0 is defined as an infinite duration.

Syntax

ip dhcp snooping database timeout <in seconds> no ip dhcp snooping database timeout

no - This command sets the timeout value to the default value.

Default Setting

300 seconds

Command Mode

5.17.2.7 ip dhcp snooping binding

This command configures the static DHCP Snooping binding..

Syntax

ip dhcp snooping binding <mac-address> vlan <vlan id> <ip address> interface <interface id> no ip dhcp snooping binding <mac-address>

no - This command removes the DHCP static entry from the DHCP Snooping database.

Default Setting

None

Command Mode

Global Config

5.17.2.8 ip dhcp snooping limit

This command controls the rate at which the DHCP Snooping messages come. The default rate is 15 pps with a range from 0 to 300 pps. The default burst level is 1 second with a range of 1 to 15 seconds.

Syntax

ip dhcp snooping limit {rate <pps> [burst interval <seconds>]} | none no ip dhcp snooping limit

no - This command sets the rate at which the DHCP Snooping messages come, and the burst level, to the defaults.

Default Setting

15 pps for rate limiting and 1 sec for burst interval

Command Mode

Interface Config

5.17.2.9 ip dhcp snooping log-invalid

This command controls the logging DHCP messages filtration by the DHCP Snooping application.

-	
Sy	ntax

ip dhcp snooping log-invalid no ip dhcp snooping log-invalid

no - This command disables the logging DHCP messages filtration by the DHCP Snooping application.

Default Setting

Disabled

Command Mode

Interface Config

5.17.2.10 ip dhcp snooping trust

This command configures the port as trusted.

Syntax

ip dhcp snooping trust no ip dhcp snooping trust

no - This command configures the port as untrusted.

Default Setting

Disabled

Command Mode

Interface Config



5.17.2.11 clear ip dhcp snooping binding

Use this command to clear all DHCP Snooping bindings on all interfaces or on a specific interface.

Syntax

clear ip dhcp snooping binding [interface <slot/port>]

<slot/port> - Specifies the interface number.

Command Mode

Privileged EXEC

5.17.2.12 clear ip dhcp snooping statistics

Use this command to clear all DHCP Snooping statistics.

Syntax

clear ip dhcp snooping statistics

Command Mode

Privileged EXEC

5.17.2.13 ip dhcp snooping information option

This command ip dhcp snooping information option enables the DHCP L2 option mode on the system.

Syntax

ip dhcp snooping information option no ip dhcp snooping information option

no - This command disables the DHCP L2 option mode.

Default Setting

Disabled

Command Mode

513



5.17.2.14 ip dhcp snooping information option

This command ip dhcp snooping information option enables the DHCP L2 option mode on the interface.

-	
Sy	ntax

ip dhcp snooping information option no ip dhcp snooping information option

no - This command disables the DHCP L2 option mode.

Default Setting

Disabled

Command Mode

Interface Config

5.17.2.15 ip dhcp snooping information option circuit-id

Use this command to enable the DHCP Snooping information option circuit-id on a range of VLANs.When enabled, the circuit ID is added in DHCP Option-82.

Use this command with **no** argument to disable the DHCP Snooping information option circuit-id on a range of VLANs. Clear the DHCP Option-82 circuit ID for a VLAN.

The circuit ID format should be in the form of LLLLVVVVXXYYZZ (LLLL: is the length from V to Z, VVVV: VLAN ID, XX is the Unit ID, YY is the function/module ID and ZZ is the Port number)

Synta	-
Synta	ĸ

ip dhcp snooping information option circuit-id vlan <vlan-list>

no ip dhcp snooping information option circuit-id vlan <vlan-list>

<vlan-list> - Specifies VLAN ID in a list. The range of VLAN ID is 1 to 4093.

no - Clear the DHCP Option-82 circuit ID for a VLAN..

Default Setting

Disabled

Command Mode

5.17.2.16 ip dhcp snooping information option remote-id

Use this command to enable the DHCP Snooping information option remote-id on a range of VLANs. When remote-id string is set using this command, all Client DHCP requests that fall under this service subscription are added with Option-82 Remote-id as the configured remote-id string.

Use this command with **no** argument to disable the DHCP Snooping information option remote-id on a range of VLANs. When remote-id string is reset using this command, the Client DHCP requests that fall under this service subscription are not added with Option-82 Remote-id.

The remote ID format should be in the form of LLLLXXXXX (LLLL: is the length from remote-id strings)

Syntax	
ip dhcp s	nooping information option remote-id <remoteid string=""> vlan <vlan-list></vlan-list></remoteid>
no ip dhc	p snooping information option remote-id vlan <vlan-list></vlan-list>

<vlan-list> - Specifies VLAN ID in a list. The range of VLAN ID is 1 to 4093.

no - Clear the DHCP Option-82 remoteld ID for a VLAN..

Default Setting

Disabled

Command Mode

Global Config

5.17.2.17 ip dhcp snooping information option vlan

Use this command to enable the DHCP Snooping information option on a range of VLANs.

Syntax

ip dhcp snooping information option vlan <vlan-list>

no ip dhcp snooping information option vlan <vlan-list>

<vlan-list> - Specifies VLAN ID in a list. The range of VLAN ID is 1 to 4093.

no - This command with **no** argument to disable the DHCP Snooping information option on a range of VLANs..

Default Setting

Disabled

Command Mode

5.17.2.18 ip dhcp snooping information option trust

Use this command to configure an interface as trusted for Option-82 reception.

poping information option trust
snooping information option trust

no - This command with **no** argument to configure an interface to default untrusted for Option-82 reception..

Default Setting

Disabled

Command Mode

5.18 IP Source Guard (IPSG) Commands

IP Source Guard (IPSG) is a security feature that filters IP packets based on source ID. The source ID may be either the source IP address or a {source IP address, source MAC address} pair. The DHCP snooping binding database and static IPSG entries identify authorized source IDs. You can configure:

- Whether enforcement includes the source MAC address.
- Static authorized source IDs.

Similar to DHCP snooping, this feature is enabled on a DHCP snooping untrusted Layer 2 port. Initially, all IP traffic on the port is blocked except for DHCP packets that are captured by the DHCP snooping process. When a client receives a valid IP address from the DHCP server, or when a static IP source binding is configured by the user, a per-port and VLAN Access Control List is installed on the port. This process restricts the client IP traffic to those source IP addresses configured in the binding; any IP traffic with a source IP address other than that in the IP source binding is filtered out. This filtering limits a host's ability to attack the network by claiming a neighbor host's IP address.

IPSG can be enabled on physical or LAG ports. IPSG is disabled by default. If you enable IPSG on a port where DHCP snooping is disabled or where DHCP snooping is enabled but the port is trusted, all IP traffic received on that port is dropped depending on the admin-configured IPSG entries. IPSG cannot be enabled on a port-based routing interface.

GUANTA COMPUTER INC.

5.18.1 Show Commands

5.18.1.1 show ip verify

This command displays the IPSG interface configurations on all ports.

Syntax

show ip verify [interface <slot/port>]

<slot/port> - Specifies the interface number.

Default Setting

None

Command Mode

Privileged Exec

Display Message

Interface: Interface address in slot/port format.

Filter Type: Is one of two values:

- ip-mac: User has configured MAC address filtering on this interface.
- **ip:** Only IP address filtering on this interface.

5.18.1.2 show ip verify source

This command displays the IPSG interface and binding configurations on all ports.

Syntax

show ip verify source [interface <slot/port>]

<slot/port> - Specifies the interface number.

Default Setting

None

Command Mode

Privileged Exec

Display Message

Interface: Interface address in slot/port format.

Filter Type: Is one of two values:

- ip-mac: User has configured MAC address filtering on this interface.
- **ip:** Only IP address filtering on this interface. •

IP Address: IP address of the interface.

MAC Address: If MAC address filtering is not configured on the interface, the MAC Address field is empty. If port security is disabled on the interface, then the MAC Address field displays "permit-all".

VLAN: The VLAN for the binding rule.

5.18.1.3 show ip source binding

This command displays the IPSG bindings.

Syntax

show ip source binding [{static | dhcp-snooping}] [interface <slot/port>] [vlan <vlan-id>]

Default Setting

None

Command Mode

Privileged Exec

Display Message

MAC Address: The MAC address for the entry that is added.

IP Address: The IP address of the entry that is added.

Type: Entry type; statically configured from CLI or dynamically learned from DHCP Snooping.

VLAN: VLAN for the entry.

Interface: IP address of the interface in slot/port format.

520

5.18.2 Configuration Commands

5.18.2.1 ip verify source

This command configures the IPSG source ID attribute to filter the data traffic in the hardware. Source ID is the combination of IP address and MAC address. Normal command allows data traffic filtration based on the IP address. With the "port-security" option, the data traffic will be filtered based on the IP and MAC addresses.

Syntax

ip verify source [port-security] no ip verify source [port-security]

no - This command disables the IPSG configuration in the hardware.

Default Setting

Disabled

Command Mode

Interface Config

5.18.2.2 ip verify binding

This command configures static IP source guard (IPSG) entries.

ip verify binding <mac-address> vlan <vlan-id> <ip address> interface <slot/port> no ip verify binding <mac-address> vlan <vlan-id> <ip address> interface <slot/port>

no - This command removes the IPSG static entry from the IPSG database.

Default Setting

None

Command Mode



5.19 Dynamic ARP Inspection (DAI) Command

Dynamic ARP Inspection (DAI) is a security feature that rejects invalid and malicious ARP packets. DAI prevents a class of man-in-the-middle attacks, where an unfriendly station intercepts traffic for other stations by poisoning the ARP caches of its unsuspecting neighbors. The miscreant sends ARP requests or responses mapping another station's IP address to its own MAC address.

To prevent ARP poisoning attacks, a switch must ensure that only valid ARP requests and responses are relayed. DAI prevents these attacks by intercepting all ARP requests and responses. Each of these intercepted packets is verified for valid MAC address to IP address bindings before the local ARP cache is updated or the packet is forwarded to the appropriate destination. Invalid ARP packets are dropped.

DAI determines the validity of an ARP packet based on valid MAC address to IP address bindings stored in a trusted database. This database is built at runtime by DHCP snooping, provided this feature is enabled on VLANs and on the switch. DAI relies on DHCP snooping. DHCP snooping listens to DHCP message exchanges and builds a binding database of valid {MAC address, IP address, VLAN, and interface} tuples. In addition, in order to handle hosts that use statically configured IP addresses, DAI can also validate ARP packets against user-configured ARP ACLs.

When DAI is enabled, the switch drops ARP packets whose sender MAC address and sender IP address do not match an entry in the DHCP snooping bindings database. You can optionally configure additional ARP packet validation.

5.19.1 Show Commands

5.19.1.1 show ip arp inspection statistics

This command displays the statistics of the ARP packets processed by Dynamic ARP Inspection. Give the vlan-list argument and the command displays the statistics on all DAI-enabled VLANs in that list. Give the single vlan argument and the command displays the statistics on that VLAN. If no argument is included, the command lists a summary of the forwarded and dropped ARP packets.

Syntax

show ip arp inspection statistics [vlan <vlan-list>]

<vlan-list> - Specifies VLAN ID in a list. The range of VLAN ID is 1 to 4093.

Default Setting

None

Command Mode

Privileged Exec

Display Message

VLAN: The VLAN ID for each displayed row.

Forwarded: The total number of valid ARP packets forwarded in this VLAN.

Dropped: The total number of not valid ARP packets dropped in this VLAN.

DHCP Drops: The number of packets dropped due to DHCP snooping binding database match failure.

ACL Drops: The number of packets dropped due to ARP ACL rule match failure.

DHCP Permits: The number of packets permitted due to DHCP snooping binding database match.

ACL Permits: The number of packets permitted due to ARP ACL rule match.

Bad Src MAC: The number of packets dropped due to Source MAC validation failure.

Bad Dest MAC: The number of packets dropped due to Destination MAC validation failure.

Invalid IP: The number of packets dropped due to invalid IP checks.

5.19.1.2 show ip arp inspection

This command displays the Dynamic ARP Inspection global configuration and configuration on all the VLANs. With the vlan-list argument (i.e. comma separated VLAN ranges), the command displays the global configuration and configuration on all the VLANs in the given VLAN list. The global configuration includes the source mac validation, destination mac validation and invalid IP validation information.

Syntax

show ip arp inspection [vlan <vlan-list>]

<vlan-list> - Specifies VLAN ID in a list. The range of VLAN ID is 1 to 4093.

Default Setting

None

Command Mode

Privileged Exec

Display Message

Source MAC Validation: Displays whether Source MAC Validation of ARP frame is enabled or disabled.

Destination MAC Validation: Displays whether Destination MAC Validation is enabled or disabled.

IP Address Validation: Displays whether IP Address Validation is enabled or disabled.

VLAN: The VLAN ID for each displayed row.

Configuration: Displays whether DAI is enabled or disabled on the VLAN.

Log Invalid: Displays whether logging of invalid ARP packets is enabled on the VLAN.

ACL Name: The ARP ACL Name, if configured on the VLAN.

Static Flag: If the ARP ACL is configured static on the VLAN.

5.19.1.3 show ip arp inspection interfaces

This command displays the Dynamic ARP Inspection configuration on all the DAI-enabled interfaces. An interface is said to be enabled for DAI if at least one VLAN, that the interface is a member of, is enabled for DAI. Given a slot/port interface argument, the command displays the values for that interface whether the interface is enabled for DAI or not.

Syntax

show ip arp inspection interfaces [<slot/port>]

<slot/port> - Interface Number.

Default Setting

None

Command Mode

Privileged Exec

Display Message

Interface: The interface ID for each displayed row.

Trust State: Whether the interface is trusted or untrusted for DAI.

Rate Limit: The configured rate limit value in packets per second.

Burst Interval: The configured burst interval value in seconds.

5.19.1.4 show arp access-list

This command displays the configured ARP ACLs with the rules. Giving an ARP ACL name as the argument will display only the rules in that ARP ACL.

Syntax

show arp access-list [acl-name]

Default Setting

None

Command Mode



5.19.2 Configuration Commands

5.19.2.1 ip arp inspection validate

This command enables additional validation checks like source-mac validation, destination-mac validation, and ip address validation on the received ARP packets.

ip arp inspection validate {[src-mac] [dst-mac] [ip]}
no ip arp inspection validate {[src-mac] [dst-mac] [ip]}

no - This command disables the additional validation checks on the received ARP packets.

Default Setting

Disabled

Command Mode

Global Config

5.19.2.2 ip arp inspection vlan

This command enables Dynamic ARP Inspection on a list of comma-separated VLAN ranges.

0	
Зy	ntax

ip arp inspection vlan <vlan-list> no ip arp inspection vlan <vlan-list>

no - This command disables Dynamic ARP Inspection on a list of comma-separated VLAN ranges.

Default Setting

Disabled

Command Mode

5.19.2.3 ip arp inspection vlan logging

This command enables logging of invalid ARP packets on a list of comma-separated VLAN ranges.

Syntax	
Syntax	

ip arp inspection vlan <vlan-list> logging no ip arp inspection vlan <vlan-list> logging

no - This command disables logging of invalid ARP packets on a list of comma-separated VLAN ranges.

Default Setting

Disabled

Command Mode

Global Config

5.19.2.4 ip arp inspection filter

This command configures the ARP ACL used to filter invalid ARP packets on a list of comma-separated VLAN ranges. If the static keyword is given, packets that do not match a permit statement are dropped without consulting the DHCP snooping bindings.

Syntax

ip arp inspection filter <acl-name> vlan <vlan-list> [static] no ip arp inspection filter <acl-name> vlan <vlan-list> [static]

no - This command unconfigures the ARP ACL used to filter invalid ARP packets on a list of comma-separated VLAN ranges.

Default Setting

No ARP ACL is configured on a VLAN

Command Mode

5.19.2.5 ip arp inspection trust

This command configures an interface as trusted for Dynamic ARP Inspection.

Syntax]		
ip arp insp	pection trust		
no ip arp i	inspection trust		

no - This command configures an interface as untrusted for Dynamic ARP Inspection.

Default Setting

Disabled

Command Mode

Interface Config

5.19.2.6 ip arp inspection limit

This command configures the rate limit and burst interval values for an interface. Configuring none for the limit means the interface is not rate limited for Dynamic ARP Inspections.

Syntax

ip arp inspection limit {rate <pps> [burst interval <seconds>] | none} no ip arp inspection limit

no - This command sets the rate limit and burst interval values for an interface to the default values of 15 pps and 1 second, respectively.

Default Setting

15 pps for rate and 1 second for burst-interval

Command Mode

Interface Config

5.19.2.7 arp access-list

This command creates an ARP ACL.

Syntax

arp access-list <acl-name> no arp access-list <acl-name>

no - This command deletes a configured ARP ACL.

Default Setting

None

Command Mode

Global Config

5.19.2.8 permit ip host mac host

This command configures a rule for a valid IP address and MAC address combination used in ARP packet validation.

Syntax

permit ip host <sender-ip> mac host <sender-mac> no permit ip host <sender-ip> mac host <sender-mac>

no - This command deletes a rule for a valid IP and MAC combination.

Default Setting

None

Command Mode

ARP Access-list Config



5.19.2.9 clear ip arp inspection statistics

This command resets the statistics for Dynamic ARP Inspection on all VLANs.

Syntax

clear ip arp inspection statistics

Default Setting

None

Command Mode

5.20 Differentiated Service Command



This Switching Command function can only be used on the QoS software version.

This chapter contains the CLI commands used for the QoS Differentiated Services (DiffServ) package.

The user configures DiffServ in several stages by specifying:

- 1. Class
 - creating and deleting classes
 - defining match criteria for a class



The only way to remove an individual match criterion from an existing class definition is to delete the class and re-create it.

- 2. Policy
 - creating and deleting policies
 - associating classes with a policy
 - defining policy statements for a policy/class combination
- 3. Service
 - adding and removing a policy to/from a directional (that is, inbound, outbound) interface

Packets are filtered and processed based on defined criteria. The filtering criteria are defined by a class. The processing is defined by a policy's attributes. Policy attributes may be defined on a per class instance basis, and it is these attributes that are applied when a match occurs.

Packet processing begins by testing the match criteria for a packet. A policy is applied to a packet when a class match within that policy is found.

Note that the type of class - all, any, or acl - has a bearing on the validity of match criteria specified when defining the class. A class type of 'any' processes its match rules in an ordered sequence; additional rules specified for such a class simply extend this list. A class type of 'acl' obtains its rule list by interpreting each ACL rule definition at the time the Diffserv class is created. Differences arise when specifying match criteria for a class type 'all', since only one value for each non-excluded match field is allowed within a class definition. If a field is already specified for a class, all subsequent attempts to specify the same field fail, including the cases where a field can be specified multiple ways through alternative formats. The exception to this is when the 'exclude' option is specified, in which case this restriction does not apply to the excluded fields.

The following class restrictions are imposed by the LB8 Series L3 Switch DiffServ design:

- nested class support limited to:
 - 'all' within 'all'
 - no nested 'not' conditions
 - no nested 'acl' class types
 - each class contains at most one referenced class
- hierarchical service policies not supported in a class definition
- access list matched by reference only, and must be sole criterion in a class
 - that is, ACL rules copied as class match criteria at time of class creation, with class type 'any'
 - implicit ACL 'deny all' rule also copied
 - no nesting of class type 'acl'

Regarding nested classes, referred to here as class references, a given class definition can contain at most one reference to another class, which can be combined with other match criteria. The referenced class is truly a reference and not a copy, since additions to a referenced class affect all classes that reference it. Changes to any class definition currently referenced by any other class must result in valid class definitions for all derived classes otherwise the change is rejected. A class reference may be removed from a class definition.

The user can display summary and detailed information for classes, policies, and services. All configuration information is accessible via the CLI, and SNMP user interfaces.

5.20.1 General Commands

The following characteristics are configurable for the platform as a whole.

5.20.1.1 diffserv

This command sets the DiffServ operational mode to active. While disabled, the DiffServ configuration is retained and can be changed, but it is not activated. When enabled, Diffserv services are activated.

Syntax	
diffserv	

Command Mode

Global Config

5.20.1.2 no diffserv

This command sets the DiffServ operational mode to inactive. While disabled, the DiffServ configuration is retained and can be changed, but it is not activated. When enabled, Diffserv services are activated.

Syntax no diffserv

Command Mode

5.20.2 Class Commands

The 'class' command set is used in DiffServ to define:

Traffic Classification specifies Behavior Aggregate (BA) based on DSCP, and Multi- Field (MF) classes of traffic (name, match criteria)

Service Levels specifies the BA forwarding classes / service levels. Conceptually, DiffServ is a two-level hierarchy of classes: 1. Service/PHB, 2. Traffic Class

This set of commands consists of class creation/deletion and matching, with the class match commands specifying layer 3, layer 2, and general match criteria. The class match criteria are also known as class rules, with a class definition consisting of one or more rules to identify the traffic belonging to the class. Note that once a class match criterion is created for a class, it cannot be changed or deleted - the entire class must be deleted and re-created.

The CLI command root is *class-map*.

5.20.2.1 class-map

This command defines a new DiffServ class of type match-all, match-any or match-access-group.

Syntax

class-map [match-all] <class-map-name> [{ipv4 | ipv6}]

<class-map-name> is a case sensitive alphanumeric string from 1 to 31 characters uniquely identifying the class.

When used without any match condition, this command enters the class-map mode. The **<class-map-name>** is the name of an existing DiffServ class.



The class name 'default' is reserved and is not allowed here. The class type of **match-all** indicates all of the individual match conditions must be true for a packet to be considered a member of the class.

The optional keywords [{ipv4 | ipv6}] specify the Layer 3 protocol for this class. If not specified, this parameter defaults to 'ipv4'. This maintains backward compatibility for configurations defined on systems before IPv6 match items were supported.

The CLI mode is changed to Class-Map Config or Ipv6-Class-Map Config when this command is successfully executed depending on the [{ipv4 | ipv6}] keyword specified.

Command Mode

Global Config

535

5.20.2.2 no class-map

This command eliminates an existing DiffServ class.

Syntax		
no class-	s-map <class-map-name></class-map-name>	

<class-map-name> is the name of an existing DiffServ class.



The class name 'default' is reserved and is not allowed here. This command may be issued at any time; if the class is currently referenced by one or more policies or by any other class, this deletion attempt shall fail.

Command Mode

Global Config

5.20.2.3 class-map rename

This command changes the name of a DiffServ class.



class-map rename <new-class-map-name>

<new-class-map-name> is a case-sensitive alphanumeric string from 1 to 31 characters uniquely identifying the class.



The class name 'default' is reserved and must not be used here.

Default Setting

None

Command Mode

Class-Map Config / Ipv6-Class-Map Config

5.20.2.4 match any

This command adds to the specified class definition a match condition whereby all packets are considered to belong to the class.

Syntax		
match any	у	

Default Setting

None

Command Mode

Class-Map Config / Ipv6-Class-Map Config

5.20.2.5 match class-map

This command adds to the specified class definition the set of match conditions defined for another class.

Syntax

match class-map <refclassname>

<**refclassname>** is the name of an existing DiffServ class whose match conditions are being referenced by the specified class definition.



There is no [not] option for this match command.

Default Setting

None

Command Mode

Class-Map Config / Ipv6-Class-Map Config

Restrictions The class types of both <*classname*> and <*refclassname*> must be identical (that is, any vs. any, or all vs. all). A class type of acl is not supported by this command.

Cannot specify **<refclassname>** the same as **<classname>** (that is, self-referencing of class name not allowed). At most one other class may be referenced by a class. Any attempt to delete the **<refclassname>** class while still referenced by any **<classname>** shall fail.

The combined match criteria of <*classname*> and <*refclassname*> must be an allowed combination based on the class type. Any subsequent changes to the <*refclassname*> class match criteria must maintain this validity, or the change attempt shall fail. The total number of class rules formed by the complete reference class chain (includes both predecessor and successor classes) must not exceed a platform-specific maximum. In some cases, each removal of a refclass rule reduces the maximum number of available rules in the class definition by one.

5.20.2.6 no match class-map

This command removes from the specified class definition the set of match conditions defined for another class.

Syntax

no match class-map <refclassname>

<refclassname> is the name of an existing DiffServ class whose match conditions

are being referenced by the specified class definition.



There is no [not] option for this match command.

Default Setting

None

Command Mode

Class-Map Config / Ipv6-Class-Map Config

5.20.2.7 match cos

This command adds to the specified class definition a match condition for the Class of Service value (the only tag in a single tagged packet or the first or outer 802.1Q tag of a double VLAN tagged packet). The value may be from 0 to 7.



This command is not available on the Broadcom 5630x platform.

Syntax			
match co	s <0-7>		

Default Setting

None

Command Mode

Class-Map Config

5.20.2.8 match secondary-cos

This command adds to the specified class definition a match condition for the secondary Class of Service value (the inner 802.1Q tag of a double VLAN tagged packet). The value may be from 0 to 7.



This command is supported on the Broadcom 56314, 56504, 56214, 56224 platform.

Syntax

match secondary-cos <0-7>

Default Setting

None

Command Mode

Class-Map Config



5.20.2.9 match destination-address mac

This command adds to the specified class definition a match condition based on the destination MAC address of a packet. The <address > parameter is any layer 2 MAC address formatted as six, two-digit hexadecimal numbers separated by colons (e.g., 00:11:22:dd:ee:ff). The <mac-mask> parameter is a layer 2 MAC address bit mask, which need not be contiguous, and is formatted as six, two-digit hexadecimal numbers separated by colons (e.g., ff:07:23:ff:fe:dc).

i	
-	

This command is not available on the Broadcom 5630x platform.

Syntax	
	match destination-address mac <address> <mac-mask></mac-mask></address>

<address> - Specifies any layer 2 MAC address.

<mac-mask> - Specifies a layer 2 MAC address bit mask.

Default Setting

None

Command Mode

Class-Map Config

5.20.2.10 match dstip

This command adds to the specified class definition a match condition based on the destination IP address of a packet.

Syntax

match dstip <ipaddr> <ipmask>

<ipaddr> specifies an IP address.

<ipmask> specifies an IP address bit mask; note that although similar to a standard subnet mask, this bit mask need not be contiguous.

Default Setting

None

Command Mode

Class-Map Config

5.20.2.11 match dstl4port

This command adds to the specified class definition a match condition based on the destination layer 4 port of a packet using a single keyword or numeric notation or a numeric range notation.

Synta	
SVIII	IX.

match dstl4port {<portkey> | <0-65535>}

To specify the match condition as a single keyword, the value for <**portkey>** is one of the supported port name keywords. The currently supported <**portkey>** values are: **domain, echo, ftp, ftpdata, http, smtp, snmp, telnet, tftp, www**. Each of these translates into its equivalent port number, which is used as both the start and end of a port range.

To specify the match condition using a numeric notation, one layer 4 port number is required.

The port number is an integer from 0 to 65535.

To specify the match condition using a numeric range notation, two layer 4 port numbers are required and together they specify a contiguous port range. Each port number is an integer from 0 to 65535, but with the added requirement that the second number be equal to or greater than the first.

Default Setting

None

Command Mode

Class-Map Config / Ipv6-Class-Map Config

5.20.2.12 match ethertype

This command adds to the specified class definition a match condition based on the value of the ethertype. The <ethertype> value is specified as one of the following keywords: **appletalk**, **arp**, **ibmsna**, **ipv4**, **ipv6**, **ipx**, **mplsucast**, **mplsucast**, **netbios**, **novell**, **pppoe**, **rarp** or as a custom ethertype value in the range of 0x0600-0xFFFF.



This command is not available on the Broadcom 5630x platform.

Syntax

match ethertype {<keyword> | <0x0600-0xFFF>}

<keyword> - Specifies appletalk, arp, ibmsna, ipv4, ipv6, ipx, mplsmcast etc <0x0600-0xFFFF> - Specifies ethertype value.

Default Setting

None

Command Mode

Class-Map Config

5.20.2.13 match ip dscp

This command adds to the specified class definition a match condition based on the value of the IP DiffServ Code Point (DSCP) field in a packet, which is defined as the high-order six bits of the Service Type octet in the IP header (the low-order two bits are not checked).

Syntax	
match ip o	dscp <value></value>

<dscpval> - value is specified as either an integer from 0 to 63, or symbolically through one of the following keywords: af11, af12, af13, af21, af22, af23, af31, af32, af33, af41, af42, af43, be, cs0, cs1, cs2, cs3, cs4, cs5, cs6, cs7, ef.



The ip dscp, ip precedence, and ip tos match conditions are alternative ways to specify a match criterion for the same Service Type field in the IP header, but with a slightly different user notation.

To specify a match on all DSCP values, use the match [not] ip tos <tosbits> <tosmask> command with <**tosbits**> set to 0 and <**tosmask**> set to 03 (hex).

Default Setting

None

Command Mode

Class-Map Config / Ipv6-Class-Map Config

5.20.2.14 match ip precedence

This command adds to the specified class definition a match condition based on the value of the IP Precedence field in a packet, which is defined as the high-order three bits of the Service Type octet in the IP header (the low-order five bits are not checked). The precedence value is an integer from 0 to 7.

Syntax	
match ip	precedence <0-7>



The ip dscp, ip precedence, and ip tos match conditions are alternative ways to specify a match criterion for the same Service Type field in the IP header, but with a slightly different user notation.

To specify a match on all Precedence values, use the match [not] ip tos <tosbits> <tosmask> command with <**tosbits>** set to 0 and <**tosmask>** set to 1F (hex).

Default Setting

None

Command Mode

Class-Map Config

5.20.2.15 match ip tos

This command adds to the specified class definition a match condition based on the value of the IP TOS field in a packet, which is defined as all eight bits of the Service Type octet in the IP header.

Syntax	
match ip	tos <tosbits> <tosmask></tosmask></tosbits>

<tosbits> is a two-digit hexadecimal number from 00 to ff.

<tosmask> is a two-digit hexadecimal number from 00 to ff.

The **<tosmask>** denotes the bit positions in **<tosbits>** that are used for comparison against the IP TOS field in a packet. For example, to check for an IP TOS value having bits 7 and 5 set and bit 1 clear, where bit 7 is most significant, use a **<tosbits>** value of a0 (hex) and a **<tosmask>** of a2 (hex).



The ip dscp, ip precedence, and ip tos match conditions are alternative ways to specify a match criterion for the same Service Type field in the IP header, but with a slightly different user notation.

In essence, this the "free form" version of the IP DSCP/Precedence/TOS match specification in that the user has complete control of specifying which bits of the IP Service Type field are checked.

Default Setting

None

Command Mode

Class-Map Config

5.20.2.16 match protocol

This command adds to the specified class definition a match condition based on the value of the IP Protocol field in a packet using a single keyword notation or a numeric value notation.

S	yntax
U	yman

match protocol {<protocol-name> | <0-255>}

<protocol-name> is one of the supported protocol name keywords. The currently supported values are: icmp, igmp, ip, tcp, udp. Note that a value of ip is interpreted to match all protocol number values. To specify the match condition using a numeric value notation, the protocol number is a standard value assigned by IANA and is interpreted as an integer from 0 to 255.



This command does not validate the protocol number value against the current list defined by IANA.

Default Setting

None

Command Mode

Class-Map Config / Ipv6-Class-Map Config



5.20.2.17 match source-address mac

This command adds to the specified class definition a match condition based on the source MAC address of a packet. The <address > parameter is any layer 2 MAC address formatted as six, two-digit hexadecimal numbers separated by colons (e.g., 00:11:22:dd:ee:ff). The <macmask> parameter is a layer 2 MAC address bit mask, which may not be contiguous, and is formatted as six, two-digit hexadecimal numbers separated by colons (e.g., ff:07:23:ff:fe:dc).



This command is not available on the Broadcom 5630x platform.



match source-address mac <address> <macmask>

<address> - Specifies any layer 2 MAC address.

<macmask> - Specifies a layer 2 MAC address bit mask.

Default Setting

None

Command Mode

Class-Map Config

5.20.2.18 match srcip

This command adds to the specified class definition a match condition based on the source IP address of a packet.

Syntax

match srcip <ipaddr> <ipmask>

<ipaddr> - specifies an IP address.

<ipmask> - specifies an IP address bit mask; note that although it resembles a standard subnet mask, this bit mask need not be contiguous.

Default Setting

None

Command Mode

Class-Map Config

5.20.2.19 match srcl4port

This command adds to the specified class definition a match condition based on the source layer 4 port of a packet using a single keyword or numeric notation or a numeric range notation.

Syntax	
Oymax	

match srcl4port {<portkey> | <0-65535>}

<portkey> is one of the supported port name keywords (listed below).

The currently supported <portkey> values are: domain, echo, ftp, ftpdata, http, smtp, snmp, telnet, tftp, www. Each of these translates into its equivalent port number, which is used as both the start and end of a port range.

To specify the match condition as a numeric value, one layer 4 port number is required. The port number is an integer from 0 to 65535.

To specify the match condition as a range, two layer 4 port numbers are required and together they specify a contiguous port range. Each port number is an integer from 0 to 65535, but with the added requirement that the second number be equal to or greater than the first.

Default Setting

None

Command Mode

Class-Map Config / IPv6-Class-Map Config

5.20.2.20 match vlan

This command adds to the specified class definition a match condition based on the value of the layer 2 VLAN Identifier field (the only tag in a single tagged packet or the first or outer tag of a double VLAN tagged packet). The VLAN ID is an integer from 1 to 4093.



This command is not available on the Broadcom 5630x platform.

Syntax

match vlan <1-4093>

Default Setting

None

Command Mode

Class-Map Config

5.20.2.21 match secondary-vlan

This command adds to the specified class definition a match condition based on the value of the layer 2 secondary VLAN Identifier field (the inner 802.1Q tag of a double VLAN tagged packet). The VLAN ID is an integer from 1 to 4093.

Syntax

match secondary-vlan <1-4093>

Default Setting

None

Command Mode

Class-Map Config

5.20.2.22 match dstip6

This command adds to the specified class definition a match condition based on the destination IPv6 address of a packet.

Syntax

match dstip6 <destination-ipv6-prefix/prefix-length>

Default Setting

None

Command Mode

IPv6-Class-Map Config

5.20.2.23 match srcip6

This command adds to the specified class definition a match condition based on the source IP address of a packet.

Syntax

match srcip6 <source-ipv6-prefix/prefix-length>

Default Setting

None

Command Mode

IPv6-Class-Map Config

5.20.2.24 match ip6flowlbl

This command adds to the specified class definition a match condition based on the IPv6 flow label value.

Syntax

match ip6flowlbl <0- 1048575>

Default Setting

None

Command Mode

IPv6-Class-Map Config

5.20.3 Policy Commands

The 'policy' command set is used in DiffServ to define:

Traffic Conditioning Specify traffic conditioning actions (policing, marking, shaping) to apply to traffic classes

Service Provisioning Specify bandwidth and queue depth management requirements of service levels (EF, AF, etc.)

The policy commands are used to associate a traffic class, which was defined by the class command set, with one or more QoS policy attributes. This association is then assigned to an interface in a particular direction to form a service. The user specifies the policy name when the policy is created.

The DiffServ CLI does not necessarily require that users associate only one traffic class to one policy. In fact, multiple traffic classes can be associated with a single policy, each defining a particular treatment for packets that match the class definition. When a packet satisfies the conditions of more than one class, preference is based on the order in which the classes were added to the policy, with the foremost class taking highest precedence.

This set of commands consists of policy creation/deletion, class addition/removal, and individual policy attributes. Note that the only way to remove an individual policy attribute from a class instance within a policy is to remove the class instance and re-add it to the policy. The values associated with an existing policy attribute can be changed without removing the class instance.

The CLI command root is *policy-map*.

5.20.3.1 assign-queue

This command modifies the queue id to which the associated traffic stream is assigned. The queueid is an integer from 0 to n-1, where n is the number of egress queues supported by the device.

Syntax

assign-queue <0-7>

<0-7> - Queue ID.

Command Mode

Policy-Class-Map Config

Incompatibilities

Drop

5.20.3.2 drop

This command specifies that all packets for the associated traffic stream are to be dropped at ingress.

Syntax]		
drop			

Command Mode

Policy-Class-Map Config

Incompatibilities

Assign Queue, Mark (all forms), Mirror, Police, Redirect



5.20.3.3 **mirror**

This command specifies that all incoming packets for the associated traffic stream are copied to a specific egress interface (physical port or LAG).



This command is not available on the Broadcom 5630x platform.

Syntax

mirror {<slot/port> | port-channel <portchannel-id>}

<slot/port> - Specifies the physical interface where the mirrored packet send to.

portchannel-id> - Specifies the port-channel interface where the mirrorred packet send to. The range of the port-channel ID is 1 to 64.

Default Setting

None

Command Mode

Policy-Class-Map Config

Incompatibilities

Drop, Redirect

5.20.3.4 redirect

This command specifies that all incoming packets for the associated traffic stream are redirected to a specific egress interface (physical port or port-channel).

Syntax

redirect {<slot/port> | port-channel <portchannel-id>}

<slot/port> - Specifies which physical interface that traffic stream are redirected to.

ortchannel-id> - Specifies which port-channel interface that traffic stream are directed to. The range of the port-channel ID is 1 to 64.

Command Mode

Policy-Class-Map Config

Incompatibilities

556

Drop, Mirror

5.20.3.5 conform-color

This command is used to enable color-aware traffic policing and define the conform-color class maps used. Used in conjunction with the police command where the fields for the conform level (for simple, single-rate, and two-rate policing) are specified. The <class-map-name> parameter is the name of an existing Diffserv class map, where different ones must be used for the conform and exceed colors.

Syntax

conform-color <class-map-name>

<class-map-name> - Name of an existing Diffserv class map, where different ones must be used for the conform colors.

Command Mode

Policy-Class-Map Config

Incompatibilities

Drop, Mirror

5.20.3.6 mark cos

This command marks all packets for the associated traffic stream with the specified class of service value in the priority field of the 802.1p header. If the packet does not already contain this header, one is inserted. The CoS value is an integer from 0 to 7.

Syntax

mark cos <0-7>

<0-7> - The range of COS value is 0 to 7.

Command Mode

Policy-Class-Map Config

Incompatibilities

Drop, Mark IP DSCP, IP Precedence, Police

557

5.20.3.7 mark cos-as-sec-cos

This command marks outer VLAN tag priority bits of all packets as the inner VLAN tag priority, marking CoS as Secondary CoS. This essentially means that the inner VLAN tag CoS is copied to the outer VLAN tag CoS.

Syntax

mark cos-as-sec-cos <0-7>

<0-7> - The range of COS value is 0 to 7.

Command Mode

Policy-Class-Map Config

Incompatibilities

Drop, Mark IP DSCP, IP Precedence, Police

5.20.3.8 **class**

This command creates an instance of a class definition within the specified policy for the purpose of defining treatment of the traffic class through subsequent policy attribute statements.

Synta	ax
clas	s <classname></classname>

<*classname>* is the name of an existing DiffServ class. Note that this command causes the specified policy to create a reference to the class definition.

Command Mode

Policy-Class-Map Config

5.20.3.9 no class

This command deletes the instance of a particular class and its defined treatment from the specified policy.

Syntax

no class <classname>

<classname> is the name of an existing DiffServ class. Note that this command removes the reference to the class definition for the specified policy.

Command Mode

Policy-Class-Map Config

5.20.3.10 mark ip-dscp

This command marks all packets for the associated traffic stream with the specified IP DSCP value.

C,	m	ax
3	7110	.aX

mark ip-dscp <value>

<value> - is specified as either an integer from 0 to 63, or symbolically through one of the following keywords: af11, af12, af13, af21, af22, af23, af31, af32, af33, af41, af42, af43, be, cs0, cs1, cs2, cs3, cs4, cs5, cs6, cs7, ef.

Command Mode

Policy-Class-Map Config

Incompatibilities

Drop, Mark CoS, Mark IP Precedence, Police

5.20.3.11 mark ip-precedence

This command marks all packets for the associated traffic stream with the specified IP Precedence value. The IP Precedence value is an integer from 0 to 7.

Syntax

mark ip-precedence <0-7>

Command Mode

Policy-Class-Map Config

Incompatibilities

Drop, Mark (all forms)

5.20.3.12 police-simple

This command is used to establish the traffic policing style for the specified class. The simple form of the police command uses a single data rate and burst size, resulting in two outcomes: conform and violate. The conforming data rate is specified in kilobits-per-second (Kbps) and is an integer from 1 to 4294967295. The conforming burst size is specified in kilobytes (KB) and is an integer from 1 to 128.

For each outcome, the only possible actions are drop, set-cos-transmit, set-dscp-transmit, setprec-transmit, or transmit. In this simple form of the police command, the conform action defaults to transmit and the violate action defaults to drop.

For set-dscp-transmit, a <dscpval> value is required and is specified as either an integer from 0 to 63, or symbolically through one of the following keywords: af11, af12, af13, af21, af22, af23,

af31, af32, af33, af41, af42, af43, be, cs0, cs1, cs2, cs3, cs4, cs5, cs6, cs7, ef.

For set-prec-transmit, an IP Precedence value is required and is specified as an integer from 0-7.

For set-cos-transmit an 802.1p priority value is required and is specified as an integer from 0-7.

Syntax

police-simple {<1-4294967295> <1-128> conform-action {drop | set-prec-transmit <0-7> | set-dscp-transmit <0-63> | set-cos-transmit <0-7> | transmit} [violate-action {drop | set-prectransmit <0-7> | set-dscp-transmit <0-63> | set-cos-transmit <0-7> | transmit}]}

The simple form of the police command uses a single data rate and burst size, resulting in two outcomes:

<conform-action & violate-action> - The conforming data rate is specified in kilobits-per-second (Kbps) and is an integer from 1 to 4294967295. The conforming burst size is specified in kilobytes (KB) and is an integer from 1 to 128. For each outcome, the only possible actions are drop, set-dscp-transmit, set-prec-transmit, or set-cos-transmit. In this simple form of the police command, the conform action defaults to transmit and the violate action defaults to drop. These actions can be set with this command once the style has been configured. Beside, the set-cos-transmit is to combine only with drop between the conform-action and the violate-action.

<set-cos-transmit> - an priority value is required and is specified as an integer from 0-7.
<set-dscp-transmit> - is required and is specified as either an integer from 0 to 63, or symbolically through one of the following keywords: af11, af12, af13, af21, af22, af23, af31, af32, af33, af41, af42, af43, be, cs0, cs1, cs2, cs3, cs4, cs5, cs6, cs7, ef.

<set-prec-transmit> - an IP Precedence value is required and is specified as an integer from 0-7.

Command Mode

Policy-Class-Map Config

Incompatibilities

Drop, Mark(all forms)

5.20.3.13 police-single-rate

This command is the single-rate form of the police command and is used to establish the traffic policing style for the specified class. For each outcome, the only possible actions are drop, set-cos-as-sec-cos, set-cos-transmit, set-sec-cos-transmit, set-dscp-transmit, set-prec-transmit, or transmit. In this single-rate form of the police command, the conform action defaults to send, the exceed action defaults to drop, and the violate action defaults to drop. These actions can be set with this command once the style has been configured.

Syntax

police-single-rate {1-4294967295 1-128 1-128 conform-action {drop | set-cos-as-sec-cos | set-cos-transmit 0-7 | set-prec-transmit 0-7 | set-dscp-transmit 0-63 | transmit} exceed-action {drop | set-cos-as-sec-cos | set-cos-transmit 0-7 | set-prec-transmit 0-7 | set-dscp-transmit 0-63 | transmit} [violate-action {drop | set-cos-as-sec-cos | set-cos-transmit 0-7 | set-prec-transmit 0-7 | set-dscp-transmit 0-63 | transmit}]}

<conform-action & violate-action & exceed-action > - The conforming data rate is specified in kilobits-per-second (Kbps) and is an integer from 1 to 4294967295. The conforming burst size is specified in kilobytes (KB) and is an integer from 1 to 128. For each outcome, the only possible actions are drop, set-dscp-transmit, set-prec-transmit, or set-cos-transmit. In this simple form of the police command, the conform action defaults to transmit and the violate action defaults to drop. These actions can be set with this command once the style has been configured. Beside, the set-cos-transmit is to combine only with drop between the conform-action and the violate-action.

<set-cos-transmit> - an priority value is required and is specified as an integer from 0-7.
<set-dscp-transmit> - is required and is specified as either an integer from 0 to 63, or symbolically through one of the following keywords: af11, af12, af13, af21, af22, af23, af31, af32, af33, af41, af42, af43, be, cs0, cs1, cs2, cs3, cs4, cs5, cs6, cs7, ef.

<set-prec-transmit> - an IP Precedence value is required and is specified as an integer from 0-7.

Command Mode

Policy-Class-Map Config

5.20.3.14 police-two-rate

This command is the two-rate form of the police command and is used to establish the traffic policing style for the specified class. For each outcome, the only possible actions are drop, set-cos-as-sec-cos, set-cos-transmit, set-sec-cos-transmit, set-dscp-transmit, set-prec-transmit, or transmit. In this two-rate form of the police command, the conform action defaults to send, the exceed action defaults to drop, and the violate action defaults to drop. These actions can be set with this command once the style has been configured.

Syntax

police-two-rate {1-4294967295 1-4294967295 1-128 1-128 conform-action {drop | setcos-as-sec-cos | set-cos-transmit 0-7 | set-sec-cos-transmit 0-7 | set-prectransmit 0-7 | set-dscp-transmit 0-63 | transmit} exceed-action {drop | set-cosas-sec-cos | set-cos-transmit 0-7 | set-sec-cos-transmit 0-7 | set-prec-transmit 0-7 | set-dscp-transmit 0-63 | transmit} [violate-action {drop | set-cos-as-seccos | set-cos-transmit 0-7 | set-sec-cos-transmit 0-7 | set-prec-transmit 0-7 | set-dscp-transmit 0-7 | set-sec-cos-transmit 0-7 | set-prec-transmit 0-7 | set-dscp-transmit 0-63 | transmit}]}

<conform-action & violate-action & exceed-action > - The conforming data rate is specified in kilobits-per-second (Kbps) and is an integer from 1 to 4294967295. The conforming burst size is specified in kilobytes (KB) and is an integer from 1 to 128. For each outcome, the only possible actions are drop, set-dscp-transmit, set-prec-transmit, or set-cos-transmit. In this simple form of the police command, the conform action defaults to transmit and the violate action defaults to drop. These actions can be set with this command once the style has been configured. Beside, the set-cos-transmit is to combine only with drop between the conform-action and the violate-action.

<set-cos-transmit> - an priority value is required and is specified as an integer from 0-7.
<set-dscp-transmit> - is required and is specified as either an integer from 0 to 63, or symbolically through one of the following keywords: af11, af12, af13, af21, af22, af23, af31, af32, af33, af41, af42, af43, be, cs0, cs1, cs2, cs3, cs4, cs5, cs6, cs7, ef.

<set-prec-transmit> - an IP Precedence value is required and is specified as an integer from 0-7.

Command Mode

Policy-Class-Map Config



5.20.3.15 policy-map

This command establishes a new DiffServ policy. The <policyname> parameter is a case-sensitive alphanumeric string from 1 to 31 characters uniquely identifying the policy. The type of policy is specific to the inbound traffic direction as indicated by the in parameter.

Syntax

policy-map <policyname> [{in | out}] no policy-map <policyname>

no - this command is to delete this policy.

in|out - The direction value is either in or out

Command Mode

Global Config

5.20.3.16 policy-map rename

This command changes the name of a DiffServ policy. The <policyname> is the name of an existing DiffServ class. The <newpolicyname> parameter is a case-sensitive alphanumeric string from 1 to 31 characters uniquely identifying the policy.

Syntax

policy-map rename <policyname> <newpolicyname>

<policyname> - Old Policy name.

<newpolicyname> - New policy name.

Command Mode

Global Config

5.20.4 Service Commands

The 'service' command set is used in DiffServ to define:

Traffic Conditioning Assign a DiffServ traffic conditioning policy (as specified by the policy commands) to an interface in the incoming direction.

Service Provisioning Assign a DiffServ service provisioning policy (as specified by the policy commands) to an interface in the outgoing direction

The service commands attach a defined policy to a directional interface. Only one policy may be assigned at any one time to an interface in a particular direction. The policy type (in, out) must match the interface direction to which it is attached.

This set of commands consists of service addition/removal.

The CLI command root is service-policy

5.20.4.1 service-policy

This command attaches a policy to an interface in a particular direction.

Syntax			
service-po	oolicy {in out} <policy-map-name></policy-map-name>		

The command can be used in the **Interface Config** mode to attach a policy to a specific interface. Alternatively, the command can be used in the **Global Config** mode to attach this policy to all system interfaces. The direction value is either in or out.

<policy-map-name> - is the name of an existing DiffServ policy, whose type must match the interface direction. Note that this command causes a service to create a reference to the policy.



This command effectively enables DiffServ on an interface (in a particular direction). There is no separate interface administrative 'mode' command for DiffServ.

This command shall fail if any attributes within the policy definition exceed the capabilities of the interface. Once a policy is successfully attached to an interface, any attempt to change the policy definition such that it would result in a violation of said interface capabilities shall cause the policy change attempt to fail.

Command Mode

Global Config (for all system interfaces)

Interface Config (for a specific interface)

Restrictions Only a single policy may be attached to a particular interface in a particular direction at any one time.

5.20.4.2 no service-policy

This command detaches a policy from an interface in a particular direction.

Syntax	
Symax	

no service-policy {in | out} <policy-map-name>

The command can be used in the Interface Config mode to detach a policy from a specific interface. Alternatively, the command can be used in the Global Config mode to detach this policy from all system interfaces to which it is currently attached. The direction value is either in or out.

cpolicy-map-name> - is the name of an existing DiffServ policy. Note that this command causes a service to remove its reference to the policy.



This command effectively disables DiffServ on an interface (in a particular direction). There is no separate interface administrative 'mode' command for DiffServ.

Command Mode

Global Config (for all system interfaces)

Interface Config (for a specific interface)

5.20.5 Show Commands

The 'show' command set is used in DiffServ to display configuration and status information for:

- Classes
- Policies
- Services

This information can be displayed in either summary or detailed formats. The status information is only shown when the DiffServ administrative mode is enabled; it is suppressed otherwise. There is also a 'show' command for general DiffServ information that is available at any time.

5.20.5.1 show class-map

This command displays all configuration information for the specified class.

Syntax

show class-map [<classname>]

<classname> is the name of an existing DiffServ class.

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Message

Class Name: The name of this class.

Class Type: The class type (all, any, or acl) indicating how the match criteria are evaluated for this class. A class type of all means every match criterion defined for the class is evaluated simultaneously they must all be true to indicate a class match. For a type of any each match criterion is evaluated sequentially and only one need be true to indicate a class match. Class type acl rules are evaluated in a hybrid manner, with those derived from each ACL Rule grouped and evaluated simultaneously, while each such grouping is evaluated sequentially.

L3 Proto: The Layer 3 protocol for this class. Possible values are IPv4 and IPv6.

Match Criteria: The Match Criteria fields will only be displayed if they have been configured. They will be displayed in the order entered by the user. These are evaluated in accordance with the class type. The possible Match Criteria fields are: Class of Service, Destination IP Address, Destination Layer 4 Port, Destination MAC Address, Every, IP DSCP, IP Precedence, IP TOS, Protocol

Keyword, Reference Class, Source IP Address, Source Layer 4 Port, Source MAC Address, and VLAN.

Values: This field displays the values of the Match Criteria.

Class Name: The name of this class. (Note that the order in which classes are displayed is not necessarily the same order in which they were created.)

Class Type: A class type of 'all' means every match criterion defined for the class is evaluated simultaneously and must all be true to indicate a class match.

Reference Class Name: The name of an existing DiffServ class whose match conditions are being referenced by the specified class definition.

5.20.5.2 show diffserv

This command displays the DiffServ General Status Group information, which includes the current administrative mode setting as well as the current and maximum number of rows in each of the main DiffServ private MIB tables.

Syntax			
show diff	fserv		

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Message

DiffServ Admin mode: The current value of the DiffServ administrative mode.

Class Table Size Current/Max: The current or maximum number of entries (rows) in the Class Table.

Class Rule Table Size Current/Max: The current or maximum number of entries (rows) in the Class Rule Table.

Policy Table Size Current/Max: The current or maximum number of entries (rows) in the Policy Table.

Policy Instance Table Size Current/Max: The current or maximum number of entries (rows) in the Policy Instance Table.

Policy Attribute Table Size Current/Max: The current or maximum number of entries (rows) in the Policy Attribute Table.

Service Table Size Current/Max: The current or maximum number of entries (rows) in the Service Table.

5.20.5.3 show diffserv service

This command displays policy service information for the specified interface and direction.

Syntax

show diffserv service {<slot/port> | port-channel <portchannel-id>} {in | out}

<slot/port> - specifies a valid slot number and port number for the system. The direction parameter indicates the interface direction of interest.

<portchannel-id> - Specifies the port-channel interface. The range of the port-channel ID is 1 to 64.

Default Setting

None

Command Mode

Privileged Exec

Display Message

DiffServ Admin Mode: The current setting of the DiffServ administrative mode. An attached policy is only in effect on an interface while DiffServ is in an enabled mode.

Interface: The slot number and port number of the interface (slot/port).

Direction: The traffic direction of this interface service.

Operational Status: The current operational status of this DiffServ service interface.

Policy Name: The name of the policy attached to the interface in the indicated direction.

Policy Details: Attached policy details, whose content is identical to that described for the show policy-map <policymapname> command (content not repeated here for brevity).

5.20.5.4 show diffserv service brief

This command displays all interfaces in the system to which a DiffServ policy has been attached. The direction parameter is optional; if specified, only services in the indicated direction are shown.

Syntax

show diffserv service brief [in | out]

Default Setting

None

Command Mode

Privileged Exec

Display Message

DiffServ Admin Mode: The current setting of the DiffServ administrative mode. An attached policy is only active on an interface while DiffServ is in an enabled mode.

The following information is repeated for interface and direction (only those

interfaces configured with an attached policy are shown):

Interface: The slot number and port number of the interface (slot/port).

Direction: The traffic direction of this interface service.

OperStatus: The current operational status of this DiffServ service interface.

Policy Name: The name of the policy attached to the interface in the indicated direction.

5.20.5.5 show policy-map

This command displays all configuration information for the specified policy.

Syntax

show policy-map [<policy-map-name>]

<policy-map-name> - is the name of an existing DiffServ policy.

Default Setting

None

Command Mode

Privileged Exec

Display Message

Policy Name: The name of this policy.

Policy Type: The policy type, namely whether it is an inbound or outbound policy definition.

The following information is repeated for each class associated with this policy

(only those policy attributes actually configured are displayed):

Class Name: The name of this class.

Mark CoS: Denotes the class of service value that is set in the 802.1p header of outbound packets. This is not displayed if the mark cos was not specified.

Mark IP DSCP: Denotes the mark/re-mark value used as the DSCP for traffic matching this class. This is not displayed if mark ip description is not specified using the police-two-rate command, or if policing is in use for the class under this policy.

Mark IP Precedence: Denotes the mark/re-mark value used as the IP Precedence for traffic matching this class. This is not displayed if either mark DSCP or policing is in use for the class under this policy.

Policing Style: This field denotes the style of policing, if any, used simple.

Committed Rate (Kbps): This field displays the committed rate, used in simple policing, single-rate policing, and two-rate policing.

Committed Burst Size (KB): This field displays the committed burst size, used in simple policing.

Conform Action: The current setting for the action taken on a packet considered to conform to the policing parameters. This is not displayed if policing is not in use for the class under this policy.

Conform COS Value: This field shows the priority mark value if the conform action is markcos.

Conform DSCP Value: This field shows the DSCP mark value if the conform action is markdscp.

Conform IP Precedence Value: This field shows the IP Precedence mark value if the conform action is markprec.

Non-Conform Action: The current setting for the action taken on a packet considered to not conform to the policing parameters. This is not displayed if policing not in use for the class under this policy.

Non-Conform DSCP Value: This field displays the DSCP mark value if this action is markdscp.

Non-Conform IP Precedence Value: This field displays the IP Precedence mark value if this action is markprec.

Assign Queue: Directs traffic stream to the specified QoS queue. This allows a traffic classifier to specify which one of the supported hardware queues are used for handling packets belonging to the class.

Drop: Drop a packet upon arrival. This is useful for emulating access control list operation using DiffServ, especially when DiffServ and ACL cannot co-exist on the same interface.

Mirror: Copies a classified traffic stream to a specified egress port (physical port or LAG). This can occur in addition to any marking or policing action. It may also be specified along with a QoS queue assignment.

Redirect: Forces a classified traffic stream to a specified egress port (physical port or LAG). This can occur in addition to any marking or policing action. It may also be specified along with a QoS queue assignment.

Policy Name: The name of this policy. (Note that the order in which the policies are displayed is not necessarily the same order in which they were created.)

Policy Type: The policy type, namely whether it is an inbound or outbound policy definition.

Class Members: List of all class names associated with this policy.

573

5.20.5.6 show policy-map interface

This command displays policy-oriented statistics information for the specified interface and direction.

Syntax

show policy-map interface {<slot/port> | port-channel <portchannel-id>} {in | out}

<slot/port> - specifies a valid slot number and port number for the system. The direction parameter indicates the interface direction of interest.

cportchannel-id> - Specifies the port-channel interface. The range of port-channel ID is 1 to 64.

Command Mode

Privileged Exec

Display Message

Interface: The slot number and port number of the interface (slot/port).

Direction: The traffic direction of this interface service, either in or out.

Operational Status: The current operational status of this DiffServ service interface.

Policy Name: The name of the policy attached to the interface in the indicated

direction.

The following information is repeated for each class instance within this policy:

Class Name: The name of this class instance.

In Offered Packets: A count of the packets offered to this class instance before the defined DiffServ treatment is applied. Only displayed for the 'in' direction.

In Discarded Packets: A count of the packets discarded for this class instance for any reason due to DiffServ treatment of the traffic class. Only displayed for the 'in' direction.

•
1
•

None of the counters listed here are guaranteed to be supported on all platforms. Only supported counters are shown in the display output.

5.20.5.7 show service-policy

This command displays a summary of policy-oriented statistics information for all interfaces in the specified direction. The direction parameter indicates the interface direction of interest. This command enables or disables the route reflector client. A route reflector client relies on a route reflector to re-advertise its routes to the entire AS. The possible values for this field are **enable** and **disable**.

Syntax

show service-policy {in | out}

Command Mode

Privileged Exec

Display Message

The following information is repeated for each interface and direction (only those interfaces configured with an attached policy are shown):

Interface: The slot number and port number of the interface (slot/port).

Operational Status: The current operational status of this DiffServ service interface.

Policy Name: The name of the policy attached to the interface.



None of the counters listed here are guaranteed to be supported on all platforms. Only supported counters are shown in the display output.

GUANTA COMPUTER INC.

5.21 ACL Command

5.21.1 Show Commands

5.21.1.1 show mac access-lists name

This command displays a MAC access list and all of the rules that are defined for the ACL. The <name> parameter is used to identify a specific MAC ACL to display.

Syntax

show mac access-lists <name>

<name> - ACL name which uniquely identifies the MAC ACL to display.

Default Setting

None

Command Mode

Privileged Exec

Display Message

MAC ACL Name: The name of the MAC ACL rule.

Rule Number: The ordered rule number identifier defined within the ACL.

Action: Displays the action associated with each rule. The possible values are Permit or

Deny.

Source MAC Address: Displays the source MAC address for this rule.

Source MAC Mask: Displays the source MAC mask for this rule.

Destination MAC Address: Displays the destination MAC address for this rule.

Destination MAC Mask: Displays the destination MAC mask for this rule.

Ethertype: Displays the Ethertype keyword or custom value for this rule.

VLAN ID: Displays the VLAN identifier value or range for this rule.

CoS Value: Displays the COS (802.1p) value for this rule.

Assign Queue: Displays the queue identifier to which packets matching this rule are assigned.

Redirect Interface: Displays the slot/port to which packets matching this rule are forwarded.

Mirror Interface: Displays the slot/port to which packets matching this rule are copied.

Time Range Name: Displays the name of the time-range if the MAC ACL rule has referenced a time range.

Rule Status: Status (Active/Inactive) of the MAC ACL rule.

redirectExtAgent: Indicates whether matching flow packets are allowed to be sent to external applications running alongside ICOS on a control CPU.

Committed Rate: The committed rate defined by the rate-limit attribute.

Committed Burst: The committed burst size defined by the rate-limit attribute.

5.21.1.2 show mac access-lists

This command displays a summary of all defined MAC access lists in the system.

Syntax
Officar

show mac access-lists

Default Setting

None

Command Mode

Privileged Exec

Display Message

Current number of all ACLs: The number of user-configured rules defined for this ACL.

Maximum number of all ACLs: The maximum number of ACL rules.

MAC ACL Name: The name of the MAC ACL rule.

Rules: The number of rule in this ACL.

Direction: Denotes the direction in which this MAC ACL is attached to the set of interfaces listed. The value is Inbound or Outbound.

Interfaces: Displays the list of interfaces (slot/port) to which this MAC ACL is attached in a given direction.

VLANs: VLAN(s) to which the MAC ACL applies.

5.21.1.3 show ip access-lists

This command displays an Access Control List (ACL) and all of the rules that are defined for the ACL.

show ip access-lists [<1-199> | <name>]

<1-199> - is the number used to identify the ACL.

<name> - is the name of the ACL.

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Message

Current number of ACLs: The number of user-configured rules defined for this ACL.

Maximum number of ACLs: The maximum number of ACL rules.

ACL ID: The identifier of this ACL.

Rule: This displays the number identifier for each rule that is defined for the ACL.

Action: This displays the action associated with each rule. The possible values are Permit or Deny.

Match ALL: Match all packets or not.

IPv4 Protocol: This displays the protocol to filter for this rule.

Source IP Address: This displays the source IP address for this rule.

Source IP Mask: This field displays the source IP Mask for this rule.

Source L4 Port Keyword: This field displays the source port for this rule.

Destination IP Address: This displays the destination IP address for this rule.

Destination IP Mask: This field displays the destination IP Mask for this rule.

Destination L4 Port Keyword: This field displays the destination port for this rule.

IP DSCP: This field displays the IP DSCP value for this rule.

IP Precedence: This field displays the IP Precedence value for this rule.

IP TOS: This field displays the IP TOS value for this rule.

Log: This field displays when you enable logging for this rule.

Assign Queue: This field displays the queue identifier to which packets matching this rule are assigned.

Mirror Interface: This field displays the slot/port to which packets matching this rule are copied.

Redirect Interface: This field displays the slot/port to which packets matching this rule are forwarded.

Time Range Name: Displays the name of the time-range if the IP ACL rule has referenced a time range.

Direction: Shows whether the ACL is applied to traffic coming into the interface (ingress)

or leaving the interface (egress).

Rule Status: Status (Active/Inactive) of the MAC ACL rule.

redirectExtAgent: Indicates whether matching flow packets are allowed to be sent to external applications running alongside ICOS on a control CPU.

Committed Rate: The committed rate defined by the rate-limit attribute.

Committed Burst: The committed burst size defined by the rate-limit attribute.

5.21.1.4 show access-lists interface

This command displays IP ACLs, IPv6 ACLs, and MAC access control lists information for a designated interface and direction. Use the control-plane keyword to display the ACLs applied on the CPU port.

Syntax

show access-lists {{ interface <slot/port> | port-channel <portchannel-id> } {in | out} | control-plane}

<slot/port> - is the interface number.

cportchannel-id> - is the port-channel ID. The port-channel ID is range from 1 to 64.

control-plane – is the management (CPU) port.

in | out - The direction value is either in or out

Default Setting

None

Command Mode

Privileged Exec

Display Message

ACL Type: This displays ACL type is IP, IPv6 or MAC.

ACL ID: Access List name for a MAC or IPv6 access list or the numeric identifier for an IP access list.

Sequence Number: An optional sequence number may be specified to indicate the order of this access list relative to other access lists already assigned to this interface and direction. A lower number indicates higher precedence order. If a sequence number is already in use for this interface and direction, the specified access list replaces the currently attached access list using that sequence number. If the sequence number is not specified by the user, a sequence number that is one greater than the highest sequence number currently in use for this interface and direction is used. Valid range is (1 to 4294967295).

5.21.1.5 show access-lists vlan

This command displays Access List information for a particular VLAN ID.

Syntax

show access-lists {{ interface <slot/port> | port-channel <portchannel-id> } {in | out} | control-plane}

<slot/port> - is the interface number.

cportchannel-id> - is the port-channel ID. The port-channel ID is range from 1 to 64.

581

control-plane - is the management (CPU) port.

in | out - The direction value is either in or out

Default Setting

None

Command Mode

Privileged Exec

Display Message

ACL Type: This displays ACL type is IP, IPv6 or MAC.

ACL ID: Access List name for a MAC or IPv6 access list or the numeric identifier for an IP access list.

Sequence Number: An optional sequence number may be specified to indicate the order of this access list relative to other access lists already assigned to this interface and direction. A lower number indicates higher precedence order. If a sequence number is already in use for this interface and direction, the specified access list replaces the currently attached access list using that sequence number. If the sequence number is not specified by the user, a sequence number that is one greater than the highest sequence number currently in use for this interface and direction is used. Valid range is (1 to 4294967295).



5.21.2 Configuration Commands

5.21.2.1 mac access-list extended

This command creates a MAC Access Control List (ACL) identified by <name>, consisting of

classification fields defined for the Layer 2 header of an Ethernet frame. The <name> parameter is a case-sensitive alphanumeric string from 1 to 31 characters uniquely identifying the MAC access list. If a MAC ACL by this name already exists, this command enters Mac-Access-List config mode to allow updating the existing ACL.

Syntax

mac access-list extended <name> no mac access-list extended <name>

<name> - It uniquely identifies the MAC access list.

Default Setting

None

Command Mode



5.21.2.2 mac access-list extended rename

This command changes the name of a MAC Access Control List (ACL). The <name> parameter is the name of an existing MAC ACL. The <newname> parameter is a case-sensitive alphanumeric string from 1 to 31 characters uniquely identifying the MAC access list. This command fails if a MAC ACL by the name <newname> already exists.

Syntax

mac access-list extended rename <oldname> <newname>

<oldname> - Old name which uniquely identifies the MAC access list.

<newname> - New name which uniquely identifies the MAC access list.

Default Setting

None

Command Mode

Global Config

584

5.21.2.3 mac access-group

This command attaches a specific MAC Access Control List (ACL) identified by <name> to an

interface, or associates it with a VLAN ID, in a given direction. The <name> parameter must be the name of an exsiting MAC ACL.

An optional sequence number may be specified to indicate the order of this access list relative to other access lists already assigned to this interface and direction. A lower number indicates higher precedence order. If a sequence number is already in use for this interface and direction, the specified access list replaces the currently attached access list using that sequence number. If the sequence number is not specified for this command, a sequence number that is one greater than the highest sequence number currently in use for this interface and direction will be used.

This command specified in 'Interface Config' mode only affects a single interface, whereas the 'Global Config' mode setting is applied to all interfaces. The 'Interface Config' mode command is only available on platforms that support independent per-port class of service queue configuration. The VLAN keyword is only valid in the 'Global Config' mode.

Syntax

mac access-group <name> [vlan <vlan-id>] {in |out} [<1-4294967295>] no mac access-group <name> [vlan <vlan-id>] {in | out}

<no> - This command removes a MAC ACL identified by <name> from the interface or vlan in a given direction.

in|out - The direction value is either in or out

Default Setting

None

Command Mode

Global Config

Interface Config



5.21.2.4 mac access-list

This command creates a new rule for the current MAC access list. Each rule is appended to the list of configured rules for the list. Note that an implicit 'deny all' MAC rule always terminates the access list. Note: The 'no' form of this command is not supported, as the rules within an ACL cannot be deleted individually. Rather, the entire ACL must be deleted and re-specified.

A rule may either deny or permit traffic according to the specified classification fields. At a minimum, the source and destination MAC value and mask pairs must be specified, each of which may be substituted using the keyword any to indicate a match on any value in that field. The bpdu keyword may be specified for the destination MAC value/mask pair indicating a well-known BPDU MAC value of 01-80-c2-xx-xx- (hex), where 'xx' indicates a don't care. The remaining command parameters are all optional.

The Ethertype may be specified as either a keyword or a four-digit hexadecimal value from 0x0600-0xFFFF. The currently supported <ethertypekey> values are: appletalk, arp, ibmsna, ipv4, ipv6, ipx, mplsmcast, mplsucast, netbios, novell, pppoe, rarp. Each of these translates into its equivalent Ethertype value(s).

The vlan and cos parameters refer to the VLAN identifier and 802.1p user priority fields, respectively, of the VLAN tag. For packets containing a double VLAN tag, this is the first (or outer) tag.

The assign-queue parameter allows specification of a particular hardware queue for handling traffic that matches this rule. The allowed <queue-id> value is 0-(n-1), where n is the number of user configurable queues available for the hardware platform.

The mirror parameter allows the traffic matching this rule to be copied to the specified <slot/port>, while the redirect parameter allows the traffic matching this rule to be forwarded to the specified <slot/port> The assign-queue and redirect parameters are only valid for a 'permit' rule.

The time-range parameter allows imposing time limitation on the MAC ACL rule as defined by the parameter time-range-name. If a time range with the specified name does not exist and the MAC ACL containing this ACL rule is applied to an interface or bound to a VLAN, then the ACL rule is applied immediately. If a time range with specified name exists and the MAC ACL containing this ACL rule is applied to an interface or bound to a VLAN, then the ACL containing this ACL rule is applied to an interface or bound to a VLAN, then the ACL containing this ACL rule is applied to an interface or bound to a VLAN, then the ACL rule is applied when the time-range with specified name becomes active. The ACL rule is removed when the time-range with specified name becomes inactive.

The redirectExtAgent optional parameter allows matching flow packets to be sent to external applications running alongside ICOS on a control CPU. agent-id is a unique identifier for the external receive client application. agent-id is an integer in the range 1 to 100. The redirectExtAgent action is mutually exclusive with the mirror and redirect parameters.

The rate-limit option allows the device to permit only the allowed rate of traffic as per the configured rate in kpbs, and burst-size in kbytes.

586

Syntax

{del-rule-id | deny | permit} {{<srcmac> <srcmask>} | any} {{<dstmac> <dstmask>} | any | bpdu} [<ethertypekey> | <0x0600-0xFFF>] [vlan {{eq <0-4095>}} [cos <0-7>] [log] [time-range time-range-name] [assign-queue <queue-id>] [{mirror | redirect} {<slot/port> | port-channel <portchannel-id>}] [<rule-id>] | redirectExtAgent <agent-id> | rate-limit rate burst-size

Default Setting

None

Command Mode

Mac Access-list Config

5.21.2.5 access-list

This command creates an Access Control List (ACL) that is identified by the parameter.

Syntax

access-list {(<1-99> {deny | permit} {every | <srcip> <srcm ask>}) | ({<100-199> {deny | permit} {every | {{eigrp| gre | icmp | igmp | ip | ipinip | ospf | pim | tcp | udp | <number>} {srcip srcmask | any | host srcip} [{range {portkey|startport} {portkey|endport} | {eq | neq | It | gt} {portkey|0-65535} {dstip dstmask | any | host dstip} [{range {portkey|startport} {portkey|endport} | {eq | neq | It | gt} {portkey|0-65535} [flag [+fin | -fin] [+syn | -syn] [+rst | -rst] [+psh | -psh] [+ack | -ack] [+urg | -urg] [established]] {[fragments] [precedence <precedence>] | [tos <tos> <tosmask>] | [dscp <dscp>] [log] [time-range time-range -name] [assign-queue <queue-id>] [{mirror | redirect} {<slot/port> | port-channel <portchannel-id>}] [{redirectExtAgent <agent-id>]] [{rate-limit rate burst-size}] [<rule-id>]}}}

<a>ccesslistnumber> - The ACL number is an integer from 1 to 199. The range 1 to 99 is for the normal ACL List and 100 to 199 is for the extended ACL List.

permit or deny - The ACL rule is created with two options. The protocol to filter for an ACL rule is specified by giving the protocol to be used like **i***cmp*, **i***gmp*, **i***p*, **t***cp*, **u***dp*. The command specifies a source ip address and source mask for match condition of the ACL rule specified by the **srcip** and **srcmask** parameters. The source layer 4 port match condition for the ACL rule is specified by the *port key p*arameter.

<portkey> - uses a single keyword notation and currently has the values of *domain, echo, ftp, ftpdata, http, smtp, snmp, telnet, tftp*, and *www*. Each of these values translates into its equivalent port number, which is used as both the start and end of a port range. The command specifies a destination ip address and destination mask for match condition of the ACL rule specified by the *dstip* and *dstmask* parameters. The command specifies the TOS for an ACL rule depending on a match of precedence or DSCP values using the parameters *tos, tosmask, dscp*.

[time-range time-range-name] - Allows imposing time limitation on the ACL rule as defined by the parameter time-range-name. If a time range with the specified name does not exist and the ACL containing this ACL rule is applied to an interface or bound to a VLAN, then the ACL rule is applied immediately. If a time range with specified name exists and the ACL containing this ACL rule is applied to an interface or bound to a VLAN, then the ACL rule is applied to an interface or bound to a VLAN, then the ACL containing this ACL rule is applied to an interface or bound to a VLAN, then the ACL rule is applied to an interface or bound to a VLAN, then the ACL rule is applied to an interface or bound to a VLAN, then the ACL rule is applied when the time-range with specified name becomes active. The ACL rule is removed when the time-range with specified name becomes inactive.

[{range {portkey|startport} {portkey|endport}} | {eq | neq | It | gt} {portkey|0-65535}] – Specifies the layer 4 port match confition for the IP ACL rule. Note: This option is available only if the protocol is tcp or udp.

flag – Specifies that the IP ACL rule matches on the TCP flags. Note: This opetion is available only if the protol is tcp.

fragments – Spectifies that the IP ACL rule matches on fragmented IP packets.

[rate-limit rate burst-size] – Specifies the allowed rate of traffic as per the configured rate in kbps, and burst –size in kbytes.

[redirectExtAgent agent-id] - allows matching flow packets to be sent to external applications running alongside ICOS on a control CPU. agent-id is a unique identifier for the external receive client application.

588



Default Setting

None Command Mode

5.21.2.6 no access-list

This command deletes an ACL that is identified by the parameter *<accesslistnumber>* from the system or remove an ACL rule that is identified by the parameter *<*1-28> from the an IP ACL *<accesslistnumber>*.

Syntax

no access-list {<1-99> | <100-199>} [<rule-id>]



The ACL number is an integer from 1 to 199. The range 1 to 99 is for the normal ACL List and 100 to 199 is for the extended ACL List.

Default Setting

None

Command Mode

5.21.2.7 ip access-group

This command attaches a specified access-control list to an interface or associates with a VLAN ID in a given direction. The parameter <name> is the name of the Access Control List.

An optional sequence number may be specified to indicate the order of this IP access list relative to other IP access lists already assigned to this interface and direction. A lower number indicates higher precedence order. If a sequence number is already in use for this interface and direction, the specified access list replaces the currently attached IP access list using that sequence number. If the sequence number is not specified for this command, a sequence number that is one greater than the highest sequence number currently in use for this interface and direction is used.

This command specified in 'Interface Config' mode only affects a single interface, whereas the 'Global Config' mode setting is applied to all interfaces. The VLAN keyword is only valid in the 'Global Config' mode.

Syntax

ip access-group {<1- 199> | <name>} [vlan <vlan-id>] {in|out} [<1-4294967295>] no ip access-group {<1-199> | <name>} [vlan <vlan-id>] {in|out}

<1- 199> The identifier of this ACL.

<name> The name of this ACL.

<vlan-id> The associated VLAN ID of this ACL.

<1-4294967295> The sequence number of this ACL.

in out - The direction value is either in or out

no - This command removes a ACL by identifier or name from the interface or vlan in a given direction.

Default Setting

None

Command Mode

Global Config

Interface Config

5.21.2.8 ip access-list

Use this command to create an extended IP Access Control List (ACL) identified by <name>, consisting of classification fields defined for the IP header of an IPv4 frame. The <name> parameter is a case-sensitive alphanumeric string from 1 to 31 characters uniquely identifying the IP access list.

If an IP ACL by this name already exists, this command enters IPv4-Access_List config mode to allow updating the existing IP ACL.

The CLI mode changes to IPv4-Access-List Configuration mode when you successfully execute this command.

Syntax

Ip access-list <name></name>	
no ip access-list <name></name>	

no - This command removes the IP ACL identified by <name> from the system.

Default Setting

None

Command Mode

Global Config

5.21.2.9 ip access-list rename

Use this command to change the name of an IP Access Control List (ACL). The <name> parameter is the names of an existing IP ACL. The <newname> parameter is a case-sensitive alphanumeric string from 1 to 31 characters uniquely identifying the IP access list.

Syntax

ip access-list rename <name> <newname>

Default Setting

None

Command Mode

5.22 IPv6 ACL Command

5.22.1 Show Commands

5.22.1.1 show ipv6 access-lists

This command displays an IPv6 access list and all of the rules that are defined for the IPv6 ACL. Use the [name] parameter to identify a specific IPv6 ACL to display.

Syntax

show ipv6 access-lists [<name>]

<name> - ACL name which uniquely identifies the IPv6 ACL to display.

Default Setting

None

Command Mode

Privileged EXEC

User EXEC

Display Message

Rule Number: The ordered rule number identifier defined within the IPv6 ACL.

Action: The action associated with each rule. The possible values are Permit or Deny.

Match All: Indicates whether this access list applies to every packet. Possible values are True or False.

IPv6 Protocol: The protocol to filter for this rule.

Source IP Address: The source IP address for this rule.

Source L4 Port Keyword: The source port for this rule.

Destination IP Address: The destination IP address for this rule.

Destination L4 Port Keyword: The destination port for this rule.

IP DSCP: The value specified for IP DSCP.

Flow Label: The value specified for IPv6 Flow Label.

Log: Displays when you enable logging for the rule.

Assign Queue: The queue identifier to which packets matching this rule are assigned.

Mirror Interface: The slot/port to which packets matching this rule are copied.

Redirect Interface: The slot/port to which packets matching this rule are forwarded.

Time Range Name: Displays the name of the time-range if the Ipv6 ACL rule has referenced a time range.

Direction: Shows whether the ACL is applied to traffic coming into the interface (ingress)

or leaving the interface (egress).

Rule Status: Status (Active/Inactive) of the MAC ACL rule.

redirectExtAgent: Indicates whether matching flow packets are allowed to be sent to external applications running alongside ICOS on a control CPU.

Committed Rate: The committed rate defined by the rate-limit attribute.

Committed Burst: The committed burst size defined by the rate-limit attribute.

5.22.2 Configuration Commands

5.22.2.1 ipv6 access-list

This command creates an IPv6 Access Control List (ACL) identified by <name>, consisting of classification fields defined for the IP header of an IPv6 frame. The <name> parameter is a case-sensitive alphanumeric string from 1 to 31 characters

uniquely identifying the IPv6 access list.

If an IPv6 ACL by this name already exists, this command enters IPv6-Access-List config mode to allow updating the existing IPv6 ACL.

Syntax

ipv6 access-list <name> no ipv6 access-list <name>

<name> - access-list name up to 31 characters in length.

no - This command deletes the IPv6 ACL identified by <name> from the system.



The CLI mode changes to IPv6-Access-List Config mode when you successfully execute this command.

Default Setting

None

Command Mode

5.22.2.2 ipv6 access-list rename

This command changes the name of an IPv6 ACL. The <name> parameter is the name of an existing IPv6 ACL. The <newname> parameter is a case-sensitive alphanumeric string from 1 to 31 characters uniquely identifying the IPv6 access list.

This command fails is an IPv6 ACL by the name <newname> already exists.

Syntax

ipv6 access-list rename <oldname> <newname>

<oldname> - current Access Control List name. <newname> - new Access Control List name.

Default Setting

None

Command Mode

5.22.2.3 {deny | permit}

This command creates a new rule for the current IPv6 access list. Each rule is appended to the list of configured rules for the list.



The 'no' form of this command is not supported, since the rules within an IPv6 ACL cannot be deleted individually. Rather, the entire IPv6 ACL must be deleted and respecified.

An implicit 'deny all' IPv6 rule always terminates the access list.

A rule may either deny or permit traffic according to the specified classification fields. At a minimum, either the 'every' keyword or the protocol, source address, and destination address values must be specified. The source and destination IPv6 address fields may be specified using the keyword 'any' to indicate a match on any value in that field. The remaining command parameters are all optional, but the most frequently used parameters appear in the same relative order as shown in the command format.

The assign-queue parameter allows specification of a particular hardware queue for handling traffic that matches this rule. The allowed <queue-id> value is 0-(n-1), where n is the number of user configurable queues available for the hardware platform. The assign-queue parameter is valid only for a permit rule.

The mirror parameter allows the traffic matching this rule to be copied to the specified <slot/port>, while the redirect parameter allows the traffic matching this rule to be forwarded to the specified <slot/port>. The assign-queue and redirect parameters are only valid for a permit rule.

The time-range parameter allows imposing time limitation on the IPv6 ACL rule as defined by the parameter time-range-name. If a time range with the specified name does not exist and the IPv6 ACL containing this ACL rule is applied to an interface or bound to a VLAN, then the ACL rule is applied immediately. If a time range with specified name exists and the IPv6 ACL containing this ACL rule is applied to a VLAN, then the ACL rule is applied to an interface or bound to a VLAN, then the ACL containing this ACL rule is applied to an interface or bound to a VLAN, then the ACL rule is applied to an interface or bound to a VLAN, then the ACL rule is applied when the time-range with specified name becomes active. The ACL rule is removed when the time-range with specified name becomes inactive.

Syntax

{del-rule-id | deny | permit} {every | {{icmpv6 | ipv6 | tcp | udp | <number>} {source-ipv6-prefix/prefix-length | any | host soure-ipv6-address} [{range {portkey | startport} {portkey | endport} | eq | neq | lt | gt} {portkey | 0-65535}] {destination-ipv6-prefix/prefix-length} | any | host destination-ipv6-address} [{range {portkey | startport} {portkey | endport} | eq | neq | lt | gt} {portkey | 0-65535}] [flag [+fin | -fin] [+syn | -syn] [+rst | -rst] [+psh | -psh] [+ack | -ack] [+urg | -urg] [established]] [flow-label value] [fragments] [log] [time-range time-range-name] [assign-queue <queue-id>] [{mirror | redirect} {<slot/port> | port-channel <portchannel-id>}] [rate-limit rate burst-size] [rule-id]

Default Setting

None

Command Mode

IPv6-Access-List Config

5.22.2.4 ipv6 traffic-filter

This command either attaches a specific IPv6 ACL identified by <name> to an interface or associates with a VLAN ID in a given direction. The <name> parameter must be the name of an existing IPv6 ACL.

An optional sequence number may be specified to indicate the order of this mac access list relative to other IPv6 access lists already assigned to this interface and direction. A lower number indicates higher precedence order. If a sequence number

is already in use for this interface and direction, the specifiedIPv6 access list replaces the currently attached IPv6 access list using that sequence number. If the sequence number is not specified for this command, a sequence number that is one greater than the highest sequence number currently in use for this interface and direction is used.

This command specified in Interface Config mode only affects a single interface, whereas the Global Config mode setting is applied to all interfaces. The vlan keyword is only valid in the Global Config mode. The Interface Config mode command is only available on platforms that support independent per-port class of service queue configuration.

Syntax

ipv6 traffic-filter <name> [vlan <vlan-id>] {in|out} [<1-4294967295>] no ipv6 traffic-filter <name> [vlan <vlan-id>] {in|out} [<1-4294967295>]

in|out - The direction value is either in or out

no - This command removes an IPv6 ACL identified by <name> from the interface(s) in a given direction

Default Setting

None

Command Mode

Global Config

Interface Config

5.23 CoS (Class of Service) Command

5.23.1 Show Commands

5.23.1.1 show queue cos-map

This command displays the current Dot1p (802.1p) priority mapping to internal traffic classes for a specific interface. The slot/port parameter is optional and is only valid on platforms that support independent per-port class of service mappings. If specified, the 802.1p mapping table of the interface is displayed. If omitted, the most recent global configuration settings are displayed.

Syntax

show queue cos-map {<slot/port> | port-channel <portchannel-id>}

< slot/port > - The interface number.

<portchannel-id> - The port-channel interface number. The range of the ID is 1 to 64.

Default Setting

None

Command Mode

Privileged EXEC

User EXEC

Display Message

The following information is repeated for each user priority.

User Priority: The 802.1p user priority value.

Traffic Class: The traffic class internal queue identifier to which the user priority value is mapped.

5.23.1.2 show queue ip-dscp-mapping

This command maps an IP DSCP value to an internal traffic class. The <ipdscp> value is specified as either an integer from 0 to 63, or symbolically through one of the following keywords: af11, af12, af13, af21, af22, af23, af31, af32, af33, af41, af42, af43, be, cs0, cs1, cs2, cs3, cs4, cs5, cs6, cs7, ef.

The <trafficclass> values can range from 0-6, although the actual number of available traffic classes depends on the platform.

Syntax

show queue ip-dscp-mapping

Default Setting None Command Mode

Privileged EXEC

Display Message

IP DSCP: Displays IP DSCP value.

Traffic Class: Displays the queue mapping.

5.23.1.3 show queue trust

This command displays the current trust mode setting for a specific interface. The slot/port parameter is optional and is only valid on platforms that support independent per-port class of service mappings. If specified, the port trust mode of the interface is displayed. If omitted, the port trust mode of each interface in the system is shown. If the platform does not support independent per-port class of service mappings, the output represents the system-wide port trust mode used for all interfaces.

Syntax

show queue trust {<slot/port> | port-channel <portchannel-id>}

< slot/port > - The interface number.

ortchannel-id> - The port-channel interface number. The range of port-channel ID is 1 to 64.

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Message

Class of Service Trust Mode: The trust mode of this interface.

Non-IP Traffic Class: The traffic class used for non-IP traffic. This is only displayed when the COS trust mode is set to either 'trust ip-dscp' or 'trust ip-precedence'.

Untrusted Traffic Class: The traffic class used for all untrusted traffic. This is only displayed when the COS trust mode is set to 'untrusted'.

5.23.1.4 show queue cos-queue

This command displays the class-of-service queue configuration for the specified interface. The slot/port parameter is optional and is only valid on platforms that support independent per-port class of service mappings. If specified, the class-of-service queue configuration of the interface is displayed. If omitted, the most recent global configuration settings are displayed.

Syntax

show queue cos-queue {<slot/port> | port-channel <portchannel-id>}

< **slot/port** > The interface number.

cportchannel-id> - The port-channel interface number. The range of port-channel ID is 1 to 64.

Default Setting

None

Command Mode

Privileged Exec

Display Message

Interface: This displays the slot/port of the interface. If displaying the global configuration, this output line is replaced with a Global Config indication.

Interface Shaping Rate: The maximum transmission bandwidth limit for the interface as a whole. It is independent of any per-queue maximum bandwidth value(s) in effect for the interface. This is a configured value.

The following information is repeated for each queue on the interface.

Queue Id: An interface supports n queues numbered 0 to (n-1). The specific n value is platform dependent.

Minimum Bandwidth: The minimum transmission bandwidth guarantee for the queue, expressed as a percentage. A value of 0 means bandwidth is not guaranteed and the queue operates using best-effort. This is a configured value.

Scheduler Type: Indicates whether this queue is scheduled for transmission using a strict priority or a weighted scheme. This is a configured value.

Queue Mgmt Type: The queue depth management technique used for this queue, either tail drop or weighted random early discard (WRED). This is a configured value.

5.23.1.5 show queue random-detect

This command displays the global WRED settings for each CoS queue. If you specify the slot/port, the command displays the WRED settings for each CoS queue on the specified interface.

C. materia	
Syntax	

show queue cos-queue {<slot/port> | port-channel <portchannel-id>}

< **slot/port** > The interface number.

ortchannel-id> - The port-channel interface number. The range of port-channel ID is 1 to 64.

Default Setting

None

Command Mode

Privileged Exec

Display Message

Queue Id: An interface supports n queues numbered 0 to (n-1). The specific n value is platform dependent.

WRED Minimum Threshold: The configured minimum threshold the queue depth (as a percentage) where WRED starts marking and dropping traffic.

WRED Maximum Threshold: The configured maximum threshold is the queue depth (as a percentage) above which WRED marks/drops all traffic.

WRED Drop Probability: The configured percentage probability that WRED will mark/drop a packet, when the queue depth is at maximum threshold. (The drop probability increases linearly from 0 just before the minimum threshold, to this value at the maximum threshold, then goes to 100% for larger queue depths.

5.23.2 Configuration Commands

5.23.2.1 queue cos-map

This command maps an 802.1p priority to an internal traffic class on a "per-port" basis.

Syntax						
	~ -	~ -				

queue cos-map <0-7> <0-7> no queue cos-map

< 0-7 > - The range of queue priority is 0 to 7.

< 0-7 > - The range of mapped traffic class is 0 to 7.

no - Reset to the default mapping of the queue priority and the mapped traffic class.

Default Setting

None

Command Mode

Interface Config.

This command maps an 802.1p priority to an internal traffic class for a device.

queue cos-map all <0-7> <0-7> no queue cos-map all

< 0-7 > - The range of queue priority is 0 to 7.

< 0-7 > - The range of mapped traffic class is 0 to 7.

no - Reset to the default mapping of the queue priority and the mapped traffic class.

Default Setting

None

Command Mode

5.23.2.2 queue trust

This command sets the class of service trust mode of an interface. You can set the mode to trust one of the Dot1p (802.1p) or IP DSCP packet markings. You can also set the interface mode to untrusted. If you configure an interface to use Dot1p, the mode does not appear in the output of the show running config command because Dot1p is the default.

Syntax

queue trust {dot1p | ip-dscp | untrusted } all no queue trust all

no - This command sets the class of service trust mode to untrusted for all interfaces.

Default Setting

dot1p

Command Mode

Global Config.

Syntax

queue trust {dot1p | ip-dscp | untrusted }
no queue trust

no - This command sets the class of service trust mode to untrusted for all interfaces.

Default Setting

dot1p

Command Mode

Interface Config.

5.23.2.3 queue cos-queue min-bandwidth

This command specifies the minimum transmission bandwidth guarantee for each interface queue.

Suntay	,
Syntax	(

queue cos-queue min-bandwidth <bw-0> <bw-1> ··· <bw-7> no queue cos-queue min-bandwidth

<bw-0> <bw-1> ··· **<bw-7>-** Each Valid range is (0 to 100) in increments of 5 and the total sum is less than or equal to 100.

no - This command restores the default for each queue's minimum bandwidth value.

Default Setting

None

Command Mode

Interface Config.

This command specifies the minimum transmission bandwidth guarantee for each interface queue in the device.

Syntax

queue cos-queue min-bandwidth all <bw-0> <bw-1> ··· <bw-7> no queue cos-queue min-bandwidth all

<bw-0> <bw-1> ···· <bw-7>- Each Valid range is (0 to 100) in increments of 1 and the total sum is less than or equal to 100.

no - This command restores the default for each queue's minimum bandwidth value in the device.

Default Setting

None

Command Mode

5.23.2.4 queue cos-queue strict

This command activates the strict priority scheduler mode for each specified queue on a "per-port" basis.

Syntax	-
Synta	Λ.

```
queue cos-queue strict <queue-id-0> [<queue-id-1> ··· <queue-id-7>]
no queue cos-queue strict <queue-id-0> [<queue-id-1> ··· <queue-id-7>]
```

no - This command restores the default weighted scheduler mode for each specified queue on a "per-port" basis.

Default Setting

None

Command Mode

Interface Config.

This command activates the strict priority scheduler mode for each specified queue on a device.

Syntax

queue cos-queue strict all <queue-id-0> [<queue-id-1> ··· <queue-id-7>] no queue cos-queue strict all <queue-id-0> [<queue-id-1> ··· <queue-id-7>]

no - This command restores the default weighted scheduler mode for each specified queue on a device.

Default Setting

None

Command Mode

5.23.2.5 queue cos-queue traffic-shape

This command specifies the maximum transmission bandwidth limit for the interface as a whole. Also known as rate shaping, this has the effect of smoothing temporary traffic bursts over time so that the transmitted traffic rate is bounded.

queue cos-queue traffic-shape <bw> no queue cos-queue traffic-shape

<bw> - Valid range is (0 to 100) in increments 1.

no - This command restores the default shaping rate value.

Default Setting

None

Command Mode

Interface Config.

This command specifies the maximum transmission bandwidth limit for all interfaces. Also known as rate shaping, this has the effect of smoothing temporary traffic bursts over time so that the transmitted traffic rate is bounded.

C.	ntax	
Jy	шах	

queue cos-queue traffic-shape all <bw> no queue cos-queue traffic-shape all

<bw> - Valid range is (0 to 100) in increments 1.

no - This command restores the default shaping rate value for all interfaces.

Default Setting

None

Command Mode

5.23.2.6 queue cos-queue random-detect

This command activates weighted random early discard (WRED) for each specified queue on the interfaces. Specific WRED parameters are configured using the random-detect queue-parms and the random-detect exponential-weighting-constant commands.

Syntax

queue cos-queue random-detect <queue-id-0> [<queue-id-1> ··· <queue-id-7>] no queue cos-queue random-detect <queue-id-0> [<queue-id-1> ··· <queue-id-7>]

<queue-id> - queue ID from 0 to 7.

no - This command restores the default value.

Default Setting

None

Command Mode

Interface Config.

5.24 Auto-Voice over IP Commands

This section describes the commands you use to configure Auto-Voice over IP (VoIP) commands. The Auto-VoIP feature explicitly matches VoIP streams in Ethernet switches and provides them with a better class-of-service than ordinary traffic. When you enable the Auto-VoIP feature on an interface, the interface scans incoming traffic for the following call-control protocols:

- Session Initiation Protocol (SIP)
- H.323
- Skinny Client Control Protocol (SCCP)

When a call-control protocol is detected, the switch assigns the traffic in that session to the highest CoS queue, which is generally used for time-sensitive traffic.

5.24.1 Show Commands

5.24.1.1 show auto-voip

Use this command to display the VoIP Profile settings on the interface or interfaces of the switch.

Syntax

show auto-voip {oui-based [interface [{< slot/port > | port-channel <portchannel-id>}]] | protocol-based interface [{< slot/port > | port-channel <portchannel-id>}] | oui-table}

< slot/port > - The interface number.

cportchannel-id> - The port-channel interface number. The range of port-channel ID is 1 to 64.

oui-based - Show OUI based auto VoIP

oui-table - Show Auto VoIP OUI Table

protocol-based - Show call control protocol based auto VoIP

Default Setting

None

Command Mode

Privileged EXEC

Display Message

AutoVoIP Mode: The Auto VoIP mode on the interface.

Traffic Class: The CoS Queue or Traffic Class to which all VoIP traffic is mapped to. This is not configurable and defaults to the highest CoS queue available in the system for data traffic.



5.24.2 Configuration Commands

5.24.2.1 auto-voip

Use this command to enable VoIP Profile on the interfaces of the switch.

Syntax

auto-voip {{oui <oui-prefix> oui-desc <string>} | {oui-based [priority <priority-value>]} | {protocol-based [remark <0-7> | traffic-class <0-7>]} | {vlan <vlan-id>}} no auto-voip {{oui <oui-prefix>} | {oui-based [priority]} | {[protocol-based {remark| traffic-class}]} | vlan}

no - Use this command to disable VoIP Profile on the interfaces of the switch.

Default Setting

Disable

Command Mode

Global Config.

5.24.2.2 auto-voip

Use this command to enable VoIP Profile on an interface or range of interfaces.

Syntax

auto-voip {oui-based | protocol-based} no auto-voip {oui-based | protocol-based}

no - Use this command to disable VoIP Profile on the interface.

Default Setting

Disable

Command Mode

Interface Config.

5.25 iSCSI Optimization Commands

This section describes commands you use to monitor iSCSI sessions and prioritize iSCSI packets. iSCSI Optimzation provides a means of giving traffic between iSCSI initiator and target systems special Quality of Service (QoS) treatment. This is accomplished by monitoring traffic to detect packets used by iSCSI stations to establish iSCSI sessions and connections. Data from these exchanges is used to create classification rules that assign the traffic between the stations to a configured traffic class. Packets in the flow are queued and scheduled for egress on the destination port based on these rules.

5.25.1 Show Commands

5.25.1.1 show iscsi

This command displays the iSCSI settings.

Syntax

show iscsi

Default Setting

None

Command Mode

Privileged EXEC

Display Message

Example : show iscsi iSCSI enabled iSCSI vpt is 5 Session aging time: 10 min Maximum number of sessions is 192

iSCSI Targets and TCP Ports:

TCP Port	Target IP Address	Name
860	-	-
3260	-	-

5.25.1.2 show iscsi sessions

This command displays the iSCSI sessions.

Syntax

show iscsi sessions [detailed]

Default Setting

None

Command Mode

Privileged EXEC

Display Message

Example #1: show iscsi sessions

Session 0:

Target: iqn.2006-03.com.kernsafe:q97041406.ImageDisk0

Initiator: iqn.2003-06.com.starwindsoftware.starport:ap111111 ISID: 801234567890

Example #2: show iscsi sessions detailed

Session 0:

Target: ign.2006-03.com.kernsafe:q97041406.ImageDisk0

Initiator: iqn.2003-06.com.starwindsoftware.starport:ap111111 Up Time: 00:00:11:00 (DD:HH:MM:SS) Time for aging out: 598 secs ISID: 801234567890

Initiator	Initiator Targ	get	Target
IP Address	TCP Port	IP Address	TCP Port
172.16.2.147	1090	172.16.2.151	3260
172.16.2.147	1092	172.16.2.151	3260



5.25.2 Configuration Commands

5.25.2.1 iscsi enable

This command globally enables iSCSI awareness.

Syntax				
iscsi enab	ble			
no iscsi e	enable			

no - This command disables iSCSI awareness. When you use the no iscsi enable command, iSCSI resources will be released.

Default Setting

Disable

Command Mode



5.25.2.2 iscsi cos

This command sets the quality of service profile that will be applied to iSCSI flows. iSCSI flows are assigned by default to the highest VPT/DSCP mapped to the highest queue not used for stack management. The user should also take care of configuring the relevant Class of Service parameters for the queue in order to complete the setting.

Setting the VPT/DSCP sets the QoS profile which determines the egress queue to which the frame is mapped. The switch default setting for egress queues scheduling is Weighted Round Robin (WRR).

You may complete the QoS setting by configuring the relevant ports to work in other scheduling and queue management modes via the Class of Service settings. Depending on the platform, these choices may include strict priority for the queue used for iSCSI traffic. The downside of strict priority is that, in certain circumstances (under heavy high priority traffic), other lower priority traffic may get starved. In WRR the queue to which the flow is assigned to can be set to get the required percentage.

Syntax

iscsi cos { dscp <dscp> [remark] | vpt <vpt> }
no iscsi cos

vpt/dscp - The VLAN Priority Tag or DSCP to assign iSCSI session packets.

remark - Mark the iSCSI frames with the configured VPT/DSCP when egressing the switch.

no - Use this command to disable VoIP Profile on the interface.

Default Setting

5 (vpt)

Command Mode

5.25.2.3 iscsi aging time

This command sets the aging time for iSCSI sessions. Behavior when changing aging time:

- When aging time is increased, current sessions will be timed out according to the new value.
- When aging time is decreased, any sessions that have been dormant for a time exceeding the new setting will be immediately deleted from the table. All other sessions will continue to be monitored against the new time out value.

Syntax	
iscsi agin	g time <time></time>
no iscsi a	ging time

time - The number of minutes a session must be inactive prior to its removal. Range: 1-43,200.

no - Use the no form of the command to reset the aging time value to the default value.

Default Setting

10 minutes

Command Mode

5.25.2.4 iscsi target port

This command configures an iSCSI target port and, optionally, a target system's IP address and IQN name. When working with private iSCSI ports (not IANA-assigned ports 3260/860), it is recommended to specify the target IP address as well, so that the switch will only snoop frames with which the TCP destination port is one of the configured TCP ports, and the destination IP is the target's IP address. This way the CPU will not be falsely loaded by non-iSCSI flows (if by chance other applications also choose to use these un-reserved ports.

When a port is already defined and not bound to an IP address, and you want to bind it to an IP address, you should first remove it by using the no form of the command and then add it again, this time together with the relevant IP address.

Target names are only for display when using the show iscsi command. These names are not used to match with the iSCSI session information acquired by snooping.

A maximum of 16 TCP ports can be configured either bound to IP or not.

Syntax

iscsi target port tcp-port-1 [tcp-port-2...tcp-port-16] [address ip-address] [name targetname] no iscsi target port tcp-port-1 [tcp-port-2...tcp-port-16] [address ip-address]

tcp-port-n - TCP port number or list of TCP port numbers on which the iSCSI target listens to requests. Up to 16 TCP ports can be defined in the system in one command or by using multiple commands.

ip-address - IP address of the iSCSI target. When the no form of this command is used, and the tcp port to be deleted is one bound to a specific IP address, the address field must be present.

Targetname - iSCSI name of the iSCSI target. The name can be statically configured; however, it can be obtained from iSNS or from sendTargets response. The initiator must present both its iSCSI Initiator Name and the iSCSI Target Name to which it wishes to connect in the first login request of a new session or connection.

no - Use the no form of the command to delete an iSCSI target port, address, and name.

Default Setting

iSCSI well-known ports 3260 and 860 are configured as default but can be removed as any

other configured target.

Command Mode



5.26 **Domain Name Server Relay Commands**

5.26.1 Show Commands

5.26.1.1 show hosts

This command displays the static host name-to-address mapping table.

Syntax			
show host	ts		

Default Setting

None

Command Mode

Privileged Exec

Display Message

Domain Name List: Domain Name.

IP Address: IPv4 or IPv6 address of the Host.

5.26.1.2 show dns

This command displays the configuration of the DNS server.

Syntax	
show dns	

Default Setting

None

Command Mode

Privileged Exec

Display Message

Domain Lookup Status: Enable or disable the IP Domain Naming System (DNS)-based host name-to-address translation function.

Domain Relay Status: Enable or disable the IP Domain Naming System (DNS)-based host name-to-address relay function.

Default Domain Name: The default domain name that will be used for querying the IP address of a host.

DNS Client Source Interface: The interface to use as the source interface.

DNS Client Source IPv4 Address: The IPv4 address used for the DNS client to send packets.

DNS Client Source IPv6 Address: The IPv6 address used for the DNS client to send packets.

Domain Name List: A list of domain names that will be used for querying the IP address of a host.

Name Server List: A list of domain name servers, including IPv4 and IPv6.

Request: Number of the DNS query packets been sent.

Response: Number of the DNS response packets been received.

5.26.1.3 show dns cache

This command displays all entries in the DNS cache table.

_		
S١	/ntax	

show dns cache

Default Setting

None

Command Mode

Privileged Exec

Display Message

Domain Name List: Domain Name

IP Address: IP address of the corresponding domain name, including IPv4 and IPv6.

TTL: Time in seconds that this entry will remain in the DNS cache table

Flag: Indicates if this entry is reliable. A value of 8 is not as reliable as a value of 10.

5.26.2 Configuration Commands

5.26.2.1 ip hosts

This command creates a static entry in the DNS table that maps a host name to an IP address.

There are maximum 8 entries for IPv4 and 8 entries for IPv6.

ip host <name> <ipaddr | ipv6addr > no ip host <name>

<name> - Host name.

<ipaddr|ipv6addr > - IPv4 or IPv6 address of the host.

<no> - Remove the corresponding name to IP address mapping entry.

Default Setting

None

Command Mode

Global Config

5.26.2.2 clear hosts

This command clears the entire static host name-to-address mapping table.

Syntax			
clear host	ts		

Default Setting

None

Command Mode

Privileged Exec

5.26.2.3 ip domain-name

This command defines the default domain name to be appended to incomplete host names (i.e., host names passed from a client are not formatted with dotted notation).

Syntax
SVIILAX

ip domain-name <name> no ip domain-name <name>

<name> - Default domain name used to complete unqualified host names. Do not include the initial period that separates an unqualified name from the domain name. (Range: 1-64 characters)

Default Setting

None

Command Mode

5.26.2.4 ip domain-list

This command defines the domain name that can be appended to incomplete host names (i.e., host names passed from a client are not formatted with dotted notation). The domain name table can contain maximum 6 entries.

Syntax	
ip domain-	-list <name></name>
no ip doma	ain-list <name></name>

<name> - Default domain name used to complete unqualified host names. Do not include the initial period that separates an unqualified name from the domain name. (Range: 1-64 characters)



When an incomplete host name is received by the DNS server on this switch, it will work through the domain name list, append each domain name in the list to the host name, and check with the specified name servers for a match. If there is no domain name list, the domain name specified with the "*ip domain-name*" command is used. If there is a domain name list, the default domain name is not used.

Default Setting

None

Command Mode



5.26.2.5 ip name-server

This command specifies the address of one or more domain name servers to use for name-to-address resolution. There are maximum 6 entries for IPv4 and 6 entries for IPv6 in the Domain Name Server Table.

Syntax	
ip name-s	erver <ipaddr></ipaddr>
no ip nam	e-server <ipaddr></ipaddr>

< ipaddr > - IP address of the Domain Name Servers.

<no> - Remove the corresponding Domain Name Server entry from the table.

Note - The listed name servers are queried in the specified sequence until a response is received, or the end of the list is reached with no response.

Default Setting

None

Command Mode

Global Config

5.26.2.6 ip name-server source-interface

This command specifies the source address of dns client to use for name-to-address resolution.

Syntax

ip name-server source-interface {<slot/port> | loopback <loopback-id> | tunnel <tunnel-id> | vlan <vlan-id>} no ip name-server source-interface

<slot/port> - Specifies the interface to use as the source interface.

<loopback-id> - Specifies the loopback interface to use as the source interface. The range of the loopback ID is 0 to 7.

<tunnel-id> - Specifies the tunnel interface to use as the source interface. The range of the tunnel ID is 0 to 7.

<vlan-id> - Specifies the VLAN interface to use as the source interface. The range of the VLAN ID is 1 to 4093.

<no> - Remove the corresponding Domain Name Server entry from the table.

Default Setting

None

625



Command Mode

5.26.2.7 ip domain-lookup

This command enables the IP Domain Naming System (DNS)-based host name-to-address translation.

Syntax		
ip domain-lo	lookup	1
no ip domai	ain-lookup	

<no> - This command disables the IP Domain Naming System (DNS)-based host name-to-address translation.

Default Setting

Enabled

Command Mode

Global Config

5.26.2.8 ip domain-lookup relay

This command enables the IP Domain Naming System (DNS)-based host name-to-address relay translation.

Syntax

ip domain-lookup relay no ip domain-lookup realy

<no> - This command disables the IP Domain Naming System (DNS)-based host name-to-address relay translation.

Default Setting

Disabled

Command Mode

5.26.2.9 clear domain-list

This command clears all entries in the domain name list table.

Syntax

clear domain-list

Default Setting

None

Command Mode

Privileged Exec

5.26.2.10 clear dns

This command sets the DNS configuration to default value.

Syntax

clear dns

Default Setting

None

Command Mode

Privileged Exec

5.26.2.11 clear dns cache

This command clears all entries in the DNS cache table.

Syntax

clear dns cache

Default Setting

None

Command Mode

Privileged Exec

5.26.2.12 clear dns counter

This command clears the statistics of all entries in the DNS cache table.

Syntax

clear dns counter

Default Setting

None

Command Mode

Privileged Exec

5.27 UDLD Commands

5.27.1 Show command

5.27.1.1 show udld

Show UDLD information in all interfaces or specific interface

Syntax

show udld {< slot/port>}

<slot/port> - The interface number.

Default Setting

None

Command Mode

Privileged Exec

Display Message

Port enable operational state: Specifies the Port Enable Operational State of the selected port.

Current bidirectional state: Specifies the Bidirectional State of the selected port.

Current operational state: Specifies the runtime Operational State of the selected port. This section will be hidden if the port doesn't enable udld.

Message interval: Specifies the runtime Message Interval of the selected port. This section will be hidden if the port doesn't enable udld.

Timeout interval: Specifies the runtime Timeout Interval of the selected port. This section will be hidden if the port doesn't enable udld.

Remote Entry: Display all the remote entry information if received.

Expiration time: Specifies the runtime Expiration Time of the remote entry.

Device ID: Specifies the Device Id associated with the remote system.

Device Name: Specifies the Device Name associated with the remote system.

Port ID: Specifies the Port Id associated with the remote system.

Neighbor echo device: Specifies the Device Id included in Echo TLV associated with the remote system.

Neighbor echo port: Specifies the port Id included in Echo TLV associated with the remote system.

Message interval: Specifies the Message Interval associated with the remote system.

Timeout interval: Specifies the Message Interval associated with the remote system.

CDP Device Name: Specifies the CDP Device Name associated with the remote system.



QuantaMesh | Switching Commands 6

631



5.27.2 Configuration Commands

5.27.2.1 udld aggressive

Enable/Disable UDLD protocol in aggressive mode on fiber ports except where locally configured

Syntax	
udld aggr	ressive
no udld a	aggressive

Default Setting

Disabled

Command Mode

Global Config.

5.27.2.2 udld enable

Enable/Disable UDLD protocol on fiber ports except where locally configured

Syntax			
udld enat	able		
no udld e	enable		

Default Setting

Disabled

Command Mode

5.27.2.3 udld message time

Set UDLD message time period in <7-90> range. The message time is to use between sending of messages in steady. Default value of UDLD message time is 15.

Syntax

udld message time <7-90>

no udld message time

Default Setting

15 sec

Command Mode

Global Config.

5.27.2.4 udld port

Enable/Disable UDLD protocol on the interface.

Syntax		
udld port		
no udld port		

Default Setting

Disable

Command Mode

Interface Config.

5.27.2.5 udld port aggressive

Enable/Disable UDLD protocol in aggressive mode on the interface

Syntax

udld port aggressive

no udld port aggressive

Default Setting

Disable

Command Mode

Interface Config.

5.28 Multi Chassis Link Aggregation Commands

5.28.1 Show Commands

5.28.1.1 show mlag

This command displays detailed information about the Multi-chassis Link Aggregation (MLAG) configured on the switch.

Syntax

show mlag <mlag-number>

Default Setting

None

Command Mode

Privileged Exec

Display Message

Admin Mode: Displays the administrative mode for MLAG functionality on the switch.

Domain Id: Represents the domain identify number of MLAG peer devices.

MLAG Status: Represents the operation status of MLAG.

Configuration Consistency Status: Represents the configuration consistency status of MLAG peer devices.

MLAG Role: Represents the role of MLAG peer device.

MLAG System-Mac: Represents the operation system MAC address of MLAG peer devices.

MLAG Local System-Mac: Represents the statically defined system MAC address of MLAG peer devices.

Number of MLAG Configured: Represents the number of MLAG port-channel member.

Peer Gateway Mode: To enable Layer 3 forwarding for packets destined to the gateway MAC address of the MLAG.

Delay Restore Time: To delay the MLAG from coming up on the restored MLAG peer device after a reload when the peer adjacency is already established. The range is from 5 to 600 seconds.

Keepalive Timeout: To specify the timeout (in seconds) between re-transmissions to the MLAG peer device. The range is from 3 to 20.

Interface: Shows the interface on which MLAG information is being displayed.

Status: Represents the link status of MLAG peer link port or port-channel member.

ID: Represents the identify number of MLAG port-channel member.

Consistency: Represents the configuration consistency status of MLAG port-channel member.

Active Vlan: Represents the VLAN which MLAG peer link port or port-channel member belong to.



QuantaMesh | Switching Commands

636

5.28.1.2 show mlag consistency-parameters

This command displays the consistency of parameters that must be compatible across the Multi-chassis Link Aggregation (MLAG).

Syntax

show mlag consistency-parameters <mlag-number>

Default Setting

None

Command Mode

Privileged Exec

Display Message

Spanning Tree Admin Mode: Indicates whether administrative mode is enabled or disabled of MLAG peer devices.

Spanning Tree Version: Represents the version of 802.1 currently supported (IEEE 802.1s, IEEE 802.1w, or IEEE 802.1d) based upon the Force Protocol Version parameter of MLAG peer devices.

Spanning Tree Configuration Name: Represents the configured name of MLAG peer devices.

Spanning Tree BPDU Guard Mode: Indicates whether BPDU guard mode is enabled or disabled of MLAG peer devices.

Spanning Tree BPDU Filter Mode: Indicates whether BPDU filter mode is enabled or disabled of MLAG peer devices.

Spanning Tree Peer-Link Port Mode: Indicates whether port mode on peer link port is enabled or disabled of MLAG peer devices.

Spanning Tree Peer-Link Root Guard: Indicates whether root guard mode on peer link port is enabled or disabled of MLAG peer devices.

Spanning Tree Peer-Link Loop Guard: Indicates whether loop guard mode on peer link port is enabled or disabled of MLAG peer devices.

Spanning Tree Peer-Link BPDU Guard: Indicates whether BPDU guard mode on peer link port is enabled or disabled of MLAG peer devices.

Spanning Tree Peer-Link BPDU Filter Mode: Indicates whether BPDU filter mode on peer link port is enabled or disabled of MLAG peer devices.

Spanning Tree Peer-Link BPDU Flood Mode: Indicates whether BPDU flood mode on peer link port is enabled or disabled of MLAG peer devices.

VTP Admin Status: Indicates whether administrative mode is enabled or disabled of MLAG peer devices.

VTP Operating Mode: Displays the VTP operating mode of MLAG peer devices, which can be server, client, or transparent.

VTP Pruning Mode: Displays whether pruning is enabled or disabled of MLAG peer devices.

VTP V2 Mode: Displays if VTP version 2 mode is enabled of MLAG peer devices.

VTP Domain Name: Displays the name that identifies the administrative domain of MLAG peer devices.

VTP Password: Displays the VTP domain password of MLAG peer devices.

IGMP Snooping Admin Mode: Indicates whether or not IGMP Snooping is active on the switch of MLAG peer devices.

MLD Snooping Admin Mode: Indicates whether or not MLD Snooping is active on the switch of MLAG peer devices.

GMRP Admin Mode: This displays the administrative mode of GARP VLAN Registration Protocol (GVRP) for the system of MLAG peer devices.

GVRP Admin Mode: This displays the administrative mode of GARP Multicast Registration Protocol (GMRP) for the system of MLAG peer devices.

When you specify a value for <mlag-number>, the following information appears.

Spanning Tree Port Mode: Indicates whether port mode on MLAG member is enabled or disabled of MLAG peer devices.

Spanning Tree Root Guard: Indicates whether root guard mode on MLAG member is enabled or disabled of MLAG peer devices.

Spanning Tree Loop Guard: Indicates whether loop guard mode on MLAG member is enabled or disabled of MLAG peer devices.

Spanning Tree BPDU Guard: Indicates whether BPDU guard mode on MLAG member is enabled or disabled of MLAG peer devices.

Spanning Tree BPDU Filter Mode: Indicates whether BPDU filter mode on MLAG member is enabled or disabled of MLAG peer devices.

Spanning Tree BPDU Flood Mode: Indicates whether BPDU flood mode on MLAG member is enabled or disabled of MLAG peer devices.

VTP Port Trunk Mode: Indicates whether trunk mode is enabled or disabled on MLAG member of MLAG peer devices.

IGMP Snooping Mode: Indicates whether or not IGMP Snooping is active on MLAG member of MLAG peer devices.

MLD Snooping Mode: Indicates whether or not MLD Snooping is active on MLAG member of MLAG peer devices.

GMRP Mode: This displays the administrative mode of GARP VLAN Registration Protocol (GVRP) for MLAG member of MLAG peer devices.

GVRP Mode: This displays the administrative mode of GARP Multicast Registration Protocol (GMRP) for MLAG member of MLAG peer devices..

5.28.2 Configuration Commands

5.28.2.1 mlag

This command enables a Multi-chassis Link Aggregation (MLAG), which allows links that are physically connected to two different devices to appear as a single port channel to a third device.

To disable MLAG on the switch, use the no form of this command.

Syntax	
mlag no mlag	

Default Setting

Disabled

Command Mode

Global Config

5.28.2.2 mlag domain

This command creates a Multi-chassis Link Aggregation (MLAG) domain and assign a domain ID. The range is from 1 and 1000.

To revert to the default mlag configuration, use the no form of this command

Syntax	
mlag doma	ain <domain-id></domain-id>
no mlag do	omain

<domain-id> - Domain identify number of MLAG (Range: 1 – 1000).

Default Setting

1

Command Mode

5.28.2.3 mlag system-mac

This command manually configures the Multi-chassis Link Aggregation (MLAG) domain MAC address. To restore the default system MAC address, use the no form of this command.

Syntax	
mlag syste	em-mac <mac-address></mac-address>
no mlag s	ystem-mac

<mac-address> - Syatem MAC adress.

Default Setting

None

Command Mode

Global Config

5.28.2.4 mlag peer-link

This command creates a Multi-chassis Link Aggregation (MLAG) peer link by designating the port channel that you want on each device as the peer link for the specified MLAG domain.

To remove the peer link, use the no form of this command.

Syntax	
mlag peer-	-link
no mlag pe	eer-link

Default Setting

Disabled

Command Mode

Interface Config

5.28.2.5 mlag <mlag-number>

This command moves other port channels into a Multi-chassis Link Aggregation (MLAG) to connect to the downstream device. The range is from 1 and 4096.

To remove the port channels from the mlag, use the no form of this command.

Syntax		
mlag <mla no mlag</mla 	ag-number>	

<mlag-number> - Domain identify number of MLAG port-channel member (Range: 1 – 4096).

Default Setting

Disabled

Command Mode

Interface Config

5.28.2.6 mlag peer-gateway

This command enable Layer 3 forwarding for packets destined to the gateway MAC address of the MLAG. Use no form to disable it.

Syntax

mlag peer-	-gateway
no mlag pe	eer-gateway

no – This command disable the peer-gateway.

Default Setting

Enabled

Command Mode

5.28.2.7 mlag keepaliv-timeout

This command is used to specify the timeout (in seconds) between re-transmissions to the MLAG peer device.

Syntax

mlag keepalive-timeout <3-20> no mlag keepalive-timeout

<3-20> - Specify the timeout value between re-transmissions.

no - This command restore the setting to default value.

Default Setting

5

Command Mode

Global Config

5.28.2.8 mlag delay-restore

This command is used to specify the time to delay the MLAG from coming up on the restored MLAG peer device aftera reload when the peer adjacency is already established.

Syntax

mlag delay-restore <5-600> no mlag delay-restore

<5-600> - Specify the number of seconds to delay bringing up the restored MLAG peer device.

no - This command restore the setting to default value.

Default Setting

10

Command Mode

5.29 Control Plane Protection Commands

5.29.1 Show Commands

5.29.1.1 show access-lists interface control-plane

This command displays IP ACLs, IPv6 ACLs, and MAC access control lists information for CPU port.

Syntax

show access-lists interface control-plane

Default Setting

None

Command Mode

Privileged Exec

Display Message

ACL Type : Type of access list (IP, IPv6 or MAC).

ACL ID : Access List name for a MAC or IPv6 access list or the numeric identifier for an IP access list.

Sequence Number: An optional sequence number may be specified to indicate the order of this access list relative to other access lists already assigned to this interface. A lower number indicates higher precedence order. If a sequence number is already in use for this interface, the specified ccess list replaces the currently attached access list using that sequence number. If the sequence number is not specified by the user, a sequence number that is one greater than the highest sequence number currently in use for this interface is used. Valid range is (1 to 4294967295).

5.29.2 Configuration Commands

5.29.2.1 interface control-plane

To enter control-plane configuration mode and apply a IP, IPv6 or MAC access list to police traffic destined for the CPU port, use the **interface control-plane** command in global configuration mode.

Syntax

Interface control-plane

Default Setting

No control plane access lists are defined.

Command Mode



6 Routing Commands

6.1 Address Resolution Protocol (ARP) Commands

6.1.1 Show Commands

6.1.1.1 **show ip arp**

This command displays the Address Resolution Protocol (ARP) cache.

Syntax

show ip arp

Default Setting

None

Command Mode

Privileged Exec

Display Message

Age Time: Is the time it takes for an ARP entry to age out. This value was configured into the unit. Age time is measured in seconds.

Response Time: Is the time it takes for an ARP request timeout. This value was configured into the unit. Response time is measured in seconds.

Retries: Is the maximum number of times an ARP request is retried. This value was configured into the unit.

Cache Size: Is the maximum number of entries in the ARP table. This value was configured into the unit.

Dynamic renew mode: Displays whether the ARP component automatically attempts to renew dynamic ARP entries when they aged out.

Total Entry Count Current/Peak: Field listing the total entries in the ARP table and the peak entry count in the ARP table.

Static Entry Count Configured/Active/Max: Field listing configured static entry count, active static entry count, and maximum static entry count in the ARP table.

The following are displayed for each ARP entry.

IP Address: Is the IP address of a device on a subnet attached to an existing routing interface.

MAC Address: Is the hardware MAC address of that device.

Interface: Is the routing slot/port associated with the device ARP entry

Type: Is the type that was configured into the unit. The possible values are Local, Gateway, Dynamic and Static.

Age: This field displays the current age of the ARP entry since last refresh (in hh:mm:ss format).

6.1.1.2 show ip arp brief

This command displays the brief Address Resolution Protocol (ARP) table information.

Syntax

show ip arp brief

Default Setting

None

Command Mode

Privileged Exec

Display Message

Age Time: Is the time it takes for an ARP entry to age out. This value was configured into the unit. Age time is measured in seconds.

Response Time: Is the time it takes for an ARP request timeout. This value was configured into the unit. Response time is measured in seconds.

Retries: Is the maximum number of times an ARP request is retried. This value was configured into the unit.

Cache Size: Is the maximum number of entries in the ARP table. This value was configured into the unit.

Dynamic renew mode: Displays whether the ARP component automatically attempts to renew dynamic ARP entries when they aged out.

Total Entry Count Current/Peak: Field listing the total entries in the ARP table and the peak entry count in the ARP table.

Static Entry Count Configured/Active/Max: Field listing the configured static entry count, active static entry count, and maximum static entry count in the ARP table.

646

6.1.1.3 show ip arp static

This command displays the static Address Resolution Protocol (ARP) table information.

Syntax				

show ip arp static

Default Setting

None

Command Mode

Privileged Exec

Display Message

IP address: Is the IP address of a device on a subnet attached to an existing routing interface.

MAC address: Is the MAC address for that device.

6.1.2 Configuration Commands

6.1.2.1 **arp**

This command creates an ARP entry. The value for <ipaddress> is the IP address of a device on a subnet attached to an existing routing interface. The value for <macaddress> is a unicast MAC address for that device.

Syntax

-					
arp <ipaddr> <macaddr></macaddr></ipaddr>					
no arp <ipaddr> <macaddr></macaddr></ipaddr>					

<ipaddr> - Is the IP address of a device on a subnet attached to an existing routing interface.

<macaddr> - Is a MAC address for that device. The format is 6 two-digit hexadecimal numbers that are separated by colons, for example, 00:06:29:32:81:40.

no - This command deletes an ARP entry.

Default Setting

None

Command Mode

Global Config

6.1.2.2 arp cachesize

This command configures the maximum number of entries in the ARP cache.

Syntax	
arn cach	

arp cachesize <767-4096> no arp cachesize

<767-3968> - The range of cache size is 767 to 4096.

no - This command configures the default ARP cache size.

Default Setting

The default cache size is 4096.

Command Mode



6.1.2.3 arp dynamicrenew

This command enables ARP component to automatically renew ARP entries of type dynamic when they age out.

Cuntou	
Syntax	

arp dynar	micrenew	
no arp dy	ynamicrenew	

no - This command disables ARP component from automatically renewing ARP entries of type dynamic when they age out.

Default Setting

Disabled

Command Mode

Global Config

6.1.2.4 arp resptime

This command configures the ARP request response timeout.

Syntax			
arp resptir	me <1-10>		
no arp res	sptime		

<1-10> - The range of default response time is 1 to 10 seconds.

no - This command configures the default response timeout time.

Default Setting

The default response time is 1.

Command Mode

Global Config

6.1.2.5 arp retries

This command configures the ARP count of maximum request for retries.

Syntax			
arp retries no arp retr	s <0-10>		
no arp retr	ries		

<0-10> - The range of maximum request for retries is 0 to 10.

no - This command configures the default count of maximum request for retries.

Default Setting

The default value is 4.

Command Mode

Global Config

6.1.2.6 arp timeout

This command configures the ARP entry ageout time.

S	yntax
Э	yniax

Г

arp timeout <15-21600> no arp timeout

<15-21600> - Represents the IP ARP entry ageout time in seconds. The range is 15 to 21600 seconds.

no - This command configures the default ageout time for IP ARP entry.

Default Setting

The default value is 1200.

Command Mode

Global Config

6.1.2.7 arp access-list

Use this command to create an ARP ACL

Syntax

arp access-list <name> no arp access-list <name>

no - Use this command to delete a configured ARP ACL.

Default Setting

None

Command Mode

Global Config

6.1.2.8 permit ip host mac host

Use this command to configure a rule for a valid IP address and MAC address combination used in ARP packet validation.

Syntax

permit ip host <sender-ip> mac host <sender-mac> no permit ip host <sender-ip> mac host <sender-mac>

no – Use this command to delete a rule for a valid IP and MAC combination.

Default Setting

None

Command Mode

ARP Access-list Config

6.1.2.9 clear ip arp-cache

This command causes all ARP entries of type dynamic to be removed form the ARP cache. If the [gateway] parameter is specified, the dynamic entries of type gateway are purged as well.

Syntax

clear ip arp-cache [gateway | interface {<slot/port> | vlan <vlan-id>}]

Default Setting

None

Command Mode

Privileged Exec

6.2 IP Routing Commands

6.2.1 Show Commands

6.2.1.1 show ip brief

This command displays all the summary information of the IP.

Syntax			
show ip b	orief		

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Message

Default Time to Live: The computed TTL (Time to Live) of forwarding a packet from the local router to the final destination.

Routing Mode: Show whether the routing mode is enabled or disabled.

Maximum Next Hops: The maximum number of hops supported by this switch.

Maximum Routes: The maximum number of routes the packet can travel.

ICMP Rate Limit Interval: Shows how often the token bucket is initialized with burst-size tokens. Burst-interval is from 0 to 2147483647 milliseconds. The default burst-interval is 1000 msec.

ICMP Rate Limit Burst Size: Shows the number of ICMPv4 error messages that can be sent during one burst-interval. The range is from 1 to 200 messages. The default value is 100 messages.

ICMP Echo Replies: Shows whether ICMP Echo Replies are enabled or disabled.

ICMP Redirects: Shows whether ICMP Redirects are enabled or disabled.

Dead Gateway Detection: Show whether Dead Gateway Detection is enabled or disabled.

Dead Gateway Detection Probe Interval: Shows the interval that ARP request is sent.

6.2.1.2 show ip interface port

This command displays all pertinent information about the IP interfaces.

Syntax

show ip interface port <slot/port>

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Message

Routing Interface Status: Determine the operational status of IPv4 routing Interface. The possible values are Up or Down.

Primary IP Address: The primary IP address and subnet masks for the interface. This value appears only if you configure it.

Method: Shows whether the IP address was configured manually or acquired from a DHCP server.

Secondary IP Address: One or more secondary IP addresses and subnet masks for the interface. This value appears only if you configure it.

Helper IP Address: The helper IP addresses configured by the command "ip helper-address (Interface Config)".

Routing Mode: The administrative mode of router interface participation. The possible values are enable or disable. This value is configurable.

Administrative Mode: The administrative mode of the specified interface. The possible values of this field are enable or disable. This value is configurable.

Forward Net Directed Broadcasts: Displays whether forwarding of network-directed broadcasts is enabled or disabled. This value is configurable.

Proxy ARP: Displays whether Proxy ARP is enabled or disabled on the system.

Local Proxy ARP: Displays whether Local Proxy ARP is enabled or disabled on the interface.

Active State Displays whether the interface is active or inactive. An interface is considered active if its link is up and it is in forwarding state.

Link Speed Data Rate: An integer representing the physical link data rate of the specified interface. This is measured in Megabits per second (Mbps).

MAC Address: The burned in physical address of the specified interface. The format is 6 two-digit hexadecimal numbers that are separated by colons.

Encapsulation Type: The encapsulation type for the specified interface. The types are: Ethernet or SNAP.

IP MTU: The maximum transmission unit (MTU) size of a frame, in bytes.

Bandwidth: Shows the bandwidth of the interface.

654

Destination Unreachables: Displays whether ICMP Destination Unreachables may be sent (enabled or disabled).

ICMP Redirects: Displays whether ICMP Redirects may be sent (enabled or disabled).

6.2.1.3 show ip interface vlan

This command displays all pertinent information about the VLAN routing interfaces.

Syntax

show ip interface vlan <1-4093>

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Message

Routing Interface Status: Determine the operational status of IPv4 routing Interface. The possible values are Up or Down.

Primary IP Address: The primary IP address and subnet masks for the interface. This value appears only if you configure it.

Method: Shows whether the IP address was configured manually or acquired from a DHCP server.

Secondary IP Address: One or more secondary IP addresses and subnet masks for the interface. This value appears only if you configure it.

Helper IP Address: The helper IP addresses configured by the command "ip helper-address (Interface Config)".

Routing Mode: The administrative mode of router interface participation. The possible values are enable or disable. This value is configurable.

Administrative Mode: The administrative mode of the specified interface. The possible values of this field are enable or disable. This value is configurable.

Forward Net Directed Broadcasts: Displays whether forwarding of network-directed broadcasts is enabled or disabled. This value is configurable.

Proxy ARP: Displays whether Proxy ARP is enabled or disabled on the system.

Local Proxy ARP: Displays whether Local Proxy ARP is enabled or disabled on the interface.

Active State Displays whether the interface is active or inactive. An interface is considered active if its link is up and it is in forwarding state.

Link Speed Data Rate: An integer representing the physical link data rate of the specified interface. This is measured in Megabits per second (Mbps).

655

GUANTA COMPUTER INC.

MAC Address: The burned in physical address of the specified interface. The format is 6 two-digit hexadecimal numbers that are separated by colons.

Encapsulation Type: The encapsulation type for the specified interface. The types are: Ethernet or SNAP.

IP MTU: The maximum transmission unit (MTU) size of a frame, in bytes.

Bandwidth: Shows the bandwidth of the interface.

Destination Unreachables: Displays whether ICMP Destination Unreachables may be sent (enabled or disabled).

ICMP Redirects: Displays whether ICMP Redirects may be sent (enabled or disabled).

6.2.1.4 show ip interface loopback

This command displays information about configured loopback interfaces.

Syntax

show ip interface loopback [<0-7>]

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Message

Loopback Id: The loopback ID associated with the rest of the information in the row..

Interface: The interface name.

IP Address: The IPv4 address of the interface.

If you specify a loopback ID, the following information appears:

Interface Link Status: Shows whether the link is up or down.

IP Address: The IPv4 address of the interface.

MTU size: The maximum transmission size for packets on this interface, in bytes..

6.2.1.5 show ip interface brief

This command displays summary information about IP configuration settings for all ports in the router.

ļ	Syntax				
ļ	show ip ir	nterface brief			

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Message

Interface: Valid slot, and port number separated by forward slashes or VLAN routing interface.

State: Indicate the operational state of the routing interface.

IP Address: The IP address of the routing interface.

IP Mask: The IP mask of the routing interface.

Method: Is the way to get the IP Address. The possible value is "Manual", "DHCP" or "None".**Netdir Bcast:** Indicates if IP forwards net-directed broadcasts on this interface. Possible values are Enable or Disable.

MultiCast Fwd: Indicates the multicast forwarding administrative mode on the interface. Possible values are Enable or Disable.

6.2.1.6 show ip route

This command displays the routing table. The <ip-address> specifies the network for which the route is to be displayed and displays the best matching best-route for the address. The <mask> specifies the subnet mask for the given <ip-address>. When you use the longerprefixes keyword, the <ip-address> and <mask> pair becomes the prefix, and the command displays the routes to the addresses that match that prefix. Use the **<protocol>** parameter to specify the protocol that installed the routes. The value for **<protocol>** can be **connected**, **ospf**, **rip**, **or static**. Use the all parameter to display all routes including best and nonbest routes. If you do not use the all parameter, the command only displays the best route.



If you use the connected keyword for **<protocol>**, the all option is not available because there are no best or non-best connected routes.

Syntax

show ip route [{<ip-address> [<protocol>] | {<ip-address> <mask> [longer-prefixes] [<protocol>] | <protocol>} [all] | all}]

Default Setting

None

Command Mode

Privileged Exec

Display Message

Route Codes: Displays the key for the routing protocol codes that might appear in the routing table output.

The command displays the routing tables in the following format:

Code IP-Address/Mask [Preference/Metric] via Next-Hop, Interface

Code: The codes for the routing protocols that created the routes.

IP-Address/Mask: The IP-Address and mask of the destination network corresponding to this route.

Preference: The administrative distance associated with this route. Routes with low values are preferred over routes with higher values.

Metric: The cost associated with this route.

via Next-Hop: The outgoing router IP address to use when forwarding traffic to the next router (if any) in the path toward the destination

6.2.1.7 show ip route bestroutes

This command displays router route table information for the best routes.

Syntax

show ip route bestroutes

Default Setting

None

Command Mode

Privileged Exec

Display Message

Total Number of Routes: The total number of routes.

Network Address: Is an IP route prefix for the destination.

Subnet Mask: Is a mask of the network and host portion of the IP address for the router interface.

Protocol: Tells which protocol added the specified route. The possibilities are: local, static, OSPF, or RIP.

for each next hop

Next Hop Intf: The outgoing router interface to use when forwarding traffic to the next destination.

Next Hop IP Address: The outgoing router IP address to use when forwarding traffic to the next router (if any) in the path toward the destination.

659

6.2.1.8 show ip route entry

This command displays the router route entry information.

Syntax

show ip route entry <networkaddress>

<networkaddress> - Is a valid network address identifying the network on the specified interface.

Default Setting

None

Command Mode

Privileged Exec

Display Message

Network Address: Is a valid network address identifying the network on the specified interface.

Subnet Mask: Is a mask of the network and host portion of the IP address for the attached network.

Protocol: Tells which protocol added the specified route. The possibilities are: local, static, OSPF, or RIP.

Total Number of Routes: The total number of routes.

for each next hop

Next Hop Intf: The outgoing router interface to use when forwarding traffic to the next destination.

Next Hop IP Address: The outgoing router IP address to use when forwarding traffic to the next router (if any) in the path toward the destination.

Metric: Specifies the metric for this route entry.

Pref: The preference value that is used for this route entry.

6.2.1.9 show ip route connected

This command displays directly connected routes.

Syntax

show ip route connected

Default Setting

None

Command Mode

Privileged Exec

Display Message

Route Codes: Displays the key for the routing protocol codes that might appear in the routing table output.

The command displays the routing tables in the following format:

Code IP-Address/Mask [Preference/Metric] via Next-Hop, Interface

Code: The codes for the routing protocols that created the routes.

IP-Address/Mask: The IP-Address and mask of the destination network corresponding to this route.

Preference: The administrative distance associated with this route. Routes with low values are preferred over routes with higher values.

Metric: The cost associated with this route.

via Next-Hop: The outgoing router IP address to use when forwarding traffic to the next router (if any) in the path toward the destination.

6.2.1.10 show ip route ospf

This command displays Open Shortest Path First (OSPF) routes. The option **all** command displays all (best and non-best) routes.

Syntax

show ip route ospf [all]

Default Setting

None

Command Mode

Privileged Exec

Display Message

Route Codes: Displays the key for the routing protocol codes that might appear in the routing table output.

The command displays the routing tables in the following format:

Code IP-Address/Mask [Preference/Metric] via Next-Hop, Interface

Code: The codes for the routing protocols that created the routes.

IP-Address/Mask: The IP-Address and mask of the destination network corresponding to this route.

Preference: The administrative distance associated with this route. Routes with low values are preferred over routes with higher values.

Metric: The cost associated with this route.

via Next-Hop: The outgoing router IP address to use when forwarding traffic to the next router (if any) in the path toward the destination.

6.2.1.11 show ip route rip

This command displays Routing Information Protocol (RIP) routes. The option **all** command displays all (best and non-best) routes.

Syntax

show ip route rip [all]

Default Setting

None

Command Mode

Privileged Exec

Display Message

Route Codes: Displays the key for the routing protocol codes that might appear in the routing table output.

The command displays the routing tables in the following format:

Code IP-Address/Mask [Preference/Metric] via Next-Hop, Interface

Code: The codes for the routing protocols that created the routes.

IP-Address/Mask: The IP-Address and mask of the destination network corresponding to this route.

Preference: The administrative distance associated with this route. Routes with low values are preferred over routes with higher values.

Metric: The cost associated with this route.

via Next-Hop: The outgoing router IP address to use when forwarding traffic to the next router (if any) in the path toward the destination.

6.2.1.12 show ip route static

This command displays Static Routes. The option all command displays all (best and non-best) routes.

Syntax

show ip route static [all]

Default Setting

None

Command Mode

Privileged Exec

Display Message

Route Codes: Displays the key for the routing protocol codes that might appear in the routing table output.

The command displays the routing tables in the following format:

Code IP-Address/Mask [Preference/Metric] via Next-Hop, Interface

Code: The codes for the routing protocols that created the routes.

IP-Address/Mask: The IP-Address and mask of the destination network corresponding to this route.

Preference: The administrative distance associated with this route. Routes with low values are preferred over routes with higher values.

Metric: The cost associated with this route.

via Next-Hop: The outgoing router IP address to use when forwarding traffic to the next router (if any) in the path toward the destination.

6.2.1.13 show ip route summary

This command displays the routing table summary. Use the optional **all** parameter to show the number of all routes, including best and non-best routes. To include only the number of best routes, do not use the optional parameter.

Syntax

show ip route summary [all]

Default Setting

None

Command Mode

Privileged Exec

Display Message

Connected Routes: The total number of connected routes in the routing table.

Static Routes: Total number of static routes in the routing table.

RIP Routes: Total number of routes installed by RIP protocol.

OSPF Routes: Total number of routes installed by OSPF protocol.

Reject Routes: Total number of reject routes installed by all protocols.

Total Routes: Total number of routes in the routing table.

6.2.1.14 show ip route preferences

This command displays detailed information about the route preferences. Route preferences are used in determining the best route. Lower router preference values are preferred over higher router preference values.

Syntax

show ip route preferences

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Message

Local: This field displays the local route preference value.

Static: This field displays the static route preference value.

OSPF Intra: This field displays the OSPF intra route preference value.

OSPF Inter: This field displays the OSPF inter route preference value.

OSPF External: The OSPF External route preference value.

RIP: This field displays the RIP route preference value.

Configured Default Gateway: The route preference value of the statically-configured default gateway

DHCP Default Gateway: The route preference value of the default gateway learned from the DHCP server.

6.2.1.15 show ip stats

This command displays IP statistical information. Refer to RFC 1213 for more information about the fields that are displayed.

Syntax
Syniax

Г

show ip stats

Default Setting

None

Command Mode

Privileged Exec

6.2.2 Configuration Commands

6.2.2.1 routing

This command enables routing for an interface.

Syntax	
routing no routing	
no routing	g

no - Disable routing for an interface.

Default Setting

Disabled

Command Mode

Interface Config

6.2.2.2 ip routing

This command enables the IP Router Admin Mode for the master switch.

Syntax			
ip routing			
ip routing no ip routin	ng		

no - Disable the IP Router Admin Mode for the master switch.

Default Setting

Disabled

Command Mode

Global Config

6.2.2.3 ip address

This command configures an IP address on an interface. The IP address may be a secondary IP address.

Syntax		
SVDTAX	C	
		vntax

ip address <ipaddr> <subnet-mask> [secondary] no ip address <ipaddr> <subnet-mask> [secondary]

<ipaddr> - IP address of the interface.

<subnet-mask> - Subnet mask of the interface.

[secondary] - It is a secondary IP address.

no - Delete an IP address from an interface.

Default Setting

None

Command Mode

Interface Config

6.2.2.4 ip address dhcp

This command enables the DHCPv4 client on an in-band interface so that it can acquire network information, such as the IP address, subnet mask, and default gateway, from a network DHCP server. When DHCP is enabled on the interface, the system automatically deletes all manually configured IPv4 addresses on the interface.

Syntax	
ip addres	s dhcp [restart]
no ip add	Iress <ipaddr> <subnet-mask> [secondary]</subnet-mask></ipaddr>

[secondary] - To restart IP Address given by DHCP server.

no - This command releases a leased address and disables DHCPv4 on an interface.

Default Setting

Disabled

Command Mode

Interface Config

669

6.2.2.5 ip route

This command configures a static route.

Syntax
Cyntax

Г

ip route <networkaddr> <subnetmask> [{<nexthopip>|Null0} [<1-255 >]] no ip route <networkaddr> <subnetmask> [{ <nexthopip> | <1-255 > | Null0 }]

<ipaddr> - A valid IP address .

<subnetmask> - A valid subnet mask.

<nexthopip> - IP address of the next hop router.

<1-255> - The precedence value of this route. The range is 1 to 255.

Nullo – Null interface.

no - delete all next hops to a destination static route. If the optional <nextHopRtr> parameter is designated, the next hop is deleted and if the optional precedence value is designated, the precedence value of the static route is reset to its default value 1.

Default Setting

None

Command Mode

Global Config

6.2.2.6 ip route default

This command configures the default route.

Syntax

ip route default <nexthopip> [1-255]

<nexthopip> - IP address of the next hop router.

<1-255> - Precedence value of this route.

Default Setting

None

Command Mode

Global Config

6.2.2.7 ip route distance

This command sets the default distance (preference) for static routes. Lower route distance values are preferred when determining the best route. The ip route and ip route default commands allow you to optionally set the distance (preference) of an individual static route. The default distance is used when no distance is specified in these commands. Changing the default distance does not update the distance of existing static routes, even if they were assigned the original default distance. The new default distance will only be applied to static routes created after invoking the ip route distance command.

Syntax

ip route distance <1-255>

<1-255> - Default the Distance value of static routes. The range is 1 to 255.

Default Setting

The default preference value is 1.

Command Mode

Global Config



6.2.2.8 ip mtu

This command sets the IP Maximum Transmission Unit (MTU) on a routing interface or range of interfaces. The IP MTU is the size of the largest IP packet that can be transmitted on the interface without fragmentation. Forwarded packets are dropped if they exceed the IP MTU of the outgoing interface.

Packets originated on the router, such as OSPF packets, may be fragmented by the IP stack.

OSPF advertises the IP MTU in the Database Description packets it sends to its neighbors during database exchange. If two OSPF neighbors advertise different IP MTUs, they will not form an adjacency. (unless OSPF has been instructed to ignore differences in IP MTU with the ip ospf mtu-ignore command.)

Syntax		
ip mtu <68-12270>		
no ip mtu <68-12270>		

<68-12270> - The IP MTU on a routing interface. The range is 68 to 12270.

no - Reset the ip mtu to the default value.

Default Setting

The default value is 1500.

Command Mode

Interface Config

6.2.2.9 encapsulation

This command configures the link layer encapsulation type for the packet.

Curator
Syntax

Г

encapsulation {ethernet | snap}

ethernet - The link layer encapsulation type is ethernet.

snap - The link layer encapsulation type is SNAP.

Default Setting

The default value is ethernet.

Command Mode

Interface Config

Restrictions

Routed frames are always Ethernet encapsulated when a frame is routed to a VLAN.

6.2.2.10 ip dead-gateway-detection

This command configures the Dead Gateway Detection feature.



ip dead-gateway-detection no ip dead-gateway-detection

Default Setting Disabled.

Command Mode

Global Config

6.2.2.11 ip dead-gateway-detection probe-interval

This command configures the probe interval for Dead Gateway Detection feature.

Syntax	

ip dead-gateway-detection probe-interval <1-30> no ip dead-gateway-detection probe-interval

Default Setting

3.

Command Mode

Global Config



6.3 Open Shortest Path First (OSPF) Commands

6.3.1 Show Commands

6.3.1.1 show ip ospf

This command displays information relevant to the OSPF router.



Default Setting

None

Command Mode

Privileged Exec

Display Messages



Some of the information below displays only if you enable OSPF and configure certain features.

Router ID : A 32-bit integer in dotted decimal format identifying the router, about which information is displayed. This is a configured value.

OSPF Admin Mode : Shows whether the administrative mode of OSPF in the router is enabled or disabled. This is a configured value.

RFC 1583 Compatibility : Indicates whether 1583 compatibility is enabled or disabled. This is a configured value.

External LSDB Limit : The maximum number of non-default AS-external-LSA (link state advertisement) entries that can be stored in the link-state database.

Exit Overflow Interval : The number of seconds that, after entering overflow state, a router will attempt to leave overflow state.

Spf Delay Time : The number of seconds between two subsequent changes of LSAs, during which time the routing table calculation is delayed.

Spf Hold Time: The number of seconds between two consecutive spf calculations.

Flood Pacing Interval: The average time, in milliseconds, between LS Update packet transmissions on an interface. This is the value configured with the timers pacing flood command.

LSA Refresh Group Pacing Time: The size of the LSA refresh group window, in seconds. This is the value configured with the timers pacing lsa-group command.**Opaque Capability:** Shows whether the router is capable of sending Opaque LSAs. This is a configured value.

Autocost Ref BW: Shows the value of auto-cost reference bandwidth configured on the router.

Default Passive Setting: Shows whether the interfaces are passive by default.

Maximum Paths: The maximum number of paths that OSPF can report for a given destination.

Default Metric: Default value for redistributed routes.

Network Area: Shows area for the Network Area setting.

Stub Router Configuration: One of Always, Startup, or None.

Summary LSA Metric Override: One of Enabled (met), Disabled, where met is the metric to be

sent in summary LSAs when in stub router mode. **Default Route Advertise:** Indicates whether the default routes received from other source protocols are advertised or not.

Always: Shows whether default routes are always advertised.

Metric: The metric of the routes being redistributed. If the metric is not configured, this field is blank.

Metric Type: Shows whether the routes are External Type 1 or External Type 2.Number of Active

Number of Active Areas: The number of OSPF areas to which the router is attached on interfaces that are up.

ABR Status: Shows whether the router is an OSPF Area Border Router.

ASBR Status: Reflects whether the ASBR mode is enabled or disabled. Enable implies that the router is an autonomous system border router. The router automatically becomes an ASBR when it is configured to redistribute routes learnt from other protocols. The possible values for the ASBR status is enabled (if the router is configured to redistribute routes learned by other protocols) or disabled (if the router is not configured for the same).

Stub Router Status: When OSPF runs out of resources to store the entire link state database, or any other state information, OSPF goes into stub router mode. As a stub router, OSPF re-originates its own router LSAs, setting the cost of all non-stub interfaces to infinity. To restore OSPF to normal operation, disable and re-enable OSPF.

Stub Router Reason: One of Configured, Startup, or Resource Limitation. This row is only listed if stub router is active.

External LSDB Overflow: When the number of non-default external LSAs exceeds the configured limit, External LSDB Limit, OSPF goes into LSDB overflow state. In this state, OSPF withdraws all of its self-originated non-default external LSAs. After the Exit Overflow Interval, OSPF leaves the overflow state, if the number of external LSAs has been reduced.

External LSA Count: The number of external (LS type 5) link-state advertisements in the link-state database.

External LSA Checksum: The sum of the LS checksums of external link-state advertisements contained in the link-state database.

AS_OPAQUE LSA Count: Shows the number of AS Opaque LSAs in the link-state database.

AS_OPAQUE LSA Checksum: Shows the sum of the LS Checksums of AS Opaque LSAs contained in the link-state database.

New LSAs Originated: The number of new link-state advertisements that have been originated.

LSAs Received: The number of link-state advertisements received determined to be new instantiations.

LSA Count: The total number of link state advertisements currently in the link state database.

Maximum Number of LSAs: The maximum number of LSAs that OSPF can store.

LSA High Water Mark: The maximum size of the link state database since the system started.

AS Scope LSA Flood List Length: Length of global flood list for LSAs with AS scope.

Retransmit List Entries: The total number of LSAs waiting to be acknowledged by all neighbors. An LSA may be pending acknowledgment from more than one neighbor.

Maximum Number of Retransmit Entries: The maximum number of LSAs that can be waiting for acknowledgment at any given time.

Retransmit Entries High Water Mark: The highest number of LSAs that have been waiting for acknowledgment.

NSF Helper Support: Whether this router is configured to act as a graceful restart helpful neighbor. Possible values are: Helper Support Always, Disabled, or Planned.

NSF Helper Strict LSA Checking: As a graceful restart helpful neighbor, whether to terminate the helper relationship if a topology change occurs during a neighbor's graceful restart.



6.3.1.2 show ip ospf abr

This command displays the internal OSPF routing table entries to Area Border Routers (ABR). This command takes no options

C.	ntov
ЗV	ntax

show ip ospf abr

Default Setting

None

Command Mode

Privileged Eexc

User Exec

Display Messages

Type: The type of the route to the destination. It can be either:

- intra Intra-area route
- inter Inter-area route

Router ID: Router ID of the destination.

Cost: Cost of using this route.

Area ID: The area ID of the area from which this route is learned.

Next Hop: Next hop toward the destination.

Next Hop Intf: The outgoing router interface to use when forwarding traffic to the next hop.

6.3.1.3 show ip ospf area

This command displays information about the area. The <areaid> identifies the OSPF area that is being displayed.

Syntax

show ip ospf area <areaid>

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Messages

ArealD: The area id of the requested OSPF area.

External Routing: A number representing the external routing capabilities for this area.

Spf Runs: The number of times that the intra-area route table has been calculated using this area's link-state database.

Area Border Router Count: The total number of area border routers reachable within this area.

Area LSA Count: Total number of link-state advertisements in this area's link-state database, excluding AS External LSA's.

Area LSA Checksum: A number representing the Area LSA Checksum for the specified AreaID excluding the external (LS type 5) link-state advertisements.

Flood List Length: Length of the area's LSA flood list.

Import Summary LSAs: Shows whether to import summary LSAs.

The following OSPF NSSA specific information displays only if the area is configured as an NSSA:

Import Summary LSAs: Shows whether to import summary LSAs into the NSSA.

No-Redistribute into NSSA: Shows whether to redistribute information into the NSSA.

Default Information Originate: Shows whether to advertise a default route into the NSSA.

Default Metric: The metric value for the default route advertised into the NSSA.

Default Metric Type: The metric type for the default route advertised into the NSSA.

Translator Role: The NSSA translator role of the ABR, which is always or candidate.

Translator Stability Interval: The amount of time that an elected translator continues to perform its duties after it determines that its translator status has been deposed by another router.

Translator State: Shows whether the ABR translator state is disabled, always, or elected.



6.3.1.4 show ip ospf asbr

This command displays the internal OSPF routing table entries to Autonomous System Boundary Routers (ASBR). This command takes no options.

Cuntor	
Syntax	

show ip ospf asbr

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Messages

Type: The type of the route to the destination. It can be one of the following values:

- intra — Intra-area route
- inter Inter-area route •

Router ID: Router ID of the destination.

Cost: Cost of using this route.

Area ID: The area ID of the area from which this route is learned.

Next Hop: Next hop toward the destination.

Next Hop Intf: The outgoing router interface to use when forwarding traffic to the next hop.

680

6.3.1.5 show ip ospf database

This command displays information about the link state database when OSPF is enabled. If you do not enter any parameters the command displays the LSA headers for all areas. Use the optional <areaid> parameter to display database information about a specific area. Use the optional parameters to specify the type of link state advertisements to display.

Syntax

show ip ospf [<areaid>] database [adv-router | asbr-summary | external | network | nssa-external | opaque-area | opaque-as | opaque-link | router | self-originate | summary] [<lsid>] [{adv-router [<ipaddr>] | self-originate}]}]

adv-router - Display the LSAs that are restricted by the advertising router. To specify a router, enter the IP address of the router.

asbr-summary - Use asbr-summary to show the autonomous system boundary router (ASBR) summary LSAs.

external - Use external to display the external LSAs.

network - Use network to display the network LSAs.

nssa-external - Use nssa-external to display NSSA external LSAs.

opaque-area - Use opaque-area to display area opaque LSAs.

opaque-as - Use opaque-as to display AS opaque LSAs.

opaque-link - Use opaque-link to display link opaque LSAs.

router - Use router to display router LSAs.

summary - Use summary to show the LSA database summary information.

Isid - Use <lsid> to specify the link state ID (LSID). The value of <lsid> can be an IP address or an integer in the range of 0-4294967295.

adv-router - Use adv-router to show the LSAs that are restricted by the advertising router.

self-originate - Use self-originate to display the LSAs in that are self originated. The information below is only displayed if OSPF is enabled

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Messages

Ls Id: A number that uniquely identifies an LSA that a router originates from all other self originated LSAs of the same LS type.

Adv Router: The Advertising Router. Is a 32 bit dotted decimal number representing the LSDB interface.

Age: A number representing the age of the link state advertisement in seconds.

Sequence: A number that represents which LSA is more recent.

Chksm: The total number LSA checksum.

Options: This is an integer. It indicates that the LSA receives special handling during routing calculations.

Rtr Opt: Router Options are valid for router links only.

6.3.1.6 show ip ospf database database-summary

Use this command to display the number of each type of LSA in the database for each area and for the router. The command also displays the total number of LSAs in the database.

Syntax

show ip ospf database database-summary

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Messages

Router: Total number of router LSAs in the OSPF link state database.

Network: Total number of network LSAs in the OSPF link state database.

Summary Net: Total number of summary network LSAs in the database.

Summary ASBR: Number of summary ASBR LSAs in the database.

Type-7 Ext: Total number of Type-7 external LSAs in the database.

Opaque Link: Number of opaque link LSAs in the database.

Opaque Area: Number of opaque area LSAs in the database.

Type-5 Ext: Total number of Type-5 external LSAs in the database.

Self-Originated Type-5 Ext: Total number of self originated Type-5 external LSAs in the database.

Subtotal: Number of entries for the identified area.

Opaque AS: Number of opaque AS LSAs in the database.

Total: Number of entries for all areas.

6.3.1.7 show ip ospf interface

This command displays the information for the IFO object or virtual interface tables.

Syntax

show ip ospf interface {<slot/port> | loopback <loopback-id> | vlan <vlan-id>}

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Messages

IP Address: The IP address for the specified interface.

Subnet Mask: A mask of the network and host portion of the IP address for the OSPF interface.

Secondary IP Address(es): The secondary IP addresses if any are configured on the interface.

OSPF Admin Mode: States whether OSPF is enabled or disabled on a router interface.

OSPF Area ID: The OSPF Area ID for the specified interface.

OSPF Network Type: The type of network on this interface that the OSPF is running on.

Router Priority: A number representing the OSPF Priority for the specified interface.

Retransmit Interval: A number representing the OSPF Retransmit Interval for the specified interface.

Hello Interval: A number representing the OSPF Hello Interval for the specified interface.

Dead Interval: A number representing the OSPF Dead Interval for the specified interface.

LSA Ack Interval: A number representing the OSPF LSA Acknowledgment Interval for the specified interface.

Transit Delay Interval: A number representing the OSPF Transit Delay for the specified interface.

Authentication Type: The OSPF Authentication Type for the specified interface are: none, simple, and encrypt.

Metric Cost: The cost of the OSPF interface.

Passive Status: Shows whether the interface is passive or not.

OSPF MTU-ignore: Indicates whether to ignore MTU mismatches in database descriptor packets sent from neighboring routers.

Flood Blocking: Indicates if flood blocking is enabled or disabled.

The information below will only be displayed if OSPF is enabled.

State: The OSPF Interface States are: down, loopback, waiting, point-to-point, designated router, and backup designated router.

Designated Router: The router ID representing the designated router.

Backup Designated Router: The router ID representing the backup designated router.

Number of Link Events: The number of link events.

Local Link LSAs: The number of Link Local Opaque LSAs in the link-state database.

Local Link LSA Checksum: The sum of LS Checksums of Link Local Opaque LSAs in the link-state database.

6.3.1.8 show ip ospf interface brief

This command displays brief information for the IFO object or virtual interface tables.

Syntax

show ip ospf interface brief

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Messages

Interface: Valid slot and port number separated by a forward slash.

OSPF Admin Mode: States whether OSPF is enabled or disabled on a router interface.

OSPF Area ID: The OSPF Area Id for the specified interface.

Router Priority: A number representing the OSPF Priority for the specified interface.

Hello Interval: A number representing the OSPF Hello Interval for the specified interface.

Dead Interval: A number representing the OSPF Dead Interval for the specified interface.

Retransmit Interval: A number representing the OSPF Retransmit Interval for the specified interface.

Retransmit Delay Interval: A number representing the OSPF Transit Delay for the specified interface.

LSA Ack Interval: A number representing the OSPF LSA Acknowledgment Interval for the specified interface.

6.3.1.9 show ip ospf interface stats

This command displays the statistics for a specific interface. The information below will only be displayed if OSPF is enabled.

Syntax

show ip ospf interface stats {<slot/port> | loopback <loopback-id> | vlan <vlan-id>}

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Messages

OSPF Area ID: The area id of this OSPF interface.

Area Border Router Count: The total number of area border routers reachable within this area. This is initially zero, and is calculated in each SPF pass.

AS Border Router Count: The total number of Autonomous System border routers reachable within this area.

Area LSA Count: The total number of link-state advertisements in this area's link-state database, excluding AS External LSAs.

IP Address: The IP address associated with this OSPF interface.

OSPF Interface Events: The number of times the specified OSPF interface has changed its state, or an error has occurred.

Virtual Events: The number of state changes or errors that occurred on this virtual link.

Neighbor Events: The number of times this neighbor relationship has changed state, or an error has occurred.

External LSA Count: The number of external (LS type 5) link-state advertisements in the link-state database.

Sent Packets: The number of OSPF packets transmitted on the interface.

Received Packets: The number of valid OSPF packets received on the interface.

Discards: Discards The number of received OSPF packets discarded because of an error in the packet or an error in processing the packet.

Bad Version: Bad Version The number of received OSPF packets whose version field in the OSPF header does not match the version of the OSPF process handling the packet.

Source Not On Local Subnet: The number of received packets discarded because the source IP address is not within a subnet configured on a local interface.

Virtual Link Not Found: The number of received OSPF packets discarded where the ingress interface is in a non-backbone area and the OSPF header identifies the packet as belonging to the backbone, but OSPF does not have a virtual link to the packet's sender.

685

GUANTA COMPUTER INC.

Area Mismatch: The number of OSPF packets discarded because the area ID in the OSPF header is not the area ID configured on the ingress interface.

Invalid Destination Address: The number of OSPF packets discarded because the packet's destination IP address is not the address of the ingress interface and is not the AllDrRouters or AllSpfRouters multicast addresses.

Wrong Authentication Type: The number of packets discarded because the authentication type specified in the OSPF header does not match the authentication type configured on the ingress interface.

Authentication Failure: The number of OSPF packets dropped because the sender is not an existing neighbor or the sender's IP address does not match the previously recorded IP address for that neighbor.

No Neighbor at Source Address: The number of OSPF packets dropped because the sender is not an existing neighbor or the sender's address does not match the previously recorded IP address for that neighbor.

Invalid OSPF Packet Type: The number of OSPF packets discarded because the packet type field in the OSPF header is not a known type.

Hellos Ignored: The number of received Hello packets that were ignored by this router from the new neighbors after the limit has been reached for the number of neighbors on an interface or on the system as a whole.

6.3.1.10 show ip ospf neighbor

This command displays information about OSPF neighbors. If you do not specify a neighbor IP address, the output displays summary information in a table. If you specify an interface or tunnel, only the information for that interface or tunnel displays.The <ip-address> is the IP address of the neighbor, and when you specify this, detailed information about the neighbor displays. The information below only displays if OSPF is enabled and the interface has a neighbor.

Syntax

show ip ospf neighbor [interface {<slot/port> | vlan <vlan-id>}] [<ip-address>]

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Messages

If you do not specify an IP address, a table with the following columns displays for all neighbors or the neighbor associated with the interface that you specify:

Router ID: The 4-digit dotted-decimal number of the neighbor router.

Priority: The OSPF priority for the specified interface. The priority of an interface is a priority integer from 0 to 255. A value of '0' indicates that the router is not eligible to become the designated router on this network.

IP Address: The IP address of the neighbor.

Interface: The interface of the local router in slot/port format.

State: The state of the neighboring routers. Possible values are:

- Down initial state of the neighbor conversation no recent information has been received from the neighbor.
- Attempt no recent information has been received from the neighbor but a more concerted effort should be made to contact the neighbor.
- Init an Hello packet has recently been seen from the neighbor, but bidirectional communication has not yet been established.
- 2 way communication between the two routers is bidirectional.
- Exchange start the first step in creating an adjacency between the two neighboring routers, the goal is to decide which router is the master and to decide upon the initial DD sequence number.
- Exchange the router is describing its entire link state database by sending Database Description packets to the neighbor.
- Loading Link State Request packets are sent to the neighbor asking for the more recent LSAs that have been discovered (but not yet received) in the Exchange state.

687

GUANTA COMPUTER INC.

• Full - the neighboring routers are fully adjacent and they will now appear in router-LSAs and network-LSAs.

Dead Time: The amount of time, in seconds, to wait before the router assumes the neighbor is unreachable.

If you specify an IP address for the neighbor router, the following fields display:

Interface: Valid slot and port number separated by a forward slash.

Neighbor IP Address: The IP address of the neighbor router.

Interface Index: The interface ID of the neighbor router.

Area ID: The area ID of the OSPF area associated with the interface.

Options: An integer value that indicates the optional OSPF capabilities supported by the neighbor. The neighbor's optional OSPF capabilities are also listed in its Hello packets. This enables received Hello Packets to be rejected (i.e., neighbor relationships will not even start to form) if there is a mismatch in certain crucial OSPF capabilities.

Router Priority: The OSPF priority for the specified interface. The priority of an interface is a priority integer from 0 to 255. A value of '0' indicates that the router is not eligible to become the designated router on this network.

Dead Timer Due: The amount of time, in seconds, to wait before the router assumes the neighbor is unreachable.

Up Time: Neighbor uptime; how long since the adjacency last reached the Full state.

State: The state of the neighboring routers.

Events: The number of times this neighbor relationship has changed state, or an error has occurred.

Retransmission Queue Length: An integer representing the current length of the retransmission queue of the specified neighbor router Id of the specified interface.

6.3.1.11 show ip ospf range

This command displays information about the area ranges for the specified <areaid>. The <areaid> identifies the OSPF area whose ranges are being displayed..

Syntax

show ip ospf range <areaid>

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Messages

Area ID: The area id of the requested OSPF area.

IP Address: An IP address which represents this area range.

Subnet Mask: A valid subnet mask for this area range.

Lsdb Type: The type of link advertisement associated with this area range.

Advertisement: The status of the advertisement. Advertisement has two possible settings: enabled or disabled.

6.3.1.12 show ip ospf statistics

This command displays information about recent Shortest Path First (SPF) calculations. The SPF is the OSPF routing table calculation. The output lists the number of times the SPF has run for each OSPF area. A table follows this information. For each of the 15 most recent SPF runs, the table lists how long ago the SPF ran, how long the SPF took, and the reasons why the SPF was scheduled.

Syntax			
show ip os	spf statistics		

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Messages

Delta T: How long ago the SPF ran. The time is in the format hh:mm:ss, giving the hours, minutes, and seconds since the SPF run.

SPF Duration: How long the SPF took in milliseconds.

Reason: The reason the SPF was scheduled. Reason codes are as follows:

- R a router LSA has changed
- N a network LSA has changed
- SN a type 3 network summary LSA has changed
- SA a type 4 ASBR summary LSA has changed
- X a type 5 or type 7 external LSA has changed

6.3.1.13 show ip ospf stub table

This command displays the OSPF stub table. The information below will only be displayed if OSPF is initialized on the switch..

Syntax

show ip ospf stub table

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Messages

Area ID: A 32-bit identifier for the created stub area.

Type of Service: The type of service associated with the stub metric. only supports Normal TOS.

Metric Val: The metric value is applied based on the TOS. It defaults to the least metric of the type of service among the interfaces to other areas. The OSPF cost for a route is a function of the metric value.

Import Summary LSA: Controls the import of summary LSAs into stub areas.

6.3.1.14 show ip ospf virtual-link

This command displays the OSPF Virtual Interface information for a specific area and neighbor. The <areaid> parameter identifies the area and the <neighbor> parameter identifies the neighbor's Router ID.

Syntax

show ip ospf virtual-link <areaid> <neighbor>

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Messages

Area ID: The area id of the requested OSPF area.

Neighbor Router ID: The input neighbor Router ID.

Hello Interval: The configured hello interval for the OSPF virtual interface.

Dead Interval: The configured dead interval for the OSPF virtual interface.

Iftransit Delay Interval: The configured transit delay for the OSPF virtual interface.

Retransmit Interval: The configured retransmit interval for the OSPF virtual interface.

Authentication Type: The configured authentication type of the OSPF virtual interface.

State: The OSPF Interface States are: down, loopback, waiting, point-to-point, designated router, and backup designated router. This is the state of the OSPF interface.

Neighbor State: The neighbor state.



6.3.1.15 show ip ospf virtual-link brief

This command displays the OSPF Virtual Interface information for all areas in the system.

Syntax

show ip ospf virtual-link brief

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Messages

Area ID: The area id of the requested OSPF area.

Neighbor: The neighbor interface of the OSPF virtual interface.

Hello Interval: The configured hello interval for the OSPF virtual interface.

Dead Interval: The configured dead interval for the OSPF virtual interface.

Retransmit Interval: The configured retransmit interval for the OSPF virtual interface.

Transit Delay: The configured transit delay for the OSPF virtual interface.

6.3.1.16 show ip ospf lsa-group

This command displays the number of self-originated LSAs within each LSA group.

Syntax

show ip ospf Isa-group

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Messages

Total self-originated LSAs: The number of LSAs originated from self.

Average LSAs per group: The average number of LSAs per group.



Pacing group limit: The maximum number for pacing group.

Number of self-originated LSAs within each LSA group: The detail number of self-originated LSAs.

Group Start Age: The start time of LSA Group aged.

Group End Age: The end time of LSA Group aged.

Count: The number of LSA Group aged.



6.3.2 Configuration Commands

6.3.2.1 router ospf

Use this command to enter Router OSPF mode.

Syntax]		
router os	spf		

Default Setting

None

Command Mode

Global Config

6.3.2.2 enable

Use **enable** command resets the default administrative mode of OSPF in the router (active). **no enable** command sets the administrative mode of OSPF in the router to inactive

Syntax	
enable no enable	
no enable	

Default Setting

Enabled

Command Mode



6.3.2.3 network area

Use **network area** command to enable OSPFv2 on an interface and set its area ID if the IP address of an interface is covered by this network command. Use **no network area** command to disable the OSPFv2 on a interface if the IP address of an interface was earlier covered by this network command

Syntax

network <ip-address> <wildcard-mask> area <area-id> no network <ip-address> <wildcard-mask> area <area-id>

Default Setting

Disabled

Command Mode

Router OSPF Config Mode

6.3.2.4 ip ospf area

Use **ip ospf area** command to enable OSPFv2 and set the area ID of an interface. The *<area-id>* is an IP address formatted as a 4-digit dotted-decimal number or a decimal value in the range of <0-4294967295>. This command supersedes the effects of the **network area** command. It can also be used to configure the advertiseability of the secondary addresses on this interface into the OSPFv2 domain. Use **no ip ospf area** command to disable OSPF on an interface.

Syntax

ip ospf area <area-id> [secondaries none] no ip ospf area [secondaries none]

Default Setting

Disabled

Command Mode



6.3.2.5 1583compatibility

1583 compatibility mode is enabled by default. If all OSPF routers in the routing domain are capable of operating according to RFC 2328, OSPF 1583 compatibility mode should be disabled. **1583compatibility** command enables OSPF 1583 compatibility. **no 1583compatibility** command disables OSPF 1583 compatibility

Syntax			
1583com			
no 1583c	compatibility		

Default Setting

Enabled

Command Mode

Router OSPF Config Mode

6.3.2.6 area default-cost

This command configures the default cost for the stub area. You must specify the area ID and an integer value between 1-16777215

Syntax

area <areaid> default-cost <1-16777215>

Default Setting

None

Command Mode

6.3.2.7 area nssa

area nssa command configures the specified areaid to function as an NSSA. no area nssa command disables nssa from the specified area id.

Syntax		
area <ar< th=""><th>areaid> nssa</th><th></th></ar<>	areaid> nssa	
no area	i <areaid> nssa</areaid>	

Default Setting

None

Command Mode

Router OSPF Config Mode

6.3.2.8 area nssa default-info-originate

area nssa default-info-originate command configures the metric value and type for the default route advertised into the NSSA. The optional metric parameter specifies the metric of the default route and is to be in a range of 1-16777214. If no metric is specified, the default value is ****. The metric type can be comparable (nssa-external 1) or non-comparable (nssa-external 2). This command disables the default route advertised into the NSSA. **no area nssa default-info-originate** command disables the default route advertised into the NSSA.

Syntax

area <areaid> nssa default-info-originate [<metric>] [{comparable | noncomparable}] no area <areaid> nssa default-info-originate [<metric>] [{comparable | noncomparable}]

Default Setting

None

Command Mode

6.3.2.9 area nssa no-redistribute

area nssa no-redistribute command configures the NSSA Area Border router (ABR) so that learned external routes will not be redistributed to the NSSA. **no area nssa no-redistribute** command disables the NSSA ABR so that learned external routes are redistributed to the NSSA

Syntax

area <areaid> nssa no-redistribute no area <areaid> nssa no-redistribute

Default Setting

None

Command Mode

Router OSPF Config Mode

6.3.2.10 area nssa no-summary

area nssa no-summary command configures the NSSA so that summary LSAs are not advertised into the NSSA. **no area nssa no-summary** command disables nssa from the summary LSAs

Syntax

area <areaid> nssa no-summary no area <areaid> nssa no-summary

Default Setting

None

Command Mode

6.3.2.11 area nssa translator-role

area nssa translator-role command configures the translator role of the NSSA. A value of *always* causes the router to assume the role of the translator the instant it becomes a border router and a value of *candidate* causes the router to participate in the translator election process when it attains border router status. **no area nssa translator-role** command disables the nssa translator role from the specified area id.

Syntax	
Symax	

area <areaid> nssa translator-role {always | candidate} no area <areaid> nssa translator-role {always | candidate}

Default Setting

None

Command Mode

Router OSPF Config Mode

6.3.2.12 area nssa translator-stab-intv

area nssa translator-stab-intv command configures the translator *<stabilityinterval>* of the NSSA. The *<stabilityinterval>* is the period of time that an elected translator continues to perform its duties after it determines that its translator status has been deposed by another router. **no area nssa translator-stab-intv** command disables the nssa translator's *<stabilityinterval>* from the specified area id.

Syntax

area <areaid> nssa translator-stab-intv <stabilityinterval> no area <areaid> nssa translator-stab-intv <stabilityinterval>

Default Setting

None

Command Mode

Router OSPF Config Mode

700



6.3.2.13 area range

area range command creates a specified area range for a specified NSSA. The *<ipaddr>* is a valid IP address. The *<subnetmask>* is a valid subnet mask. The LSDB type must be specified by either **summarylink** or **nssaexternallink**, and the advertising of the area range can be allowed or suppressed. **no area range** command deletes a specified area range. The *<ipaddr>* is a valid IP address. The *<subnetmask>* is a valid subnet mask.

Syntax

area <areaid> range <ipaddr> <subnetmask> {summarylink | nssaexternallink} [advertise | not-advertise] no area <areaid> range <ipaddr> <subnetmask>

Default Setting

None

Command Mode

Router OSPF Config Mode

6.3.2.14 area stub

area stub command creates a stub area for the specified area ID. A stub area is characterized by the fact that AS External LSAs are not propagated into the area. Removing AS External LSAs and Summary LSAs can significantly reduce the link state database of routers within the stub area. **no area stub** command deletes a stub area for the specified area ID.

Syntax area <areaid> stub no area <areaid> stub

Default Setting

None

Command Mode

6.3.2.15 area stub no-summary

area stub no-summary command configures the Summary LSA mode for the stub area identified by *<areaid>*. Use this command to prevent LSA Summaries from being sent. **no area stub no-summary** command configures the default Summary LSA mode for the stub area identified by *<areaid>*.

Syntax

area <areaid> stub no-summary no area <areaid> stub no-summary

Default Setting

Disabled

Command Mode

Router OSPF Config Mode

6.3.2.16 area virtual-link

area virtual-link command creates the OSPF virtual interface for the specified *<areaid>* and *<neighbor>*. The *<neighbor>* parameter is the Router ID of the neighbor. **no area virtual-link** command deletes the OSPF virtual interface from the given interface, identified by *<areaid>* and *<neighbor>*. The *<neighbor>* parameter is the Router ID of the neighbor.

Syntax

area <areaid> virtual-link <neighbor> no area <areaid> virtual-link <neighbor>

Default Setting

None

Command Mode

6.3.2.17 area virtual-link authentication

area virtual-link authentication command configures the authentication type and key for the OSPF virtual interface identified by *<areaid>* and *<neighbor>*. The *<neighbor>* parameter is the Router ID of the neighbor. The value for *<type>* is either none, simple, or encrypt. The *[key]* is composed of standard displayable, non-control keystrokes from a Standard 101/102-key keyboard. The authentication key must be 8 bytes or less if the authentication type is simple. If the type is encrypt, the key may be up to 16 bytes. Unauthenticated interfaces do not need an authentication key. If the type is encrypt, a key id in the range of 0 and 255 must be specified. The default value for authentication type is none. Neither the default password key nor the default key id are configured.

no area virtual-link authentication command configures the default authentication type for the OSPF virtual interface identified by *<areaid>* and *<neighbor>*. The *<neighbor>* parameter is the Router ID of the neighbor.

Syntax

area <areaid> virtual-link <neighbor> authentication {none | {simple <key>} | {encrypt <key> <keyid>}} no area <areaid> virtual-link <neighbor> authentication

Default Setting

None

Command Mode

Router OSPF Config Mode

6.3.2.18 area virtual-link dead-interval

area virtual-link dead-interval command configures the dead interval for the OSPF virtual interface on the virtual interface identified by *<areaid>* and *<neighbor>*. The *<neighbor>* parameter is the Router ID of the neighbor. The range for seconds is 1 to 65535. **no area virtual-link dead-interval** command configures the default dead interval for the OSPF virtual interface on the virtual interface identified by *<areaid>* and *<neighbor>*. The *command* configures the default dead interval for the OSPF virtual interface on the virtual interface identified by *<areaid>* and *<neighbor>*. The *command* configures the default dead interval for the OSPF virtual interface on the virtual interface identified by *careaid>* and *command* configures the default dead interval for the OSPF virtual interface on the virtual interface identified by *careaid>* and *command* configures the default dead interval for the OSPF virtual interface on the virtual interface identified by *careaid>* and *command* configures the default dead interval for the OSPF virtual interface on the virtual interface identified by *careaid>* and *command* configures the default dead interval for the OSPF virtual interface on the virtual interface identified by *careaid>* and *command* command *command* command co

Syntax

area <areaid> virtual-link <neighbor> dead-interval <seconds> no area <areaid> virtual-link <neighbor> dead-interval

Default Setting

40

Command Mode

6.3.2.19 area virtual-link hello-interval

area virtual-link hello-interval command configures the hello interval for the OSPF virtual interface on the virtual interface identified by *<areaid>* and *<neighbor>*. The *<neighbor>* parameter is the Router ID of the neighbor. The range for *<seconds>* is 1 to 65535. **no area virtual-link hello-interval** command configures the default hello interval for the OSPF virtual interface on the virtual interface identified by *<areaid>* and *<neighbor>*. The *command* configures the default hello interval for the OSPF virtual interface on the virtual interface identified by *<areaid>* and *<neighbor>*. The *command* configures the default hello interval for the OSPF virtual interface on the virtual interface identified by *careaid>* and *confighbor>*. The *command* configures the Router ID of the neighbor.

Syntax
Syntax

area <areaid> virtual-link <neighbor> hello-interval <1-65535> no area <areaid> virtual-link <neighbor> hello-interval

Default Setting

10

Command Mode

Router OSPF Config Mode

6.3.2.20 area virtual-link retransmit-interval

area virtual-link retransmit-interval command configures the retransmit interval for the OSPF virtual interface on the virtual interface identified by *<areaid>* and *<neighbor>*. The *<neighbor>* parameter is the Router ID of the neighbor. The range for seconds is 0 to 3600.. **no area virtual-link retransmit -interval** command configures the default retransmit interval for the OSPF virtual interface on the virtual interface identified by *<areaid>* and *<neighbor>* parameter is the Router ID of the neighbor. The *<neighbor>* parameter is the OSPF virtual interface on the virtual interface identified by *<areaid>* and *<neighbor>*. The *<neighbor>* parameter is the Router ID of the neighbor>. The *<neighbor>* parameter is the Router ID of the neighbor>. The *<neighbor>* parameter is the Router ID of the neighbor>. The *<neighbor>* parameter is the Router ID of the neighbor>. The *<neighbor>* parameter is the Router ID of the neighbor

Syntax

area <areaid> virtual-link <neighbor> retransmit-interval <seconds> no area <areaid> virtual-link <neighbor> retransmit-interval

Default Setting

5

Command Mode

6.3.2.21 area virtual-link transmit-delay

area virtual-link transmit-delay command configures the transmit delay for the OSPF virtual interface on the virtual interface identified by *<areaid>* and *<neighbor>*. The *<neighbor>* parameter is the Router ID of the neighbor. The range for seconds is 0 to 3600 (1 hour). **no area virtual-link transmit-delay** command resets the default transmit delay for the OSPF virtual interface to the default value.

Syntax

area <areaid> virtual-link <neighbor> transmit-delay <seconds> no area <areaid> virtual-link <neighbor> transmit-delay

Default Setting

1

Command Mode

Router OSPF Config Mode

6.3.2.22 auto-cost

By default, OSPF computes the link cost of each interface from the interface bandwidth. Faster links have lower metrics, making them more attractive in route selection. The configuration parameters in the **auto-cost reference bandwidth** and **bandwidth** commands give you control over the default link cost. You can configure for OSPF an interface bandwidth that is independent of the actual link speed. A second configuration parameter allows you to control the ratio of interface bandwidth to link cost. The link cost is computed as the ratio of a reference bandwidth to the interface bandwidth (ref_bw /interface bandwidth), where interface bandwidth is defined by the **bandwidth** command. Because the default reference bandwidth is 100 Mbps, OSPF uses the same default link cost for all interfaces whose bandwidth is 100 Mbps or greater. Use the **auto-cost** command to change the reference bandwidth, specifying the reference bandwidth in megabits per second (Mbps). The reference bandwidth range is 1-4294967 Mbps. The different reference bandwidth can be independently configured for OSPFv2 and OSPFv3.

Use no auto-cost command to set the reference bandwidth to the default value.

Syntax

auto-cost reference-bandwidth <1 to 4294967> no auto-cost reference-bandwidth

Default Setting

100Mbps

Command Mode



6.3.2.23 bandwidth

By default, OSPF computes the link cost of an interface as the ratio of the reference bandwidth to the interface bandwidth. Reference bandwidth is specified with the **auto-cost** command. For the purpose of the OSPF link cost calculation, use the bandwidth command to specify the interface bandwidth. The bandwidth is specified in kilobits per second. If no bandwidth is configured, the bandwidth defaults to the actual interface bandwidth for port-based routing interfaces and to 10 Mbps for VLAN routing interfaces. This command does not affect the actual speed of an interface. Use **no bandwidth** command to set the interface bandwidth to its default value

Syntax

bandwidth <1-10000000> no bandwidth

Default Setting

Actual interface bandwidth

Command Mode

Interface Config

6.3.2.24 capability opaque

Use **capability opaque** command to enable Opaque Capability on the Router. The information contained in Opaque LSAs may be used directly by OSPF or indirectly by an application wishing to distribute information throughout the OSPF domain. Supports the storing and flooding of Opaque LSAs of different scopes. Use **no capability opaque** command to disable opaque capability on the router

Syntax

capability opaque no capability opaque

Default Setting

Disabled

Command Mode



6.3.2.25 clear ip ospf

Use this command to disable and re-enable OSPF.

S	/n	tax

clear ip ospf

Default Setting

None

Command Mode

Privileged Exec

6.3.2.26 clear ip ospf configuration

Use this command to reset the OSPF configuration to factory defaults.

Syntax

clear ip ospf configuration

Default Setting

None

Command Mode

Privileged Exec



6.3.2.27 clear ip ospf counters

Use this command to reset global and interface statistics

Syntax

clear ip ospf counters

Default Setting

None

Command Mode

Privileged Exec

6.3.2.28 clear ip ospf neighbor

Use this command to drop the adjacency with all OSPF neighbors. On each neighbor's interface, send a one-way hello. Adjacencies may then be re-established. To drop all adjacencies with a specific router ID, specify the neighbor's Router ID using the optional parameter [neighbor-id].

Syntax

clear ip ospf neighbor [neighbor-id]

Default Setting

None

Command Mode

Privileged Exec

708

6.3.2.29 clear ip ospf neighbor interface

To drop adjacency with all neighbors on a specific interface, use the optional parameter [slot/port]. To drop adjacency with a specific router ID on a specific interface, use the optional parameter [ipaddr].

Syntax

clear ip ospf neighbor [interface {{<slot/port> | vlan <vlan-id>} [ipAddr] | <ipaddr>}]

Default Setting

None

Command Mode

Privileged Exec

6.3.2.30 clear ip ospf redistribution

Use this command to flush all self-originated external LSAs. Reapply the redistribution configuration and re-originate prefixes as necessary.

Syntax

clear ip ospf redistribution

Default Setting

None

Command Mode

Privileged Exec



6.3.2.31 default-information originate

default-information originate command is used to control the advertisement of default routes.

no default-information originate command is used to control the advertisement of default routes.

Syntax

default-information originate [always] [metric <0-16777214>] [metric-type {1 | 2}] no default-information originate [metric] [metric-type]

Default Setting

metric-unspecified

type-2

Command Mode

Router OSPF Config Mode

6.3.2.32 default-metric

default-metric command is used to set a default for the metric of distributed routes.

no default-metric command is used to set a default for the metric of distributed routes.

Syntax

default-metric <1-16777214> no default-metric

Default Setting

None

Command Mode

6.3.2.33 distance ospf

distance ospf command sets the route preference value of OSPF in the router. Lower route preference values are preferred when determining the best route. The type of OSPF route can be intra, inter, or external. All the external type routes are given the same preference value. The range of cypreference>value is 1 to 255. no distance ospf command sets the default route preference value of OSPF routes in the router. The type of OSPF can be intra, inter, or external. All the external type routes are given the same preference value of OSPF routes in the router. The type of OSPF can be intra, inter, or external. All the external type routes are given the same preference value of other type of the same preference value.

Syntax

distance ospf {intra-area <1-255> | inter-area <1-255> | external <1-255>} no distance ospf {intra-area | inter-area | external}

Default Setting

110

Command Mode

Router OSPF Config Mode

6.3.2.34 distribute-list out

Use **distribute-list out** command to specify the access list to filter routes received from the source protocol.

no distribute-list out command to specify the access list to filter routes received from the source protocol.

Syntax

distribute-list <1-199> out {rip | bgp | static | connected} no distribute-list <1-199> out {rip | bgp | static | connected}

Default Setting

None

Command Mode

6.3.2.35 exit-overflow-interval

exit-overflow-interval command configures the exit overflow interval for OSPF. It describes the number of seconds after entering overflow state that a router will wait before attempting to leave the overflow state. This allows the router to again originate non-default AS-external-LSAs. When set to 0, the router will not leave overflow state until restarted. The range for seconds is 0 to 2147483647 seconds. **no exit-overflow-interval** command configures the default exit overflow interval for OSPF.

nterval <seconds></seconds>		
w-interval		

Default Setting

0

Command Mode

Router OSPF Config Mode

6.3.2.36 external-Isdb-limit

external-Isdb-limit command configures the external LSDB limit for OSPF. If the value is -1, then there is no limit. When the number of non-default AS-external-LSAs in a router's link-state database reaches the external LSDB limit, the router enters overflow state. The router never holds more than the external LSDB limit non-default AS-external-LSAs in it database. The external LSDB limit MUST be set identically in all routers attached to the OSPF backbone and/or any regular OSPF area. The range for limit is -1 to 2147483647. **no external-Isdb-limit** command configures the default external LSDB limit for OSPF.

Syntax	
external-	-Isdb-limit <limit></limit>
no extern	nal-Isdb-limit

imit> - The range for limit is -1 to 2147483647. If the value is -1, then there is no limitation.

Default Setting

-1

Command Mode

6.3.2.37 ip ospf authentication

ip ospf authentication command sets the OSPF Authentication Type and Key for the specified interface. The value of <type> is either none, simple or encrypt. The <key> is composed of standard displayable, non-control keystrokes from a Standard 101/102-key keyboard. The authentication key must be 8 bytes or less if the authentication type is simple. If the type is encrypt, the key may be up to 16 bytes. If the type is encrypt a <keyid> in the range of 0 and 255 must be specified. Unauthenticated interfaces do not need an authentication key or authentication key ID. There is no default value for this command.

no ip ospf authentication command sets the default OSPF Authentication Type for the specified interface.

Syntax

ip ospf authentication {none | {simple <key>} | {encrypt <key> <keyid>}} no ip ospf authentication

Default Setting

None

Command Mode

Interface Config

6.3.2.38 ip ospf cost

ip ospf cost command configures the cost on an OSPF interface. The <cost> parameter has a range of 1 to 65535. **no ip ospf cost** command configures the default cost on an OSPF interface.

Syntax			
ip ospf co	ost <1–65535>		
no ip ospf	f cost		

Default Setting

10

Command Mode

6.3.2.39 ip ospf dead-interval

ip ospf dead-interval command sets the OSPF dead interval for the specified interface. The value for <seconds> is a valid positive integer, which represents the length of time in seconds that a router's Hello packets have not been seen before its neighbor routers declare that the router is down. The value for the length of time must be the same for all routers attached to a common network. This value should be some multiple of the Hello Interval (i.e. 4). Valid values range in seconds from 1 to 2147483647. **no ip ospf dead-interval** command sets the default OSPF dead interval for the specified interface.

Syntax	
ip ospf dead-interval <seconds></seconds>	
no ip ospf dead-interval	

Default Setting

40

Command Mode

Interface Config

6.3.2.40 ip ospf hello-interval

ip ospf hello-interval command sets the OSPF hello interval for the specified interface. The value for seconds is a valid positive integer, which represents the length of time in seconds. The value for the length of time must be the same for all routers attached to a network. Valid values range from 1 to 65535. **no ip ospf hello-interval** command sets the default OSPF hello interval for the specified interface.

Syntax

ip ospf hello-interval <seconds> no ip ospf hello-interval

Default Setting

10

Command Mode

6.3.2.41 ip ospf network

ip ospf network command to configure OSPF to treat an interface as a point-to-point rather than broadcast interface. The broadcast option sets the OSPF network type to broadcast. The point-to-point option sets the OSPF network type to point-to-point. OSPF treats interfaces as broadcast interfaces by default. (Loopback interfaces have a special loopback network type, which cannot be changed.) When there are only two routers on the network, OSPF can operate more efficiently by treating the network as a point-to-point network. For point-to-point networks, OSPF does not elect a designated router or generate a network link state advertisement (LSA). Both endpoints of the link must be configured to operate in point-to-point mode..

no ip ospf network command to return the OSPF network type to the default.

Syntax	
ip ospf ne	etwork {broadcast point-to-point}

Default Setting

Broadcast

no ip ospf network

Command Mode

Interface Config

6.3.2.42 ip ospf priority

ip ospf priority command sets the OSPF priority for the specified router interface. The priority of the interface is a priority integer from 0 to 255. A value of 0 indicates that the router is not eligible to become the designated router on this network. **no ip ospf priority** command sets the default OSPF priority for the specified router interface.

Syntax	
ip ospf pr	iority <0-255>
no ip ospi	f priority

Default Setting

1, which is the highest router priority

Command Mode

6.3.2.43 ip ospf retransmit-interval

ip ospf retransmit command sets the OSPF retransmit Interval for the specified interface. The retransmit interval is specified in seconds. The value for <seconds> is the number of seconds between link-state advertisement retransmissions for adjacencies belonging to this router interface. This value is also used when retransmitting database description and link-state request packets. Valid values range from 0 to 3600 (1 hour). **no ip ospf retransmit** command sets the default OSPF retransmit Interval for the specified interface.

it-interval <0-3600>			
smit-interval			
	it-interval <0-3600> smit-interval	it-interval <0-3600> asmit-interval	

Default Setting

5

Command Mode

Interface Config

6.3.2.44 ip ospf transmit-delay

ip ospf transmit-delay command sets the OSPF Transit Delay for the specified interface. The transmit delay is specified in seconds. In addition, it sets the estimated number of seconds it takes to transmit a link state update packet over this interface. Valid values for <seconds> range from 1 to 3600 (1 hour). **no ip ospf transmit-delay** command sets the default OSPF Transit Delay for the specified interface

Syntax

ip ospf transmit-delay <1-3600> no ip ospf transmit-delay

Default Setting

1

Command Mode

6.3.2.45 ip ospf mtu-ignore

ip ospf mtu-ignore command disables OSPF maximum transmission unit (MTU) mismatch detection. OSPF Database Description packets specify the size of the largest IP packet that can be sent without fragmentation on the interface. When a router receives a Database Description packet, it examines the MTU advertised by the neighbor. By default, if the MTU is larger than the router can accept, the Database Description packet is rejected and the OSPF adjacency is not established. **no ip ospf mtu-ignore** command enables the OSPF MTU mismatch detection.

Syntax			
ip ospf mtu-ignore			
no ip ospf mtu-ignore			

Default Setting

Enabled

Command Mode

Interface Config

6.3.2.46 ip ospf database-filter

ip ospf database-filter command disables OSPFv2 LSA flooding on this interface. This means that you can still establish adjacencies (since hellos are still sent), but you won't send your neighboring router any

LSA's. Therefore you will receive all the LSA's in their database, but they will not receive any of yours. **no ip ospf database-filter** command enables OSPFv2 LSA flooding on this interface.

Syntax

ip ospf database-filter all out no ip ospf database-filter all out

Default Setting

Disabled

Command Mode

6.3.2.47 router-id

router-id command sets a 4-digit dotted-decimal number uniquely identifying the router ospf id. The <ipaddress> is a configured value.

Syntax

router-id <ipaddress>

Default Setting

None

Command Mode



6.3.2.48 redistribute

redistribute command configures OSPF protocol to allow redistribution of routes from the specified source protocol/routers. **no redistribute** command configures OSPF protocol to prohibit redistribution of routes from the specified source protocol/routers.

Syntax

redistribute {rip | bgp | static | connected} [metric <0-16777214>] [metric-type {1 | 2}] [tag <0-4294967295>] [subnets] no redistribute {rip | bgp | static | connected} [metric <0-16777214>] [metric-type {1 | 2}] [tag <0-4294967295>] [subnets]

Default Setting

metric-unspecified

type-2

tag—0

Command Mode

Router OSPF Config Mode

6.3.2.49 maximum-paths

maximum-paths command sets the number of paths that OSPF can report for a given destination where maxpaths is platform dependent. **no maximum-paths** command resets the number of paths that OSPF can report for a given destination back to its default value.

Syntax

maximum-paths <maxpaths> no maximum-paths

Default Setting

4

Command Mode

6.3.2.50 passive-interface default

passive-interface default command to enable global passive mode by default for all interfaces. It overrides any interface level passive mode. OSPF will not form adjacencies over a passive interface. **no passive-interface default** command to disable the global passive mode by default for all interfaces. Any interface previously configured to be passive reverts to non-passive mode.

Syntax			
passive-i	nterface default		
no passiv	ve-interface default		

Default Setting

Disabled

Command Mode

Router OSPF Config Mode

6.3.2.51 passive-interface

passive-interface command to set the interface or tunnel as passive. It overrides the global passive mode that is currently effective on the interface or tunnel. **no passive-interface** command to set the interface or tunnel as non-passive. It overrides the global passive mode that is currently effective on the interface or tunnel.

Syntax

passive-interface {<slot/port> | vlan <vlan-id>} no passive-interface {<slot/port> | vlan <vlan-id>}

Default Setting

Disabled

Command Mode

6.3.2.52 timers spf

Use this command to configure the SPF delay time and hold time. The valid range for both parameters is 0-65535 seconds..

Syntax

timers spf <delay-time> <hold-time>

Default Setting

delay-time-5

hold-time—10

Command Mode

Router OSPF Config Mode

6.3.2.53 timers pacing flood

Use this command to configure the LS Update transmit pacing time to adjust the rate at which OSPFv2 sends LS Update packets. The valid range for both parameters is 5-100 seconds. Use the **no timers pacing flood** command to return the timer pacing to the default.

value.

Syntax

timers pacing flood <flood-pacing-interval> no timer pacing flood

Default Setting

33

Command Mode

Router OSPF Config Mode

6.3.2.54 timers pacing lsa-group

Use this command to tune how OSPF groups LSAs for periodic refresh. The valid range for both parameters is 10-1800 seconds. Use the **no timers pacing Isa-group** command to return the timer pacing to the default.

Syntax

timers pacing lsa-group <lsa-refresh-group-pacing-time> no timers pacing lsa-group

Default Setting

60

Command Mode

Router OSPF Config Mode

6.3.2.55 max-metric

Use **max-metric** command to configure OSPF to enable stub router mode. Use **no max-metric** command to disable stub router mode.

Syntax

max-metric router-lsa [on-startup <seconds> [summary-lsa] | summary-lsa [<metric> [on-startup <seconds>] | on-startup <seconds>] no max-metric router-lsa [on-startup] [summary-lsa]

on-startup - OSPF starts in stub router mode after a reboot.

seconds - The number of seconds that OSPF remains in stub router mode after a reboot. The range is 5 to 86,400 seconds. There is no default value.

summary-Isa - Set the metric in type 3 and 4 summary LSAs to LsInfinity (0xFFFFF).

metric - Metric to send in summary LSAs when in stub router mode. Range is 1 to 16,777,215. Default is 16,711,680(0xFF0000).

Default Setting

None

Command Mode

Router OSPF Config Mode

6.3.2.56 log-adjacency-changes

log-adjacency-changes command logs OSPFv2 neighbor state changes. **no log-adjacency-changes** command disables logging OSPFv2 neighbor state changes.

Syntax

log-adjacency-changes [detail]

detail—Sends a syslog message for each state change, not just when a neighbor goes up or down.

Default Setting

Disable

Command Mode

Router OSPF Config Mode

6.4 BOOTP/DHCP Relay Commands

6.4.1 Show Commands

6.4.1.1 show bootpdhcprelay

This command displays the BootP/DHCP Relay information.



show bootpdhcprelay

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Message

Maximum Hop Count: Is the maximum allowable relay agent hops.

Minimum Wait Time (Seconds) Is the minimum wait time.

Admin Mode Represents whether relaying of requests is enabled or disabled.

Server IP Address Is the IP Address for the BootP/DHCP Relay server.

Circuit Id Option Mode Is the DHCP circuit Id option which may be enabled or disabled.

Requests Received Is the number of requests received.

Requests Relayed Is the number of requests relayed.

Packets Discarded Is the number of packets discarded.

6.4.2 Configuration Commands

6.4.2.1 bootpdhcprelay cidoptmode

This command enables the circuit ID option mode for BootP/DHCP Relay on the system.

Syntax	
bootpdhc	prelay cidoptmode
no bootpo	dhcprelay cidoptmode

no - This command is used to disable the circuit ID option mode for BootP/DHCP Relay on the system.

Default Setting

Disabled

Command Mode

Global Config

6.4.2.2 bootpdhcprelay enable

This command enables the forwarding of relay requests for BootP/DHCP Relay on the system.

Syntax		
ip helper	r enable	
no ip help	Iper enable	

no - Disable the forwarding of relay requests for BootP/DHCP Relay on the system.

Default Setting

Disabled

Command Mode

Global Config

6.4.2.3 bootpdhcprelay maxhopcount

This command configures the maximum allowable relay agent hops for BootP/DHCP Relay on the system.



Syntax

bootpdhcprelay maxhopcount <hops> no bootpdhcprelay maxhopcount

<hops> - The range of maximum hop count is 1 to 16.

no - Set the maximum hop count to 4.

Default Setting

The default value is 4.

Command Mode

Global Config

6.4.2.4 bootpdhcprelay minwaittime

This command configures the minimum wait time in seconds for BootP/DHCP Relay on the system. When the BOOTP relay agent receives a BOOTREQUEST message, it may use the seconds-since-client-began-booting field of the request as a factor in deciding whether to relay the request or not.

Syntax

bootpdhcprelay minwaittime <minwaittime> no bootpdhcprelay minwaittime

<minwaittime> - The range of minimum wait time is 0 to 100.

no - Set the minimum wait time to 0 seconds.

Default Setting

The default value is 0.

Command Mode



6.4.2.5 bootpdhcprelay serverip

This command configures the server IP Address for BootP/DHCP Relay on the system.

Syntax

bootpdhcprelay serverip <ipaddr> no bootpdhcprelay serverip

<ipaddr> - The IP address of the BootP/DHCP server.

no - Clear the IP address of the BootP/DHCP server.

Default Setting

None

Command Mode

6.5 IP Helper Commands

6.5.1 Show Commands

6.5.1.1 show ip helper-address

Use this command to display the IP helper address configuration.

Syntax

show ip helper-address

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Message

Interface: The relay configuration is applied to packets that arrive on this interface. This field is set to 'any' for global IP helper entries.

UDP Port: The relay configuration is applied to packets whose destination UDP port is this port.

Discard: Indicate discard the UDP packets or not.

Hit Count: The number of times the IP helper entry has been used to relay or discard a packet.

Server Address: The IPv4 address of the server to which packets are relayed.

6.5.1.2 show ip helper statistics

Use this command to display the number of UDP packets processed and relayed.

Syntax
O ymax

show ip helper statistics

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Message

DHCP client messages received: The number of valid messages received form a DHCP client

DHCP client messages relayed: The number of DHCP client messages relayed to a server.

DHCP server messages received The number of DHCP responses received from the server.

DHCP server messages relayed The number of DHCP server messages relayed to a client.

UDP client messages received The number of valid UDP messages received.

UDP client messages relayed The number of valid UDP messages relayed

DHCP messages hop count exceeded max The number of DHCP client messages received whose hop count is larger than the maximum allowed.

DHCP messages with secs field below min The number of DHCP client messages received whose Second field is less than the minimum value.

DHCP message with giaddr set to local address The number of DHCP client messages received whose gateway address, giaddr, is already set to an IP address configured on one of the relay agent's own IP address.

Packets with expired TTL The number of packets received with TTL of 0 or 1 that otherwise have been relayed.

Packets that matched a discard entry The number of packets ignored by the relay agent because they match a discard entry.

6.5.2 Configuration Commands

6.5.2.1 ip helper-address

Use this command to configure the relay of certain UDP broadcast packets received on a specific interface or range of interfaces. This command can be invoked multiple times on a routing interface, either to specify multiple server addresses for a given port number or to specify multiple port numbers handled by a specific server.

Syntax

ip helper-address <ipaddr> [<udp-port> | dhcp | domain | isakmp | mobile-ip | nameserver | netbios-dgm | netbios-ns | ntp | pim-auto-rp | rip | tacacs | tftp | time] no ip helper-address <ipaddr> [<udp-port> | dhcp | domain | isakmp | mobile-ip | nameserver | netbios-dgm | netbios-ns | ntp | pim-auto-rp | rip | tacacs | tftp | time]

no - This command is used to delete the address.

Default Setting

None

Command Mode

Interface Config

6.5.2.2 ip helper-address discard

Use this command to configure the discard of certain UDP broadcast packets received on a specific interface or range of interfaces. This command can be invoked multiple times on a routing interface for a given port number or to specify multiple port numbers handled by a specific server.

Syntax

ip helper-address discard { <udp-port> | dhcp | domain | isakmp | mobile-ip | nameserver | netbios-dgm | netbios-ns | ntp | pim-auto-rp | rip | tacacs | tftp | time } no ip helper-address discard { <udp-port> | dhcp | domain | isakmp | mobile-ip | nameserver | netbios-dgm | netbios-ns | ntp | pim-auto-rp | rip | tacacs | tftp | time }

no - This command is used to delete the address.

Default Setting

None

Command Mode

6.5.2.3 ip helper-address

Use this command to configure the relay of certain UDP broadcast packets received on any interface. If the interface that receives a UDP packet has been configured with an address, this global address value will be ignored. This command can be invoked multiple times, either to specify multiple server addresses for a given UDP port number or to specify multiple UDP port numbers handled by a specific server.

C.	ntov
3	ntax

ip helper-address <ipaddr> { <udp-port> | dhcp | domain | isakmp | mobile-ip | nameserver | netbios-dgm | netbios-ns | ntp | pim-auto-rp | rip | tacacs | tftp | time } no ip helper-address <ipaddr> { <udp-port> | dhcp | domain | isakmp | mobile-ip | nameserver | netbios-dgm | netbios-ns | ntp | pim-auto-rp | rip | tacacs | tftp | time }

no - This command is used to delete the address.

Default Setting

None

Command Mode

Global Config

6.5.2.4 ip helper enable

This command enable the relay of UDP packets.

Syntax	
ip helper	enable
no ip help	per enable

no – disable the relay of UDP packets.

Default Setting

Disabled.

Command Mode

6.5.2.5 clear ip helper statistics

This command is used this command to clear the information of UDP packets processed and relayed by IP helper.

Syntax

clear ip helper statistics

Default Setting

None

Command Mode

Privileged Exec

User Exec

6.6 Routing Information Protocol (RIP) Commands

6.6.1 Show Commands

6.6.1.1 show ip rip

This command displays information relevant to the RIP router.

Syntax						
show ip ri	.ip					

Default Setting

None

Command Mode

Privileged Exec

Display Message

RIP Admin Mode: Select enable or disable from the pulldown menu. If you select enable RIP will be enabled for the switch. The default is disabled.

Split Horizon Mode: Select none, simple or poison reverse from the pulldown menu. Split horizon is a technique for avoiding problems caused by including routes in updates sent to the router from which the route was originally learned. The options are: None - no special processing for this case. Simple - a route will not be included in updates sent to the router from which it was learned. Poisoned reverse - a route will be included in updates sent to the router from which it was learned, but the metric will be set to infinity. The default is simple

Auto Summary Mode: Select enable or disable from the pulldown menu. If you select enable groups of adjacent routes will be summarized into single entries, in order to reduce the total number of entries. The default is enabled.

Host Routes Accept Mode: Select enable or disable from the pulldown menu. If you select enable the router will be accept host routes. The default is enabled.

Global Route Changes: The number of route changes made to the IP Route Database by RIP. This does not include the refresh of a route's age.

Global queries: The number of responses sent to RIP queries from other systems. Default Metric Sets a default for the metric of redistributed routes. This field displays the default metric if one has already been set or blank if not configured earlier. The valid values are (1 to 15).

Default Metric: Sets a default for the metric of redistributed routes. This field displays the default metric if one has already been set or blank if not configured earlier. The valid values are (1 to 15).

Default Route Advertise: The default route.

Distance: Configured distance value for rip routes.

6.6.1.2 show ip rip interface

This command displays information related to a particular RIP interface.

Syntax

show ip rip interface {<slot/port> | loopback <loopback-id> | vlan <vlan-id>}

< slot/port > - Interface number

Default Setting

None

Command Mode

Privileged Exec

Display Message

Interface: Valid slot and port number separated by forward slashes. This is a configured value.

IP Address: The IP source address used by the specified RIP interface. This is a configured value.

Send version: The RIP version(s) used when sending updates on the specified interface. The types are none, RIP-1, RIP-1c, and RIP-2. This is a configured value.

Receive version: The RIP version(s) allowed when receiving updates from the specified interface. The types are none, RIP-1, RIP-2, Both. This is a configured value.

RIP Admin Mode: RIP administrative mode of router RIP operation; enable, disable it. This is a configured value.

Link State: Indicates whether the RIP interface is up or down. This is a configured value.

Authentication Type: The RIP Authentication Type for the specified interface. The types are none, simple, and encrypt. This is a configured value.

Authentication Key: 16 alpha-numeric characters for authentication key when uses simple or encrypt authentication.

Authentication Key ID: It is a Key ID when uses MD5 encryption for RIP authentication.

Default Metric: A number which represents the metric used for default routes in RIP updates originated on the specified interface. This is a configured value. The following information will be invalid if the link state is down.

Bad Packets Received: The number of RIP response packets received by the RIP process which were subsequently discarded for any reason.

Bad Routes Received: The number of routes contained in valid RIP packets that were ignored for any reason.

Updates Sent: The number of triggered RIP updates actually sent on this interface.

6.6.1.3 show ip rip interface brief

This command displays general information for each RIP interface. For this command to display successful results routing must be enabled per interface (i.e. ip rip).

Syntax

show ip rip interface brief

Default Setting

None

Command Mode

Privileged Exec

Display Message

Interfacet: Valid slot and port number separated by forward slashes.

IP Address: The IP source address used by the specified RIP interface.

Send Version: The RIP version(s) used when sending updates on the specified interface. The types are none, RIP-1, RIP-1c, RIP-2.

Receive Version: The RIP version(s) allowed when receiving updates from the specified interface. The types are none, RIP-1, RIP-2, Both

RIP Mode: RIP administrative mode of router RIP operation; enable, disable it.

Link State: The mode of the interface (up or down).

6.6.2 Configuration Commands

6.6.2.1 enable rip

This command resets the default administrative mode of RIP in the router (active).

Syntax		
enable no enable		
no enable	le	

no - This command sets the administrative mode of RIP in the router to inactive.

Default Setting

Enabled

Command Mode

Router RIP Config

6.6.2.2 ip rip

This command enables RIP on a router interface.

Syntax	
ip rip no ip rip	

no - This command disables RIP on a router interface.

Default Setting

Disabled

Command Mode

6.6.2.3 auto-summary

This command enables the RIP auto-summarization mode.

Syntax				
auto-sum	auto-summary			
no auto-s	no auto-summary			

no - This command disables the RIP auto-summarization mode.

Default Setting

Disabled

Command Mode

Router RIP Config

6.6.2.4 default-information originate

This command is used to set the advertisement of default routes.

Syntax

default-information originate no default-information originate

no - This command is used to cancel the advertisement of default routes.

Default Setting

Not configured

Command Mode

6.6.2.5 default-metric

This command is used to set a default for the metric of distributed routes.

Syntax			
default-metric <1-15	>		
no default-metric			

<1 - 15> - a value for default-metric.

no - This command is used to reset the default metric of distributed routes to its default value.

Default Setting

Not configured

Command Mode

Router RIP Config

6.6.2.6 distance rip

This command sets the route preference value of RIP in the router. Lower route preference values are preferred when determining the best route.

Syntax			
distance	rip <1-255>		
no distan	nce rip		

<1 - 255> - the value for distance.

no - This command sets the default route preference value of RIP in the router.

Default Setting

15

Command Mode

6.6.2.7 hostrouteaccept

This command enables the RIP hostroutesaccept mode.

Syntax				
hostroute	eaccept			
no hostro	outeaccept			

no - This command disables the RIP hostroutesaccept mode.

Default Setting

Enabled

Command Mode

Router RIP Config

6.6.2.8 split-horizon

This command sets the RIP split horizon mode. **None mode** will not use RIP split horizon mode. **Simple mode** will be that a route is not advertised on the interface over which it is learned. **Poison mode** will be that routes learned over this interface should be re-advertised on the interface with a metric of infinity (16).

Syntax

split-horizon {none | simple | poison} no split-horizon

none - This command sets without using RIP split horizon mode.

simple - This command sets to use simple split horizon mode.

poison - This command sets to use poison reverse mode.

no - This command cancel to set the RIP split horizon mode and sets none mode.

Default Setting

Simple

Command Mode

6.6.2.9 distribute-list

This command is used to specify the access list to filter routes received from the source protocol. Source protocols have OSPF, Static, and Connected.

Syntax

distribute-list <1-199> out {ospf | static | connected} no distribute-list <1-199> out {ospf | static | connected}

<1 - 199> - Access List ID value. The Access List filters the routes to be redistributed by the source protocol.

no - This command is used to cancel the access list to filter routes received from the source protocol.

Default Setting

0

Command Mode



6.6.2.10 redistribute

This command configures RIP protocol to redistribute routes from the specified source protocol/routers. There are five possible match options. When you submit the command redistribute ospf match <matchtype> the match-type or types specified are added to any match types presently being redistributed. Internal routes are redistributed by default. Source protocols have OSPF, Static, and Connetced. Match types will have internal, external 1, external 2, nssa-external 1, and nssa-external 2.

Syntax

<u>Format for OSPF as source protocol:</u> redistribute ospf [metric <1-15>] [match [internal] [external 1] [external 2] [nssa-external 1] [nssa-external 2]] <u>Format for other source protocols:</u> redistribute {static | connected} [metric <1-15>] no redistribute {ospf | static | connected} [metric] [match [internal] [external 1] [external 2] [nssa-external 1] [nssa-external 2]]

<1 - 15> - a value for metric.

no - This command de-configures RIP protocol to redistribute routes from the specified source protocol/routers.

Default Setting

Metric - not-configured

Match - internal

Command Mode



6.6.2.11 ip rip authentication

This command sets the RIP Version 2 Authentication Type and Key for the specified interface. The value of <type> is either **none**, **simple**, or **encrypt**.

The value for authentication key [key] must be 16 bytes or less. The [key] is composed of standard displayable, non-control keystrokes from a Standard 101/102-key keyboard. If the value of <type> is encrypt, a keyid in the range of 0 and 255 must be specified.

Syntax

ip rip authentication {none | {simple <key>} | {encrypt <key> <keyid>}} no ip rip authentication

none - This command uses no authentication.

simple - This command uses simple authentication for RIP authentication .

encrypt - This command uses MD5 encryption for RIP authentication.

<key> - 16 alpha-numeric characters to be used for authentication key.

<keyid> - a value in the range of 0 – 255 to be used for MD5 encryption.

no - This command sets the default RIP Version 2 Authentication Type.

Default Setting

None

Command Mode

6.6.2.12 ip rip receive version

This command configures the interface to allow RIP control packets of the specified version(s) to be received.

The value for <mode> is one of: **rip1** to receive only RIP version 1 formatted packets, **rip2** for RIP version 2, **both** to receive packets from either format, or **none** to not allow any RIP control packets to be received

Syntax

ip rip receive version {rip1 rip2 both none}	
no ip rip receive version	

no - This command configures the interface to allow RIP control packets of the default version(s) to be received.

Default Setting

Both

Command Mode

6.6.2.13 ip rip send version

This command configures the interface to allow RIP control packets of the specified version to be sent.

The value for <mode> is one of: **rip1** to broadcast RIP version 1 formatted packets, **rip1c** (RIP version 1 compatibility mode) which sends RIP version 2 formatted packets via broadcast, **rip2** for sending RIP version 2 using multicast, or **none** to not allow any RIP control packets to be sent.

Syntax

ip rip send version {rip1 | rip1c | rip2 | none} no ip rip send version

no - This command configures the interface to allow RIP control packets of the default version to be sent.

Default Setting

rip2

Command Mode

GUANTA COMPUTER INC.

6.7 Router Discovery Protocol Commands

6.7.1 Show Commands

6.7.1.1 show ip irdp

This commands displays the router discovery information for all interfaces, or a specified interface.

Syntax

show ip irdp [{<slot/port> | vlan <vlan-id>}]

<slot/port> - Show router discovery information for the specified interface.

no parameter - Show router discovery information for all interfaces.

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Message

Ad Mode: Displays the advertise mode which indicates whether router discovery is enabled or disabled on this interface.

Advertise Address: Addresses to be used to advertise the router for the interface.

Max Int: Displays the maximum advertise interval which is the maximum time allowed

between sending router advertisements from the interface in seconds.

Min Int: Displays the minimum advertise interval which is the minimum time allowed

between sending router advertisements from the interface in seconds.

Hold Time: Displays advertise holdtime which is the value of the holdtime field of the router advertisement sent from the interface in seconds.

Preferences: Displays the preference of the address as a default router address, relative to other router addresses on the same subnet.



6.7.2 Configuration Commands

6.7.2.1 ip irdp

This command enables Router Discovery on an interface.

Syntax	
ip irdp no ip irdp	
no ip irdp	

<no> - Disable Router Discovery on an interface.

Default Setting

Disabled

Command Mode

Interface Config

6.7.2.2 ip irdp address

This command configures the address to be used to advertise the router for the interface.

C.	/nta	
.51	/nt/	4 X I

ip irdp address <address> no ip irdp address

<address> - The address used is 224.0.0.1 or 255.255.255.255.

no - The address used is 224.0.0.1.

Default Setting

The default address is 224.0.0.1

Command Mode

6.7.2.3 ip irdp holdtime

This commands configures the value, in seconds, of the holdtime field of the router advertisement sent from this interface.

Syr	4
SVI	пах
UVI	παλ

ip irdp holdtime < maxadvertinterval-9000 > no ip irdp holdtime

< maxadvertinterval-9000 > The range is the maxadvertinterval to 9000 seconds.

no - This command configures the default value, in seconds, of the holdtime field of the router advertisement sent from this interface.

Default Setting

The default value is 3* maxadvertinterval (600) =1800.

Command Mode

Global Config

6.7.2.4 ip irdp maxadvertinterval

This commands configures the maximum time, in seconds, allowed between sending router advertisements from the interface.

Syntax

ip irdp maxadvertinterval < minadvertinterval-1800 > no ip irdp maxadvertinterval

< minadvertinterval-1800 > - The range is 4 to 1800 seconds.

no - This command configures the default maximum time, in seconds.

Default Setting

The default value is 600.

Command Mode

6.7.2.5 ip irdp minadvertinterval

This command configures the minimum time, in seconds, allowed between sending router

advertisements from the interface.

Syntax

ip irdp minadvertinterval < 3-maxadvertinterval> no ip irdp minadvertinterval

< 3-maxadvertinterval> - The range is 3 to maxadvertinterval seconds.

no - This command sets the minimum time to 450.

Default Setting

The default value is 450.

Command Mode

Global Config

6.7.2.6 ip irdp preference

This command configures the preferability of the address as a default router address, relative to other router addresses on the same subnet.



```
ip irdp preference < -2147483648-2147483647>
no ip irdp preference
```

<-2147483648-2147483647> - The range is -2147483648 to 2147483647.

no - This command sets the preference to 0.

Default Setting

The default value is 0.

Command Mode

6.8 VLAN Routing Commands

6.8.1 Configuration Commands

6.8.1.1 Interface vlan

This command creates a VLAN routing interface.

Syntax				
interface	vlan <vlan-id></vlan-id>			
no interface vlan <vlan-id></vlan-id>				

<vlan-id> - The VLAN ID used for this interface. The range of VLAN ID is 1 to 4093.

no - Delete a VLAN routing interface.

Default Setting

None

Command Mode

6.9 Virtual Router Redundancy Protocol (VRRP) Commands

6.9.1 Show Commands

6.9.1.1 show ip vrrp

This command displays whether VRRP functionality is enabled or disabled. It also displays some global parameters which are required for monitoring.

Syntax			
show ip v	vrrp		

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Message

Admin Mode: Displays the administrative mode for VRRP functionality on the switch.

Router Checksum Errors: Represents the total number of VRRP packets received with an invalid VRRP checksum value.

Router Version Errors: Represents the total number of VRRP packets received with Unknown or unsupported version number.

Router VRID Errors: Represents the total number of VRRP packets received with invalid VRID for this virtual router.

6.9.1.2 show ip vrrp brief

This command displays information about each virtual router configured on the switch.

ę	Syntax	
\$	show ip vrrp brief]

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Message

Interface: Valid slot and port number separated by forward slashes.

VRID: Represents the router ID of the virtual router.

IP Address: Is the IP Address that was configured on the virtual router

Mode: Represents whether the virtual router is enabled or disabled.

State: Represents the state (Master/backup) of the virtual router.

6.9.1.3 show ip vrrp interface

This command displays all configuration information of a virtual router configured on a specific interface. Note that the information will be displayed only when the IP address of the specific interface is configured.

Syntax

show ip vrrp interface {<slot/port> | vlan <vlan-id>} [<vrid>]

<slot/port> - Valid slot and port number separated by forward slashes.

<vrid> - Virtual router ID.

<vlan-id> - VLAN ID. The range of VLAN ID is 1 to 4093.

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Message

VRID: Represents the router ID of the virtual router.

Primary IP Address: This field represents the configured IP Address for the Virtual router.

VMAC address: Represents the VMAC address of the specified router.

Authentication type: Represents the authentication type for the specific virtual router.

Priority: Represents the priority value for the specific virtual router.

Configured Priority: The priority configured through the ip vrrp vrid priority 1-254 command.

Advertisement interval: Represents the advertisement interval for the specific virtual router.

Pre-Empt Mode: Is the preemption mode configured on the specified virtual router.

Pre-Empt Delay: How much time to be delayed before becoming the active router. It only performs the delay when the preemption is first attempted.

Administrative Mode: Represents the status (Enable or Disable) of the specific router.

Accept Mode: When enabled, the VRRP Master can accept ping packets sent to one of the virtual router's IP addresses.

State: Represents the state (Master/backup) of the specific virtual router

6.9.1.4 show ip vrrp interface stats

This command displays the statistical information about each virtual router configured on the switch.

show ip vrrp interface stats {<slot/port> | vlan <vlan-id>} [<vrid>]

<slot/port> - Valid slot and port number separated by forward slashes.

<vrid> - Virtual router ID.

<vlan-id> - VLAN ID. The range of VLAN ID is 1 to 4093.

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Message

VRID: Represents the router ID of the virtual router.

Uptime: Is the time that the virtual router has been up, in days, hours, minutes and seconds.

Protocol: Represents the protocol configured on the interface.

State Transitioned to Master: Represents the total number of times virtual router state has changed to MASTER.

Advertisement Received: Represents the total number of VRRP advertisements received by this virtual router.

Advertisement Interval Errors: Represents the total number of VRRP advertisements received for which advertisement interval is different than the configured value for this virtual

router.

Authentication Failure: Represents the total number of VRRP packets received that don't pass the authentication check.

IP TTL errors: Represents the total number of VRRP packets received by the virtual router with IP TTL (time to live) not equal to 255.

Zero Priority Packets Received: Represents the total number of VRRP packets received by virtual router with a priority of '0'.

Zero Priority Packets Sent: Represents the total number of VRRP packets sent by the virtual router with a priority of '0'

Invalid Type Packets Received: Represents the total number of VRRP packets received by the virtual router with invalid 'type' field.

Address List Errors: Represents the total number of VRRP packets received for which address list does not match the locally configured list for the virtual router.

Invalid Authentication Type: Represents the total number of VRRP packets received with

unknown authentication type.

Authentication Type Mismatch: Represents the total number of VRRP advertisements received for which 'auth type' not equal to locally configured one for this virtual router.

Packet Length Errors: Represents the total number of VRRP packets received with packet length less than length of VRRP header.

6.9.2 Configuration Commands

6.9.2.1 ip vrrp

This command enables the administrative mode of VRRP in the router.

Syntax	
ip vrrp no ip vrrp	
no ip vrrp)

Default Setting

Disabled

Command Mode

Global Config

This command sets the virtual router ID on an interface for Virtual Router configuration in the router.

Syntax			
ip vrrp <1-255>			
no ip vrrp <1-255	>		

<1-255> - The range of virtual router ID is 1 to 255.

<no> - This command removes all VRRP configuration details of the virtual router configured on a specific interface.

Default Setting

None

Command Mode

Interface Config

6.9.2.2 ip vrrp ip

This commands also designates the configured virtual router IP address as a secondary IP address on an interface.

Cuntou	
Syntax	

ip vrrp <1-255> ip <addr> [secondary] no ip vrrp <1-255> ip <addr> [secondary]

<1-255> - The range of virtual router ID is 1 to 255.

<addr> - Secondary IP address of the router ID.

<no> - This command removes all VRRP configuration details of the virtual router configured on a specific interface.

Default Setting

None

Command Mode

Interface Config

6.9.2.3 ip vrrp mode

This command enables the virtual router configured on the specified interface. Enabling the status field starts a virtual router.

Syntax]		
ip vrrp <1	1-255> mode		
no ip vrrp	o <1-255> mode		

<1-255> - The range of virtual router ID is 1 to 255.

<no> - Disable the virtual router configured on the specified interface. Disabling the status field stops a virtual router.

Default Setting

Disabled

Command Mode

Interface Config

6.9.2.4 ip vrrp accept-mode

Use this command to allow the VRRP Master to accept ping packets sent to one of the virtual router's IP addresses.

Syntax	
Syntax	

ip vrrp <1-255> accept-mode no ip vrrp <1-255> accept-mode

<1-255> - The range of virtual router ID is 1 to 255.

<no> - Use this command to prevent the VRRP Master from accepting ping packets sent to one of the virtual router's IP addresses.

Default Setting

Disabled

Command Mode

Interface Config

6.9.2.5 ip vrrp authentication

This command sets the authorization details value for the virtual router configured on a specified interface.

Syntax

ip vrrp <1-255> authentication <key> no ip vrrp <1-255> authentication

<1-255> - The range of virtual router ID is 1 to 255.

<key> - A text password used for authentication.

<no> - This command sets the default authorization details value for the virtual router configured on a specified interface.

Default Setting

no authentication

Command Mode

6.9.2.6 ip vrrp preempt

This command sets the preemption mode value for the virtual router configured on a specified interface.

Cuntor	
Syntax	ĸ

ip vrrp <1-255> preempt [delay <0-3600>] no ip vrrp <1-255> preempt [delay]

<1-255> - The range of virtual router ID is 1 to 255.

<0-3600> - The time to be delayed to become active router.

<no> - This command sets the default preemption mode value for the virtual router configured on a specified interface.

Default Setting

Preempt mode: Enabled

Preempt delay: 0

Command Mode

6.9.2.7 ip vrrp priority

This command sets the priority value for the virtual router configured on a specified interface.

The router with the highest priority is elected master. If a router is configured with the address used as the address of the virtual router, the router is called the "address owner". The priority of the address owner is always 255 so that the address owner is always master. If the master has a priority less than 255 (it is not the address owner) and you configure the priority of another router in the group higher than the master's priority, the router will take over as master only if preempt mode is enabled.

Syntax

ip vrrp <1-255> priority <1-254> no ip vrrp <1-255> priority

<1-255> - The range of virtual router ID is 1 to 255.

<1-254> - The range of priority is 1 to 254.

<no> - This command sets the default priority value for the virtual router configured on a specified interface.

Default Setting

The default priority value is 100 unless the router is the address owner, in which case its priority is automatically set to 255.

Command Mode

6.9.2.8 ip vrrp timers advertise

This command sets the advertisement value for a virtual router in seconds.

ners advertise <1-	255>		
ners advertise			
	ners advertise <1-2 ners advertise	ners advertise <1-255> ners advertise	

- <1-255> The range of virtual router ID is 1 to 255.
- <1-255 > The range of advertisement interval is 1 to 255.
- <no> This command sets the default advertisement value for a virtual router.

Default Setting

The default value of advertisement interval is 1.

Command Mode

Interface Config

6.9.2.9 ip vrrp track interface

This command alters the priority of the VRRP router based on the availability of its interfaces. This command is useful for tracking interfaces that are not configured for VRRP. Only IP interfaces are tracked. A tracked interface is up if the IP on that interface is up. Otherwise, the tracked interface is down.

When the tracked interface is down or the interface has been removed from the router, the priority of the VRRP router will be decremented by the value specified in the decrement argument. When the interface is up for IP protocol, the priority will be incremented by the decrement value.

A VRRP configured interface can track more than one interface. When a tracked interface goes down, then the priority of the router will be decreased by 10 (the default priority decrement) for each downed interface. The default priority decrement is changed using the decrement argument. The default priority of the virtual router is 100, and the default decrement priority is 10. By default, no interfaces are tracked. If you specify just the interface to be tracked, without giving the optional priority, then the default priority will be set. The default priority decrement is 10.

Syntax

ip vrrp <1-255> track interface {<slot/port> | vlan <vlan-id>} [decrement <1-254>] no ip vrrp <1-255> track interface {<slot/port> | vlan <vlan-id>} [decrement]

<1-255> - The range of virtual router ID is 1 to 255.

<1-254 > - The range of decrement is 1 to 254.

<vlan-id> - VLAN ID. The range of VLAN ID is 1 to 4093.

<no> - This command removes the interface from the tracked list or to restore the priority decrement to its default.

Default Setting

Decrement: 10

Command Mode

Interface Config

6.9.2.10 ip vrrp track ip route

This command tracks the route reachability. When the tracked route is deleted, the priority of the VRRP router will be decremented by the value specified in the decrement argument. When the tracked route is added, the priority will be incremented by the same.

A VRRP configured interface can track more than one route. When a tracked route goes down, then the priority of the router will be decreased by 10 (the default priority decrement) for each downed route. By default no routes are tracked. If you specify just the route to be tracked, without giving the optional priority, then the default priority will be set. The default priority decrement is 10. The default priority decrement is changed using the decrement argument.

Syntax

ip vrrp <1-255> track ip route <ip-address/prefix-length> [decrement <1-254>] no ip vrrp <1-255> track ip route <ip-address/prefix-length> [decrement]

<1-255> - The range of virtual router ID is 1 to 255.

<1-254 > - The range of decrement is 1 to 254.

<no> - This command removes the route from the tracked list or to restore the priority decrement to its default. When removing a tracked IP route from the tracked list, the priority should be incremented by the decrement value if the route is not reachable.

Default Setting

Decrement : 10

Command Mode

6.10 Policy Based Routing (PBR) Commands

6.10.1 Show Commands

6.10.1.1 show ip policy

This command lists the route map associated with each interface.

Syntax	
show ip polic	ý

Default Setting

None

Command Mode

Privileged Exec

Display Message

Interface: The interface.

Route-map: The route map.

6.10.1.2 show ip prefix-list

This command displays configuration and status for a prefix list.

Syntax

show ip prefix-list [detail | summary] [prefix-list-name] [network/length] [seq sequencenumber] [longer] [first-match]

Default Setting

None

Command Mode

Privileged Exec

Parameter

detail | summary: (Optional) Displays detailed or summarized information about all prefix lists.

prefix-list-name: (Optional) The name of a specific prefix list.

network/length: (Optional) The network number and length (in bits) of the network mask.

seq: (Optional) Applies the sequence number to the prefix list entry.

sequence-number: (Optional) The sequence number of the prefix list entry.



longer: (Optional) Displays all entries of a prefix list that are more specific than the given network/length.

first-match: (Optional) Displays the entry of a prefix list that matches the given network/length.

6.10.1.3 show route-map

To display a route map, use the show route-map command in Privileged EXEC mode.

Syntax

show route-map [map-name]

Default Setting

None

Command Mode

Privileged Exec

Parameter

map-name: (Optional) Name of a specific route map.

6.10.2 Configuration Commands

6.10.2.1 ip policy route-map

Use this command to identify a route map to use for policy-based routing on an interface specified by <route-map-name>. Policy-based routing is configured on the interface that receives the packets, not on the interface from which the packets are sent.

When a route-map applied on the interface is changed, that is, if new statements are added to route-map or match/set terms are added/removed from route-map statement, and also if route-map that is applied on an interface is removed, route-map needs to be removed from interface and added back again in order to have changed route-map configuration to be effective.

In order to disable policy based routing from an interface, use **no** form of this command.

Syntax

ip policy route-map <route-map-name> no ip policy route-map <route-map-name>

Default Setting

None

Command Mode

Interface Config

6.10.2.2 ip prefix-list

To create a prefix list or add a prefix list entry, use the **ip prefix-list** command in Global Configuration mode.

Prefix lists allow matching of route prefixes with those specified in the prefix list. Each prefix list includes of a sequence of prefix list entries ordered by their sequence numbers. A router sequentially examines each prefix list entry to determine if the route's prefix matches that of the entry. An empty or nonexistent prefix list permits all prefixes. An implicit deny is assume if a given prefix does not match any entries of a prefix list. Once a match or deny occurs the router does not go through the rest of the list.

A prefix list may be used within a route map to match a route's prefix using the command "match ip address"

Up to 128 prefix lists may be configured. The maximum number of statements allowed in prefix list is 64.

To delete a prefix list or a statement in a prefix list, use the **no** form of this command. The command **no ip prefix-list list-name** deletes the entire prefix list. To remove an individual statement from a prefix list, you must specify the statement exactly, with all its options.

Syntax

ip prefix-list <list-name> {[seq number] {permit | deny} network/length [ge length] [le length] | renumber renumber-interval first-statement-number} no ip prefix-list <list-name> [seq number] {permit | deny} network/length [ge length] [le length]



Default Setting

No prefix lists are configured by default. When neither the **ge** nor the **le** option is configured, the destination prefix must match the network/length exactly. If the **ge** option is configured without the **le** option, any prefix with a network mask greater than or equal to the **ge** value is considered a match. Similarly, if the **le** option is configured without the **ge** option, a prefix with a network mask less than or equal to the **le** value is considered a match.

Command Mode

Global Config

Parameter

list-name: The text name of the prefix list. Up to 32 characters.

seq number: (Optional) The sequence number for this prefix list statement. Prefix list statements are ordered from lowest sequence number to highest and applied in that order. If you do not specify a sequence number, the system will automatically select a sequence number five larger than the last sequence number in the list. Two statements may not be configured with the same sequence number. The value ranges from 1 to 4,294,967,294.

permit: Permit routes whose destination prefix matches the statement.

deny: Deny routes whose destination prefix matches the statement.

network/length: Specifies the match criteria for routes being compared to the prefix list statement. The network can be any valid IP prefix. The length is any IPv4 prefix length from 0 to 32.

ge length: (Optional) If this option is configured, then a prefix is only considered a match if its network mask length is greater than or equal to this value. This value must be longer than the network length and less than or equal to 32.

le length: (Optional) If this option is configured, then a prefix is only considered a match if its network mask length is less than or equal to this value. This value must be longer than the ge length and less than or equal to 32.

renumber: (Optional) Provides the option to renumber the sequence numbers of the IP prefix list statements with a given interval starting from a particular sequence number. The valid range for renumber-interval is 1 - 100, and the valid range for first-statement-number is 1 - 1000.

6.10.2.3 ip prefix-list description

To apply a text description to a prefix list, use the **ip prefix-list description** command in Global Configuration mode.

To remove the text description, use the **no** form of this command.

Syntax

ip prefix-list <list-name> description <text> no ip prefix-list <list-name> description

Default Setting

No description is configured by default.

Command Mode

Global Config

Parameter

list-name: The text name of the prefix list.

description text: Text description of the prefix list. Up to 80 characters.

6.10.2.4 route-map

To create a route map and enter Route Map Configuration mode, use the **route-map** command in Global Configuration mode. One use of a route map is to limit the redistribution of routes to a specified range of route prefixes. The redistribution command specifies a route map which refers to a prefix list. The prefix list identifies the prefixes that may be redistributed. It accepts up to 64 route maps.

To delete a route map or one of its statements, use the **no** form of this command.

Syntax	
--------	--

route-map <map-tag> [permit|deny] [sequence-number] no route-map <map-tag> [permit|deny] [sequence-number]

Default Setting

No route maps are configured by default. If no permit or deny tag is given, permit is the default.

Command Mode

Global Config

Parameter

map-tag: Text name of the route map. Route maps with the same name are grouped together in order of their sequence numbers. A route map name may be up to 32 characters long.

permit: (Optional) Permit routes that match all of the match conditions in the route map.

deny: (Optional) Deny routes that match all of the match conditions in the route map.

sequence-number: (Optional) An integer used to order the set of route maps with the same name. Route maps are ordered from lowest to greatest sequence number, with lower sequence numbers being considered first. If no sequence number is specified, the system assigns a value ten greater than the last statement in the route map. The range is 0 to 65,535.

6.10.2.5 match as-path

This route map match term matches BGP autonomous system paths against an AS path access list. If you enter a new **match as-path** term in a route map statement that already has a **match as-path** term, the AS path list numbers in the new term are added to the existing match term, up to the maximum number of lists in a term. A route is considered a match if it matches any one or more of the AS path access lists the match term refers to.

To delete the match as-path term that matches BGP autonomous system paths against an AS path access list, use the **no** form of this command.

Syntax

match as-path <as-path-list-number> no match as-path



Default Setting

None

Command Mode

Route Map Config

Parameter

as-path-list-number: An integer from 1 to 500 identifying the AS path access list to use as match criteria.

6.10.2.6 match community

To configure a route map to match based on a BGP community list, use the **match community** command in Route Map Configuration mode. If the community list returns a permit action, the route is considered a match. If the match statement refers to a community list that is not configured, no routes are considered to match the statement.

To delete a match term from a route map, use the **no** form of this command. The command no match community list exact-match removes the match statement from the route map. (It does not simply remove the exact-match option.) The command no match community removes the match term and all its community lists.

Syntax

match community <community-list> [community-list...] [exact-match] no match community <community-list> [community-list...] [exact-match]

Default Setting

None

Command Mode

Route Map Config

Parameter

community-list: The name of a standard community list. Up to eight names may be included in a single match term.

exact-match: (Optional) When this option is given, a route is only considered a match if the set of communities on the route is an exact match for the set of communities in one of the statements in the community list.

6.10.2.7 match ip address

To configure a route map to match based on a destination prefix, use the **match ip address** command in Route Map Configuration mode. If you specify multiple prefix lists in one statement, then a match occurs if a prefix matches any one of the prefix lists. If you configure a match ip address statement within a route map section that already has a match ip address statement, the new prefix lists are added to the existing set of prefix lists, and a match occurs if any prefix list in the combined set matches the prefix.

To delete a match statement from a route map, use the **no** form of this command.

Syntax

match ip address prefix-list <prefix-list-name> [prefix-list-name...] no match ip address prefix-list <prefix-list-name> [prefix-list-name...]

Default Setting

No match criteria are defined by default.

Command Mode

Route Map Config

Parameter

prefix-list-name: The name of a prefix list used to identify the set of matching routes. Up to eight prefix lists may be specified.

6.10.2.8 match ip address <access-list-number | access-list-name>

Use this command to configure a route map in order to match based on the match criteria configured in an IP access-list. Note that an IP ACL must be configured before it is linked to a route-map. Actions present in an IP ACL configuration are applied with other actions involved in route-map. If an IP ACL referenced by a route-map is removed or rules are added or deleted from that ACL, the configuration is rejected.

If there are a list of IP access-lists specified in this command and the packet matches at least one of these access-list match criteria, the corresponding set of actions in route-map are applied to packet.

If there are duplicate IP access-list numbers/names in this command, the duplicate configuration is ignored.

To delete a match statement from a route map, use the **no** form of this command.

Syntax

match ip address <access-list-number | access-list-name> [...access-list-number | name] no match ip address <access-list-number | access-list-name> [...access-list-number | name]

Default Setting

No match criteria are defined by default.

Command Mode

Route Map Config

Parameter

access-list-number: The access-list number that identifies an access-list configured through access-list CLI configuration commands. This number is 1 to 99 for standard access list number. This number is 100 to 199 for extended access list number.

access-list-name: The access-list name that identifies named IP ACLs. Access-list name can be up to 31 characters in length. A maximum of 16 ACLs can be specified in this 'match' clause.



6.10.2.9 match length

Use this command to configure a route map to match based on the Layer 3 packet length between specified minimum and maximum values. min specifies the packet's minimum Layer 3 length, inclusive, allowed for a match. max specifies the packet's maximum Layer 3 length, inclusive, allowed for a match. Each route-map statement can contain one 'match' statement on packet length range.

To delete a match statement from a route map, use the **no** form of this command.

Syntax	
match length	<min> <max></max></min>
no match leng	gth

Default Setting

No match criteria are defined by default.

Command Mode

Route Map Config

6.10.2.10 match mac-list

Use this command to configure a route map in order to match based on the match criteria configured in an MAC access-list.

A MAC ACL is configured before it is linked to a route-map. Actions present in MAC ACL configuration are applied with other actions involved in route-map. When a MAC ACL referenced by a route-map is removed, the route-map rule is also removed and the corresponding rule is not effective. When a MAC ACL referenced by a route-map is removed or rules are added or deleted from that ACL, the configuration is rejected.

To delete a match statement from a route map, use the **no** form of this command.



match mac-list <mac-list-name> [mac-list-name] no match mac-list <mac-list-name> [mac-list-name]

Default Setting

No match criteria are defined by default.

Command Mode

Route Map Config

Parameter

mac-list-name: The mac-list name that identifies MAC ACLs. MAC Access-list name can be up to 31 characters in length.

6.10.2.11 set as-path

To prepend one or more AS numbers to the AS path in a BGP route, use the **set as-path** command in Route Map Configuration mode. This command is normally used to insert one or more instances of the local AS number at the beginning of the AS_PATH attribute of a BGP route. Doing so increases the AS path length of the route. The AS path length has a strong influence on BGP route selection. Changing the AS path length can influence route selection on the local router or on routers to which the route is advertised.

When prepending an inbound route, if the first segment in the AS_PATH of the received route is an AS_SEQUENCE, as-path-string is inserted at the beginning of the sequence. If the first segment is an AS_SET, as-path-string is added as a new segment with type AS_SEQUENCE at the beginning of the AS path. When prepending an outbound route to an external peer, as-path-string follows the local AS number, which is always the first ASN.

To remove a set command from a route map, use the **no** form of this command.

Syntax

set as-path prepend <as-path-string> no set as-path prepend

Default Setting

None.

Command Mode

Route Map Config

Parameter

as-path-string: A list of AS path numbers to insert at the beginning of the AS_PATH attribute of matching BGP routes. To prepend more than one AS number, separate the ASNs with a space and enclose the string in quotes. Up to ten AS numbers may be prepended.

6.10.2.12 set comm-list delete

To remove BGP communities from an inbound or outbound UPDATE message, use the **set comm-list delete** command in Route Map Configuration mode. A route map with this **set** command can be used to remove selected communities from inbound and outbound routes. When a community list is applied to a route for this purpose, each of the route's communities is submitted to the community list one at a time. Communities permitted by the list are removed from the route. Because communities are processed individually, a community list used to remove communities should not include the exact-match option on statements with multiple communities. Such statements can never match an individual community.

When a route map statement includes both set community and **set comm-list delete** terms, the **set comm-list delete** term is processed first, and then the **set community** term (meaning that, communities are first removed, and then communities are added).

To delete the set command from a route map, use the **no** form of this command.

Syntax

set comm-list <community-list-name> delete no set comm-list



Default Setting

None.

Command Mode

Route Map Config

Parameter

community-list-name: A standard community list name.

6.10.2.13 set community

To modify the communities attribute of matching routes, use the **set community** command in Route Map Configuration mode. The **set community** command can be used to assign communities to routes originated through BGP's network and redistribute commands, and to set communities on routes received from a specific neighbor or advertised to a specific neighbor. It can also be used to remove all communities from a route.

To remove a subset of the communities on a route, use the command "set comm-list delete".

To remove a set term from a route map, use the **no** form of this command.

Syntax

set community <community-number [additive] | no-advertise | no-export | none> no set community

Default Setting

None.

Command Mode

Route Map Config

Parameter

community-number: One to sixteen community numbers, either as a 32-bit integers or in AA:NN format. Communities are separated by spaces. The well-known communities no advertise and no-export are also accepted.

additive: (Optional) Communities are added to those already attached to the route.

no-advertise: Matching route not to be advertised to any BGP peer.

no-export: Matching route not to be advertised to external BGP peer.

none: Removes all communities from matching routes.

6.10.2.14 set interface

If network administrator does not want to revert to normal forwarding but instead want to drop a packet that does not match the specified criteria, a set statement needs to be configured to route the packets to interface null 0 as the last entry in the route-map. **set interface null0** needs to be configured in a

separate statement. It should not be added along with any other statement having other match/set terms.

A route-map statement that is used for PBR is configured as permit or deny. If the statement is marked as deny, traditional destination-based routing is performed on the packet meeting the match criteria. If the statement is marked as permit, and if the packet meets all the match criteria, then set commands in the route-map statement are applied. If no match is found in the route-map, the packet is not dropped; instead the packet is forwarded using the routing decision taken by performing destination-based routing.

To remove a set term from a route map, use the **no** form of this command.

Syntax	
set interface r	nullO
no set interfac	ce null0

Default Setting

None.

Command Mode

Route Map Config

6.10.2.15 set default interface

A packet is dropped by this command only if there is no explicit route for the packet's destination address in the routing table. A default route in the routing table is not considered an explicit route for an unknown destination address.

In a route-map statement, 'set interface null0' and 'set default interface null0' terms are mutually exclusive.

To remove a set term from a route map, use the **no** form of this command.

Syntax

set default interface null0 no set default interface null0

Default Setting

None.

Command Mode

Route Map Config

6.10.2.16 set ip next-hop

Use this command to specify the adjacent next-hop router in the path toward the destination to which the packets should be forwarded. If more than one IP address is specified, the ECMP rule is used to route the packets.

GUANTA COMPUTER INC.

This command affects all incoming packet types and is always used if configured. If configured next-hop is not present in the routing table, an ARP request is sent from the router.

In a route-map statement, 'set ip next-hop' and 'set ip default next-hop' terms are mutually exclusive. However, a 'set ip default next-hop' can be configured in a separate route-map statement.

To remove a set command from a route map, use the **no** form of this command.

Syntax

set ip next-hop <next-hop-address> [...next-hop-address] no set ip next-hop <next-hop-address> [...next-hop-address]

Default Setting

None.

Command Mode

Route Map Config

Parameter

next-hop-address: The IP address of the next hop to which packets are output. It must be the address of an adjacent router. A maximum of 16 next-hop IP addresses can be specified in this 'set' clause.

6.10.2.17 set ip default next-hop

Use this command to set a list of default next-hop IP addresses. If more than one IP address is specified, the ECMP rule is used.

A packet is routed to the next hop specified by this command only if there is no explicit route for the packet's destination address in the routing table. A default route in the routing table is not considered an explicit route for an unknown destination address.

In a route-map statement, 'set ip next-hop' and 'set ip default next-hop' terms are mutually exclusive. However, a 'set ip next-hop' can be configured in a separate route-map statement.

To remove a set command from a route map, use the **no** form of this command.

Syntax

set ip default next-hop <next-hop-address> [...next-hop-address] no set ip default next-hop <next-hop-address> [...next-hop-address]

Default Setting

None.

Command Mode

Route Map Config

Parameter

next-hop-address: The IP address of the next hop to which packets are output. It must be the address of an adjacent router. A maximum of 16 next-hop IP addresses can be specified in this 'set' clause.

6.10.2.18 set ip precedence

Use this command to set the three IP precedence bits in the IP packet header. With three bits, you have eight possible values for the IP precedence; values 0 through 7 are defined. This command is used when implementing QoS and can be used by other QoS services, such as weighted fair queuing (WFQ) and weighted random early detection (WRED).

To reset the three IP precedence bits in the IP packet header to the default, use the **no** form of this command.

Syntax

set ip precedence 0-7 no set ip precedence

Default Setting

None.

Command Mode

Route Map Config

Parameter

- 0: Sets the routine precedence.
- **1:** Sets the priority precedence.
- 2: Sets the immediate precedence.
- 3: Sets the Flash precedence.
- 4: Sets the Flash override precedence.
- **5:** Sets the critical precedence.
- 6: Sets the internetwork control precedence.
- 7: Sets the network control precedence.

6.10.2.19 set local-preference

To set the local preference of specific BGP routes, use the **set local-preference** command in Route Map Configuration mode. The local preference is the first attribute used to compare BGP routes. Setting the local preference can influence which route BGP selects as the best route.

When used in conjunction with a 'match as-path' or 'match ip address' command, this command can be used to prefer routes that transit certain ASs or to make the local router a more preferred exit point to certain destinations.

To remove a set command from a route map, use the **no** form of this command.

Syntax

set local-preference <value> no set local-preference

Default Setting

None.

Command Mode

Route Map Config

Parameter

value: A local preference value, from 0 to 4,294,967,295 (any 32-bit integer).

6.10.2.20 set metric

To set the metric of a route, use the **set metric** command in Route Map Configuration mode. This command sets the Multi Exit Discriminator (MED) when used in a BGP context. When there are multiple peering points between two autonomous systems (AS), setting the MED on routes advertised by one router can influence the other AS to send traffic through a specific peer.

To remove a set command from a route map, use the **no** form of this command.

Syntax	
set metric <va< th=""><th>alue></th></va<>	alue>
no set metric	

Default Setting

None.

Command Mode

Route Map Config

Parameter

value: A metric value, from 0 to 4,294,967,295 (any 32-bit integer).

6.10.2.21 clear ip prefix-list

To reset IP prefix-list counters, use the **clear ip prefix-list** command in Privileged EXEC mode. This command is used to clear prefix-list hit counters. The hit count is a value indicating the number of matches to a specific prefix list entry.

Syntax

clear ip prefix-list [[prefix-list-name] [network/length]]



Command Mode

Privileged Exec

Parameter

prefix-list-name: (Optional) Name of the prefix list from which the hit count is to be cleared.

network/length: (Optional) Network number and length (in bits) of the network mask. If this option is specified, hit counters are only cleared for the matching statement.

6.11 Border Gateway Protocol (BGP) Commands

6.11.1 Show Commands

6.11.1.1 show ip bgp

This command displays information relevant to the BGP router.

Syntax				
show ip b	ogp			

Default Setting

None

Command Mode

Privileged Exec

Display Messages

BGP table version: The BGP Table Version is the main number used. This number is the same as the Generation ID of any BGP prefix for a specific address family and is used to track changes to the BGP route table.

Local Route ID: A 32-bit integer in dotted decimal format identifying the router, about which information is displayed. This is a configured value.

Status Codes : Status of the table entry. The status is displayed at the beginning of each line in the table. It can be one of the following values:

- s The table entry is suppressed.
- * The table entry is valid.
- > The table entry is the best entry to use for that network.
- I The table entry was learned via an internal BGP (iBGP) session.

Origin codes: Origin of the entry. The origin code is placed at the end of each line in the table. It can be one of the following values:

- i Entry originated from an Interior Gateway Protocol (IGP) and was advertised with a **network** router configuration command.
- e Entry originated from an Exterior Gateway Protocol (EGP).
- ? Origin of the path is not clear. Usually, this is a router that is redistributed into BGP from an IGP.

Network: IP address of a network entity.

Next Hop: IP address of the next system that is used when forwarding a packet to the destination network. An entry of 0.0.0.0 indicates that the router has some non-BGP routes to this network.

Metric: If shown, the value of the interautonomous system metric.

LocPref: Local preference value as set with the **set local-preference** route-map configuration command. The default value is 100.

Path: Autonomous system paths to the destination network. There can be one entry in this field for each autonomous system in the path.

6.11.1.2 show ip bgp <prefix/length>

This command displays the BGP routing table entries which are filtered the display output with a prefix/length.

Syntax

show ip bgp <prefix/length>

Default Setting

None

Command Mode

Privileged Eexc

User Exec

Display Messages

Prefix/Prefix Length: IP prefix and prefix length entered to filter the output to display only a particular host or network in the BGP routing table.

Generation ID: Incremented each time phase 2 of the decision process runs and whenever an aggregate address changes. Used to track changes to the BGP route table.

Forwarding: Yes if RTO has selected this route as the best route.

Advertised to Update Groups: The number of update groups reported.

Best Path: Show best path information as following.

Non-Best Paths: Show non-best path information as following.

Local Preference: Local preference value as set with the set local-preference route-map configuration command. The default value is 100.

AS Path: An Autnonomous System path is a list of all the autonomous systems that a specific route passes through to reach one destination.

Origin: Indicates the origin of the entry. It can be IGP, EGP, and Incomplete.

Metric: The value of the interautonomous system metric.

Type: Type of peer (internal or external).

IGP Cost: The cost of Interior Gateway Protocol (IGP).

Peer (Peer ID): The IP Address of the Peer's BGP interface (The Router ID of the Peer's BGP).

BGP Next Hop: IP address of the next system that is used when forwarding a packet to the destination network.

Atomic Aggregate: Include atomic-aggregate routes or not.

Aggregator (AS, Router ID): The information of the speaker that aggregated the routes.

Communities: Valid value is a community number in the range from 1 to 4294967200, or AA:NN (autonomous system-community number/2-byte number), **no-peer**, **no-export**, **no-export-subconfed**, or **no-advertise**.



6.11.1.3 show ip bgp aggregate-address

This command displays information about the aggregate-address.

Syntax

show ip bgp aggregate-address

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Messages

Aggregation of routes with different MED values is allowed: The aggregate-different-meds is enabled.

Prefix/Len: IP prefix and prefix length of the entry.

AS Set: With AS Set feature or not.

Summary Only: With Summary Only feature or not.

Active: The aggregate address is active or not.

6.11.1.4 show ip bgp community

This command display routes that belong to specified BGP communities.

Syntax

show ip bgp community <community-number> [exact-match | local-as | no-advertise | no-export]

< community-number > - Valid value is a community number in the range from 1 to 4294967200, or AA:NN (autonomous system-community number/2-byte number).

exact-match - Display only routes that have an exact match.

local-as - Display only routes that are not sent outside of the local AS.

no-advertise - Display only routes that are not advertised to any peer.

no-export - Display only routes that are not exported outside of the local AS.

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Messages

BGP table version: The BGP Table Version is the main number used. This number is the same as the Generation ID of any BGP prefix for a specific address family and is used to track changes to the BGP route table.

Local Route ID: A 32-bit integer in dotted decimal format identifying the router, about which information is displayed. This is a configured value.

Status Codes: Status of the table entry. The status is displayed at the beginning of each line in the table. It can be one of the following values:

- s The table entry is suppressed.
- * The table entry is valid.
- > The table entry is the best entry to use for that network.
- I The table entry was learned via an internal BGP (iBGP) session.

Origin codes: Origin of the entry. The origin code is placed at the end of each line in the table. It can be one of the following values:

- i Entry originated from an Interior Gateway Protocol (IGP) and was advertised with a **network** router configuration command.
- e Entry originated from an Exterior Gateway Protocol (EGP).
- ? Origin of the path is not clear. Usually, this is a router that is redistributed into BGP from an IGP.

Network: IP address of a network entity.

Next Hop: IP address of the next system that is used when forwarding a packet to the destination network. An entry of 0.0.0.0 indicates that the router has some non-BGP routes to this network.

Metric: If shown, the value of the interautonomous system metric.

LocPref: Local preference value as set with the **set local-preference** route-map configuration command. The default value is 100.

Path: Autonomous system paths to the destination network. There can be one entry in this field for each autonomous system in the path.

6.11.1.5 show ip bgp community-list

This command display routes that are permitted by the Border Gateway Protocol (BGP) community list.

show ip bgp community-list community-list-name [exact-match]

community-list-name - Community list name. The community list name can be standard or expanded.

exact-match - Displays only routes that have an exact match.

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Messages

BGP table version: The BGP Table Version is the main number used. This number is the same as the Generation ID of any BGP prefix for a specific address family and is used to track changes to the BGP route table.

Local Route ID: A 32-bit integer in dotted decimal format identifying the router, about which information is displayed. This is a configured value.

Status Codes: Status of the table entry. The status is displayed at the beginning of each line in the table. It can be one of the following values:

- s The table entry is suppressed.
- * The table entry is valid.
- > The table entry is the best entry to use for that network.
- I The table entry was learned via an internal BGP (iBGP) session.

Origin codes: Origin of the entry. The origin code is placed at the end of each line in the table. It can be one of the following values:

- i Entry originated from an Interior Gateway Protocol (IGP) and was advertised with a **network** router configuration command.
- e Entry originated from an Exterior Gateway Protocol (EGP).
- ? Origin of the path is not clear. Usually, this is a router that is redistributed into BGP from an IGP.

Network: IP address of a network entity.

Next Hop: IP address of the next system that is used when forwarding a packet to the destination network. An entry of 0.0.0.0 indicates that the router has some non-BGP routes to this network.

Metric: If shown, the value of the interautonomous system metric.

LocPref: Local preference value as set with the **set local-preference** route-map configuration command. The default value is 100.

Path: Autonomous system paths to the destination network. There can be one entry in this field for each autonomous system in the path.

6.11.1.6 show ip bgp filter-list

Use this command to display routes that conform to a specified filter list.

Syntax

show ip bgp filter-list access-list-number

access-list-number - Number of an autonomous system path access list. It can be a number from 1 to 500.

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Messages

BGP table version: The BGP Table Version is the main number used. This number is the same as the Generation ID of any BGP prefix for a specific address family and is used to track changes to the BGP route table.

Local Route ID: A 32-bit integer in dotted decimal format identifying the router, about which information is displayed. This is a configured value.

Status Codes: Status of the table entry. The status is displayed at the beginning of each line in the table. It can be one of the following values:

- s The table entry is suppressed.
- * The table entry is valid.
- > The table entry is the best entry to use for that network.
- I The table entry was learned via an internal BGP (iBGP) session.

Origin codes: Origin of the entry. The origin code is placed at the end of each line in the table. It can be one of the following values:

- i Entry originated from an Interior Gateway Protocol (IGP) and was advertised with a **network** router configuration command.
- e Entry originated from an Exterior Gateway Protocol (EGP).
- ? Origin of the path is not clear. Usually, this is a router that is redistributed into BGP from an IGP.

Network: IP address of a network entity.

Next Hop: IP address of the next system that is used when forwarding a packet to the destination network. An entry of 0.0.0.0 indicates that the router has some non-BGP routes to this network.

Metric: If shown, the value of the interautonomous system metric.

LocPref: Local preference value as set with the **set local-preference** route-map configuration command. The default value is 100.

Path: Autonomous system paths to the destination network. There can be one entry in this field for each autonomous system in the path.

6.11.1.7 show ip bgp neighbors

This command displays information about Border Gateway Protocol (BGP) and TCP connections to neighbors.

Syntax

show ip bgp neighbors [<ip-address> [advertised-routes | policy | received-routes | rejected-routes | routes] | policy]

ip-address - Displays information about the IPv4 neighbor. If this argument is omitted, information about all neighbors is displayed.

policy - Display inbound and outbound policies for all neighbors or the specified neighbor.

advertised-routes - Display routes advertised to a neighbor.

received-routes - Display routes received from a neighbor.

rejected-routes - Display routes rejected by inbound policy.

routes - Display routes accepted by inbound policy.

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Messages

Remote Address: The IP Address of the Peer's BGP interface.

Remote AS: Autonomous system number of the neighbor.

Peer ID: Router ID of the neighbor.

Peer Admin Status: States whether BGP is enabled or disabled of the neighbor.

Peer State: Finite state machine (FSM) stage of session negotiation.

Local Port: The port number of the local port.

Remote Port: The port number of the remote port.

Connection Retry Interval: Time interval, in seconds, at which the device resend messages to this neighbor.

Neighbor Capabilities: BGP capabilities advertised and received from this neighbor.

IPv4 Unicast Support: Support IPv4 unicast packets or not. The valid value will be Both, Sent, Received or None.

IPv6 Unicast Support: Support IPv6 unicast packets or not. The valid value will be Both, Sent, Received or None..

Template Name: Name of a locally configured peer policy template.

Update Source: Allowed interface for TCP connections to the neighbor.

GUANTA COMPUTER INC.

Local Interface Address: The IPv4 Address of the local BGP interface.

Local IPv6 Interface Address: The IPv6 Address of the local BGP interface.

Global Hold Time: Default time, in seconds, that BGP will maintain the session with this neighbor without receiving a messages.

Global Keep Alive Time: Default time interval, in seconds, at which keepalive messages are transmitted to this neighbor.

Configured Hold Time: Configured time for this neighbor, in seconds, that BGP will maintain the session with this neighbor without receiving a messages.

Configured Keep Alive Time: Configured time interval for this neighbor, in seconds, at which keepalive messages are transmitted to this neighbor.

Negotiated Hold Time: Negotiated time with this neighbor, in seconds, that BGP will maintain the session with this neighbor without receiving a messages.

Negotiated Keep Alive Time: Negotiated time interval with this neighbor, in seconds, at which keepalive messages are transmitted to this neighbor.

Password: MD5 authentication on a TCP connection for this neighbor.

eBGP-MultiHop Configured TTL value of the external BGP for this neighbor.

Last Error (): Last error from received or sent for this neighbor.

Last SubError: Last sub error for this neighbor.

Time Since Last Error: The time stamps in which the last error occurred.

Established Transitions: The number of connections established.

Established Time: The time from the last connection established.

Time Since Last Update: The time from the last Update message received.

IPv4 Outbound Update Group: The corresponding index number of the IPv4 update group.

IPv6 Outbound Update Group: The corresponding index number of the IPv6 update group.

Msgs Sent: Total number of transmitted messages.

Msgs Rcvd: Total number of received messages.

Open: Number of open messages sent and received.

Update: Number of update messages sent and received.

Keepalive: Number of keepalive messages sent and received.

Notification: Number of notification (error) messages sent and received.

Refresh: Number of route refresh request messages sent and received.

Total: Total number of messages sent and received.

Received UPDATE Queue: The statistics of received UPDATE queue (Size, High, Limit, Drops).

IPv4 Prefix Statistics: The statistics of the IPv4 prefix.

IPv6 Prefix Statistics: The statistics of the IPv6 prefix.

Prefixes Advertised: Number of prefixes advertised.

Prefixes Withdrawn: Number of prefixes withdrawn.

Prefixes Current: Number of prefixes current kept.

Prefixes Accepted: Number of prefixes accepted.



Prefixes Rejected: Number of prefixes rejected.

Max NLRI per Update: Maximum number of network layer reachability attributes in UPDATEs.

Min NLRI per Update: Minimum number of network layer reachability attributes in UPDATEs.

Inbound: Received from the peer.

Outbound: Transmitted to the peer.

6.11.1.8 show ip bgp prefix-list

This command displays information about a prefix list or prefix list entries.

Syntax

show ip prefix-list <prefix-list-name>

prefix-list-name - Displays the entries in a specific prefix list.

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Messages

BGP table version: The BGP Table Version is the main number used. This number is the same as the Generation ID of any BGP prefix for a specific address family and is used to track changes to the BGP route table.

Local Route ID: A 32-bit integer in dotted decimal format identifying the router, about which information is displayed. This is a configured value.

Status Codes: Status of the table entry. The status is displayed at the beginning of each line in the table. It can be one of the following values:

- s The table entry is suppressed.
- * The table entry is valid.
- > The table entry is the best entry to use for that network.
- I The table entry was learned via an internal BGP (iBGP) session.

Origin codes: Origin of the entry. The origin code is placed at the end of each line in the table. It can be one of the following values:

- i Entry originated from an Interior Gateway Protocol (IGP) and was advertised with a **network** router configuration command.
- e Entry originated from an Exterior Gateway Protocol (EGP).
- ? Origin of the path is not clear. Usually, this is a router that is redistributed into BGP from an IGP.

Network: IP address of a network entity.

Next Hop: IP address of the next system that is used when forwarding a packet to the destination network. An entry of 0.0.0.0 indicates that the router has some non-BGP routes to this network.

Metric: If shown, the value of the interautonomous system metric.

LocPref: Local preference value as set with the **set local-preference** route-map configuration command. The default value is 100.

Path: Autonomous system paths to the destination network. There can be one entry in this field for each autonomous system in the path.

6.11.1.9 show ip bgp statistics

This command displays the recent decision process history.

Syntax

Г

show ip bgp statistics

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Messages

Delta T: The time values since decision process ran.

Phase: Decision process phase that ran.

Upd Grp: Outbound update group ID. Only set when decProcPhase is 3.

GenId: Generation ID of BGP routing table when decision process was run.

Reason: Why decision process was triggered.

Peer: Only set if decProcPhase is 1. Identifies the peer whose paths are reprocessed.

Duration: How long the decision process phase took.

Adds: Number of routes added during decision process phase.

Mods: Number of routes modified during decision process phase.

Dels: Number of routes deleted during decision process phase.

6.11.1.10 show ip bgp summary

This command displays the status of all Border Gateway Protocol (BGP) connections.

Syntax

show ip ospf neighbor [interface {<slot/port> | vlan <vlan-id>}] [<ip-address>]

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Messages

Admin Mode: Shows whether the administrative mode of BGP in the router is enabled or disabled.

BGP Router ID: Router ID for the current BGP.

Local AS Number: Autonomous system number of the current BGP.

Number of Network Entries: Number of unique prefix entries in the BGP database.

Number of AS Paths: Number of path entries in the BGP database.

Neighbor: IP address of the neighbor.

ASN: Autonomous system number of the neighbor.

MsgRcvd: Number of messages received from the neighbor.

MsgSent: Number of messages sent to the neighbor.

State: The area ID of the OSPF area associated with the interface.

Up/Down Time: The length of time that the BGP session has been in the Established state, or the current status if not in the Established state.

Pfx Rcvd: The number of prefixes that have been received from a neighbor.

6.11.1.11 show ip bgp template

This command displays peer policy template configurations.

show ip bgp template [<template-name>]

template-name - Displays the configurations in a specific template.

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Messages

Template Name: Name of the peer template.

AF: Address Family (IPv4 or IPv6).

Configuration: The configuration information of the peer template.

794

6.11.1.12 show ip bgp traffic

This command displays global BGP message counters.

Syntax	
Oyncar	

show ip bgp traffic

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Messages

Time Since Counters Cleared: How long ago the SPF ran. The time is in the format hh:mm:ss, giving the hours, minutes, and seconds since the SPF run.

BGP Message Statistics: The statistics of BGP messages sent/received.

Msgs Sent: Total number of transmitted messages.

Msgs Rcvd: Total number of received messages.

Open: Number of open messages sent and received.

Update: Number of update messages sent and received.

Keepalive: Number of keepalive messages sent and received.

Notification: Number of notification (error) messages sent and received.

Refresh: Number of route refresh request messages sent and received.

Total: Total number of messages sent and received.

Max Received UPDATE rate: Maximum rate of received UPDATE messages.

Max Send UPDATE rate: Maximum rate of sent UPDATE messages.

BGP Queue Statistics: The queue statistics of BGP protocol thread.

Events: Holds configuration events, timer expiration events and TCP status reports.

Keepalive Tx: Keepalive timer event expirations.

Dec Proc: Holds events to trigger one of the 3 phases of the decision proces.

Rx Data: Incoming data.

RTO Notifications: RTO notifications. Redistributed routes and next hop resolution changes.

MIB Queries: BGP MIB path queries.

Current: Number of messages in queue currently.

Max: Maximum number of messages in queue.

Drops: Number of messages dropped.

Limit: Maximum size of queue.

6.11.1.13 show ip bgp update-group

This command displays information about the Border Gateway Protocol (BGP) update groups.

Syntax	
• • • • • • • • • • • • • • • • • • • •	

show ip bgp update-group [index-group | peeripadd]

index-group - Update group type with its corresponding index number. The range of update-group index numbers is from 1 to 4294967295.

peeripadd - IP address of a single neighbor who is a member of an update group.

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Messages

Update Group: Update-group number.

Peer Type: Update-group type (internal or external).

Minimum Advertisement Interval: Minimum time, in seconds, between update advertisements.

Neighbor AS Path Access List Out: Neighbor AS Path list out. All members of the group use the same.

Neighbor Prefix List Out: Neighbor prefix list out. All members of the group use the same.

Neighbor Route Map Out: Neighbor route map out. All members of the group use the same.

Members Added: Number of members added to the group.

Members Removed: Number of members removed from the group.

Update Version: Number of times phase 3 of the decision process has run for the group.

Number of UPDATES Sent: Number of UPDATE packets sent to this group.

Time Since Last UPDATE: Number of seconds since last UPDATE sent to group.

Current Prefixes: Number of prefixes currently advertised to the group.

Current Paths: Number of paths in update group's Adj-RIB-Out.

Prefixes Advertised: Number of prefixes advertised.

Prefixes Withdrawn: Number of prefixes withdrawn.

UPDATE Send Failures: Tx of UPDATE message failed to one or more group members.

Current Members: Number of member listed by IP address in the update group.

Version: The number of times decision process phase 3 had run before this history table entry. **Delta T:** When update send occured.

Duration: How long the update send process took.

UPD Built: Number of UPDATE messages constructed during this update send.

UPD Sent: Number of UPDATE messages transmitted during this update send. Generally each UPDATE built is sent once to each member of the update group.

Paths Sent: Number of prefixes advertised during this update send.

Pfxs Adv: Number of prefixes withdrawn during this update send.

Pfxs Wd: Number of paths advertised.



6.11.2 Configuration Commands

6.11.2.1 router bgp

Use this command to the Border Gateway Protocol (BGP) routing mode.

Syntax

router bgp <autonomous-system-number>

autonomous-system-number - Number of an autonomous system that identifies the router to other BGP routers and tags the routing information that is passed along. Number in the range from 1 to 65535.

Default Setting

None

Command Mode

Global Config

6.11.2.2 enable

Use **enable** command resets the default administrative mode of BGP in the router (active). **no enable** command sets the administrative mode of BGP in the router to inactive

Syntax	
enable	
enable no enable	e

Default Setting

Enabled

Command Mode

6.11.2.3 aggregate-address

Use **aggregate-address** command to create an aggregate entry in a Border Gateway Protocol (BGP) database. Use **no aggregate-address** command to disable an aggregate entry in a Border Gateway Protocol (BGP) database.

Syntax

aggregate-address <address> <mask> [as-set] [summary-only] no aggregate-address <address> <mask> [as-set] [summary-only]

address - Aggregate address.

mask - Aggregate mask.

as-set - Generates autonomous system set path informatio.

summary-only - Filters all more-specific routes from update.

Default Setting

The atomic aggregate attribute is set automatically when an aggregate route is created with this command unless the as-set keyword is specified.

Command Mode

Router BGP Config Mode

6.11.2.4 bgp aggregate-different-meds

Use **bgp aggregate-different-meds** command to allow aggregation of routes with different MED values. Use **no bgp aggregate-different-meds** command to disable this function.

Syntax

bgp aggregate-different-meds no bgp aggregate-different-meds

Default Setting

Disabled

Command Mode

6.11.2.5 bgp always-compare-med

Use **bgp always-compare-med** command to compare MED values always from peers in different ASes. Use **no bgp always-compare-med** command to disable this function.

Syntax	
SVIItax	

bgp always-compare-med no bgp always-compare-med

Default Setting

Disabled

Command Mode

Router BGP Config Mode

6.11.2.6 bgp default local-preference

This command change the default local preference value. To return the local preference value to the default setting, use the no form of this command.

Syntax

bgp default local-preference <number> no bgp default local-preference

number - Local preference value from 0 to 4294967295.

Default Setting

100

Command Mode

6.11.2.7 bgp fast-external-failover

This command configures Border Gateway Protocol (BGP) routing process to immediately reset external BGP peering sessions if the link used to reach these peers goes down. **no bgp fast-external-failover** command disables this function.

Syntax

bgp fast-external-failover no bgp fast-external-failover

Default Setting

Enabled

Command Mode

Router BGP Config Mode

6.11.2.8 bgp fast-internal-failover

This command configures Border Gateway Protocol (BGP) routing process to immediately reset internal BGP peering sessions if the link used to reach these peers goes down. **no bgp fast-internal-failover** command disables fast failover for internal peers.

Syntax

bgp fast-internal-failover no bgp fast-internal-failover

Default Setting

Enabled

Command Mode

6.11.2.9 bgp log-neighbor-changes

This command enable logging of BGP neighbor resets . To disable the logging of changes in BGP neighbor adjacencies, use the **no** form of this command.

Syntax

bgp log-neighbor-changes no bgp log-neighbor-changes

Default Setting

Disabled

Command Mode

Router BGP Config Mode

6.11.2.10 bgp router-id

This command sets a 4-digit dotted-decimal number uniquely identifying the router bgp id. The <router-id> is a configured value.

Syntax

bgp <router-id> no bgp <router-id>

Default Setting

None

Command Mode

Router BGP Config Mode

6.11.2.11 bgp maxas-limit

This command configures Border Gateway Protocol (BGP) to discard routes that have a number of autonomous system numbers in AS-path that exceed the specified value. To return the router to default operation, use the no form of this command.

Syntax

bgp maxas-limit <number> no bgp maxas-limit



number - Maximum number of autonomous system numbers in the AS-path attribute of the BGP Update message, ranging from 1 to 100.

Default Setting

75

Command Mode

6.11.2.12 exit

This command is used to exit bgp configuration mode.

Syntax		
exit		

Default Setting

None

Command Mode

Router BGP Config Mode

6.11.2.13 timers bgp

This command is used to set the keepalive and holdtime timers. To return the router to default operation, use the no form of this command.

Syntax

timers bgp <keepalive> <holdtime> no timers bgp

keepalive: The number of seconds this BGP speaker waits for a keepalive message before deciding that the connection is down. We recommend you configure the *keepalive* parameter as 1/3 of the *holdtime* parameter.

holdtime: The number of seconds this BGP speaker waits for a keepalive, update, or notification message before deciding that the connection is down. We recommend you configure the holdtime parameter as 3 times the keepalive parameter.

Default Setting

The default value of **keepalive** is 60 seconds.

The default value of **holdtime** is 180 seconds.

Command Mode

6.11.2.14 neighbor default-originate route-map

This command is used to allow a BGP speaker (the local router) to send the default route 0.0.0.0 to a neighbor for use as a default route, use the neighbor default-originate command in address family or router configuration mode. To send no route as a default, use the no form of this command.

Syntax

neighbor <peeripaddr> default-originate [route-map <route-map-name>] no neighbor <peeripaddr> default-originate [route-map <route-map-name>]

peeripaddr: IP address of the neighboring router.

route-map-name: Identifier of a configured route map. The route map should be examined to filter the networks to be advertised.

Default Setting

None

Command Mode

Router BGP Config Mode

6.11.2.15 neighbor inherit peer

This command is used to inherit neighbor configuration from template.

Syntax

neighbor <peeripaddr> inherit peer <templatename> no neighbor <peeripaddr> inherit peer <templatename>

peeripaddr: IP address of the neighboring router.

templatename: Name for the peer session template.

Default Setting

None

Command Mode

6.11.2.16 neighbor update-source

This command is used to allow BGP sessions to use any operational interface for TCP connections, use the neighbor update-source command in Router BGP Config Mode. To restore the interface assignment to the closest interface, which is called the best local address, use the no form of this command.

Syntax

neighbor <peeripaddr> update-source {<slot/port> | loop <loop interface number>} no neighbor <peeripaddr> update-source

peeripaddr: IP address of the neighboring router.

slot/port: Valid slot and port number separated by forward slashes.

loop interface number: The valid value is 0 to 7.

Default Setting

None

Command Mode

Router BGP Config Mode

6.11.2.17 neighbor description

This command is used to associate a description with a neighbor, use the neighbor description command in router configuration mode. To remove the description, use the no form of this command.



neighbor <peeripaddr> description <description> no neighbor <peeripaddr> description <description>

peeripaddr: IP address of the neighboring router.

description: Text (up to 80 characters) that describes the neighbor

Default Setting

None

Command Mode

6.11.2.18 neighbor password

This command is used to enable Message Digest 5 (MD5) authentication on a TCP connection between two BGP peers, use the neighbor password command in Router BGP Config Mode. To disable this function, use the no form of this command.

Syntax

neighbor <peeripaddr> password <string> no neighbor < peeripaddr> password <string>

peeripaddr: IP address of the neighboring router.

string: Case-sensitive password of up to 25 characters in length.

Default Setting

None

Command Mode

Router BGP Config Mode

6.11.2.19 neighbor connect-retry-interval

This command is used to specify a time interval at which the router attempts to open sessions to peers that are not fully established. To return the router to default operation, use the no form of this command.

Syntax

neighbor <peeripaddr> connect-retry-interval <connection-retry-interval> no neighbor <peeripaddr> connect-retry-interval

peeripaddr: IP address of the neighboring router.

connection-retry-interval: The valid range is 1 to 65535 seconds.

Default Setting

connection-retry-interval: The default is 2 seconds.

Command Mode

6.11.2.20 neighbor maximum-prefix

This command is used to control how many prefixes can be received from a neighbor, use the neighbor maximum-prefix command in Router BGP Config Mode.

Syntax

neighbor <peeripaddr> maximum-prefix {<maximum> | unlimited} [<threshold> | warning-only]

peeripaddr: IP address of the neighboring router.

maximum: Maximum number of prefixes allowed from this neighbor.

unlimited: Don't restric the number of prefixes from this neighbor.

threshold: Integer specifying at what percentage of maximum the router starts to generate a warning message. The range is from 1 to 100.

warning-only: Allows the router to generate a log message when the maximum is exceeded, instead of terminating the peering.

Default Setting

maximum: default is 8160

threshold: default is 75

Command Mode

6.11.2.21 neighbor nexthopself

This command is used to configure the router as the next hop for a BGP-speaking neighbor, use the neighbor nexthopself command in Router BGP Config Mode. To disable this feature, use the no form of this command.

Syntax

neighbor <peeripaddr> nexthopself no neighbor <peeripaddr> nexthopself

peeripaddr: IP address of the neighboring router.

Default Setting

None

Command Mode

Router BGP Config Mode

6.11.2.22 neighbor filter-list

This command is used to set up a BGP filter, use the neighbor filter-list command in Router BGP Config Mode. To disable this function, use the no form of this command.

Syntax
Cyntax

neighbor <peeripaddr> filter-list <listnum> {in | out} no neighbor <peeripaddr> filter-list <listnum> {in | out}

peeripaddr: IP address of the neighboring router.

listname: Number of an autonomous system path access list. You define this access list with the **ip as-path access-list** command.

in: Access list is applied to incoming routes.

out: Access list is applied to outgoing routes.

Default Setting

None

Command Mode

6.11.2.23 neighbor prefix-list

This command is used to prevent distribution of Border Gateway Protocol (BGP) neighbor information as specified in a prefix list, use the neighbor prefix-list command Router BGP Config Mode. To remove a filter list, use the no form of this command.

Syntax

neighbor <peeripaddr> prefix-list <listname> {in | out} no neighbor <peeripaddr> prefix-list <listname> {in | out}

peeripaddr: IP address of the neighboring router.

listname: Name of a prefix list.

in: Applied to incoming advertisements from that neighbor.

out: Applied to outgoing advertisements to that neighbor.

Default Setting

None

Command Mode

Router BGP Config Mode

6.11.2.24 neighbor remoteas

This command is used to add an entry to the BGP or multiprotocol BGP neighbor table, use the neighbor remote-as command in Router BGP Config Mode. To remove an entry from the table, use the no form of this command.



neighbor <peeripaddr> remote-as <as-number> no neighbor <peeripaddr> remote-as <as-number>

peeripaddr: IP address of the neighboring router.

As-number: Number of an autonomous system to which the neighbor belongs in the range from 1 to 65535.

Default Setting

None

Command Mode

6.11.2.25 neighbor route-map

This command is used to apply a route map to incoming or outgoing routes, use the neighbor route-map command in Router BGP Config Mode. To remove a route map, use the no form of this command.

Syntax	
Oyntur	

neighbor <peeripaddr> route-map <route-map-name> { in | out } no neighbor <peeripaddr> route-map <route-map-name> { in | out }

peeripaddr: IP address of the neighboring router.

route-map-name: Identifier of a configured route map. The route map should be examined to filter the networks to be advertised.

in: Applies route map to incoming routes.

out: Applies route map to outgoing routes.

Default Setting

None

Command Mode

Router BGP Config Mode

6.11.2.26 neighbor shutdown

This command is used to disable a neighbor, use the neighbor shutdown command in Router BGP Config Mode. To reenable the neighbor, use the no form of this command.

Syntax

neighbor <peeripaddr> shutdown no neighbor <peeripaddr> shutdown

peeripaddr: IP address of the neighboring router.

Default Setting

None

Command Mode

6.11.2.27 neighbor timers

This command is used to set the timers for a specific BGP peer, use the neighbor timers command in Router BGP Config Mode. To clear the timers for a specific BGP peer, use the no form of this command.

Syntax

neighbor <peeripaddr> timers <keepalive> <holdtime> no neighbor <peeripaddr> timers <keepalive> <holdtime>

peeripaddr: IP address of the neighboring router.

keepalive: Frequency (in seconds) with which the router sends keepalive messages to its peer. The range is from 0 to 65535.

holdtime: Interval (in seconds) after not receiving a keepalive message that the router declares a peer dead. The range is from 0 to 65535.

Default Setting

The default value of <keepalive> is 60 seconds.

The default value of <holdtime> is 180 seconds.

Command Mode

Router BGP Config Mode

6.11.2.28 neighbor advertisement-interval

This command is used to set the minimum interval between the sending of BGP routing updates, use the neighbor advertisement-interval command in Router BGP Config Mode. To remove an entry, use the no form of this command.

Syntax

neighbor <peeripaddr> advertisement-interval <seconds> no neighbor <peeripaddr> advertisement-interval <seconds>

peeripaddr: IP address of the neighboring router.

seconds: Time (in seconds) is specified by an integer ranging from 0 to 600.

Default Setting

30 seconds for external peers and 5 seconds for internal peers.

Command Mode

6.11.2.29 neighbor send-community

This command is used to specify that communities attribute should be sent to a BGP neighbor, use the neighbor send-community command in router configuration mode. To remove the entry, use the no form of this command.

Syntax

neighbor <peeripaddr> send-community no neighbor <peeripaddr> send-community

peeripaddr: IP address of the neighboring router.

Default Setting

None

Command Mode

Router BGP Config Mode

6.11.2.30 distance

This command is used to set the distance based on source and destination information obtained from the routes. To return to the default values, use the no form of this command.

Syntax

distance <1-255> <ipv4-prefix> <wildcard-mask> [prefix-list] no distance

Default Setting

None

Command Mode

6.11.2.31 distance bgp

This command is used to allow the use of external, internal, and local administrative distances that could be a better route than other external, internal, or local routes to a node, use the distance bgp command in address family or router configuration mode. To return to the default values, use the no form of this command.

distance bgp <external-distance> <internal-distance> <local-distance> no distance bgp

external-distance: Administrative distance for external BGP routes. Routes are external when learned from an external autonomous system. The range of values for this argument are from 1 to 255.

internal-distance: Administrative distance for internal BGP routes. Routes are internal when learned from peer in the local autonomous system. The range of values for this argument are from 1 to 255.

local-distance: Administrative distance for local BGP routes. Local routes are those networks listed with a **network** router configuration command, often as back doors, for the router or for the networks that is being redistributed from another process. The range of values for this argument are from 1 to 255.

Default Setting

external-distance: default is 20

internal-distance: default is 200

local-distance: default is 200

Command Mode

6.11.2.32 default-information originate

This command is used to control the redistribution of a protocol or network into the BGP, use the default-information originate command in address family or router configuration mode. To disable this function, use the no form of this command.

Syntax

default-information originate <always> no default-information originate

<always>: Originate a default route even if routing table doesn't have one.

Default Setting

Disabled

Command Mode

Router BGP Config Mode

6.11.2.33 maximum-paths

This command is used to configure the maximum number of parallel routes that an IP routing protocol will install into the routing table, use the maximum-paths command in router bgp configuration. To restore the default value, use the no form of this command.

_	
S١	ntax

maximum-paths [ibgp] <number> no maximum-paths [ibgp] <number>

<number>: Specifies the number of routes to install to the routing table. The range is from 1 to 32.

Default Setting

None

Command Mode

6.11.2.34 default-metric

This command is used to set a default metric for routes redistributed into Border Gateway Protocol (BGP), use the default-metric command in Router BGP Config Mode. To remove the configured value and return BGP to default operation, use the no form of this command.

Syntax	
default-m	netric <number></number>
no defaul	It-metric

<number>: Default metric value applied to the redistributed route. The range of values for this argument is from 1 to 4294967295.

Default Setting

The metric of redistributed connected and static routes is set to 0.

Command Mode

Router BGP Config Mode

6.11.2.35 redistribute

This command is used to redistribute routes from one routing domain into another routing domain, use the redistribute command in router configuration mode. To disable redistribution, use the no form of this command.

Syntax

redistribute <protocol> [metric <0-4294967295>][match {internal | external 1 | external 2 | nssa-external 1 | nssa-external 2}] [route-map <route-map-name>] no redistribute <protocol> [metric <0-4294967295>][match {internal | external 1 | external 2 | nssa-external 1 | nssa-external 2}] [route-map <route-map-name>]

protocol: Source protocol from which routes are being redistributed. It can be one of the following keywords: connected, ospf, static, rip.

route-map-name: Identifier of a configured route map. The route map should be examined to filter the networks to be advertised.

Default Setting

None

Command Mode

6.11.2.36 distribute-list in

This command is used to filter routes or networks received in incoming Border Gateway Protocol (BGP) updates, use the distribute-list in command in router configuration mode. To delete the distribute list and remove it from the running configuration file, use the no form of this command.

Syntax

distribute-list <prefix list-name> in no distribute-list <prefix list-name> in

prefix list-name: Name of a prefix list. The list defines which networks are to be received and which are to be suppressed in routing updates, based upon matching prefixes in the prefix list.

Default Setting

None

Command Mode

Router BGP Config Mode

6.11.2.37 distribute-list out

This command is used to suppress networks from being advertised in outbound Border Gateway Protocol (BGP) updates, use the distribute-list out command in router configuration mode. To delete the distribute list and remove it from the running configuration file, use the no form of this command.

Syntax

distribute-list <prefix list-name> out <protocol> no distribute-list <prefix list-name> out <protocol>

protocol: The source protocol shall be applied with the filter. It can be one of the following keywords: connected, ospf, static, rip.

prefix list-name: Name of a prefix list. The list defines which networks are to be received and which are to be suppressed in routing updates, based upon matching prefixes in the prefix list.

Default Setting

None

Command Mode

6.11.2.38 network

This command is used to specify the networks to be advertised by the Border Gateway Protocol (BGP) routing processes, use the network command in address family or router configuration mode. To remove an entry from the routing table, use the no form of this command.

Syntax

network <ipaddress> mask <mask> [route-map <route-map-name>] no network <ipaddress> mask <mask> [route-map <route-map-name>]

ipaddress: Network that BGP will advertise..

mask: Network mask with mask address..

route-map-name: Identifier of a configured route map. The route map should be examined to filter the networks to be advertised.

Default Setting

None

Command Mode

Router BGP Config Mode

6.11.2.39 template peer

This command is used to enter bgp peer template mode for the specified template. Use the no form of this command to remove the specified template. Peer template is a configuration feature that allows you to share policies between neighbors. This has the advantage of being reusable and with inheritance support that also provides better optimizations regarding building bgp updates.

Syntax

template peer <template name> no template peer <template name>

template name: Name of the peer template.

Default Setting

None

Command Mode

IP Multicast Commands 7

7.1 Distance Vector Multicast Routing Protocol (DVMRP) Commands

This section provides a detailed explanation of the DVMRP commands. The commands are divided into the following different groups:

Show commands are used to display device settings, statistics and other information. Configuration commands are used to configure features and options of the switch. For every configuration command there is a show command that will display the configuration setting.

7.1.1 Show Commands

7.1.1.1 show ip dvmrp

This command displays the system-wide information for DVMRP.

Syntax

show ip dvmrp

Default Setting

None

Command Mode

Privileged Exec

User EXEC

Admin Mode This field indicates whether DVMRP is enabled or disabled. This is a configured value.

Display Message

Admin Mode: Enable or disable DVMRP function.

Version: This field indicates the version of DVMRP being used.

Total Number of Routes: This field indicates the number of routes in the DVMRP routing table.

Reachable Routes: This field indicates the number of entries in the routing table with non-infinitemetrics. The following fields are displayed for each interface.

Slot/Port: Valid slot and port number separated by forward slashes.

Interface Mode: This field indicates the mode of this interface. Possible values are Enabled and Disabled.

State: This field indicates the current state of DVMRP on this interface. Possible values are Operational or Non-Operational.

7.1.1.2 show ip dvmrp interface

This command displays the interface information for DVMRP on the specified interface.

show ip dvmrp interface {<slot/port> | vlan <vlan-id>}

<slot/port> - Valid slot and port number separated by forward slashes.

<vlan-id> - VLAN ID. The range of VLAN ID is 1 to 4093.

Default Setting

None

Command Mode

Privileged Exec

User EXEC

Display Message

Interface Mode: This field indicates whether DVMRP is enabled or disabled on the specified interface. This is a configured value.

Interface Metric: This field indicates the metric of this interface. This is a configured value.

Local Address: This is the IP Address of the interface.

This Field is displayed only when DVMRP is operational on the interface.

Generation ID: This is the Generation ID value for the interface. This is used by the neighboring routers to detect that the DVMRP table should be resent.

The following fields are displayed only if DVMRP is enabled on this interface.

Received Bad Packets: This is the number of invalid packets received.

Received Bad Routes: This is the number of invalid routes received.

Sent Routes: This is the number of routes that have been sent on this interface.

7.1.1.3 show ip dvmrp neighbor

This command displays the neighbor information for DVMRP.

Syntax

show ip dvmrp neighbor

Default Setting

None

Command Mode

Privileged Exec

User EXEC

Display Message

IfIndex: This field displays the value of the interface used to reach the neighbor.

Nbr IP Addr: This field indicates the IP Address of the DVMRP neighbor for which this entry contains information.

State: This field displays the state of the neighboring router. The possible value for this field are ACTIVE or DOWN.

Up Time: This field indicates the time since this neighboring router was learned.

Expiry Time: This field indicates the time remaining for the neighbor to age out. This field is not applicable if the State is DOWN.

Generation ID: This is the Generation ID value for the neighbor.

Major Version: This shows the major version of DVMRP protocol of neighbor.

Minor Version: This shows the minor version of DVMRP protocol of neighbor.

Capabilities: This shows the capabilities of neighbor.

Received Routes: This shows the number of routes received from the neighbor.

Rcvd Bad Pkts: This field displays the number of invalid packets received from this neighbor.

Rcvd Bad Routes: This field displays the number of correct packets received with invalid routes.

7.1.1.4 show ip dvmrp nexthop

This command displays the next hop information on outgoing interfaces for routing multicast datagrams.

Suntay	,
Syntax	<u> </u>

show ip dvmrp nexthop

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Message

Source IP: This field displays the sources for which this entry specifies a next hop on an outgoing interface.

Source Mask: This field displays the IP Mask for the sources for which this entry specifies a next hop on an outgoing interface.

Next Hop Interface: This field displays the interface in slot/port format for the outgoing interface for this next hop.

Type: This field states whether the network is a LEAF or a BRANCH.

7.1.1.5 show ip dvmrp prune

This command displays the table listing the router's upstream prune information.

Syntax					
show ip c	o dvmrp prune				

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Message

Group IP: This field identifies the multicast Address that is pruned.

Source IP: This field displays the IP Address of the source that has pruned.

Source Mask: This field displays the network Mask for the prune source. It should be all 1s or both the prune source and prune mask must match.

Expiry Time (secs): This field indicates the expiry time in seconds. This is the time remaining for this prune to age out.

7.1.1.6 show ip dvmrp route

This command displays the multicast routing information for DVMRP.

Sv	ntax	

show ip dvmrp route

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Message

Source Address: This field displays the multicast address of the source group.

Source Mask: This field displays the IP Mask for the source group.

Upstream Neighbor: This field indicates the IP Address of the neighbor which is the source for the packets for a specified multicast address.

Interface: This field displays the interface used to receive the packets sent by the sources.

Metric: This field displays the distance in hops to the source subnet. This field has a different

meaning than the Interface Metric field.

Expiry Time(secs): This field indicates the expiry time in seconds. This is the time remaining for this route to age out.

Up Time(secs): This field indicates the time when a specified route was learnt, in seconds.

7.1.2 Configuration Commands

7.1.2.1 ip dvmrp

This command sets administrative mode of DVMRP in the router to active. IGMP must be enabled before DVMRP can be enabled.

Syntax		
ip dvmrp no ip dvm	2	
no ip dvm	mrp	

no - This command sets administrative mode of DVMRP in the router to inactive. IGMP must be enabled before DVMRP can be enabled.

Default Setting

Disabled

Command Mode

Global Config

This command sets the administrative mode of DVMRP on an interface to active.

Syntax	IX	
ip dvmrp no ip dvm	nrp	
no ip dvm	dvmrp	

no - This command sets administrative mode of DVMRP on an interface to inactive.

Default Setting

Disabled

Command Mode

Interface Config

7.1.2.2 ip dvmrp metric

This command configures the metric for an interface. This value is used in the DVMRP messages as the cost to reach this network.

Syntax
Oyman

ip dvmrp metric <value> no <u>ip dvmrp metric <value></u>

<value> - This field has a range of 1 to 31.

no - This command resets the metric for an interface to the default value. This value is used in the DVMRP messages as the cost to reach this network.

Default Setting

1

Command Mode

Interface Config

7.2 Internet Group Management Protocol (IGMP) Commands

This section provides a detailed explanation of the IGMP commands. The commands are divided into the following different groups:

Show commands are used to display device settings, statistics and other information.

Configuration commands are used to configure features and options of the switch. For every configuration command there is a show command that will display the configuration setting.

7.2.1 Show Commands

7.2.1.1 show ip igmp

This command displays the system-wide IGMP information.

Syntax	
Syntax	

show ip igmp

Default Setting

None

Command Mode

Privileged Exec

User EXEC

Display Message

IGMP Admin Mode: This field displays the administrative status of IGMP. This is a configured

value.

IGMP Router-Alert check: This field displays the administrative status of Router-Alert validation for IGMP packets.

Interface: Valid slot and port number separated by forward slashes.

Interface Mode: This field indicates whether IGMP is enabled or disabled on the interface. This is a configured value.

Operational-Status: This field indicates the current state of IGMP on this interface. Possible values are Operational or Non-Operational.

827

7.2.1.2 show ip igmp groups

This command displays the registered multicast groups on the interface. If "detail" is specified this command displays the registered multicast groups on the interface in detail.

Syntax
Oyntax

show ip igmp groups {<slot/port> | vlan <vlan-id>} [detail]

<slot/port> - Valid slot and port number separated by forward slashes.

<vlan-id> - VLAN ID. The range of VLAN ID is 1 to 4093.

[detail] - Display details of subscribed multicast groups.

Default Setting

None

Command Mode

Privileged Exec

Display Message

IP Address: This displays the IP address of the interface participating in the multicast group.

Subnet Mask: This displays the subnet mask of the interface participating in the multicast group.

Interface Mode: This displays whether IGMP is enabled or disabled on this interface.

The following fields are not displayed if the interface is not enabled:

Querier Status: This displays whether the interface has IGMP in Querier mode or Non-Querier mode.

Groups: This displays the list of multicast groups that are registered on this interface.

If detail is specified, the following fields are displayed:

Multicast IP Address: This displays the IP Address of the registered multicast group on this interface.

Last Reporter: This displays the IP Address of the source of the last membership report received for the specified multicast group address on this interface.

Up Time: This displays the time elapsed since the entry was created for the specified multicast group address on this interface.

Expiry Time: This displays the amount of time remaining to remove this entry before it is aged out.

Version1 Host Timer: This displays the time remaining until the local router will assume that there are no longer any IGMP version 1 multicast members on the IP subnet attached to this interface. This could be an integer value or "-----" if there is no Version 1 host present.

Version2 Host Timer: TThis displays the time remaining until the local router will assume that there are no longer any IGMP version 2 multicast members on the IP subnet attached to this interface. This could be an integer value or "-----" if there is no Version 2 host present.

828



Group Compatibility Mode: The group compatibility mode (v1, v2 or v3) for this group on the specified interface.

7.2.1.3 show ip igmp interface

This command displays the IGMP information for the interface.

Syntax

show ip igmp interface {<slot/port> | vlan <vlan-id>}

<slot/port> - Valid slot and port number separated by forward slashes.

<vlan-id> - VLAN ID. The range of VLAN ID is 1 to 4093.

Default Setting

None

Command Mode

Privileged Exec

User EXEC

Display Message

Interface: Valid slot and port number separated by forward slashes.

IP Address: This displays the IP address of the interface participating in the multicast group.

Subnet Mask: This displays the subnet mask of the interface participating in the multicast group.

IGMP Admin Mode: This field displays the administrative status of IGMP. This is a configured

value.

Interface Mode: This field indicates whether IGMP is enabled or disabled on the interface. This is a configured value.

IGMP Version: This field indicates the version of IGMP running on the interface. This value can be configured to create a router capable of running either IGMP version 1 or 2.

Query Interval (secs): This field indicates the frequency at which IGMP Host-Query packets are transmitted on this interface. This is a configured value.

Query Max Response Time (1/10 of a second): This field indicates the maximum query response time advertised in IGMPv2 queries on this interface. This is a configured value.

Robustness: This field displays the tuning for the expected packet loss on a subnet. If a subnet is expected to be have a lot of loss, the Robustness variable may be increased for that interface. This is a configured value.

Startup Query Interval (secs): This value indicates the interval between General Queries sent by a Querier on startup. This is a configured value.

Startup Query Count: This value is the number of Queries sent out on startup, separated by the Startup Query Interval. This is a configured value.

Last Member Query Interval (1/10 of a second): This value indicates the Maximum Response Time inserted into Group-Specific Queries sent in response to Leave Group messages. This is a configured

value.

830

Last Member Query Count: This value is the number of Group-Specific Queries sent before the router assumes that there are no local members. This is a configured value.

7.2.1.4 show ip igmp interface membership

This command displays the list of interfaces that have registered in the multicast group.

Syntax

show ip igmp interface membership <multiipaddr> [detail]

< multipaddr > - A multicast IP address..

[detail] - Display details of subscribed multicast groups.

Default Setting

None

Command Mode

Privileged Exec

User EXEC

Display Message

linterface: Valid slot and port number separated by forward slashes.

Interface IP: This displays the IP address of the interface participating in the multicast group.

State: This displays whether the interface has IGMP in Querier mode or Non-Querier mode.

Group Compatibility Mode: The group compatibility mode (v1, v2 or v3) for the specified group on this interface.

Source Filter Mode: The source filter mode (Include/Exclude) for the specified group on this interface. This is "-----" for IGMPv1 and IGMPv2 Membership Reports.

If detail is specified, the following fields are displayed:

Interface: Valid slot and port number separated by forward slashes.

Group Compatibility Mode: The group compatibility mode (v1, v2 or v3) for the specified group on this interface.

Source Filter Mode: The source filter mode (Include/Exclude) for the specified group on this interface. This is "-----" for IGMPv1 and IGMPv2 Membership Reports.

Source Hosts: This displays the list of unicast source IP Addresses in the group record of the IGMPv3 Membership Report with the specified multicast group IP Address. This is "-----" for IGMPv1 and IGMPv2 Membership Reports.

Expiry Time: This displays the amount of time remaining to remove this entry before it is aged out. This is "- ----" for IGMPv1 and IGMPv2 Membership Reports.

7.2.1.5 show ip igmp interface stats

This command displays the IGMP statistical information for the given interface. The statistics are only displayed when the interface is enabled for IGMP.

show ip igmp interface stats {<slot/port> | vlan <vlan-id>}

<slot/port> - Valid slot and port number separated by forward slashes.

<vlan-id> - VLAN ID. The range of VLAN ID is 1 to 4093.

Default Setting

None

Command Mode

Privileged Exec

User EXEC

Display Message

Querier Status: This field indicates the status of the IGMP router, whether it is running in Querier mode or Non-Querier mode.

Querier IP Address: This field displays the IP Address of the IGMP Querier on the IP subnet to which this interface is attached.

Querier Up Time: This field indicates the time since the interface Querier was last changed.

Querier Expiry Time: This field displays the amount of time remaining before the Other Querier

Present Timer expires. If the local system is the querier, the value of this object is

zero.

Wrong Version Queries: This field indicates the number of queries received whose IGMP version does not match the IGMP version of the interface.

Number of Joins: This field displays the number of times a group membership has been added on this interface.

Number of Groups: This field indicates the current number of membership entries for this interface.

833

7.2.2 Configuration Commands

7.2.2.1 ip igmp

This command sets the administrative mode of IGMP in the router to active.

Syntax	
ip igmp no ip igm	סנ
no ip igin	۱۲ ۲

no - This command sets the administrative mode of IGMP in the router to inactive.

Default Setting

Disabled

Command Mode

Global Config

This command sets the administrative mode of IGMP on an interface to active.

Syntax					
ip igmp no ip igm	ıp				

no - This command sets the administrative mode of IGMP on an interface to inactive.

Default Setting

Disabled

Command Mode

7.2.2.2 ip igmp router-alert-check

This command Disables/Enables Router-Alert validation for IGMP packets.

Syntax	
ip igmp ro	outer-alert-check
no ip igm	p router-alert-check

no - This command disables/Enables Router-Alert validation for IGMP packets.

Default Setting

Disabled

Command Mode

Global Config

7.2.2.3 ip igmp version

This command configures the version of IGMP for an interface.

Syntax

igmp version {1 2 3}	
ip igmp version	

<1- 3> - The igmp version number.

no - This command resets the version of IGMP for this interface. The version is reset to the default value.

Default Setting

3

Command Mode

7.2.2.4 ip igmp last-member-query-count

This command sets the number of Group-Specific Queries sent before the router assumes that there are no local members on the interface.

Synta	v
Synta	х

ip igmp last-member-query-count <1-20> no ip igmp last-member-query-count

<1-20> - The range for <1-20> is 1 to 20.

no - This command resets the number of Group-Specific Queries to the default value.

Default Setting

2

Command Mode

Interface Config

7.2.2.5 ip igmp last-member-query-interval

This command configures the Maximum Response Time being inserted into Group-Specific Queries sent in response to Leave Group messages on the interface.

Syntax

ip igmp last-member-query-interval <0-255> no ip igmp last-member-query-interval

<0-255> - The range for **<0-255>** is 0 to 255 tenths of a second.

no - This command resets the Maximum Response Time being inserted into Group-Specific Queries sent in response to Leave Group messages on the interface to the default value.

Default Setting

10 tenths of a second

Command Mode

7.2.2.6 ip igmp query-interval

This command configures the query interval for the specified interface. This is the frequency at which IGMP Host-Query packets are transmitted on this interface.

Syntax

ip igmp query-interval <1-31744> no ip igmp query-interval

<1-31744> - The range for **<1-31744>** is 1 to 31744 seconds.

IGMP version 3: range 1-31744, version 2: range 1-3600, version 1: range 1-3600

no - This command resets the query interval for the specified interface to the default value. This is the frequency at which IGMP Host-Query packets are transmitted on this interface.

Default Setting

125 seconds

Command Mode

Interface Config

7.2.2.7 ip igmp query-max-response-time

This command configures the maximum response time interval for the specified interface, which is the maximum query response time advertised in IGMPv2 queries on this interface. The time interval is specified in tenths of a second.

Syntax

ip igmp query-max-response-time <0-31744> no ip igmp query-max-response-time

<0-31744> - The range for **<**0-31744**>** is 0 to 31744 tenths of a second.

IGMP version 3: range 0-31744, version 2: range 0-255, version 1: range 0-255

no - This command resets the maximum response time interval for the specified interface, which is the maximum query response time advertised in IGMPv2 queries on this interface to the default value. The maximum response time interval is reset to the default time.

Default Setting

100

Command Mode

Interface Config

837

7.2.2.8 ip igmp robustness

This command configures the robustness that allows tuning of the interface. The robustness is the tuning for the expected packet loss on a subnet. If a subnet is expected to have a lot of loss, the Robustness variable may be increased for the interface.

Syntax			
ip iamp ro	obustness <1-255>		

no ip igmp robustness

<1-255> - The range for **<1-255>** is 1 to 255.

no - This command sets the robustness value to default.

Default Setting

2

Command Mode

Interface Config

7.2.2.9 ip igmp startup-query-count

This command sets the number of Queries sent out on startup, separated by the Startup Query Interval on the interface.

Syntax

ip igmp startup-query-count <1-20> no ip igmp startup-query-count

<1-20> - The range for <1-20> is 1 to 20.

no - This command resets the number of Queries sent out on startup, separated by the Startup Query Interval on the interface to the default value.

Default Setting

2

Command Mode

7.2.2.10 ip igmp startup-query-interval

This command sets the interval between General Queries sent by a Querier on startup on the interface. The time interval value is in seconds.

-	
Syn	tax

ip igmp startup-query-interval <1-300> no ip igmp startup-query-interval

<1-300> - The range for **<1-300>** is 1 to 300 seconds.

no - This command resets the interval between General Queries sent by a Querier on startup on the interface to the default value.

Default Setting

31

Command Mode

Interface Config

7.3 MLD Commands

This section provides a detailed explanation of the MLD commands. The commands are divided into the following different groups:

Show commands are used to display device settings, statistics and other information.

Configuration commands are used to configure features and options of the switch. For every configuration command there is a show command that will display the configuration setting.

7.3.1 Show Commands

7.3.1.1 show ipv6 mld groups

Use this command to display information about multicast groups that MLD reported. The information is displayed only when MLD is enabled on at least one interface. If MLD was not enabled on even one interface, there is no group information to be displayed.

Syntax

show ipv6 mld groups {<slot/port> | vlan <vlan-id> | <group-address>}

<slot/port> - Valid slot and port number separated by forward slashes.

839

<vlan-id> - VLAN ID. The range of VLAN ID is 1 to 4093.

Default Setting

None

Command Mode

Privileged Exec

Display Message

The following fields are displayed as a table when <slot/port> is specified.

Group Address: The address of the multicast group.

Interface: Interface through which the multicast group is reachable.

Up Time: Time elapsed in hours, minutes, and seconds since the multicast group has been known.

Expiry Time: Time left in hours, minutes, and seconds before the entry is removed from the MLD membership table.

When <group-address> is specified, the following fields are displayed for each multicast group and each interface.

Interface: Interface through which the multicast group is reachable.

Group Address: The address of the multicast group.

Last Reporter: The IP Address of the source of the last membership report received for this multicast group address on that interface.

Filter Mode: The filter mode of the multicast group on this interface. The values it can take are *include* and *exclude*.

Version 1 Host Timer: The time remaining until the router assumes there are no longer any MLD version-1 Hosts on the specified interface.

Group Compat Mode: The compatibility mode of the multicast group on this interface. The values it can take are *MLDv1* and MLDv2

The following table is displayed to indicate all the sources associated with this group.

Source Address: The IP address of the source.

Uptime: Time elapsed in hours, minutes, and seconds since the source has been known.

Expiry Time: Time left in hours, minutes, and seconds before the entry is removed.

7.3.1.2 show ipv6 mld interface

Use this command to display MLD-related information for the interface.

show ipv6 mld interface [{<slot/port> | vlan <vlan-id>}]

<slot/port> - Valid slot and port number separated by forward slashes.

<vlan-id> - VLAN ID. The range of VLAN ID is 1 to 4093.

Default Setting

None

Command Mode

Privileged Exec

Display Message

The following information is displayed for each of the interfaces or for only the specified interface.

Interface: The interface number in slot/port format.

MLD Global Admin Mode: Displays the configured administrative status of MLD.

MLD Interface Admin Mode: Displays the configured administrative status of MLD on the interface.

MLD Operational Mode: The operational status of MLD on the interface.

MLD Version: Indicates the version of MLD configured on the interface.

Query Interval: Indicates the configured query interval for the interface.

Query Max Response Time: Indicates the configured maximum query response time (in seconds) advertised in MLD queries on this interface.

Robustness: Displays the configured value for the tuning for the expected packet loss on a subnet attached to the interface.

Startup Query interval: This valued indicates the configured interval between General Queries sent by a Querier on startup.

Startup Query Count: This value indicates the configured number of Queries sent out on startup, separated by the Startup Query Interval.

Last Member Query Interval: This value indicates the configured Maximum Response Time inserted into Group-Specific Queries sent in response to Leave Group messages.

Last Member Query Count: This value indicates the configured number of Group-Specific Queries sent before the router assumes that there are no local members.

The following information is displayed if the operational mode of the MLD interface is enabled.

Querier Status: This value indicates whether the interface is an MLD querier or non-querier on the subnet it is associated with.

Querier IP Address: The IP address of the MLD querier on the subnet the interface is associated with.

Querier Up Time: Time elapsed in seconds since the querier state has been updated.

Querier Expiry Time: Time left in seconds before the Querier loses its title as querier.

Wrong Version Queries: Indicates the number of queries received whose MLD version does not match the MLD version of the interface.

Number of Joins Received: The number of times a group membership has been added on this interface.

Number of Groups: The current number of membership entries for this interface.

7.3.1.3 show ipv6 mld traffic

Use this command to display MLD statistical information for the router.

Syntax				
show ipv6	6 mld traffic			

Default Setting

None

Command Mode

Privileged Exec

Display Message

Valid MLD Packets Received: The number of valid MLD packets received by the router.

Valid MLD Packets Sent: The number of valid MLD packets sent by the router.

Queries Received: The number of valid MLD queries received by the router.

Queries Sent: The number of valid MLD queries sent by the router.

Reports Received: The number of valid MLD reports received by the router.

Reports Sent: The number of valid MLD reports sent by the router.

Leaves Received: The number of valid MLD leaves received by the router.

Leaves Sent: The number of valid MLD leaves sent by the router.

Bad Checksum MLD Packets: The number of bad checksum MLD packets received by the router.

Malformed MLD Packets: The number of malformed MLD packets received by the router.

7.3.2 Configuration Commands

7.3.2.1 ipv6 mld query-interval

Use this command to set the MLD router's query interval for the interface. The query-interval is the amount of time between the general queries sent when the router is the querier on that interface.

Cuntor	
Syntax	

ipv6 mld query-interval <1-31744> no ipv6 mld query-interval

<1-31744> - The range for **<1-31744>** is 1 to 31744 seconds.

MLD version 2: range 1-31744, version 1: range 1-3600

no - Use this command to reset the MLD query interval to the default value for that interface.

Default Setting

125

Command Mode

Interface Config

7.3.2.2 ipv6 mld query-max-response-time

Use this command to set the MLD querier's maximum response time for the interface and this value is used in assigning the maximum response time in the query messages that are sent on that interface.

Syntax

ipv6 mld query-max-response-time <0-8387584> no ipv6 mld query-max-response-time

<1-8387584> - The range for <1-8387584> is 1 to 8387584 milliseconds.

MLD version 2: range 1-8387584, version 1: range 1-65535

no - This command resets the MLD query max response time for the interface to the default value.

Default Setting

10000 milliseconds

Command Mode

7.3.2.3 ipv6 mld last-member-query-interval

Use this command to set the last member query interval for the MLD interface, which is the value of the maximum response time parameter in the group specific queries sent out of this interface. The range for *<last-member-query-interval>* is 0 to 65535 milliseconds.

Syntax

ipv6 mld last-member-query-interval <0-65535> no ipv6 mld last-member-query-interval

no - Use this command to reset the *<last-member-query-interval>* parameter of the interface to the default value.

Default Setting

1000 milliseconds

Command Mode

Interface Config

7.3.2.4 ipv6 mld last-member-query- count

Use this command to set the number of listener-specific queries sent before the router assumes that there are no local members on the interface. The range for *<last-member-query-count>* is 1 to 20.

Syntax

ipv6 mld last-member-query-count <1-20> no ipv6 mld last-member-query-count

no - Use this command to reset the *<last-member-query-count>* parameter of the interface to the default value.

Default Setting

2

Command Mode

7.3.2.5 ipv6 mld router

Use this command, in the administrative mode of the router, to enable MLD in the router.

Syntax				
ipv6 mld	router			
no ipv6 n	nld router			

Default Setting

Disabled

Command Mode

Global Config

Interface Config

7.3.2.6 clear ipv6 mld counters

The user can go to the CLI Privilege Configuration Mode to clear MLD counters on the system, use the **clear ipv6 mld counters [<slot/port>]** priviledge configuration command.

Syntax

clear ipv6 mld counters [{<slot/port> vlan <vlan-id>}]

<slot/port> - Specify the interface.

<vlan-id> - Specifies the VLAN interface. The range of the VLAN ID is 1 to 4093.

Default Setting

None

Command Mode

Privilege Exec

7.3.2.7 clear ipv6 mld traffic

The user can go to the CLI Privilege Configuration Mode to clear MLD traffec on the system, use the **clear ipv6 mld traffic** priviledge configuration command.

Syntax
SVIILAX

clear ipv6 mld traffic

Default Setting

None

Command Mode

Privilege Exec

7.3.2.8 ipv6 mld version

This command configures the version of MLD for an interface.

Syntax

ipv6 mld	version {1 2}
no ipv6 n	nld version

<1- 2> - The mld version number.

no - This command resets the version of MLD for this interface. The version is reset to the default value.

Default Setting

2

Command Mode

7.4 Multicast Commands

7.4.1 Show Commands

7.4.1.1 show ip mcast

This command displays the system-wide multicast information

Syntax]	
show ip n	mcast	

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Message

Admin Mode: This field displays the administrative status of multicast. This is a configured value.

IPv4 Protocol State: This field indicates the current state of the IPv4 multicast protocol. Possible values are Operational or Non-Operational.

IPv6 Protocol State: This field indicates the current state of the IPv6 multicast protocol. Possible values are Operational or Non-Operational.**Table Max Size:** This field displays the maximum number of entries allowed in the multicast table.

IPv4 Protocol: This field displays the multicast protocol running on the router. Possible values are PIMDM, PIMSM, or DVMRP.

IPv6 Protocol: This field displays the multicast protocol running on the router. Possible values are PIMDM or PIMSM,

Multicast Forwarding Cache Entry Count: This field displays the number of entries in the multicast table.

7.4.1.2 show ip mcast boundary

This command displays all the configured administrative scoped multicast boundaries.

Syntax

show ip mcast boundary [{<slot/port> | vlan <vlan-id>}]

<**slot/port > -** Interface number.

<vlan-id> - VLAN ID. The range of VLAN ID is 1 to 4093.

no parameter - Represents all interfaces.

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Message

Interface: Valid slot and port number separated by forward slashes.

Group IP: The group IP address.

Mask: The group IP mask.

7.4.1.3 show ip mcast interface

This command displays the multicast information for the specified interface.

Syntax

show ip mcast interface {<slot/port> | vlan <vlan-id>}

<**slot/port > -** Interface number.

<vlan-id> - VLAN ID. The range of VLAN ID is 1 to 4093.

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Message

Interface: Valid slot and port number separated by forward slashes.

TTL: This field displays the time-to-live value for this interface.

7.4.1.4 show ip mcast mroute

This command displays a summary or all the details of the multicast table.

Syntax
SVIITAX

show ip mcast mroute {detail | summary}

detail - displays the multicast routing table details.

summary - displays the multicast routing table summary.

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Message

If the "detail" parameter is specified, the following fields are displayed:

Source IP: This field displays the IP address of the multicast data source.

Group IP: This field displays the IP address of the destination of the multicast packet.

Expiry Time (secs): This field displays the time of expiry of this entry in seconds.

Up Time (secs): This field displays the time elapsed since the entry was created in seconds.

RPF Neighbor: This field displays the IP address of the RPF neighbor.

Flags: This field displays the flags associated with this entry.

If the "summary" parameter is specified, the following fields are displayed:

Source IP: This field displays the IP address of the multicast data source.

Group IP: This field displays the IP address of the destination of the multicast packet.

Protocol: This field displays the multicast routing protocol by which this entry was created.

Incoming Interface: This field displays the interface on which the packet for this source/group arrives.

Outgoing Interface List: This field displays the list of outgoing interfaces on which this packet is forwarded.

This command displays the multicast configuration settings such as flags, timer settings, incoming and outgoing interfaces, RPF neighboring routers, and expiration times of all the entries in the multicast mroute table containing the given <groupipaddr>.

Syntax

show ip mcast mroute group <groupipaddr> {detail |summary}

< groupipaddr > - the IP Address of the destination of the multicast packet.

detail - Display the multicast routing table details.

summary - Display the multicast routing table summary.

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Message

If the **detail** parameter is specified the follow fields are displayed:

Source IP: This field displays the IP address of the multicast data source.

Group IP: This field displays the IP address of the destination of the multicast packet.

Expiry Time (secs): This field displays the time of expiry of this entry in seconds.

Up Time (secs): This field displays the time elapsed since the entry was created in seconds.

RPF Neighbor: This field displays the IP address of the RPF neighbor.

Flags: This field displays the flags associated with this entry.

If the **summary** parameter is specified the follow fields are displayed:

Source IP: This field displays the IP address of the multicast data source.

Group IP: This field displays the IP address of the destination of the multicast packet.

Protocol This field displays the multicast routing protocol by which this entry was created.

Incoming Interface: This field displays the interface on which the packet for this group arrives.

Outgoing Interface List: This field displays the list of outgoing interfaces on which this packet is forwarded.

This command displays the multicast configuration settings such as flags, timer settings, incoming and outgoing interfaces, RPF neighboring routers, and expiration times of all the entries in the multicast mroute table containing the given <sourceipaddr>.

Syntax

show ip mcast mroute source <sourceipaddr> {summary | detail}

< sourceipaddr > - the IP Address of the multicast data source.

summary - display the multicast routing table summary

detail - Display the multicast routing table details.

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Message

If the < groupipaddr > parameter is specified the follow fields are displayed:

Source IP: This field displays the IP address of the multicast data source.

Group IP: This field displays the IP address of the destination of the multicast packet.

Expiry Time (secs): This field displays the time of expiry of this entry in seconds.

Up Time (secs): This field displays the time elapsed since the entry was created in seconds.

RPF Neighbor: This field displays the IP address of the RPF neighbor.

Flags: This field displays the flags associated with this entry.

If the **summary** parameter is specified the follow fields are displayed:

Source IP: This field displays the IP address of the multicast data source.

Group IP: This field displays the IP address of the destination of the multicast packet.

Protocol: This field displays the multicast routing protocol by which this entry was created.

Incoming Interface: This field displays the interface on which the packet for this source arrives.

Outgoing Interface List: This field displays the list of outgoing interfaces on which this packet is forwarded.

7.4.2 Configuration Commands

7.4.2.1 ip multicast

This command sets the administrative mode of the IP multicast forwarder in the router to active. For multicast routing to become operational, IGMP must be currently enabled. An error message will be displayed on the CLI if multicast routing is enabled while IGMP is disabled. However, the IP multicast mode configuration is stored in the multicast configuration file and is automatically enabled once IGMP is enabled.

Syntax			
ip multica	ip multicast		
no ip multicast			

no - This command sets the administrative mode of the IP multicast forwarder in the router to inactive . For multicast routing to become operational, IGMP must be currently enabled. An error message will be displayed on the CLI if multicast routing is enabled while IGMP is disabled. However, the IP multicast mode configuration is stored in the multicast configuration file and is automatically enabled once IGMP is enabled.

Default Setting

Disbaled

Command Mode

Global Config

7.4.2.2 ip mcast boundary

This command adds an administrative scope multicast boundary specified by <groupipaddr> and <mask> for which this multicast administrative boundary is applicable. <groupipaddr> is a group IP address and <mask> is a group IP mask.

Syntax
Oyman

ip mcast boundary <groupipaddr> <mask> no ip mcast boundary <groupipaddr> <mask>

<groupipaddr> - the multicast group address for the start of the range of addresses to be excluded. The address must be in the range of 239.0.0.0 through 239.255.255.255.

<mask> - mask to be applied to the multicast group address.

no - This command deletes an administrative scope multicast boundary specified by <groupipaddr> and <mask> for which this multicast administrative boundary is applicable. <groupipaddr> is a group IP address and <mask> is a group IP mask.

Default Setting

None

Command Mode

7.4.2.3 ip multicast ttl-threshold

This command applies the given <ttlthreshold> to a routing interface. The <ttlthreshold> is the

TTL threshold which is to be applied to the multicast Data packets which are to be forwarded from the interface. The value for <ttlthreshold> has range from 0 to 255.

Syntax	
ip multica	st ttl-threshold <0 - 255>

no ip multicast ttl-threshold

<0 - 255> - the TTL threshold.

no - This command applies the default <ttlthreshold> to a routing interface. The <ttlthreshold> is the TTL threshold which is to be applied to the multicast Data packets which are to be forwarded from the interface.

Default Setting

1

Command Mode

7.5 IPv4 Protocol Independent Multicast (PIM) Commands

7.5.1 Show Commands

7.5.1.1 **show ip pim**

This command displays the system-wide information for PIM-DM or PIM-SM.

Syntax			
show ip pim			

Default Setting

None

Command Mode

Privileged Exec, User Exec

Display Message

PIM Mode: Indicates whether the PIM mode is dense (PIM-DM) or sparse (PIM-SM)

Data Threshold: Rate (in kbps) of SPT Threshold

Register Rate-limit: Rate (in kbps) of the Register Threshold

Interface: slot/port

Interface Mode: Indicates whether PIM is enabled or disabled on this interface

Operational Status: The current state of PIM on this interface: Operational or Non-Operational.

7.5.1.2 show ip pim bsr-router

This command displays the bootstrap router (BSR) information.

Suntay
Syntax

Г

show ip pim bsr-router {candidate | elected}

Default Setting

None

Command Mode

Privileged Exec, User Exec

Display Message

BSR Address: IP address of the BSR

BSR Priority: Priority as configured in the "ip pim bsr-candidate" command

BSR Hash Mask Length: Length of a mask (maximum 32 bits) that is to be ANDed with the group address before the hash function is called. This value is configured in the ip pim bsrcandidate command

Next Bootstrap Message: Time (in hours, minutes, and seconds) in which the next bootstrap message is due from this BSR

Next Candidate RP advertisement: Time (in hours, minutes, and seconds) in which the next candidate RP advertisement will be sent

7.5.1.3 show ip pim interface

This command displays the interface information for PIM on the specified interface. If no interface is specified, the command displays the status parameters for all PIM-enabled interfaces.

•	
Syntax	

show ip pim interface [{<slot/port> | vlan <vlan-id>}]

<slot/port> - Interface number.

<vlan-id> - VLAN ID. The range of VLAN ID is 1 to 4093.

Default Setting

None

Command Mode

Privileged Exec, User Exec

Display Message

Interface: slot/port

Mode: Indicates whether the PIM mode enabled on the interface is dense or sparse

Hello Interval: The frequency at which PIM hello messages are transmitted on this interface. By default, the value is 30 seconds

Join Prune Interval: The join/prune interval for the PIM router. The interval is in seconds

DR Priority: The priority of the Designated Router configured on the interface. This field is not applicable if the interface mode is Dense

BSR Border: Identifies whether this interface is configured as a bootstrap router border interface

Neighbor Count: The number of PIM neighbors learned on this interface. This is a dynamic value and is shown only when a PIM interface is operational

Designated Router: The IP address of the elected Designated Router for this interface. This is a dynamic value and will only be shown when a PIM interface is operational. This field is not applicable if the interface mode is Dense

7.5.1.4 show ip pim neighbor

This command displays PIM neighbors discovered by PIMv2 Hello messages. If the interface number is not specified, this command displays the neighbors discovered on all the PIM enabled interfaces.

•	
Syntax	

show ip pim neighbor [{<slot/port> | vlan <vlan-id>}]

<slot/port > - Interface number.

<vlan-id> - VLAN ID. The range of VLAN ID is 1 to 4093.

Default Setting

None

Command Mode

Privileged Exec, User Exec

Display Message

Neighbor Address: The IP address of the neighbor on an interface

Interface: slot/port

Up Time: The time since this neighbor has become active on this interface

Expiry Time: The expiry time of the neighbor on this interface

DR Priority: The DR Priority configured on this Interface (PIM-SM only)



DR Priority is applicable only when sparse-mode configured routers areneighbors. Otherwise, NA is displayed in this field

7.5.1.5 show ip pim rp mapping

Use this command to display all active group-to-RP mappings of which the router is a aware (either configured or learned from the bootstrap router (BSR)). Use the optional parameters to limit the display to a specific RP address or to view group-to-candidate RP or group to Static RP mapping information.

Syntax

show ip pim rp mapping [{<rp-address> | candidate | static}]

Default Setting

None

Command Mode

Privileged Exec, User Exec

Display Message

RP Address: The IP address of the RP for the group specified

Group Address: The IP address and prefix length of the multicast group

Group Mask: The subnet mask associated with the group

Origin: Indicates the mechanism (BSR or static) by which the RP was selected

Expiry Time: The expiry time of the RP mapping

7.5.1.6 show ip pim rp-hash

This command displays which rendezvous point (RP) is being used for a specified group.

Syntax	
--------	--

show ip pim rp-hash <group-address>

<group-address> - the multicast group address for the start of the range of addresses to be excluded. The address must be in the range of 239.0.0.0 through 239.255.255.255.

Default Setting

None

Command Mode

Privileged Exec, User Exec

Display Message

RP Address: The IP address of the RP for the group specified

Type: Indicates the mechanism (BSR or static) by which the RP was selected

7.5.1.7 show ip pim ssm

This command displays the configured source specific IP multicast addresses. If no SSM Group range is configured, this command output is No SSM address range is configured.

Syntax show ip pim ssm

Default Setting

None

Command Mode

Privileged Exec, User Exec

Display Message

Group Address: The IP multicast address of the SSM group

Prefix Length: The network prefix length



QuantaMesh | IP Multicast Commands

862

7.5.2 Configuration Commands

7.5.2.1 ip pim bsr-candidate

This command is used to configure the router to announce its candidacy as a bootstrap router (BSR).

Syntax

ip pim bsr-candidate interface {<slot/port> | vlan <vlan-id>} <hash-mask-length> [<priority>] no ip pim bsr-candidate interface {<slot/port> | vlan <vlan-id>} <hash-mask-length> [<priority>]

<slot/port> - Valid slot and port number separated by forward slashes.

<vlan-id> - VLAN ID. The range of VLAN ID is 1 to 4093.

<hash-mask-length> - BSR hash-mask length. The range of the mask is 0 to 32.

<priority> - BSR priority. The range of the priority is 0 to 255.

no - This command is used to disable the router to announce its candidacy as a bootstrap router (BSR).

Default Setting

Disabled

Command Mode

Global Config

Parameters

hash-mask-length: Length of a mask (32 bits maximum) that is to be ANDed with the group address before the hash function is called. All groups with the same seed hash correspond to the same RP. For example, if this value was 24, only the first 24 bits of the group addresses matter. This allows you to get one RP for multiple groups.

priority: Priority of the candidate BSR. The range is an integer from 0 to 255. The BSR with the larger priority is preferred. If the priority values are the same, the router with the larger IP address is the BSR. The default value is 0.

i

This command takes effect only when PIM-SM is configured as the PIM mode

863

7.5.2.2 ip pim dense

This command enables the administrative mode of PIM-DM in the router.

Syntax				
ip pim de	nse			
no ip pim	dense			

no - This command disables the administrative mode of PIM-DM in the router.

Default Setting

Disabled

Command Mode

Global Config

7.5.2.3 ip pim rp-address

This command is used to statically configure the RP address for one or more multicast groups. The parameter rp-address is the IP address of the RP. The parameter groupaddress is the group address supported by the RP. The parameter groupmask is the group mask for the group address. The optional keyword override indicates that if there is a conflict, the RP configured with this command prevails over the RP learned by BSR.

Syntax

ip pim rp-address <rp-address> <group-address> <group-mask> [override] no ip pim rp-address <rp-address> <group-address> <group-mask>

<rp-address> - Specifies the rp address.

<group-address> - Specifies the group address.

<group-mask> - Specifies the group mask.

no - This command is used to statically remove the RP address for one or more multicast groups.

Default Setting

0

Command Mode

Global Config

i

This command takes effect only when PIM-SM is configured as the PIM mode

7.5.2.4 ip pim rp-candidate

This command is used to configure the router to advertise itself as a PIM candidate rendezvous point (RP) to the bootstrap router (BSR).

Syntax

ip pim rp-candidate interface {<slot/port> | vlan <vlan-id>} <group-address> <group-mask> no ip pim rp-candidate interface {<slot/port> | vlan <vlan-id>} <group-address> <group-mask>

<slot/port> - Valid slot and port number separated by forward slashes.

<vlan-id> - VLAN ID. The range of VLAN ID is 1 to 4093.

<group-address> - Specifies the group address.

<group-mask> - Specifies the group mask.

no - This command is used to disable the router to advertise itself as a PIM candidate rendezvous point (RP) to the bootstrap router (BSR).

Default Setting

None

Command Mode

Global Config



This command takes effect only when PIM-SM is configured as the PIM mode

7.5.2.5 ip pim sparse

This command enables the administrative mode of PIM-SM in the router.

Syntax			
ip pim spa	ip pim sparse		
no ip pim	o ip pim sparse		

no - This command disables the administrative mode of PIM-SM in the router.

Default Setting

Disabled

Command Mode

Global Config

7.5.2.6 ip pim spt-threshold

Use this command to configure the Data Threshold rate for the last-hop router to switch to the shortest path. The possible values are 0 or Infinity.

Syntax			
	ip pim spt-threshold {0 Infinity}		
no ip pim	no ip pim spt-threshold		

no - This command is used to set the Data Threshold rate for the RP router to the default value.

Default Setting

0

Command Mode

Global Config



This command takes effect only when PIM-SM is configured as the PIM mode

7.5.2.7 **ip pim ssm**

Use this command to define the Source Specific Multicast (SSM) range of IP multicast addresses.

Syntax

ip pim ssm {default | <group-address> <group-mask>} no ip pim ssm {default | <group-address> <group-mask>}

<group-address> - Specifies the group address.

<group-mask> - Specifies the group-mask.

no - This command is used to disable the specified Source Specific Multicast (SSM) range.

Default Setting

Disabled

Command Mode

Global Config

Parameters

default - Defines the SSM range access list to 232/8.

867

7.5.2.8 **ip pim**

This command administratively enables PIM on an interface or range of interfaces.

Syntax	
ip pim no ip pim	

no - This command sets the administrative mode of PIM on an interface to disabled.

Default Setting

Disabled

Command Mode

Interface Config

7.5.2.9 ip pim bsr-border

Use this command to prevent bootstrap router (BSR) messages from being sent or received through an interface or range of interfaces.

Syntax		
ip pim bsr-border		
no ip pim bsr-border		

no - Use this command to disable the interface from being the BSR border.

Default Setting

Disabled

Command Mode

Interface Config



This command takes effect only when PIM-SM is configured as the PIM mode

7.5.2.10 ip pim dr-priority

Use this command to set the priority value for which a router is elected as the designated router (DR). This command can be configured on a single interface or a range of interfaces.

Syntax		
ip pim dr-	ip pim dr-priority <0-4294967294>	
no ip pim	n dr-priority	

no - Use this command to reset the priority value for which a router is elected as the designated router (DR).

Default Setting

1

Command Mode

Interface Config



This command takes effect only when PIM-SM is configured as the PIM mode

7.5.2.11 ip pim hello-interval

Use this command to configure the PIM hello interval for the specified router interface or range of interfaces. The hello-interval is specified in seconds and is in the range 10–18000.

Syntax			
ip pim he	ip pim hello-interval <10–18000>		
no ip pim	no ip pim hello-interval		

no - Use this command to set the PIM hello interval to the default value.

Default Setting

30

Command Mode

Interface Config



7.5.2.12 ip pim join-prune-interval

This command is used to configure the join/prune interval for the PIM-SM router on an interface or range of interfaces. The join/prune interval is specified in seconds. This parameter can be configured to a value from 0 to 18000.

. .	
Synta	Х

ip pim joir	n-prune-interval <0-18000>
no ip pim	join-prune-interval

no - Use this command to set the join/prune interval to the default value.

Default Setting

60

Command Mode

Interface Config



This command takes effect only when PIM-SM is configured as the PIM mode

7.5.2.13 ip pim-trapflags

This command enables the PIM trap mode for both Sparse Mode (SM) and Dense Mode. (DM).

Syntax					
ip pim-tra	ip pim-trapflags				
no ip pim	-trapflags				

no - This command sets the PIM trap mode to the default

Default Setting

Disabled

Command Mode

Global Config



7.6 IPv6 Protocol Independent Multicast Commands

7.6.1 Show Commands

7.6.1.1 show ipv6 pim

Use this command to display the system-wide information for PIM-DM or PIM-SM.

Syntax	
show ipv6	6 pim

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Message

PIM Mode: Indicates whether the PIM mode is dense (PIM-DM) or sparse (PIM-SM)

Data Threshold Rate: Indicates the data threshold rate for PIM.

Interface: Valid slot, and port number separated by forward slashes.

Interface-Mode: Indicates whether PIM is enabled or disabled on this interface.

Operational-State: The current state of PIM on this interface. Possible values are Operational or Non-Operational.

7.6.1.2 show ipv6 pim ssm

Use this command to displays the configured source specific IPv6 multicast addresses. If no SSM Group range is configured, this command output is No SSM address range is configured.

Cuntor	
Syntax	

show ipv6 pim ssm

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Message

Group Address: The IPv6 multicast address of the SSM group.

Prefix Length: The network prefix length.

7.6.1.3 show ipv6 pim interface

Use this command to displays the interface information for PIM on the specified interface. If no interface is specified, the command displays the status parameters for all PIM-enabled interfaces.

Cuntor	
Syntax	ς.

show ipv6 pim interface [{<slot/port> | vlan <vlan-id>}]

<slot/port> - Valid slot and port number separated by forward slashes.

<vlan-id> - VLAN ID. The range of VLAN ID is 1 to 4093.

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Message

Interface: slot/port.

Mode: Indicate whether the PIM mode enabled on the interface is dense or sparse.

Hello Interval: The frequency at which PIM hello messages are transmitted on this interface. By default, the value is 30 seconds.

Join Prune Interval: The join/prune interval for the PIM router. The interval is in seconds. By default, the value is 60 seconds.

DR Priority: The priority of the Designated Router configured on the interface. This field is not applicable if the interface mode is Dense.

BSR Border: Identifies whether this interface is configured as a bootstrap router border interface.

Neighbor Count: The number of PIM neighbors learned on this interface. This is a dynamic value and is shown only when a PIM interface is operational.

Designated Router: The IP address of the elected Designated Router for this interface. This is a dynamic value and will only be shown when a PIM interface is operational. This field is not applicable if the interface mode is Dense.

7.6.1.4 show ipv6 pim neighbor

Use this command to display PIM neighbors discovered by PIMv2 Hello messages. If the interface number is not specified, this command displays the neighbors discovered on all the PIM-enabled interfaces.

show ipv6 pim neighbor [{<slot/port> | vlan <vlan-id>}]

<slot/port> - Valid slot and port number separated by forward slashes.

<vlan-id> - VLAN ID. The range of VLAN ID is 1 to 4093.

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Message

Interface: Slot, and port number separated by forward slashes.

Neighbor Address: The IP address of the neighbor on an interface.

Up Time: The time since this neighbor has become active on this interface.

Expiry Time: The expiry time of the neighbor on this interface.

DR Priority: The DR Priority configured on this interface (PIM-SM only).

7.6.1.5 show ipv6 pim bsr-router

This command displays the bootstrap router (BSR) information.

Syntax

show ipv6 pim bsr-router {candidate | elected}

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Message

BSR Address: IPv6 address of the BSR.

BSR Priority: Priority as configured in the ipv6 pim bsr-candidate command.

BSR Hash Mask Length: Length of a mask (maximum 32 bits) that is to be ANDed with the group address before the hash function is called. This value is configured in the **ipv6 pim bsr-candidate** command.

Next Bootstrap Message: Time (in hours, minutes, and seconds) in which the next bootstrap message is due from this BSR.

C-BSR Advertisement Interval: Indicates the configured C-BSR Advertisement interval with which the router, acting as a C-BSR, will periodically send the C-BSR advertisement messages.

7.6.1.6 show ipv6 pim rp-hash

This command displays which rendezvous point (RP) is being used for a specified group.

~	
Sy	ntax

show ipv6 pim rp-hash <group-address>

<group-address> - The IPv6 address of the RP for the group specified.

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Message

RP Address: The IPv6 address of the RP for the group specified.

Type: Indicates the mechanism (BSR or static) by which the RP was selected.

7.6.1.7 show ipv6 pim rp mapping

Use this command to display all active group-to-RP mappings of which the router is a aware (either configured or learned from the bootstrap router (BSR)). Use the optional parameters to limit the display to a specific RPaddress or to view group-to-candidate RP or group to Static RP mapping information.

Syntax

show ipv6 pim rp mapping [{rp-address | candidate | static}]

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Message

RP Address: The IPv6 address of the RP for the group specified.

Group Address: The IPv6 address and prefix length of the multicast group.

Origin: Indicates the mechanism (BSR or static) by which the RP was selected.

Expiry Time: The expiry time of the RP mapping.

If detail is specified, the following fields are displayed:

C-RP Advertisement Interval: Indicates the configured C-RP Advertisement interval with which the router, acting as a Candidate RP will periodically send the C-RP advertisement messages to the elected BSR.

7.6.2 Configuration Commands

7.6.2.1 ipv6 pim dense

This command enables the administrative mode of PIM-DM in the router.

Syntax					
ipv6 pim no ipv6 p	dense				
no ipv6 p	oim dense				

no - This command disables the administrative mode of PIM-DM in the router.

Default Setting

Disabled

Command Mode

Global Config

7.6.2.2 ipv6 pim sparse

This command enables the administrative mode of PIM-SM in the router.

Syntax			
ipv6 pim s no ipv6 pi	sparse im sparse		

no - This command disables the administrative mode of PIM-SM in the router.

Default Setting

Disbaled

Command Mode

Global Config

7.6.2.3 ipv6 pim

This command administratively enables PIM on an interface or range of interfaces.

Syntax	K	
ipv6 pim	m	
no ipv6 p	3 pim	

no - This command sets the administrative mode of PIM on an interface to disabled.

Default Setting

Disbaled

Command Mode

Interface Config

7.6.2.4 ipv6 pim hello-interval

Use this command to configure the PIM hello interval for the specified router interface or range of interfaces. The hello-interval is specified in seconds and is in the range 0–18000.

Syntax

ipv6 pim hello-interval <0–18000> no ipv6 pim hello-interval

no - Use this command to set the PIM hello interval to the default value.

Default Setting

30

Command Mode

Interface Config

7.6.2.5 ipv6 pim bsr-border

Use this command to prevent bootstrap router (BSR) messages from being sent or received through an interface or range of interfaces. Note that this command takes effect only when PIM-SM is enabled in the Global mode.

Syntax		
ipv6 pim	bsr-border	
no ipv6 p	pim bsr-border	

no - Use this command to disable the interface from being the BSR border.

Default Setting

Disbaled

Command Mode

Interface Config

7.6.2.6 ipv6 pim bsr-candidate

This command is used to configure the router to announce its candidacy as a bootstrap router (BSR). The argument <slot/port> corresponds to a physical routing interface or VLAN routing interface.

Syntax

ipv6 pim bsr-candidate interface {<slot/port> | vlan <vlan-id>} <*hash-mask-length>* [<priority>] no ipv6 pim bsr-candidate interface {<slot/port> | vlan <vlan-id>}

<slot/port> - Interface number on this router from which the BSR address is derived, to make it a candidate. This interface must be enabled with PIM..

<vlan-id> - VLAN ID. The range of VLAN ID is 1 to 4093.

<hash-mask-length> - BSR hash-mask length. The range of the mask is 0 to 128. The length of a mask that is to be ANDed with the group address before the hash function is called. All groups with the saem seed hash correspond to the same RP. For example, if this value was 24, only the first 24 bits of the group addresses matter. This allows you to get one RP for multiple groups.

<priority> - Priority of the candidate BSR. The range of the priority is 0 to 255. The BSR with the larger priority is preferred. If the priority values are the same, the router with the larger IP address is the BSR. The default value is 0.

no - This command is used to remove the configured PIM candidate BSR router.



None Command Mode Global Config

7.6.2.7 ipv6 pim dr-priority

Use this command to set the priority value for which a router is elected as the designated router (DR). This command can be configured on a single interface or a range of interfaces.

Syntax			
	dr-priority <0-4294967294> im dr-priority		

no - Use this command to disable the interface from being the BSR border.

Default Setting

1

Command Mode

Interface Config

7.6.2.8 ipv6 pim join-prune-interval

This command is used to configure the interface join/prune interval for the PIM-SM router on an interface or range of interfaces. The join/prune interval is specified in seconds. This parameter can be configured to a value from 0 to 18000.

Syntax

ipv6 pim join-prune-interval <0-18000> no ipv6 pim join-prune-interval

no - Use this command to set the join/prune interval to the default value.

Default Setting

60

Command Mode

Interface Config

7.6.2.9 ipv6 pim rp-address

This command is used to define the address of a PIM Rendezvous point (RP) for a specific multicast group range. The parameter *<rp-address>* is the IPv6 address of the RP. The parameter *<group-address>* is the group address supported by the RP. The parameter *<prefix-length>* is the group

882

mask for the group address. The optional keyword **override** indicates that if there is a conflict, the RP configured with this command prevails over the RP learned by BSR.

Syntax

ipv6 pim rp-address <*rp-address*> <*group-address/prefix-length*> [override] no ipv6 pim rp-address <*rp-address*> <*group-address/prefix-length*>

<rp-address> - The IPv6 address of the RP.

<group-address> - The group address supported by the RP.

<prefix-length> - The group mask for the group address.

override - Indicates that if there is a conflict, the RP configured with this command prevails over the RP learned by BSR.

no - This command is used to remove the address of the configured PIM Rendezvous point (RP) for the specified multicast group range.

Default Setting

None

Command Mode

Global Config

7.6.2.10 ipv6 pim rp-candidate

This command is used to configure the router to advertise itself as a PIM candidate rendezvous point (RP) to the bootstrap router (BSR) for a specific multicast group range.

Syntax

ipv6 pim rp-candidate interface {<slot/port> / vlan <vlan-id>} <group-address/prefix-length> [interval <interval>]

no ipv6 pim rp-candidate interface {<slot/port> | vlan <vlan-id>} <group-address/prefix-length>

<**slot/port> -** The IP address associated with this interface type and number is advertised as a candidate RP address. This interface must be enabled with PIM.

<vlan-id> - VLAN ID. The range of VLAN ID is 1 to 4093.<group-address> - The multicast group address that is advertised in association with the RP address.

<prefix-length> - The multicast group prefix that is advertised in association with the RP address.

<interval> - Configure the C-RP advertisement interval. The range of interval is 1 to 16383, and the default value is 60.

no - This command is used to disable the router to advertise itself as a PIM candidate rendezvous point (RP) to the bootstrap router (BSR).

Default Setting

None

Command Mode

Global Config

7.6.2.11 ipv6 pim spt-threshold

This command is used to configure the Data Threshold rate for the last-hop router to switch to the shortest path. Now support to enable (0) or disable(Infinity).

Syntax

iipv6 pim spt-threshold <0 | Infinity>
no ipv6 pim spt-threshold

<0> - This is 0 kilobits per seconds.

<Infinity> - This command will disable the function.

no - This command is used to reset the Data Threshold rate for the last-hop router to switch to the shortest path to the default value.

Default Setting

0

Command Mode

Global Config

7.6.2.12 ipv6 pim ssm

Use this command to define the Source Specific Multicast (SSM) range of IPv6 multicast addresses on the router. Note that this command takes effect only when PIM-SM is configured as the PIM mode.



ipv6 pim ssm {default | <group-address>/<prefix-length>}
no ipv6 pim ssm {default | <group-address>/<prefix-length>}

default - Defines the SSM range access list FF3x::/32.

no - This command is used to disable the Source Specific Multicast (SSM) range.

Default Setting

Disbaled

Command Mode

Global Config

7.7 IGMP Proxy Commands

The IGMP Proxy is used by IGMP Router (IPv4 system) to enable the system to issue IGMP host messages on behalf of hosts that the system discovered through standard IGMP router interfaces. With IGMP Proxy enabled, the system acts as proxy to all the hosts residing on its router interfaces.

7.7.1 Show Commands

7.7.1.1 show ip igmp-proxy

This command displays a summary of the host interface status parameters. It displays the following parameters only when you enable IGMP Proxy.

Syntax

show ip igmp-proxy

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Message

Interface Index: The interface number of the IGMP Proxy.

Admin Mode: States whether the IGMP Proxy is enabled or not. This is a configured value.

Operational Mode: States whether the IGMP Proxy is operationally enabled or not. This is a status parameter.

Version: The present IGMP host version that is operational on the proxy interface.

Number of Multicast Groups: States the number of multicast groups that are associated with the IGMP Proxy interface.

Unsolicited Report Interval: The time interval at which the IGMP Proxy interface sends unsolicited group membership report.

Querier IP Address on Proxy Interface: The IP address of the Querier, if any, in the network attached to the upstream interface (IGMP-Proxy interface).

Older Version 1 Querier Timeout: The interval used to timeout the older version 1 queriers.

Older Version 2 Querier Timeout: The interval used to timeout the older version 2 queriers.

Proxy Start Frequency: The number of times the IGMP Proxy has been stopped and started.

7.7.1.2 show ip igmp-proxy groups

This command displays information about the subscribed multicast groups that IGMP Proxy reported. It displays a table of entries with the following as the fields of each column.

Syntax	
--------	--

show ip igmp-proxy groups

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Message

Interface: The interface number of the IGMP Proxy.

Group Address: The IP address of the multicast group.

Last Reporter: The IP address of host that last sent a membership report.

Up Time (in secs): The time elapsed since last created.

Member State: The status of the entry. Possible values are IDLE_MEMBER or DELAY_MEMBER.

- **IDLE_MEMBER** interface has responded to the latest group membership query for this group.
- **DELAY_MEMBER** interface is going to send a group membership report to respond to a group membership query for this group.

Filter Mode: Possible values are Include or Exclude.

Sources: The number of sources attached to the multicast group.

7.7.1.3 show ip igmp-proxy groups detail

This command displays complete information about multicast groups that IGMP Proxy reported. It displays a table of entries with the following as the fields of each column.

Syntax

show ip igmp-proxy groups detail

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Message

Interface Index: The interface number of the IGMP Proxy.

Group Address: The IP address of the multicast group.

Last Reporter: The IP address of host that last sent a membership report for the current

group, on the network attached to the IGMP-Proxy interface (upstream interface).

Up Time (in secs): The time elapsed since last created.

Member State: The status of the entry. Possible values are IDLE_MEMBER or DELAY_MEMBER.

- **IDLE_MEMBER** interface has responded to the latest group membership query for this group.
- **DELAY_MEMBER** interface is going to send a group membership report to respond to a group membership query for this group.

Filter Mode: Possible values are include or exclude.

Sources: The number of sources attached to the multicast group.

Group Source List: The list of IP addresses of the sources attached to the multicast group.

Expiry Time: Time left before a source is deleted.

7.7.1.4 show ip igmp-proxy interface

This command displays a detailed list of the host interface status parameters. It displays the following parameters only when you enable IGMP Proxy.

Syntax

show ip igmp-proxy interface

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Message

Interface Index: Shows the slot/port of the IGMP proxy.

The column headings of the table associated with the interface are as follows:

Ver: Shows the IGMP version.

Query Rcvd: Number of IGMP queries received.

Report Rcvd: Number of IGMP reports received.

Report Sent: Number of IGMP reports sent.

Leaves Rcvd: Number of IGMP leaves received.

Leaves Sent: Number of IGMP leaves sent.

7.7.2 Configuration Commands

7.7.2.1 ip igmp-proxy

This command enables the IGMP Proxy on the router. To enable the IGMP Proxy on the router, you must enable multicast forwarding. Also, make sure that there are no multicast routing protocols enabled on the router.

Syntax	x	
ip igmp-p no ip igm	p-proxy gmp-proxy	

no - This command disables the IGMP Proxy on the router.

Default Setting

Disabled

Command Mode

Interface Config

7.7.2.2 ip igmp-proxy reset-status

This command resets the host interface status parameters of the IGMP Proxy router. This command is valid only when you enable IGMP Proxy on the interface.

Syntax

ip igmp-proxy reset-status

Default Setting

None

Command Mode

Interface Config

7.7.2.3 ip igmp-proxy unsolicit-rprt-interval

This command sets the unsolicited report interval for the IGMP Proxy router. This command is valid only when you enable IGMP Proxy on the interface. The value of <interval> can be 1-260 seconds.

Syntax	
Oyntax	

ip igmp-proxy unsolicit-rprt-interval <1-260> no ip igmp-proxy unsolicit-rprt-interval

no - This command resets the unsolicited report interval of the IGMP Proxy router to the default value.

Default Setting

1

Command Mode

Interface Config

7.8 MLD Proxy Commands

MLD-Proxy is the IPv6 equivalent of IGMP-Proxy. MLD-Proxy commands allow you to configure the network device as well as to view device settings and statistics using either serial interface or telnet session. The operation of MLD-Proxy commands is the same as for IGMP-Proxy: MLD is for IPv6 and IGMP is for IPv4.MGMD is a term used to refer to both IGMP and MLD.

7.8.1 Show Commands

7.8.1.1 show ipv6 mld-proxy

This command displays a summary of the host interface status parameters.

_
Syntax
Oyncar

show ipv6 mld-proxy

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Message

Interface Index: The interface number of the MLD-Proxy.

Admin Mode: States whether the MLD-Proxy is enabled or not. This is a configured value.

Operational Mode: States whether the MLD-Proxy is operationally enabled or not. This is a status parameter.

Version: The present MLD host version that is operational on the proxy interface.

Number of Multicast Groups: States the number of multicast groups that are associated with the MLD-Proxy interface.

Unsolicited Report Interval: The time interval at which the MLD-Proxy interface sends unsolicited group membership report.

Querier IP Address on Proxy Interface: The IP address of the Querier, if any, in the network attached to the upstream interface (MLD-Proxy interface).

Older Version 1 Querier Timeout: The interval used to timeout the older version 1 queriers.

Proxy Start Frequency: The number of times the MLD-Proxy has been stopped and started.

7.8.1.2 show ipv mld-proxy groups

This command displays information about multicast groups that the MLD-Proxy reported.

Syntax

show ipv6 mld-proxy groups

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Message

Interface Index: The interface number of the MLD-Proxy.

Group Address: The IP address of the multicast group.

Last Reporter: The IP address of the host that last sent a membership report for the current group, on the network attached to the MLD-Proxy interface (upstream interface).

Up Time (in secs): The time elapsed since last created.

Member State: Possible values are:

- Idle_Member interface has responded to the latest group membership query for this group.
- **Delay_Member** interface is going to send a group membership report to respond to a group membership query for this group.

Filter Mode: Possible values are Include or Exclude.

Sources: The number of sources attached to the multicast group.

7.8.1.3 show ipv6 mld-proxy groups detail

This command displays information about multicast groups that MLD-Proxy reported.

S	vntax
J	ynican

show ipv6 mld-proxy groups detail

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Message

Interface: The interface number of the MLD-Proxy.

Group Address: The IP address of the multicast group.

Last Reporter: The IP address of host that last sent a membership report for the current

group, on the network attached to the MLD-Proxy interface (upstream interface).

Up Time (in secs): The time elapsed since last created.

Member State: Possible values are:

- Idle_Member interface has responded to the latest group membership query for this group.
- **Delay_Member** interface is going to send a group membership report to respond to a group membership query for this group.

Filter Mode: Possible values are include or exclude.

Sources: The number of sources attached to the multicast group.

Group Source List: The list of IP addresses of the sources attached to the multicast group.

Expiry Time: Time left before a source is deleted.

7.8.1.4 show ipv6 mld-proxy interface

This command displays a detailed list of the host interface status parameters. It displays the following parameters only when you enable MLD-Proxy.

Syntax

show ipv6 mld-proxy interface

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Message

Interface Index: Shows the slot/port of the MLD-proxy.

The column headings of the table associated with the interface are as follows:

Ver: Shows the MLD version.

Query Rcvd: Number of MLD queries received.

Report Rcvd: Number of MLD reports received.

Report Sent: Number of MLD reports sent.

Leaves Rcvd: Number of MLD leaves received. Valid for version 2 only.

Leaves Sent: Number of MLD leaves sent on the Proxy interface. Valid for version 2 only.

7.8.2 Configuration Commands

7.8.2.1 ipv6 mld-proxy

This command enables MLD-Proxy on the router. To enable MLD-Proxy on the router, you must enable multicast forwarding. Also, make sure that there are no other multicast routing protocols enabled n the router.

Syntax		
ipv6 mld-		
no ipv6 m	nia-proxy	

no - This command disables the MLD-Proxy on the router.

Default Setting

Disabled

Command Mode

Interface Config

7.8.2.2 ipv6 mld-proxy reset-status

This command resets reset the host interface status parameters of the MLD-Proxy router. This command is only valid when you enable MLD-Proxy on the interface.

Syntax

ipv6 mld-proxy reset-status

Default Setting

None

Command Mode

Interface Config

7.8.2.3 ipv6 mld-proxy unsolicit-rprt-interval

This command sets the unsolicited report interval for the MLD-Proxy router. This command is only valid when you enable MLD-Proxy on the interface. The value of <interval> is 1-260 seconds.

Syntax	

ipv6 mld-proxy unsolicit-rprt-interval <1-260> no ipv6 mld-proxy unsolicit-rprt-interval

no - This command resets the unsolicited report interval of the MLD-Proxy router to the default value.

Default Setting

1

Command Mode

Interface Config

8 IPv6 Commands

8.1 Tunnel Interface Commands

The commands in this section describe how to create, delete, and manage tunnel interfaces. Several different types of tunnels provide functionality to facilitate the transition of IPv4 networks to IPv6 networks. These tunnels are divided into two classes: configured and automatic. The distinction is that configured tunnels are explicitly configured with a destination or endpoint of the tunnel. Automatic tunnels, in contrast, infer the endpoint of the tunnel from the destination address of packets routed into the tunnel. To assign an IP address to the tunnel interface, please refer to "ip address" command. To assign an IPv6 address to the tunnel interface, please refer to "ipv6 address" command.

8.1.1 Show Commands

8.1.1.1 show interface tunnel

This command displays the parameters related to tunnel such as tunnel mode, tunnel source address and tunnel destination address.

Syntax

show interface tunnel [<0-7>]

Default Setting

None

Command Mode

Privileged Exec

Display Message

If you do not specify a tunnel ID, the command shows the following information for each configured tunnel:

Tunnel ID: Shows the tunnel identification number.

Interface: Shows the name of the tunnel interface.

Tunnel Mode: Shows the tunnel mode.

Source Address: Shows the source transport address of the tunnel.

Destination Address: Shows the destination transport address of the tunnel.

If you specify a tunnel ID, the command shows the following information for the tunnel:

Interface Link Status: Shows whether the link is up or down.

MTU Size: Shows the maximum transmission unit for packets on the interface.

IPv6 Address/Length: If you enable IPv6 on the interface and assign an address, the IPv6 address and prefix display.

8.1.2 Configuration Commands

8.1.2.1 interface tunnel

This command uses to enter the Interface Config mode for a tunnel interface. The <tunnel-id> range is 0 to 7.

Syntax

interface	tunnel <0-7>
no interfa	ace tunnel <0-7>

no - This command removes the tunnel interface and associated configuration parameters for the specified tunnel interface.

Default Setting

None

Command Mode

Global Config

8.1.2.2 tunnel source

This command specifies the source transport address of the tunnel, either explicitly or by reference to an interface.

Syntax

tunnel source {<ipv4-address> | <ethernet> {<slot/port> | vlan <vlan-id>}}

<slot/port> - The Interface number.

<vlan-id> - VLAN ID. The range of VLAN ID is 1 to 4093.

<ipv4-address> - A valid IP Address.

Default Setting

None

Command Mode

Interfacel Tunnel Mode

8.1.2.3 tunnel destination

This command specifies the destination transport address of the tunnel.

Syntax

tunnel destination {<ipv4-address>}

<ipv4-address> - A valid IP Address.

Default Setting

None

Command Mode

Interfacel Tunnel Mode

8.1.2.4 tunnel mode ipv6ip

This command specifies the mode of the tunnel. With the optional 6to4 argument, the tunnel mode is set to 6to4 automatic. Without the optional 6to4 argument, the tunnel mode is configured.

Syntax

tunnel mode ipv6ip [6to4]

Default Setting

None

Command Mode

Interfacel Tunnel Mode

8.2 Loopback Interface Commands

The commands in this section describe how to create, delete, and manage loopback interfaces. A loopback interface is always expected to be up. This interface can provide the source address for sent packets and can receive both local and remote packets. The loopback interface is typically used by routing protocols. To assign an IP address to the loopback interface, please refer to "ip address" command. To assign an IPv6 address to the loopback interface, please refer to "ipv6 address" command.

8.2.1 Show Commands

8.2.1.1 show interface loopback

This command displays information about configured loopback interfaces.

Syntax

show interface loopback [<0-7>]

Default Setting

None

Command Mode

Privileged Exec

Display Message

If you do not specify a loopback ID, the following information appears for each loopback interface on the system:

Loopback ID: Shows the loopback ID associated with the rest of the information in the row.

Interface: Shows the interface name.

IP Address: Shows the IPv4 address of the interface

Received Packets: Shows the number of packets received on this interface.

Sent Packets: Shows the number of packets transmitted from this interface.

IPv6 Address: Shows the IPv6 address of this interface

If you specify a loopback ID, the following information appears:

Interface Link Status: Shows whether the link is up or down.

IP Address: Shows the IPv4 address of the interface.

IPv6 is enabled (disabled): Show whether IPv6 is enabled on the interface

IPv6 Address/Length: Shows the IPv6 address of the interface.

MTU size: Shows the maximum transmission size for packets on this interface, in bytes.

8.2.2 Configuration Commands

8.2.2.1 interface loopback

This command uses to enter the Interface Config mode for a loopback interface. The range of the loopback ID is 0 to 7.

Syntax

interface loopback <0-7> no interface loopback <0-7>

no - This command removes the loopback interface and associated configuration parameters for the specified loopback interface.

Default Setting

Disabled

Command Mode

Global Config

8.3 IPv6 Routing Commands

This section describes the IPv6 commands you use to configure IPv6 on the system and on the interfaces. This section also describes IPv6 management commands and show commands.

8.3.1 Show Commands

8.3.1.1 show ipv6 brief

This command displays the IPv6 status and IPv6 unicast routing mode.

Syntax			
show ipve	6 brief		

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Message

IPv6 Unicast Routing Mode: Shows whether the IPv6 unicast routing mode is enabled.

IPv6 Hop Limit : Shows the unicast hop count used in IPv6 packets originated by the node. For more information, see "ipv6 hot-limit"

ICMPv6 Rate Limit Error Interval : Shows how often the token bucket is initialized with burst-size tokens. For more information, see "ipv6 icmp error-interval"

ICMPv6 Rate Limit Burst Size : Shows the number of ICMPv6 error messages that can be sent during one burst-interval. For more information, see "ipv6 icmp error-interval"

Maximum Routes : Shows the maximum IPv6 route table size.

8.3.1.2 show ipv6 interface port

This command displays the usability status of IPv6 interfaces and whether ICMPv6 Destination Unreachable messages may be sent.

Syntax	,
Oyntax	١.

show ipv6 interface [{ brief | {port <slot/port> | vlan <vlan-id>} [prefix] }]

<slot/port> - Valid slot and port number separated by forward slashes.

<vlan-id> - VLAN ID. The range of VLAN ID is 1 to 4093.

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Message

If you use the brief parameter, the following information displays for all configured IPv6 interfaces: **Interface:** Shows the interface in slot/port format.

IPv6 Routing Operational Mode: Shows whether the mode is enabled or disabled.

IPv6 Address/Length: Shows the IPv6 address and length on interfaces with IPv6 enabled.

If you specify an interface, the following information also appears.

Routing Mode: Shows whether IPv6 routing is enabled or disabled.

IPv6 Routing Operational Mode: Shows whether the operational state of an interface is enabled or disabled.

Bandwidth: Shows the bandwidth of the interface.

Interface Maximum Transmission Unit: Shows the MTU size, in bytes.

Router Duplicate Address Detection Transmits: Shows the number of consecutive duplicate address detection probes to transmit.

Router Advertisement NS Interval: Shows the interval, in milliseconds, between router advertisements for advertised neighbor solicitations.

Router Lifetime Interval: Shows the router lifetime value of the interface in router advertisements

Router Advertisement Reachable Time: Shows the amount of time, in milliseconds, to consider a neighbor reachable after neighbor discovery confirmation.

Router Advertisement Interval: Shows the frequency, in seconds, that router advertisements are sent.

Router Advertisement Managed Config Flag: Shows whether the managed configuration flag is set (enabled) for router advertisements on this interface.

Router Advertisement Other Config Flag: Shows whether the other configuration flag is set (enabled) for router advertisements on this interface.

Router Advertisement Suppress Flag: Shows whether router advertisements are suppressed (enabled) or sent (disabled).

Router Advertisement Router Preference: Shows router preference value in IPv6 router advertisements.

IPv6 Destination Unreachables: Shows whether ICMPv6 Destination Unreachable messages may be sent (enabled) or not (disabled).

If an IPv6 prefix is configured on the interface, the following information also appears.

IPv6 Prefix: Shows the IPv6 prefix for the specified interface.

Preferred Lifetime: Shows the amount of time the advertised prefix is a preferred prefix.

Valid Lifetime: Shows the amount of time the advertised prefix is valid.

Onlink Flag: Shows whether the onlink flag is set (enabled) in the prefix.

Autonomous Flag: Shows whether the autonomous address-configuration flag (autoconfig) is set (enabled) in the prefix.

8.3.1.3 show ipv6 interface neighbors

This command displays information about the IPv6 neighbors.

Syntax

show ipv6 interface neighbors

Default Setting

None

Command Mode

Privileged Exec

Display Message

Count of Learned Neighbors the number of neighbor mac address be learned.

Interface: Shows the interface in slot/port format.

IPv6 Address: IPV6 address of neighbor or interface.

MAC Address: Link-layer Address.

IsRtr: Shows whether the neighbor is a router. If the value is TRUE, the neighbor is known to be a router, and FALSE otherwise. A value of FALSE might not mean Note that routers are not always known to be routers.

Neighbor State: State of neighbor cache entry. Possible values are Incomplete, Reachable, Stale, Delay, Probe, and Unknown.

Age(Seconds): The time in seconds that has elapsed since an entry was added to the cache.

8.3.1.4 show ipv6 ndp

This command displays NDP cache information for the management port.

Syntax			
show ipv6	6 ndp		

Default Setting

None

Command Mode

Privilege Exec

Display Message

IPv6 Address: The IPv6 address of the interface.

MAC Address: The MAC Address used.

isRtr: Specifies the router flag.

Neighbor State: The state of the neighbor cache entry. Possible values are: Reachable, Delay.

Age Updated: The time in seconds that has elapsed since an entry was added to the cache.

8.3.1.5 show ipv6 route

This command displays the IPv6 routing table The **<ipv6-address>** specifies a specific IPv6 address for which the best-matching route would be displayed. The **<ipv6-prefix/ipv6-prefix-length>** specifies a specific IPv6 network for which the matching route would be displayed. The **<interface>** specifies that the routes with next-hops on the **<interface>** be displayed. The **<protocol>** specifies the protocol that installed the routes. The **<protocol>** is one of the following keywords: **connected, ospf, static, 6to4.** The all specifies that all routes including best and non-best routes are displayed. Otherwise, only the best routes are displayed.



If you use the connected keyword for **<protocol>**, the all option is not available because there are no best or non-best connected routes.

Syntax

show ipv6 route [{<ipv6-address> [<protocol>] | {{<ipv6-prefix/ipv6-prefix-length> | <slot/port> | vlan <vlan-id>} [<protocol>] | <protocol> | summary} [all] | all}]

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Message

The show ipv6 route command displays the routing tables in the following format:

Codes: C - connected, S - static, 6To4 - 6to4 Route, RG - RIPng

O - OSPF Intra, OI - OSPF Inter, OE1 - OSPF Ext 1, OE2 - OSPF Ext 2

ON1 - OSPF NSSA Ext Type 1, ON2 - OSPF NSSA Ext Type 2

The columns for the routing table display the following information:

Code: The code for the routing protocol that created this routing entry.

IPv6-Prefix/IPv6-Prefix-Length: The IPv6-Prefix and prefix-length of the destination IPv6 network corresponding to this route.

Preference/Metric: The administrative distance (preference) and cost (metric) associated with this route. An example of this output is [1/0], where 1 is the preference and 0 is the metric.

Tag: Displays the decimal value of the tag associated with a redistributed route, if it is not 0.

Next-Hop: The outgoing router IPv6 address to use when forwarding traffic to the next router (if any) in the path toward the destination

Route-Timestamp: The last updated time for dynamic routes. The format of Route-Timestamp will be

• Days:Hours:Minutes if days > = 1



• Hours:Minutes:Seconds if days < 1

Interface: The outgoing router interface to use when forwarding traffic to the next destnation.

To administratively control the traffic destined to a particular network and prevent it from being forwarded through the router, you can configure a static reject route on the router. Such traffic would be discarded and the ICMP destination unreachable message is sent back to the source. This is typically used for preventing routing loops. The reject route added in the RTO is of the type OSPF Inter-Area. Reject routes (routes of REJECT type installed by any protocol) are not redistributed by OSPF/RIP. Reject routes are supported in both OSPFv2 and OSPFv3.

8.3.1.6 show ipv6 route preferences

This command displays the preference value associated with the type of route. Lower numbers have a greater preference. A route with a preference of 255 cannot be used to forward traffic.

Syntax

show ipv6 route preferences

Default Setting

None

Command Mode

Privileged Exec

Display Message

Local: Preference of directly-connected routes.

Static: Preference of static routes.

OSPF Intra: Preference of routes within the OSPF area.

OSPF Inter: Preference of routes to other OSPF routes that are outside of the area.

OSPF External: Preference of OSPF external routes.

RIPng: Preference of RIPng routes.

8.3.1.7 show ipv6 route summary

This command displays the summary of the routing table. Use all to display the count summary for all routes, including best and non-best routes. Use the command without parameters to display the count summary for only the best routes.

Syntax

show ipv6 route summary [all]

Default Setting

None

Command Mode

Privileged Exec

Display Message

Connected Routes: Total number of connected routes in the routing table.

Static Routes: Shows whether the IPv6 unicast routing mode is enabled.

RIPng Routes: Total number of routes installed by RIPng protocol.

6to4 Routes: Total number of 6to4 routes in the routing table.

OSPF Routes: Total number of routes installed by OSPFv3 protocol.

Reject Routes : Total number of reject routes installed by all protocols.

Number of Prefixes: Summarizes the number of routes with prefixes of different lengths.

Total Routes: Shows the total number of routes in the routing table.



8.3.1.8

show ipv6 traffic

This command displays traffic and statistics for IPv6 and ICMPv6. Specify a logical, loopback, or tunnel interface to view information about traffic on a specific interface. If you do not specify an interface, the command displays information about traffic on all interfaces.

Syntax

show ipv6 traffic [{<slot/port> | loopback <loopback-id> | tunnel <tunnel-id> | vlan <vlan-id>}]

Default Setting

None

Command Mode

Privileged Exec

Display Message

IPv6 STATISTICS

Total Datagrams Received: Total number of input datagrams received by the interface, including those received in error.

Received Datagrams Locally Delivered: Total number of datagrams successfully delivered to IPv6 user-protocols (including ICMP). This counter increments at the interface to which these datagrams were addressed, which might not necessarily be the input interface for some of the datagrams.

Received Datagrams Discarded Due To Header Errors: Number of input datagrams discarded due to errors in their IPv6 headers, including version number mismatch, other format errors, hop count exceeded, errors discovered in processing their IPv6 options, etc.

Received Datagrams Discarded Due To MTU: Number of input datagrams that could not be forwarded because their size exceeded the link MTU of outgoing interface.

Received Datagrams Discarded Due To No Route: Number of input datagrams discarded because no route could be found to transmit them to their destination.

Received Datagrams With Unknown Protocol: Number of locally-addressed datagrams received successfully but discarded because of an unknown or unsupported protocol. This counter increments at the interface to which these datagrams were addressed, which might not be necessarily the input interface for some of the datagrams.

Received Datagrams Discarded Due To Invalid Address: Number of input datagrams discarded because the IPv6 address in their IPv6 header's destination field was not a valid address to be received at this entity. This count includes invalid addresses (for example, ::0) and unsupported addresses (for example, addresses with unallocated prefixes). Forentities which are not IPv6 routers and therefore do not forward datagrams, this counter includes datagrams discarded because the destination address was not a local address.

Received Datagrams Discarded Due To Truncated Data: Number of input datagrams discarded because datagram frame didn't carry enough data.

Received Datagrams Discarded Other: Number of input IPv6 datagrams for which no problems were encountered to prevent their continue processing, but which were discarded (e.g., for lack of buffer space). Note that this counter does not include datagrams discarded while awaiting re-assembly.

Received Datagrams Reassembly Required: Number of IPv6 fragments received which needed to be reassembled at this interface. Note that this counter increments at the interface to which these

GUANTA COMPUTER INC.

fragments were addressed, which might not be necessarily the input interface for some of the fragments.

Datagrams Successfully Reassembled: Number of IPv6 datagrams successfully reassembled. Note that this counter increments at the interface to which these datagrams were addressed, which might not be necessarily the input interface for some of the fragments.

Datagrams Failed To Reassemble: Number of failures detected by the IPv6 reassembly algorithm (for whatever reason: timed out, errors, etc.). Note that this is not necessarily a count of discarded IPv6 fragments since some algorithms (notably the algorithm in by combining them as they are received. This counter increments at the interface to which these fragments were addressed, which might not be necessarily the input interface for some of the fragments.

Datagrams Forwarded: Number of output datagrams which this entity received and forwarded to their final destinations. In entities which do not act as IPv6 routers, this counter will include only those packets which were Source-Routed via this entity, and the Source-Route processing was successful. Note that for a successfully forwarded datagram the counter of the outgoing interface increments.

Datagrams Locally Transmitted: Total number of IPv6 datagrams which local IPv6 user-protocols (including ICMP) supplied to IPv6 in requests for transmission. Note that this counter does not include any datagrams counted in ipv6lfStatsOutForwDatagrams.

Datagrams Transmit Failed: Number of output IPv6 datagrams for which no problem was encountered to prevent their transmission to their destination, but which were discarded (e.g., for lack of buffer space). Note that this counter would include datagrams counted in ipv6lfStatsOutForwDatagrams if any such packets met this (discretionary) discard criterion.

Fragments Created: Number of output datagram fragments that have been generated as a result of fragmentation at this output interface.

Datagrams Successfully Fragmented: Number of IPv6 datagrams that have been successfully fragmented at this output interface.

Datagrams Failed To Fragment: Number of IPv6 datagrams that have been discarded because they needed to be fragmented at this output interface but could not be.

Multicast Datagrams Received: Number of multicast packets received by the interface.

Multicast Datagrams Transmitted: Number of multicast packets transmitted by the interface.

ICMPv6 STATISTICS

Total ICMPv6 Messages Received: Total number of ICMP messages received by the interface which includes all those counted by ipv6lflcmpInErrors. Note that this interface is the interface to which the ICMP messages were addressed which may not be necessarily the input interface for the messages.

ICMPv6 Messages With Errors Received: Number of ICMP messages which the interface received but determined as having ICMP-specific errors (bad ICMP checksums, bad length, etc.).

ICMPv6 Destination Unreachable Messages Received: Number of ICMP Destination Unreachable messages received by the interface.

ICMPv6 Messages Prohibited Administratively Received: Number of ICMP destination unreachable/communication administratively prohibited messages received by the interface.

ICMPv6 Time Exceeded Messages Received: Number of ICMP Time Exceeded messages received by the interface.

ICMPv6 Parameter Problem Messages Received: Number of ICMP Parameter Problem messages received by the interface.

ICMPv6 Packet Too Big Messages Received: Number of ICMP Packet Too Big messages received by the interface.

ICMPv6 Echo Request Messages Received: Number of ICMP Echo (request) messages received by the interface.

ICMPv6 Echo Reply Messages Received: Number of ICMP Echo Reply messages received by the interface.

ICMPv6 Router Solicit Messages Received: Number of ICMP Router Solicit messages received by the interface.

ICMPv6 Router Advertisement Messages Received: Number of ICMP Router Advertisement messages received by the interface.

ICMPv6 Neighbor Solicit Messages Received: Number of ICMP Neighbor Solicit messages received by the interface.

ICMPv6 Neighbor Advertisement Messages Received: Number of ICMP Neighbor Advertisement messages received by the interface.

ICMPv6 Redirect Messages Received: Number of Redirect messages received by the interface.

ICMPv6 Group Membership Query Messages Received: Number of ICMPv6 Group Membership Query messages received by the interface.

ICMPv6 Group Membership Response Messages Received: Number of ICMPv6 Group Membership Response messages received by the interface.

ICMPv6 Group Membership Reduction Messages Received: Number of ICMPv6 Group Membership Reduction messages received by the interface.

Total ICMPv6 Messages Transmitted: Total number of ICMP messages which this interface attempted to send. Note that this counter includes all those counted by icmpOutErrors.

ICMPv6 Messages Not Transmitted Due To Error: Number of ICMP messages which this interface did not send due to problems discovered within ICMP such as a lack of buffers. This value should not include errors discovered outside the ICMP layer such as the inability of IPv6 to route the resultant datagram. In some implementations there may be no types of error which contribute to this counter's value.

ICMPv6 Destination Unreachable Messages Transmitted: Number of ICMP Destination Unreachable messages sent by the interface.

ICMPv6 Messages Prohibited Administratively Transmitted: Number of ICMP destination unreachable/communication administratively prohibited messages sent.

ICMPv6 Time Exceeded Messages Transmitted: Number of ICMP Time Exceeded messages sent by the interface.

ICMPv6 Parameter Problem Messages Transmitted: Number of ICMP Parameter Problem messages sent by the interface.

ICMPv6 Packet Too Big Messages Transmitted: Number of ICMP Packet Too Big messages sent by the interface.

ICMPv6 Echo Request Messages Transmitted: Number of ICMP Echo (request) messages sent by the interface.ICMP echo messages sent.

ICMPv6 Echo Reply Messages Transmitted: Number of ICMP Echo Reply messages sent by the interface.

ICMPv6 Router Solicit Messages Transmitted: Number of ICMP Router Solicitation messages sent by the interface.

ICMPv6 Router Advertisement Messages Transmitted: Number of ICMP Router Advertisement messages sent by the interface.

ICMPv6 Neighbor Solicit Messages Transmitted: Number of ICMP Neighbor Solicitation messages sent by the interface.

ICMPv6 Neighbor Advertisement Messages Transmitted: Number of ICMP Neighbor Advertisement messages sent by the interface.

ICMPv6 Redirect Messages Transmitted: Number of Redirect messages sent. For a host, this object will always be zero, since hosts do not send redirects.

ICMPv6 Group Membership Query Messages Transmitted: Number of ICMPv6 Group Membership Query messages sent.

ICMPv6 Group Membership Response Messages Transmitted: Number of ICMPv6 Group Membership Response messages sent.

ICMPv6 Group Membership Reduction Messages Transmitted: Number of ICMPv6 Group Membership Reduction messages sent.

ICMPv6 Duplicate Address Detects: Number of duplicate addresses detected by interface.

8.3.2 Configuration Commands

8.3.2.1 ipv6 hop-limit

This command defines the unicast hop count used in ipv6 packets originated by the node. The value is also included in router advertisements. Valid values for <hops> are 1-64 inclusive. The default "not configured" means that a value of zero is sent in router advertisements and a value of 64 is sent in packets originated by the node. Note that this is not the same as configuring a value of 64.

Syntax		
ipv6 hop-l	-limit <hops></hops>	
no ipv6 ho	Iop-limit	

no - Use this command to disable the forwarding of IPv6 hop-limit.

Default Setting

not configured

Command Mode

Global Config

8.3.2.2 ipv6 unicast-routing

Use this command to enable the forwarding of IPv6 unicast packets.

Syntax		
ipv6 unica	ast-routing	
no ipv6 u	no ipv6 unicast-routing	

no – Use this command to disable the forwarding of IPv6 unicast packets.

Default Setting

Disabled

Command Mode

Global Config

8.3.2.3 ipv6 enable

Use this command to enable IPv6 routing on an interface, including a tunnel and loopback interface that has not been configured with an explicit IPv6 address. When you use this command, the interface is automatically configured with a link-local address. You do not need to use this command if you configured an IPv6 global address on the interface.

Syntax		
ipv6 enab	able	
no ipv6 e	enable	

no – Use this command to disable IPv6 routing on an interface.

Default Setting

Disabled

Command Mode

Interface Config

Interface VLAN



8.3.2.4 ipv6 address

Use this command to configure an IPv6 address on an interface, including tunnel and loopback interfaces, and to enable IPv6 processing on this interface. You can assign multiple globally reachable addresses to an interface by using this command. You do not need to assign a linklocal address by using this command since one is automatically created. The <prefix> field consists of the bits of the address to be configured. The <prefix_length> designates how many of the high-order contiguous bits of the address make up the prefix.

You can express IPv6 addresses in eight blocks. Also of note is that instead of a period, a colon now separates each block. For simplification, leading zeros of each 16 bit block can be omitted. One sequence of 16 bit blocks containing only zeros can be replaced with a double colon "::", but not more than one at a time (otherwise it is no longer a unique representation).

- Dropping zeros: 3ffe:ffff:100:f101:0:0:0:1 becomes 3ffe:ffff:100:f101::1
- Local host: 0000:0000:0000:0000:0000:0000:0001 becomes ::1
- Any host: 0000:0000:0000:0000:0000:0000:0000 becomes ::

The hexadecimal letters in the IPv6 addresses are not case-sensitive. An example of an IPv6 prefix and prefix length is 3ffe:1::1234/64.

The optional [eui-64] field designates that IPv6 processing on the interfaces was enabled using an EUI-64 interface ID in the low order 64 bits of the address. If you use this option, the value of <prefix_length> must be 64 bits.

Syntax

ipv6 address <prefix> / <prefix_length> [eui64] no ipv6 address [<prefix> / <prefix_length>] [eui64]

<prefix> - parameter consists of the bits of the address to be configured.

cyrefix_length> - It designates how many of the high-order contiguous bits of the address comprise
the prefix.

[eui-64] – This field designates that IPv6 processing on the interfaces was enabled using an EUI-64 interface ID in the low order 64 bits of the address. If you do not supply any parameters, the command deletes all the IPv6 addresses on an interface.

no - Use this command to remove all IPv6 addresses on an interface or specified IPv6 address.

Default Setting

None

Command Mode

Interface Config Interface VLAN



8.3.2.5 ipv6 gateway

Use this command to configure IPv6 gateway (i.e. default routers) information for the network port.

-	
S١	/ntax

ipv6 gateway <gateway-address> no ipv6 gateway

<gateway-address> - Gateway address in IPv6 global or link-local address format.

no – Use this command remove IPv6 gateways on the network port interface.

Command Mode

Interface vlan



8.3.2.6 ipv6 route

Use this command to configure an IPv6 static route. The <ipv6-prefix> is the IPv6 network that is the destination of the static route. The <prefix_length> is the length of the IPv6 prefix — a decimal value (usually 0-64) that shows how many of the high-order contiguous bits of the address comprise the prefix (the network portion of the address). A slash mark must precede the <prefix_length>. The <next-hop-address> is the IPv6 address of the next hop that can be used to reach the specified network. The <preference> parameter is a value the router uses to compare this route with routes from other route sources that have the same destination. The range for preference> is 1 - 255, and the default value is 1. The interface <slot/port> identifies direct static routes from point-to-point and broadcast interfaces, and must be specified when using a link-local address as the next hop. A route with a preference of 255 cannot be used to forward traffic.

Syntax

ipv6 route <ipv6-prefix>/<prefix_length> {<next-hop-address> [<preference>] | interface {<slot/port> |
tunnel <tunnel-id> | vlan <vlan-id>} <next-hop-address> [<preference>]}
no ipv6 route <ipv6-prefix>/<prefix_length> [{<next-hopaddress> | interface {<slot/port> | tunnel
<tunnel-id> | vlan <vlan-id>} <next-hop-address> | <preference>}]

no – Use this command to delete an IPv6 static route. Use the command without the optional parameters to delete all static routes to the specified destination. Use the preference> parameter to revert preference of a route to default preference.

Default Setting

Disabled

Command Mode

Global Config

8.3.2.7 ipv6 route distance

This command sets the default distance (preference) for IPv6 static routes. Lower route distance values are preferred when determining the best route. The ipv6 route command allows you to optionally set the distance (preference) of an individual static route. The default distance is used when no distance is specified in this command.

Changing the default distance does not update the distance of existing static routes, even if they were assigned the original default distance. The new default distance will only be applied to static routes created after invoking the ipv6 route distance command.

vntax	
/6 route distance <1-255>	
ipv6 route distance	

no – This command resets the default static route preference value in the router to the original default preference. Lower routepreference values are preferred when determining the best route.

Default Setting

1

Command Mode

Global Config



8.3.2.8 ipv6 mtu

This command sets the maximum transmission unit (MTU) size, in bytes, of IPv6 packets on an interface. This command replaces the default or link MTU with a new MTU value.

Syntax			
ipv6 mtu	<1280-1500>		
no ipv6 n	ntu		

no - This command resets maximum transmission unit value to default value.

Default Setting

0 or link speed (MTU value is 1500)

Command Mode

Interface Config

8.3.2.9 ipv6 nd dad attempts

This command sets the number of duplicate address detection probes transmitted. Duplicate address detection verifies that an IPv6 address on an interface is unique.

Syntax

ipv6 nd dad attempts <0 – 600> no ipv6 nd dad attempts

no - This command resets to number of duplicate address detection value to default value.

Default Setting

1

Command Mode

8.3.2.10 ipv6 nd managed-config-flag

This command sets the "managed address configuration" flag in router advertisements. When the value is true, end nodes use DHCPv6. When the value is false, end nodes automatically configure addresses.

C.	ntax
Jy	IIIax

ipv6 nd managed-config-flag no ipv6 nd managed-config-flag

no – This command resets the "managed address configuration" flag in router advertisements to the default value.

Default Setting

False

Command Mode

Interface Config

8.3.2.11 ipv6 nd ns-interval

This command sets the interval between router advertisements for advertised neighbor solicitations, in milliseconds. An advertised value of 0 means the interval is unspecified.

Syntax

```
ipv6 nd ns-interval { <1000 – 4294967295> | 0 }
no ipv6 nd ns-interval
```

no – This command resets the neighbor solicit retransmission interval of the specified interface to the default value.

Default Setting

0

Command Mode

8.3.2.12 ipv6 nd other-config-flag

This command sets the "other stateful configuration" flag in router advertisements sent from the interface.

Cunto	~
Synta	х

ipv6 nd other-config-flag no ipv6 nd other-config-flag

no – This command resets the "other stateful configuration" flag back to its default value in router advertisements sent from the interface.

Default Setting

False

Command Mode

Interface Config

8.3.2.13 ipv6 nd ra-interval

This command sets the transmission interval between router advertisements.

S	yntax
	yman

ipv6 nd ra-interval <4 – 1800 > no ipv6 nd ra-interval

no – This command sets router advertisement interval to the default.

Default Setting

600

Command Mode



8.3.2.14 ipv6 nd ra-lifetime

This command sets the value, in seconds, that is placed in the Router Lifetime field of the router advertisements sent from the interface. The fetime> value must be zero, or it must be an integer between the value of the router advertisement transmission interval and 9000. A value of zero means this router is not to be used as the default router.

Syntax			
ipv6 nd ra-l	lifetime <lifetime></lifetime>		
no ipv6 nd	ra-lifetime		

no – This command resets router lifetime to the default value.

Default Setting

1800

Command Mode

Interface Config

8.3.2.15 ipv6 nd reachable-time

This command sets the router advertisement time to consider a neighbor reachable after neighbor discovery confirmation. Reachable time is specified in milliseconds. A value of zero means the time is unspecified by the router.

Syntax

ipv6 nd re	eachable-time <0 - 3600000>	
no ipv6 no	d reachable-time	

no – This command means reachable time is unspecified for the router.

Default Setting

0

Command Mode

8.3.2.16 ipv6 nd router-preference

This command sets the router preference for Default Router.

Syntax	r
Syntax	Ł

Г

ipv6 nd router-preference <high | low | medium> no ipv6 nd router-preference

no - This command resets router preference to default.

Default Setting

Medium

Command Mode

Interface Config

8.3.2.17 ipv6 nd suppress-ra

This command suppresses router advertisement transmission on an interface.

Syntax

ipv6 nd suppress-ra no ipv6 nd suppress-ra

no -This command enables router transmission on an interface.

Default Setting

Disabled

Command Mode

8.3.2.18 ipv6 nd prefix

This command sets the IPv6 prefixes to include in the router advertisement. The first optional parameter is the valid lifetime of the router, in seconds. You can specify a value or indicate that the lifetime value is infinite. The second optional parameter is the preferred lifetime of the router.

Syntax	
Junan	•

ipv6 nd prefix <prefix/prefix_length> [{<0-4294967295> | infinite} {<0-4294967295> | infinite}] [no-autoconfig off-link] no ipv6 nd prefix

no – This command sets prefix configuration to default values.

The router advertises its global IPv6 prefixes in its router advertisements (RAs). An RA only includes the prefixes of the IPv6 addresses configured on the interface where the RA is transmitted. Addresses are configured using the ipv6 address interface configuration command. Each prefix advertisement includes information about the prefix, such as its lifetime values and whether hosts should use the prefix for on-link determination or address auto-configuration. Use the ipv6 nd prefix command to configure these values.

The ipv6 nd prefix command allows you to preconfigure RA prefix values before you configure the associated interface address. In order for the prefix to be included in RAs, you must configure an address that matches the prefix using the ipv6 address command. Prefixes specified using ipv6 nd prefix without associated interface address will not be included in RAs and will not be committed to the device configuration.

Default Setting

Valid-lifetime –2592000

Preferred-lifetime -604800

Autoconfig - enabled

On-link - enabled

Command Mode

8.3.2.19 ipv6 unreachables

Use this command to enable the generation of ICMPv6 Destination Unreachable messages. By default, the generation of ICMPv6 Destination Unreachable messages is enabled.

Syntax	ĸ	
ipv6 unre	nreachables	
no ipv6 u	6 unreachables	

no – This command prevent the generation of ICMPv6 Destination Unreachable messages.

Default Setting

Enabled

Command Mode

Interface Config

8.3.2.20 ipv6 icmp error-interval

Use this command to limit the rate at which ICMPv6 error messages are sent. The rate limit is configured as a token bucket, with two configurable parameters, burst-size and burst-interval.

Syntax

ipv6 icmp error-interval <burst-interval> [<burst-size>] no ipv6 icmp error-interval

<burst-interval> - Specifies how often the token bucket is initialized with burst-size tokens. burst-interval is from 0 to 2147483647 milliseconds (msec).

<burst-size> - The number of ICMPv6 error messages that can be sent during one burst-interval. The range is from 1 to 200 messages. To disable ICMP rate limiting, set burst-interval to zero (0).

no - This command return burst-interval and burst-size to their default values.

Default Setting

burst-interval of 1000 msec.

burst-size of 100 messages

Command Mode

Global Config

8.4 **OSPFv3 Commands**

This section describes the commands you use to configure OSPFv3, which is a link-state routing protocol that you use to route traffic within a network.

8.4.1 Show Commands

8.4.1.1 show ipv6 ospf

This command displays information relevant to the OSPF router.

Syntax

show ipv6 ospf

Default Setting

None

Command Mode

Privileged Exec

Display Messages

NOTE: Some of the information below displays only if you enable OSPF and configure certain features.

Router ID: Is a 32 bit integer in dotted decimal format identifying the router, about which information is displayed. This is a configured value.

OSPF Admin Mode: Shows whether the administrative mode of OSPF in the router is enabled or disabled. This is a configured value.

External LSDB Limit: Shows the maximum number of non-default AS-external-LSAs entries that can be stored in the link-state database.

Exit Overflow Interval: Shows the number of seconds that, after entering Overflow State, a router will attempt to leave Overflow State.

Autocost Ref BW: Shows the value of auto-cost reference bandwidth configured on the router.

Default Passive Setting: Shows whether the interfaces are passive by default.

Maximum Paths: The maximum number of paths that OSPF can report for a given destination.

Default Metric: Default value for redistributed routes.

Default Route Advertise: Indicates whether the default routes received from other source protocols are advertised or not.

Always: Shows whether default routes are always advertised.

Metric: The metric of the routes being redistributed. If the metric is not configured, this field is blank.

Metric Type: Shows whether the routes are External Type 1 or External Type 2.Number of Active

Number of Active Areas: The number of active OSPF areas. An "active" OSPF area is an area with at least one interface up.

ABR Status: Shows whether the router is an OSPF Area Border Router.

ASBR Status: Reflects whether the ASBR mode is enabled or disabled. Enable implies that the router is an autonomous system border router. The router automatically becomes an ASBR when it is configured to redistribute routes learnt from other protocols. The possible values for the ASBR status is enabled (if the router is configured to redistribute routes learned by other protocols) or disabled (if the router is not configured for the same).

Stub Router: When OSPF runs out of resources to store the entire link state database, or any other state information, OSPF goes into stub router mode. As a stub router, OSPF re-originates its own router LSAs, setting the cost of all non-stub interfaces to infinity. To restore OSPF to normal operation, disable and re-enable OSPF.

External LSDB Overflow: When the number of non-default external LSAs exceeds the configured limit, External LSDB Limit, OSPF goes into LSDB overflow state. In this state, OSPF withdraws all of its self-originated non-default external LSAs. After the Exit Overflow Interval, OSPF leaves the overflow state, if the number of external LSAs has been reduced.

External LSA Count: Shows the number of external (LS type 5) link-state advertisements in the link-state database.

External LSA Checksum: Shows the sum of the LS checksums of external link-state advertisements contained in the link-state database.

New LSAs Originated: Shows the number of new link-state advertisements that have been originated.

LSAs Received: Shows the number of link-state advertisements received determined to be new instantiations.

LSA Count: The total number of link state advertisements currently in the link state database.

Maximum Number of LSAs: The maximum number of LSAs that OSPF can store.

LSA High Water Mark: The maximum size of the link state database since the system started.

Retransmit List Entries: The total number of LSAs waiting to be acknowledged by all neighbors. An LSA may be pending acknowledgment from more than one neighbor.

Maximum Number of Retransmit Entries: The maximum number of LSAs that can be waiting for acknowledgment at any given time.

Retransmit Entries High Water Mark: The highest number of LSAs that have been waiting for acknowledgment.

NSF Helper Support: Configure graceful restart.

NSF Helper Strict LSA Checking: Terminate graceful restart helper on topology change.

8.4.1.2 show ip ospf abr

This command displays the internal OSPFv3 routes to reach Area Border Routers (ABR). This command takes no options.

Syntax

show ipv6 ospf abr

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Messages

Type: The type of the route to the destination. It can be either:

- intra Intra-area route
- inter Inter-area route

Router ID: Router ID of the destination

Cost: Cost of using this route

Area ID: The area ID of the area from which this route is learned.

Next Hop: Next hop toward the destination

Next Hop Intf: The outgoing router interface to use when forwarding traffic to the next hop.

8.4.1.3 show ipv6 ospf area

This command displays information about the area. The <areaid> identifies the OSPF area that is being displayed.

Syntax

show ipv6 ospf area <areaid>

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Messages

AreaID: Is the area id of the requested OSPF area.

External Routing: Is a number representing the external routing capabilities for this area.

Spf Runs: Is the number of times that the intra-area route table has been calculated using this area's link-state database.

Area Border Router Count: The total number of area border routers reachable within this area.

Area LSA Count: Total number of link-state advertisements in this area's link-state database, excluding AS External LSAs.

Area LSA Checksum: A number representing the Area LSA Checksum for the specified AreaID excluding the external (LS type 5) link-state advertisements.

Stub Mode: Represents whether the specified Area is a stub area or not. The possible values are enabled and disabled. This is a configured value.

Import Summary LSAs: Shows whether to import summary LSAs (enabled).

The following OSPF NSSA specific information displays only if the area is configured as an NSSA.

Import Summary LSAs: Shows whether to import summary LSAs into the NSSA.

No-Redistribute into NSSA: Shows whether to redistribute information into the NSSA.

Default Information Originate: Shows whether to advertise a default route into the NSSA

Default Metric: Shows the metric value for the default route advertised into the NSSA.

Default Metric Type: Shows the metric type for the default route advertised into the NSSA.

Translator Role Shows the NSSA translator role of the ABR, which is always or candidate.

Translator Stability Interval: Shows the amount of time that an elected translator continues to perform its duties after it determines that its translator status has been deposed by another router.

Translator State: Shows whether the ABR translator state is disabled, always, or elected.



8.4.1.4 show ipv6 ospf asbr

This command displays the internal OSPFv3 routes to reach Autonomous System Boundary Routers (ASBR). This command takes no options.

C.	ntax
21	ntax.

show ipv6 ospf asbr

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Messages

Type: The type of the route to the destination. It can be either:

- intra Intra-area route
- inter Inter-area route

Router ID: Router ID of the destination

Cost: Cost of using this route

Area ID: The area ID of the area from which this route is learned.

Next Hop: Next hop toward the destination

Next Hop Intf: The outgoing router interface to use when forwarding traffic to the next hop.



8.4.1.5 show ipv6 ospf database

This command displays information about the link state database when OSPFv3 is enabled. If you do not enter any parameters, the command displays the LSA headers for all areas. Use the optional <areaid> parameter to display database information about a specific area. Use the other optional parameters to specify the type of link state advertisements to display. Use external to display the external LSAs. Use inter-area to display the inter-area LSAs. Use link to display the link LSAs. Use network to display the network LSAs. Use nssa-external to display NSSA external LSAs. Use prefix to display intra-area Prefix LSAs. Use router to display router LSAs. Use unknown area, unknown as, or unknown link to display unknown area, AS or link-scope LSAs, respectively. Use <lsid> to specify the link state ID (LSID). Use adv-router to show the LSAs that are restricted by the advertising router. Use selforiginate to display the LSAs in that are self originated. The information below is only displayed if OSPF is enabled.

Syntax

show ipv6 ospf [<areaid>] database [{external | inter-area {prefix | router} | link | network | nssa-external | prefix | router | unknown {area | as | link}}] [<lsid>] [{adv-router [<rtrid>] | self-originate}]

<areaid> - Configures to display database information about a specific area.

<lsid>- Specify the link state ID.

<rtrid>- Specify an IP Address.

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Messages

Ls Id: Is a number that uniquely identifies an LSA that a router originates from all

other self originated LSA's of the same LS type.

Adv Router: The Advertising Router. Is a 32 bit dotted decimal number representing the LSDB interface.

Age: Is a number representing the age of the link state advertisement in seconds.

Sequence: Is a number that represents which LSA is more recent.

Csum: Is the total number LSA checksum.

Options: This is an integer. It indicates that the LSA receives special handling during routing calculations.

Rtr Opt: Router Options are valid for router links only.

8.4.1.6 show ipv6 ospf database database-summary

This command displays the number of each type of LSA in the database and the total number of LSAs in the database.

Syntax

show ipv6 ospf database database-summary

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Messages

Router: Total number of router LSAs in the OSPFv3 link state database.

Network: Total number of network LSAs in the OSPFv3 link state database.

Inter-area Prefix: Total number of inter-area prefix LSAs in the OSPFv3 link state database.

Inter-area Router: Total number of inter-area router LSAs in the OSPFv3 link state database.

Type-7 Ext: Total number of NSSA external LSAs in the OSPFv3 link state database.

Link: Total number of link LSAs in the OSPFv3 link state database.

Intra-area Prefix: Total number of intra-area prefix LSAs in the OSPFv3 link state database.

Link Unknown: Total number of link-source unknown LSAs in the OSPFv3 link state database.

Area Unknown: Total number of area unknown LSAs in the OSPFv3 link state database.

AS Unknown: Total number of as unknown LSAs in the OSPFv3 link state database.

Subtotal: Number of entries for the identified area.**Self-Originated Type-7 Ext:** Total number of self originated Type-7 external LSAs in the database.

Type-5 Ext: Total number of Type-5 external LSAs in the database.

Self-Originated Type-5 Ext: Total number of self originated Type-5 external LSAs in the database.

Total: Total number of router LSAs in the OSPFv3 link state database.

8.4.1.7 show ipv6 ospf interface

This command displays the information for the IFO object or virtual interface tables.

Syntax

show ipv6 ospf interface {<slot/port> | loopback <0-7> | tunnel <0-7> | vlan <vlan-id>}

<slot/port> - Interface number.

<0-7> - Loopback/Tunnel Interface ID.

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Messages

IPv6 Address: Shows the IPv6 address of the interface.

ifIndex: Shows the interface index number associated with the interface.

OSPF Admin Mode: Shows whether the admin mode is enabled or disabled.

OSPF Area ID: Shows the area ID associated with this interface.

Router Priority: Shows the router priority. The router priority determines which router is the designated router.

Retransmit Interval: Shows the frequency, in seconds, at which the interface sends LSA.

Hello Interval: Shows the frequency, in seconds, at which the interface sends Hello packets.

Dead Interval: Shows the amount of time, in seconds, the interface waits before assuming a neighbor is down.

LSA Ack Interval: Shows the amount of time, in seconds, the interface waits before sending an LSA acknowledgement after receiving an LSA.

Transmit Delay Interval: A number representing the OSPF Transmit Delay for the specified interface.

Authentication Type: Shows the type of authentication the interface performs on LSAs it receives.

Metric Cost: Shows the priority of the path. Low costs have a higher priority than high costs.

OSPF MTU-ignore: Shows whether to ignore MTU mismatches in database descriptor packets sent from neighboring routers.

The following information only displays if OSPF is initialized on the interface:

OSPF Interface Type: Broadcast LANs, such as Ethernet and IEEE 802.5, take the value broadcast. The OSPF Interface Type will be 'broadcast'.

State: The OSPF Interface States are: down, loopback, waiting, point-to-point, designated router, and backup designated router.

Designated Router: The router ID representing the designated router.

Backup Designated Router: The router ID representing the backup designated router.

Number of Link Events: The number of link events.

8.4.1.8 show ipv6 ospf interface brief

This command displays brief information for the IFO object or virtual interface tables.

Syntax

show ipv6 ospf interface brief

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Messages

Interface: Valid slot and port number separated by forward slashes.

OSPF Admin Mode: States whether OSPF is enabled or disabled on a router interface. This is a configured value.

OSPF Area ID: Represents the OSPF Area Id for the specified interface. This is a configured value.

Router Priority: Shows the router priority. The router priority determines which router is the designated router.

Hello Interval: Shows the frequency, in seconds, at which the interface sends Hello packets.

Dead Interval: Shows the amount of time, in seconds, the interface waits before assuming a neighbor is down.

Retransmit Interval: Shows the frequency, in seconds, at which the interface sends LSA.

Retransmit Delay Interval: Shows the number of seconds the interface adds to the age of LSA packets before transmission.

LSA Ack Interval: Shows the amount of time, in seconds, the interface waits before sending an LSA acknowledgement after receiving an LSA.

8.4.1.9 show ipv6 ospf interface stats

This command displays the statistics for a specific interface. The command only displays

information if OSPF is enabled

Syntax

show ipv6 ospf interface stats {<slot/port> | loopback <loopback-id> | tunnel <tunnel-id> | vlan <vlan-id>}

<slot/port> - Interface number.

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Messages

OSPFv3 Area ID: The area id of this OSPF interface.

IP Address: The IP address associated with this OSPF interface.

OSPFv3 Interface Events: The number of times the specified OSPF interface has changed its state, or an error has occurred.

Virtual Events: The number of state changes or errors that occurred on this virtual link.

Neighbor Events: The number of times this neighbor relationship has changed state, or an error has occurred.

Packets Received: The number of OSPFv3 packets received on the interface.

Packets Transmitted: The number of OSPFv3 packets sent on the interface.

LSAs Sent: The total number of LSAs flooded on the interface.

LSA Acks Received: The total number of LSA acknowledged from this interface.

LSA Acks Sent: The total number of LSAs acknowledged to this interface.

Sent Packets: The number of OSPF packets transmitted on the interface.

Received Packets: The number of valid OSPF packets received on the interface.

Discards: The number of received OSPF packets discarded because of an error in the packet or an error in processing the packet.

Bad Version: The number of received OSPF packets whose version field in the OSPF header does not match the version of the OSPF process handling the packet.

Virtual Link Not Found: The number of received OSPF packets discarded where the ingress interface is in a non-backbone area and the OSPF header identifies the packet as belonging to the backbone, but OSPF does not have a virtual link to the packet's sender.

Area Mismatch: The number of OSPF packets discarded because the area ID in the OSPF header is not the area ID configured on the ingress interface.

Invalid Destination Address: The number of OSPF packets discarded because the packet's destination IP address is not the address of the ingress interface and is not the AllDrRouters or AllSpfRouters multicast addresses.

No Neighbor at Source Address: The number of OSPF packets dropped because the sender is not an existing neighbor or the sender's IP address does not match the previously recorded IP address for that neighbor. NOTE: Does not apply to Hellos.

Invalid OSPF Packet Type The number of OSPF packets discarded because the packet type field in the OSPF header is not a known type.

8.4.1.10 show ipv6 ospf neighbor

This command displays information about OSPF neighbors. If you do not specify a neighbor IP address, the output displays summary information in a table. If you specify an interface or tunnel, only the information for that interface or tunnel displays. The **<ipaddr>** is the IP address of the neighbor, and when you specify this, detailed information about the neighbor displays. The information below only displays if OSPF is enabled and the interface has a neighbor.

Syntax

show ipv6 ospf neighbor [{interface {<slot/port> | tunnel <0-7> | vlan <vlan-id>} | <ipaddr>}]

<ipaddr> - IP address of the neighbor.

<slot/port> - Interface number.

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Messages

If you do not specify an IP address, a table with the following columns displays for all neighbors or the neighbor associated with the interface that you specify:

Router ID: Shows the 4-digit dotted-decimal number of the neighbor router.

Priority: Displays the OSPF priority for the specified interface. The priority of an interface is a priority integer from 0 to 255. A value of '0' indicates that the router is not eligible to become the designated router on this network.

Intf ID: Shows the interface ID of the neighbor.

Interface: Shows the interface of the local router in slot/port format.

State: Shows the state of the neighboring routers. Possible values are:

- Down initial state of the neighbor conversation no recent information has been received from the neighbor.
- Attempt no recent information has been received from the neighbor but a more concerted effort should be made to contact the neighbor.
- Init an Hello packet has recently been seen from the neighbor, but bidirectional communication has not yet been established.
- 2 way communication between the two routers is bidirectional.
- Exchange start the first step in creating an adjacency between the two neighboring routers, the goal is to decide which router is the master and to decide upon the initial DD sequence number.
- Exchange the router is describing its entire link state database by sending Database Description packets to the neighbor.

GUANTA COMPUTER INC.

- Loading Link State Request packets are sent to the neighbor asking for the more recent LSAs that have been discovered (but not yet received) in the Exchange state.
- Full the neighboring routers are fully adjacent and they will now appear in router-LSAs and network-LSAs.

Dead Time: Shows the amount of time, in seconds, to wait before the router assumes the neighbor is unreachable.

If you specify an IP address for the neighbor router, the following fields display:

Interface: Shows the interface of the local router in slot/port format.

Area ID: The area ID associated with the interface.

Options: An integer value that indicates the optional OSPF capabilities supported by the neighbor. These are listed in its Hello packets. This enables received Hello Packets to be rejected (i.e., neighbor relationships will not even start to form) if there is a mismatch in certain crucial OSPF capabilities.

Router Priority: Displays the router priority for the specified interface.

Dead Timer Due: Shows the amount of time, in seconds, to wait before the router assumes the neighbor is unreachable.

State: Shows the state of the neighboring routers.

Events: The number of times this neighbor relationship has changed state, or an error has occurred.

Retransmission Queue Length: An integer representing the current length of the retransmission queue of the specified neighbor router Id of the specified interface.

8.4.1.11 show ipv6 ospf range

This command displays information about the area ranges for the specified <areaid>. The <areaid> identifies the OSPF area whose ranges are being displayed.

Syntax	,
Synta	•

show ipv6 ospf range <areaid>

<areaid> - The area id of the requested OSPF area

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Messages

Area ID: The area id of the requested OSPF area.

IP Address: An IP Address which represents this area range.

Subnet Mask: A valid subnet mask for this area range.

Lsdb Type: The type of link advertisement associated with this area range.

Advertisement: The status of the advertisement. Advertisement has two possible settings: enabled or disabled.

8.4.1.12 show ipv6 ospf stub table

This command displays the OSPF stub table. The information bello will only be displayed if OSPF is initialized on the switch.

Syntax

show ipv6 ospf stub table

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Messages

Area ID: Is a 32-bit identifier for the created stub area.

Type of Service: Is the type of service associated with the stub metric. Only supports Normal TOS.

Metric Val: The metric value is applied based on the TOS. It defaults to the least metric of the

type of service among the interfaces to other areas. The OSPF cost for a route is a

function of the metric value.

Import Summary LSA: Controls the import of summary LSAs into stub areas.

8.4.1.13 show ipv6 ospf virtual-link

This command displays the OSPF Virtual Interface information for a specific area and neighbor.

Syntax

show ip ospfv6 virtual-link <areaid> <neighbor>

<areaid> - Area ID.

<neighbor> - Neighbor's router ID.

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Messages

Area ID: The area id of the requested OSPF area.

Neighbor Router ID: The input neighbor Router ID.

Hello Interval: The configured hello interval for the OSPF virtual interface.

Dead Interval: The configured dead interval for the OSPF virtual interface.

Iftransit Delay Interval: The configured transit delay for the OSPF virtual interface.

Retransmit Interval: The configured retransmit interval for the OSPF virtual interface.

Authentication Type: Shows the type of authentication the interface performs on LSAs it receives.

State: The OSPF Interface States are: down, loopback, waiting, point-to-point, designated

router, and backup designated router. This is the state of the OSPF interface.

Neighbor State: The neighbor state.

8.4.1.14 show ipv6 ospf virtual-link brief

This command displays the OSPFv4 Virtual Interface information for all areas in the system.

Syntax

show ipv6 ospf virtual-link brief

Default Setting

None

Command Mode

Privileged Exec

User Exec

Display Messages

Area Id: Is the area id of the requested OSPFv3 area.

Neighbor: Is the neighbor interface of the OSPFv3 virtual interface.

Hello Interval: Is the configured hello interval for the OSPFv3 virtual interface.

Dead Interval: Is the configured dead interval for the OSPFv3 virtual interface.

Retransmit Interval: Is the configured retransmit interval for the OSPFv3 virtual interface.

Transit Delay: Is the configured transit delay for the OSPFv3 virtual interface.

8.4.2 Configuration Commands

8.4.2.1 ipv6 ospf

This command enables OSPF on a router interface or loopback interface.

Syntax			
ipv6 ospf	f		
ipv6 ospf no ipv6 o	ospf		

<no> - This command disables OSPF on a router interface or loopback interface.

Default Setting

Disabled

Command Mode

Interface Config

8.4.2.2 ipv6 ospf areaid

This command sets the OSPF area to which the specified router interface belongs. The <areaid> is an IPv6 address, formatted as a 4-digit dotted-decimal number or a decimal value in the range of <0-4294967295>. The <areaid> uniquely identifies the area to which the interface connects. Assigning an area id, which does not exist on an interface, causes the area to be created with default values.

Syntax

ipv6 ospf areaid <areaid>

<areaid> - is an IPv6 address, formatted as a 4-digit dotted-decimal number or a decimal value in the range of <0-4294967295>.

Default Setting

None

Command Mode

8.4.2.3 ipv6 ospf cost

This command configures the cost on an OSPF interface. The <cost> parameter has a range of 1 to 65535.

Syntax

ipv6 ospf cost <1-65535> no ipv6 ospf cost

<no> - This command configures the default cost on an OSPF interface.

Default Setting

None

Command Mode

Interface Config

8.4.2.4 ipv6 ospf dead-interval

This command sets the OSPF dead interval for the specified interface. The value for <seconds> is a valid positive integer, which represents the length of time in seconds that a router's Hello packets have not been seen before its neighbor routers declare that the router is down. The value for the length of time must be the same for all routers attached to a common network. This value should be some multiple of the Hello Interval (i.e. 4). Valid values range for <seconds> is from 1 to 2147483647.

Syntax

ipv6 ospf dead-interval <seconds> no ipv6 ospf dead-interval

<no> - This command sets the default OSPF dead interval for the specified interface.

Default Setting

40

Command Mode

8.4.2.5 ipv6 ospf hello-interval

This command sets the OSPF hello interval for the specified interface. The value for <seconds> is a valid positive integer, which represents the length of time in seconds. The value for the length of time must be the same for all routers attached to a network. Valid values for <seconds> range from 1 to 65535.

Syntax	
ipv6 ospf	of hello-interval <seconds></seconds>
no ipv6 o	ospf hello-interval

<no> - This command sets the default OSPF hello interval for the specified interface.

Default Setting

10

Command Mode

Interface Config

8.4.2.6 ipv6 ospf mtu-ignore

This command disables OSPF maximum transmission unit (MTU) mismatch detection. OSPF Database Description packets specify the size of the largest IP packet that can be sent without fragmentation on the interface. When a router receives a Database Description packet, it examines the MTU advertised by the neighbor. By default, if the MTU is larger than the router can accept, the Database Description packet is rejected and the OSPF adjacency is not established.

Syntax	
Oyntar	

ipv6 ospf	f mtu-ignore
no ipv6 o	ospf mtu-ignore

<no> - This command enables the OSPF MTU mismatch detection.

Default Setting

Enabled

Command Mode

8.4.2.7 ipv6 ospf network

This command changes the default OSPF network type for the interface. Normally, the network type is determined from the physical IP network type. By default all Ethernet networks are OSPF type broadcast. Similarly, tunnel interfaces default to point-to-point. When an Ethernet port is used as a single large bandwidth IP network between two routers, the network type can be point-to-point since there are only two routers. Using point-to-point as the network type eliminates the overhead of the OSPF designated router election. It is normally not useful to set a tunnel to OSPF network type broadcast.

ipv6 ospf network {broadcast point-to-point}
no ipv6 ospf network {broadcast point-to-point}

<no> - This command sets the interface type to the default value.

Default Setting

Syntax

Broadcast

Command Mode

Interface Config

8.4.2.8 ipv6 ospf priority

This command sets the OSPF priority for the specified router interface. The priority of the interface is a priority integer from 0 to 255. A value of 0 indicates that the router is not eligible to become the designated router on this network.

Syntax	
ipv6 ospf	f priority <0-255>
no ipv6 o	ospf priority

<no> - This command sets the default OSPF priority for the specified router interface.

Default Setting

1, which is the highest router priority

Command Mode

8.4.2.9 ipv6 ospf retransmit-interval

This command sets the OSPF retransmit Interval for the specified interface. The retransmit interval is specified in seconds. The value for <seconds> is the number of seconds between link-state advertisement retransmissions for adjacencies belonging to this router interface. This value is also used when retransmitting database description and link-state request packets. Valid values range from 0 to 3600 (1 hour).

Syntax		
ipv6 ospf retransmit-interval <seconds> no ipv6 ospf retransmit-interval</seconds>		

<no> - This command sets the default OSPF retransmit Interval for the specified interface.

Default Setting

5

Command Mode

Interface Config

8.4.2.10 ipv6 ospf transmit-delay

This command sets the OSPF Transit Delay for the specified interface. The transmit delay is specified in seconds. In addition, it sets the estimated number of seconds it takes to transmit a link state update packet over this interface. Valid values for <seconds> range from 1 to 3600 (1 hour).

Syntax

ipv6 ospf transmit-delay <seconds> no ipv6 ospf transmit-delay

<no> - This command sets the default OSPF Transit Delay for the specified interface.

Default Setting

1

Command Mode



8.4.2.11 ipv6 router ospf

Use this command to enter Router OSPFv3 Config mode.

Syntax

ipv6 router ospf

Default Setting

None

Command Mode

Global Config

8.4.2.12 area default-cost

This command configures the monetary default cost for the stub area. The operator must specify the area id and an integer value between 1-16777215.

Syntax

area <areaid> default-cost <1-16777215>

<areaid> - Area ID.

Default Setting

None

Command Mode

8.4.2.13 area nssa

This command configures the specified areaid to function as an NSSA.

Syntax	x	
--------	---	--

area <areaid> nssa no area <areaid> nssa

<areaid> - Area ID.

no - This command disables nssa from the specified area id.

Default Setting

None

Command Mode

Router OSPFv3 Config

8.4.2.14 area nssa default-info-originate

This command configures the metric value and type for the default route advertised into the NSSA. The optional metric parameter specifies the metric of the default route and is to be in a range of 1-16777214. If no metric is specified, the default value is 10. The metric type can be comparable (nssa-external 1) or non-comparable (nssa-external 2).

Syntax

area <areaid> nssa default-info-originate [<1-16777215>] [{comparable | non-comparable}] no area <areaid> nssa default-info-originate [<1-16777215>] [{comparable | non-comparable}]

<areaid> - Area ID.

<1-16777215> - The metric of the default route. The range is 1 to 16777215.

comparable - It's NSSA-External 1.

non-comparable - It's NSSA-External 2.

no - This command disables the default route advertised into the NSSA.

Default Setting

None

Command Mode

8.4.2.15 area nssa no-redistribute

This command configures the NSSA ABR so that learned external routes will not be redistributed to the NSSA.

Syntax

area <areaid> nssa no-redistribute no area <areaid> nssa no-redistribute

<areaid> - Area ID.

no - This command disables the NSSA ABR so that learned external routes are redistributed to the NSSA.

Default Setting

None

Command Mode

Router OSPFv3 Config

8.4.2.16 area nssa no-summary

This command configures the NSSA so that summary LSAs are not advertised into the NSSA

Syntax

area <areaid> nssa no-summary no area <areaid> nssa no-summary

<areaid> - Area ID.

no - This command disables nssa from the summary LSAs.

Default Setting

None

Command Mode

8.4.2.17 area nssa translator-role

This command configures the translator role of the NSSA. A value of always causes the router to assume the role of the translator the instant it becomes a border router and a value of candidate causes the router to participate in the translator election process when it attains border router status.

Syntax

area <areaid> nssa translator-role {always | candidate} no area <areaid> nssa translator-role

<areaid> - Area ID.

always - A value of *always* will cause the router to assume the role of the translator when it becomes a border router.

candidate - a value of *candidate* will cause the router to participate in the translator election process when it attains border router status.

no - This command disables the nssa translator role from the specified area id.

Default Setting

None

Command Mode



8.4.2.18 area nssa translator-stab-intv

This command configures the translator stability interval of the NSSA. The <stability interval> is the period of time that an elected translator continues to perform its duties after it determines that its translator status has been deposed by another router.

Syntax

area <areaid> nssa translator-stab-intv <0-3600> no area <areaid> nssa translator-stab-intv

<areaid> - Area ID.

<0-3600> - The range is 0 to 3600.

no - Disables the nssa translator's <stabilityinterval> from the specified area id.

Default Setting

None

Command Mode



8.4.2.19 area range

This command creates a specified area range for a specified NSSA. The **<ipv6-prefix>** is a valid IPv6 address. The **<prefix-length>** is a valid subnet mask. The LSDB type must be specified by either summarylink or nssaexternallink, and the advertising of the area range can be allowed or suppressed.

Syntax

area <areaid> range <ipv6-prefix>/<prefix-length> {summarylink | nssaexternallink} [advertise | not-advertise] no area <areaid> range <ipv6-prefix>/<prefix-length>

<areaid> - Area ID.

<ipv6-prefix> - IP Address.

<prefix-length> - The subnetmask.

summarylink - The lsdb type. The value is summarylink or nssaexternallink

nssaexternallink - The lsdb type. The value is summarylink or nssaexternallink

advertise - Allow advertising the specified area range.

not-advertise - Disallow advertising the specified area range.

no - This command deletes a specified area range.

Default Setting

None

Command Mode



8.4.2.20 area stub

This command creates a stub area for the specified area ID. A stub area is characterized by the fact that AS External LSAs are not propagated into the area. Removing AS External LSAs and Summary LSAs can significantly reduce the link state database of routers within the stub area.

Syntax			
area <areaid> stub</areaid>			
no area <	no area <areaid> stub</areaid>		

<areaid> - Area ID.

<no> - This command deletes a stub area for the specified area ID.

Default Setting

None

Command Mode

Router OSPFv3 Config

8.4.2.21 area stub no-summary

This command disables the import of Summary LSAs for the stub area identified by <areaid>.

Syntax

area <areaid> stub no-summary no area <areaid> stub no-summary

<areaid> - Area ID.

no - This command sets the Summary LSA import mode to the default for the stub area identified by <areaid>.

Default Setting

Enabled

Command Mode

8.4.2.22 area virtual-link

This command creates the OSPF virtual interface for the specified <areaid> and <neighbor>. The <neighborid> parameter is the Router ID of the neighbor.

Sunta	v
Synta	IX

area <areaid> virtual-link <neighborid> no area <areaid> virtual-link <neighborid>

<areaid> - Area ID.

<neighborid> - Router ID of the neighbor.

no - This command deletes the OSPF virtual interface from the given interface, identified by **<areaid>** and **<neighborid>**. The **<neighborid>** parameter is the Router ID of the neighbor.

Default Setting

The default authentication type is none.

Command Mode

8.4.2.23 area virtual-link dead-interval

This command configures the dead interval for the OSPF virtual interface on the virtual interface identified by **<areaid>** and **<neighborid>**.

Sy	/ntax

area <areaid> virtual-link <neighborid> dead-interval <1-65535> no area <areaid> virtual-link <neighborid> dead-interval

<areaid> - Area ID.

<neighborid> - Router ID of the neighbor.

<1-65535> - The range of the dead interval is 1 to 65535.

no - This command configures the default dead interval for the OSPF virtual interface on the virtual interface identified by **<areaid>** and **<neighbor>**. The **<neighbor>** parameter is the Router ID of the neighbor.

Default Setting

40 seconds.

Command Mode

8.4.2.24 area virtual-link hello-interval

This command configures the hello interval for the OSPF virtual interface on the interface identified by **<areaid>** and **<neighborid>**.

C.			
Sy	/111	Ld)	ĸ

area <areaid> virtual-link <neighborid> hello-interval <1-65535> no area <areaid> virtual-link <neighborid> hello-interval

<areaid> - Area ID.

<neighborid> - Router ID of the neighbor.

<1-65535> - The range of the hello interval is 1 to 65535.

no - This command configures the default hello interval for the OSPF virtual interface on the interface identified by **<areaid>** and **<neighborid>**.

Default Setting

10 seconds.

Command Mode

8.4.2.25 area virtual-link retransmit-interval

This command configures the retransmit interval for the OSPF virtual interface on the interface identified by **areaid>** and **areighborid>**.

Cuntav	
Syntax	

area <areaid> virtual-link <neighborid> retransmit-interval <0-3600> no area <areaid> virtual-link <neighborid> retransmit-interval

<areaid> - Area ID.

<neighborid> - Router ID of the neighbor.

<0-3600> - The range of the retransmit interval is 0 to 3600.

no - This command configures the default retransmit interval for the OSPF virtual interface on the interface identified by <areaid> and <neighborid>.

Default Setting

5 seconds.

Command Mode

8.4.2.26 area virtual-link transmit-delay

This command configures the transmit delay for the OSPF virtual interface on the virtual interface identified by **<areaid>** and **<neighborid>**.

Syntax	
Syntax	

area <areaid> virtual-link <neighborid> transmit-delay <0-3600> no area <areaid> virtual-link <neighborid> transmit-delay

<areaid> - Area ID.

<neighborid> - Router ID of the neighbor.

<0-3600> - The range of the transmit delay is 0 to 3600.

no - This command configures the default transmit delay for the OSPF virtual interface on the virtual interface identified by <areaid> and <neighborid>.

Default Setting

1 second.

Command Mode



8.4.2.27 auto-cost

By default, OSPF computes the link cost of each interface from the interface bandwidth. Faster links have lower metrics, making them more attractive in route selection. The configuration parameters in the auto-cost reference bandwidth and bandwidth commands give you control over the default link cost. You can configure for OSPF an interface bandwidth that is independent of the actual link speed. A second configuration parameter allows you to control the ratio of interface bandwidth to link cost. The link cost is computed as the ratio of a reference bandwidth to the interface bandwidth (ref_bw /interface bandwidth), where interface bandwidth is defined by the bandwidth command. Because the default reference bandwidth is 100 Mbps, OSPF uses the same default link cost for all interfaces whose bandwidth is 100 Mbps or greater. Use the auto-cost command to change the reference bandwidth, specifying the reference bandwidth in megabits per second (Mbps). The reference bandwidth range is 1–4294967 Mbps. The different reference bandwidth can be independently configured for OSPFv2 and OSPFv3.

Syntax

auto-cost reference-bandwidth <1 to 4294967> no auto-cost reference-bandwidth

Default Setting

100Mbps

Command Mode



8.4.2.28 default-information originate

This command is used to control the advertisement of default routes.

Syntax
Jyillax

default-information originate [always] [metric <1-16777215>] [metric-type {1 | 2}] no default-information originate [metric] [metric-type]

[always] - Sets the router advertise 0.0.0/0.0.0.0.

metric - The range of the metric is 1 to 16777215.

metric type - The value of metric type is type 1 or type 2.

no - This command configures the default advertisement of default routes.

Default Setting

Metric: unspecified

Type: 2

Command Mode

Router OSPFv3 Config

8.4.2.29 default-metric

This command is used to set a default for the metric of distributed routes.

Syntax

default-metric <1-16777215> no default-metric

<1-16777215> - The range of default metric is 1 to 16777215.

<no> - This command is used to set a default for the metric of distributed routes.

Default Setting

None

Command Mode

8.4.2.30 distance ospf

This command sets the route preference value of OSPF in the router. Lower route preference values are preferred when determining the best route. The type of OSPF can be intra, inter, type-1, or type-2. The OSPF specification (RFC 2328) requires that preferences must be given to the routes learned via OSPF in the following order: intra < inter < type-1 < type-2. The <pre>reference range is 1 to 255. A route with a preference of 255 cannot be used to forward traffic.

Syntax

distance ospf {intra | inter | type1 | type2} <preference> no distance ospf {intra | inter | type1 | type2}

<preference> - The range for intra is 1 to 252. The range for inter is 2 to 253. The range for type1 is
3 to 254. The range for type2 is 4 to 255.

no - This command sets the default route preference value of OSPF in the router.

Default Setting

Intra is 8.

Inter is 10.

Type 1 is 13.

Type 2 is 150.

Command Mode

8.4.2.31 enable

This command resets the default administrative mode of OSPF in the router (active).

Syntax		
enable		
no enable	le	

<no> - This command sets the administrative mode of OSPF in the router to inactive.

Default Setting

Enabled

Command Mode

Router OSPFv3 Config

8.4.2.32 exit-overflow-interval

This command configures the exit overflow interval for OSPF. It describes the number of seconds after entering Overflow state that a router will wait before attempting to leave the Overflow State. This allows the router to again originate non-default AS-external-LSAs. When set to 0, the router will not leave Overflow State until restarted.

Syntax

exit-overflow-interval <0-2147483647> no exit-overflow-interval

<0-2147483674> - The range of exit overflow interval for OSPF is 0 to 2147483674.

no - This command configures the default exit overflow interval for OSPF.

Default Setting

0

Command Mode

8.4.2.33 external-Isdb-limit

This command configures the external LSDB limit for OSPF. If the value is -1, then there is no limit. When the number of non-default AS-external-LSAs in a router's link-state database reaches the external LSDB limit, the router enters overflow state. The router never holds more than the external LSDB limit non-default AS-external-LSAs in it database. The external LSDB limit MUST be set identically in all routers attached to the OSPF backbone and/or any regular OSPF area.

Syntax

external-Isdb-limit <-1-2147483647> no external-Isdb-limit

<-1-2147483647> - The range of external LSDB limit for OSPF is -1 to 2147483674.

no - This command configures the default external LSDB limit for OSPF.

Default Setting

-1

Command Mode

Router OSPFv3 Config

8.4.2.34 maximum-paths

This command sets the number of paths that OSPF can report for a given destination where <maxpaths> is platform dependent.

s	Syntax					
m	maximum-paths <1-2>					
n	o maximum-paths					

<1-2> - The maximum number of paths that OSPF can report for a given destination. The range of the value is 1 to 2.

no - This command resets the number of paths that OSPF can report for a given destination back to its default value.

Default Setting

1

Command Mode

8.4.2.35 passive-interface default

Use this command to enable global passive mode by default for all interfaces. It overrides any interface level passive mode.OSPF shall not form adjacencies over a passive interface.

Syntax

passive-interface default no passive-interface default

Default Setting

Disabled

Command Mode

Router OSPFv3 Config.

8.4.2.36 passive-interface

Use this command to set the interface or tunnel as passive. It overrides the global passive mode that is currently effective on the interface or tunnel.

Syntax

passive-interface {< slot/port> | default | tunnel <tunnel-id> | vlan <vlan-id>} no passive-interface {< slot/port> | default | tunnel <tunnel-id> | vlan <vlan-id>}

Default Setting

Disabled

Command Mode

8.4.2.37 redistribute

This command configures the OSPFv3 protocol to allow redistribution of routes from the specified source protocol/routers.

Syntax

redistribute {static | connected} [metric <0-16777214>] [metric-type {1 | 2}] [tag <0-4294967295>] no redistribute { static | connected} [metric] [metric-type] [tag]

<0-16777215> - The range of metric is 0 to 16777214.

<0-4294967295> - The range of tag is 0 to 4294967295.

Default Setting

Metric is unspecified.

Type is 2.

Tag is 0.

Command Mode

Router OSPFv3 Config

8.4.2.38 router-id

This command sets a 4-digit dotted-decimal number uniquely identifying the router ospf id.

Syntax			
router-id	<ipaddress></ipaddress>		

<ipaddress> - IP Address.

Default Setting

None

Command Mode

8.5 **RIPng Commands**

RIPng is intended to allow routers to exchange information for computing routes through an IPv6-based network. RIPng is a distance vector protocol. RIPng should be implemented only in routers. Any router that uses RIPng is assumed to have interfaces to one or more networks, otherwise it isn't really a router. These are referred to as its directly-connected networks. The protocol relies on access to certain information about each of these networks, the most important of which is its metric. The RIPng metric of a network is an integer between 1 and 15, inclusive. It is set in some manner not specified in this protocol; however, given the maximum path limit of 15, a value of 1 is usually used. Implementations should allow the system administrator to set the metric of each network. In addition to the metric, each network will have an IPv6 destination address prefix and prefix length associated with it. These are to be set by the system administrator in a manner not specified in this protocol.

8.5.1 Show Commands

8.5.1.1 show ipv6 rip

This command displays information relevant to the RIPng router

Syntax

show ipv6 rip

Default Setting

None

Command Mode

Privileged Exec

Display Messages

RIPng Admin Mode: Select enable or disable from the pulldown menu. If you select enable RIPng will be enabled for the switch. The default is disabled.

Split Horizon Mode: Select none, simple or poison reverse from the pulldown menu. Split horizon is a technique for avoiding problems caused by including routes in updates sent to the router from which the route was originally learned. The options are: None - no special processing for this case. Simple - a route will not be included in updates sent to the router from which it was learned. Poisoned reverse - a route will be included in updates sent to the router from which it was learned, but the metric will be set to infinity. The default is simple.

Default Metric: Sets a default for the metric of redistributed routes. This field displays the default metric if one has already been set or blank if not configured earlier. The valid values are (1 to 15).

Default Route Advertise: The default route.

Distance: Configured value.

Update Time: Configured value.

Garbage Time: Configured value.

Info Time: Configured value.

Enable Ripng of interfaces: List all interfaces enabled RIPng.

Enable passive mode of interfaces: List all interfaces enabled RIPng passive.

8.5.2 Configuration Commands

8.5.2.1 enable

This command resets the default administrative mode of RIPng in the router (active).

Syntax	
enable no enable	
no enable	le

no - This command sets the administrative mode of RIPng in the router to inactive.

Default Setting

Enabled

Command Mode

IPv6 Router RIP Config

8.5.2.2 ipv6 rip

This command enables RIPng on a router interface.

Syntax	
ipv6 rip no ipv6 rip	
no ipv6 rip	р

no - This command disables RIPng on a router interface.

Default Setting

Disabled

Command Mode

Interface Config

8.5.2.3 ipv6 router rip

Use this command to enter Router RIPng mode.

_
Syntax
SVIILAX

Г

ipv6 router rip

Default Setting

Disabled

Command Mode

Global Config

8.5.2.4 default-information originate

This command is used to set the advertisement of default routes.

Syntax

default-information originate no default-information originate

no - This command is used to cancel the advertisement of default routes.

Default Setting

Disabled

Command Mode

8.5.2.5 default-metric

This command is used to set a default for the metric of distributed routes.

Syntax			
default-me no default	etric <1-15> t-metric		

<1-15> - a value for default-metric.

no - This command is used to reset the default metric of distributed routes to its default value.

Default Setting

Not configured

Command Mode

IPv6 Router RIP Config

8.5.2.6 distance rip

This command sets the route preference value of RIPng in the router. Lower route preference values are preferred when determining the best route.

Syntax				
distance	distance rip <1-255>			
no distan	no distance rip			

<1-255> - the value for distance.

no - This command sets the default route preference value of RIPng in the router.

Default Setting

15

Command Mode



8.5.2.7 split-horizon

This command sets the RIPngplit horizon mode. None mode will not use RIPngplit horizon mode. Simple mode will be that a route is not advertised on the interface over which it is learned. Poison mode will be that routes learned over this interface should be re-advertised on the interface with a metric of infinity (16).

Syntax

split-horizon {none | simple | poison} no split-horizon

none - This command sets without using RIPngplit horizon mode.

simple - This command sets to use simple split horizon mode.

poison - This command sets to use poison reverse mode.

no - This command cancel to set the RIPngplit horizon mode and sets none mode.

Default Setting

Simple

Command Mode



8.5.2.8 redistribute

This command configures RIPng protocol to redistribute routes from the specified source protocol/routers. Source protocols have OSPF, Static, and Connetced.

-	
Sv	ntax

Format for OSPF as source protocol: redistribute ospf [metric <1-15>] *Format for other source protocols:* redistribute {static | connected} [metric <1-15>] no redistribute {ospf | static | connected} [metric]

<1 - 15> - a value for metric.

no - This command de-configures RIPng protocol to redistribute routes from the specified source protocol/routers.

Default Setting

Metric – not-configured

Command Mode



8.5.2.9 ipv6 rip timer

The user can go to the CLI Global Configuration Mode to set ipv6 rip timer, use the **ipv6 rip timer {update|garbage|info} <5-2147483647>** global configuration command. Use the **no ipv6 rip timer {update|garbage|info}** return to the default value.

Syntax

ipv6 rip timer {update|garbage|info} <5-2147483647> no ipv6 rip timer {update|garbage|info}

update - This command sets to the RIPng update time.

garbage - This command sets to the RIPng garbage time.

info - This command sets to the RIPng info time.

no - This command sets the RIPng timer to default value.

Default Setting

update - the default value is 30 (seconds)

garbage - the default value is 120 (seconds)

info - the default value is 180 (seconds)

Command Mode

Global Config



8.5.2.10 ipv6 rip passive-interface

The user can go to the CLI Interface Configuration Mode to set ipv6 rip passive, use the **ipv6 rip passive-interface** interface configuration command. Use the **no ipv6 rip passive-interface** return to the default value.

C.	ntax
Зy	max

ipv6 rip passive-interface no ipv6 rip passive-interface

no - This command sets the RIPng timer to default value.

Default Setting

Disabled

Command Mode

Interface Config

8.6 Routing Policy Commands

8.6.1 Show Commands

8.6.1.1 show ip6 prefix-list

This command displays configuration and status for a prefix list.

Syntax

show ipv6 prefix-list [detail | summary] listname [ipv6-prefix/prefix-length] [seq sequencenumber] [longer] [first-match]

Default Setting

None

Command Mode

Privileged Exec

Parameter

detail | summary: (Optional) Displays detailed or summarized information about all prefix lists.

listname: (Optional) The name of a specific prefix list.

ipv6-prefix/prefixlength: (Optional) The network number and length (in bits) of the network mask.

seq: (Optional) Applies the sequence number to the prefix list entry.

sequence-number: (Optional) The sequence number of the prefix list entry.

longer: (Optional) Displays all entries of a prefix list that are more specific than the given network/length.

first-match: (Optional) Displays the entry of a prefix list that matches the given network/length.

8.6.2 Configuration Commands

8.6.2.1 Ipv6 prefix-list

Use this command to create IPv6 prefix lists. An IPv6 prefix list can contain only ipv6 addresses. Prefix lists allow matching of route prefixes with those specified in the prefix list. Each prefix list includes of a sequence of prefix list entries ordered by their sequence numbers. A router sequentially examines each prefix list entry to determine if the route's prefix matches that of the entry. For IPv6 routes, only IPv6 prefix lists are matched. An empty or nonexistent prefix list permits all prefixes. An implicit deny is assumed if a given prefix does not match any entries of a prefix list. Once a match or deny occurs the router does not go through the rest of the list. An IPv6 prefix list may be used within a route map to match a route's prefix using the match ipv6 address command. A route map may contain both IPv4 and IPv4 prefix lists. If a route being matched is an IPv6 route, only the IPv6 prefix lists are matched.

Up to 128 prefix lists may be configured. The maximum number of statements allowed in prefix list is 64. These numbers indicate only IPv6 prefix lists. IPv4 prefix lists may be configured in appropriate numbers independently.

To delete a deletes either the entire prefix list or an individual statement from a prefix list, use the **no** form of this command. The description must be removed using the no ip prefix-list description before using this command to delete an IPv6 Prefix List.

Syntax

ipv6 prefix-list list-name [seq seq-number] { {permit/deny} ipv6-prefix/prefix-length [ge ge-value] [le le-value] | description text | renumber renumber-interval first-statement-number} no ipv6 prefix-list <list-name>

Default Setting

No prefix lists are configured by default. When neither the **ge** nor the **le** option is configured, the destination prefix must match the network/length exactly. If the **ge** option is configured without the **le** option, any prefix with a network mask greater than or equal to the **ge** value is considered a match. Similarly, if the **le** option is configured without the **ge** option, a prefix with a network mask less than or equal to the **le** value is considered a match.

Command Mode

Global Config

Parameter

list-name: The text name of the prefix list. Up to 32 characters.

seq number: (Optional) The sequence number for this prefix list statement. Prefix list statements are ordered from lowest sequence number to highest and applied in that order. If you do not specify a sequence number, the system will automatically select a sequence number five larger than the last sequence number in the list. Two statements may not be configured with the same sequence number. The value ranges from 1 to 4,294,967,294.

permit: Permit routes whose destination prefix matches the statement.

deny: Deny routes whose destination prefix matches the statement.

ipv6-prefix/prefix-length: Specifies the match criteria for routes being compared to the prefix list statement. The ipv6-prefix can be any valid IPv6 prefix where the address is specified in hexadecimal using 16-bit values between colons. The prefix-length is the The length of the IPv6

982

QUANTA COMPUTER INC.

prefix, given as a decimal value that indicates how many of the high-order contiguous bits of the address comprise the prefix (the network portion of the address). A slash mark must precede the decimal value.

ge length: (Optional) If this option is configured, specifies a prefix length greater than or equal to the ipv6-prefix/prefix-length. It is the lowest value of a range of the length.

le length: (Optional) If this option is configured, specifies a prefix length less than or equal to the ipv6-prefix/prefix-length. It is the highest value of a range of the length.

description: A description of the prefix list. It can be up to 80 characters in length...

renumber: (Optional) Provides the option to renumber the sequence numbers of the IPv6 prefix list statements with a given interval starting from a particular sequence number. The valid range for renumber-interval is 1 - 100, and the valid range for first-statement-number is 1 - 1000.

8.6.2.2 match ipv6 address

Use this command to configure a route map to match based on a destination prefix. prefix-list prefix-listname identifies the name of an IPv6 prefix list used to identify the set of matching routes. Up to eight prefix lists may be specified. If multiple prefix lists are specified, a match occurs if a prefix matches any one of the prefix lists. If you configure a match ipv6 address statement within a route map section that already has a match ipv6 address statement, the new prefix lists are added to the existing set of prefix lists, and a match occurs if any prefix list in the combined set matches the prefix.

To delete a match statement from a route map, use the **no** form of this command.

Syntax

match ipv6 address prefix-list <prefix-list-name> [prefix-list-name...] no match ipv6 address prefix-list <prefix-list-name> [prefix-list-name...]

Default Setting

No match criteria are defined by default.

Command Mode

Route Map Config

Parameter

prefix-list-name: The name of a prefix list used to identify the set of matching routes. Up to eight prefix lists may be specified.

8.6.2.3 set ipv6 next-hop (BGP)

To set the IPv6 next hop of a route, use the set ipv6 next-hop command in Route Map Configuration mode. When used in a route map applied to UPDATE messages received from a neighbor, the command sets the next hop address for matching IPv6 routes received from the neighbor.

When used in a route map applied to UPDATE messages sent to a neighbor, the command sets the next hop address for matching IPv6 routes sent to the neighbor. If the address is a link local address, the address is assumed to be on the interface where the UPDATE is sent or received. If the command specifies a global IPv6 address, the address is not required to be on a local subnet.

To remove a set command from a route map, use the **no** form of this command.

Syntax

set ipv6 next-hop <ipv6-address> no set ipv6 next-hop

Default Setting

None.

Command Mode

Route Map Config

Parameter

Ipv6-address: The IPv6 address set as the Network Address of Next Hop field in the MP_NLRI attribute of an UPDATE message.

8.6.2.4 clear ipv6 prefix-list

Use this command to reset and clear IPv6 prefix-list hit counters. The hit count is a value indicating the number of matches to a specific prefix list entry.

Syntax

clear ipv6 prefix-list [prefix-list-name] [ipv6-prefix/prefix-length]

Command Mode

Privileged Exec

Parameter

prefix-list-name: (Optional) Name of the prefix list from which the hit count is to be cleared.

ipv6-prefix/prefixlength: (Optional) IPv6 prefix number and length (in bits) of the network mask. If this option is specified, hit counters are only cleared for the matching statement.

9 Data Center Bridging Commands

9.1 FIP Snooping

9.1.1 show dcb fip-snooping

This command displays fip-snooping whether enable or disable.

Syntax

show dcb fip-snooping

Default Setting

None

Command Mode

Privileged Exec

Display Message

FIP Snooping: fip-snooping function status.

9.1.2 show fip-snooping enode

This command displays the ENode connections for the entire system.

Syntax

show dcb fip-snooping enode

Default Setting

None

Command Mode

Privileged Exec

Display Message

ENode MAC: MAC address of the ENode.

ENode Interface Number: Name of the interface to which the ENode is connected.

VLAN ID: ID number of the VLAN to which the ENode belongs. ENode Name ID: Name ID.



9.1.3 show dcb fip-snooping session

This command displays all FIP snooping sessions for the entire system.

Syntax	
Syntax	

show dcb fip-snooping session

Default Setting

None

Command Mode

Privileged Exec

Display Message

VN Port MAC: FCoE MAC address that is used to send the FCoE packets.

FCF Interface Number: The interface to which the FCF is connected

FCF MAC address: MAC address of the FCF..

ENode MAC address: MAC address of the ENode.

ENode Interface Number: The interface to which the ENode is connected



9.1.4 show dcb fip-snooping fcf

This command displays to what interfaces the FCFs are connected for the entire system.

Syntax	
SVNtax	

show dcb fip-snooping fcf

Default Setting

None

Command Mode

Privileged Exec

Display Message

FCF MAC: MAC address of the FCF.

FCF Interface Number: Name of the interface to which the FCoE Forwarder (FCF) is connected.

VLAN ID: ID number of the VLAN to which the FCF belongs.

FC MAP: May FC-Map value used by the FCF.

Switch Name: Name ID.

Fabric Name: Name of the FCF.

9.1.5 show dcb fip-snooping vlan

This command displays FIP snooping whether enable or disable on specific VLAN.

Syntax	
Syntax	

show dcb fip-snooping vlan {< 1-4093> | all}

<1 - 4093> - VLAN ID.

all - This command represents all interfaces.

Default Setting

None

Command Mode

Privileged Exec

Display Message

Vian ID: fip-snooping function status on the specific VLAN.

9.1.6 fip-snooping

The FIP snooping function is disabled by default. Only after enabling it, are the FIP related CLIs under VLAN and interface mode visible. The FIP-snoop process also starts after the "fip-snooping" command is enabled. Once the feature is enabled, the FIP-snoop packets and FCoE packets are dropped, unless explicitly enabled on a per-VLAN basis. If FIP snooping is enabled, all the FIP frames are snooped and security ACLs are added. FCoE traffic is blocked on all ports until the device re-initializes with FIP. If the feature is disabled, snooping is removed and all programmed ACLs and internal data are cleaned up.

Syntax		
fip-snooping		
no fip-snoopi	ing	

no - This command disables fip snooping function.

Default Setting

Disabled

Command Mode

DCB (Data Center Bridging) Config



9.1.7 fip-snooping vlan

This command enables FIP snooping on a VLAN. VLAN must be configured before it can be used. Once VLAN is enabled, the FIP packets will be snooped only on the configured VLANs. FIP snooping is disabled on VLANs by default.

fip-snooping vlan <1-4093>

no fip-snooping vlan <1-4093>

<1 - 4093> - VLAN ID.

no - This command disable snooping on a specific VLAN.

Default Setting

Disabled

Command Mode

DCB (Data Center Bridging) Config

GUANTA COMPUTER INC.

9.2 Priority-based Flow Control

9.2.1 show dcb priority-flow-control

Display the PFC information of a given interface or all interface.



show dcb priority-flow-control {<interface> | all }

Default Setting

None

Command Mode

Privileged Exec

9.2.2 priority-flow-control mode

Set Priority-Flow-Control (PFC) to be enabled, disabled, or atuo on the interface.



Both PFC and 802.3x flow control are enabled, PFC will take effect.

Syntax	
priority-flo	ow-control mode { on auto}
no priority	y-flow-control mode

no - This command auto the Priority-Flow-Control (PFC) on the interface.

Default Setting

Auto

Command Mode

DCB (Data Center Bridging) interface mode



9.2.3 priority-flow-control priority

Enable or disable the priority group for lossless (no-drop) or lossy (drop) behavior on the selected interface.

Syntax

priority-flow-control priority <priority_id> { drop | no-drop }

no priority-flow-control priority

Default Setting

The default behavior for priority(3,4,5,6) are no-drop

Command Mode

DCB (Data Center Bridging) interface mode

9.2.4 clear priority-flow-control statistics

Clear all global and interface PFC statistics

Syntax

clear priority-flow-control statistics

Command Mode

Privileged EXEC

9.3 Enhanced Transmission Selection (ETS)

9.3.1 show dcb ets classofservice traffic-class-group

This command displays ETS classofservice traffic-class-group.

Syntax

show dcb ets classofservice traffic-class-group [<slot/port>]

<slot/port> - Interface number.

Default Setting

None

Command Mode

Privileged Exec

Display Message

Traffic Class: The Traffic Class can range from 0-7, although the actual number of available traffic classes depends on the platform.

Traffic Class Group: The Traffic Class Group can range from 0-7, although the actual number of available traffic classes depends on the platform..

9.3.2 show dcb ets traffic-class-group

This command displays ETS traffic-class-group.

Syntax

show dcb ets traffic-class-group [<slot/port>]

<slot/port> - Interface number.

Default Setting

None

Command Mode

Privileged Exec

Display Message

Interface: The slot/port of the interface.

Traffic Class Group: The Traffic Class Group identifier.

Min. Bandwidth: The minimum transmission bandwidth, expressed as a percentage. A value of zero means bandwidth is not guaranteed and the TCG operates using best-effort.

Max. Bandwidth: The maximum transmission bandwidth, expressed as a percentage. A value of zero means no upper limit is enforced, so the queue may use any or all of the available bandwidth of the interface.

Weight: The weight of the TCG used during non-strict scheduling.

Scheduler Type: Indicates whether this queue is scheduled for transmission using a strict priority or a weighted scheme.



9.3.3 ets classofservice traffic-class-group

Use the ets classofservice traffic-class-group command to map the internal Traffic Class Group.

Syntax	
Syntax	

ets classofservice traffic-class-group <0-7> <0-2>

- <0 7>: Traffic Class number.
- <0 2>: Traffic Class Group number.

Default Setting

None

Command Mode

Data-Center-Bridging Interface Mode

9.3.4 ets traffic-class-group max-bandwidth

Use the ets traffic-class-group max-bandwidth command to specify the maximum transmission bandwidth limit for each Traffic Class Group.

ets traffic-class-group max-bandwidth <bw-0> <bw-1> <bw-2>

<bw-0>: The maximum bandwidth percentage for TCG 0.

<bw-1>: The maximum bandwidth percentage for TCG 1.

<bw-2>: The maximum bandwidth percentage for TCG 2.

Default Setting

None

Command Mode

Data-Center-Bridging Interface Mode



9.3.5 ets traffic-class-group min-bandwidth

Use the ets traffic-class-group min-bandwidth command to specify the minimum transmission bandwidth guarantee for each Traffic Class Group.

Syntax	
Syntax	

ets traffic-class-group min-bandwidth <bw-0> <bw-1> <bw-2>

<bw-0>: The minimum bandwidth percentage for TCG 0.

<bw-1>: The minimum bandwidth percentage for TCG 1.

<bw-2>: The minimum bandwidth percentage for TCG 2.

Default Setting

None

Command Mode

Data-Center-Bridging Interface Mode

9.3.6 ets traffic-class-group strict

Use the ets traffic-class-group strict command to activate the strict priority scheduler mode for each Traffic Class Group.

Syntax

ets traffic-class-group strict <TCG-id> [<TCG-id>] [<TCG-id>]

< TCG ID >: The number of TCG ID from 0 to 2.

Default Setting

None

Command Mode

Data-Center-Bridging Interface Mode

996

9.3.7 ets traffic-class-group weight

Use the ets traffic-class-group weight command to specify the weight for each interface Traffic Class Group.

Syntax

ets traffic-class-group weight < wp-0> <wp-1> <wp-2>

<wp-0>: The number of weight for queue 0.

<wp-1>: The number of weight for queue 1.

<wp-2>: The number of weight for queue 2.

Default Setting

None

Command Mode

Data-Center-Bridging Interface Mode

9.4 Ethernet Virtual Bridging

9.4.1 show evb status

This command displays EVB function global parameter on system.

Syntax		
show evb	status	

Default Setting None Command Mode Privileged Exec Display Message Interface: Displays the interface number. Link: Displays the link status of this interface

Admin Mode: Displays the administrative mode of EVB on this interface.

9.4.2 show evb status

This command displays EVB function interface parameter on system.

Cuntar	
Syntax	

show evb status <slot/port>

Default Setting

None

Command Mode

Privileged Exec

Display Message

Admin Mode: Display the administrative mode of this interface

Remote Sync: Displays the synchronization status

Support Capability: Displays the support capabilities of EVB on this interface.

Configure Capability: Displays the configured capabilities of EVB on this interface.

Support Mode: Display the support mode of EVB on this interface.

Configure Mode: Display the configured mode of EVB on this interface.

Configure RTE: Display the configured RTE of EVB on this interface.

Current RTE: Display the current RTE of EVB on this interface.



9.4.3 show evb vsi-profile

This command displays VSI profile paramters on system.

Cuntor	
Syntax	

show evb vsi-profile [<slot/port> | detailed <slot/port>]

Default Setting

None

Command Mode

Privileged Exec

Display Message

Interface: Display the interface number.

Instance ID: Displays the instance ID of the VSI profile.

MAC address: Displays the MAC address of VSI profile.

VLAN: Displays the VLAN information of VSI profile.

9.4.4 evb enable

This command sets the administrative mode of EVB for an interface.

Syntax			
evb enab			
no evb er	nable		

no - This command sets administrative mode to disable for the interface.

Default Setting

Disabled

Command Mode

Interface Config



9.4.5 evb rte

This command sets the Retransmission Timer Exponent of EVB for an interface.

Syntax	
evb rte <1 no evb rte	

<16-31>: Retransmission timer Exponent (RTE) ranged from 16 to 31.

no - This command sets RTE to default setting.

Default Setting

16

Command Mode

Interface Config

9.5 VM Tracer Commands

9.5.1 Show Commands

9.5.1.1 show vmtracer interface

This command displays VM Tracer interface mode on all interfaces or the VM interface (Vnics) that are on the specific switch interface where the VM Tracer interface mode is enabled.

Syntax

show vmtracer interface [<slot/port>]

<slot/port> - show the VM interface (Vnics) that are on the <slot/port> where the VMTracer interface mode is enabled.

Default Setting

None

Command Mode

Privileged Exec

Display Message

Port: the physical interface number of the device.

VM Tracer: the VM Tracer interface mode state. The value should be Enable or Disable.

VM Name: the name of attached VM.

VM Adapter: the adapter name of the VM interface.

VLAN: the VLAN value of the VM interface.

9.5.1.2 show vmtracer session

This command displays information about a specified VM Tracer session on the system.

Syntax
Syntax

show vmtracer session [<name>]

<name> - displays the specific configured VM Tracer session with the name.

Default Setting

None

Command Mode

Privileged Exec

Display Message

Session Name: the configured name of the VM Tracer session.
vCenter URL: the url address of vCenter. It should be start with https://.
Username: the login username of vCenter on the VM Tracer session
Password: the login password of vCenter on the VM Tracer session.
AutoVIan: the mode of AutoVIan. The value should be Enable of Disable.
Allow-VIan: allow-vIan list of the VM Tracer session.
Session Status: the link state of the VM Tracer session.

9.5.1.3 show vmtracer vm

The command displays VMs interfaces (Vnics) that are accessible to the switch interfaces where the VM Tracer interface mode is enabled.

Syntax

show vmtracer vm [detail <vm_name>]

<vm_name> - displays information for the specific VM.

Default Setting

None

Command Mode

Privileged Exec

Display Message

VM Name: the name of attached VM.

VM Adapter: the adapter name of the VM interface.

Interface: the associated switch interface of attached VM.

VLAN: the VLAN value of the VM interface.

Vnic: the adapter name of the VM interface.

Mac: the network mac address of vnic.

Portgroup: the portgroup of the VM.

Vlan: the vlan value of the VM interface.

Switch: the vSwitch of the VM.

Host: the host of the VM.

9.5.1.4 show vmtracer host

The command displays information about the hosts associated to the VM Tracer enabled interface.

-	
Syntax	

show vmtracer host

Default Setting

None

Command Mode

Privileged Exec

Display Message

Interface: the associated switch interface of the host device.

Host: the host name

Manufacturer: the manufacture vendor of the host device

Model: the model name of host device.

CPU Speed: the cpu speed of the host device.

CPUs: the number of cpu inside the host device.

CPU Cores: the cpu cores of the host device.

Memory: the memory size of the host device.

9.5.2 Configuration Commands

9.5.2.1 vmtracer session

This command places the switch in vmtracer mode for the specified session. The command creates a new session or loads an existing session for editing.

The switch supports total four VM Tracer sessions.

vmtracer session no vmtracer sess			

no - This command removes a existed VM Tracer session.

<name> - The label assigned to the VM Tracer session.

Default Setting

None

Command Mode

Global Config

When the switch in vmtracer mode, it can configure the following commands:

- allow-vlan
- autovlan disable
- exit (vmtracer mode)
- password (vmtracer mode)
- url
- username (vmtracer mode)

9.5.2.2 allow-vlan

The command specifies the VLANs that may be added when a VM is added or moved from the hypervisor connected to the session specified by the vmtracer mode. By default, all VLANs are allowed.

Sv	ntax
Uyi	ILAA

allow-vlan {<vlan-list> | {add | remove <vlan-list>} | none | all}

<vlan-list> - Enter VLAN IDs in range <1-4093>. Use '-' to specify a range, or ',' to separate VLAN IDs in a list. Spaces and Zeros are not permitted.

<add> - Add VLAN IDs to current allow-vlan list.

<remove> - Remove VLAN IDs from current allow-vlan list.

<none> - Make allow-vlan list to be empty.

<all> - Add all VLAN IDs to current allow-vlan list.

Default Setting

all

Command Mode

VM Tracer Config

1007

9.5.2.3 autovlan disable

This command disable vlan auto provisioning which allows the dynamic assignment and pruning of VLANs when a VM attached to the ESX connected to the switch is created, deleted, or moved to a different ESX host. The autovlan setting controls auto provisioning.

Syntax	
autovlan disable	
no autovlan disable	

no - this command enables vlan auto provisioning.

Default Setting

no autovlan disable

Command Mode

VM Tracer Config

9.5.2.4 password

The command specifies the token that authorizes the username to the vCenter associated with the VM Tracer session.

Syntax

password {0 | 7 <password>}

<0 | **7> -** This command sets encryption level of the password.0 - the password is a clear text string.

7 - the password is an encrypted string.

<password> - text that authenticates the username.

Default Setting

None

Command Mode

VM Tracer Config

9.5.2.5 username

The command identifies the switch's account name on the vCenter server. The switch uses this user name to access vCenter information.

Syntax			
username	e <name></name>		

<name> - vCenter account username. Parameter must match the username configured on the vCenter.

Default Setting

None

Command Mode

VM Tracer Config

9.5.2.6 **url**

The command specifies the vCenter server location that is monitored by the session being edited by the current vmtracer mode. The command must reference a fully formed secure url.

Syntax

url <url_name>

<url_name> - the location value of the vCenter server. Valid formats include IP address (dotted decimal notation) and fully qualified domain name.

Default Setting

None

Command Mode

VM Tracer Config

9.5.2.7 exit

This command returns the switch to Global Configuration mode and enables the VM Tracer session. Changes to the VM Tracer session that were made in vmtracer mode are stored when the mode is exited.

Syntax			
exit			
Default Setting			,

None

Command Mode

VM Tracer Config

9.5.2.8 vmtracer

The command enables vmtracer mode on the interface configuration mode. Interfaces with vmtracer mode enabled send discovery packets to the connected host device.

The no vmtracer command disables vmtracer mode on the configuration mode interface.

Syntax	
vmtracer	
no vmtracer	

no - This command disables VM Tracer mode on the configuration mode interface

Default Setting

Disable

Command Mode

Interface Config

10 OpenFlow Commands

10.1 Show Commands

10.1.1 show openflow instance

This command displays the OpenFlow instance status and configuration information.

Syntax

show openflow < instance-id >

Default Setting

None

Command Mode

Priviledged EXEC

Examples: (Quanta) #show openflow 1

Administrative Mode	Enable
Operational Status	Enabled
Disable Reason	None
IP Address	192.168.2.117
OpenFlow Variant	OpenFlow 1.1
Fail Mode	Fail-Secure
Ignore Legacy Protocol	Disable
Hybrid Mode	

Port List:

0/1-0/3,0/5,0/7-0/8,ch1-ch2,ch4,ch6-ch7

10.1.2 show openflow controller

This command displays the OpenFlow controller configuration information.

Syntax	
--------	--

show openflow <instance-id> configured controller

Default Setting

None

Command Mode

Privileged EXEC

Examples: (Quanta) #show openflow 1 configured controller

IP Address	IP Port	Connection Mode	Connection Status

192.168.2.5	6633	tcp	ACTIVE	N/A

Role

10.1.3 show openflow installed flows

This command displays the installed flows information from OpenFlow Controller.

Syntax

show openflow < instance-id > installed flows

Default Setting

None

Command Mode

Privileged EXEC

Examples: (Quanta) #show openflow 1 installed flows

Flow 000000B type "1DOT0"

Match criteria: Flow table Ingress port	24 : Priority 0/1 : Src MAC	65535 00:00:00:00:00:1 : Dst MAC	00:00:00:00:00:02
VLAN	5 : VLAN	prio 3 : Ether	type 800
IP proto	6 : Src IP	1.1.1.1 : Dst IP	2.2.2.2
Src IP port Actions:	12345 : Dst IP po	rt 80 : TOS	16
Egress port Status:	0/3		
Duration	131 : Idle	125 : installed	in hardware 1

10.1.4 show openflow installed meters

This command displays the installed meters information from OpenFlow Controller.

Syntax

show openflow < instance-id > installed meters

Default Setting

None

Command Mode

Privileged EXEC

Examples:

(Quanta) #do show openflow 1 installed meters

Meter ID..... 6

Number of bands	1
Band type	Drop
Rate for dropping packets	
Size of bursts	4000

Number of flows bound to meter Number of packets in input	
Number of bytes in input	
Duration	274
Band ID	1
Number of packets in band	
Number of bytes in band	41635520
Number of packets out band	
Number of bytes out band	158984768

10.1.5 show openflow table status

This command displays the table information of OpenFlow switch.

Syntax

show openflow <instance-id> table-status

Default Setting

None

Command Mode

Privileged EXEC

Examples:

(Quanta) #show openflow 1 table-status

Flow Table Name	Openflow
Maximum Size	896
Number of Entries	3
Hardware Entries	3
Software-Only Entries	0
Waiting for Space Entries	0
Flow Insertion Count	3
Flow Deletion Count	0
Insertion Failure Count	0
Flow Table Description	The Oper

Flow Table Description...... The Openflow table matches on the packet layer-2 header, including DA-MAC, SA-MAC, VLAN, Vlan priority ether type; layer-3 header, including SRC-IP, DST-IP, IP protocol, IP-TOS; layer-4 header, including UDP/TCP source and dest port, ICMP type, and code; and input port including physical port, LAG port.

10.2 Configuration Commands

10.2.1 OpenFlow Instance

This command enters OpenFlow instance.

Syntax

openflow instance <instance-id>

Default Setting

None

Command Mode

Global Config

10.2.2 OpenFlow Enable/Disable

To configure admin mode of OpenFlow instance.

Syntax	
enable no enable	
no enable)

Default Setting

Disable

Command Mode

OpenFlow Instance Mode

10.2.3 **OpenFlow Controller**

Specify up to five IP addresses to which the switch should establish an OpenFlow Controllers connection. Each command invocation specifies one IP address and connection mode (TCP or TLS). If the IP Port is omitted then the default IP port number 6633 is used. The default connection mode is TLS.

Syntax

controller	<ipaddr> [<portid>] [ssl tcp]</portid></ipaddr>
no control	<pre>ller {<ipaddr> [<portid>] all }</portid></ipaddr></pre>

Default Setting

SSL

Command Mode

OpenFlow Instance Mode

10.2.4 OpenFlow Hybrid Mode

To configure the hybrid OpenFlow.

Syntax

hybridmode {per-vlan | per-port}

Default Setting

None

Command Mode

OpenFlow Instance Mode

10.2.5 **OpenFlow VLAN in Per-VLAN mode instance**

To add/remove VLAN to OpenFlow per-VLAN instance.

Syntax]		
vlan <vlan-list> no vlan <vlan-list></vlan-list></vlan-list>			

Default Setting

None

Command Mode

OpenFlow Instance per-VLAN Mode

10.2.6 **OpenFlow PORT in Per-PORT mode instance**

To add/remove PORT to OpenFlow per-PORT instance.

Syntax

port {<port-list> | port-channel <Chld-List> } no port {<port-list> | port-channel <Chld-List> }

Default Setting

None

Command Mode

OpenFlow Instance per-PORT Mode

10.2.7 **OpenFlow Variant**

To configure the OpenFlow variant of switch. It can choose the OpenFlow 1.0 or OpenFlow 1.1 or OpenFlow 1.2 or OpenFlow 1.3 protocol to connect with Controller.

Syntax

variant { openflow10 | openflow11 | openflow12 | openflow13 }

Default Setting

openflow10

Command Mode

OpenFlow Instance Mode

10.2.8 OpenFlow Fail Mode

To configure the OpenFlow fail mode of connection interruption. It can choose the Fail-Secure or Fail-Standalone mode.

In the case that a switch loses contact with all controllers, the switch should immediately enter either 3 protocol to connect with standalone modet a switch loses contact with only change to switch behavior is that packets and messages destined to the controllers are dropped. Flows should continue to expire according to their timeouts in es destined to the controllers are dropped. Fl the switch processes all packets using the OFPP_NORMAL port; in other words, the switch acts as a legacy Ethernet switch or router.

Syntax		
failmode {	{ secure standalone }	

Default Setting

secure

Command Mode

OpenFlow Instance Mode

10.2.9 OpenFlow ignore-legacy-protocol

To configure the OpenFlow legacy protocol mode. Igore the process of legacy protocol(STP, CDP, LLDP, EAPOL,...)



Syntax

ignore-legacy-protocol no ignore-legacy-protocol

Default Setting

Disable

Command Mode

OpenFlow Instance Mode