

Agilent 16900, 16700 and 16500 Mainframe/Module Compatibility Table

	16900A-series	16700B-series	16700A-series	16600A-series	16505A	16500C	16500B	16500A
16950A	Yes	No	No	No	No	No	No	No
16910A/11A	Yes	No	No	No	No	No	No	No
16760A	Yes ††	Yes †	Yes †	No	No	No	No	No
16753/54/55/56A	Yes	Yes †	Yes †	No	No	No	No	No
16750/51/52B	Yes	Yes †	Yes †	No	No	No	No	No
16750/51/52A	Yes	Yes †	Yes †	No	No	No	No	No
16740/41/42A	Yes	Yes †	Yes †	No	No	No	No	No
16720A	Yes ††	Yes	Yes	No	No	No	No	No
16718/19A	No	Yes	Yes	No	No	No	No	No
16715/16/17A	No	Yes	Yes	No	No	No	No	No
16710/11/12A	No	Yes	Yes	Yes	No	No	No	No
16557D	No	Yes	Yes	Yes	Yes	Yes	Yes	No
16556A/D	No	Yes	Yes	Yes	Yes	Yes	Yes	No
16555A/D	No	Yes	Yes	Yes	Yes	Yes	Yes	No
16554A	No	Yes	Yes	Yes	Yes	Yes	Yes	No
16550A	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes
16542A	No	No	No	No	No	Yes	Yes	Yes
16540/41D	No	No	No	No	No	Yes	Yes	Yes
16540/41A	No	No	No	No	No	Yes	Yes	Yes
16535A	No	No	No	No	Yes	Yes	Yes	No
16534A	No	Yes	Yes	Yes	Yes	Yes	No	No
16533A	No	Yes	Yes	Yes	Yes	Yes	No	No
16532A	No	No	No	No	No	Yes	Yes	Yes
16530/31A	No	No	No	No	No	Yes	Yes	Yes
16522A	No	Yes	Yes	Yes	Yes	Yes	Yes	No
16520/21A	No	No	No	No	No	Yes	Yes	Yes
16517/18A	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes
16515/16A	No	No	No	No	No	Yes	Yes	Yes
16511B	No	No	No	No	No	Yes	Yes	Yes
16510B	No	No	No	No	No	Yes	Yes	Yes
16510A	No	No	No	No	No	Yes	Yes	Yes

† Requires 16700-series software version A.02.70.00 or higher
†† Requires 16900-series software version 03.20.0000 or higher

For 16900 or 16700 series software updates on CD, please visit
<http://software.cos.agilent.com/logicanalyzerSW>

To download 16900 series software, please visit
http://www.agilent.com/find/16900_SW_Download