



NPM




NETWORK POWER MANAGER SPECIAL FOR CABINET
DESIGNATED MODULARIZED AND MULTI-FUNCTIONAL
POWER DISTRIBUTION UNIT FOR CABINET

HI-TECH
Patented products, any fraudulently
copy is strictly forbidden.



NPM *Network Power Manager*

NEW
2012




NPM *Network Power Manager*



NEW
2012





NPM






Main Functions (vertical mount)

- Total current / Voltage monitoring
- Total / Outlet power (kW) monitoring
- Power factor monitoring
- Total / Outlet energy consumption (kWh) metering
- Total / Outlet current monitoring
- Outlet switching
- Outlet time-switching
- Outlet sequential switching
- User defined management
- Log record



Optional components:



Features (vertical mount)

0 U :

Vertical mount, no rack space occupied;

1 U thickness:

Thin and high strength aluminum alloy, do not affect the installation of other devices;

1.5 U width:

Narrow aluminum alloy, easy installation;

2 /Double protection:

Threshold exceeding protection, master circuit breaker protection;

3 access method:

SNMP, Telnet, Web;

4 metering data:

Total and outlet energy consumption (kWh), total and outlet power (kW);

5 function series:

A (Total metered), B (Outlet metered), C (Total metered and Outlet switched), D (Outlet metered and switched), E (Group metered and switched);

6 alarm methods:

E-mail, SNMP trap, indicator on web interface flashes, audible and visible alarm, LCD display flashes and NPM buzzers, SMS alert (not available in some countries);

7 main monitoring data:

Input voltage, total and outlet current, power factor, power (kW) , outlet state, environment state;

8 outlet types:

IEC320 C13, IEC320 C19, NEMA5-15R, NEMA5-20R, GB1002 10A, DIN49440, NFC61-314, BS1363;

9 main controlling functions:

Total current, outlet current, outlet switching, group outlet switching, sequential switching with delay, threshold exceeding alerts, power automatic cut-off when overload occurs, centralized management ;

10 NPM daisy-chain:

10 NPM daisy-chain through serial port connection;

11 sensor ports:

2 temperature and humidity sensor ports on NPM, other sensor ports are on optional modules;

24 outlets at most for 42U rack:

Outlets designed with every 4 on one board, can do customized specification;

32 A Max. load on each phase or circuit:

Voltage 110V, 220V, 380V, Max. 380V with 96A load;

N_x NPM centralized management:


Via CLEVER Manager, administrator or user can do centralized management of thousands of NPM;





Main Functions (horizontal mount)

- Total current / Voltage monitoring
- Total / Outlet power (kW) monitoring
- Power factor monitoring
- Total / Outlet energy consumption (kWh) metering
- Total / Outlet current monitoring
- Outlet switching
- Outlet time-switching
- Outlet sequential switching
- User defined management
- Log record



● **Optional components:**



Features (horizontal mount)

1 U height:

Cold-rolled steel case which occupying 1U rack space;

2 /Double protection:

Threshold exceeding protection, master circuit breaker protection;

3 access method:

SNMP, Telnet, Web;

4 metering data:

Total and outlet energy consumption (kWh), total and outlet power (kW);

5 outlet types:

IEC320 C13, IEC320 C19, NEMA5-15R, NEMA5-20R, NBR14136;

6 alarm methods:

E-mail, SNMP trap, indicator on web interface flashes, audible and visible alarm, LCD display flashes and NPM buzzers, SMS alert (not available in some countries);

7 main monitoring data:

Total voltage, total and outlet current, power factor, power (kW), outlet state, environment state;

8 outlets on the front:

8 outlets on the front, 4 outlets on the rear, Max. 12 outlets ;

9 main controlling functions:

Total current, outlet current, outlet switching, outlet time-switching, sequential switching with delay, temperature and humidity monitoring, threshold exceeding alerts, power automatic cut-off when overload occurs, centralized management ;

10 NPM daisy-chain:

10 NPM daisy-chain through serial port connection;

32 A Max. load:

Voltage 110V, 220V, Max. 32A load;

N x NPM centralized management:

Via CLEVER Manager, administrator or user can do centralized management of thousands of NPM;



front



front

NPM7000/8000 (vertical mount) function parameters list 1









Main Functions		Details	Function levels				
			Monitor		Control		
			A	B	C	D	E
Monitor		Total load current	•	•	•	•	•
		Input voltage	•	•	•	•	•
		Total energy consumption (kWh)	•	•	•	•	•
		Total power (kW) and power factor	•	•	•	•	•
		Outlet power (kW)		•		•	
		Group outlet power (kW)					•
		Group outlet load current					•
		Outlet load current		•		•	
		Group outlet state					•
		Outlet state (on/off)		•	•	•	
		System operating state (RUN indicator)	•	•	•	•	•
		Temperature and humidity state	•	•	•	•	•
		Smoke occurs or not	•	•	•	•	•
		Water-logging occurs or not	•	•	•	•	•
		Door opened or closed	•	•	•	•	•
Control		Outlet switching			•	•	
		Group outlet switching					•
		Set the delay of outlet sequential switching			•	•	
		Set the delay of group outlet sequential switching					•
		Set the automatic switching time of outlet			•	•	
		Set the automatic switching time of group outlet					•
		Set to cut off power or not when overload occurs				•	•
Keep the former state		Keep the former state of group or individual outlet after reset			•	•	•
Automatic alarm	User defined alarm	Threshold of total load current	•	•	•	•	•
		Threshold of group outlet load current					•
		Threshold of outlet load current		•		•	
		Threshold of temperature and humidity	•	•	•	•	•
	System automatic alarm	Threshold of total load current is exceeded	•	•	•	•	•
		Threshold of group outlet load current is exceeded					•
		Threshold of outlet load current is exceeded		•		•	
		Smoke occurs	•	•	•	•	•
		Water logging occurs	•	•	•	•	•
	Door opening	•	•	•	•	•	
Energy consumption metering		Record the total energy consumption (kWh)	•	•	•	•	
		Record the energy consumption of group outlet					•
		Record the energy consumption of individual outlet		•		•	
Alarm	RUN indicator on controlling panel flashes and buzzer sounds						
	Indicator on Web interface flashes						
	Send Email to administrator automatically						
	Send SMS to administrator (not available in some countries)						
	SNMP send Trap alarm information						
	Logical port outputs level signal (RJ11 port, < 50VDC)						



NPM7000/8000 (vertical mount) function parameters list 2

Main Functions	Details
Daisy-chain	10 NPM for daisy-chain (< 5 is suggested)
Log record	Record and save the operation and alarm information which can be checked and output
Time synchronization	SNTP to realize network time synchronization
User management	Different user permission configuration
	Outlet alarm permission configuration
	Set the permission to clear the energy consumption (kWh) number
Accessing method	Web, access via IE
	SNMP V1, V2 support
	Telnet, SSH (optional)
Software system	Multi-user operation system, support software upgrade

NPM7000/8000 (vertical mount) function parameters list 3

Main Functions	Details	Parameters	
		NPM7000	NPM8000
Input characteristics	Rated input voltage	110/220VAC 50/60 Hz	380VAC 50/60 Hz
	Max. load current	32A	3X32A
	Cable specification	3×2.5mm ² , 3×6.0mm ²	5×2.5mm ² , 5×6.0mm ²
	Cable length	2.5M	2.5M
Output characteristics	Rated output voltage	110/220VAC	220VAC
	Outlet standard	 IEC320 C13  IEC320 C19  DIN49440  NF C61-314  NEMA 5-15R  NEMA 5-20R  GB1002  BS1363	
	Outlet specification	The standard outlet number is 12, 16, 20 or 24 for A, B, C, D series The standard outlet is 2, 3, 4 or 5 groups for E series. *Standard combination of each group is 5 x IEC320 C13 + 1 x IEC320 C19 *Can produce customized products if standard version cannot meet specific requirement	
	Outlet safety device	IEC320 C13 is patented outlet with anti-fall device to lock C14 plug	
	Sensor port	T/H1, T/H2	
	Logical port	Alarm	
	Product dimension	L: subject to actual length W: 66.6mm H: 44.4mm	
Physical properties	Case material	Aluminum	
	Case color	Black, with surface spray coating treatment	
	Mounting method	Both ends installation with brackets or rear button mounting	
	Factory standard fittings	User Manual, 2 x RJ 45 network wire	
	Working environment	Temperature: 0 - +55°C Relative humidity: 5-95%	
Environment characteristics	Storage environment	Temperature: -20- +60°C Relative humidity: 5-95%	
	Optional functions	Master circuit breaker module	
Rear button mounting			
Terminal block		Connect optional cables and connectors	
Centralized management		Via CLEVER Manager to realize centralized monitoring, controlling and management of thousand of NPM	
Sensor port expanding		Sensor ports module: T/H 3, T/H 4, T/H5	
	Sensor ports module: T/H 6, Smoke, Water		
	Sensor ports module: Door 1, door 2, T/H7		






NPM

NPM6000 (horizontal mount) function parameters list 1


Main Functions		Details	Function levels			
			Monitor		Control	
			A	B	C	D
Monitor		Total load current	●	●	●	●
		Input voltage	●	●	●	●
		Total energy consumption (kWh)	●	●	●	●
		Total power (kW) and power factor	●	●	●	●
		Outlet power (kW)		●		●
		Outlet load current		●		●
		Outlet state (on/off)		●	●	●
		System operating state (RUN Indicator)	●	●	●	●
		Temperature and humidity state	●	●	●	●
Control		Outlet switching			●	●
		Set the delay of outlet sequential switching			●	●
		Set the automatic switching time of outlet			●	●
		Set to cut off power or not when overload occurs				●
Keep the former state		Keep the former state of group or individual outlet after reset			●	●
Automatic alarm	User defined alarm	Threshold of total load current	●	●	●	●
		Threshold of outlet load current		●		●
		Threshold of temperature and humidity	●	●	●	●
	System automatic alarm	Threshold of total load current is exceeded	●	●	●	●
		Threshold of outlet load current is exceeded		●		●
Energy consumption metering		Record the total energy consumption (kWh)	●	●	●	●
		Record the energy consumption of individual outlet		●		●
Alarm		RUN indicator on controlling panel flashes and buzzer sounds				
		Indicator on Web interface flashes				
		Send Email to administrator automatically				
		Send SMS to administrator (not available in some countries)				
		SNMP sends Trap alarm information				
		Logical port outputs level signal (RJ11 port, < 50VDC)				
Log record		10 NPM for daisy-chain (< 5 is suggested)				
Daisy-chain		Record and save the operation and alarm information which can be checked and output				
Time synchronization		SNTP to realize network time synchronization				
User management		Different user permission configuration				
		Outlet alarm permission configuration				
		Set the permission to clear the energy consumption (kWh) number				
Accessing method		Web, access via IE				
		SNMP V1, V2 support				
		Telnet, SSH (optional)				
Software system		Multi-user operation system, support software upgrade				



NPM6000 (horizontal mount) function parameters list 2

Main Functions	Details	Parameters
		NPM6000
Input characteristics	Rated input voltage	110/220VAC 50/60 Hz
	Max. load current	32A
	Cable specification	3×2.5mm ² , 3×6.0mm ²
	Cable length	2.5M
Output characteristics	Rated output voltage	110/220VAC
	Outlet standard	     IEC320 C13 IEC320 C19 NEMA 5-15R NEMA 5-20R NBR14136
	Outlet number	8 12 (8 on the front, 4 on the rear)
	Outlet safety device	IEC320 C13 with anti-fall device to lock C14 plug
	Sensor port	T/H1, T/H2
	Logical port	Alarm
Physical properties	Product dimension	L: 482.6mm W: 216mm H: 44.4mm
	Case material	Cold-rolled steel case
	Case color	Black, with surface spray coating treatment
	Mounting method	Both ends installation with brackets
	Factory standard fittings	User Manual, 2 x RJ 45 network wire
Environment characteristics	Working environment	Temperature: 0 - +55°C Relative humidity: 5-95%
	Storage environment	Temperature: -20- +60°C Relative humidity: 5-95%
Optional functions	Master circuit breaker	
	Input	Connect optional cables and connectors
	Centralized management	Via CLEVER Manager to realize centralized monitoring, controlling and management of thousands of NPM


NPM



6.1 NPM7000/8000 A series

Remote monitoring functions:

- Total load current;
- Input voltage;
- Total energy consumption (kWh) ;
- Total power (kW) and power factor;
- System running state;
- Temperature and humidity state ;
- Smoke occurs or not;
- Water logging occurs or not;
- Door opened or closed;
- Logical port output;



Typical models

Product code	Socket standard	Outlet quantity	Load current (A)
NA712C1212	IEC320 C13	12	16
NA712H1612	IEC320 C13 / C19	16	16
NA712M2012	NEMA 5-15R	20	16
NA712H2012	NEMA 5-15 / 5-20R	20	16
NA712F2412	NF C61-314	24	16
NA812D1242	DIN49440	12	3×32
NA812B2442	BS1363	24	3×32

Detailed models and specifications, please ask from CLEVER sales or local distributors.


The detailed functions and technical parameters of this series, please refer to form 1 on page 8 and form 2 and 3 on page 9.



6.2 NPM7000/8000 B series

Remote monitoring functions:

- Total load current;
- Input voltage;
- Total energy consumption (kWh) ;
- Outlet energy consumption (kWh);
- Total power (kW) and power factor;
- Outlet power (kW) ;
- Outlet load current
- Outlet state (on/off);
- System running state ;
- Temperature and humidity state ;
- Smoke occurs or not;
- Water logging occurs or not;
- Door opened or closed;
- Logical port output;



NPM

Typical models

Product code	Socket standard	Outlet quantity	Load current (A)
NB712C1212	IEC320 C13	12	16
NB712H1612	IEC320 C13 / C19	16	16
NB712M2012	NEMA 5-15R	20	16
NB712H2012	NEMA 5-15 / 5-20R	20	16
NB712F2412	NF C61-314	24	16
NB812D1242	DIN49440	12	3×32
NB812B2442	BS1363	24	3×32



Detailed models and specifications, please ask from CLEVER sales or local distributors.

The detailed functions and technical parameters of this series, please refer to form 1 on page 8 and form 2 and 3 on page 9.

6.3 NPM7000/8000 C series

Remote monitoring and controlling functions:

- Total load current;
- Input voltage;
- Total energy consumption (kWh);
- Total power (kW) and power factor;
- Outlet state (on/off);
- System running state;
- Temperature and humidity state;
- Smoke occurs or not;
- Water logging occurs or not;
- Door opened or closed;
- Logical port output;
- Outlet switching;
- Set the delay of outlet sequential switching;
- Set the time of outlet automatic switching;



Typical models

Product code	Socket standard	Outlet quantity	Load current (A)
NC712C1212	IEC320 C13	12	16
NC712H1612	IEC320 C13 / C19	16	16
NC712M2012	NEMA 5-15R	20	16
NC712H2012	NEMA 5-15 / 5-20R	20	16
NC712F2412	NF C61-314	24	16
NC812D1242	DIN49440	12	3×32
NC812B2442	BS1363	24	3×32

Detailed models and specifications, please ask from CLEVER sales or local distributors.


The detailed functions and technical parameters of this series, please refer to form 1 on page 8 and form 2 and 3 on page 9.



6.4 NPM7000/8000 D series

Remote monitoring and controlling functions :

- Total load current;
- Input voltage;
- Total energy consumption (kWh) ;
- Outlet energy consumption (kWh) ;
- Total power (kW) and power factor;
- Outlet power (kW);
- Outlet state (on/off);
- System running state;
- Temperature and humidity state ;
- Smoke occurs or not;
- Water logging occurs or not;
- Door opened or closed;
- Logical port output;
- Threshold setting of the outlet current;
- Outlet switching;
- Set the delay of outlet sequential switching;
- Set the time of outlet automatic switching;
- Set whether to cut off power when overload occurs;



NPM

Typical models

Product code	Socket standard	Outlet quantity	Load current (A)
ND711C1212	IEC320 C13	12	16
ND711H1612	IEC320 C13 / C19	16	16
ND712M2012	NEMA 5-15R	20	16
ND712H2012	NEMA 5-15 / 5-20R	20	16
ND714F2412	NF C61-314	24	16
ND812D1242	DIN49440	12	3×32
ND814B2442	BS1363	24	3×32


Detailed models and specifications, please ask from CLEVER sales or local distributors.

The detailed functions and technical parameters of this series, please refer to form 1 on page 8 and form 2 and 3 on page 9.

6.5 NPM7000/8000 E series

Remote monitoring and controlling functions :

- Total load current;
- Input voltage;
- Total energy consumption (kWh);
- Group outlet energy consumption (kWh) ;
- Total power (kW) and power factor;
- Group outlet load current;
- Group outlet state (on/off) ;
- System running state;
- Temperature and humidity state ;
- Smoke occurs or not;
- Water logging occurs or not;
- Door opened or closed;
- Logical port output;
- Threshold setting of group outlet current;
- Group outlet switching ;
- Set the delay of group outlet sequential switching ;
- Set the time of group outlet automatic switching;
- Set whether to cut off power when overload occurs;



Typical models

Product code	Socket standard	Outlet quantity	Load current (A)
NE712C1212	IEC320 C13	12	16
NE712H1612	IEC320 C13 / C19	16	16
NE712M2012	NEMA 5-15R	20	16
NE712H2012	NEMA 5-15 / 5-20R	20	16
NE712F2412	NF C61-314	24	16
NE812D1242	DIN49440	12	3×32
NE812B2442	BS1363	24	3×32

Detailed models and specifications, please ask from CLEVER sales or local distributors.



The detailed functions and technical parameters of this series, please refer to form 1 on page 8 and form 2 and 3 on page 9.

7.1 NPM6000 A series



Remote monitoring functions:

- Total load current;
- Input voltage;
- Total energy consumption (kWh);
- Total power (kW) and power factor;
- System running state;
- Temperature and humidity state ;
- Logical port output;



front



rear

Typical models

Product code	Front		Rear		Load current (A)
	Socket standard	Outlet quantity	Socket standard	Outlet quantity	
NA612C0812	IEC320 C13	8	NO	0	16
NA612M0812	NEMA 5-15R	8	NO	0	16
NA612N0812	NEMA 5-20R	8	NO	0	16
NA612H1212	IEC320 C13	8	IEC320 C19	4	18
NA612H1212	NEMA 5-15R	8	NEMA 5-15R	4	18
NA612H1212	NEMA 5-20R	8	NEMA 5-20R	4	18

Detailed models and specifications, please ask from CLEVER sales or local distributors.


The detailed functions and technical parameters of this series, please refer to form 1 on page10 and form 2 on page11.

7.2 NPM6000 B series



Remote monitoring functions:

- Total load current;
- Input voltage;
- Total energy consumption (kWh);
- Outlet energy consumption (kWh) ;
- Total power (kW) and power factor;
- Outlet power (kW) ;
- Outlet load current
- Outlet state (on/off);
- System running state ;
- Temperature and humidity state ;
- Logical port output;



Typical models

Product code	Front		Rear		Load current (A)
	Socket standard	Outlet quantity	Socket standard	Outlet quantity	
NB612C0812	IEC320 C13	8	NO	0	16
NB612M0812	NEMA 5-15R	8	NO	0	16
NB612N0812	NEMA 5-20R	8	NO	0	16
NB612H1212	IEC320 C13	8	IEC320 C19	4	16
NB612H1212	NEMA 5-15R	8	NEMA 5-15R	4	16
NB612H1212	NEMA 5-20R	8	NEMA 5-20R	4	16

Detailed models and specifications, please ask from CLEVER sales or local distributors.

The detailed functions and technical parameters of this series, please refer to form 1 on page10 and form 2 on page11.





7.3 NPM6000 C series



Remote monitoring and controlling functions:

- Total load current;
- Input voltage;
- Total energy consumption (kWh);
- Total power (kW) and power factor;
- Outlet state (on/off);
- System running state;
- Temperature and humidity state ;
- Logical port output;
- Outlet switching ;
- Set the delay of outlet sequential switching;
- Set the time of outlet automatic switching;



front



rear

NPM

Typical models

Product code	Front		Rear		Load current (A)
	Socket standard	Outlet quantity	Socket standard	Outlet quantity	
NC612C0812	IEC320 C13	8	NO	0	16
NC612M0812	NEMA 5-15R	8	NO	0	16
NC612N0812	NEMA 5-20R	8	NO	0	16
NC812H1212	IEC320 C13	8	IEC320 C19	4	18
NC812H1212	NEMA 5-15R	8	NEMA 5-15R	4	18
NC812H1212	NEMA 5-20R	8	NEMA 5-20R	4	18

Detailed models and specifications, please ask from CLEVER sales or local distributors.

The detailed functions and technical parameters of this series, please refer to form 1 on page10 and form 2 on page11.

7.4 NPM6000 D series



Remote monitoring and controlling functions:


- Total load current;
- Input voltage;
- Total energy consumption (kWh);
- Outlet energy consumption (kWh) ;
- Total power (kW) and power factor;
- Outlet power (kW);
- Outlet state (on/off);
- System running state;
- Temperature and humidity state ;
- Logical port output;
- Set the threshold of outlet current;
- Outlet switching ;
- Set the delay of outlet sequential switching ;
- Set the time of outlet automatic switching;
- Set whether to cut off power when overload occurs;



front



rear



Typical models

Product code	Front		Rear		Load current (A)
	Socket standard	Outlet quantity	Socket standard	Outlet quantity	
ND612C0812	IEC320 C13	8	NO	0	16
ND612M0812	NEMA 5-15R	8	NO	0	16
ND612N0812	NEMA 5-20R	8	NO	0	16
ND612H1212	IEC320 C13	8	IEC320 C19	4	16
ND612H1212	NEMA 5-15R	8	NEMA 5-15R	4	16
ND311H1212	NEMA 5-20R	8	NEMA 5-20R	4	16

Detailed models and specifications, please ask from CLEVER sales or local distributors.

The detailed functions and technical parameters of this series, please refer to form 1 on page10 and form 2 on page11.



● Some NPM examples with optional modules



NPM

● Some optional accessories



CATALOGUE


1. 2012 NEW NPM	2
2. NPM (vertical mount)	4
2.1 NPM (vertical mount) functions	4
2.2 NPM (vertical mount) features.....	5
3. NPM (horizontal mount)	6
3.1 NPM (horizontal mount) functions.....	6
3.2 NPM (vertical mount) features	7
4. NPM (vertical mount) function parameters list	8
5. NPM (horizontal mount) function parameters list	10
6. NPM (vertical mount) 7000/8000 series	12
7. NPM (horizontal mount) 6000 series	17
8. Some NPM examples with optional modules	21
9. Some optional accessories	21

To meet with EU directive, all materials and electronic components of CLEVER NPM are RoHS approved.

All rights reserved. Contents are subject to change without prior notices. The pictures are for indication only, subject to the final product.



Network Power Manager



**Patented products, any
fraudulently copy is
strictly forbidden.**



SHENZHEN CLEVER ELECTRONIC CO., LTD.

ADD: 25D/3, Citysunlight No.6017 Shennan Rd. Shenzhen China
Factory: 1&3, Lhe Industrial, Shenzhen China

Tel: +86-755-8179 5396 8179 5326 +86-10-82176022

Fax: +86-755-8204 7966 8179 5456 Post: 518048

E-mail: clever@china-clever.com <http://www.china-clever.com>

