DIGITAL	FCO	CATEGORY [O]	PAGE 1 OF 4						
FIELD CHANGE	ORDER	NUMBER: 5900-000	)1						
APPLICABILITY in DS5900 ser	: This FCO may be utilized when vers.	n RZ57 disk drives are	e installed						
shipped to cu for these sys will be affec tend to exhib	PROBLEM & SYMPTOM: Approximately 150 RZ57 disk drives were installed in and shipped to customers as part of a DS5900 configuration. There is potential for these systems to experience SCSI bus hangs. Although not all 5900's will be affected, systems with four or more drives on the same SCSI bus tend to exhibit the problem more frequently. The problem will manifest itself as a system hang.								
systems can b	s FCO is being issued so that t e replaced with RZ58 disk drive     	es.							
	At the DS5900 system prompt type message. Check the configuration	•							
PRE/CO-REQUIS	ITE FCO: None		MFIT HRS						
· -	IPMENT: Power-up and console diration of the drive.	iagnostics are all tha	at are needed						
appropriate R	going on site assure that the Z57 drives. Coordinate this act		=						
	FCO PARTS INFORMA	ATION							
FCO KIT NO.	DESCRIPTION OF CONTENT	TS							
EQ-01670-01									
FA-05005-01	05005-01   FCO Document								
	FCO CHARGING INFORMATION (S	See Page 4 of 4)							

APPROVALS

TECH. ENGINEER	ENG. BUSINESS MGR.	DSHQ LOGISTICS	DS PRODUCT SAFETY
Joe Amorelli 		Carol Sarasin 	Robert Brister
MICROMEDIA	PARTS AVAILABILITY	FCO REVISION: A	FCO RELEASE DATE
Brenda Rogers	June, 1993		1-JUNE-1993

+						+
d	i	g	i	t	a	1 1
j	İ		İ	İ	İ	i i
+					· 	+

FCO 5900-0001

PAGE 2 OF 3

\*\*\*\*\*\*\*\*\*\*\*\*\*\*\*

NOTE: Before going on site, assure that the Customer has backed up the appropriate RZ57 drives. Coordinate this activity with your customer prior to scheduling the install of this FCO.

\*\*\*\*\*\*\*\*\*
\* CAUTION \*

\*\*\*\*\*

Observe Proper Antistatic Procedures

- 1. Follow site specific system shutdown procedure.
- 2. Disconnect system from power source.
- 4. Refer to Section 4 of the DECsystem 5900 Maintenance
  Manual and follow the procedures for removing the RZ57 storage devices.
- 5. Note the SCSI configuration of the RZ57 that you have removed. Configure the new RZ58 to the same SCSI address.
- 6. Install the new RZ58 into the mass storage drawer in

the same location that you removed the RZ57 from.

- 7. Continue until all RZ57s have been replaced.
- 8. When finished replacing the RZ57s, close the last storage drawer and slide back into the chassis. Slide the stabilizer bar into the chassis as well.
- 9. Reconnect the system power.

+	 	 	 	+	
					FCO 5900-0001
		t			
					PAGE 3 OF 4
+	 	 	 	+	

- 10. Assure that all power up diagnostics complete without failure.
- 11. A device test from the console can be run to assure that the drive(s) can be accessed. Please note that the read-write test is destructive and that all data on the selected drive can be lost.

To run the test on drives connected to the base system SCSI bus enter the following:

Where # = SCSI address 0-6

To run the test on drives connected to Turbochannel SCSI bus option enter the following:

Where X = Turbochannel slot 0,1,2 and # = SCSI address 0-6

NOTE: It is important to select the proper drive because this test

does write on the drive and may corrupt data.

++	
	FCO 5900-0001
d   i   g   i   t   a   l	
	PAGE 4 OF 4
++	
	į

Report this FCO activity on the LARS form in the "Fail Area/Module/FCO/Comments" column as follows: FCO 5900-0001

## LARS

τ	USA	GIA	EUROPE
Activity -			
(a)Contract	W	U	K
Warranty	W	U	W
(b)IN-DEC Contract	K	U	A
Non Contract/Non Warranty	F	F	F
(c)RTD/Off-site Agreement	F	U	F
Hardware Segment Code Product Line	111 031	111	111 031
DEC Option	240TB	240TB	5900
Option ID	X	N/A	N/A
Type of Call	M	M	M
Action Taken	D	D	I/V
Fail Area-Module-FCO-Comments	5900-0001	5900-0001	5900-0001
Material Used	EQ-01670-01	EQ-01670-01	EQ-01670-01

- (a) Warranty Optimum, Warranty Standard and Warranty Basic (on-site)
  Agreements: \* Note material (only) free of charge for all customers.
- (b) Applies to IN-DEC area only
- (c) RTD=Return to Digital or off-site agreements; If Field Engineer on-site, use Activity Code "F".

FCO CHARGING INFORMATION						
WARRANTY/CONTRACT   NONWARRANTY/NONCONTRACT						
ON-SITE	OFF-SITE	ON-SITE	OFF-SITE	MATERIAL ONLY		

TRAVEL/	EQ		EQ	TRAVEL/	EQ		EQ	ORDER-ADMIN, HANDLING
INSTALL	KIT	INSTALL	KIT	INSTALL	KIT	INSTALL	KIT	PKG,SHIPPING & EQ KIT
				.				
DEC	DEC	DEC	DEC	CUS	CUS	CUS	CUS	CUS
İ	İ	İ	İ	.i ii		İI		

\\ FCO\_DOCS 5900 DS5900