

## Multimode to Singlemode



### Features


- Converts Multimode fiber to Singlemode fiber
- Extend links to over 100 km on Singlemode fiber
- Hot swappable
- SNMP managed
- Wide range of protocol support
- Compatible with all the appropriate protocol standards
- Fits in all Fiber Driver chassis

### Overview

The Fiber Driver™ collection of Multimode to Singlemode converters allow network managers to connect between Multimode and Singlemode fiber. Conversion to Singlemode fiber can extend the transmission distance to over 100 km. Protocols covered by this group of modules include Fast Ethernet, FDDI, ESCON, SONET OC-3, ATM OC-3, SONET OC-12, Gigabit Ethernet, and Fibre Channel.

Additional Multimode to Singlemode modules can be found in the group of Repeater modules; Multimode to Single Fiber Singlemode modules can be found in the group of Single Fiber modules.

For additional information, including pricing and availability, contact your MRV Communications sales representative today.



### Physical Specifications: Multimode to Singlemode

<b>Operating Temperature:</b>	0° to 50° C / 32° to 122° F
<b>Storage Temperature:</b>	-10° to 60° C / -14° to 140° F
<b>Relative Humidity:</b>	85% maximum, non-condensing
<b>Physical Dimensions:</b>	25 mm x 75 mm x 175 mm deep (1" x 3" x 7" deep), 1-Slot
<b>Weight:</b>	120 - 240 g (4.2 - 8.5 oz) depending on configuration
<b>Standards Compliance:</b>	FCC-PART 15, SUBPART B 1999, CLASS A. CE MARK - EN 50081-1:1992; EN 50082:1997; EN 55024:1998; EN 55022:1998. AS/NZS 3548:1995

Part Number	Description	Protocol	Connectors* Port/Link	Wavelength Input/Output (nm)	Minimum Loss Budget (dB)	Range** Approx. (km)
EM316FM/S1	Fast Ethernet MM to SM	Fast Ethernet	DSC/DSC	1310 / 1310	17	0 - 35
EM316FM/S2	Fast Ethernet MM to SM	Fast Ethernet	DSC/DSC	1310 / 1310	24	25 - 45
FM316FM/S3	Fast Ethernet MM to SM	Fast Ethernet	DSC/DSC	1310 / 1550	24	35 - 90
FM316FM/S4	Fast Ethernet MM to SM	Fast Ethernet	DSC/DSC	1310 / 1550	29	40 - 110
EM316FD/S1	FDDI MM to SM	FDDI	DSC/DSC	1310 / 1310	17	0 - 35
EM316FD/S2	FDDI MM to SM	FDDI	DSC/DSC	1310 / 1310	24	25 - 45
EM316FD/S3	FDDI MM to SM	FDDI	DSC/DSC	1310 / 1550	24	35 - 90
EM316FD/S4	FDDI MM to SM	FDDI	DSC/DSC	1310 / 1550	29	40 - 110
EM316S/S1	ESCON MM to SM	ESCON	DSC/DSC	1310 / 1310	17	0 - 35
EM316S/S2	ESCON MM to SM	ESCON	DSC/DSC	1310 / 1310	24	25 - 45
EM316S/S3	ESCON MM to SM	ESCON	DSC/DSC	1310 / 1550	24	35 - 90
EM316O3/S1	SONET OC-3 MM to SM	SONET OC-3	DSC/DSC	1310 / 1310	17	0 - 35
EM316O3/S2	SONET OC-3 MM to SM	SONET OC-3	DSC/DSC	1310 / 1310	24	25 - 45
EM316O3/S3	SONET OC-3 MM to SM	SONET OC-3	DSC/DSC	1310 / 1550	24	35 - 90
EM316O3/S4	SONET OC-3 MM to SM	SONET OC-3	DSC/DSC	1310 / 1550	29	40 - 110
EM316A/S1	ATM OC-3 MM to SM	ATM OC-3	DSC/DSC	1310 / 1310	17	0 - 35
EM316A/S2	ATM OC-3 MM to SM	ATM OC-3	DSC/DSC	1310 / 1310	24	25 - 45
EM316A/S3	ATM OC-3 MM to SM	ATM OC-3	DSC/DSC	1310 / 1550	24	35 - 90
EM316A/S4	ATM OC-3 MM to SM	ATM OC-3	DSC/DSC	1310 / 1550	29	40 - 110
EM316O12/S1	SONET OC-12 MM to SM	SONET OC-12	DSC/DSC	1310 / 1310	6	0 - 12
EM316O12/S2	SONET OC-12 MM to SM	SONET OC-12	DSC/DSC	1310 / 1310	18	10 - 35
EM316O12/S3	SONET OC-12 MM to SM	SONET OC-12	DSC/DSC	1310 / 1550	18	30 - 70
EM316G/S1	Gigabit Ethernet MM to SM, SX to LX	Gigabit Ethernet	DSC/DSC	850 / 1310	DL	0 - 10
EM316G/S2	Gigabit Ethernet MM to SM, SX to LX	Gigabit Ethernet	DSC/DSC	850 / 1550	8	0 - 30
EM316G/S3	Gigabit Ethernet MM to SM, SX to LX	Gigabit Ethernet	DSC/DSC	850 / 1550	15	30 - 60
EM316G/S4	Gigabit Ethernet MM to SM	Gigabit Ethernet	DSC/DSC	850 / 1550	20	50 - 80
EM316FC/S1	Fibre Channel MM to SM	Fibre Channel	DSC/DSC	850 / 1310	DL	0 - 10
EM316FC/S2	Fibre Channel MM to SM	Fibre Channel	DSC/DSC	850 / 1550	8	0 - 30
EM316FC/S3	Fibre Channel MM to SM	Fibre Channel	DSC/DSC	850 / 1550	15	30 - 60
EM316FC/S4	Fibre Channel MM to SM	Fibre Channel	DSC/DSC	850 / 1550	20	50 - 80

Ordering Info

\*Default connectors listed, DST optional  
 \*\*Distances are approximate and assume 9µ SM and 62.5µ MM  
 DL= Dispersion Limited

MRV has more than 50 offices throughout the world. Addresses, phone numbers, and fax numbers are listed at [www.mrv.com](http://www.mrv.com). Please e-mail us at [sales@mrv.com](mailto:sales@mrv.com) or call us for assistance.

**MRV (West Coast USA)**  
 20415 Nordhoff St.  
 Chatsworth, CA 91311  
 800-338-5316  
 818-773-0900

**MRV (East Coast USA)**  
 295 Foster St.  
 Littleton, MA 01460  
 800-338-5316  
 978-952-4700

**MRV (International)**  
 Business Park Moerfelden  
 Waldeckerstrasse 13  
 64546 Moerfelden-Walldorf  
 Germany  
 Tel. (49) 6105/2070  
 Fax. (49) 6105/207-100

All statements, technical information and recommendations related to the products herein are based upon information believed to be reliable or accurate. However, the accuracy or completeness thereof is not guaranteed, and no responsibility is assumed for any inaccuracies. Please contact MRV Communications for more information. MRV Communications and the MRV Communications logo are trademarks of MRV Communications, Inc. Other trademarks are the property of their respective holders.