



Security Products

ScreenOS CLI Reference Guide: IPv4 Command Descriptions

Release 6.2.0, Rev. 01

Juniper Networks, Inc.
1194 North Mathilda Avenue
Sunnyvale, CA 94089
USA
408-745-2000
www.juniper.net

Copyright Notice

Copyright © 2008 Juniper Networks, Inc. All rights reserved.

Juniper Networks, the Juniper Networks logo, JUNOS, NetScreen, ScreenOS, and Steel-Belted Radius are registered trademarks of Juniper Networks, Inc. in the United States and other countries. JUNOSe is a trademark of Juniper Networks, Inc. All other trademarks, service marks, registered trademarks, or registered service marks are the property of their respective owners.

All specifications are subject to change without notice. Juniper Networks assumes no responsibility for any inaccuracies in this document or for any obligation to update information in this document. Juniper Networks reserves the right to change, modify, transfer, or otherwise revise this publication without notice.

FCC Statement

The following information is for FCC compliance of Class A devices: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. The equipment generates, uses, and can radiate radio-frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case users will be required to correct the interference at their own expense.

The following information is for FCC compliance of Class B devices: The equipment described in this manual generates and may radiate radio-frequency energy. If it is not installed in accordance with Juniper Networks' installation instructions, it may cause interference with radio and television reception. This equipment has been tested and found to comply with the limits for a Class B digital device in accordance with the specifications in part 15 of the FCC rules. These specifications are designed to provide reasonable protection against such interference in a residential installation. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Consult the dealer or an experienced radio/TV technician for help.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.

Caution: Changes or modifications to this product could void the user's warranty and authority to operate this device.

Disclaimer

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR JUNIPER NETWORKS REPRESENTATIVE FOR A COPY.

Table of Contents

About This Guide	9
Understanding the CLI	13
access-list	17
action-group	19
active-user	21
address	23
admin	25
alarm	35
alg	45
alias	55
all	57
anti-spam	59
arp	65
asic	67
attack	69
attack-db	77
audible-alarm	79
auth	81
auth-server	87
av	97
BGP Commands	113
bgroup	143
bulkcli	145
chassis	149
clock	151
common-criteria	155
config	157
console	161
core-dump	165

counter	167
cpu-limit.....	171
cpu-protection	175
crypto-policy	177
dbuf.....	181
delete.....	183
deny-message.....	185
di.....	187
dip	215
dns	217
domain	225
dot1x	227
envar	229
event	233
exit.....	237
failover	239
file.....	241
fips-mode	243
firewall.....	245
flow	247
group	257
group-expression.....	261
gtp.....	263
hostname	275
icap	277
igmp.....	281
ike	285
ike-cookie	307
infranet	309
interface.....	313
ip.....	387
ip-classification	389
ippool	391
irdp.....	393
key	395
l2tp.....	397

lcd.....	403
led	405
license-key	407
log	411
mac	423
mac-learn	425
mac-learn-sticky.....	427
match-group	429
memory.....	431
management-vroute	433
mip	435
mirror.....	437
modem	439
multicast-group-policy	445
NHRP Commands.....	449
nrtip	453
nsgp	455
nsmgmt.....	457
nsrp.....	463
ntp.....	477
os.....	481
OSPF Commands	483
override	503
password-policy	505
pattern-update	507
pbr	509
performance.....	513
PIM Commands	515
ping	525
pki	527
policy.....	539
ppp	559
pppoa	561
pppoe	565
proxy-id.....	571
reset	573

RIP Commands	575
route.....	593
sa.....	597
sa-filter	599
sa-statistics	601
sat	603
save	605
scheduler	609
scp.....	611
service	613
session	617
shdsl	623
sm-ctx	625
sm-ksh.....	627
snmp.....	631
socket	635
ssh.....	637
ssid	643
ssl.....	649
switch.....	651
syslog.....	653
system	657
task.....	659
tech-support.....	661
telnet.....	663
tftp	665
timer	667
trace-route.....	669
traffic-shaping.....	671
url	673
usb-device	683
user.....	685
user-group.....	691
vip.....	695
vlan	697
vpn	701

	vpn-group	711
	vpnmonitor	713
	vrouter	715
	vrrp.....	731
	vsys.....	733
	vsys-profile.....	739
	webauth.....	745
	webtrends.....	747
	wlan	749
	xauth	757
	zone	761
Appendix A	Interfaces	771
Appendix B	Zones	773

About This Guide

This guide describes the Internet Protocol version 4 (IPv4) commands used to configure and manage a security device from a console interface.

NOTE: If a command is not included in this document, it is not supported for this release of ScreenOS.

Document Organization

This guide includes the following sections:

- Command chapters are listed alphabetically by keyword or topic.
- Appendix A lists and briefly describes security-device interfaces.
- Appendix B lists and briefly describes zones.

Document Conventions

This document uses the conventions described in the following sections:

- Dependency Delimiters on page 10
- Nested Dependencies on page 10
- Object-Naming Conventions on page 10

Dependency Delimiters

Each command line interface (CLI) command description lists optional and mandatory dependency delimiters.

Delimiter	Description
{ }	The { and } symbols denote required keyword choices.
[]	The [and] symbols denote optional keyword choices. You are not required to include these choices.
	The symbol denotes an “or” relationship between two features. When this symbol appears between two features on the same line, you can use either feature (but not both).

Nested Dependencies

Many CLI commands have *nested* dependencies, which make features optional in some contexts and mandatory in others. For example,

```
[ feature_1 { feature_2 | feature_3 } ]
```

In this example, the delimiters [and] surround the entire clause. You can execute the command successfully without indicating **feature_1**, **feature_2**, and **feature_3**. If you include **feature_1**, however, you must include either **feature_2** or **feature_3** because the { and } delimiters surround **feature_2** and **feature_3**.

The following example shows some of the **set interface** command’s feature dependencies:

```
set interface vlan1 broadcast { flood | arp [ trace-route ] }
```

The { and } brackets indicate that specifying either **flood** or **arp** is mandatory. By contrast, the [and] brackets indicate that the **arp** option’s **trace-route** switch is not mandatory. The command can take any of the following forms:

```
set interface vlan1 broadcast flood
set interface vlan1 broadcast arp
set interface vlan1 broadcast arp trace-route
```

Object-Naming Conventions

ScreenOS follows these conventions for object names—such as addresses, admin users, auth servers, IKE gateways, virtual systems, VPN tunnels, and zones:

- If a name string includes one or more spaces, the entire string must be enclosed within double quotes ("); for example:


```
set address trust "local LAN" 10.1.1.0/24
```
- Any leading spaces or trailing text within a set of double quotes are trimmed; for example, “ local LAN ” becomes “local LAN”.
- Multiple consecutive spaces are treated as a single space.
- Name strings are case-sensitive, although many CLI key words are case-insensitive. For example, “local LAN” is different from “local lan”.

ScreenOS supports the following character types:

- Single-byte character sets (SBCS) and multiple-byte character sets (MBCS). Examples of SBCS are ASCII, European, and Hebrew. Examples of MBCS are Chinese, Korean, and Japanese.
- ASCII characters from 32 (0x20 in hexadecimal notation) to 255 (0xff), except double quotes ("), which have special significance as an indicator of the beginning or end of a name string that includes spaces.

NOTE: A console connection only supports SBCS. The WebUI supports both SBCS and MBCS, depending on the character sets that your browser supports.

Requesting Technical Support

Technical product support is available through the Juniper Networks Technical Assistance Center (JTAC). If you are a customer with an active J-Care or JNASC support contract, or are covered under warranty, and need postsales technical support, you can access our tools and resources online or open a case with JTAC.

- JTAC policies—For a complete understanding of our JTAC procedures and policies, review the *JTAC User Guide* located at <http://www.juniper.net/customers/support/downloads/710059.pdf>.
- Product warranties—For product warranty information, visit <http://www.juniper.net/support/warranty/>.
- JTAC hours of operation—The JTAC centers have resources available 24 hours a day, 7 days a week, 365 days a year.

Self-Help Online Tools and Resources

For quick and easy problem resolution, Juniper Networks has designed an online self-service portal called the Customer Support Center (CSC) that provides you with the following features:

- Find CSC offerings—<http://www.juniper.net/customers/support/>
- Find product documentation—<http://www.juniper.net/techpubs/>
- Find solutions and answer questions using our Knowledge Base—<http://kb.juniper.net/>
- Download the latest versions of software and review your release notes—<http://www.juniper.net/customers/csc/software/>
- Search technical bulletins for relevant hardware and software notifications—<http://www.juniper.net/alerts/>
- Join and participate in the Juniper Networks Community Forum—<http://www.juniper.net/company/communities/>

- Open a case online in the CSC Case Manager—
<http://www.juniper.net/customers/cm/>
- To verify service entitlement by product serial number, use our Serial Number Entitlement (SNE) Tool—
<https://tools.juniper.net/SerialNumberEntitlementSearch/>

Opening a Case with JTAC

You can open a case with JTAC on the Web or by telephone.

- Use the Case Manager tool in the CSC at <http://www.juniper.net/customers/cm/>.
- Call 1-888-314-JTAC (1-888-314-5822—toll free in USA, Canada, and Mexico).

For international or direct-dial options in countries without toll-free numbers, visit us at <http://www.juniper.net/customers/support/requesting-support/>.

Document Feedback

If you find any errors or omissions in this document, contact Juniper Networks at techpubs-comments@juniper.net.

Understanding the CLI

The command line interface (CLI) is at the core of configuring your Juniper Networks security device. Use these commands to configure and manage your device.

Accessing the CLI Prompt

You can access a CLI prompt in one of the following three ways:

- **Console**—The Console port on the device lets you access the device through a serial cable connected to your workstation or terminal.
- **Remote Console**—You can remotely access the console interface on a security device by dialing into it. You can either dial into the v.92 modem port or into a modem connected to the AUX port.
- **Telnet/SSH**—Telnet and SSH are applications that allow you to access devices through an IP network.

For more information about connecting to the device, see the hardware documentation that came with your security device. If you have not yet changed the default username and password, enter **netscreen** at both the login and password prompts. (Use lowercase letters only. The login and password fields are both case-sensitive.)

```
login: netscreen  
password:netscreen  
device->
```

Enter the root CLI commands (see “Root Commands” on page 14) at the device prompt -> . The administrative user has complete privileges to configure a device. We recommend that you change the default admin name (netscreen) and password (netscreen) immediately.

Root Commands

The following table lists the root commands on your security device.

Root Commands	Description
clear	Use this command to clear dynamic system information.
delete	Use this command to delete persistent information in flash memory or on a storage device. For more information, see "delete" on page 183.
exec	Use this command to run system commands immediately.
exit	Use this command to exit a command context or a virtual system or to terminate and log out from a CLI session. For more information, see "exit" on page 237.
get	Use this command to display system information.
mtrace	Use this command to configure multicast traceroute from source to destination.
ping	Use this command to check a network connection to another host. For more information, see "ping" on page 525.
reset	Use this command to restart the security device. For more information, see "reset" on page 573.
save	Use this command to save ScreenOS images to a security device and to save device configuration settings to or from a security device. For more information, see "save" on page 605.
set	Use this command to configure system parameters on the security device.
trace-route	Use this command to display the route to a host. For more information, see "trace-route" on page 669.
unset	Use this command to undo a configuration on the security device.

Accessing Help

The CLI commands at each level can be displayed with a question mark (?).

```
device-> set zone ?
Trust      Trust zone
Untrust    Untrust zone
Global     Global zone
DMZ        DMZ zone
VLAN       VLAN zone
name       new zone name
```

A < return> in the CLI structure indicates the end of the command line syntax. In the following example, < return> shows that you can terminate the command with the zone name techpubs.

```
device-> set zone name techpubs ?
<return>
L2          Layer 2 zone
tunnel      tunnel zone
```

You can also configure a Layer 2 or tunnel zone with the following commands:

```
device-> set zone name techpubs l2
device-> set zone name techpubs tunnel sales
```

Availability of Commands

Some ScreenOS commands are device-specific. Because security devices treat unsupported commands as improper syntax, attempting to execute such a command usually generates the **unknown keyword** error message. When this message appears, enter the command followed by **?** to confirm the availability of the command.

For example, the following commands list available options for the **set vpn** command:

```
device-> set vpn ?
name_string
device-> set vpn vpn_name ?
acvpn-dynamic
acvpn-profile
backup-weight
bind
df-bit
gateway
device-> set vpn vpn_name gateway gate_name ?
```


access-list

Use the **access-list** commands to configure the security device for setting extended access lists to use with policy based routing (PBR).

Syntax

set

```
set access-list extended ext_acl_id [ src-ip prefix/length ] [ dst-ip prefix/length ] [ src-port min_max ] [ dst-port min_max ] [ protocol protocol ] [ qos-prec prec ] entry acl_entry_id
```

Keywords and Variables

access-list

```
set access-list extended ext_acl_id [ src-ip prefix/length ] [ dst-ip prefix/length ] [ src-port min_max ] [ dst-port min_max ] [ protocol protocol ] [ qos-prec prec ] entry acl_entry_id
```

access-list To remove an access-list, enter **unset access-list extended entry *acl_entry_id***.

action-group

Use the **action-group** commands to configure the security device for grouping match groups for policy based routing (PBR).

Syntax

set

```
set action-group action_group_name { [ next-interface interface_name] [ next-hop  
ip_addr ] } action-entry action_seq_number
```

Keywords and Variables

action-group

```
set action-group action_group_name { [ next-interface interface_name] [ next-hop  
ip_addr ] } action-entry action_seq_number  
unset action-group action_group_name action-entry action_seq_number
```

action-group Specifies the name of a match group. Each action-group name must be unique alphanumeric string and must be between 1 and 28 characters in length. An action group can specify the next interface or a next hop and associates an action-entry, which is a number between 1 and 99. The sequence number (action-entry) specifies the order in which the forwarding solution is looked for.

To remove an action group, enter **unset action-group** *action_group_name* **action-entry** *action_seq_number*.

active-user

Use the **active-user** commands to clear or display information for all users who initiated a service request through the security device. The displayed information includes the IP address of each user and the number of sessions (incoming and outgoing) currently active for the user.

NOTE: The maximum number of sessions allowed for users depends upon the software license installed on the device.

Syntax

Clear

```
clear active-user { IPv4 address | all }
```

Get

```
get active-user
```

Keywords and Variables

all

```
clear active-user all
```

all Deletes all active users.

address

Use the **address** commands to define entries in the address book of a security zone.

An address book is a list containing all addresses, address groups, and domain names defined for a security zone. You use address-book entries to identify addressable entities in policy definitions.

Syntax

get

```
get address zone [ group name_str | name name_str ]
```

set

```
set address zone name_str  
{  
  fqdn |  
  ip_addr/network_mask |  
  ip_addr/wildcard_mask  
}  
[ string ]
```

Keywords and Variables

Variable Parameters

<code>zone</code>	The name of the security zone. The default security zones to which you can bind an address book include Trust, Untrust, Global, DMZ, V1-Trust, V1-Untrust, and V1-DMZ. You can also assign address book entries to user-defined zones. For more information, see “Zones” on page 773.
<code>fqdn</code>	The fully qualified domain name of the host.
<code>ip_addr/network_mask</code>	The IP address and subnet mask identifying an individual host or a subnet.
<code>ip_addr/wildcard_mask</code>	The IP address and wildcard mask identifying a set of hosts or subnets.
<code>name_str</code>	The name of the zone or group.
<code>string</code>	A character string containing a comment line.

Example: The following commands create address book entries named **Local_Net** and **Outside_Net**:

```
set address trust Local_Net 10.1.1.0/24 "New_York_Subnet"
set address untrust Outside_Net 1.1.12.1/24 "London_Subnet"
```

group

```
get address zone group name_str
```

<code>group</code>	The name of a group of address book entries. You can use an address group in a security policy definition to specify multiple addresses. (Create address groups using the set group address command.)
--------------------	--

Example: The following command displays information for an address group named **Sales_Group**:

```
get address trust group HTTP_Servers
```

name

```
get address zone name name_str
```

<code>name name_str</code>	The name of an individual address book entry. You can use an address group in a security policy definition to specify a single address.
----------------------------	---

admin

Use the **admin** commands to configure or display administrative parameters for the security device. These parameters determine the following:

- Characteristics for each administrator, such as password and privilege level
- How the device performs administrator authentication
- Methods administrators can use to access the device
- An IP address or address range from which one or more administrators can connect to the device
- Which port the device uses to detect administrative traffic
- Whether the device automatically sends generated alerts and traffic alarms via email
- Whether the device is enabled for reset

Syntax

clear

```
clear [ cluster ] admin { all | name name_str | lock }
```

get

```
get admin  
[  
  auth [ banner [ secondary ] | settings ] |  
  current-user |  
  manager-ip [ all device ] |  
  ssh all |  
  user [ login | trustee ]  
]
```

set

```

set admin
{
  access
  {
    attempts number |
    lock-on-failure number
  } |
  auth
  {
    banner { console login string | secondary string | telnet login string } |
    remote { fallback permit { non-root | root } | primary | read-only | root } |
    server name_str |
    timeout number
  } |
  device-reset |
  format { dos | unix } |
  http redirect |
  hw-reset |
  mail
  {
    alert |
    mail-addr1 name_str | mail-addr2 name_str |
    server-name { ip_addr | name_str } |
    traffic-log
  } |
  manager-ip { ip_addr | ipv6_addr[ mask ] | enforce } |
  name name_str |
  password [ pswd_str | restrict length number ] |
  port port_num |
  privilege { get-external | read-write } |
  root access console |
  ssh
  {
    password { disable | enable } username name_str |
    port port_num
  } |
  telnet port port_num |
  user name_str
  {
    access schedule schedule_str
    password pswd_str [ privilege { all | read-only } ] |
    role { audit | cryptographic | security } |
    trustee [ interface | modem ]
  }
}

```

Keywords and Variables

access

```

set admin access attempts number
set admin access lock-on-failure number
unset admin access attempts
unset admin access lock-on-failure

```

access Configures the admin login attempts limit and locks unauthenticated user accounts for a specified period.

- **attempts**—Specifies the number (1–255) of unsuccessful login attempts allowed before the security device closes the connection. The default is 3.
- **lock-on-failure**—Specifies the lockout time (1–1440) for unauthenticated admin user accounts. The default is 1 minute. If the *number* is set to **0**, the security device locks the user account until a root or security admin unlocks it.

Example: The following commands set the number of allowed unsuccessful login attempts to **5** and locks the user account for **60 minutes** when login attempts exceed the limit:

```
set admin access attempts 5
set admin access lock-on-failure 60
save
```

access schedule

```
set admin user user_name access schedule schedule_str
```

access schedule Restricts admin access to device based on a predefined scheduler.

- ***schedule_str*** Predefined scheduler attached to the specified admin. Once the permitted access period set in the access schedule expires, the permit time window is closed and the security device will restrict the admin from accessing the device since

alert

```
set admin mail alert
```

alert Collects system alarms from the device for sending to an email address.

all

```
clear admin all
```

all Clears all admin user profiles.

auth

```
get admin auth [ banner [ secondary ] | settings ]
set admin auth banner console login string
set admin auth banner secondary string
set admin auth banner telnet login string
set admin auth remote { ... }
set admin auth server name_str
set admin auth timeout number
unset admin auth banner { console login | secondary | telnet login }
unset admin auth server
unset admin auth timeout
```

auth

Configures admin authentication settings for the security device.

- **banner**—Specifies the banner (*string*) displayed during login through the console port (**console**) or a Telnet or SSH session (**telnet**). The security device uses the banner created from the command **set admin auth banner telnet login *string*** for both Telnet and Secure Shell (SSH) logins.
 - **secondary**—Specifies a second banner line that is always the same—for either console or Telnet—under the first banner line, which can be different for a console login and a Telnet login. The secondary banner can be up to 4000 bytes in length. Also, you can create an unrestricted number of line breaks by inserting the special symbol “\n” wherever you want a line to end.

Defines the sequence in which the admin authentication services are attempted and the fallback behavior of the secondary authentication service.

- **fallback permit**—Defines the behavior of the secondary authentication server. By default, the secondary authentication server is attempted if the primary authentication server fails. The command configures the device to accept or not to accept **root** or **non-root** privileged admins authenticated by a remote authentication server. If you **unset** the command, the admin authentication is not accepted.
- **primary**—Sets a higher priority to the remote authentication server. The **unset** command defaults to the local authentication server.
- **read-only**—Assigns read-only privileges for remotely authenticated admins.
- **root**—Accepts remotely authenticated root-privileged admins only. By default, the remote authentication server is not permitted to authenticate root-privileged admins.

Note: If the remote authentication server cannot be reached and local authentication is disabled, then as a last resort the device allows the root-privileged admin to authenticate using the serial console.

- **server**—The name of the authentication server used for authenticating admin users.
- **timeout**—Specifies the length of idle time (in minutes) before the security device automatically closes the Web administrative session. The value can be up to 999 minutes. A value of 0 specifies no timeout. (Telnet admin sessions time out after the console timeout interval expires. You set this interval using the **set console timeout** command).

Example 1: The following commands create two login banners:

- “HyperTerminal Management Console“ is displayed at the start of new console admin sessions.
- “Telnet Login Here” is displayed at the start of new Telnet admin sessions.

```
set admin auth banner console login "HyperTerminal Management Console"
set admin auth banner telnet login "Telnet Login Here"
```

Example 2: The following command creates a secondary banner line with the text string “Network Empire”. When an admin initiates a console or Telnet login attempt, this line will appear under the two login banners defined in the previous example:

```
set admin auth banner secondary "Network Empire"
```

cluster

```
clear cluster admin user { cache | login }
```

`cluster` Propagates the **clear** operation to all other devices in an NSRP cluster.

Example: The following command clears remote administrative users from the cache and propagates this change to other devices in an NSRP cluster:

```
clear cluster admin user cache
```

current-user

```
get admin current-user
```

`current-user` Displays the user for the current administrative session.

device-reset

```
set admin device-reset  
unset admin device-reset
```

`device-reset` Enables device reset for asset recovery.

format

```
set admin format { dos | unix }  
unset admin format
```

`format` Determines the format (**dos** or **unix**) used when the security device generates the configuration file. On certain platforms, you can download this file to a TFTP server or PCMCIA card using the CLI or to a local directory using the WebUI.

http redirect

```
set admin http redirect  
unset admin http redirect
```

`http redirect` Enables and disables the redirection of administrative traffic to the security device from HTTP (default port 80) to HTTPS (default port 443). By default, HTTP redirection is disabled.

hw-reset

```
set admin hw-reset  
unset admin hw-reset
```

`hw-reset` Enables and disables hardware reset for asset recovery.

login

```
clear [ cluster ] admin user login
```

```
get admin user login
```

login Clears or displays all current administrative users.

mail

```
set admin mail { ... }
unset admin mail { ... }
```

mail Enables email for sending alerts and traffic logs.

Example: The following command configures the email address *john@abc.com* to receive updates concerning administrative issues:

```
set admin mail mail-addr1 john@abc.com
```

mail-addr1

```
set admin mail mail-addr1 name_str
```

mail-addr1 *name_str*—Sets the first email address (such as *chris@acme.com*) for sending alert and traffic logs.

mail-addr2

```
set admin mail mail-addr2 name_str
```

mail-addr2 *name_str*—Sets the secondary email address for sending alert and traffic logs.

Example: The following command configures the secondary email address *pat@acme.com* to receive updates concerning administrative issues:

```
set admin mail mail-addr2 pat@acme.com
```

manager-ip

```
get admin manager-ip [ all device ]
set admin manager-ip { ip_addr [ mask ] | enforce }
unset admin manager-ip { ip_addr | all [ device ] | enforce }
```

manager-ip Restricts management to a host or a subnet. The default **manager-ip** address is 0.0.0.0, which allows management from any workstation. The number of manager IP addresses you can set depends on the security device. On devices that support virtual systems, the number of manager IP addresses is 50 plus one times the number of vsys.

- **all**—Displays or removes all manager IP addresses for the current vsys.
- **device**—Displays or removes all manager IP addresses from all vsys on the device.
- **enforce**—Specifies that all vsys be configured to use **manager-ip**.
- **ip_addr/ ipv6_addr [mask]**—Adds the specified IPv4 or IPv6 address to the list of manager IP addresses for the current vsys.

Note: The **manager-ip** address must be unique, and different from the physical IP address of the management interface.

Example: The following command restricts management to a single host with IP address 10.1.10.100:

```
set admin manager-ip 10.1.10.100 255.255.255.255
```

Example: The following command restricts management to a single host with IPv6 address 3ffe:7777::1

```
set admin manager-ip 3ffe:7777::1
```

name

```
set admin name name_str
unset admin name
```

name The login name (*name_str*) of the root user for the security device. The maximum length of the name is 31 characters, including all symbols except ?. The name is case-sensitive.

password

```
set admin password pswd_str
unset admin password
```

password Specifies the password (*pswd_str*) of the root user. The maximum length of the password is 31 characters, including all symbols except the special command character ?.

port

```
set admin port port_num
unset admin port
```

port Sets the port number (*port_num*) for detecting configuration changes when using the Web. Use any number between 1024 and 32767, or use the default port number (80). Changing the admin port number might require resetting the device (see "reset" on page 573).

privilege

```
set admin privilege ( get-external | read-write )
```

privilege Defines the administrative privilege level:

- **get-external**—Instructs the security device to obtain the admin user privileges externally from the RADIUS server.
- **read-write**—Gives the RADIUS administrator read-write privileges and ignores the privilege returned from the RADIUS server.

restrict length

```
set admin password restrict length number
unset admin password restrict length
```

`restrict length` Sets the minimum password length of the root admin. The password length can be any number from 1 to 31.

root access console

`set admin root access console`
`unset admin root access console`

`root access console` Restricts the root admin to logging into the device through the console only.

server-name

`set admin mail server-name ip_addr`

`server-name` The IP address or name of the Simple Mail Transfer Protocol (SMTP) server. This server receives email notification of system alarms and traffic logs.

Example: The following command specifies a SMTP server at IP address 10.1.10.10:

set admin mail server-name 10.1.10.10

settings

`get admin auth settings`

`settings` Displays admin authentication settings, including the current timeout setting and the admin user type (local or remote).

ssh

`get admin ssh all`
`set admin ssh password { disable | enable } username name_str`
`set admin ssh password port port_num`
`unset admin ssh [port]`

`ssh` Provides access to the Secure Shell (SSH) utility. SSH allows you to administer security devices from an Ethernet connection or a dial-in modem, thus providing secure CLI access over unsecured channels.

- **all**—Displays the SSH PKA (Public Key Authentication) information for each admin.
- **password**—Sets the password for the user that establishes the SSH session. The **enable | disable** switch enables or disables password authentication. **username name_str** specifies the admin username.
- **port port_num**—Specifies the logical SSH port through which the communication occurs. The default is port 22. Unsetting the port resets the SSH port to the default.

telnet

`set admin telnet port port_num`

unset admin telnet port

telnet port Provides CLI access through a Telnet connection. The acceptable range of *port_num* is 1024–32767.

traffic-log

set admin mail traffic-log
unset admin mail traffic-log

traffic-log Generates a log of network traffic handled by the security device. The traffic log can contain a maximum of 4,096 entries. The security device sends a copy of the log file to each specified email address (see *mail-addr1* and *mail-addr2*). This happens when the log is full, or every 24 hours, depending upon which occurs first.

user

get admin user [cache | login]
set admin user *name_str* password *pswd_str* [privilege { all | read-only }]
set admin user *name_str* role { audit | cryptographic | security }
set admin user *name_str* trustee [interface | modem]
unset admin user *name_str*

user Creates or displays a non-root admin (super-admin or sub-admin) and assigns a role attribute to the admin. The maximum username length is 31 characters, including all symbols except the special command character ?. The username is case-sensitive.

- The **privilege** switch determines the privilege level of the user (**all** or **read-only**).
- A **trustee** can be permitted to configure the untrust Ethernet interface or the untrust modem interface. Default: none.
Admin accounts that have a trustee attribute set are restricted as follows:
 - Permitted to manage the device using the Web only.
 - Trustee accounts do not function when the device is in transparent mode, if an account is created while the device is in transparent mode, or when the device is in dual-untrust or combined mode.
 - Permitted only to manage a predefined set of physical interface attributes corresponding to the settings of the configured trustee attribute (interface and/or modem).
- The **role** determines the role attribute assigned to the non-root admin.
 - **none**—No role attribute is assigned. This is the default.
 - **audit**—Enables the non-root admin to perform audit tasks. The audit admin can configure and monitor audit data.
 - **cryptographic**—Enables the non-root admin to perform cryptographic tasks. The cryptographic admin can configure and monitor cryptographic and audit data.
 - **security**—Enables the non-root admin to perform configuration and security tasks. The security admin can access security and audit data.

Example 1: The following command creates a non-root admin named **rsmith** with password **swordfish**:

```
set admin user rsmith password swordfish privilege all
```

Example 2: The following command assigns a non-root admin named **rsmith** with the role attribute **security**:

```
set admin user rsmith role security
```

Defaults

- The default admin name and password are both **netscreen**.
- The default number of access attempts is **3**.
- The default role attribute is **none**.
- The default manager-ip is **0.0.0.0**, and the default subnet mask is **255.255.255.255**.
- The default privilege for a super-admin is **read-only**.
- By default, HTTP redirection is **enabled** on security devices that ship with ScreenOS 5.1.0 or later.
- The default admin port is **80**.
- The default mail alert setting is **off**.
- The default for device reset is **on**.
- The default primary authentication server is **local**. The secondary authentication server is attempted if the primary server fails.

alarm

Use the **alarm** commands to set or display alarm parameters.

Alarm parameters determine when a security device generates alarm messages and the amount and type of information contained in the messages.

Syntax

clear

```
clear [ cluster ] alarm traffic
      [ policy { pol_num | pol_start - pol_end } ]
      [ end-time string ]
```

exec

```
exec alarm security [ ack-id number | all ]
```

get

```
get alarm
{
  event
  [ dst-ip ip_addr [ -ip_addr | dst-netmask mask ] ]
  [ dst-port port_num [-port_num ] ]
  [ end-date date ]
  [ end-time string ]
  [ exclude string ]
  [ include string ]
  [ interface interface ]
  [ level
  {
    alert | critical | debug |
    emergency | error | information |
    notification | warning
  } ]
  [ module name_str ]
  [ policy { pol_num1 [ -pol_num2 ] } ]
  [ protocol protocol 1 [ -protocol2 ] ]
  [ sort-by
  {
    date | dst-ip | dst-port |
    interface | policy | src-ip |
    user-name | time
  } ]
}
```

```

    ]]
  [ src-ip ip_addr [ -ip_addr | src-netmask mask ] ]
  [ start-date string ]
  [ start-time string ]
  [ type id_num [ - id_num ] ] |
  security { config | ack-id number | all | statistics }
  snapshot cpu { alarm_time time | all } |
  threshold |
  traffic
    [ policy { pol_num1 | pol_start - pol_end } ]
    [ service name_str ]
    [ src-address ip_addr ]
    [ dst-address ip_addr ]
    [ detail
      [ start-time string ]
      [ end-time string ]
      [ {minute | second}
        [ threshold { number | number_low - number_high } ]
        [ rate { number | number_low - number_high } ]
      ]
    ]
  ]
}

```

set

```

set alarm threshold
{
  cpu number |
  memory number |
  session { count number | percent number }
}

set alarm security
{
  audible |
  enable |
  interval number |
  local-force |
  overwrite disable |
  potential-violation
  {
    authentication-violation enable |
    crypto-failure-self-test enable |
    decryption-failures number |
    encryption-failures number |
    ike-p1-failures number |
    ike-p2-failures number |
    key-gen-failure-self-test enable |
    non-crypto-failure-self-test enable |
    policy-violation rate number per [ minute | second ]
    replay enable |
  }
}

```

Keywords and Variables

cluster

clear cluster alarm traffic [...]

cluster Propagates the **clear** operation to all other devices in a NSRP cluster.

Example: The following command clears the alarm table entries for policy 4 and propagates the change to other devices in an NSRP cluster:

clear cluster alarm traffic policy 4

detail

get alarm traffic [...] detail [...]

detail Displays detailed information for each policy, including all traffic alarm entries that occurred under the policy. If you omit this option, the output contains only general information and the time of the most recent alarm for each policy.

Example: The following command displays event alarm entries or traffic alarm entries that occur on or after January 1, 2003:

get alarm traffic detail start-time 01/01/2003

event

get alarm event [...]

Displays sorts, and searches the event log messages.

dst-ip Directs the device to display event logs with the specified destination IP address or address range. The device can also sort event logs by destination IP address.

include
exclude Directs the device to exclude or include events containing a specified string of characters (*string*).

Interface Specifies the name of the interface that generated the event.

level Specifies the priority level of the event message. The priority levels are as follows:

- **emergency** (Level 0) The system is unusable.
- **alert** (Level 1) Immediate action is necessary.
- **critical** (Level 2) The event affects functionality.
- **error** (Level 3) Error condition exists.
- **warning** (Level 4) The event might affect functionality.
- **notification** (Level 5) The event is a normal occurrence.
- **information** (Level 6) The event generates general information about normal operation.
- **debug** (Level 7) The event generates detailed information for troubleshooting purposes.

module	Specifies the name of the system module that generated the event.
policy	Displays the log events for a policy specified by its ID number or for several policies specified by a range of ID numbers. The ID number can be any value between 0 and the total number of established policies. To define a range, enter the starting and ending ID numbers as follows: <i>pol_num1-pol_num2</i>
protocol	Specifies the Transport Layer protocol with which the event was generated.
sort-by	Sorts event logs by date, source IP address, destination IP address, destination port, policy, protocol, user-name or time.
src-ip	Displays event logs by source IP address. The device can also display event logs with the specified source IP address or address range.
start-time end-time	Specifies the lower and upper ends of a range of times for an event. When you specify a start-time and/or end-time, the device sorts or filters the event logs based on the specified times, regardless of the date. The format is as follows: <i>hh:mm:ss</i>
start-date end-date	Specifies the lower and upper ends of a range of times for an event. The format is as follows: <i>mm/dd/yy-hh:mm:ss</i> You can omit the year (the current year is the default) or express the year using the last two digits or all four digits. The hour, minute, and second are optional. The delimiter between the date and the time can be a dash or an underscore, as follows: 12/31/2001-23:59:00 12/31/2001_23:59:00
type	Specifies a priority level or a range of priority levels.

end-time | start-time

```
clear [ cluster ] alarm traffic policy [ ... ] end-time number
get alarm traffic [ ... ] end-time number
get alarm traffic [ ... ] start-time number
```

start-time	The start-time option displays event alarm entries or traffic alarm entries that occurred at or before the time specified. The end-time option displays event alarm entries or traffic alarm entries that occurred at or after the time specified. The format for <i>string</i> is <i>mm/dd/yy-hh:mm:ss</i> You can omit the year (the current year is the default), or express the year using the last two digits or all four digits. The hour, minute, and second are optional. The delimiter between the date and the time can be a dash or an underscore: 12/31/2002-23:59:00 12/31/2002_23:59:00
end-time	

Example: The following command performs a detailed display of traffic alarm entries at (or after) 11:59pm, December 31, 2003 and at or before 12:00am, December 31, 2004:

```
get alarm traffic detail start-time 12/31/2003-23:59:00 end-time
12/31/2004-24:00:00
```

policy

```
clear [ cluster ] alarm traffic policy pol_num1 [ -pol_num2 ] [ ... ]
get alarm traffic policy pol_num
```

policy Displays traffic alarm entries for a policy specified by its ID number or for several policies specified by a range of ID numbers. The ID number can be any value between 0 and the total number of established policies. To define a range, enter the starting and ending ID numbers as follows:
pol_num1-pol_num2

Example: The following command clears the entries for policy 2 in the alarm table:

```
clear alarm traffic policy 2
```

rate

```
get alarm traffic [ ... ] rate [ number /number_low - number_high ]
```

rate Displays traffic alarm entries for policies with rate settings at a specified value or within a specified range.

Example: The following command displays the traffic alarm entries for which the threshold limit is 12 kilobytes/minute:

```
get alarm traffic detail minute rate 12
```

second | minute

```
get alarm traffic [ ... ] detail
```

second | minute Displays traffic alarm entries for policies with threshold settings at bytes per second or bytes per minute.

- The **rate** *number* [*-number*] option displays traffic alarm entries for policies with a flow rate at a specified value or within a specified range.
- The **threshold** *number* [*-number*] option displays traffic alarm entries for policies with a threshold at a specified value or within a specified range.

Example: The following command displays traffic alarm entries for policies with threshold settings at bytes per second:

```
get alarm traffic detail second
```

service

```
get alarm traffic [ ... ] service name_str [ ... ]
```

service Displays traffic alarm entries for a specified service (*name_str*), such as TCP, ICMP, or FTP. (To display all services, make the *name_str* value **Any**.) The name does not have to be complete; for example, both **TC** and **CP** are recognized as **TCP**. Although you cannot specify a Service group, note that because **TP** is recognized as **FTP**, **HTTP**, and **TFTP**, entering **TP** displays traffic alarm entries for all three of these Services.

Example: The following command displays traffic alarm entries for the HTTP service:

```
get alarm traffic service http
```

security

```
get alarm security [ config | ack-id number | all | statistics ]
set alarm security enable
set alarm security audible
set alarm security interval number
set alarm security local-force
set alarm security overwrite disable
```

set alarm security potential-violation [...]

- security Enables you to configure automatic alarms when the security device detects a security violation.
- **enable**—Enables the security alarm functions. Use **disable** to disable the functions.
 - **audible**—Turns on the audible bell sound. Users are alerted with an audible sound when a security alert message is displayed on the console. If the audible is not set, the alert message is displayed without any sound.
 - **interval *number***—Indicates the interval period. The security device displays the alert message at regular intervals until the event is acknowledged by the administrator. The default interval is 10 seconds. You can set a maximum interval of 3600 seconds.
 - **local-force**—Enables the security device to display security alarms on a local system regardless of whether or not an administrator is logged in.
 - **overwrite**—Overwrites the oldest event in the alarm log with a new event. The maximum number of alarm events the security device can store is 100. You can configure the security device to drop new security alarms using the **set alarm security overwrite disable** command.
 - **potential-violation**—Enables a security alarm in the event of a possible security violation.
 - **authentication-violation**—Enables an authentication violation security alarm when there is an authentication failure or unauthorized access.
 - **crypto-failure-self-test**—Enables a crypto-failure-self-test security alarm.
 - **decryption-failures *number***—Enables a decryption failure security alarm when the number of decryption failures exceeds the configured threshold. The value of *number* ranges from 1 through 65535.
 - **encryption-failures *number***—Enables an encryption failure security alarm when the number of encryption failures exceeds the configured threshold. The value of *number* ranges from 1 through 65535.
 - **ike-p1-failures *number***—Enables a security alarm when the number of IKE phase 1 failures exceeds the configured threshold. The value of *number* ranges from 1 through 65535.
 - **ike-p2-failures *number***—Enables a security alarm when the number of IKE phase 2 failures exceeds the configured threshold. The value of *number* ranges from 1 through 65535.
 - **key-gen-failure-self-test**—Enables a key generating security alarm when a key-generation operation fails.
 - **non-crypto-failure-self-test**—Enables a non-crypto-self-test security alarm.
 - **policy-violation rate**—Enables a policy violation security alarm when the policy-violation generation rate exceeds the configured threshold. The rate can be per second or per minute.
 - **replay**—Enables the security device to replay the security alarm.

Example: The following commands enable an audible security alarm to be displayed by the security device every 30 seconds.

```
set alarm security enable
set alarm security audible
set alarm security interval 30
set alarm security local-force
```

```
set alarm security overwrite disable
save
```

snapshot

```
get alarm snapshot cpu { alarm_time | all }
```

snapshot Displays snapshots triggered by a CPU alarm.

- **alarm_time** *MM/DD/YYYY-hh:mm:ss*—Shows a snapshot of a specific time.
- **all**—Shows all snapshots.

src-address / dst-addr

```
get alarm traffic [ ... ] src-address ip_addr [ ... ]
get alarm traffic [ ... ] dst-address ip_addr [ ... ]
```

src-address Displays traffic alarm entries originating from a specified IP address (*ip_addr*) or from a specified direction, such as **inside_any** or **outside_any**.

dst-address Displays traffic alarm entries destined for a specified IP address (*ip_addr*) or for a specified direction, such as **inside_any** or **outside_any**.

Example: The following command displays traffic alarm entries originating from IP address 10.1.9.9 and destined for IP address 1.1.10.10:

```
get alarm traffic src-address 10.1.9.9 dst-address 1.1.10.10
```

threshold

```
get alarm threshold
get alarm traffic [ ... ] threshold [ number | number_low - number_high ]
set alarm threshold { ... }
unset alarm threshold { CPU | memory | session }
```

threshold Displays traffic alarm entries for policies with threshold settings at a specified value or within a specified range.

- **cpu** *number* sets the cpu threshold.
- **memory** *number* sets the memory threshold.
- **session** sets the session threshold. The **count** *number* option specifies how many sessions can exist before the device generates an alarm. The **percent** *number* option specifies what percentage of the session limit is allowable before the device generates an alarm.

Example: The following command sets the session limit threshold to 75,000 sessions:

```
set alarm threshold session count 75000
```

traffic

```
clear [ cluster ] alarm traffic [ ... ]
get alarm traffic [ ... ]
```

traffic Specifies traffic alarm entries.

Example: The following command performs a detailed display of traffic alarm entries originating from IP address 10.1.9.9 and destined for IP address 1.1.10.10:

get alarm traffic src-address 10.1.9.9 dst-address 1.1.10.10 detail

alg

Use the **alg** commands to enable or disable an Application Layer Gateway (ALG) on the security device. An ALG runs as a service and can be associated in policies with specified types of traffic. ALGs are enabled by default.

Syntax

clear

```
clear alg
{
  h323 counters |
  mgcp counters |
  sccp counters |
  sip call | counters | rate
}
```

get

```
get alg
{
  applechat
}
{
  h323 [ counters ] |
  mgcp
  [
    calls [ endpoint string ] |
    counters |
    endpoints [ name string ] |
    sessions [ dst-ip ip_addr | src-ip [ ip_addr ] ]
  ] |
  msrpc |
  pptp { counters | xlate } |
  rtsp |
  sip
  [
    calls [ details ] |
    counters |
    details |
    memory |
    rate |
    setting |
    transactions
  ]
}
```

```

]
sccp
[
  calls [ detail ] |
  counters |
]
}|
sql |
sunrpc
}

```

set

```

set alg
{
  applechat { call-answer-time | re-assembly [ enable ] | enable }
}|
{
  h323
  {
    app-screen
    {
      message-flood gatekeeper [ threshold number ] |
      unknown-message [ nat | route ] permit
    }|
    enable |
    gate source-port-any |
    incoming-table timeout number
  }|
  mgcp
  {
    app-screen
    {
      connection-flood [ threshold number ] |
      message-flood [ threshold number ] |
      unknown-message [ nat | route [ permit ] ]
    }|
    enable |
    inactive-media-timeout number /
    max-call-duration number |
    transaction-timeout number
  }|
  msrpc [ enable ] |
  pptp [ enable ] |
  rtsp [ enable ] |
  sccp
  {
    app-screen
    {
      call flood [ threshold number ] |
      unknown message [ nat | route ] permit
    }|
    enable |
    inactive-media-timeout number
  }|
}

```

```

sctp [ enable ] |
sip
{
  C-timeout number |
  T1-interval number |
  T4-interval number |
  app-screen
  {
    protect deny [ dst-ip [ ip_addr/mask | ipv6 ipv6-addr / prefix_length ] |
    timeout number | unknown-message [nat | route ] permit ]
  } |
  enable |
  media-inactivity-timeout number |
  signaling-inactivity-timeout number
} |
sql [ enable ] |
sunrpc [ enable ]
}

```

Keywords and Variables

AppleChat

```

get alg applechat [ ... ]
set alg applechat [ ... ]
unset alg applechat [ ... ]

```

applechat	<p>Specifies the AppleChat ALG on the device. By default, this ALG is disabled on high-end systems and enabled on low-end systems.</p> <ul style="list-style-type: none"> ■ Call-answer-time—Specifies the time duration for which the pinholes of the firewall will be open for establishing an iChat audio/video call. The default value is 32 seconds. The configurable value can range from 20 seconds through 90 seconds. ■ re-assembly [enable]—Enables the reassembly option for the ALG. Maximum Segment Size (MSS) is the maximum amount of data, in bytes, a device can handle in a single, unfragmented piece. Whenever the iChat application fragments the packets to be sent to the receiver into smaller packets based on the MSS specified by the receiver, the chopped packets need to be reassembled at the ALG to undergo Network Address Translation (NAT). ■ enable—Configures the Applechat ALG to support iChat audio/video.
-----------	--

h323

```
clear alg h323 [ ... ]
get alg h323 [ ... ]
set alg h323 [ ... ]
unset alg h323 [ ... ]
```

h323 Specifies the H.323 ALG on the device. H.323 is a control-signaling protocol used to exchange messages between H.323 endpoints.

- **app-screen message flood gatekeeper [threshold number]** Limits the rate per second at which Remote Access Server (RAS) requests to the gatekeeper are processed. Messages exceeding **threshold** are dropped. Disabled by default. When enabled, the default threshold value is 1000 connections requests; the range is 1 to 65535.
- **app-screen unknown-message [nat | route] permit**—Specifies how unidentified H.323 messages are handled by the security device. The default is to drop unknown (unsupported) messages. Permitting unknown messages can compromise security and is not recommended. However, in a secure test or production environment, this command can be useful for resolving interoperability issues with disparate vendor equipment. By permitting unknown H.323 (unsupported) messages, you can get your network operational and later analyze your VoIP traffic to determine why some messages were being dropped.

Note that this command applies only to received packets identified as supported VoIP packets. If a packet cannot be identified, it is always dropped. If a packet is identified as a supported protocol and **unknown-message** is set to **permit**, the message is forwarded without processing.

- **nat**—Specifies that unknown messages be allowed to pass if the session is in NAT mode.
- **route**—Specifies that unknown messages be allowed to pass if the session is in route mode. (Sessions in transparent mode are treated as route mode.)
- **counters**—Clears all H.323 ALG counters.
- **enable**—Enables and disables the H.323 ALG (the default is enabled).
- **gate source-port-any**—Specifies that the security device accept calls from any port number.
- **incoming-table timeout**—Specifies the timeout value in seconds for entries in the NAT table. The default is 3600 seconds.

mgcp

```

get alg mgcp [ ... ]
set alg mgcp [ ... ]
unset alg mgcp [ ... ]
clear alg mgcp counters

```

- mgcp** Specifies the MGCP ALG on the device. MGCP is a text-based Application Layer protocol that can be used for call setup and call control.
- **app-screen connection-flood [threshold *number*]**—Specifies the threshold for connections per second, limiting the rate of processing CreateConnection requests from the call agent and thereby constraining pinhole creation. CreateConnection requests that exceed this threshold are dropped. Disabled by default. When enabled, the default threshold value is 200 connections. The minimum is 10; the maximum is 1000.
 - **app-screen message-flood [threshold]**—Specifies the rate in seconds beyond which messages arriving on an MGCP session are dropped. Disabled by default. When enabled, the default is 1000 messages. The minimum is 50; the maximum is 500.
 - **app-screen unknown-message [nat | route] permit**—Specifies how unidentified messages are handled by the security device. The default is to drop unknown messages. Permitting unknown messages can compromise security and is not recommended. However, in a secure test or production environment, this command can be useful for resolving interoperability issues with disparate vendor equipment. For example, the security device rejects SIP messages containing unsupported SIP “methods.” By permitting unknown SIP messages in this case, you can get your network operational and later analyze your VoIP traffic to determine why some messages were being dropped.

Note: This command applies only to received packets identified as supported VoIP packets. If a packet cannot be identified, it is always dropped. If a packet is identified as a supported protocol and **unknown-message** is set to **permit**, the message is forwarded without processing.

 - **nat**—Specifies that unknown messages be allowed to pass if the session is in NAT mode.
 - **route**—Specifies that unknown messages be allowed to pass if the session is in route mode. (Sessions in transparent mode are treated as route mode.)
 - **calls**—Displays active MGCP calls.
 - **counters**—Displays or clears MGCP statistics.
 - **enable**—Enables and disables the MGCP ALG (the default is enabled).
 - **endpoints**—Displays endpoints of active sessions.
 - **inactive-media-timeout**—Specifies how long pinholes and sessions opened for media are kept alive in the absence of activity. The default is 120 seconds. The minimum is 10 seconds, the maximum is 2550 seconds.
 - **max-call-duration**—Specifies the maximum number of minutes (the default is 720) established calls are kept alive. The minimum is 3; the maximum is 1440.
 - **transaction-timeout**—Specifies the time, in seconds, for an MGCP transaction. The range is 5 to 50 seconds; the default is 30 seconds.

- **sessions** displays MGCP session information.
 - **dst-ip**—Matches the destination IP address of the session.
 - **src-ip**—Matches the source IP address of the session.

msrpc

```
get alg msrpc
set alg msrpc enable
unset alg msrpc enable
```

msrpc Specifies the Microsoft Remote Procedure Call ALG on the device (the default is enabled).

pptp

```
get alg pptp
get alg pptp counters
get alg pptp xlate
set alg pptp enable
unset alg pptp enable
```

pptp Enables Point to Point Tunneling Protocol on the device. By default, PPTP is disabled. Enables the PPTP ALG for the entire network server. Use the **unset** command to disable the PPTP ALG for the entire network server.

- **counters**—Displays the PPTP ALG statistics counter. The statistics counter includes error counters and the sum of the different packet types.
- **xlate**—Displays the translation mapping table showing the source IP address, destination IP address, call ID, translated source IP address, translated destination IP address, and translated call ID.

rtsp

```
get alg rtsp
set alg rtsp enable
unset alg rtsp enable
```

rtsp Specifies the Real-Time Streaming Protocol ALG on the device (the default is enabled).

Note: In a dual stack environment, the **set** command will enable both IPv4 and IPv6 RTSP ALGs at the same time. Similarly, the **unset** command will disable the IPv4 and IPv6 RTSP ALGs. The limitations of this feature are:

- ALG does not support NAT for IPv6.
- ALG does not support transparent mode and NetScreen Redundancy Protocol (NSRP) for IPv6.
- ALG does not support NetScreen Redundancy Protocol (NSRP) for IPv6.

sctp

```
set alg sctp enable
unset alg sctp enable
```

sctp Specifies the Stream Control Transfer Protocol (SCTP) ALG on the device. This enables stateful inspection on all SCTP traffic. By default, SCTP ALG is disabled on high-end platforms but is enabled on low-end platforms.

sccp

```
clear alg sccp counters
get alg sccp [ ... ]
set alg sccp [ ... ]
unset alg sccp [ ... ]
```

sccp Specifies the Skinny Call Control Protocol ALG on the device.

- **app-screen call-flood [threshold number]**—Enables outbound call protection for the client, to protect the Call Manager from being flooded with new calls from an already compromised, connected client or a faulty device. This feature is not enabled by default. When enabled, outbound calls to Call Manager exceeding **threshold** per minute are dropped for that interval. When enabled, the default is 20 calls per minute; the range is 1 to 1000.

- **app-screen unknown-message [nat | route] permit**—Specifies how unidentified messages are handled by the security device. The default is to drop unknown messages. Permitting unknown messages can compromise security and is not recommended. However, in a secure test or production environment, this command can be useful for resolving interoperability issues with disparate vendor equipment. For example, the security device rejects SIP messages containing unsupported SIP “methods.” By permitting unknown SIP messages in this case, you can get your network operational and later analyze your VoIP traffic to determine why some messages were being dropped.

Note that this command applies only to received packets identified as supported VoIP packets. If a packet cannot be identified, it is always dropped. If a packet is identified as a supported protocol and **unknown-message** is set to **permit**, the message is forwarded without processing.

- **nat**—Specifies that unknown messages be allowed to pass if the session is in NAT mode.
- **route**—Specifies that unknown messages be allowed to pass if the session is in route mode. (Sessions in transparent mode are treated as route mode).
- **calls [details]**—Displays the number of active calls and, optionally, information about those calls. The maximum number of calls possible on a security device depends on the platform type. For more information, see the datasheet for your product.
- **counters**—Displays or clears SCCP ALG statistics.
- **enable**—Enables and disables the SCCP ALG on the device (the default is enabled).
- **inactive-media-timeout number**—Specifies how long pinholes and sessions opened for media are kept alive in the absence of activity. The default is 120 seconds; the range is 10 to 600 seconds.

sip

```

get alg sip [ ... ]
set alg sip [ ... ]
unset alg sip [ ... ]
clear alg sip [ ... ]

```

sip

Specifies the Session Initiation Protocol ALG on the device.

- **app-screen protect deny** [**dst-ip** [ip_addr/mask | **ipv6** ipv6-addr / prefix_length] | **timeout** number]—Specifies that repeat SIP INVITE requests be denied to a proxy server that denied the initial request.
 - **dst-ip**—Specifies the IP address and netmask of the proxy server or other SIP server.
 - **ipv6**—Specifies the IPv6 address and netmask of the proxy server or other SIP server.
 - **timeout**—Specifies the time in seconds the proxy server denies repeated SIP messages before it begins accepting them again. The default is 5 seconds; the range is 1 to 3600 seconds.
- **app-screen unknown-message** [**nat** | **route**] **permit**—Specifies how unidentified messages are handled by the security device. The default is to drop unknown messages. Permitting unknown messages can compromise security and is not recommended. However, in a secure test or production environment, this command can be useful for resolving interoperability issues with disparate vendor equipment. For example, the security device rejects SIP messages containing unsupported SIP “methods.” By permitting unknown SIP messages in this case, you can get your network operational and later analyze your VoIP traffic to determine why some messages were being dropped.

Note that this command applies only to received packets identified as supported VoIP packets. If a packet cannot be identified, it is always dropped. If a packet is identified as a supported protocol and **unknown-message** is set to **permit**, the message is forwarded without processing.

 - **nat**—Specifies that unknown messages be allowed to pass if the session is in NAT mode.
 - **route**—Specifies that unknown messages be allowed to pass if the session is in route mode. (Sessions in transparent mode are treated as route mode.)
- **C-timeout**—Specifies the INVITE transaction timeout at the proxy, in minutes; the default is 3. Because the SIP ALG is in the middle, instead of using the INVITE transaction timer value B (which is $(64 * T1) = 32$ seconds), the SIP ALG gets its timer value from the proxy.
- **calls** [**details**]—Displays and clears the number of active calls and information about those calls. The maximum number of calls possible on a security device depends on the platform type. For more information, see the datasheet for your product.
- **counters**—Displays and clears SIP ALG statistics counters.
- **details**—Displays information about active calls.
- **enable**—Enables and disables the SIP ALG on the device (the default is enabled).
- **media-inactivity-timeout**—Specifies how long sessions opened are kept alive in the absence of active media. The default is 120 seconds. The minimum is 10 seconds; the maximum is 2550 seconds.
- **memory**—Displays SIP memory utilization.

- **rate**—Displays or clears SIP ALG performance records.
- **setting**—Displays the inactivity timeout parameters for SIP signaling and media, and the destination address of a SIP proxy server protected from repeat SIP INVITE requests from the proxy server initially rejected. Also provides information about the SIP application screen configuration.
- **signaling-inactivity-timeout**—Configures or removes the maximum length of time in seconds a call can remain active without any SIP signaling traffic. Each time a SIP signaling message occurs within a call, this timeout resets. The default is 43200 seconds (12 hours). The minimum is 10; the maximum is 65535.
- **transactions**—Displays SIP ALG transactions.
- **T1-interval**—Specifies the roundtrip time estimate, in seconds, of a transaction between endpoints. The default is 500 milliseconds. Because many SIP timers scale with the T1-Interval (as described in RFC 3261), when you change the value of the T1-Interval timer, those SIP timers also are adjusted.
- **T4-interval**—Specifies the maximum time a message remains in the network. The default is 5 seconds. Because many SIP timers scale with the T4-Interval (as described in RFC 3261), when you change the value of the T4-Interval timer, those SIP timers also are adjusted.

sql

```
get alg sql
set alg sql enable
unset alg sql enable
```

sql Specifies the SQL ALG on the device (the default is enabled).

sunrpc

```
get alg sunrpc
set alg sunrpc enable
unset alg sunrpc enable
```

sunrpc Specifies the Sun Remote Procedure Call ALG on the device (the default is enabled).

alias

Use the **alias** commands to create, remove, or list aliases. An alias is a named variable containing the initial characters of a CLI command. After creating an alias, you can use it to execute the represented command.

Syntax

get

get alias

set

set alias *name_str* *string*

Keywords and Variables

Variable Parameters

name_str The name of the CLI command alias.

string The CLI command to which you assign the alias.

Example: The following commands create an alias representing the **get interface ethernet1/1** command, then execute the command using the alias:

```
set alias int_1 "get interface ethernet1/1"  
int_1
```


all

Use the **all** command to return all configuration settings to the factory default values.

Syntax

`unset all`

Keywords and Variables

None.

Example

In the following example, you reset the device to its factory default settings and reset the device.

1. Execute the **unset all** command.

unset all

The following prompt appears: "Erase all system config, are you sure y / [n]?"

2. Press the **Y** key. This action returns the system configuration to the factory default settings.

3. Execute the **reset** command.

reset

The following prompt appears: "Configuration modified, save? [y] / n"

4. Press the **N** key. This action generates the following prompt: "System reset, are you sure? y / [n]"
5. Press the **Y** key. This action restarts the system. The device now has its original factory default settings.

anti-spam

Use the **anti-spam** commands to create and modify an anti-spam profile. You can use these profiles in policies to filter out suspected spam messages. An anti-spam profile allows you to designate lists of IP addresses, emails, hostnames, or domain name as malicious (spam) or benign (not spam). The profile can include lists of the following types:

- Public-based whitelists or blacklists

If the connection is from a mail-forwarding agent, the device can filter the connection's source-IP address using lists of devices deemed to be benign (whitelist) or malicious (blacklist).
- Custom-defined whitelists or blacklists
 - Domain-name-based whitelists or blacklists. The device can use such lists to filter connections that use domain names deemed to be benign or malicious.
 - Address-book-based whitelists or blacklists. The device can use such lists to base filtering on the sender's email address or domain. By default, any email server should accept its own user's email.

NOTE: This release supports anti-spam for Simple Mail Transfer Protocol (SMTP) only.

To execute most anti-spam commands, it is necessary to initiate the anti-spam context. For more information, see "Context Initiation" on page 60. This anti-spam feature is not meant to replace your anti-spam server, but rather to complement it.

Blacklists and Whitelists

The anti-spam feature requires that the security device have Internet connectivity with the Spam Block List (SBL) server. Domain Name System (DNS) must be available to access the SBL server. The firewall performs reverse DNS lookups on the source of the SMTP sender (or relaying agent), adding the name of the SBL server (such as sbl-server) as the authoritative domain. The DNS server then forwards each request to the SBL server, which returns a value to the device.

Alternatively, you can configure local white and blacklists. In this case, by default the system checks first against the local database of white/blacklists. If it does not find the name, the firewall proceeds to query the SBL server located on the Internet.

Basic Configuration

The following command provides a basic example of anti-spam configuration. The command is used to prevent a corporate email server from receiving and distributing spams. Corporate users retrieve emails from an internal email server without going through the firewall. This should be a typical configuration in an enterprise environment.

```
set anti-spam profile ns-profile
set policy from untrust to trust any mail-server SMTP permit log anti-spam ns-profile
```

Context Initiation

Executing the **set anti-spam profile ns-profile** command without specifying further options places the CLI within the context of a new or existing anti-spam profile. For example, you first use the following commands to define a profile named **ns-profile**, then you enter the ns-profile context to instruct the device to drop suspected spam messages:

```
device-> set anti-spam profile ns-profile
device(anti-spam:ns-profile)-> set default action drop
```

After you enter an anti-spam context, all subsequent command executions modify the specified anti-spam profile (**ns-profile** in this example). To save your changes, you must first exit the anti-spam context, then enter the **save** command:

```
device(anti-spam:ns-profile)-> exit
device-> save
```

Syntax

clear

clear anti-spam stat

exec

exec anti-spam testscan *string*

get

get anti-spam

set

set anti-spam profile ns-profile

The following **get** and **set** commands are executable in the anti-spam context.

get (within the profile context)

```
get { blacklist | default | sbl | whitelist }
```

set (within the profile context)

```

set
{
  blacklist string |
  default action { drop | tag [ { header | subject } string ] }
  sbi default-server enable |
  whitelist string
}

```

Keywords and Variables

blacklist (Within the Profile Context)

```

get blacklist
set blacklist string
unset blacklist string

```

Use the **blacklist** command to add or remove an IP address, an email, a hostname, or a domain name from the local anti-spam blacklist. Each entry in a blacklist can identify a possible spammer. The following table shows some possible entries.

Type of Entry	Sample Content
IP address	11.22.33.44
Email	admin@www.wibwaller.com
Hostname	www.wibwaller.com
Domain name	wibwaller.com

string A pattern inserted into the local blacklist. Such patterns identify spam messages. The pattern may include an IP address, an email, a hostname, or a domain name. Multiple strings are separated by semicolons (;).

Example1: These commands perform the following tasks:

1. Initiate a profile context (ns-profile).
2. Give the profile a black-list entry that prevents connections with the hostname www.wibwaller.com.
3. Exit the spam context and apply the profile to an existing policy (id 2).

```

device-> set anti-spam profile ns-profile
device(anti-spam:ns-profile)-> set blacklist www.wibwaller.com
device(anti-spam:ns-profile)-> exit
device-> set policy id 2 anti-spam ns-profile

```

Example2: These commands show blacklists with multiple entries:

```

device(anti-spam:ns-profile)-> set blacklist cat@aaa.com;1.1.1.1
device(anti-spam:ns-profile)-> set blacklist 47.YOU2Q.COM

```

default action (Within the Profile Context)

```
get default
set default action drop
set default action tag header string
set default action tag subject string
unset default action
```

Use the **default** commands to specify how the device handles messages deemed to be spam. The device can either drop a spam message or identify it as spam by tagging it.

drop	Instructs the device to drop all messages identified as spam.
tag	Instructs the device to tag all messages identified as spam, without dropping the messages. Use <i>string</i> to tag a spam email. The default tag is ***SPAM*** and can be any user-defined string up to 40 bytes. You can place the tag in either of two email message areas: <ul style="list-style-type: none"> ■ header <i>string</i> places <i>string</i> in the header of the message. ■ subject <i>string</i> places <i>string</i> in the subject of the message.

Example: These commands perform the following tasks:

1. Initiate a profile context (ns-profile).
2. Specify that email messages deemed to be spam have the string "This is spam" in the message header.
3. Exit the spam context and apply the profile to an existing policy (id 2).

```
device-> set anti-spam profile ns-profile
device(anti-spam:ns-profile)-> set default action tag header "This is spam"
device(anti-spam:ns-profile)-> exit
device-> set policy id 2 anti-spam ns-profile
```

profile

```
set anti-spam profile ns-profile
unset anti-spam profile ns-profile
```

Configures the default anti-spam profile, ns-profile.

sbl (Within the Profile Context)

```
get sbl
set sbl default-server-enable
unset sbl default-server-enable
```

Use the **sbl** command to enable use of the external spam-blocking SBL service, which uses a blacklist to identify known spam sources. The service replies to queries from the device about whether an IP address belongs to a known spammer.

default-server-enable Enables the default SBL service. The server for this service contains a blacklist of known spam sources. The service identifies each source by an IP address.

Example: These commands perform the following tasks:

1. Initiate a profile context (ns-profile).
2. Enable use of the default anti-spam service.
3. Exit the spam context and apply the profile to an existing policy (id 2).

```
device-> set anti-spam profile ns-profile
device(anti-spam:ns-profile)-> set sbl default-server-enable
device(anti-spam:ns-profile)-> exit
device-> set policy id 2 anti-spam ns-profile
```

stat

```
clear anti-spam stat
```

Clears all accumulated statistical anti-spam counters.

testscan

```
exec anti-spam testscan string
```

Tests the anti-spam scan engine where *string* can be an IP address, a domain name, or an email address. The result is displayed to the console (serial port) only and is not displayed to a Telnet terminal. The result is also available in the debug buffer (**get dbuf stream**). Juniper Networks recommends to use this command to test your anti-spam scan engine.

Example: The following examples validate an SMTP sender. The firewall tests to see if the domain resides on the whitelist or blacklist.

```
exec antispan testscan spammer.org
exec antispan testscan the.very.bad.spammers.com
```

whitelist (Within the Profile Context)

```
get whitelist
set whitelist string
unset whitelist string
```

Use the **whitelist** command to add or remove an IP address, an email, a hostname or a domain name from the local whitelist. Each entry in a whitelist can identify an entity that is not a suspected spammer. The following table shows some possible entries.

Type of Entry	Sample Content
IP address	11.22.33.44
Email	admin@www.wibwaller.com
Hostname	www.wibwaller.com
Domain name	wibwaller.com

string A pattern inserted into the whitelist. Such patterns identify messages that are deemed not to be spam. The pattern may include an IP address, an email, a hostname, or a domain name.

Example 1: The following two commands show a domain name and an IP address. Multiple strings are separated by semicolons (;).

```
set whitelist cat@aaa.com;1.1.1.1
set whitelist 47.YOU2Q.COM
```

Example 2: These commands perform the following tasks:

1. Initiate a profile context (ns-profile).
2. Give the profile a whitelist entry that allows connections with the hostname www.fiddwicket.com.
3. Exit the spam context and apply the profile to an existing policy (id 2).

```
device-> set anti-spam profile ns-profile
device(anti-spam:ns-profile)-> set whitelist www.fiddwicket.com
device(anti-spam:ns-profile)-> exit
device-> set policy id 2 anti-spam ns-profile
```

arp

Use the **arp** commands to create, remove, or list interface entries in the Address Resolution Protocol (ARP) table of the security device.

Syntax

clear

```
clear [ cluster ] arp [ ip_addr | all ]
```

get

```
get arp [ all | asic id_num]
```

set

```
set arp  
{  
  ip_addr mac_addr interface |  
  age number |  
  always-on-dest |  
  nat-dst |  
}
```

Keywords and Variables

Variable Parameters

```
set arp ip_addr mac_addr interface
```

<i>ip_addr</i>	The IP address of a network device to which you want to make a static entry in the ARP table.
<i>mac_addr</i>	The MAC address of a network device to which you want to make a static entry in the ARP table.
<i>interface</i>	The name of the interface through which the security device can direct traffic to reach the network device with the specified IP and MAC addresses. For more information, see “Interfaces” on page 771.

all

get arp all

all Lists all current ARP entries for every existing virtual system (vsys).

asicget asic *id_num*

asic Lists all current ARP entries for each Application-Specific Integrated Circuit (ASIC) chip identified by ID number.

ageset arp age *number*

age Sets the age-out value (in seconds) for ARP entries. The default value is 1200 seconds (20 minutes).

always-on-dest

set arp always-on-dest

always-on-dest Directs the security device to send an ARP request for any incoming packet with a heading containing a MAC address not yet listed in the MAC address table. This may be necessary when packets originate from server load-balancing (SLB) switches or from devices using the Hot Standby Router Protocol/Virtual Router Redundancy Protocol (HSRP/VRRP).

cluster

clear [cluster] arp

cluster Propagates the **clear** operation to all other devices in a NetScreen Redundancy Protocol (NSRP) cluster.**nat-dst**set arp nat-dst
unset arp nat-dst

nat-dst Configures the security device to respond to ARP requests sent by the host during NAT destination policy configuration.

asic

Use the **asic** commands to display the configuration details, functions, counters, and packet flow process of a packet processing unit (PPU) in an Application-Specific Integrated Circuit (ASIC) used in high-end platforms.

Syntax

get

```
get asic
{
  mapping |
  ppu
  {
    configuration |
    defrag |
    dest-mac-check { drop-counter | status } |
    functions |
    ha-idp-fwd |
    idp |
    syn-cookie |
    syn-proxy |
    tcp-3way-check |
  }
}
```

Keywords and Variables

mapping

get asic mapping

mapping Identifies the number of ASICs that each series of Juniper Networks security devices supports.

ppu

get asic ppu {...}

ppu Specifies the programmable hardware engine called the packet processing unit (PPU) in the ASIC

- **configuration**—Displays the configuration details of ASIC in shared memory.
- **defrag**—Specifies defragmentation statistics for encrypted and clear-text packets.
- **dest-mac-check**—Specifies the destination MAC check conducted on a TCP Syn packet when SYN-Cookie is detected.
 - **status**—Indicates if the **dest-mac-check** feature is enabled. By default, the **dest-mac-check** feature is disabled in the PPU.
 - **drop-counter**—Indicates the number of packets that are dropped as a result of mismatch in the destination MAC address.
- **functions**—Specifies the different functions of the PPU.
- **ha-idp-fwd**—Represents the counter statistics related to HA and IDP packets forwards.
- **idp**—Specifies the IDP process statistics in the PPU.
- **syn-cookie**—Displays the process statistics of SYN-Cookies in the PPU. This command is supported only on IPv4.
- **syn-proxy**—Displays the process statistics of SYN-Proxy in the PPU. This command is supported only on IPv4.
- **tcp-3way-check**—Displays the output of a **TCP-3way-check** operation conducted to establish an authenticated communication channel between endpoints.

attack

Use the **attack** commands to view and define attack objects and database-server settings for attack objects. You can also use **attack** commands to download predefined signature packs.

NOTE: This command is available only if an advanced mode license key is installed on the device.

Use **attack** along with the **attack-db** and **di** commands, described on page 77 and page 187, respectively.

Syntax

get

```
get attack
[
  name_str |
  anomaly [ sort-by { id | name } ] |
  db { pattern-update } |
  disable [ sort-by { def-type | id | name | type } ] |
  group [ name_str | sort-by { def-type | name } ] |
  id id_num |
  signature sort-by { def-type | id | name } |
  sort-by { def-type | id | name | type }
]
```

set

```
set attack
{
  CS:name_str
  {
    aim-chat-room-desc |
    aim-chat-room-name |
    aim-get-file |
    aim-nick-name |
    aim-put-file |
    aim-screen-name |
    dns-cname |
    ftp-command |
    ftp-password |
```

```

ftp-pathname |
ftp-username |
gnutella-http-get-filename |
http-authorization |
http-header-user-agent |
http-request |
http-status |
http-text-html |
http-url |
http-url-parsed |
http-url-variable-parsed |
imap-authenticate |
imap-login |
imap-mailbox |
imap-user |
msn-display-name |
msn-get-file |
msn-put-file |
msn-sign-in-name |
pop3-auth |
pop3-header-from |
pop3-header-line |
pop3-header-subject |
pop3-header-to |
pop3-mime-content-filename |
pop3-user |
smb-account-name |
smb-connect-path |
smb-connect-service |
smb-copy-filename |
smb-delete-filename |
smb-open-filename |
smtp-from |
smtp-header-from |
smtp-header-line
smtp-header-subject
smtp-header-to |
smtp-mime-content-filename |
smtp-rcpt |
stream256 |
ymsg-alias |
ymsg-chatroom-message |
ymsg-chatroom-name |
ymsg-nickname |
ymsg-p2p-get-filename-url |
ymsg-p2p-put-filename-url |
ymsg-user-name
}
    [ not ] string
        severity { info | low | medium | high | critical } |
db
{
mode { notification | update } |
pattern-update use-proxy |
schedule
{

```

```

    daily hh:mm |
    monthly number hh:mm |
    weekly day hh:mm
  } |
  server url_str
  sigpack { base | client | server | worm }
} |
disable name_str |
group name_str1 [ add name_str2 ] |
}

```

Keywords and Variables

Variable Parameter

```

get attack name_str
set attack name_str aim-chat-room-desc string severity string
...
set attack name_str ymsg-user-name string severity string
unset attack name_str

```

<i>name_str</i>	<p>Defines the attack-object name. If it is a user-defined attack, it must be prefaced with <i>CS</i>.</p> <p>Specifies one of the following contexts for Deep Inspection (DI) to search and defines the signature string for which the DI module searches:</p> <ul style="list-style-type: none"> ■ aim-chat-room-desc <i>string</i> ... ■ ymsg-user-name <i>string</i> <p>severity—Defines the severity level of the attack. You can specify any of the following levels: info, low, medium, high, critical.</p>
-----------------	---

NOTE: For a complete list of contexts that you can specify when creating your own attack objects, see *Volume 4: Attack Detection and Defense Mechanisms* in the *Concepts & Examples ScreenOS Reference Guide*.

Example: The following command creates an attack object for FTP named **CS:rootuser**, specifies its context as **ftp-username**, defines its signature as **root**, and specifies its severity level as **high**:

```
set attack CS:rootuser ftp-username root severity high
```

anomaly

```
get attack anomaly [ sort-by { id | name } ]
```

anomaly	Displays protocol-anomaly attack objects currently stored in the local database.
sort-by	Indicates the organization for the display of protocol anomalies in the local database—either numerically by id or alphabetically by name .

attack

get attack

attack Displays all attack objects currently stored in the local database, displaying—in alphabetical order—first user-defined attacks (if any) and then predefined attacks.

db

get attack db

set attack db mode { notification | update }

set attack db pattern-update use-proxy

set attack db schedule { daily *hh:mm* | monthly number *hh:mm* | weekly day *hh:mm* }set attack db server *url_str*

unset attack db { mode | pattern-update use-proxy | schedule | server | sigpack }

db Specifies the attack-object database server. On security devices that support virtual systems, you must set this command at the root level.

mode—Selects either **notification** or **update** as the mode for checking and updating the attack-object database. The **notification** method automatically checks the attack-object database server at user-defined times and notifies the admin if the database on the server is more recent than the one on the security device. (If the data on the server is more recent, a notice appears on the WebUI main page and in the CLI after you log into the device.) The **update** method automatically checks the attack object database server at user-defined times and automatically updates the database on the security device if it determines that the database on the server is more recent than the one on the security device.

Unsetting this command stops the security device from automatically checking the server.

pattern-update—Sets the mode of attack-object pattern updates.

■ **use-proxy**—Enables the security device to update its attack-object database through the HTTP/SSL proxy server.

schedule string—Sets the time for automatically checking the attack-object database server and updating the attack object database on the security device. You can set a daily, monthly, or weekly schedule.

server url_str—Defines the URL of the attack-object database server. ScreenOS provides four predefined DI signature packs: base, server, client, and worm. The base signature pack is the default. If you do not specify a signature pack as shown in Example 1, then the basic signature pack is retrieved.

Unsetting the attack object database server retrieves the basic signature pack only. If you run the **exec attack-db update** command with a server URL set to null, then the base signature pack from the following URL is loaded:

<https://services.netscreen.com/restricted/sigupdates>

sigpack—Specifies the predefined signature packs. To use a signature pack, you must purchase a DI database license key and download the appropriate package for your environment from the Juniper Networks Web site.

ScreenOS provides four predefined DI signature packs:

- **base**—Includes a sample of worm, client-to-server, and server-to-client signatures for Internet-facing protocols and services, such as HTTP, DNS, FTP, SMTP, POP3, IMAP, NetBIOS/SMB, MS-RPC, P2P, and IM (AIM, YMSG, MSN, and IRC).
- **server**—Focuses on protecting a server farm. It includes a comprehensive set of server-oriented protocols, such as HTTP, DNS, FTP, SMTP, IMAP, MS-SQL, and LDAP. Also includes worm signatures that target servers.
- **client**—Focuses on protecting users from getting malware, Trojans, and so on while surfing the Internet. Includes a comprehensive set of client-oriented protocols, such as HTTP, DNS, FTP, IMAP, POP3, P2P, and IM (AIM, YMSG, MSN, and IRC). Also includes worm signatures that target clients.
- **worm**—Includes stream signatures and primarily focuses on providing comprehensive worm protection. Detects server-to-client and client-to-server worm attacks for all protocols.

The base signature pack is the default. If you do not specify a signature pack as shown in Example 1, then the base signature pack is retrieved.

Note: Your security device allows you to load one signature pack at a time.

The **unset attack db sigpack** command followed by the **exec attack-db update** command retrieves the basic signature pack. See “attack-db” on page 77.

Example 1: The following command configures your security device to retrieve the server signature pack:

```
set attack db sigpack server
```

Example 2: Use the following URL strings to configure your security device to retrieve the base, server, client, or worm signature packs, respectively:

```
set attack db server http://services.netscreen.com/restricted/sigupdate
set attack db server http://services.netscreen.com/restricted/sigupdate/server
set attack db server http://services.netscreen.com/restricted/sigupdate/client
set attack db server http://services.netscreen.com/restricted/sigupdate/worm
```

Example 3: The following commands define the URL of the attack-object database server and set a schedule to check the server automatically and then notify the security device admin when the database on the server is more recent than that on the security device:

```
set attack db server http://www.juniper.net/attacks
set attack db schedule daily 07:00
set attack db mode notification
```

disable

```
set attack disable name_str
unset attack disable name_str
get attack disable
get attack disable sort-by [ sort-by { def-type | id | name | type } ]
```

disable Disables the specified predefined attack object or a list of all disabled attack objects. You can organize the display of the list by one of the following attributes:

- **def-type**—Organizes the disabled attack-object display by anomaly and then by signature, and then within each of these two categories, alphabetically by protocol.
- **id**—Organizes the disabled attack-object display numerically by ID number.
- **name**—Organizes the disabled attack-object display alphabetically by attack name.
- **type**—Organizes the disabled attack-object display alphabetically by anomaly and then by signature.

group

```
get attack group [ name_str | sort-by { def-type | name } ]
set attack group name_str1 [ add name_str2 ]
unset attack group name_str1 [ remove name_str2 ]
```

group Specifies an attack-object group.

sort-by Indicates the organization for the display of attack groups from the local database:

- **def-type**—Organizes the attack-group display by the definition type of the group, displaying—in alphabetical order—first user-defined groups (if any) and then predefined attack groups.
- **name**—Organizes the attack-group display alphabetically by attack-group names, regardless of whether they are user-defined or predefined. However, because all user-defined attack group names must begin with “CS:”, they appear together alphabetically anyway.

name_str specifies a name for the creation, deletion, or modification of an attack group. The keywords **add** and **remove** indicate whether you are adding or deleting an attack from the specified group.

Example: The following command displays all the attack groups on the security device by name in alphabetical order:

```
get attack group sort-by name
```

id

```
get attack id id_num
```

id Specifies the ID number of an attack object in the local database.

Example: The following command displays the attack object with ID number 500 in the security device:

```
get attack id 720
```

not

```
set attack CS:name_str not string1 severity string2
```

not Defines as an attack object anything in the specified context except the user-defined attack pattern.

Example: The following command defines the attack object named **CS:badlogin** as anything except the permitted FTP username **jj2345** with a medium-level severity:

```
set attack CS:badlogin ftp-username not jj2345 severity medium
```

signature

```
get attack signature [ sort-by { def-type | id | name } ]
```

signature Displays stateful-signature attack objects currently stored in the local database.

- **sort-by**—Specifies the organizational display of signature attack-objects by one of the following attributes:
 - **def-type**—Organizes the stateful-signature attack-object display by the definition type of the attack object, displaying—in alphabetical order—first user-defined objects (if any) and then predefined attack objects.
 - **id**—Organizes the stateful-signature attack-object display numerically by ID number, first listing user-defined attack objects, which have no ID number, and then predefined attack objects.
 - **name**—Organizes the stateful-signature attack-object display alphabetically by attack name.

Example: The following command displays signature-attack objects alphabetically by name:

```
get attack signature sort-by name
```

sort-by

```
get attack sort-by { def-type | id | name | type }
```

sort-by Specifies the organizational display of attack objects in the local database by one of the following attributes:

- **def-type**—Organizes the attack-object display by the definition type of the attack object—first anomaly and then stateful-signature attack objects.
- **id**—Organizes the attack-object display numerically by ID number.
- **name**—Organizes the attack-object display alphabetically by attack name.
- **type**—Organizes the attack-object display alphabetically, first by anomaly and then by signature.

Example: The following command displays all attack objects in the security device organized numerically:

```
get attack sort-by id
```


attack-db

Use the **attack-db** commands to check and perform signature pack or attack-object database updates. ScreenOS provides four predefined signature packs. For more information about the signature packs, see “attack” on page 69. Use the **attack-db** command along with the **di** command described on page 187.

NOTE: This command is available only if advanced mode and the Deep Inspection (DI) key are installed on the device.

Syntax

```
exec attack-db { check | update }
```

Keywords and Variables

check

```
exec attack-db check
```

check Immediately checks if the attack-object database on the server is more recent than the one on the security device.

update

```
exec attack-db update
```

update Updates the attack-object database on the security device immediately with the database stored on the attack-object database server.

audible-alarm

Use the **audible-alarm** commands to activate the audible-alarm feature.

Syntax

get

```
get audible-alarm
```

set

```
set audible-alarm { all | battery | fan-failed | power-failed | temperature }
```

Keywords and Variables

all

```
set audible-alarm all  
unset audible-alarm all
```

all Enables or disables the audible alarm in the event of a fan failure, an interface module failure, a power-supply failure, or a temperature increase above an admin-defined threshold.

battery

```
set audible-alarm battery  
unset audible-alarm battery
```

battery Enables or disables the audible alarm in the event of a battery failure.

fan-failed

```
set audible-alarm fan-failed  
unset audible-alarm fan-failed
```

fan-failed Enables or disables the audible alarm in the event of a fan failure.

module-failed

set audible-alarm module-failed
unset audible-alarm module-failed

module-failed Enables or disables the audible alarm in the event of an interface-module failure.

power-failed

set audible-alarm power-failed
unset audible-alarm power-failed

power-failed Enables or disables the audible alarm in the event of a power-supply failure.

temperature

set audible-alarm temperature
unset audible-alarm temperature

temperature Enables or disables the audible alarm if the temperature rises above an admin-defined threshold.

auth

Use the **auth** commands to specify a user-authentication method.

The five available methods include:

- Built-in database
- RADIUS server
- SecurID
- Lightweight Directory Access Protocol (LDAP)
- Terminal Access Controller Access Control System+ (TACACS+)

NOTE: If the security device uses SecurID to authenticate users, and communication problems occur with the ACE server, clear the current SecurID shared secret from the device (and the server) by executing the **delete node_secret** command.

Syntax

clear

```
clear [ cluster ] auth
  [
    history |
    queue |
    statistics |
    table [ id id_num | infranet [ auth_id id_num ] | ipaddr ip_addr ]
  ]
```

exec

```
exec auth
  {
    table [ id id_num | infranet
      {
        auth-id id_num;
        ip ip_addr;
        idle-timeout seconds;
        role string;
        role-names string |
```

```

src-zone |
user |
user-context |
vsys }
}

```

get

```

get auth
[
  banner |
  history [ id id_num | ip ip_addr ] |
  queue |
  settings [ radius accounting ] |
  statistics |
  table [ id id_num | infranet [ auth_id id_num ] | ip ip_addr ]
]

```

set

```

set auth
{
  banner { ftp | http | telnet } { fail string | login string | success string }
  default auth server name_str |
  radius accounting
  {
    action cleanup-session |
    port port_num
  } |
}

```

Keywords and Variables

banner

```

get auth banner
set auth banner { ftp | http | telnet }
unset auth banner { ftp | http | telnet }

```

banner Defines or displays firewall banners. The security device uses these banners to report the success or failure of login requests.

- **ftp** Reports on the success or failure of FTP login requests.
- **http** Reports on the success or failure of HTTP login requests.

- **telnet** Reports on the success or failure of Telnet login requests.
 - **fail string**—Specifies a message string to display when a login attempt is unsuccessful.
 - **login string**—Specifies a message string to display when a login prompt appears.
 - **success string**—Specifies a message string to display when a login attempt is successful.

FTP, HTTP, and Telnet login, success, and fail banners can each be up to 4000 or greater bytes in length. You can include multiple line breaks in a banner by inserting the special symbol “/n” wherever you want to insert a line break.

Example: The following command defines a banner for a failed FTP login attempt:

```
set auth banner ftp fail "FTP login attempt failed"
```

cluster

```
clear [ cluster ] auth [ ... ]
```

cluster Propagates the **clear** operation to all other devices in a NetScreen Redundancy Protocol (NSRP) cluster.

default

```
set auth default auth server name_str
unset auth default auth server
```

default auth server Specifies a default firewall authentication server (*name_str*). The security device uses this server when a security policy does not explicitly identify an authentication server.

Example: The following command identifies the default authentication server (Auth_Server):

```
set auth default auth server Auth_Server
```

history

```
clear [ cluster ] auth history
get auth history [ id id_num | ip ip_addr ]
```

history Clears or displays the history of users authenticated through the security device.

queue

```
clear [ cluster ] auth queue
get auth queue
```

queue Clears or displays the internal user authentication queue.

radius accounting

```
set auth radius accounting action cleanup-session
set auth radius accounting port port_num
unset auth radius accounting action cleanup-session
unset auth radius accounting port
```

radius
accounting

This feature allows any organization that owns or controls a RADIUS server to track RADIUS session information for billing, monitoring, or other purposes. For example, a RADIUS server might need to record information about when authorized sessions begin, when they end, the number of bytes or packets exchanged during each session, and so on. Such tracking is generally referred to as *RADIUS accounting*. Each RADIUS accounting session begins when the RADIUS server receives an Accounting-Start message and ends when it receives an Accounting-Stop message.

RADIUS accounting allows the device to monitor and manage authorized sessions. For example, a device might clear out zombie sessions when it receives an Accounting-Stop message from an external RADIUS client. This could prevent misuse of wireless calls if a subsequent user gets a previous user's assigned IP address and attempts to use the previous user's session.

The port (*port_num*) setting specifies the port through which the device receives Accounting-Start and Accounting-Stop messages. In addition, the **cleanup-session** feature allows the device to clear out zombie sessions when it receives an Accounting-Stop message from an external RADIUS client. This feature prevents misuse of wireless calls if subsequent users get the same assigned IP address and happen to use the previous user's session in the device.

Note: This feature is not supported on the vsys level and is for the root level only. This feature is only for clearing zombie sessions. Enablement this feature is not required for the security device to support RADIUS accounting while communicating with the RADIUS server.

settings

```
get auth settings radius accounting
```

settings

Displays default user authentication server settings. (This option yields the same display as the **get auth** command.) If you specify **radius accounting**, the device displays RADIUS-related parameters.

statistics

```
clear auth statistics
get auth statistics
```

statistics

Clears or displays authentication run-time statistics.

table

```
clear [ cluster ] auth table [ id id_num | infranet [ auth_id id_num ] | ip ip_addr ]
get auth table [ id id_num | infranet [ auth_id id_num ] | ip ip_addr ]
```

table Displays or clears entries in the user auth table. Clearing the entries forces reauthentication. Entries in the user auth table can represent:

- Users currently authenticated
- Users currently undergoing authentication
- Users denied authentication

Without parameters (described below), the **table** option clears or displays all table entries.

- **id** *id_num*—Clears or displays a particular entry by ID (*id_num*).
- **infranet**—Clears or displays a list of all Infranet Controller auth table entries. The output includes an auth-id, a source IP address, a username, and a role ID for each auth table entry.
 - **auth_id** *id_num*—Displays information about a specific Infranet Controller auth table entry. Specify the table entry's auth-id for *id_num*. The output includes a source IP address, a username, a role ID(s), and a role name(s) for the table entry. (For information about how to display the role ID in the Infranet Controller, see the *Unified Access Control Administration Guide*.)
- **ip** *ip_addr*—Clears or displays all entries with a common source-IP address (*ip_addr*).
- **idle-timeout** *seconds*—Specifies how long an Infranet auth table entry remains when there are no sessions for it. If you specify this value as 0, the auth table entry does not expire.

Example 1: The following command clears entry 7 from the user auth table:

```
clear auth table id 7
```

Example 2: The following command displays authentication details from a table entry with source IP 10.1.10.10:

```
get auth table ip 10.1.10.10
```

Example 3: The following commands display the Infranet users in the auth table:

```
device-> get auth table infranet
Total Infranet users in table: 1
auth-id src user roles age status srczone dstzone
2 10.64.9.26 user1 00000000 0 N/A Null Null
device-> get auth table infranet auth-id 2
Infranet Auth Id: 2
Source IP: 10.64.9.26
Username: user1
Roles: 0000000001.000005.0
Roles-names: Users
User Context:
Sessions associated: 0
Zone: Null->Null
```

Note that Username, **user1** is displayed in the output of the first and second command. Roles-names, **Users** is displayed in the second output only.

auth-server

Use the **auth-server** commands to configure the security device for user authentication with a specified authentication server. Administrators, policies, VPN tunnel specifications, and XAuth configurations use these server specifications to gain access to the appropriate resources.

Syntax

get

```
get auth-server
{
  name_str |
  all |
  id id_num
}
```

set

```
set auth-server name_str
{
  account-type { [ 802.1X ] [ admin ] | [ auth ] [ l2tp ] [ xauth ] } |
  backup1 { ip_addr | name_str } |
  backup2 { ip_addr | name_str } |
  fail-over revert-interval number |
  forced-timeout |
  id id_num |
  ldap
  {
    cn name_str |
    dn name_str |
    port port_num |
    server-name { ip_addr | name_str }
  } |
  radius
  {
    accounting-port number |
    attribute acct-session-id length number |
    compatibility rfc-2138 |
    port port_num |
    retries number |
    secret shar_secret |
    timeout number |
```

```

        zone-verification
    } |
    securid
    {
        auth-port port_num |
        duress number |
        encr id_num |
        retries number |
        timeout number
    } |
    server-name { ip_addr | name_str } |
    src-interface interface |
    tacacs { port port_num / secret shar_secret }
    timeout number |
    type { ldap | radius | securid | tacacs } |
    username
    {
        domain dom_name |
        separator string number number
    }
}

```

Keywords and Variables

Variable Parameter

```
set auth-server name_str [ ... ]
```

name_str Identifies the object name of the authentication server.

Example: The following command creates a server object name (radius1) and specifies type RADIUS:

```
set auth-server radius1 type radius
```

account-type

```
set auth-server name_str account-type { [ 802.1X ] [ admin ] | [ auth ] [ l2tp ] [ xauth ] }
```

account-type Specifies the types of users authenticated by the server (*name_str*).

- **802.1X** specifies that the server configuration uses only 802.1x protocol for wireless connectivity between the device and the authentication server.
- **admin** specifies admin users.
- **auth** specifies authentication users.
- **l2tp** specifies Layer 2 Tunneling Protocol (L2TP) users.
- **xauth** specifies XAuth users.

You can define a user as a single user type—an admin user, an authentication user, an L2TP user, or an XAuth user. You can combine auth, L2TP, and XAuth user types to create an auth-L2TP user, an auth-XAuth user, an L2TP-XAuth user, or an auth-L2TP-XAuth user. You cannot combine an admin user with another user type.

Specify admin users only for TACACS+ authentication.

all

```
get auth-server all
```

all Specifies all configured authentication servers.

backup1 | backup2

```
set auth-server name_str { backup1 { ip_addr | name_str } | backup2 { ip_addr |
  name_str } }
unset auth-server name_str { backup1 | backup2 }
```

backup1 The IP address or DNS name of the primary backup authentication server for an LDAP, a RADIUS, a SecurID, or a TACACS+ server type.

backup2 The IP address or DNS name of the secondary backup authentication server for an LDAP, a RADIUS, or a TACACS+ server type. SecurID does not support more than one backup server.

Example: With the following commands, you first create a RADIUS authentication server object named **radius1** at IP address **10.1.1.50**. It stores authentication user accounts. Then you define a primary backup server at **10.1.1.51** and a secondary backup server at **10.1.1.52**:

```
set auth-server radius1 server-name 10.1.1.50
set auth-server radius1 type radius
set auth-server radius1 account-type auth
set auth-server radius1 backup1 10.1.1.51
set auth-server radius1 backup2 10.1.1.52
```

fail-over

```
set auth-server name_str fail-over revert-interval number |
unset auth-server name_str fail-over revert-interval
```

fail-over This feature specifies the interval (expressed in seconds) that must pass after an authentication attempt, before the device attempts authentication through backup authentication servers. When an authentication request sent to a primary server fails, the security device tries the backup servers. If authentication via a backup server is successful, and the **revert-interval** time interval has elapsed, the device sends subsequent authentication requests to the backup server. Otherwise, it resumes sending the requests to the primary server. The range is 0 seconds (disabled) to 86400 seconds.

This feature applies to RADIUS, LDAP, and TACACS+ servers only.

forced-timeout

```
set auth-server forced-timeout number|
unset auth-server forced-timeout
```

forced-timeout Specifies the time, in minutes, after which access for the authenticated user is terminated. The auth table entry for the user is removed, as are all associated sessions for the auth table entry. Forced timeout behavior is independent of idle timeout setting. The default is 0 (disabled); the range is 0 to 10000 (6.9 days). Compare “timeout” on page 93.

id

```
get auth-server id id_num
set auth-server name_str id id_num
unset auth-server id id_num
```

id The user-defined identification number (*id_num*) of the authentication server. If you do not define an ID number explicitly, the security device creates one automatically.

Example: The following command creates an identification number (200) for the authentication server radius1:

```
set auth-server radius1 id 200
```

ldap

```
set auth-server name_str ldap { ... }
```

ldap Configures the security device to use an LDAP server for authentication.

- **cn** *name_str* The Common Name identifier used by the LDAP server to identify the individual entered in a LDAP server. For example, an entry of "uid" means "user ID" and "cn" means "common name".
- **dn** *name_str* The Distinguished Name identifier is the path used by the LDAP server before using the common name identifier to search for a specific entry (for example, c= us;o= juniper, where "c" stands for "country", and "o" for "organization").
- **port** *port_num*—Specifies the port number to use for communication with the LDAP server. The default port number for LDAP is 389.
- **server-name** *name_str*—The IP address or DNS name of the LDAP server.

Example: For an example of this option, see "Defining an LDAP Server Object" on page 95.

radius

```
set auth-server name_str radius { ... }
unset auth-server name_str radius { port | timeout }
```

- radius** Configures the security device to use a RADIUS server for authentication.
- **accounting-port** *number*—Specifies a target port for RADIUS accounting message.
- This command designates a port as the target for RADIUS accounting messages. The RADIUS accounting port number is authentication port number+ 1. The default RADIUS authentication port number is 1645 and the accounting port number is 1646. To reset the RADIUS accounting port to the default:
- ```
unset auth-server name_str radius accounting-port
```
- **attribute**—Specifies settings for RADIUS accounting.
- Each time an XAuth user connects to the device and the device authenticates the user, the device establishes a new acct-session-id, which identifies the accounting session. The accounting session lasts between the time the device sends the RADIUS server an Accounting-Start message and the time it sends an Accounting-Stop message. To identify the user, each RADIUS access or request message contains the calling-station-id.
- **acct-session-id length** *number* The length of the account-session-id in bytes. The acct-session-id uniquely identifies the accounting session. The default value is 11 bytes. The *number* setting is for accommodating some RADIUS servers that might have problems with the default length. You can set the length of acct-session-id from 6 bytes to 10 bytes, inclusive. To restore the default setting:  

```
unset auth-server name_str radius attribute acct-session-id length
```
  - **compatibility rfc-2138** Makes RADIUS accounting comply with RFC 2138, as compared with RFC 2865. For operations where RFC 2865 (the most recent standard) and RFC 2138 are mutually exclusive, the command works in accordance with RFC 2138 instead of RFC 2865. In cases where the behavior is additive, the command works compatibly with both RFC 2865 and RFC 2138.
  - **port** *port\_num* The port number on a RADIUS server to which the security device sends authentication requests. The default port number is 1645. You can change the default port number to any number between 1024 and 65535, inclusive.
  - **retries** *number* The number of retries sent to the RADIUS server before RADIUS authentication fails. The range is 1 to 20 retries.
  - **secret** *shar\_secret*—Specifies the RADIUS shared secret (*shar\_secret*) that is shared between the security device and the RADIUS server. The security device uses this secret to encrypt the user’s password that it sends to the RADIUS server.
  - **timeout** *number* The interval (in seconds) that the security device waits before sending another authentication request to the RADIUS server if the previous request does not elicit a response. The default is 3 seconds.

**Example:** For an example of these options, see “Defining a RADIUS Server Object” on page 95.

## **securid**

```
set auth-server name_str securid auth-port port_num
set auth-server name_str duress number
set auth-server name_str encr id_num
set auth-server name_str retries number
set auth-server name_str timeout number
```

**securid** Configures the security device to use a SecurID server for authentication.

- **auth-port** *port\_num*—Specifies the port number to use for communications with the SecurID server. The default SecurID port number is 5500.
- **duress** { 0 | 1 } If the SecurID server is licensed to use duress mode, a value of 0 deactivates it and 1 activates it. When duress mode is activated, a user can enter a special duress PIN number when logging in. The security device allows the login, but sends a signal to the SecurID server, indicating that someone is forcing the user to login against his or her will. The SecurID auth server blocks further login attempts by that user until he or she contacts the SecurID server admin.
- **encr** { 0 | 1 }—Specifies the encryption algorithm for SecurID network traffic. A value of 0 specifies SDI, and 1 specifies DES. We recommend the default encryption type DES.
- **retries** *number*—Specifies the number of retries between requests for authentication.
- **timeout** *number*—Specifies the length of time (in seconds) that the security device waits between authentication retry attempts.

**Example:** For an example of this option, see “Defining a SecurID Server Object” on page 95.

## **server-name**

```
set auth-server name_str server-name ip_addr
set auth-server name_str server-name name_str
```

**server-name** The IP address or DNS name of the authentication server.

## **src-interface**

```
set auth-server name_str src-interface interface
```

**src-interface** Instructs the device to transmit authentication requests (RADIUS or SecurID) through the specified interface.

## **tacacs**

```
set auth-server name_str tacacs { ... }
unset auth-server name_str tacacs { port | secret }
```

**tacacs** Configures the security device to use a TACACS+ server for authentication.

- **port** *port\_num* The TCP port on a TACACS+ server to which the security device sends authentication requests. The default port number is **49**. You can change the default port number to any number between 1024 and 32767, inclusive.
- **secret** *shar\_secret*—Specifies the TACACS+ shared secret (*shar\_secret*) that is shared between the security device and the TACACS+ server. The security device uses this secret to encrypt the user’s password that it sends to the TACACS+ server.

## **timeout**

```
set auth-server name_str timeout number
unset auth-server name_str timeout
```

**timeout** Specifies how many minutes must elapse after the termination of an authentication, L2TP, or XAuth user’s last session before the user needs to reauthenticate. The default timeout value is 10 minutes, and the maximum setting is 255 minutes. If the user initiates a new session before the countdown reaches the timeout threshold, the user does not have to reauthenticate and the timeout countdown resets.

If the user is an admin user, this setting specifies how many minutes of inactivity must elapse before the security device times out and closes an admin session. The default is 10 minutes and the maximum is 1000 minutes. Compare with “forced-timeout” on page 89.

**Example:** For an example of this option, see “Defining a SecurID Server Object” on page 95.

## **type**

```
set auth-server name_str type { ldap | radius | securid | tacacs }
```

**type** Specifies the type of authentication server—LDAP, SecurID, RADIUS, or TACACS+ . The **unset** command sets **type** to **radius**.

**Example:** For an example of this option, see “Defining a RADIUS Server Object” on page 95.

## username

```
set auth-server name_str username domain dom_name
set auth-server name_str username separator string number number
unset auth-server name_str username domain
unset auth-server name_str username separator
```

**username** Specifies a domain name for a particular auth server, or a portion of a username from which to strip characters. If you specify a domain name for the auth server, it must be present in the username during authentication.

The device uses a **separator** character to identify where stripping occurs. Stripping removes all characters to the right of each instance of the specified character, plus the character itself. The device starts with the right-most separator character.

The parameters for this feature are as follows:

- *string* is the character separator.
- *number* is the number of character separator instances with which to perform the character stripping.

If the specified number of separator characters (*number*) exceeds the actual number of separator characters in the username, the command stops stripping at the last available separator character.

**Note:** The device performs domain-name matching before stripping.

**Example:** In the following example, you strip characters to the right of two instances of a separator character in a username.

- Auth server name *Acme\_Server*
- Username *bob@hello@jnpr.com*
- Separator is *@*
- Number of instances *2*

```
set auth-server Acme_Server username separator bob@hello@jnpr.com number 2
```

The resulting username is **bob**.

## zone-verification

```
set auth-server name_str radius zone-verification
unset auth-server name_str radius zone-verification
```

**zone-verification** Verifies the zones the user is a member of and the zone configured on the port.

An authentication check can include support for zone verification. This command requires the specified RADIUS server to support RADIUS VSA enhancement. Authentication is allowed only if the zone configured on the port is a zone that a user is a member of.

In your dictionary file, add an attribute name of *Zone\_Verification* as a string attribute type. The vendor ID is 3224, and the attribute number is 10.

**Example:** For an example of this option, see “Defining a RADIUS Server Object” on page 95.

### ***Defining a RADIUS Server Object***

The following commands define an auth-server object for a RADIUS server:

```
set auth-server radius1 type radius
set auth-server radius1 account-type auth l2tp xauth
set auth-server radius1 server-name 10.1.1.50
set auth-server radius1 backup1 10.1.1.51
set auth-server radius1 backup2 10.1.1.52
set auth-server radius1 radius port 4500
set auth-server radius1 radius timeout 4
set auth-server radius1 radius secret A56htYY97kl
set auth-server radius1 radius zone-verification
save
```

If you are using vendor-specific attributes, you must load the netscreen.dct file on the RADIUS server.

### ***Defining a SecurID Server Object***

The following commands define an auth-server object for a SecurID server:

```
set auth-server securid1 type securid
set auth-server securid1 server-name 10.1.1.100
set auth-server securid1 backup1 10.1.1.110
set auth-server securid1 timeout 60
set auth-server securid1 account-type admin
set auth-server securid1 securid retries 3
set auth-server securid1 securid timeout 10
set auth-server securid1 securid auth-port 15000
set auth-server securid1 securid encr 1
set auth-server securid1 securid duress 0
save
```

### ***Defining an LDAP Server Object***

The following commands define an auth-server object for an LDAP server:

```
set auth-server ldap1 type ldap
set auth-server ldap1 account-type auth
set auth-server ldap1 server-name 10.1.1.150
set auth-server ldap1 backup1 10.1.1.151
set auth-server ldap1 backup2 10.1.1.152
set auth-server ldap1 timeout 40
set auth-server ldap1 ldap port 15000
set auth-server ldap1 ldap cn cn
set auth-server ldap1 ldap dn c=us;o=netscreen;ou=marketing
save
```

The following command lists all auth-server settings:

```
get auth-server all
```

### ***Defining a TACACS+ Server Object***

The following commands define an auth-server object for a TACACS+ server:

```
set auth-server tacacs1 type tacacs
set auth-server tacacs1 account-type admin
set auth-server tacacs1 server-name 10.1.1.50
set auth-server tacacs1 backup1 10.1.1.51
set auth-server tacacs1 backup2 10.1.1.52
set auth-server tacacs1 tacacs port 1050
set auth-server tacacs1 tacacs secret A56htYY97kl
set auth-server tacacs1 timeout 4
save
```

## av

On select security devices, use the **av** commands to perform the following tasks:

- Configure your device to support an external antivirus (AV) scanner

External AV scanning is when the security device redirects traffic to an external Internet Content Adaptation Protocol (ICAP) AV scan server. Use the commands in this section and in “icap” on page 277 to configure the ICAP client on your security device to support the external AV scanner.

- Configure your device to support the internal AV scanner (scan-mgr)

Internal AV scanning is when the embedded scanner (Juniper-Kaspersky scan engine) in the security device scans traffic for viruses.

- Support policy-based scanning

AV scanning profiles increase the flexibility and granularity of AV scans. You may scan for viruses based on application protocol, file extensions, or content type. Profile-based scanning allows you to configure a profile to scan traffic and assign the profile to a policy.

- Support antivirus scanning for instant messaging services: AIM, ICQ, Yahoo! Messenger, and MSN Messenger.

- Download or update AV pattern files regularly for internal AV scanner either from the Juniper server or the proxy server.

- Notify sender and receiver by email of virus information

For more information about antivirus concepts and how to use these commands, see *Volume 4: Attack Detection and Defense Mechanisms* in the *Concepts & Examples ScreenOS Reference Guide*.

---

**NOTE:** To activate internal AV scanning, you must first obtain and load an AV license key. An AV license is not required if you are using an external AV scanner.

---

## Context Initiation

---

Executing the **set av profile** *name\_str* command without specifying further options places the CLI within the context of a new or an existing AV profile. For example, the following commands initiate a custom profile named **jnpr-profile**, which by default is configured to scan FTP, HTTP, IMAP, POP3, SMTP, AIM-ICQ, MSNMS, YMSG, and ICAP traffic.

The following procedure invokes the profile and disables scanning of SMTP traffic:

1. Enter the AV profile context:

```
device-> set av profile jnpr-profile
device(av:jnpr-profile)->
```

After you enter an AV profile context, all subsequent command executions modify the specified AV profile (*jnpr-profile*).

2. Configure the AV scan engine to disable scanning of SMTP traffic:

```
device(av:jnpr-profile)-> unset smtp enable
```

3. Exit the AV profile context:

```
device (av:jnpr-profile)-> exit
```

4. Link the AV profile to a firewall policy. Only one AV profile can be linked to a specific firewall policy.

```
device-> set policy id policy_num av jnpr-profile
```

For more information about assigning an AV profile to a firewall policy, see “av” on page 544.

5. Save your changes:

```
device-> save
```

## Syntax

---

### **clear**

```
clear av statistics
```

### **exec (for Internal AV Only)**

```
exec av scan-mgr pattern-update
```

### **get**

```
get av
{
 all |
 extension-list name_str |
 http |
 mime-list name_str |
 notify-mail-charset |
 notify-mail-source |
 notify-mail-subject |
 profile name_str |
 scan-mgr |
 session
 [src-ip ip_addr/mask]
 [dst-ip ip_addr/mask]
 [src-port port_num1 [port_num2]]
 [dst-port port_num1 [port_num2]] |
 statistics |
 warning-message
}
```

### **set**

```
set av
{
 all { fail-mode { traffic [permit] } | resources number } |
 extension-list name_str { string1[;string2...;stringn] } |
 http
 {
 keep-alive |
 trickling
 {
 default |
 threshold number segment-size number trickle-size number
 timeout number |
 }
 } |
 mime-list name_str { string1 [;string2...;stringn] } |
 notify-mail-charset |
 notify-mail-source |
 notify-mail-subject |
 profile name_str |
 scan-mgr
 {
 corrupt-file drop |
 }
}
```

```

 decompress-layer drop |
 engine-not-ready drop |
 max-content-size { drop | number } |
 max-msgs drop |
 out-of-resource drop |
 passwd-file drop |
 pattern-type { extended | itw | standard } |
 pattern-update { mail-to-admin | use-proxy } |
 pattern-update-url url_str interval number |
 timeout drop
 }
 warning-message
}

```

**get (Within a Profile Context)**

```
get { aim-icq | ftp | http | icap | imap | msnms | pop3 | smtp | ymsg }
```

**set (Within a Profile Context)**

```

set
{
 aim-icq
 {
 decompress-layer number |
 enable |
 extension-list { include name_str | exclude name_str } |
 file |
 msg |
 scan-mode { scan-all | scan-intelligent | scan-ext } |
 timeout number |
 unknown-version { best-effort | pass }
 } |
 ftp
 {
 decompress-layer number |
 enable |
 extension-list { include name_str | exclude name_str } |
 scan-mode { scan-all | scan-intelligent | scan-ext } |
 virus-detection-notify-method { protocol }
 timeout number
 } |
 http
 {
 decompress-layer number |
 enable |
 extension-list { include name_str | exclude name_str } |
 skipmime { enable | mime-list string } |
 scan-mode { scan-all | scan-intelligent | scan-ext } |
 timeout number
 virus-detection-notify-method { protocol }
 } |
 icap { name_str | req-url url_str | resp-url url_str } |
 imap
 {
 decompress-layer number |
 email-notify { scan-error { sender | recipient } | virus sender } |

```

```

enable |
extension-list { include name_str | exclude name_str } |
scan-mode { scan-all | scan-intelligent | scan-ext } |
timeout number
virus-detection-notify-method { protocol }
}|
msnms
{
decompress-layer number |
enable |
extension-list { include name_str | exclude name_str } |
file |
msg |
scan-mode { scan-all | scan-intelligent | scan-ext } |
timeout number |
unknown-version { best-effort | pass }
}|
pop3
{
decompress-layer number |
email-notify { scan-error { sender | recipient } | virus sender } |
enable |
extension-list { include name_str | exclude name_str } |
scan-mode { scan-all | scan-intelligent | scan-ext } |
timeout number
virus-detection-notify-method { protocol }
}|
smtp
{
decompress-layer number |
email-notify { scan-error { sender | recipient } | virus sender } |
enable |
extension-list { include name_str | exclude name_str } |
scan-mode { scan-all | scan-intelligent | scan-ext } |
virus-detection-notify-method { protocol }
timeout number
}|
ymsg
{
decompress-layer number |
enable |
extension-list { include name_str | exclude name_str } |
file |
msg |
scan-mode { scan-all | scan-intelligent | scan-ext } |
timeout number |
unknown-version { best-effort | pass }
}|
}

```

## Keywords and Variables

---

### **all**

get av all

```
set av all { fail-mode traffic permit } | resources number }
unset av all { fail-mode traffic | resources }
```

**all** Specifies all AV-related information, including the following:

- **fail-mode**—Determines whether traffic is permitted to pass through when an error condition occurs. The **traffic permit** switch allows the traffic to pass when an error condition occurs.
- **resources *number***—Determines how many resources (number of connections, expressed as a percentage of total resources) the client can use. The default is 70.

**Example 1:** The following command allows traffic to pass when an error condition occurs:

```
set av all fail-mode traffic permit
```

**Example 2:** The following command instructs the device to drop traffic if an error condition occurs. This is the default behavior.

```
unset av all fail-mode traffic
```

**Example 3:** The following command allows each AV client to use 20 percent of the total resources:

```
set av all resources 20
```

### ***aim-icq, msnms, ymsg (within a profile context)***

```
get { aim-icq | msnms | ymsg }
set { aim-icq | msnms | ymsg } { ... }
unset { aim-icq | msnms | ymsg } { ... }
```

Displays or sets AV scanning options for instant messaging (IM) communication protocols.

|                                   |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
|-----------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| decompress-layer<br><i>number</i> | <p>Specifies how many layers of nested compressed files the internal AV scanner can decompress before it executes the virus scan. For example, if a message contains a compressed .zip file that contains another compressed .zip file, there are two compression layers, and decompressing both files requires a <b>decompress-layer</b> setting of 2.</p> <p>The range is 1 through 8 (maximum value is device-specific) meaning that the AV scanner can decompress up to eight layers of compressed files. See the <i>ScreenOS Release Notes</i> for the maximum value for each device. The default setting for the IM protocols is 3.</p> <p><b>Note:</b> When transmitting data, some protocols use a content-encoding layer. The AV scan engine needs to decode this layer, which is considered a decompression level, before it scans for viruses.</p> |
| enable                            | <p>Enables AV scanning for one of the following types of IM traffic:</p> <ul style="list-style-type: none"> <li>■ AOL Instant Messenger and ICQ traffic</li> <li>■ Microsoft (MSN) Messenger traffic</li> <li>■ Yahoo! Messenger traffic</li> </ul> <p>AV scanning is supported for the following services only:</p> <ul style="list-style-type: none"> <li>■ Text and group chat messages</li> <li>■ File transfer and file sharing</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                               |
| extension-list                    | <p>Specifies the extension list (<i>string</i>) to include or exclude in the scan process. See “extension-list” on page 104.</p> <ul style="list-style-type: none"> <li>■ <b>include</b>—Instructs the security device to scan the file extensions in the list.</li> <li>■ <b>exclude</b>—Instructs the device to not scan the file extensions in the list.</li> </ul> <p>Only one extension list can be included or excluded for each protocol.</p>                                                                                                                                                                                                                                                                                                                                                                                                          |
| file                              | <p>Scans IM files. If you unset this command, the scan engine allows instant messaging files to pass.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| msg                               | <p>Scans IM only. If you unset this command, the scan engine stops scanning instant messages.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| scan-mode                         | <p>Specifies how the scan engine scans traffic for a specific protocol.</p> <ul style="list-style-type: none"> <li>■ <b>scan-all</b>—Specifies that the scan engine scan all traffic at all times.</li> <li>■ <b>scan-intelligent</b>—Specifies that the scan engine use an algorithm that scans the traffic for the most common and prevalent viruses, including ensuring that the file type is true and that it doesn't infect other files directly. Although this option is not as broad in coverage as <b>scan-all</b>, it provides better performance.</li> <li>■ <b>scan-ext</b>—Bases all scanning decisions on the file extensions in the traffic.</li> </ul>                                                                                                                                                                                         |
| timeout <i>number</i>             | <p>Changes the timeout value for an AV session for each protocol. By default, an AV session times out after 180 seconds of inactivity. The range is 1 to 1800 seconds.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| unknown-version                   | <p>Controls the scan engine's behavior when it processes IM traffic for unsupported versions of the client or the protocol. Use the <b>get</b> command (for example, <b>get aim-icq</b>) to view supported versions of the protocol. See the product Release Notes for information about supported client versions.</p> <ul style="list-style-type: none"> <li>■ <b>best effort</b>—Processes traffic to the best effort using existing protocol knowledge.</li> <li>■ <b>pass</b>—Passes the traffic without scanning for viruses.</li> </ul>                                                                                                                                                                                                                                                                                                                |

## extension-list

```
get av extension-list [name_str]
set av extension-list name_str { string1 [;string2 ...;stringn] }
unset av extension-list name_str
```

**extension-list** Specifies a file extension list (*name\_str*) with a list of extensions (*string1* through *stringn*). The security device uses these file extensions to make decisions on which files undergo AV scanning. File extensions are case-insensitive and separated by a semicolon. An empty file extension is represented by quotation marks (“”).

The maximum length for any *name\_str* is 29 bytes. The maximum length for *string1* through *stringn* is 255 bytes.

**Example:** The following command specifies a list named **acme** with file extensions .exe, .com, and .pdf, for AV scanning.

```
set av extension-list acme exe;com;pdf
```

## ftp, http (within a profile context)

```
get { ftp | http }
set { ftp | http } { ... }
unset { ftp | http } { ... }
```

Displays or sets AV scanning options for the FTP and HTTP protocols.

**decompress-layer number** Specifies how many layers of nested compressed files the internal AV scanner can decompress before it executes the virus scan. For example, if a message contains a compressed .zip file that contains another compressed .zip file, there are two compression layers, and decompressing both files requires a **decompress-layer** setting of 2.

The range is 1 through 8 (maximum value is device-specific) meaning that the AV scanner can decompress up to eight layers of compressed files. See the *ScreenOS Release Notes* for the maximum value for each device. The default setting for HTTP is 2 and for FTP is 3.

**Note:** When transmitting data, some protocols use a content-encoding layer. The AV scan engine needs to decode this layer, which is considered a decompression level, before it scans for viruses.

**enable** Enables AV scanning for one of the following types of traffic:

- File Transfer Protocol (FTP)
- Hypertext Transfer Protocol (HTTP)

**extension-list** Specifies the extension list (*string*) to include or exclude in the scan process. See “extension-list” on page 104.

- **include**—Instructs the security device to scan the file extensions in the list.
  - **exclude**—Instructs the device to not scan the file extensions in the list.
- Only one extension list can be included or excluded for each protocol.

**skipmime** Skips the specified MIME list from AV scanning. This option is available for HTTP only.

- **enable**—Enables the skipmime option. By default, **skipmime** is enabled.
- **mime-list string**—Specifies the MIME list to skip. (For more information, see “mime-list” on page 108.) Only one MIME list can be linked to a profile.

|                               |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|-------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| scan-mode                     | <p>Specifies how the scan engine scans traffic for a specific protocol.</p> <ul style="list-style-type: none"> <li>■ <b>scan-all</b>—Specifies that the scan engine scan all traffic at all times.</li> <li>■ <b>scan-intelligent</b>—Specifies that the scan engine use an algorithm that scans the traffic for the most common and prevalent viruses, including ensuring the file type is true and that it doesn't infect other files directly. Although this option is not as broad in coverage as <b>scan-all</b>, it provides better performance.</li> <li>■ <b>scan-ext</b>—Bases all scanning decisions on the file extensions in the traffic.</li> </ul> |
| timeout <i>number</i>         | <p>Changes the timeout value for an AV session for each protocol. By default, an AV session times out after 180 seconds of inactivity. The range is 1 to 1800 seconds.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| virus-detection-notify-method | <p>Specifies how the scan engine notifies the detected virus for a specific protocol.</p> <ul style="list-style-type: none"> <li>■ <b>protocol</b>—Drops the traffic if virus is detected and sends a warning message to the client initiating the traffic.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                           |

## http

```
get av http
set av http { . . . }
unset av http { keep-alive | trickling }
```

Displays or sets global HTTP configuration options for AV scanning.

|            |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
|------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| keep-alive | <p>Directs the security device to use the HTTP keep-alive connection option. Use this option to prevent the device from modifying a connection header for each request. (By default, the device uses the HTTP close connection option.)</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| trickling  | <p>Configures the security device for HTTP trickling, which automatically forwards specified amounts of unscanned HTTP traffic to the requesting HTTP host. Trickling prevents the host from timing out while the AV scanner is busy examining downloaded HTTP files.</p> <ul style="list-style-type: none"> <li>■ <b>default</b>—Restores all HTTP trickling settings to the default values.</li> <li>■ <b>threshold</b>—Provides more granularity for setting trickling options. <ul style="list-style-type: none"> <li>■ <b>threshold <i>number</i></b>—Specifies the minimum length to begin trickling. Enter the minimum size in kilobytes for an HTTP file to trigger trickling.</li> <li>■ <b>segment-size <i>number</i></b>—Specifies the content size sent for scanning in kilobytes.</li> <li>■ <b>trickle-size <i>number</i></b>—Specifies the size (a nonzero value in bytes) of unscanned traffic that the security device forwards to the client.</li> <li>■ <b>timeout <i>number</i></b>—Specifies a value between 0-600 seconds. The value 0 indicates that time-based trickling is disabled.</li> </ul> </li> </ul> |

**Note:** Because the **threshold** command provides more granularity, we recommend you set the trickling options using the **threshold** command.

**Example 1:** The following command configures HTTP trickling to trickle 800 bytes of content for every 2MB scanned and to initiate trickling when the HTTP file is 6MB or larger:

```
set av http trickling threshold 6000 segment-size 2000 trickle-size 800
```

**icap (within a profile context)**

```

get icap
unset icap
set icap { name_str | req-url url_str | resp-rl url_str }
unset icap { name_str | req-url url_str | resp-url url_str }

```

Displays or sets AV scanning options on the device to support external Internet Content Adaptation Protocol (ICAP).

**Note:** External AV scanning is supported for HTTP and SMTP traffic only.

|                 |                                                                                                                                                                                                                                                                                                                                                                                                    |
|-----------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <i>name-str</i> | <p>Binds a single ICAP server or an ICAP server group to the AV profile.</p> <p>Configures unique name strings for ICAP servers and server groups. Your security device selects either the ICAP server specified by <i>name-str</i> or the load-balanced server from an ICAP server group. The maximum string length for the server or server group name is 31 characters.</p>                     |
| <i>req-url</i>  | <p>Configures the request URL string on the ICAP server to scan all POST transactions (files that are being posted to the Internet) for viruses. The default request service string, <i>/SYMCSanReq-AV</i>, is valid for the Symantec scan engine 5.0 ICAP server. Modify this URL string if you are communicating with a different ICAP server. The maximum string length for the URL is 255.</p> |
| <i>resp-url</i> | <p>Configures the response URL string on the ICAP server to scan responses returned by an HTTP/SMTP server. The default response service string, <i>/SYMCSanResp-AV</i>, is valid for the Symantec scan engine 5.0 ICAP server. Modify this URL string if you are communicating with a different ICAP server. The maximum string length for the URL is 255.</p>                                    |

**imap, pop3, smtp (within a profile context)**

```

get { imap | pop3 | smtp }
set { imap | pop3 | smtp } { ... }
unset { imap | pop3 | smtp } { ... }

```

Displays or sets AV scanning options for Internet Mail Access Protocol (IMAP), Post Office Protocol, version 3 (POP3), and Simple Mail Transfer Protocol (SMTP) communication protocols.

|                                   |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|-----------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| decompress-layer<br><i>number</i> | <p>Specifies how many layers of nested compressed files the internal AV scanner can decompress before it executes the virus scan. For example, if a message contains a compressed .zip file that contains another compressed .zip file, there are two compression layers, and decompressing both files requires a <b>decompress-layer</b> setting of 2.</p> <p>The range is 1 through 8 (maximum value is device-specific) meaning that the AV scanner can decompress up to eight layers of compressed files. See the <i>ScreenOS Release Notes</i> for the maximum value for each device. The default setting for the protocols is 3.</p> <p><b>Note:</b> When transmitting data, some protocols use content encoding. The AV scan engine needs to decode this layer, which is considered a decompression level before it scans for viruses.</p> |
| email-notify                      | <p>Notifies the sender or recipient about detected viruses or scanning errors.</p> <ul style="list-style-type: none"> <li>■ <b>scan error</b>—Sends email to sender or recipient on scanning errors. <ul style="list-style-type: none"> <li>■ <b>sender</b>—Notifies sender if an email message is dropped as a result of a scan error.</li> <li>■ <b>recipient</b>—Notifies recipient if an email message is passed as a result of a scan error.</li> </ul> </li> <li>■ <b>virus sender</b>—Notifies sender if a virus is found in an email message.</li> </ul>                                                                                                                                                                                                                                                                                  |
| enable                            | Enables AV scanning for IMAP, POP3, or SMTP traffic.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| extension-list                    | <p>Specifies the extension list (<i>string</i>) to include or exclude in the scan process. See “extension-list” on page 104.</p> <ul style="list-style-type: none"> <li>■ <b>include</b>—Instructs the security device to scan the file extensions in the list.</li> <li>■ <b>exclude</b>—Instructs the device to not scan the file extensions in the list.</li> </ul> <p>Only one extension list can be included or excluded for each protocol.</p>                                                                                                                                                                                                                                                                                                                                                                                              |
| scan-mode                         | <p>Specifies how the scan engine scans traffic for a specific protocol.</p> <ul style="list-style-type: none"> <li>■ <b>scan-all</b>—Specifies that the scan engine scan all traffic at all times.</li> <li>■ <b>scan-intelligent</b>—Specifies that the scan engine use an algorithm that scans the traffic for the most common and prevalent viruses, including ensuring that the file type is true and that it doesn’t infect other files directly. Although this option is not as broad in coverage as <b>scan-all</b>, it provides better performance.</li> <li>■ <b>scan-ext</b>—Bases all scanning decisions on the file extensions in the traffic.</li> </ul>                                                                                                                                                                             |
| timeout <i>number</i>             | Changes the timeout value for an AV session for each protocol. By default, an AV session times out after 180 seconds of inactivity. The range is 1 to 1800 seconds.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| virus-detection-no<br>tify-method | <p>Specifies how the scan engine notifies the detected virus for a specific protocol.</p> <ul style="list-style-type: none"> <li>■ <b>protocol</b>—Drops the traffic if virus is detected and sends a warning message to the client initiating the traffic.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |

**Example:** The following commands allow you to email virus or scan-error notification messages to senders or recipients. (For more information about invoking a profile, see “Context Initiation” on page 98.)

- To send virus notification messages to sender:

```
device-> set av profile jnpr-profile
device(av:jnpr-profile)-> set imap email-notify virus sender
```

- To send scan error notification messages to sender:

```
device-> set av profile jnpr-profile
device(av:jnpr-profile)-> set imap email-notify scan-error sender
```

- To disable sending scan error notification messages to recipient:

```
device-> set av profile jnpr-profile
device(av:jnpr-profile)-> unset imap email-notify scan-error recipient
```

- To disable sending virus notification messages to sender:

```
device-> set av profile jnpr-profile
device(av:jnpr-profile)-> unset imap email-notify virus sender
```

## *mime-list*

```
get av mime-list [name_str]
set av mime-list name_str { string1 [;string2...;stringn] }
unset av mime-list name_str
```

**mime-list** Specifies a Multipurpose Internet Mail Extension (MIME) list name (*name\_str*) with a list of MIME types (*string1* through *stringn*). The security device uses such MIME types to decide which HTTP traffic must undergo AV scanning.

MIME entries are case-insensitive and separated by semicolons. An empty MIME string is invalid and should not appear in the MIME list. If the MIME entry ends with a slash (/), then the matching is a prefix match. The maximum length for a *stringn* is 40 bytes. The maximum length for a MIME list (*string1* through *stringn*) is 1023 bytes.

The default MIME list, ns-skip-mime-list, includes the following predefined MIME types:

- application/x-director
- application/pdf
- image/
- video/
- audio/
- text/css
- text/html

The maximum number of user-defined MIME lists for each vsys (and root) is 9.

**Example:** The following commands configure a list of HTTP MIME types (`text/plain`; `text/css`; `text/html`; `image/`) and enables the list for HTTP skipmime:

```
set av mime-list textmime-list text/plain;text/css;text/html:image/
set av profile HTTPProfile
device(av:HTTPProfile)-> set http skipmime enable
device(av:HTTPProfile)-> set http skipmime mime-list textmime-list
```

A traffic MIME type, `image/gif`, is a prefix match of the MIME entry `image/`. A traffic MIME type, `text/css`, is a prefix match of the MIME entry `text/css`. A traffic MIME type, `image/gif`, does not prefix-match any MIME type in the MIME list.

### ***notify-mail-charset***

```
set av notify-mail-charset string
get av notify-mail-charset
```

`notify-mail-charset` Specifies the character set for a notification mail. The maximum string length is 15 characters. A warning message is returned in the CLI if the string exceeds its maximum length.

### ***notify-mail-source***

```
set av notify-mail-source string
get av notify-mail-source
```

`notify-mail-source` Sets the source address for a notification mail. The maximum string length is 63 characters. A warning message is returned in the CLI if the string exceeds its maximum length.

### ***notify-mail-subject***

```
set av notify-mail-subject string
get av notify-mail-subject
```

`notify-mail-subject` Sets the subject of a notification mail. The maximum string length is 500 characters. A warning message is returned in the CLI if the string exceeds its maximum length.

### ***profile***

```
get av profile name_str
set av profile name_str
unset av profile name_str
```

`profile` Configures or displays an AV profile. Policies use AV profiles to determine which traffic undergoes AV examination and the actions to be taken as a result. Only one AV profile can be linked to a specific firewall policy. For more information about creating user-defined AV profiles and assigning an AV profile to a firewall policy, see “av” on page 544.

Two predefined AV profiles, **ns-profile** and **scan-mgr**, exist on your device. **scan-mgr** is automatically generated during upgrade to migrate the global **scan-mgr** settings.

**scan-mgr**

```
exec av scan-mgr pattern-update
get av scan-mgr { ... }
set av scan-mgr { ... }
unset av scan-mgr { ... }
```

Configures, displays, or performs actions on parameters that control internal AV scanning:

|                       |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
|-----------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| corrupt-file drop     | Drops corrupted files. By default, the scan engine allows corrupted files to pass.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| decompress-layer drop | Drops traffic when it reaches the configured value set in the profile. See “decompress-layer number” on page 103. By default, the scan engine allows traffic to pass when it reaches the configured value set in the profile.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| engine-not-ready drop | Drops traffic if the scan engine is not ready to scan traffic. By default, the device drops traffic if the scan engine is not ready to scan traffic.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| max-content-size      | Specifies the maximum size of content for a single message that the internal AV scanner scans for virus patterns. If you enable the <b>drop</b> option and the total content of an incoming message exceeds the maximum, the security device drops the message content without checking for viruses.<br><br>If you unset the <b>drop</b> option, the security device passes traffic without examining it. The range for <b>max-content-size</b> is device-dependent. See the <i>ScreenOS Release Notes</i> for device-specific values. The default maximum content size is 10,000 KB.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| max-msgs drop         | Drops the message content without checking for viruses if the total number of concurrent messages exceeds the maximum number of messages supported on the device. See the <i>ScreenOS Release Notes</i> for device-specific values.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| out-of-resource drop  | Drops traffic when the device runs out of resources. By default, the scan engine drops traffic when the device runs out of resources. This value is platform-dependent.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| passwd-file drop      | Drops password-protected files. By default, the scan engine allows password-protected files to pass.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| pattern-type          | Selects the AV-scan engine signature databases. The selected database affects the AV scan engine’s performance and coverage of virus signatures. For example, selecting the <b>extended</b> option provides a comprehensive coverage of pattern signatures but may affect the performance of the device. <ul style="list-style-type: none"> <li>■ <b>extended</b>—Includes virus signatures in the standard database and other supplemental databases. In addition to all virus and spyware programs, this option also detects adware, pornware, riskware, and greyware. This option may display more false positives.</li> <li>■ <b>itw</b>—Uses in-the-wild virus signatures only. This database detects in-the-wild virus and spyware programs. This option scans the most prevalent viruses, although it provides increased performance.</li> <li>■ <b>standard</b>—Uses the default standard virus database (downloaded by the <b>pattern-update</b> command), which detects all viruses (including polymorphic and other advanced viruses) and also provides inbound spyware and phishing protection.</li> </ul> |
| pattern-update        | Sets the mode of attack-object pattern updates. <ul style="list-style-type: none"> <li>■ <b>mail-to-admin</b>—Enables the security device to notify the administrator via e-mail when an updated pattern file is available.</li> <li>■ <b>use-proxy</b>—Enables the security device to update its attack-object database through the HTTP/SSL proxy server.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |

|                                                   |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|---------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>pattern-update-url</code><br><i>url_str</i> | <p>Specifies the URL of the server from which the security device updates the pattern files. The URL address format is <b>http[s]://host[:port]/path</b>. (See examples below.)</p> <p>The URL to update the AV pattern file is device-dependent, because a smaller database is downloaded to the lower-end devices.</p> <p><b>interval number</b>—Specifies the time interval (in minutes) between automatic updates to the signature database. Specifying a value of zero disables automatic pattern update.</p> |
| <code>timeout drop</code>                         | <p>Drops traffic if the protocol-based profile times out. If you unset this command, the device passes traffic if the configured timeout value is exceeded. To configure the timeout value, see “timeout number” on page 103.</p>                                                                                                                                                                                                                                                                                  |

**Example:** The following commands show examples of updating pattern signatures from an URL location:

```
set av scan-mgr pattern-update-url
 http://update.juniper-updates.net/av/ssg5_SSG20 int 60
```

**session**

```
get av session [[src-ip ip_addr] [dst-ip ip_addr] [src-port port_num1 [port_num2]]
 [dst-port port_num1 [port_num2]]
```

**session** Displays the status of the current application sessions and packet queue size.

- **src-ip** *ip\_addr/mask*—Matches the source IP address and mask of the session.
- **dst-ip** *ip\_addr/mask*—Specifies the destination IP address and mask of the session.
- **src-port** *port\_num1* [ *port\_num2* ]—Matches the specific source port number (lower boundary) or a range of port numbers for that session.
- **dst-port** *port\_num1* [ *port\_num2* ]—Matches the specific destination port number (lower boundary) or a range of port numbers for that session.

**statistics**

```
clear av statistics
get av statistics
```

**statistics** Clears or displays all accumulated statistical AV counters.

**warning-message**

```
set av warning-message string
get av warning-message
```

**warning-message** Sets the customized warning message that the security device sends to the client when it detects a virus. The maximum string length is 500 characters. A warning message is returned in the CLI if the string exceeds its maximum length.

# BGP Commands

Use the **bgp** context to configure Border Gateway Protocol (BGP) in a virtual router (VR).

## Context Initiation

---

Initiating the **bgp** context requires the following two steps:

1. Enter the **vrouter** context by executing the **set vrouter** command:

```
set vrouter vrouter
```

where *vrouter* is the name of the virtual router. (For all examples that follow, assume that *vrouter* is the **trust-vr** virtual router.)

2. Enter the **bgp** context by executing the **set protocol bgp** command.

```
device(trust-vr)-> set protocol bgp as_num
```

where *as\_num* is the number of the autonomous system in which the BGP routing instance resides. Once you define an autonomous system number for the BGP routing instance, you no longer have to enter the number in the **set protocol bgp** command.

## BGP Command List

---

The following commands are executable in the **bgp** context. Click on a keyword in the table to go to complete syntax and usage information.

|                     |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|---------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| advertise-def-route | Use the <b>advertise-def-route</b> commands to advertise or display the default route in the current VR to peers.<br>Command options: <b>set, unset</b>                                                                                                                                                                                                                                                                                                                                                                                 |
| aggregate           | Use <b>aggregate</b> commands to create, display, or delete aggregate addresses.<br><br>Aggregation is a technique for summarizing a range of routing addresses into a single route entry, expressed as an IP address and a subnet mask (IPv4) or an IP address and a prefix length (IPv6). Aggregates can reduce the size of the routing table, while maintaining its level of connectivity. In addition, aggregates can reduce the number of advertised addresses, thus reducing overhead.<br>Command options: <b>get, set, unset</b> |
| always-compare-med  | Use the <b>always-compare-med</b> commands to enable or disable the security device from comparing paths from each autonomous system (AS) using the Multi-Exit Discriminator (MED). The MED value is one of the criteria that determines the most suitable route to the neighbor device.<br>Command options: <b>get, set, unset</b>                                                                                                                                                                                                     |
| as-number           | Use the <b>as-number</b> command to display the autonomous system number configured for the BGP routing instance. When you create the BGP routing instance in a VR, you must specify the autonomous system (AS) in which it resides.<br>Command options: <b>get</b>                                                                                                                                                                                                                                                                     |
| as-path-access-list | Use <b>as-path-access-list</b> commands to create, remove, or display a regular expression in an AS-path access list.<br><br>An AS-path access list serves as a packet filtering mechanism. The security device can consult such a list and permit or deny BGP packets based on the regular expressions contained in the list. The system can have up to 99 AS-path access lists.<br>Command options: <b>get, set, unset</b>                                                                                                            |
| comm-rib-in         | Use the <b>comm-rib-in</b> command to display the BGP internal routing information base (RIB) learned from peers within a community.<br>Command options: <b>get</b>                                                                                                                                                                                                                                                                                                                                                                     |
| community-list      | Use <b>community-list</b> commands to enter a route in a community list, to remove a route from the list, or to display the list.<br>Command options: <b>get, set, unset</b>                                                                                                                                                                                                                                                                                                                                                            |
| confederation       | Use the <b>confederation</b> commands to create a confederation, to remove a confederation, or to display confederation information.<br><br>Confederation is a technique for dividing an AS into smaller sub-ASs and grouping them. Using confederations reduces the number of connections inside an AS, thus simplifying full mesh topology.<br>Command options: <b>get, set, unset</b>                                                                                                                                                |
| config              | Use the <b>config</b> command to display the BGP configuration.<br>Command options: <b>get</b>                                                                                                                                                                                                                                                                                                                                                                                                                                          |

|                |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|----------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| enable         | <p>Use the <b>enable</b> commands to enable or disable the BGP routing protocol in a VR.</p> <p>Command options: <b>set, unset</b></p>                                                                                                                                                                                                                                                                                                                                         |
| flap-damping   | <p>Use the <b>flap-damping</b> commands to enable or disable the flap-damping setting, or to display flap-damping information.</p> <p>Enabling this setting blocks the advertisement of a route until the route becomes stable. Flap damping allows the security device to prevent routing instability at an AS border router, adjacent to the region where instability occurs.</p> <p>Command options: <b>get, set, unset</b></p>                                             |
| hold-time      | <p>Use the <b>hold-time</b> commands to specify or display the maximum amount of time (in seconds) that can elapse between keepalive messages received from the BGP neighbor.</p> <p>Command options: <b>get, set, unset</b></p>                                                                                                                                                                                                                                               |
| keepalive      | <p>Use the <b>keepalive</b> commands to set, unset, or display the amount of time (in seconds) that elapses between keepalive packet transmissions. These transmissions ensure that the TCP connection between the local BGP router and a neighbor router stays up.</p> <p>Command options: <b>get, set, unset</b></p>                                                                                                                                                         |
| local-pref     | <p>Use the <b>local-pref</b> command to configure a LOCAL_PREF value for the BGP routing protocol. The LOCAL_PREF attribute is the metric most often used in practice to express preferences for one set of paths over another for internal BGP (IBGP).</p> <p>Command options: <b>get, set, unset</b></p>                                                                                                                                                                     |
| med            | <p>Use the <b>med</b> commands to specify or display the local Multi-Exit Discriminator (MED).</p> <p>Command options: <b>get, set, unset</b></p>                                                                                                                                                                                                                                                                                                                              |
| neighbor       | <p>Use the <b>neighbor</b> commands to set or display configuration parameters for communicating with BGP peers.</p> <p>Command options: <b>clear, exec, get, set, unset</b></p>                                                                                                                                                                                                                                                                                               |
| network        | <p>Use the <b>network</b> commands to create, display, or delete network and subnet mask (IPv4) and prefix length (IPv6) entries. The BGP virtual router advertises these entries to peer devices, without first requiring redistribution into BGP (as with static routing table entries).</p> <p>Command options: <b>get, set, unset</b></p>                                                                                                                                  |
| redistribute   | <p>Use the <b>redistribute</b> commands to import routes advertised by external routers that use protocols other than BGP, or to display the current redistribution settings.</p> <p>Command options: <b>set, unset</b></p>                                                                                                                                                                                                                                                    |
| redistribution | <p>Use the <b>redistribution</b> command to display the BGP redistribution rules.</p> <p>Command options: <b>get</b></p>                                                                                                                                                                                                                                                                                                                                                       |
| reflector      | <p>Use the <b>reflector</b> commands to allow the local BGP virtual router to serve as a route reflector.</p> <p>A <i>route reflector</i> is a router that passes IBGP learned routes to specified IBGP neighbors (<i>clients</i>), thus eliminating the need for each router in a full mesh to talk to every other router. The clients use the route reflector to readvertise routes to the entire autonomous system (AS).</p> <p>Command options: <b>get, set, unset</b></p> |

|                      |                                                                                                                                                                                                                                                                      |
|----------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| reject-default-route | Use the <b>reject-default-route</b> commands to enable, disable, or display the reject-default-route setting. Enabling this setting makes the security device ignore default route advertisements from a BGP peer router.<br>Command options: <b>get, set, unset</b> |
| retry-time           | Use the <b>retry-time</b> command to specify the amount of time (in seconds) after failing to establish a BGP session with a peer that the local BGP routing instance retries to initiate the session.<br>Command options: <b>set, unset</b>                         |
| rib-in               | Use the <b>rib-in</b> command to display the internal routing information base learned from peers.<br>Command options: <b>get</b>                                                                                                                                    |
| router-id            | Use the <b>router-id</b> command to display the router ID for the VR.<br>Command options: <b>get</b>                                                                                                                                                                 |
| synchronization      | Use the <b>synchronization</b> command to enable synchronization with Interior Gateway Protocol (IGP).<br>Command options: <b>set, unset</b>                                                                                                                         |

### **advertise-def-route**

Use the **advertise-def-route** commands to advertise or display the default route in the current VR to BGP peers.

Before you can execute the **advertise-def-route** command, you must initiate the **bgp** context. (See “Context Initiation” on page 113.)

#### **Syntax**

```
set [ipv4 | ipv6] advertise-def-route
```

#### **Keywords and Variables**

##### **ipv4 | ipv6**

```
set [ipv4 | ipv6] advertise-def-route
unset [ipv4 | ipv6] advertise-def-route
```

ipv4 | ipv6      Indicates that you want to set the attribute or configuration for the routes of the IPv4 or IPv6 address family. If you do not use these keywords, only the routes of the IPv4 address family are configured (by default).

### **aggregate**

Use **aggregate** commands to create, display, or delete aggregate addresses.

Aggregation is a technique for summarizing a range of routing addresses into a single route entry. Each aggregate is an address range expressed as an IP address and a subnet mask (IPv4) or an IP address and a prefix length (IPv6). Aggregation can reduce the size of a router’s routing table while maintaining its level of connectivity. In addition, aggregation can reduce the number of advertised addresses, thus reducing overhead.

Before you can execute an **aggregate** command, you must initiate the **bgp** context. (See “Context Initiation” on page 113.)

## Syntax

### get

```
get { aggregate [ipv4_addr/mask | ipv6_addr/prefix_length] |
 ipv4 aggregate [ipv4_addr/mask] |
 ipv6 aggregate [ipv6_addr/prefix_length]
 }
```

### set

```
set { [ipv4] aggregate ipv4_addr/mask | ipv6 aggregate
 ipv6_addr/prefix_length }
 [as-set] [summary-only | suppress-map name_str]
 [advertise-map name_str] [attribute-map name_str]
```

## Keywords and Variables

### Variable Parameter

```
set { [ipv4] aggregate ipv4_addr/mask | ipv6 ipv6_addr/prefix_length } [...]
```

*ipv4\_addr/mask*            The address range expressed as an IPv4 address and a mask value.

*ipv6\_addr/prefix\_length*   The address range expressed as an IPv6 address and a prefix-length value.

### advertise-map

```
set { [ipv4] aggregate ipv4_addr/mask | ipv6 aggregate ipv6_addr/prefix_length }
 advertise-map name_str
```

advertise-map    Selects the routes that match the specified route map for the AS-Path attribute of the aggregate route entry.

### as-set

```
set { [ipv4] aggregate ipv4_addr/mask | ipv6 aggregate ipv6_addr/prefix_length }
 as-set [...]
```

as-set            Specifies that the aggregate uses an unordered set of AS numbers (the AS-Set field is set in the AS-Path path attribute) instead of an ordered sequence (the AS-Sequence field is set in the AS-Path path attribute). This option supports the aggregation of routes with different AS-Paths.

### attribute-map

```
set { [ipv4] aggregate ipv4_addr/mask | ipv6 aggregate ipv6_addr/prefix_length }
 attribute-map name_str
```

attribute-map    Changes the attributes of the aggregate route to those in the specified route map.

### ipv4 | ipv6

```
set { [ipv4] aggregate ipv4_addr/mask | ipv6 aggregate ipv6_addr/prefix_length }
 as-set [...]
```

`ipv4 | ipv6` Indicates that you want to set the attribute or configuration for the routes of the IPv4 or IPv6 address family. If you do not use these keywords, only the routes of the IPv4 address family are configured (by default). For the **get** command, if you do not use these keywords, all related content is listed, including the routes of both the IPv4 and IPv6 address families.

### **summary-only**

```
set { [ipv4] aggregate ipv4_addr/mask | ipv6 aggregate ipv6_addr/prefix_length }
 [as-set] summary-only
```

`summary-only` Specifies that more specific routes that fall into the aggregate route IP address and subnet mask (IPv4) or IP address and prefix (IPv6) range are not advertised.

**Example:** The following command examples specify that the aggregate uses an unordered set of AS numbers while suppressing more specific routes.

- For routes of the IPv4 address family:

```
set aggregate 3.3.3.3/24 as-set summary-only
```

- For routes of the IPv6 address family:

```
set ipv6 aggregate 2aaa:77::/32 as-set summary-only
```

### **suppress-map**

```
set { [ipv4] aggregate ipv4_addr/mask | ipv6 aggregate ipv6_addr/prefix_length }
 suppress-map name_str
```

`suppress-map` Suppresses the routes that match the specified route map.

## ***always-compare-med***

Use the **always-compare-med** commands to enable or disable the security device from comparing paths from each autonomous system (AS) using the Multi-Exit Discriminator (MED). The MED is one of the criteria that determines the most suitable route to the neighbor device.

Before you can execute an **always-compare-med** command, you must initiate the **bgp** context. (See “Context Initiation” on page 113.)

### **Syntax**

#### ***get***

```
get always-compare-med
```

#### ***set***

```
set [ipv4 | ipv6] always-compare-med
```

### **Keywords and Variables**

#### ***ipv4 | ipv6***

```
set [ipv4 | ipv6] always-compare-med
```

unset [ ipv4 | ipv6 ] always-compare-med

ipv4 | ipv6      Indicates that you want to set the attribute or configuration for the routes of the IPv4 or IPv6 address family. If you do not use these keywords, only the routes of the IPv4 address family are configured (by default).

## ***as-number***

Use the **as-number** command to display the autonomous system (AS) number configured for the BGP routing instance. When you create the BGP routing instance in a VR, you must specify the AS in which it resides.

Before you can execute the **as-number** command, you must initiate the **bgp** context. (See “Context Initiation” on page 113.)

### **Syntax**

get as-number

### **Keywords and Variables**

None.

## ***as-path-access-list***

Use **as-path-access-list** commands to create, remove, or display a regular expression in an AS-path access list.

An AS-path access list serves as a packet filtering mechanism. The security device can consult such a list and permit or deny BGP packets based on the regular expressions contained in the list.

Before you can execute an **as-path-access-list** command, you must initiate the **bgp** context. (See “Context Initiation” on page 113.)

### **Syntax**

#### ***get***

get as-path-access-list

#### ***set***

set as-path-access-list *id\_num* { deny | permit } *string*

### **Keywords and Variables**

#### ***Variable Parameters***

set as-path-access-list *id\_num* { deny | permit } *string*

unset as-path-access-list *id\_num* [ { deny | permit } *string* ]

|               |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|---------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <i>id_num</i> | The identification number of the access list (range 1–99 inclusive).                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| <i>string</i> | The regular expression used for BGP packet filtering. You can use the following in the regular expression: <ul style="list-style-type: none"> <li>■ '^' The start of a path</li> <li>■ '\$' The end of a path</li> <li>■ '{' The start of an AS_SET</li> <li>■ '}' The end of an AS_SET</li> <li>■ '(' The start of an AS_CONFED_SET or AS_CONFED_SEQ</li> <li>■ ')' The end of an AS_CONFED_SET or AS_CONFED_SEQ</li> <li>■ '.' Matches any single character</li> <li>■ '*' Matches zero or more characters</li> <li>■ '+' Matches one or more characters</li> <li>■ '_' Matches zero or one instance of a punctuation character</li> <li>■ '[' Specifies a set of characters</li> <li>■ '-' Used within brackets to specify a range of AS numbers</li> <li>■ '^' Used as the first item within brackets to exclude AS numbers</li> </ul> |

**deny | permit**

```
set as-path-access-list id_num { deny | permit } string
unset as-path-access-list id_num [{ deny | permit } string]
```

deny | permit      Denies or permits BGP packets containing the regular expression (*string*).

**Example:** The following command places the regular expression “23” in an AS-Path access list with ID number 10:

```
set as-path-access-list 10 permit 23
```

**comm-rib-in**

Use the **comm-rib-in** command to display the BGP internal routing information base learned from peers within a community.

Before you can execute the **comm-rib-in** command, you must initiate the **bgp** context. (See “Context Initiation” on page 113.)

**Syntax**

```
get comm-rib-in
```

**Keywords and Variables**

None.

**community-list**

Use **community-list** commands to create a community list that defines community attributes of routes that are permitted or denied.

A community consists of routes that are associated with the same identifier. Routers can use the community identifier when they need to treat two or more advertised routes in the same way.

Before you can execute a **community-list** command, you must initiate the **bgp** context. (See “Context Initiation” on page 113.)

## Syntax

### *get*

```
get community-list
```

### *set*

```
set community-list id_num1 { default-permit | deny | permit }
 [number | as id_num2 id_num3 |
 no-advertise | no-export | no-export-subconfed | none
]
```

## Keywords and Variables

### *Variable Parameters*

```
set community-list id_num1 { deny | permit | default-permit } number
unset community-list id_num1 { deny | permit | default-permit } number
```

*id\_num1*            The identifier of the community list (range 1–99 inclusive).  
*number*            The community number, which can be between 0-65535 inclusive.

### *as*

```
set community-list id_num1 { deny | permit } as id_num2 id_num3
unset community-list id_num1 { deny | permit } as id_num2 id_num3
```

*as*                Defines a private community, in the form of an AS number (*id\_num2*) and a community number defined within the AS (*id\_num3*). The community number can be between 0-65535 inclusive.

**Example:** The following command creates a community list with an ID of 10 that permits the community 11 in AS 10000:

```
set community-list 10 permit as 10000 11
```

### *deny | permit | default-permit*

```
set community-list id_num1 { deny | permit } [...]
unset community-list id_num1 { deny | permit } [...]
```

*deny | permit*    Denies or permits routes with the specified community value.  
*default-permit*   Permits the route if it does not match any community value specified in the community list. By default, routes that do not match community values in the community list are denied.

**Example:** The following command defines the community list 20 that denies routes with the community value 200.

```
set community-list 20 deny 200
```

**no-advertise**

```
set community-list id_num1 { deny | permit } no-advertise
unset community-list id_num1 { deny | permit } no-advertise
```

no-advertise      Specifies that the security device does not advertise routes with this community value in the communities attribute to any peer devices.

**no-export**

```
set community-list id_num1 { deny | permit } no-export
unset community-list id_num1 { deny | permit } no-export
```

no-export      Specifies that the security device does not advertise routes with this community value to external BGP (EBGP) peers, except subautonomous systems within the confederation.

**no-export-subconfed**

```
set community-list id_num1 { deny | permit } no-export-subconfed
unset community-list id_num1 { deny | permit } no-export-subconfed
```

no-export-subconfed      Specifies that the security device does not advertise routes with this community value to any external peers.

**none**

```
set community-list id_num1 { deny | permit } none
unset community-list id_num1 { deny | permit } none
```

none      Specifies that the security device remove community values.

**confederation**

Use the **confederation** commands to create a confederation, to remove a confederation, or to display confederation information.

Confederation is a technique for dividing an AS into smaller sub-ASs and grouping them. Using confederations reduces the number of connections inside an AS, simplifying the routing matrices created by meshes.

Before you can execute a **confederation** command, you must initiate the **bgp** context. (See “Context Initiation” on page 113.)

**Syntax****get**

```
get confederation
```

**set**

```
set confederation { id id_num1 | peer id_num2 | rfc3065 }
```

## Keywords and Variables

### *id*

set confederation id *id\_num1*  
unset confederation id

*id\_num1*            The identification number of the confederation.

**Example:** The following command creates a confederation with an ID of 10:

**set confederation id 10**

### *peer*

set confederation peer *id\_num2*  
unset confederation peer *id\_num2*

*id\_num2*            The identifier of a new peer autonomous system (AS) entry.

**Example:** The following command adds AS 45040 to the confederation:

**set confederation peer 45040**

### *rfc3065*

set confederation rfc3065  
unset confederation rfc3065

*rfc3065*            Specifies configuration in compliance with RFC 3065. The default is compliance with RFC 1965.

## *config*

Use the **config** command to display the CLI commands used in the BGP configuration in the current VR.

Before you can execute the **config** command, you must initiate the **bgp** context. (See “Context Initiation” on page 113.)

## Syntax

get config

## Keywords and Variables

None.

## *enable*

Use the **enable** commands to enable or disable the BGP routing protocol in a VR.

Before you can execute an **enable** command, you must initiate the **bgp** context. (See “Context Initiation” on page 113.)

## Syntax

set enable

## Keywords and Variables

None.

## *flap-damping*

Use the **flap-damping** commands to enable or disable the flap-damping setting or to display flap-damping information.

Enabling this setting blocks the advertisement of a route until the route becomes stable. Flap damping allows the security device to contain routing instability at an AS border router, adjacent to the region where instability occurs.

Before you can execute a **flap-damping** command, you must initiate the **bgp** context. (See “Context Initiation” on page 113.)

## Syntax

set [ ipv4 | ipv6 ] flap-damping

## Keywords and Variables

### *ipv4 | ipv6*

set [ ipv4 | ipv6 ] flap-damping

unset [ ipv4 | ipv6 ] flap-damping

*ipv4 | ipv6*      Indicates that you want to set the attribute or configuration for the routes of the IPv4 or IPv6 address family. If you do not use these keywords, only the routes of the IPv4 address family are configured (by default).

## *hold-time*

Use the **hold-time** commands to specify or display the maximum amount of time (in seconds) that can elapse between keepalive messages received from the BGP neighbor. If the hold-time elapses before any message is received from a BGP neighbor, the session is considered down. The default is 180 seconds.

---

**NOTE:** The default keepalive value is always one-third of the current hold-time value.

---

Before you can execute a **hold-time** command, you must initiate the **bgp** context. (See “Context Initiation” on page 113.)

## Syntax

### *get*

get hold-time

### *set*

set hold-time *number*

## Keywords and Variables

### *Variable Parameter*

set hold-time *number*

*number*            The maximum length of time (in seconds) between messages.

## *keepalive*

Use the **keepalive** commands to set, unset, or display the amount of time (in seconds) that elapses between keepalive packet transmissions. These transmissions ensure that the TCP connection between the local BGP router and a neighbor router stays up. The default value is one-third of the hold-time value (for the default **hold-time** value of 180 seconds, the default **keepalive** value is 60 seconds).

Before you can execute a **keepalive** command, you must initiate the **bgp** context. (See “Context Initiation” on page 113.)

## Syntax

### *get*

get keepalive

### *set*

set keepalive *number*

## Keywords and Variables

### *Variable Parameter*

set keepalive *number*

*number*            The maximum length of time (in seconds) between keepalive messages.

## *local-pref*

Use the **local-pref** commands to configure the Local-Pref path attribute for the BGP routing protocol.

The **local-pref** path attribute is a metric used to inform IBGP peers of the local router’s preference for the route. The higher the value, the greater the preference. Routers advertise this attribute to internal peers (peers in the same AS) and to neighboring confederations, but never to external peers. The default value is 100.

Before you can execute the **local-pref** command, you must initiate the **bgp** context. (See “Context Initiation” on page 113.)

## Syntax

### *get*

get local-pref

**set**

```
set [ipv4 | ipv6] local-pref number
```

**Keywords and Variables****Variable Parameter**

```
set [ipv4 | ipv6] local-pref number
```

*number*                    The preference level for the VR.

**ipv4 | ipv6**

```
set [ipv4 | ipv6] local-pref number
unset [ipv4 | ipv6] local-pref number
```

*ipv4 | ipv6*                Indicates that you want to set the attribute or configuration for the routes of the IPv4 or IPv6 address family. If you do not use these keywords, only the routes of the IPv4 address family are configured (by default).

**med**

Use the **med** commands to specify or display the local Multi-Exit Discriminator (MED).

MED is an attribute that notifies a neighbor in another AS of the optimal path to use when there are multiple entry points to the AS. If an EBGp update contains a MED value, the BGP routing instance sends the MED to all IBGP peers within the AS. If you assign a MED value, this value overrides any MED values received in update messages from external peers.

Although you set the MED in the local AS, the neighbor in another AS uses the MED value to decide which entry point to use. If all other factors are equal, the path with the lowest MED value is chosen. The default MED value is 0.

Before you can execute a **med** command, you must initiate the **bgp** context. (See “Context Initiation” on page 113.)

**Syntax****get**

```
get med
```

**set**

```
set [ipv4 | ipv6] med id_num
```

**Keywords and Variables****Variable Parameter**

```
set [ipv4 | ipv6] med id_num
```

*id\_num*                    The identification number of the MED.

**Example:** The following command specifies MED 100 for the virtual router *trust-vr*:

**set med 100**

**ipv4 | ipv6**

```
set [ipv4 | ipv6] med id_num
unset [ipv4 | ipv6] med id_num
```

**ipv4 | ipv6**      Indicates that you want to set the attribute or configuration for the routes of the IPv4 or IPv6 address family. If you do not use these keywords, only the routes of the IPv4 address family are configured (by default).

## neighbor

Use the **neighbor** commands to set or display general configuration parameters for communicating with BGP peers.

Before you can execute a **neighbor** command, you must initiate the **bgp** context. (See “Context Initiation” on page 113.)

### Syntax

#### clear

```
clear { neighbor
 { ipv4_addr | ipv6_addr } { flap-route ipv4_route_addr [add] | soft-in |
 soft-out | stats } |
 ipv4 neighbor { ipv4_addr | ipv6_addr } { flap-route ipv4_route_addr
 [add] | soft-in | soft-out } |
 ipv6 neighbor { ipv4_addr | ipv6_addr } { flap-route ipv6_route_addr
 [add] | soft-in | soft-out }
 }
```

#### exec

```
exec neighbor { ipv4_addr | ipv6_addr }
 { connect | disconnect | tcp-connect }
```

#### get

```
get neighbor { ipv4_addr | ipv6_addr | peer-group name_str }
```

#### set

```
set [ipv4 | ipv6] neighbor { { ipv4_addr | ipv6_addr }
 [
 activate |
 advertise-def-route |
 ebgp-multihop number |
 enable |
 force-reconnect |
 hold-time number |
 keepalive number |
 md5-authentication string |
 med number |
 nhself-enable |
 peer-group name_str |
 reflector-client |
 reject-default-route |
```

```

remote-as number
[
 local-ip { ipv4_addr/mask | ipv6_addr/prefix_length } |
 outgoing-interface interface |
 src-interface interface
] |
remove-private-as
retry-time number |
route-map name_str { in | out } |
send-community |
weight number
] |
peer-group name_str
[
 ebgp-multihop number |
 force-reconnect |
 hold-time number |
 keepalive number |
 md5-authentication string |
 nhself-enable |
 reflector-client |
 remote-as number |
 retry-time number |
 route-map name_str { in | out } |
 send-community |
 weight number
]
}

```

## Keywords and Variables

### Variable Parameter

```

clear neighbor { ipv4_addr | ipv6_addr } flap-route ipv4_route_addr [...]
clear ipv4 neighbor { ipv4_addr | ipv6_addr } flap-route ipv4_route_addr [...]
clear ipv6 neighbor { ipv4_addr | ipv6_addr } flap-route ipv6_route_addr [...]
get neighbor { ipv4_addr | ipv6_addr } peer-group name_str
set [ipv4 | ipv6] neighbor { ipv4_addr | ipv6_addr } { ... }
unset [ipv4 | ipv6] neighbor { ipv4_addr | ipv6_addr } { ... }

```

*ipv4\_addr* | *ipv6\_addr* The IPv4 or IPv6 address of the neighboring peer device.

*ipv4\_route\_addr* | *ipv6\_route\_addr* The IPv4 or IPv6 address of the route for which advertisement is blocked with flap damping.

**Example:** The following command displays information about a neighbor device at IP address 1.1.100.101:

```
get neighbor 1.1.100.101
```

### activate

```

set [ipv4 | ipv6] neighbor { ipv4_addr | ipv6_addr } activate
unset [ipv4 | ipv6] neighbor { ipv4_addr | ipv6_addr } activate

```

**activate** Sets or unsets the address family for the neighbor. Use this keyword before you enable the BGP neighbor with the **enable** keyword so that the new address family can be negotiated through open messages at the session start stage.

**ipv4 | ipv6** Indicates that you want to set the attribute or configuration for the routes of the IPv4 or IPv6 address family. If you do not use these keywords, only the routes of the IPv4 address family are configured (by default).

### **advertise-def-route**

```
set [ipv4 | ipv6] neighbor { ipv4_addr | ipv6_addr | peer-group name_str }
 advertise-def-route
unset neighbor [ipv4 | ipv6] neighbor { ipv4_addr | ipv6_addr | peer-group name_str }
 advertise-def-route
```

**advertise-def-route** Advertises the default route in the current VR to the BGP peer.

**ipv4 | ipv6** Indicates that you want to set the attribute or configuration for the routes of the IPv4 or IPv6 address family. If you do not use these keywords, only the routes of the IPv4 address family are configured (by default).

### **connect**

```
exec neighbor { ipv4_addr | ipv6_addr } connect
```

**connect** Establishes a BGP connection to the neighbor. You can use this command to troubleshoot a BGP connection.

### **disconnect**

```
exec neighbor { ipv4_addr | ipv6_addr } disconnect
```

**disconnect** Terminates the BGP connection to the neighbor. You can use this command for troubleshooting a BGP connection.

### **ebgp-multihop**

```
set neighbor { ipv4_addr | ipv6_addr | peer-group name_str } ebgp-multihop number
unset neighbor { ipv4_addr | ipv6_addr | peer-group name_str } ebgp-multihop
```

**ebgp-multihop** The number of intervening routing nodes (*number*) allowed between the local BGP router and the BGP neighbor (*ipv4\_addr* or *ipv6\_addr*). A setting of zero (the default value) disables the multihop feature.

The local BGP router uses the **ebgp-multihop** value as the time-to-live (TTL) value

**Example:** The following command examples direct the VR to allow three intervening route nodes between the VR and a neighbor device at the specified IP address.

- IPv4 address:

```
set neighbor 1.1.100.101 ebgp-multihop 3
```

- IPv6 address:

```
set neighbor 2001:0db8:3aaa::2 ebgp-multihop 3
```

**enable**

```
set neighbor { ipv4_addr | ipv6_addr } enable
unset neighbor { ipv4_addr | ipv6_addr } enable
```

enable                    Enables or disables peer communications.

**flap-route**

```
clear [ipv4 | ipv6] neighbor { ipv4_addr | ipv6_addr } flap-route ipv4_route_addr [...]
clear ipv4 neighbor { ipv4_addr | ipv6_addr } flap-route ipv4_route_addr [...]
clear ipv6 neighbor { ipv4_addr | ipv6_addr } flap-route ipv6_route_addr [...]
```

ipv4 | ipv6              Indicates that you want to set the attribute or configuration for the routes of the IPv4 or IPv6 address family. If you do not use these keywords, only the routes of the IPv4 address family are configured (by default).

flap-route               Specifies that the security device clear the neighbor's flap-damped route from history. (Flap damping blocks the advertisement of a route until the route becomes stable.)

**force-reconnect**

```
set neighbor { ipv4_addr | ipv6_addr | peer-group name_str } force-reconnect
unset neighbor { ipv4_addr | ipv6_addr | peer-group name_str } force-reconnect
```

force-reconnect        Causes the peer to drop the existing BGP connection and accept a new connection. You can use this option when NetScreen Redundancy Protocol (NSRP) failover occurs but the failover interval is long enough that the BGP peer still considers the connection to be active and rejects new connection attempts.

**hold-time**

```
set neighbor { ipv4_addr | ipv6_addr | peer-group name_str } hold-time number
unset neighbor { ipv4_addr | ipv6_addr | peer-group name_str } hold-time
```

hold-time               Specifies the number of seconds (*number*) that the current BGP speaker waits to receive a message from its neighbor. The default is 180 seconds.

**Example:** The following command examples specify a hold-time value of 60.

- IPv4 address:
 

```
set neighbor 1.1.10.10 hold-time 60
```
- IPv6 address:
 

```
set neighbor 2001:0db8:3aaa::2 hold-time 60
```

**keepalive**

```
set neighbor { ipv4_addr | ipv6_addr | peer-group name_str } keepalive number
unset neighbor { ipv4_addr | ipv6_addr | peer-group name_str } keepalive
```

**keepalive** Specifies the maximum amount of time (in seconds) that can elapse between keepalive packet transmissions before the local BGP virtual router terminates the connection to the neighbor. The default is one-third of the hold-time value (for the default **hold-time** value of 180 seconds, the default **keepalive** value is 60 seconds).

**Example:** The following command examples specify a keepalive value of 90 seconds.

- IPv4 address:

```
device(trust-vr/bgp)-> set neighbor 1.1.100.101 keepalive 90
```

- IPv6 address:

```
device(trust-vr/bgp)-> set neighbor 2001::2 keepalive 90
```

#### **md5-authentication**

```
set neighbor { ipv4_addr | ipv6_addr | peer-group name_str } md5-authentication string
unset neighbor { ipv4_addr | ipv6_addr | peer-group name_str } md5-authentication string
```

**md5-authentication** Specifies the BGP peer MD5 authentication string. The maximum length is 32 characters.

**Example:** The following command examples specify an MD5 authentication string (5784ldk094).

- IPv4 address:

```
set neighbor 1.1.100.101 md5-authentication 5784ldk094
```

- IPv6 address:

```
set neighbor 2005::2 md5-authentication 5784ldk094
```

#### **med**

```
set [ipv4 | ipv6] neighbor { ipv4_addr | ipv6_addr } med id_num
unset [ipv4 | ipv6] neighbor { ipv4_addr | ipv6_addr } med
```

**ipv4 | ipv6** Indicates that you want to set the attribute or configuration for the routes of the IPv4 or IPv6 address family. If you do not use these keywords, only the routes of the IPv4 address family are configured (by default).

**med** Specifies the ID number (*id\_num*) of the local Multi-Exit Discriminator (MED). The default value is 0.

**Example:** The following command examples specify the MED 20099 for a neighbor with the specified IP address.

- For routes of the IPv4 address family:

```
set neighbor 1.1.10.10 med 20099
```

- For routes of the IPv6 address family:

```
set ipv6 neighbor 2001:0db8:3aaa::2 med 20099
```

#### ***nhself-enable***

```
set [ipv4 | ipv6] neighbor { ipv4_addr | ipv6_addr | peer-group name_str } nhself-enable
unset [ipv4 | ipv6] neighbor { { ipv4_addr | ipv6_addr } | peer-group name_str }
nhself-enable
```

|               |                                                                                                                                                                                                                            |
|---------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ipv4   ipv6   | Indicates that you want to set the attribute or configuration for the routes of the IPv4 or IPv6 address family. If you do not use these keywords, only the routes of the IPv4 address family are configured (by default). |
| nhself-enable | Specifies that the Next-Hop path attribute for routes sent to this peer is set to the interface IP address of the local VR.                                                                                                |

**Example:** The following command examples make the interface IP address of the local VR the next hop value for the peer (1.1.10.10 or 2008::5).

- For routes of the IPv4 address family:

```
set ipv4 neighbor 1.1.10.10 nhself-enable
or
set neighbor 1.1.10.10 nhself-enable
```

- For routes of the IPv6 address family:

```
set ipv6 neighbor 1.1.10.10 nhself-enable
or
set ipv6 neighbor 2008::5 nhself-enable
```

#### ***peer-group***

```
get neighbor peer-group name_str
set neighbor { ipv4_addr | ipv6_addr } peer-group name_str [...]
set [ipv4 | ipv6] neighbor { ipv4_addr | ipv6_addr | peer-group name_str } [...]
set neighbor peer-group name_str [...]
unset neighbor { ipv4_addr | ipv6_addr } peer-group name_str [...]
unset [ipv4 | ipv6] neighbor { ipv4_addr | ipv6_addr | peer-group name_str } [...]
unset neighbor peer-group name_str [...]
```

|             |                                                                                                                                                                                                                                                                                                                      |
|-------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ipv4   ipv6 | Indicates that you want to set the attribute or configuration for the routes of the IPv4 or IPv6 address family. If you do not use these keywords, only the routes of the IPv4 address family are configured (by default).                                                                                           |
| peer-group  | The name of a group of BGP neighbors. Each BGP neighbor in a peer group shares the same update policies. This allows you to set up policies that apply to all the BGP peers instead of creating a separate policy for each peer. Use this command to both create the peer-group and configure peer-group parameters. |

#### ***reflector-client***

```
set [ipv4 | ipv6] neighbor { ipv4_addr | ipv6_addr | peer-group name_str }
reflector-client
unset [ipv4 | ipv6] neighbor { ipv4_addr | ipv6_addr | peer-group name_str }
reflector-client
```

|                               |                                                                                                                                                                                                                            |
|-------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>ipv4   ipv6</code>      | Indicates that you want to set the attribute or configuration for the routes of the IPv4 or IPv6 address family. If you do not use these keywords, only the routes of the IPv4 address family are configured (by default). |
| <code>reflector-client</code> | Specifies that the neighbor is a reflector client in the route reflector cluster. The local BGP routing instance is the route reflector.                                                                                   |

**Example:** The following command examples specify that the neighbors in the peer group `Acme_Peers` are reflector clients for the routes of the specified address family.

- For routes of the IPv4 address family:
 

```
set ipv4 neighbor peer-group Acme_Peers reflector-client
```
- For routes of the IPv6 address family:
 

```
set ipv6 neighbor peer-group Acme_Peers reflector-client
```

#### **reject-default-route**

```
set [ipv4 | ipv6] neighbor { ipv4_addr | ipv6_addr | peer-group name_str }
 reject-default-route
unset [ipv4 | ipv6] neighbor { ipv4_addr | ipv6_addr | peer-group name_str }
 reject-default-route
```

|                                   |                                                                                                                                                                                                                            |
|-----------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>ipv4   ipv6</code>          | Indicates that you want to set the attribute or configuration for the routes of the IPv4 or IPv6 address family. If you do not use these keywords, only the routes of the IPv4 address family are configured (by default). |
| <code>reject-default-route</code> | Specifies that the local BGP routing instance is to ignore default route advertisements from the peer. By default, default routes advertised by peers are added to the local routing table.                                |

#### **remote-as**

```
set neighbor { ipv4_addr | ipv6_addr | peer-group name_str } remote-as number [...]
set neighbor { ipv4_addr | ipv6_addr | peer-group name_str } remote-as number [...]
unset neighbor { ipv4_addr | ipv6_addr | peer-group name_str } remote-as number [...]
```

|                        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>remote-as</code> | Identifies the remote AS ( <i>number</i> ) to be the neighbor of the current BGP speaker: <ul style="list-style-type: none"> <li>■ <b>local-ip</b> { <i>ipv4_addr/mask</i>   <i>ipv6_addr/prefix_length</i> }—Specifies the local IP address for the EBGP multi-hop peer.</li> <li>■ <b>outgoing-interface</b> <i>interface</i>—Specifies the outgoing interface to which BGP binds.</li> <li>■ <b>src-interface</b> <i>interface</i>—Specifies the source interface to which the BGP binds.</li> </ul> |
|------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

**Example:** The following command examples identify AS 30 as the remote AS for the specified peer.

- IPv4 address:
 

```
set neighbor 1.1.10.10 remote-as 30
```

- IPv6 address:

```
set neighbor 2001::2 remote-as 30
```

#### **remove-private-as**

```
set [ipv4 | ipv6] neighbor { ipv4_addr | ipv6_addr } remove-private-as
unset [ipv4 | ipv6] neighbor { ipv4_addr | ipv6_addr } remove-private-as
```

|                   |                                                                                                                                                                                                                            |
|-------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ipv4   ipv6       | Indicates that you want to set the attribute or configuration for the routes of the IPv4 or IPv6 address family. If you do not use these keywords, only the routes of the IPv4 address family are configured (by default). |
| remove-private-as | Removes the private AS number from the AS-Path for this neighbor.                                                                                                                                                          |

#### **retry-time**

```
set neighbor { ipv4_addr | ipv6_addr | peer-group name_str } retry-time number
unset neighbor { ipv4_addr | ipv6_addr | peer-group name_str } retry-time number
```

|            |                                                                                                                                                                                                 |
|------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| retry-time | Specifies the time (in seconds) that the BGP routing instance retries to establish a session with the peer after an unsuccessful BGP session establishment attempt. The default is 120 seconds. |
|------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

#### **route-map**

```
set [ipv4 | ipv6] neighbor { ipv4_addr | ipv6_addr | peer-group name_str } route-map
name_str { in | out }
unset [ipv4 | ipv6] neighbor { ipv4_addr | ipv6_addr | peer-group name_str } route-map
name_str { in | out }
```

|             |                                                                                                                                                                                                                            |
|-------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ipv4   ipv6 | Indicates that you want to set the attribute or configuration for the routes of the IPv4 or IPv6 address family. If you do not use these keywords, only the routes of the IPv4 address family are configured (by default). |
| route-map   | Specifies the route map to use for the BGP neighbor. The <b>in</b>   <b>out</b> switches determine if the route map applies to incoming or outgoing routes.                                                                |

**Example:** The following command examples specify that the route map **Mkt\_Map** applies to incoming routes from the neighbor at the specified IP address.

- For routes of the IPv4 address family:

```
set neighbor 1.1.10.10 route-map Mkt_Map in
```

- For routes of the IPv6 address family:

```
set ipv6 neighbor 2aaa::/64 route-map Mkt_Map in
```

#### **send-community**

```
set [ipv4 | ipv6] neighbor { ipv4_addr | ipv6_addr | peer-group name_str }
send-community
unset [ipv4 | ipv6] neighbor { ipv4_addr | ipv6_addr | peer-group name_str }
send-community
```

|             |                                                                                                                                                                                                                            |
|-------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ipv4   ipv6 | Indicates that you want to set the attribute or configuration for the routes of the IPv4 or IPv6 address family. If you do not use these keywords, only the routes of the IPv4 address family are configured (by default). |
|-------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

`send-community` Directs the BGP routing protocol to transmit the community attribute to the neighbor. By default, the community attribute is not sent to neighbors.

### ***soft-in***

```
clear [ipv4 | ipv6] neighbor { ipv4_addr | ipv6_addr } soft-in
clear ipv4 neighbor { ipv4_addr | ipv6_addr } soft-in
clear ipv6 neighbor { ipv4_addr | ipv6_addr } soft-in
```

`ipv4 | ipv6` Indicates that you want to set the attribute or configuration for the routes of the IPv4 or IPv6 address family. If you do not use these keywords, only the routes of the IPv4 address family are configured (by default).

`soft-in` Specifies that the security device send a route-refresh request to the neighbor.

**Example:** The following command examples specify that a route-refresh request is to be sent to the neighbor at the specified IP address.

- For routes of the IPv4 address family:

```
clear neighbor 10.10.10.10 soft-in
or
clear neighbor 2001:0db8:3aaa::2 soft-in
```

- For routes of the IPv6 address family:

```
clear ipv6 neighbor 2001:0db8:3aaa::2 soft-in
```

### ***soft-out***

```
clear [ipv4 | ipv6] neighbor { ipv4_addr | ipv6_addr } soft-out
clear ipv4 neighbor { ipv4_addr | ipv6_addr } soft-out
clear ipv6 neighbor { ipv4_addr | ipv6_addr } soft-out
```

`ipv4 | ipv6` Indicates that you want to set the attribute or configuration for the routes of the IPv4 or IPv6 address family. If you do not use these keywords, only the routes of the IPv4 address family are configured (by default).

`soft-out` Specifies that the security device send a full routing table to the neighbor.

### ***stats***

```
clear neighbor { ipv4_addr | ipv6_addr } stats
```

`stats` Specifies that the security device clear the neighbor's statistics, including packet number statistics and so forth.

### ***tcp-connect***

```
exec neighbor { ipv4_addr | ipv6_addr } tcp-connect
```

`tcp-connect` Tests the TCP connection to the neighbor. You can use this command for troubleshooting a TCP connection.

### ***weight***

```
set [ipv4 | ipv6] neighbor { ipv4_addr | ipv6_addr | peer-group name_str } weight
number
unset [ipv4 | ipv6] neighbor { ipv4_addr | ipv6_addr | peer-group name_str } weight
```

|                          |                                                                                                                                                                                                                            |
|--------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>ipv4   ipv6</code> | Indicates that you want to set the attribute or configuration for the routes of the IPv4 or IPv6 address family. If you do not use these keywords, only the routes of the IPv4 address family are configured (by default). |
| <code>weight</code>      | The preference for routes learned from this neighbor. The higher the value, the more preference given to the routes learned from this neighbor. The default value is 100.                                                  |

**Example:** The following command examples assign a weight of 200 to the path to the neighbor at the specified IP address.

- For routes of the IPv4 address family:  
`set neighbor 1.1.10.10 weight 200`
- For routes of the IPv6 address family:  
`set ipv6 neighbor 2001::2 weight 200`

## **network**

Use the **network** commands to create, display, or delete static network and subnet mask (IPv4) or prefix length (IPv6) entries that are reachable from the VR. BGP advertises these entries to peer devices, without first requiring redistribution into BGP (as with static routing table entries).

Before you can execute a **network** command, you must initiate the **bgp** context. (See “Context Initiation” on page 113.)

### **Syntax**

#### **get**

```
get [ipv4 | ipv6] network
```

#### **set**

```
set { [ipv4] network ipv4_addr1/mask1 [no-check | check ipv4_addr2/mask2] |
 ipv6 network ipv6_addr1/prefix_length1 [no-check |
 check ipv6_addr2/prefix_length2] }
 [weight number | route-map name_str]
```

### **Keywords and Variables**

#### **Variable Parameters**

```
set [ipv4] network ipv4_addr1/mask1 [no-check | check ipv4_addr2/mask2] [...]
set ipv6 network ipv6_addr1/prefix_length1 [no-check |
check ipv6_addr2/prefix_length2] [...]
unset [ipv4] network ipv4_addr1/mask1 [no-check | check ipv4_addr2/mask2] [...]
unset ipv6 network ipv6_addr1/prefix_length1 [no-check |
check ipv6_addr2/prefix_length2] [...]
```

*ipv4\_addr/mask* The IP address and subnet mask of the network. The subnet mask value indicates which bits of the address are significant. The mask does not have to be the same as the subnet mask used in the network. For example, 10.0.0.0/8 is a valid network to be advertised by BGP. When the **check** option is used, *ip4\_addr1/mask1* can be a MIP address range.

*ipv6\_addr/prefix\_length* The IP address and prefix\_length of the network. The address is specified in hexadecimal, using 16-bit values between colons. The prefix\_length is a decimal value that indicates how many of the high-order contiguous bits of the address comprise the prefix (the network portion of the address).

**Example:** The following command examples create a network entry for the virtual router *trust-vr*.

- For routes of the IPv4 address family:

```
set network 10.1.0.0/16
```

- For routes of the IPv6 family:

```
set ipv6 network 2aaa::/64
```

#### **check**

```
set [ipv4] network ipv4_addr1/mask1 check ipv4_addr2/mask2
set ipv6 network ipv6_addr1/prefix_length1 check ipv6_addr2/prefix_length2
```

**check** Directs the device to check *ipv4\_addr2/mask2* or *ipv6\_addr2/prefix\_length2* for network reachability before advertising *ipv4\_addr1/mask1* or *ipv6\_addr1/prefix\_length1* to BGP peers. If *ipv4\_addr2/mask2* or *ipv6\_addr2/prefix\_length2* is reachable, BGP advertises *ipv4\_addr1/mask1* or *ipv6\_addr1/prefix\_length1* to its peers. If *ipv4\_addr2/mask2* or *ipv6\_addr2/prefix\_length2* becomes unreachable, BGP withdraws the route *ipv4\_addr1/mask1* or *ipv6\_addr1/prefix\_length1* from its peers.

#### **no-check**

```
set [ipv4] network ipv4_addr/mask no-check
set ipv6 network ipv6_addr/prefix_length no-check
```

**no-check** Directs the device not to check for network reachability.

#### **ipv4 | ipv6**

```
set [ipv4] network ipv4_addr/mask [...]
set ipv6 network ipv6_addr/prefix_length [...]
```

**ipv4 | ipv6** Indicates that you want to set the attribute or configuration for the routes of the IPv4 or IPv6 address family. If you do not use these keywords, only the routes of the IPv4 address family are configured (by default). For the **get** command, if you do not use these keywords, all related content is listed, including the routes of both the IPv4 and IPv6 address families.

#### **route-map**

```
set [ipv4] network ipv4_addr/mask [...] route-map name_str
set ipv6 network ipv6_addr/prefix_length [...] route-map name_str
```

`route-map` Sets the attributes of this route entry to those in the specified route map.

### **weight**

```
set [ipv4] network ipv4_addr/mask [...] weight number
set ipv6 network ipv6_addr/prefix_length [...] weight number
```

`weight` Sets the weight of this route entry to the specified value. Enter a value between 0 and 65535.

## **redistribute**

Use the **redistribute** commands to import routes advertised by external routers that use protocols other than BGP. Use the **get redistribution** command to display current redistribution settings.

Before you can execute a **redistribute** command, you must initiate the **bgp** context. (See “Context Initiation” on page 113.)

### **Syntax**

#### **get**

```
get redistribution
```

#### **set**

```
set { [ipv4] redistribute route-map name_str protocol { connected | discovered |
imported | ospf | rip | static } |
 ipv6 redistribute route-map name_str protocol { connected | discovered |
imported | ripng | static }
}
```

### **Keywords and Variables**

#### **ipv4 | ipv6**

```
set { [ipv4] | ipv6 } redistribute route-map name_str protocol { ... }
unset { [ipv4] | ipv6 } redistribute route-map name_str protocol { ... }
```

`ipv4 | ipv6` Indicates that you want to set the attribute or configuration for the routes of the IPv4 or IPv6 address family. If you do not use these keywords, only the routes of the IPv4 address family are configured (by default).

#### **protocol**

```
set { [ipv4] | ipv6 } redistribute route-map name_str protocol { ... }
unset { [ipv4] | ipv6 } redistribute route-map name_str protocol { ... }
```

`protocol` The protocol from which the redistributed routes were learned. For IPv4, use one of the following keywords: **connected**, **discovered**, **imported**, **ospf**, **rip**, or **static**. For IPv6, use one of the following keywords: **connected**, **discovered**, **imported**, **ripng**, or **static**.

**route-map**

```
set { [ipv4] | ipv6 } redistribute route-map name_str protocol { ... }
unset { [ipv4] | ipv6 } redistribute route-map name_str protocol { ... }
```

route-map            The name (*name\_str*) of the route map to be used to filter routes.

**redistribution**

Use the **redistribution** command to display BGP redistribution rules.

Before you can execute the **redistribution** command, you must initiate the **bgp** context. (See “Context Initiation” on page 113.)

**Syntax**

```
get redistribution
```

**Keywords and Variables**

None.

**reflector**

Use the **reflector** commands to allow the local VR to serve as a route reflector to clients in a cluster.

A *route reflector* is a router that passes IBGP learned routes to specified IBGP neighbors (*clients*), thus eliminating the need for each router in a full mesh to talk to every other router. A cluster consists of multiple routers, with a single router designated as the route reflector, and the others as clients. Routers outside of the cluster treat the entire cluster as a single entity, instead of interfacing with each individual router in full mesh. This arrangement greatly reduces overhead. The clients exchange routes with the route reflector, while the route reflector reflects routes between clients.

To configure clients in the cluster, use the **reflector-client** command option of “neighbor” on page 127.

Before you can execute a **reflector** command, you must initiate the **bgp** context. (See “Context Initiation” on page 113.)

**Syntax**

```
get
get reflector
```

```
set
set reflector [cluster-id id_num]
```

**Keywords and Variables****cluster-id**

```
set reflector cluster-id id_num
unset reflector cluster-id id_num
```

**cluster-id**            The ID number (*id\_num*) of the cluster. The cluster ID allows the BGP routing instance to append the cluster ID to the cluster list of a route. BGP must be disabled before you can set the cluster ID.

**Example:** The following command allows the local BGP routing instance to serve as a route reflector, and sets the cluster ID to 20:

```
set reflector
set reflector cluster-id 20
```

## ***reject-default-route***

Use the **reject-default-route** commands to enable, disable, or display the reject-default-route setting. Enabling this setting makes the security device ignore default route advertisements from a BGP peer router. By default, BGP accepts default routes advertised by BGP peers.

Before you can execute an **reject-default-route** command, you must initiate the **bgp** context. (See “Context Initiation” on page 113.)

### **Syntax**

#### **get**

```
get reject-default-route
```

#### **set**

```
set [ipv4 | ipv6] reject-default-route
```

### **Keywords and Variables**

#### ***ipv4 | ipv6***

```
set [ipv4 | ipv6] reject-default-route
unset [ipv4 | ipv6] reject-default-route
```

**ipv4 | ipv6**            Indicates that you want to set the attribute or configuration for the routes of the IPv4 or IPv6 address family. If you do not use these keywords, only the routes of the IPv4 address family are configured (by default).

## ***retry-time***

Use the **retry-time** command to specify the amount of time (in seconds) after failing to establish a BGP session with a peer that the local BGP routing instance retries to initiate the session. The default is 120 seconds.

Before you can execute a **retry-time** command, you must initiate the **bgp** context. (See “Context Initiation” on page 113.)

### **Syntax**

```
set retry-time number
unset retry-time number
```

## Keywords and Variables

None.

### *rib-in*

Use the **rib-in** command to display the BGP internal routing information base (RIB) learned from peers.

Before you can execute the **rib-in** command, you must initiate the **bgp** context. (See “Context Initiation” on page 113.)

## Syntax

```
get { rib-in [ipv4_addr/mask | ipv6_addr/prefix_length] |
 ipv4 rib-in [ipv4_addr/mask] |
 ipv6 rib_in [ipv6_addr/prefix_length]
 }
```

## Keywords and Variables

### *Variable Parameter*

|                                |                                                                      |
|--------------------------------|----------------------------------------------------------------------|
| <i>ipv4_addr/mask</i>          | The network mask for which you want to see RIB information.          |
| <i>ipv6_addr/prefix_length</i> | The network prefix_length for which you want to see RIB information. |

### *ipv4 | ipv6*

```
get ipv4 rib-in [ipv4_addr/mask]
get ipv6 rib-in [ipv6_addr/mask]
```

|                    |                                                                                                                                                                                                                                                                                                                            |
|--------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <i>ipv4   ipv6</i> | Indicates that the protocol is IPv4 or IPv6. When you use these keywords, the IP address must be based on the same address family as the specified protocol. For the <b>get</b> command, if you do not use these keywords, all related content is listed, including the routes of both the IPv4 and IPv6 address families. |
|--------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

### *router-id*

Use the **router-id** command to display the ID for the VR.

Before you can execute the **router-id** command, you must initiate the **bgp** context. (See “Context Initiation” on page 113.)

## Syntax

```
get router-id
```

## Keywords and Variables

None.

## **synchronization**

Use the **synchronization** command to enable synchronization with an Interior Gateway Protocol (IGP), such as OSPF.

If an EBGp router advertises a route before other routers in the AS learn the route via an IGP, traffic forwarded within the AS could be dropped if it reaches a router that has not learned the route. Synchronization prevents this from occurring by ensuring that a BGP router does not advertise a route until it has also learned the route through an IGP.

Before you can execute a **synchronization** command, you must initiate the **bgp** context. (See “Context Initiation” on page 113.)

### **Syntax**

```
set [ipv4 | ipv6] synchronization
```

### **Keywords and Variables**

#### **ipv4 | ipv6**

```
set [ipv4 | ipv6] synchronization
unset [ipv4 | ipv6] synchronization
```

**ipv4 | ipv6**      Indicates that you want to set the attribute or configuration for the routes of the IPv4 or IPv6 address family. If you do not use these keywords, only the routes of the IPv4 address family are configured (by default).

# bgroup

Use the **bgroup** command to create and delete bridge group (bgroup) interfaces. Bgroups let you group multiple Ethernet and wireless interfaces together. Each bgroup interface constitutes its own broadcast domain and provides high-speed Ethernet switching between interfaces within the group. You can assign a single IP address to each bgroup interface. You can bind a bgroup interface to any zone.

## Syntax

---

### set

```
set bgroup slot_number group_number
```

## Keywords and Variables

---

### Variable Parameters

|                     |                                                                                   |
|---------------------|-----------------------------------------------------------------------------------|
| <i>slot_number</i>  | Configures the slot number of the PIM on which you are creating the bridge group. |
| <i>group_number</i> | Configures the bridge group number.                                               |

**Example:** The following command creates bridge group interface bgroup5/0:

```
set bgroup 5 0
```



# bulkcli

Use the **bulkcli** command to send multi-line commands about the auth table, policies, virtual private networks (VPNs), users, and the configuration details of the IPsec Radius server from the Infranet Controller to the Infranet Enforcer.

## Syntax

---

### exec

```
exec bulkcli vsys name_str
{
 "exec auth table infranet
 auth-id id_num\;
 ip ip_addr\;
 {
 idle-timeout seconds\;
 role string\;
 role-names string\ |
 src-zone |
 user name_str\ |
 user-context user_context_str\ |
 }"
}

exec bulkcli vsys name_str
{
 " set auth-server name_str\
 account-type { [802.1X] [admin] | [auth] [l2tp] [xauth] } \r
 set auth-server name_str\ id id_num\ \r
 set auth-server name_str\ server-name { ip_addr | name_str } \ \r
 set auth-server name_str\ src-interface interface\ \r
 set auth-server name_str\
 radius
 {
 accounting-port number\ |
 attribute acct-session-id length number\ |
 compatibility rfc-2138 |
 port port_num\ |
 retries number\ |
 secret shar_secret\ |
 timeout number\ |
 zone-verification
 }"
}
```

```

exec bulkcli vsys name_str
{
 "set -n infranet policy command \"string\""
}

exec bulkcli vsys name_str
{
 "set user \"name_str\"enable \r
 set user \"name_str\"
 ike-id
 {
 asn1-dn { [container string] wildcard string } [share-limit \number\] |
 fqdn name_str [share-limit \number\] |
 ip string [share-limit \number\] |
 u-fqdn \"name_str \" [share-limit \number\]
 } \r
 set user \"name_str\"
 type { [auth] [ike] [l2tp] [wan] [xauth] } \r
 set user \"name_str\" uid \number\"
}

exec bulkcli vsys name_str
{
 "set user-group \"name_str\" id \id_num\ \r
 set user-group \"name_str\" user \"name_str\" \r
 set user-group \"name_str\" "
}

exec bulkcli vsys name_str
{
 "set ike gateway \"name_str\"
 {
 acvpn-dynamic [local-id string]
 acvpn-profile { proposal \name_str\ } { sec-level { basic | compatible | standard } } |
 address { \ip_addr\ | hostname [.dom_name] [id] }
 dialup { \usr_str\ | \grp_name\ }
 } \r
 set ike gateway \"name_str\"
 {
 dialup { \usr_str\ | \grp_name\ }
 {
 [aggressive | main] [local-id \id_str\]
 [outgoing-interface \interface\
 [outgoing-zone \zone\]
]
 [preshare \key_str\ | seed-preshare \key_str\]
 {
 sec-level { basic | compatible | standard } |
 proposal \"name_str1\"
 [\" name_str2 \"] [\"name_str3\"] [\"name_str4\"]
 }
 }
} \r
set ike gateway \"name_str\"
nat-traversal
[
 keepalive-frequency \number\ |
 udp-checksum
] \r

```

```

set ike gateway \name_str\
 xauth
 [
bypass-auth |
 client { any | chap | securid } username \name_str\ password \name_str\ |
do-edipi-auth |
 server \name_str\
 [chap] [query-config] [user \name_str\ | user-group \name_str\]
] \r
set ike gateway ikev2 \name_str\
 {
 auth-method
 self { preshare | rsa-sig | dsa-sig | eap }
 peer { preshare | rsa-sig | dsa-sig | eap } |
 eap
 {
 supplicant md5 username \name_str\ password password |
 authenticator passthrough auth-server [user \name_str\] [send-id-req]
 } |
 xauth { accounting off | accounting server \name_str\ }
 }"
}

exec bulkcli vsys \name_str\
 {
 "set vpn tunn_str\ gateway { ip_addr\ | \name_str\ }
 [replay | no-replay]
 [transport | tunnel]
 [idletime number\]
 {
 proposal [\name_str1\ [\name_str2\ [\name_str3\ [
 \name_str4\]]]] |
 sec-level { basic | compatible | standard }
 }"
 }

exec bulkcli vsys \name_str\
 {
 "set policy
 [id pol_num1]
 [from zone1 to zone2]
 src_addr dst_addr svc_name
 [
 nat
 [src [dip-id id_num]]
 [dst ip addr1 [addr2 | port port_num]]
]
 {
 deny |
 permit |
 reject |
 tunnel { l2tp tunn_str | vpn-group id_num }
 tunnel vpn tunn_str [l2tp tunn_str | pair-policy pol_num]"
 }"
 }

```

## Keywords and Variables

---

### **Variable Parameters**

exec bulkcli vsys *name\_str*

*name\_str* Defines the name of a virtual system (vsys) and automatically places the root-level admin within the vsys. Subsequent commands configure the newly created vsys.

auth See “auth” on page 81.

auth-server See “auth-server” on page 87.

ike See “ike” on page 285.

infranet See “infranet” on page 309.

policy See “policy” on page 539.

user See “user” on page 685.

user-group See “user-group” on page 691.

vpn See “vpn” on page 701.

# chassis

Use the **chassis** commands to activate the audible alarm feature or to set the normal and severe temperature thresholds for triggering temperature alarms.

## Syntax

---

### **get**

```
get chassis [slot]
```

### **set**

```
set chassis
{
 audible-alarm
 { all | battery | fan-failed | power-failed | temperature } |
 temperature-threshold
 { alarm | severe } { celsius number | fahrenheit number } |
 { cpu { celsius number | fahrenheit number } } |
 { system { celsius number | fahrenheit number } }
}
```

## Keywords and Variables

---

### **audible-alarm**

- audible-alarm** Enables or disables the audible alarm to announce hardware-failure events.
- **all**—Enables or disables the audible alarm in the event of a fan failure, an interface module failure, a power supply failure, or a temperature increase above an admin-defined threshold.
  - **battery**—Enables or disables the audible alarm in the event of a battery failure.
  - **fan-failed**—Enables or disables the audible alarm in the event of a fan failure.
  - **module-failed**—Enables or disables the audible alarm in the event of an interface-module failure.
  - **power-failed**—Enables or disables the audible alarm in the event of a power-supply failure.
  - **temperature**—Enables or disables the audible alarm if the temperature rises above an admin-defined threshold.

**Example:** To enable the audible alarm to sound in the event that one or more of the fans in the fan assembly fails:

```
set chassis audible-alarm fan-failed
```

### *temperature-threshold*

temperature-threshold Defines the temperature (**celsius** or **fahrenheit**) required to trigger a regular or severe alarm. A severe alarm sounds a greater frequency of audible alarms and generates a greater number of event-log entries.

**Example:** To enable an alarm when the CPU temperature reaches 65 degrees Celsius:

```
set chassis temperature-threshold cpu celsius 65
```

# clock

Use the **clock** commands to set the system time on the security device.

---

**NOTE:** By default, the security device automatically adjusts its system clock for daylight saving time.

---

## Syntax

---

### **get**

```
get clock
```

### **set**

```
set clock
{
 date [time] |
 dst
 {
 recurring
 {
 start-date date month hour:minute end-date date month hour:minute
 offset minutes |
 start-weekday { week day month hour:minute | last day month hour:minute }
 end-weekday { week day month hour:minute | last day month hour:minute }
 offset minutes
 } |
 start-date [date month year hour:minute end-date date month year hour:minute
 offset minutes]
 } |
 dst-off |
 ntp |
 timezone number
}
```

## Keywords and Variables

---

### **Variable Parameters**

set clock *date time*

*date time* Configures the correct current date and time on the security device. Specify the date and time using the following formats: *mm/dd/yyyy hh:mm* or *mm/dd/yyyy hh:mm:ss*.

**Example:** The following command sets the clock to December 15, 2002, 11:00am:

**set clock 12/15/2002 11:00**

### ***dst***

unset clock dst

*dst* Resets DST adjustment to the default setting (start on the second Sunday of March 02:00 and end on the first Sunday of November 02:00 with a 60 minute offset).

### ***dst-off***

set clock dst-off  
unset clock dst-off

*dst-off* Turns off the automatic time adjustment for daylight saving time.

### ***ntp***

set clock ntp  
unset clock ntp

*ntp* Configures the device for Network Time Protocol (NTP), which synchronizes computer clocks on the Internet.

## recurring

```
set clock dst recurring start-date date month hour:minute end-date date month
hour:minute offset minutes
set clock dst recurring start-weekday { week day month hour:minute | last day month
hour:minute } end-weekday { week day month hour:minute | last day month
hour:minute } offset minutes
```

recurring Sets DST adjustment to recur yearly on specific dates or specific weekdays.

- **date:** Date of the month (1-31).
- **day** Day of the week, with 0 representing Sunday and 6 representing Saturday.
- **end-date:** Date when DST adjustment should end.
- **end-weekday:** Weekday when DST adjustment should end.
- **hour:minute** Hour and minute.
- **last:** Adjust on the last specified weekday of the specified month.
- **month:** Month of the year (1-12).
- **offset:** Adjustment in minutes.
- **start-date:** Recur on specific dates.
- **start-weekday:** Recur on specific days of the week and month.
- **week:** Week of the month (1-4).

## start-date

```
set clock dst start-date date month hour:minute end-date date month hour:minute
offset minutes
```

start-date Sets DST adjustment on a non-recurring basis. DST adjustment occurs on specific dates and will not repeat on a yearly basis.

- **date:** Date of the month (1-31).
- **end-date:** Date when DST adjustment should end.
- **hour:minute** Hour and minute.
- **month:** Month of the year (1-12).
- **offset:** Adjustment in minutes.
- **week:** Week of the month (1-4).

## timezone

```
set clock timezone number
unset clock timezone number
```

timezone Sets the current time-zone value. This value indicates the time difference between GMT standard time and the current local time (when DST is OFF). When DST is ON and the clock is already set forward one hour, decrease the time difference by one hour and set the minutes accurately. Set the value between -12 and 12.



# common-criteria

Use the **common-criteria** command to disable all internal commands. Only the root admin can set this command. If someone other than the root admin tries to set this command, the security device displays an error message.

## Syntax

---

```
set common-criteria no-internal-commands
```

## Keywords and Variables

---

### ***no-internal-commands***

```
set common-criteria no-internal-commands
unset common-criteria no-internal-commands
```

`no-internal-commands`     Disables all internal commands.



# config

Use the **config** commands to display the configuration settings for a security device or an interface.

You can display recent configuration settings (stored in RAM) or saved configurations (stored in flash memory).

## Syntax

---

### **exec**

```
exec config {
 lock { abort | end | start } |
 rollback [enable | disable]
}
```

### **get**

```
get config
[
 all |
 datafile |
 global |
 hash |
 lock |
 nsmgmt-dirty |
 rollback |
 saved |
 timestamp
]
```

### **set**

```
set config lock timeout number
```

## Keywords and Variables

---

### **all**

get config all

all                    Displays all configuration information.

### **datafile**

get config datafile

datafile              Displays the Security Manager datafile, which resides on the security device and contains current device configurations formatted according to the Security Manager syntax schema. ScreenOS generates the datafile from the current device configuration when the Security Manager management system queries the device.

### **global**

get config global [ hash ]

global                 Displays the configuration size and the global commands. The **hash** command displays the hash of the currently running configuration.

### **hash**

get config hash

hash                    Displays the MD5 hash of the currently running configuration.

### **lock**

exec config lock start  
 exec config lock end  
 exec config lock abort  
 set config lock timeout *number*  
 unset config lock timeout

lock                    Instructs the security device to lock a configuration file in memory for a specified interval.

- **exec config lock** Locks/unlocks the configuration file in memory. You can also abort the lockout and immediately restart the device with the configuration file that was previously locked in memory.
- **set config lock timeout** Changes the default lockout period, which is five minutes.

## nsmgmt-dirty

```
clear config nsmgmt-dirty
get config nsmgmt-dirty
```

**nsmgmt-dirty** Clears the “dirty” flag, which indicates that an administrator changed a ScreenOS setting or parameter locally instead of through Network and Security Manager (NSM).

ScreenOS pushes a message to NSM whenever a non-NSM entity, such as a WebUI session or a CLI-capable console session, modifies the device configuration. This message contains a flag named **NSP\_DEVICE\_DIRECTIVE\_NSMGMT\_DIRTY**, which informs NSM that a local change occurred. The device sends the message only once, so it does not send notice of any further locally executed changes until NSM (or a local administrator) clears the flag.

After NSM receives the message and finishes all necessary tasks in response, it issues the **clear config nsmgmt-dirty** command to the device, thus clearing the “dirty” flag.

## rollback

```
exec config rollback
exec config rollback enable
exec config rollback disable
get config rollback
```

**rollback** Reverts the security device to the last-known-good (LKG) configuration—providing that an LKG configuration is available.

- **enable**—Enables the security device to automatically roll back to the LKG configuration in case of a problem when loading a new configuration.
- **disable**—Disables the automation of the configuration-rollback feature on the security device. If you disable the automation of this feature, you can still perform a configuration rollback manually using the **exec config rollback** command.

### get config rollback

Indicates if an LKG configuration is available for configuration rollback and if the automatic config-rollback feature is enabled.

If there is an LKG configuration saved in memory, the following output displayed:

```
“lkg.cfg” (the name of the LKG file)
```

The config-rollback feature is enabled if the output of the command displays “= yes” at the end of the string. For example:

```
““lkg.cfg” = yes”
```

If the feature is not enabled, the output displays a blank space instead of “yes.”

## saved

```
get config saved
```

## ***timestamp***

get config timestamp

timestamp      Displays the time of the latest local change made on the currently running configuration.

# console

Use the **console** commands to define or list the CLI console parameters.

The console parameters determine the following:

- Whether the security device displays messages in the active console window
- The number of lines that may appear on a console window page
- The maximum time that can pass before automatic logout occurs due to inactivity

If console access is currently disabled, you can enable it using the **unset console disable** command through a Telnet connection.

## Syntax

---

### **get**

```
get console
```

### **set**

```
set console
 {
 aux disable |
 dbuf |
 disable |
 page number |
 save-on-exit default-no |
 timeout number
 }
```

## Keywords and Variables

---

### **aux disable**

```
set console aux disable
unset console aux disable
```

**aux disable** Enables or disables the auxiliary modem console port. Some platforms have this auxiliary port, in addition to the standard console port. An admin can use the auxiliary modem console port to execute CLI configuration commands. Use the **aux disable** switch to disable the port when you need to enforce strict security by excluding admin access through this port.

## ***dbuf***

```
set console dbuf
unset console dbuf
```

**dbuf** Redirects output to the debug buffer.

## ***disable***

```
set console disable
unset console disable
```

**disable** Disables console access through the serial port. Two confirmations are required to disable access to the console. Executing this option saves the current device configuration and closes the current login session.

**Note:** After you execute the **console disable** option, nonserial console sessions can still function (as with SSH and Telnet).

## ***page***

```
set console page number
unset console page
```

**page** An integer value specifying how many lines appear on each page between page breaks. When you set this value to zero, there are no page breaks, and the text appears in a continual stream.

**Example:** To define 20 lines per page displayed on the console:

```
set console page 20
```

## ***timeout***

```
set console timeout number
unset console timeout
```

**timeout** Determines how many minutes the device waits before closing an inactive administrator session. If you set the value to zero, the console never times out.

**Example:** To define the console timeout value to 40 minutes:

```
set console timeout 40
```

## ***Defaults***

Access to the serial console is *enabled*.

The console displays *22* lines per page.

The default inactivity timeout is *10* minutes.

The security device sends console messages to the *buffer* by default.



# core-dump

Use the **core-dump** command to configure diagnostic core dumps to a file on a USB storage device inserted into the USB port found on some security devices. Since security devices do not initialize their USB ports until after executing the configuration file, you must manually enter this command to capture a core dump.

## Syntax

---

### **get**

get core-dump

### **set**

set core-dump usb { large | full } filename\_prefix [file\_size]

## Keywords and Variables

---

### **full | large**

set core-dump usb { large | full }...

**full | large** Enables either large or full-mesh coredump to USB. A Large core dump contains basic system information plus all of the device register contents. A Full core dump contains the same information as a Large core dump plus all of the device memory contents that will fit into the specified file size.

### **filename\_prefix**

set core-dump... *filename\_prefix*...

**filename** Specifies the filename prefix for the coredump. The full filename for the core dump is < hostname> \_< filename\_prefix> . The device creates the specified file on the drive at the time the command is issued.

### **file\_size**

set core-dump... [ *file\_size* ]

`file_size` Sets the maximum file size for the core dump in megabytes. The default file size is 1 MB.

**Example:** The following command instructs the security device to direct full core-dump information, including the first 2 MB of memory contents, to the file `hostname_exception.log` on the inserted USB drive.

```
set core-dump usb full exception.log 2
```

# counter

Use the **counter** commands to clear or display the values contained in traffic counters.

Traffic counters provide processing information that you can use to monitor traffic flow. The security devices maintain the following categories of counters:

- **Screen**—for monitoring firewall behavior for the entire zone or for a particular interface
- **Policy**—for reporting the amount of traffic affected by specified policies
- **Hardware**—for monitoring hardware performance and tracking the number of packets containing errors
- **Flow**—for monitoring the number of packets inspected at the flow level

## Syntax

---

### *clear*

```
clear [cluster] counter
{
 all |
 flow |
 ha |
 interface |
 screen [interface interface | zone zone]
}
```

### *get*

```
get counter
{
 flow | statistics
 [interface interface [extensive] | zone zone] |
 screen { interface interface | zone zone }
 policy pol_num { day | hour | minute | month | second }
}
```

## Keywords and Variables

---

### **cluster**

clear [ cluster ] counter [ ... ]

**cluster** Propagates the **clear** operation to all other devices in an NSRP cluster.

**Example:** To clear the contents of all counters and propagate the operation to all devices in the cluster:

**clear cluster counter all**

### **flow**

clear counter flow  
get counter flow [ ... ]

**flow** Specifies counters for packets inspected at the flow level. A flow-level inspection examines various aspects of a packet to gauge its nature and intent.

### **ha**

clear [ cluster ] counter ha

**ha** Specifies counters for packets transmitted across a high-availability (HA) link between two security devices. An HA-level inspection keeps count of the number of packets and packet errors.

### **interface**

clear counter interface

**interface** Clears counters for packets inspected at the interface level. The inspection checks for packet errors and monitors the quantity of packets according to established threshold settings.

### **policy**

get counter policy *pol\_num* { day | hour | minute | month | second }

**policy** Identifies a particular policy (*pol\_num*). This allows you to monitor the amount of traffic that the policy permits.

**day | hour | minute | month | second**—Specifies the period of time for monitoring traffic permitted by a particular policy.

**screen**

```
clear [cluster] counter screen [interface interface | zone zone]
get counter screen { interface interface | zone zone }
```

**screen** Clears the screen counters. The **interface** *interface* parameter specifies the name of a particular interface. For more information, see “Interfaces” on page 771.

**statistics**

```
get counter statistics [...]
```

**statistics** Displays the counter statistics.

**zone**

```
get counter screen zone zone
```

**zone** Identifies the zone, and specifies counters for packets inspected at the zone level. The inspection checks for packet errors and monitors the quantity of packets according to established threshold settings. For more information, see “Interfaces” on page 771.



# cpu-limit

Use the **cpu-limit** commands to enable and configure the CPU limit feature, which allows you to configure a more fair distribution of CPU resources.

Before you configure CPU limit feature parameters, you must use the **set cpu-limit** command to initialize and allocate resources for the feature.

Use the **get cpu-limit** command to review CPU limit feature parameters configured with the **set cpu-limit** commands.

## Syntax

---

### **exec**

```
exec cpu-limit mode { fair | shared }
```

### **get**

```
get cpu-limit [utilization]
```

### **set**

```
set cpu-limit
 [
 enable |
 fair-to-shared
 {
 automatic [threshold number] |
 fair-time number |
 never
 } |
 shared-to-fair threshold number [hold-down-time number]
]
```

## Keywords and Variables

---

### **enable**

```
set cpu-limit enable
unset cpu-limit enable
```

**enable** Use this command after configuring the CPU limit feature parameters to enable the feature.

**Example:** The following command enables the CPU limit feature:

```
set cpu-limit enable
```

## ***fair-to-shared***

```
set cpu-limit fair-to-shared automatic [threshold number] [hold-down-time number]
set cpu-limit fair-to-shared fair-time number
set cpu-limit fair-to-shared never
unset cpu-limit fair-to-shared { ... }
```

**fair-to-shared** Configures parameters to determine when the security device transitions from Fair to Shared mode.

- **automatic**—Specifies that the security device automatically transitions to Shared mode when the flow CPU utilization percentage falls below a specific threshold.  
Optionally, specify the threshold value, which is from 0 through 100 percent. If you do not specify a threshold value, the threshold is the same value as the shared-to-fair threshold.
- **fair-time**—Specifies the amount of time the security device is in Fair mode before going back to Shared mode. The value range is 5 through 7200 seconds (2 hours). The default value is 30 seconds.
- **never**—Specifies that the security device never transitions from Fair to Shared mode. You can manually force the security device into Shared mode by using the **exec cpu-limit mode shared** command.

The following command configures the security device to remain in Fair mode for 3600 seconds (1 hour).

```
set cpu-limit fair-to-shared fair-time 3600
```

## ***mode***

```
exec cpu-limit mode { fair | shared }
```

**fair** Forces the security device into Fair mode.

**shared** Forces the security device into Shared mode.

Depending on network conditions and the configured CPU limit feature parameters, the security device might transition from the mode specified by this command. Use the **exec cpu-limit mode shared** command to return to Shared mode in the following situations:

- You configured the security device to never transition from Fair to Shared mode.
- You want the security device to return to Shared mode before the specified fair-time value or hold-down time elapses.

If you configured a hold-down time with the **set cpu-limit shared-to-fair** command, use the **exec cpu-limit mode fair** command if you want the security device to return to Fair mode before the hold-down time elapses.

The following command forces the security device into Fair mode:

```
exec cpu-limit mode fair
```

The following command forces the security device into Shared mode:

```
exec cpu-limit mode shared
```

### ***shared-to-fair threshold***

```
set cpu-limit shared-to-fair threshold number [hold-down-time number]
unset cpu-limit shared-to-fair threshold
```

**shared-to-fair threshold** Configures the flow CPU utilization percentage threshold at which the security device transitions from shared mode to Fair mode. The value range is 0 through 100. The default value is 80%.

Optionally, configure a hold-down time, which is the minimum amount of time that the flow CPU utilization percentage must exceed the flow CPU utilization percentage threshold. Valid value range is 0 through 1800 seconds (30 minutes). The default value is 5 seconds.

The following command configures that the security device transitions from Shared to Fair mode when the flow utilization percentage stays above 70% for longer than 30 seconds:

```
set cpu-limit shared-to-fair threshold 70 hold-down-time 30
```

### ***utilization***

```
get cpu-limit utilization
```

**utilization** Displays flow CPU utilization for the last 60 seconds. Entries with an asterisk indicate that the security device was in Fair mode.

The following command displays the flow CPU utilization for the last 60 seconds:

```
get cpu-limit utilization
```



# cpu-protection

Use the **cpu-protection** commands to configure the security device to drop malicious packets within the application-specific integrated circuit (ASIC) after the CPU has detected the malicious traffic. The CPU protection mechanism applies to the entire security device and is not limited to specific virtual systems (vsys).

## Syntax

---

### **clear**

```
clear cpu-protection
{
 blacklist { all | id number } |
 statistics
}
```

### **set**

```
set cpu-protection
{
 blacklist
 {
 id number |
 src-ip ip_addr/mask |
 dst-ip ip_addr/mask
 {
 protocol number [src-port number] [dst-port number]
 }
 [timeout number]
 } |
 threshold number
}
```

## Keywords and Variables

---

### **blacklist**

```
set cpu-protection blacklist [...]
```

unset cpu-protection blacklist id *number*

|           |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
|-----------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| blacklist | Configures a blacklist entry to detect a malicious packet reaching the security device.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|           | <ul style="list-style-type: none"> <li>■ <b>id</b> <i>number</i>—Specifies the ID of the blacklist entry. The range is from 0 to 31.</li> <li>■ <b>src-ip</b> <i>ip_addr/mask</i>—Specifies the source IP address and netmask of the packet</li> <li>■ <b>dst-ip</b> <i>ip_addr/mask</i>—Specifies the destination IP address and netmask of the packet</li> <li>■ <b>protocol</b> <i>number</i>—Specifies the protocol number of the packet. The range is 0 to 255. Set to 0 to match any protocol.</li> <li>■ <b>src-port</b> <i>number</i>—Specifies the source port number of the packet. Set this to 0 to match all valid port numbers when the protocol is either TCP or UDP.</li> <li>■ <b>dst-port</b> <i>number</i>—Specifies the destination port number of the packet. Set to 0 to match all valid port numbers when the protocol is either TCP or UDP.</li> <li>■ <b>timeout</b> <i>number</i>—Specifies the length of time, in minutes, before the security device removes a blacklist entry. The range is 0 to 600 minutes. Set to 0 to permanently keep the blacklist entry.</li> </ul> |

**Example:** Use the following command to configure a blacklist entry that expires after five minutes:

```
set cpu-protection blacklist id 4 1.1.1.1/32 2.2.2.2/32 protocol 6 src-port 3128
dst-port 8080 timeout 5
```

## statistics

get cpu-protection statistics

|            |                                         |
|------------|-----------------------------------------|
| statistics | Displays the CPU protection statistics. |
|------------|-----------------------------------------|

## threshold

set cpu-protection threshold *number*

unset cpu-protection threshold *number*

|           |                                                                                                                                                                                                                                                                                                                                                                                            |
|-----------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| threshold | Sets the CPU protection threshold as a percentage of CPU utilization. The security device starts prioritizing traffic when the threshold limit is reached. The default value is 100; the range is 0 to 100. The security device drops all noncritical traffic when the threshold is set to 0. When the threshold is set to 100, the security device allows noncritical traffic to the CPU. |
|-----------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

# crypto-policy

Use the **crypto-policy** command to configure a cryptographic policy on the security device. You need to be a cryptographic or root administrator to configure cryptographic policies.

## Syntax

---

### set

```
set crypto-policy
set auth-alg { md5 | sha-1 | sha2-256 }
set auth-method { dsa-sig | ecdsa-sig | preshare | rsa-sig }
set dh { group1 | group2 | group 5 | group14 }
set encrypt-alg { 3des | aes128 | aes192 | aes 256 | des }
set mode { main | aggressive }
set p1-sa-lifetime upper-threshold
{
 days number |
 hours number |
 minutes number |
 seconds number
}
set p2-sa-lifetime upper-threshold
{
 days number |
 hours number |
 minutes number |
 seconds number
}
set p2-sa-size upper-threshold number
```

### exit

```
exit
```

## Keywords and Variables

---

### *crypto-policy*

set crypto-policy

crypto-policy      Configures the cryptographic policy. This command is visible to the root and cryptographic admins only.

### *auth-alg*

set auth-alg { md5 | sha-1 | sha2-256 }

alert                Configures the authentication algorithm in the context of a cryptographic policy. You can specify MD5, SHA-1, or SHA2-256.

### *auth-method*

set auth-method { dsa-sig | ecdsa-sig | preshare | rsa-sig }

auth-method        Configures the authentication method in the context of a cryptographic policy.

### *dh*

set dh { group1 | group2 | group5 | group14 }

dh                    Configures the Diffie-Hellman (DH) Group in the context of a cryptographic policy. You can specify **Group1**, **Group2**, **Group5**, or **Group14**.

### *encrypt-alg*

set encrypt-alg { 3des | aes128 | aes192 | aes256 | des }

encrypt-alg        Configures the encryption algorithm in the context of a cryptographic policy. You can specify **3des**, **aes128**, **aes192**, **aes256**, or **des** encryption algorithm.

### *exit*

exit

exit                Exits from the cryptographic policy context.

### *mode*

set mode { main | aggressive }

mode                Configures the operational mode in the context of a cryptographic policy. You can use both modes if no operational mode is specified in the policy.

### ***p1-sa-lifetime***

```
set p1-sa-lifetime upper-threshold { days number | hours number | minutes number |
seconds number }
```

**p1-sa-lifetime** Configures the upper threshold limit for the Phase 1 security association (SA) lifetime in the context of a cryptographic policy. The value can be in days, hours, minutes, or seconds.

### ***p2-sa-lifetime***

```
set p2-sa-lifetime upper-threshold { days number | hours number | minutes number |
seconds number }
```

**p2-sa-lifetime** Configures the upper threshold limit for the Phase 1 SA lifetime in the context of a cryptographic policy. The value can be in days, hours, minutes, or seconds.

After creating a new cryptographic policy, you must save the configuration and restart the security device for the changes to take effect. You must use the **exit** command to exit from the cryptographic policy context.

### ***p2-sa-size***

```
set p2-sa-size upper-threshold number
```

**p2-sa-size** Configures the upper threshold limit for the Phase 2 SA life size in the context of a cryptographic policy.



# dbuf

Use the **dbuf** commands to set the size for the debug buffer and to direct debug information to a USB flash drive.

## Syntax

---

### set

```
set dbuf
{
 size number |
 usb { filename string | filesize number | default-file | enable }
}
```

### get

```
get dbuf usb
```

## Keywords and Variables

---

### size

```
set dbuf size number
unset dbuf size
```

size           ■ Sets the maximum file size, in megabytes, for the debug buffer. The default size is 4MB.

### usb

```
set dbuf usb { filename string | filesize number | default-file | enable }
unset dbuf usb { filename string | filesize number | enable }
```

**usb**

Specifies a USB flash drive as the target of debug information. Use **get dbuf usb** to query whether USB is enabled, the maximum file size, the current file size, the list of files created, and the active file.

- **filesize**—Sets the maximum size, in megabytes, for a file on a USB flash drive. The default size is 32 MB.
- **filename**—Defines the filename stored in a USB flash drive. The maximum number of files that can be created on a USB flash drive is 32.
- **enable**—Enables storing of debug information in a file on a USB flash drive.
- **default-file**—Sets the default-file as the active one to store debug information.

# delete

Use the **delete** commands to delete persistent information in flash memory or on a storage device.

## Syntax

---

```
delete [cluster]
{
 crypto { auth-key | file } |
 file dev_name:/filename |
 node_secret [ipaddr] ip_addr |
 nsmgmt keys |
 pki object-id { system | id_num } |
 ssh device all
}
```

## Keywords and Variables

---

### **crypto**

```
delete [cluster] crypto auth-key
delete [cluster] crypto file
```

**crypto** Removes encrypted items from flash memory.

- **auth-key**—Removes image signature verification key.
- **file**—Removes all crypto hidden files.

### **file**

```
delete file { dev_name:/filename }
```

**file** The file residing on the module named **dev\_name** from the flash card memory. Flash and Universal Serial Bus (USB) are the only *dev\_name* names available. The *filename* is the file that you want to delete that was saved on the flash card or USB storage device. If you do not specify a device, the system defaults to flash.

**Example:** The following command deletes a file named **myconfig** in the flash memory on the memory board:

```
delete file flash:myconfig
```

**node\_secret ipaddr**

```
delete node_secret [ipaddr] ip_addr
```

**node\_secret** Deletes the SecurID stored node secret. The node secret is a 16-byte key shared between the SecurID Ace server and its clients (which may include the security device). The server and the clients use this key to encrypt exchanged traffic. The Ace Server sends the node secret to the security device during initial authentication.

The node secret *must* remain consistent with the ACE Server. Otherwise, there can be no communication between the security device and the ACE Server. You can detect communication problems by checking the ACE Server log for a message saying that the node secret is invalid. If you find such a message, the solution is as follows.

- Execute **delete node\_secret**.
- On the ACE Server, change the configuration for the client (the security device) to say that the server did *not* send the node secret.

This causes the security device to request the node secret and authorizes the ACE Server to send a new one. This action resyncs communication.

The **ipaddr ip\_addr** parameter clears the node secret associated with the outgoing IP address of the interface that communicates with the SecurID server (*ip\_addr*).

**nsmgmt**

```
delete nsmgmt keys
```

**nsmgmt keys** Deletes the public and private keys for nsmgmt. The security device uses these keys to encrypt and decrypt the Configlet file.

**pki object-id**

```
delete pki object-id { system | id_num }
```

**pki object-id** Deletes a particular public key infrastructure (PKI) object, which is a four digit value (*id\_num*) used to identify a PKI object in a security device.

**system** Deletes the system generated self-signed certificate.

**ssh device all**

```
delete ssh device all
```

**ssh device all** Clears all sessions and keys and disables SSH for all vsys on the device. The information removed includes:

- Active SSH sessions
- SSH enablement for the current vsys
- PKA keys
- Host keys

# deny-message

Use the **deny-message** command to allow administrators to add or modify deny messages in the integrated Web-filtering blocks.

## Syntax

---

### **set**

```
set deny-message deny_message_str
```

### **get**

```
get deny-message
```

## Keywords and Variables

---

### ***deny-message***

```
set deny-message deny_message_str
unset deny-message
```

**deny-message** Allows you to set and modify deny messages in integrated Web-filtering blocks. *deny-messages-str* is 1 to 500 characters in length. The unset command resets the deny message to the default:

Your page is blocked due to a security policy that prohibits access to \$URL-CATEGORY.



# di

Use the **di** commands to configure the security device to perform Deep Inspection (DI) on packets that use specified protocols.

DI is a mechanism for filtering traffic permitted by the firewall. DI enables the device to examine Layer 3 and 4 packet headers and Layer 7 application content and protocol characteristics in an effort to detect and prevent any attacks or anomalous behavior that might be present.

---

**NOTE:** This command is available only if the Advanced-mode license key is installed on the device.

---

Use the **di** commands along with “attack” on page 69 and “attack-db” on page 77, respectively.

## Syntax

---

### **exec**

See “attack” on page 72.

### **get**

```
get di
{
 disable_tcp_checksum |
 service
 {
 aim
 [
 max_flap_length |
 max_icmb_length |
 max_ofc_frame |
 max_tlv_length
] |
 dhcp
 [
 check_client_sport
] |
 dns
 [
 cache_size |
```

```

 cache_time |
 nxt_length |
 pointer_loop_limit |
 report_unexpected |
 report_unknowns |
 udp_message_limit
] |
ftp
[
 failed_logins |
 line_length |
 password_length |
 pathname_length |
 sitestring_length |
 username_length
] |
gnutella
[
 max_line_length |
 max_query_size |
 max_ttl_hops
] |
gopher
[
 host_length |
 line_length
] |
http
[
 alternate_ports |
 auth_length |
 brute_search |
 content_type_length |
 cookie_length |
 download_content_len number
 download_skip
 failed_logins |
 header_length |
 host_length |
 max_content_length number
 referer_length |
 request_length |
 user_agent_length
] |
icmp
[
 flood_packets |
 flood_time
] |
ident
[
 max_requests |
 reply_length |
 request_length
] |
ike
[

```

```

 max_payloads
] |
imap
 [
 failed_logins |
 flag_length |
 line_length |
 literal_length |
 mbox_length |
 pass_length |
 ref_length |
 user_length
] |
irc
 [
 channel_length |
 nickname_length |
 password_length |
 username_length
] |
ldap
 [
 attributedesc_length |
 dn_max_length |
 enc_length_left_zeros |
 failed_logins |
 integer_max_bytes |
 max_mesg_size |
 mesgid_max |
 search_filter_levels |
 search_sizelimit |
 search_timelimit |
 tag_left_zeros |
 tag_max_value
] |
lpr
 [
 banner_length |
 cfile_length |
 cfilename_length |
 cmd_length |
 dfile_length |
 dfilename_length |
 file_format_length |
 font_length |
 mail_length |
 reply_length |
 symlink_length
] |
msn
 [
 max_display_name |
 max_group_name |
 max_ip_port |
 max_phone_number |
 max_url |
 max_user_name |

```

```

 max_user_state
] |
msrpc
 [
 epm_max_num_entries |
 epm_max_tower_len |
 max_frag_len |
] |
nbname
 [
 pointer_loop_limit |
] |
nfs
 [
 max_buffer_length |
 max_name_length |
 max_path_length
] |
ntp
 [
 ctl_auth_len |
 dmsg_ver3_max_len |
 dmsg_ver4_max_len |
 match_ts |
 max_clkage |
 max_data_store |
 max_stratum |
 min_poll |
 pasv_dissolve_tm |
 varname_len |
 varvalue_len |
] |
pop3
 [
 apop_length |
 failed_logins |
 line_length |
 max_msg_num |
 pass_length |
 user_length
] |
radius
 [
 failed_auth
] |
smb
 [
 failed_logins |
 regkey_length |
] |
smtp
 [
 check_headers_in_body |
 cmdline_length |
 content_filename_length |
 content_name_length |
 domain_length |

```

```

 multipart_depth |
 num_rcpt |
 parse_cnt_length |
 path_length |
 replyline_length |
 textline_length |
 user_length
] |
 syslog
 [
 validate_timestamp
] |
 telnet
 [
 failed_logins
] |
 tftp
 [
 filename_length
] |
 vnc
 [
 failed_logins |
 max_cutttext_length |
 max_name_length |
 max_reason_length |
 verify_message
] |
 whois
 [
 request_length
] |
 ymsg
 [
 max_activity |
 max_buddy_list |
 max_challenge |
 max_chatroom_msg |
 max_chatroom_name |
 max_conf_msg |
 max_conference_name |
 max_cookie_length |
 max_crypt |
 max_file_name |
 max_group_name |
 max_mail_address |
 max_mail_subject |
 max_message_size |
 max_url_name |
 max_user_name |
 max_webcam_key |
 max_yahoo_message
]
}
}

```

**set**

```

set di
{
 disable_tcp_checksum |
 service
 {
 aim
 {
 max_flap_length number |
 max_icmb_length number |
 max_ofc_frame number |
 max_tlv_length number
 } |
 dhcp
 {
 check_client_sport number
 } |
 dns
 {
 cache_size number |
 cache_time number |
 nxt_length number |
 pointer_loop_limit number |
 report_unexpected number |
 report_unknowns number |
 udp_message_limit number
 } |
 ftp
 {
 failed_logins number |
 line_length number |
 password_length number |
 pathname_length number |
 sitestring_length number |
 username_length number
 } |
 gnutella
 {
 max_line_length number |
 max_query_size number |
 max_ttl_hops number
 } |
 gopher
 {
 host_length number |
 line_length number
 } |
 http
 {
 alternate_ports number |
 auth_length number |
 brute_search number |
 content_type_length number |
 cookie_length number |
 download_content_len number |
 download_skip

```

```

failed_logins |
header_length |
host_length |
max_content_length number |
referer_length number |
request_length number |
user_agent_length number
}|
icmp
{
flood_packets number |
flood_time number
}|
ident
{
max_requests number |
reply_length number |
request_length number
}|
ike
{
max_payloads number
}|
imap
{
failed_logins number |
flag_length number |
line_length number |
literal_length number |
mbox_length number |
pass_length number |
ref_length number |
user_length number
}|
irc
{
channel_length number |
nickname_length number |
password_length number |
username_length number
}|
ldap
{
attributedesc_length number |
dn_max_length number |
enc_length_left_zeros number |
failed_logins number |
integer_max_bytes number |
max_mesg_size number |
mesgid_max number |
search_filter_levels number |
search_sizelimit number |
search_timelimit number |
tag_left_zeros number |
tag_max_value number
}|
lpr

```

```

{
 banner_length number |
 cfile_length number |
 cfilename_length number |
 cmd_length number |
 dfile_length number |
 dfilename_length number |
 file_format_length number |
 font_length number |
 mail_length number |
 reply_length number |
 symlink_length number
}|
msn
{
 max_display_name number |
 max_group_name number |
 max_ip_port number |
 max_phone_number number |
 max_url number |
 max_user_name number |
 max_user_state number
}|
msrpc
{
 epm_max_num_entries number |
 epm_max_tower_len number |
 max_frag_len number |
}|
nbname
{
 pointer_loop_limit number |
}|
nfs
{
 max_buffer_length number |
 max_name_length number |
 max_path_length number
}|
ntp
{
 ctl_auth_len number |
 dmsg_ver3_max_len number |
 dmsg_ver4_max_len number |
 match_ts number |
 max_clkage number |
 max_data_store number |
 max_stratum number |
 min_poll number |
 pasv_dissolve_tm number |
 varname_len number |
 varvalue_len number |
}|
pop3
{
 apop_length number |
 failed_logins number |

```

```

 line_length number |
 max_msg_num number |
 pass_length number |
 user_length number
 } |
radius
{
 failed_auth
} |
smb
{
 failed_logins number |
 regkey_length number
} |
smtp
{
 check_headers_in_body number |
 cmdline_length number |
 content_filename_length number |
 content_name_length number |
 domain_length number |
 multipart_depth number |
 num_rcpt number |
 parse_cnt_length number |
 path_length number |
 replyline_length number |
 textline_length number |
 user_length number
}
syslog
{
 validate_timestamp number
} |
telnet
{
 failed_logins number
} |
tftp
{
 filename_length number
} |
vnc
{
 failed_logins number |
 max_cutttext_length number |
 max_name_length number |
 max_reason_length number |
 verify_message number
} |
whois
{
 request_length number
} |
ymsg
{
 max_activity number |
 max_buddy_list number |

```

```

max_challenge number |
max_chatroom_msg number |
max_chatroom_name number |
max_conf_msg number |
max_conference_name number |
max_cookie_length number |
max_crypt number |
max_file_name number |
max_group_name number |
max_mail_address number |
max_mail_subject number |
max_message_size number |
max_url_name number |
max_user_name number |
max_webcam_key number |
max_yahoo_message number
}
}
}

```

## Keywords and Variables

---

### ***disable\_tcp\_checksum***

```

get disable_tcp_checksum
set disable_tcp_checksum
unset disable_tcp_checksum

```

**disable\_tcp\_checksum** Disables the TCP-checksum operation. The security device uses TCP checksums in exchanged packets to detect TCP transmission errors. Because the checksum operation uses up processor resources, it may be useful to disable it. The security device performs the checksum operation by default.

**Example 1:** The following command disables the checksum operation:

```
set di disable_tcp_checksum
```

**Example 2:** The following command enables the checksum operation:

```
unset di disable_tcp_checksum
```

## aim

```
get di service aim { ... }
set di service aim { ... }
unset di service aim { ... }
```

**aim** Determines how the security device evaluates America Online Instant Messaging (AIM) traffic. AIM makes use of the Open System for Communication in Real Time (OSCAR) protocol, which in turn uses FDDITalk Link Access Protocol (FLAP) for packet structuring.

- **max\_flap\_length** *number*—Specifies the maximum number of bytes in a FLAP packet—6-byte header + data.

Valid range: 6–10,000 bytes; default: 10,000 bytes.

- **max\_icmb\_length** *number*—Specifies the maximum number of bytes in an inter-client-message block (ICMB). When an instant message is transmitted, the FLAP protocol breaks it into multiple ICMBs and sends each block in a separate Type, Length, and Value (TLV).

Valid range: 0–10,000 bytes; default: 2000 bytes.

- **max\_ofst\_frame** *number*—Specifies the maximum number of bytes in an OSCAR file transfer (OFT) frame.

Valid range: 0–10,000 bytes; default: 10,000 bytes.

- **max\_tlv\_length** *number*—Specifies the length of a TLV unit. A TLV unit consists of a 2-byte type code + a 2-byte value for Length + the actual data in the Value field. TLVs often appear in the FLAP data field.

Valid range: 0–100,000; default: 8000.

## dhcp

```
get di service dhcp { check_client_sport }
set di service dhcp { check_client_sport }
unset di service dhcp { check_client_sport }
```

**dhcp** **check-client-sport { 0 | 1 }** allows you to set the device to verify that the client's source port is 68. This feature is disabled by default (0). Set the value to 1 to enable this option.

## dns

```
get di service dns { ... }
set di service dns { ... }
unset di service dns { ... }
```

**dns** Determines how the security device evaluates Domain Name System (DNS) traffic and how it caches DNS queries.

- **cache\_size** *number* The maximum size, in bytes, of the DNS cache on the security device.

Valid range: 0–1,000,000 ; default: 100.

- **cache\_time** *number* The maximum number of seconds that the security device stores a query in its cache.

Valid range: 0–3600; default: 60.

- **nxt\_length** *number* The maximum number of bytes in a nonexistent resource record (NXT RR) in a DNS response message.

Valid range: 1024–8192; default: 4096.

- **pointer\_loop\_limit** *number* The valid range is 0 through 24; the default is 8.
- **report\_unexpected** { 0 | 1 }—Enables or disables the reporting of unexpected DNS parameters. A value of 0 disables such reporting, and 1 enables it. The following are examples of unexpected DNS parameters:
  - The TYPE value is equal to or greater than 252. Values equal to and greater than 252 are reserved for QTYPE fields. (See RFC 1035, *Domain Names—Implementation and Specification*.)
  - The RR TYPE code is 249, but the CLASS code is not 255 (any class). TYPE 249 is for the Transaction Key (TKEY) RR. The TKEY RR provides a mechanism with which a DNS server and resolver can establish shared secret keys to authenticate the DNS queries and responses passing between them. (See RFC 2930, *Secret Key Establishment for DNS (TKEY RR)*.)

By default, the reporting of unexpected DNS parameters is disabled.

- **report\_unknowns** { 0 | 1 }—Enables or disables the reporting of any unknown DNS TYPE and CLASS parameter. A value of 0 disables such reporting, and 1 enables it. An unknown DNS TYPE or CLASS is anything not defined in one of the following DNS-related RFCs: 1035, 1183, 2535, 1712, 1876, 1886, 1995, 2053, 2065, 2538, 2671, 2672, and 2930. By default, the reporting of unknown DNS parameters is disabled.
- **udp\_message\_limit** *number*—Specifies the maximum number of bytes in a UDP message sent during a DNS exchange.  
Valid range: 512–4096; default: 512.

## ftp

```
get di service ftp { ... }
set di service ftp { ... }
unset di service ftp { ... }
```

### ftp

Determines how the security device evaluates File Transfer Protocol (FTP) traffic. The security device compares actual FTP traffic with maximum settings of what you consider to be normal FTP traffic. The security device considers any traffic exceeding such settings to be anomalous.

- **failed\_logins** *number*—Specifies the maximum number of failed login attempts per minute to an FTP server from a single host.  
Valid range: 2–100; default: 8.
- **line\_length** *number*—Specifies the maximum number of bytes in an FTP command line.  
Valid range: 1–8192; default: 1024.
- **password\_length** *number*—Specifies the maximum number of bytes for an FTP password.  
Valid range: 1–8192; default: 64.
- **pathname\_length** *number*—Specifies the maximum number of bytes in an FTP path name.  
Valid range: 1–8192; default: 512.
- **sitestring\_length** *number*—Specifies the maximum number of bytes in an FTP site string.  
Valid range: 1–8192; default: 512.

**username\_length** *number*—Specifies the maximum number of bytes in an FTP username.  
Valid range: 1–8192; default: 32.

## **gnutella**

```
get di service gnutella { ... }
set di service gnutella { ... }
unset di service gnutella { ... }
```

**gnutella** Determines how the security device evaluates Gnutella traffic. Gnutella is a peer-to-peer (P2P) file-sharing protocol and application that does not make use of centralized servers.

- **max\_line\_length** *number*—Specifies the maximum number of bytes in a Gnutella command line.  
Valid range: 1–4096; default: 2048.
- **max\_query\_size** *number*—Specifies the maximum number of bytes in a query sent between two Gnutella peers.  
Valid range: 256–4096; default: 256.
- **max\_ttl\_hops** *number*—Specifies the maximum number of network forwarding devices (hops) already passed plus the remaining Time to Live (TTL) value indicated in the Gnutella header.  
Valid range: 1–10; default: 8.

## **gopher**

```
get di service gopher [...]
set di service gopher { ... }
unset di service gopher { ... }
```

**gopher**

- **host\_length**—Specifies the maximum length of the hostname.  
Valid range: 1–128; default: 64.
- **line\_length**—Specifies the maximum number of lines.  
Valid range: 1–2048. default: 512.

## http

```
get di service http { ... }
set di service http { ... }
unset di service http { ... }
```

**http** Determines how the security device evaluates Hypertext Transfer Protocol (HTTP) traffic. The security device compares actual HTTP traffic with maximum settings of what you consider to be normal HTTP traffic. The security device considers any traffic exceeding such settings to be anomalous.

- **alternate\_ports { 0 | 1 }**—Enables or disables the inspection of HTTP traffic on the default HTTP port of 80 and on the following ports: 7001, 8000, 8001, 8100, 8200, 8080, 8888, and 9080. A value of 0 disables HTTP traffic inspection on these alternative ports, and 1 enables it. By default, this option is enabled.
- **auth\_length *number***—Specifies the maximum number of bytes in an HTTP header-authorization line.  
Valid range: 1–1024; default: 512.
- **brute\_search *number***—Specifies the maximum number of HTTP errors per minute. If the security device detects more HTTP 301 (Moved Permanently), 403 (Forbidden), 404 (Not Found), and 405 (Method Not Allowed) errors than the specified maximum, the device considers it an anomalous event.  
Valid range: 2–100; default: 16.
- **content\_type\_length *number***—Specifies the maximum number of bytes for an HTTP header Content Type field, which specifies the media type of the data contained in the HTTP packet.  
Valid range: 1–8192; default: 512.
- **cookie\_length *number***—Specifies the maximum number of bytes in a cookie.  
Valid range: 1–8192; default: 8192.  
Cookies that exceed the cookie-length setting can match the protocol anomaly HTTP-HEADER-OVERFLOW and produce unnecessary log records. If the security device generates too many log records for this anomaly, increase the cookie-length setting.
- **download\_content\_len *number***—Specifies the maximum number of bytes of HTTP downloads.  
Valid range: 0–2GB; default: 2GB.
- **download-skip** Skips checking HTTP downloads for attacks. This is the default. Use the **unset** command to always check HTTP downloads for attacks.
- **failed\_logins *number***—Specifies the maximum number of failed login attempts per minute to an HTTP server from a single host.  
Valid range: 2–100; default: 8.
- **header\_length *number***—Specifies the maximum number of bytes for an HTTP packet header.  
Valid range: 1–8192; default: 8192.
- **host\_length *number***—Specifies the maximum number of bytes for an HTTP header host, which can be an Internet domain name or an IP address.  
Valid range: 1–8192; default: 64.

- **max\_content\_length** *number*—Specifies the maximum number of bytes of text or HTML content that is downloaded.

Valid range: 0–2GB; default: less than 2GB.

- **referer\_length** *number*—Specifies the maximum number of bytes for a header-referer field, which the client uses to specify the address Uniform Resource Identifier (URI), which is a formatted string that identifies a network resource by a characteristic such as a name or a location.

Valid range: 1–8192; default: 8192

- **request\_length** *number*—Specifies the maximum number of bytes for an HTTP request, which includes information such as a network-resource identifier, the method to apply to the resource, and the protocol version.

Valid range: 1–8192; default: 8192

**user\_agent\_length** *number*—Specifies the maximum number of bytes for an HTTP header user-agent field, which contains information about the user agent that originated the request.

Valid range: 1–8192; default: 256

## icmp

```
get di service icmp [...]
set di service icmp { ... }
unset di service icmp { ... }
```

icmp

- **flood\_packets** *number*—Specifies the maximum number of packets per second to trigger a flood. Valid range: 1 through 65535; default: 250.

- **flood\_time** *number*—Specifies the minimum number of seconds between packets. Valid range: 1 through 65535; default: 1.

## ident

```
get di service ident [...]
set di service ident { ... }
unset di service ident { ... }
```

ident

- **max\_requests** *number*—Specifies the maximum number of requests per session. Valid range: 1 through 65535; default: 1.

- **reply\_length** *number*—Specifies the maximum length of a reply. Valid range: 1 through 8192; default: 128.

- **request\_length** *number*—Specifies the maximum length of a request length. Valid range: 1 through 8192; default: 15.

## ike

```
get di service ike [...]
set di service ike max_payloads
unset di service ike max_payloads
```

ike

**max\_payloads** *number* Valid range: 1 through 256; default: 57.

**imap**

```
get di service imap { ... }
set di service imap { ... }
unset di service imap { ... }
```

|      |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| imap | <p>Determines how the security device evaluates Internet Message Access Protocol (IMAP) traffic. The security device compares actual IMAP traffic with maximum settings of what you consider to be normal IMAP traffic. The security device considers any traffic exceeding such settings to be anomalous.</p> <ul style="list-style-type: none"> <li> <p>■ <b>failed_logins</b> <i>number</i>—Specifies the maximum number of failed login attempts per minute to an IMAP server from a single host.</p> <p>Valid range: 2–100; default: 8.</p> </li> <li> <p>■ <b>flag_length</b> <i>number</i>—Specifies the maximum number of bytes for an IMAP flag.</p> <p>Valid range: 1–8192; default: 64.</p> </li> <li> <p>■ <b>line_length</b> <i>number</i>—Specifies the maximum number of bytes for an IMAP line.</p> <p>Valid range: 1–8192; default: 2048.</p> </li> <li> <p>■ <b>literal_length</b> <i>number</i>—Specifies the maximum number of octets in a literal string. In IMAP4, a string can be in one of two forms: literal or quoted. As defined in RFC 2060, <i>Internet Message Access Protocol—Version 4rev1</i>:</p> <p>A literal is a sequence of zero or more octets (including CR and LF), prefix-quoted with an octet count in the form of an open brace ("{"), the number of octets, close brace ("}"), and CRLF.</p> <p>Valid range: 1–16,777,215; default: 65,535.</p> </li> <li> <p>■ <b>mbx_length</b> <i>number</i>—Specifies the maximum number of bytes for an IMAP mailbox.</p> <p>Valid range: 1–8192; default: 64.</p> </li> <li> <p>■ <b>pass_length</b> <i>number</i>—Specifies the maximum number of bytes for an IMAP password.</p> <p>Valid range: 1–8192; default: 64.</p> </li> <li> <p>■ <b>ref_length</b> <i>number</i>—Specifies the maximum number of bytes for an IMAP reference.</p> <p>Valid range: 1–8192; default: 64.</p> </li> <li> <p>■ <b>user_length</b> <i>number</i>—Specifies the maximum number of bytes for an IMAP username.</p> <p>Valid range: 1–8192; default: 64.</p> </li> </ul> |
|------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

## irc

```
get di service irc [...]
set di service irc { ... }
unset di service irc { ... }
```

- irc
- **channel\_length** *number*—Specifies the maximum channel length. Valid range: 1 through 512; default: 64.
  - **nickname\_length** *number*—Specifies the maximum length for a nickname. Valid range: 1 through 512; default: 16.
  - **password\_length** *number*—Specifies the maximum length for a password. Valid range: 1 through 512; default: 16.
  - **username\_length** *number*—Specifies the maximum length for a username. Valid range: 1 through 512; default: 16.

## ldap

```
get di service ldap [...]
set di service ldap { ... }
unset di service ldap { ... }
```

- ldap
- **attributedesc\_length** *number*—Specifies the maximum length of the attribute descriptor. Valid range: 0 through 4096; default: 512.
  - **dn\_max\_length** *number*—Specifies the maximum length for an LDAP distinguished name. Valid range: 0 through 4096; default: 512.
  - **enc\_length\_left\_zeros** *number*—Specifies the number of left zeros for the length of the BER. Valid range: 0 through 1024; default: 64.
  - **failed\_logins** *number*—Specifies the maximum number of failed logins per minute. Valid range: 2 through 100; default: 8.
  - **integer\_max\_bytes** *number*—Specifies the maximum length of integer representation in BER. Valid range: 0 through 1024; default: 4.
  - **max\_mesg\_size** *number*—Specifies the maximum size of an LDAP message. Valid range: 0 through 8192; default: 8100.
  - **mesgid\_max** *number*—Specifies the maximum size of an LDAP message ID. Valid range: 0 through 2,147,483,647; default: 2,147,483,647.
  - **search\_filter\_levels** *number*—Specifies the maximum number of nested operators in a search request. Valid range: 1 through 100; default: 8.
  - **search\_sizelimit** *number*—Specifies the maximum number of search results requested. Valid range: 0 through 2,147,483,647; default: 0.
  - **search\_timelimit** *number*—Specifies the maximum amount of time to search results requested. Valid range: 0 through 600,000; default: 0.
  - **tag\_left\_zeros** *number*—Specifies the number of left zeros for a tag in the BER. Valid range: 0 through 1024; default: 4.
  - **tag\_max\_value** *number*—Specifies the maximum value for any LDAP tag in the BER. Valid range: 0 through 31; default: 31.

## *lpr*

```
get di service lpr [...]
set di service lpr { ... }
unset di service lpr { ... }
```

- lpr*
- **banner\_length** *number*—Specifies the maximum length of the banner.  
Valid range: 1 through 1024; default: 32.
  - **cfile\_length** *number*—Specifies the maximum value of the control file size.  
Valid range: 1 through 4,294,967,295; default: 1024.
  - **cfilename\_length** *number*—Specifies the maximum length of the control filename.  
Valid range: 1 through 1024; default: 64.
  - **cmd\_length** *number*—Specifies the maximum subcommand length of the RECEIVE-JOB command.  
Valid range: 1 through 8192; default: 256.
  - **dfile\_length** *number*—Specifies the maximum data-file size.  
Valid range: 1 through 4,294,967,295; default: 65535.
  - **dfilename\_length** *number*—Specifies the maximum length of a data filename.  
Valid range: 1 through 1024; default: 64.
  - **file\_format\_length** *number*—Specifies the maximum filename length of format-related subcommands.  
Valid range: 1 through 1024; default: 32.
  - **font\_length** *number*—Specifies the maximum font length.  
Valid range: 1 through 1024; default: 64.
  - **mail\_length** *number*—Specifies the maximum size of an email message.  
Valid range: 1 through 1024; default: 32.
  - **reply\_length** *number*—Specifies the maximum length of a reply from the server.  
Valid range: 1 through 8192; default: 256.
  - **symlink\_length** *number*—Specifies the maximum symbolic length.  
Valid range: 1 through 1024; default: 1024.

## *msn*

```
get di service msn { ... }
set di service msn { ... }
unset di service msn { ... }
```

- msn*
- Determines how the security device evaluates Microsoft Network Instant Messaging (MSN IM) traffic. The security device compares actual MSN traffic with maximum settings of what you consider to be normal MSN traffic. The security device considers any traffic exceeding such settings to be anomalous.
- **max\_display\_name** *number*—Specifies the maximum number of bytes in an MSN display name, which is the name that you use to identify yourself to other MSN principals. A display name is also known as a *friendly name*, *custom name* or *custom username*.  
Valid range: 1–1024; default: 128.

- **max\_group\_name number**—Specifies the maximum number of bytes for an MSN group. Every group has a name and an ID number, and every principal belongs to at least one group: the default group named “~ ” (tilde) with ID 0.

Valid range: 1–1024; default: 84.
- **max\_ip\_port number**—Specifies the maximum number of bytes for the IP address:port number of an MSN server (notification or switchboard server) for a switchboard session.

Valid range: 30–40; default: 30.

All MSN notification and switchboard servers use port 1863.
- **max\_phone\_number number**—Specifies the maximum number of bytes for a telephone number in an MSN Forward List (FL). The FL is essentially a contact list of other MSN principals.

Valid range: 20–50; default: 20.
- **max\_url number**—Specifies the maximum number of bytes for a URL address in an MSN message.

Valid range: 1–2000; default: 1024.
- **max\_user\_name number**—Specifies the maximum number of bytes in any MSN user’s name.

Valid range: 1–1024; default: 84.
- **max\_user\_state number**—Specifies the maximum number of bytes in an MSN user state, which is a 3-letter code that indicates the status of a user’s connection. Some examples: NLN (online), FLN (offline), HDN (hidden/invisible). Other states are substates of NLN, including BSY (Busy), IDL (Idle), and BRB (Be Right Back).

Valid range: 3–15; default: 3.

## msrpc

```
get di service msrpc { ... }
set di service msrpc { ... }
unset di service msrpc { ... }
```

- msrpc
- Determines how the security device evaluates Microsoft Remote Procedure Call (MSRPC) traffic. The security device compares actual MSRPC traffic with maximum settings of what you consider to be normal MSRPC traffic. The security device considers any traffic exceeding such settings to be anomalous.
- **epm\_max\_num\_entries number**—Specifies the maximum number of entries in an MSRPC endpoint mapper (EPM) message.

Valid range: 100–8192; default: 100.
  - **epm\_max\_tower\_len number**—Specifies the maximum number of bytes in a protocol-tower representation in an MSRPC EPM message. A protocol tower consists of an interface identifier and binding information between a client and server that permits the client to make a remote procedure call to the server.

Valid range: 8192–268,435,456; default: 8192.
  - **max\_frag\_len number**—Specifies the maximum length, in bytes, of an MSRPC fragment.

Valid range: 4096–65,535; default: 8192.

**nbrname**

```
get di service nbrname { ... }
set di service nbrname { ... }
unset di service nbrname { ... }
```

**nbrname** Determines how the security device evaluates NetBIOS name (**nbrname**) traffic. The security device compares actual **nbrname** traffic with maximum settings of what you consider to be normal **nbrname** traffic. The security device considers any traffic exceeding such settings to be anomalous.

- **pointer\_loop\_limit** *number*—Specifies the maximum number of pointer-loop levels for NetBIOS names.  
Valid range: 0–24; default: 8.

**nfs**

```
get di service nfs [...]
set di service nfs { ... }
unset di service nfs { ... }
```

**nfs**

- **max\_buffer\_length** *number*—Specifies the maximum buffer size for read/write requests.  
Valid range: 1 through 65536; default: 32768.
- **max\_name\_length** *number*—Specifies the maximum length for the name.  
Valid range: 1 through 4096; default; 256.
- **max\_path\_length** *number*—Specifies the maximum value for the path length.  
Valid range: 1 through 4096; default: 1024.

**ntp**

```
get di service ntp [...]
set di service ntp { ... }
unset di service ntp { ... }
```

|            |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
|------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>ntp</b> | <p>Determines how the security device evaluates Network Time Protocol (NTP) traffic.</p> <ul style="list-style-type: none"> <li>■ <b>ctl_auth_len</b> <i>number</i>—Specifies the maximum size of the authentication-field length in the control message.<br/>Valid range: 0 through 24; default: 20.</li> <li>■ <b>dmsg_ver3_max_len</b> <i>number</i>—Specifies the maximum length of an NTP version 3 message.<br/>Valid range: 0 through 72; default: 68.</li> <li>■ <b>dmsg_ver4_max_len</b> <i>number</i>—Specifies the maximum length of an NTP version 4 message.<br/>Valid range: 0 through 72; default: 68.</li> <li>■ <b>match_ts</b> { <b>0</b>   <b>1</b> }—Enables (1) or disables (0) the feature that matches the timestamps of NTP requests and responses. Default: 1.</li> <li>■ <b>max_clkage</b> <i>number</i>—Specifies the maximum time since the last update of the reference clock.<br/>Valid range: 0 through 86400; default: 86400.</li> <li>■ <b>max_data_store</b> <i>number</i>—Specifies the maximum buffer length to store between control packets.<br/>Valid range: 0 through 255; default: 255.</li> <li>■ <b>max_stratum</b> <i>number</i>—Specifies the maximum stratum value for any NTP peer. Valid range: 0 through 15; default: 15.</li> <li>■ <b>min_poll</b> <i>number</i>—Specifies the minimum number of seconds between two requests.<br/>Valid range: 0 through 1024; default: 0.</li> <li>■ <b>pasv_dissolve_tm</b> <i>number</i>—Specifies the maximum time for a symmetric passive association to dissolve.<br/>Valid range: 0 through 3600; default: 900.</li> <li>■ <b>varname_len</b> <i>number</i>—Specifies the maximum length of any NTP control variable.<br/>Valid range: 0 through 255; default: 128.</li> <li>■ <b>varvalue_len</b> <i>number</i>—Specifies the maximum length of any NTP variable.<br/>Valid range: 0 through 255; default: 255.</li> </ul> |
|------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

## pop3

```
get di service pop3 { ... }
set di service pop3 { ... }
unset di service pop3 { ... }
```

|      |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| pop3 | <p>Determines how the security device evaluates Post Office Protocol version 3 (POP3) traffic. The security device compares actual POP3 traffic with maximum settings of what you consider to be normal POP3 traffic. The security device considers any traffic exceeding such settings to be anomalous.</p> <ul style="list-style-type: none"> <li>■ <b>apop_length</b> <i>number</i>—Specifies the maximum number of bytes for an Authenticated Post Office Protocol (APOP) command, which a POP3 user issues when authenticating himself to a POP3 mailserver.<br/>Valid range: 1–8192; default: 100.</li> <li>■ <b>failed_logins</b> <i>number</i>—Specifies the maximum number of failed login attempts per minute to a POP3 server from a single host.<br/>Valid range: 2–100; default: 4.</li> <li>■ <b>line_length</b> <i>number</i>—Specifies the maximum number of bytes for any POP3 line.<br/>Valid range: 1–8192; default: 512.</li> <li>■ <b>max_msg_num</b> <i>number</i>—Specifies the maximum number of messages in a single mailbox on a POP3 server.<br/>Valid range: 100–10,000,000; default: 10,000,000.</li> <li>■ <b>pass_length</b> <i>number</i>—Specifies the maximum number of bytes in a POP3 password.<br/>Valid range: 1–8192; default: 64.</li> <li>■ <b>user_length</b> <i>number</i>—Specifies the maximum number of bytes in a POP3 username.<br/>Valid range: 1–8192; default: 64.</li> </ul> |
|------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

## radius

```
get di service radius [...]
set di service radius { ... }
unset di service radius { ... }
```

|        |                                                                                                                                                                                                                                  |
|--------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| radius | <ul style="list-style-type: none"> <li>■ <b>failed_auth</b> <i>number</i>—Specifies the maximum number of failed login attempts per minute to a RADIUS server from a single host.<br/>Valid range: 2–100; default: 8.</li> </ul> |
|--------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

**smb**

```
get di service smb { ... }
set di service smb { ... }
unset di service smb { ... }
```

- smb** Determines how the security device evaluates Server Message Block (SMB) traffic. The security device compares actual SMB traffic with maximum settings of what you consider to be normal SMB traffic. The security device considers any traffic exceeding such settings to be anomalous.
- **failed\_logins** *number*—Specifies the maximum number of failed login attempts per minute to an SMB server from a single host.  
Valid range: 2–100; default: 8.
  - **regkey\_length** *number*—Specifies the maximum number of bytes in an SMB registry key.  
Valid range: 32–64,535; default: 8192.

**smtp**

```
get di service smtp { ... }
set di service smtp { ... }
unset di service smtp { ... }
```

- smtp** Uses the Simple Mail Transfer Protocol (SMTP) threshold parameters to control how the security device handles SMTP packets. The threshold parameters define the boundaries of normal SMTP traffic. Traffic that exceeds these boundaries is considered abnormal and might contain protocol anomalies.
- **check\_headers\_in\_body** { **0** | **1** }—Enables or disables the inspection of SMTP traffic for email headers in the body of an email message, which can occur when a bounced message contains an attachment.  
A value of 0 disables checking for SMTP headers in the body of an email message, and 1 enables it. By default, this option is disabled.
  - **cmdline\_length** *number*—Specifies the maximum number of bytes in any command line sent from an SMTP client within an SMTP message envelope.  
Valid range: 1–8192; default: 1024.
  - **content\_filename\_length** *number*—Specifies the maximum number of bytes for the name of a file in a content-disposition filename parameter in an SMTP header. For information about the content-disposition header field, see RFC 2183, *Communicating Presentation Information in Internet Messages: The Content-Disposition Header Field*.  
Valid range: 1–1024; default: 128.
  - **content\_name\_length** *number*—Specifies the maximum number of bytes in the content-type name attribute in an SMTP header. Two examples of content-type names are *text/plain; name= "CLI.pdf"* and *application/zip; name= "nsremote.zip"*. For information about various content types, see RFC 2046, *Multipurpose Internet Mail Extensions (MIME) Part Two: Media Types*.  
Valid range: 1–1024; default: 128.

- **domain\_length number**—Specifies the maximum number of bytes in the domain-name component of the forward-path field in an RCPT command or reverse-path field in a MAIL command in an SMTP message envelope. The forward-path field indicates the destination mailbox. The reverse-path field indicates the sender’s mailbox. The mailbox name consists of two parts: `usr_name@domain_name`

Valid range: 1–8192; default: 64.
- **multipart\_depth number**—Specifies the number of nested elements in a multipart content type. For an example, see “Appendix A—A Complex Multipart Example” in RFC 2049, *Multipurpose Internet Mail Extensions (MIME) Part Five: Conformance Criteria and Examples*.

Valid range: 1–16; default: 4.
- **num\_rcpt number**—Specifies the maximum number of recipients for an SMTP message.

Valid range: 1–1000; default: 100.
- **parse\_cnt\_length number**—Specifies the maximum number of bytes of encoded MIME data that the security device must decode.

Valid range: 1–8192; default: 128.
- **path\_length number**—Specifies the maximum number of bytes that can appear in the forward-path field in an RCPT command or in the reverse-path field in a MAIL command in an SMTP message envelope. The forward-path typically consists of the destination mailbox. The reverse-path typically consists of the sender’s mailbox.

Valid range: 1–8192; default: 256.
- **replyline\_length number**—Specifies the maximum number of bytes in a reply line sent from an SMTP server. The total length includes the three-digit reply code and the < CRLF> .

Valid range: 1–8192; default: 512.
- **textline\_length number**—Specifies the maximum number of bytes in a single SMTP text line, including the < CRLF> .

Valid range: 1–8192; default: 512.
- **user\_length number**—Specifies the maximum number of bytes in a username component of the forward-path field in an RCPT command or in the reverse-path field in a MAIL command in an SMTP message envelope. The forward-path field indicates the destination mailbox. The reverse-path field indicates the sender’s mailbox. The mailbox name consists of two parts: `usr_name@domain_name`

Valid range: 1–8192; default: 256.

## syslog

```
get di service syslog [...]
set di service syslog { ... }
unset di service syslog { ... }
```

```
syslog validate_timestamp { 0 | 1 }—Enables (1) or disables (0) the feature that validates RFC 3164, Compliant Timestamp, format.
```

## telnet

```
get di service telnet [...]
set di service telnet { ... }
unset di service telnet { ... }
```

telnet                    **failed\_logins** *number*—Specifies the maximum number of login failures per minute.  
Valid range: 2 through 100; default: 4.

## tftp

```
get di service tftp [...]
set di service tftp { ... }
unset di service tftp { ... }
```

tftp                    **filename\_length** *number*—Specifies the maximum length for the filename.  
Valid range: 1 through 8192; default: 128.

## vnc

```
get di service vnc [...]
set di service vnc { ... }
unset di service vnc { ... }
```

vnc

- **failed\_logins** *number*—Specifies the maximum number of failed logins per minute.  
Valid range: 2 through 100; default: 4.
- **max\_cutttext\_length** *number*—Specifies the maximum cut-text length.  
Valid range: 1 through 65,536; default: 4096.
- **max\_name\_length** *number*—Specifies the maximum length for the display name.  
Valid range: 1 through 1024; default: 128.
- **max\_reason\_length** *number*—Specifies the maximum string length for the reason.  
Valid range: 1 through 2048; default: 512.
- **verify\_message** { 0 | 1 }—Enables (1) or disables (0) the feature that checks the maximum length of the verify message after the initial handshake.

## whois

```
get di service whois [...]
set di service whois { ... }
unset di service whois { ... }
```

**whois**                    **request\_length** *number*—Specifies the maximum length of a request.  
Valid range: 1 through 1024; default: 128.

## ymsg

```
get di service ymsg { ... }
set di service ymsg { ... }
unset di service ymsg { ... }
```

**ymsg**                    Determines how the security device evaluates Yahoo! Messenger (YMSG) traffic. The security device compares actual YMSG traffic with maximum settings of what you consider to be normal YMSG traffic. The security device considers any traffic exceeding such settings to be anomalous.

- **max\_activity** *number*—Specifies the maximum number of bytes in the length of a data-type activity value. Data-type activities include PEERTOPEER, FILEXFER, and TYPING.  
Valid range: 1–20; default: 15.
- **max\_buddy\_list** *number*—Specifies the maximum length in bytes of the buddy list that a YMSG server sends.  
Valid range: 20–8000; default: 8000.
- **max\_challenge** *number*—Specifies the maximum length in bytes of the challenge string that a YMSG server sends during the authentication process.  
Valid range: 1–1024; default: 84.
- **max\_chatroom\_msg** *number*—Specifies the maximum length in bytes of a message sent in a chat room.  
Valid range: 1–8000; default: 2000.
- **max\_chatroom\_name** *number*—Specifies the maximum length in bytes of a YMSG chat-room name.  
Valid range: 1–8000; default: 1024.
- **max\_conf\_msg** *number*—Specifies the maximum number of bytes in a YMSG conference-join message.  
Valid range: 1–8000; default: 1024.
- **max\_conference\_name** *number*—Specifies the maximum length in bytes of a YMSG conference-session name.  
Valid range: 1–8000; default: 1024.
- **max\_cookie\_length** *number*—Specifies the maximum number of bytes in the cookie that a YMSG server sends to a client.  
Valid range: 1–1000; default: 400.
- **max\_crypt** *number*—Specifies the maximum number of bytes in the encrypted password sent during the YMSG authorization process.  
Valid range: 1–8000; default: 1024.

- **max\_file\_name** *number*—Specifies the maximum length in bytes of the name of a file that YMSG peers can transfer to each other.  
Valid range: 1–8000; default: 1000.
- **max\_group\_name** *number*—Specifies the maximum length in bytes for a name of a group of buddies.  
Valid range: 1–1024; default: 84.
- **max\_mail\_address** *number*—Specifies the maximum length in bytes of the address in an email message that a YMSG server sends as part of a new email alert.  
Valid range: 1–1024; default: 84.
- **max\_mail\_subject** *number*—Specifies the length in bytes of the subject line in an email message that a YMSG server sends as part of a new email alert.  
Valid range: 1–1024; default: 128.
- **max\_message\_size** *number*—Specifies the maximum length in bytes of a YMSG instant message.  
Valid range: 1–1024; default: 128.
- **max\_url\_name** *number*—Specifies the maximum length in bytes of a uniform resource locator (URL).  
Valid range: 1–8000; default: 1024.
- **max\_user\_name** *number*—Specifies the maximum length in bytes of a YMSG username.  
Valid range: 1–1024; default: 84.
- **max\_webcam\_key** *number*—Specifies the maximum number of bytes in the Webcam key that YMSG uses to support Webcam transmissions.  
Valid range: 1–1024; default: 124.
- **max\_yahoo\_message** *number*—Specifies the maximum total length in bytes of a YMSG instant message.  
Valid range: 200–8192; default: 8192.



# dip

Use the **dip** commands to set up a dynamic IP (DIP) group, display DIP group information, or assign the same IP address from a port-translating DIP pool to a host that originates multiple concurrent sessions (*sticky DIP*).

A DIP group contains one or more DIP pools, each consisting of a range of Internet Protocol (IP) addresses defined on a Layer 3 security zone interface, extended interface, or numbered tunnel interface. When multiple security devices are in a High Availability (HA) cluster, a policy requiring source-address translation and referencing a DIP pool defined on one virtual security interface (VSI) can result in dropped traffic. When that traffic arrives at a physical security device on which the DIP pool specified in the policy belongs to a VSI in an inactive virtual security device (VSD), the device drops the traffic because it cannot find the specified DIP pool to use for address translation. If, instead, the policy references a DIP group that contains DIP pools on different egress VSIs, the security device receiving the traffic can use the DIP pool belonging to the VSI for its active VSD.

---

**NOTE:** If the range of addresses in a DIP pool is in the same subnet as the interface IP address, the pool must exclude the interface IP address, router IP addresses, and any mapped IP or virtual IP addresses (MIPs and VIPs) that might also be in that subnet. If the range of addresses is in the subnet of an extended interface, the pool must exclude the extended interface IP address.

---

## Syntax

---

### **get**

```
get dip [all]
```

### **set**

```
set dip
{
 alarm-raise number1 [alarm-clear number2] |
 group { id_num1 [member id_num2] } |
 sticky
}
```

## Keywords and Variables

---

### **alarm-raise**

```
set dip alarm-raise number1 [alarm-clear number2]
unset alarm-raise
```

**alarm-raise** Sets a DIP utilization alarm threshold, expressed as a percentage of possible DIP utilization. When DIP utilization exceeds this threshold, the device triggers a SNMP trap. Because this threshold is zero by default, it is not enabled until you increase the setting to a nonzero value. (Possible values are 50 to 100, inclusive).

The **alarm-clear** setting specifies an optional threshold, also expressed as a percentage of possible DIP utilization. When DIP utilization falls below this threshold (and DIP utilization previously exceeded the **alarm-raise** threshold), the device triggers a SNMP alarm. The default value for this threshold is 10% below the configured **alarm-raise** threshold. (Possible configured values are 40 to 100, inclusive.)

The device logs these alarm events.

**Example:** The following command specifies upper and lower DIP utilization alarm thresholds. The device generates an SNMP alarm when either of the following conditions apply:

- DIP utilization exceeds 85 percent of capacity.
- DIP utilization falls below 45 percent of capacity.

```
set dip alarm-raise 85 alarm-clear 45
```

### **group**

```
set dip group id_num1 [member id_num2]
unset dip group id_num1 [member id_num2]
```

**group** Creates a DIP group or adds a DIP pool to a group. *id\_num1* is the identification number you assign to the new DIP group. **member** *id\_num2* specifies the identification number of a DIP pool.

**Example:** The following commands create DIP pools and a DIP group:

- DIP pool with ID 5 for interface ethernet3, which has IP address 1.1.1.1/24.
- DIP pool with ID 6 for interface ethernet3:1, which has IP address 1.1.1.2/24.
- DIP group with ID number 7. Both DIP pools added to the DIP group.

```
set interface ethernet3 dip 5 1.1.1.10 1.1.1.10
set interface ethernet3:1 dip 6 1.1.1.11 1.1.1.11
set dip group 7
set dip group 7 member 5
set dip group 7 member 6
```

### **sticky**

```
set dip sticky
unset dip sticky
```

**sticky** Specifies that the security device assigns the same IP address to a host for multiple concurrent sessions.

# dns

Use **dns** commands to configure Domain Name System (DNS) or to display DNS configuration information.

DNS allows network devices to identify each other using domain names instead of IP addresses. Support for DNS is provided by a DNS server, which keeps a table of domain names with associated IP addresses. For example, using DNS makes it possible to reference locations by domain name (such as `www.juniper.net`) in addition to using the routable IPv4 address in the format `123.123.123`.

DNS translation is supported in all the following applications:

- Address Book
- Syslog
- Email
- WebTrends
- Websense
- LDAP
- SecurID
- RADIUS
- NetScreen-Global PRO

Before you can use DNS for domain name/address resolution, you must enter the addresses for the primary and secondary DNS servers in the security device.

## Syntax

---

### **clear**

```
clear [cluster] dns
 [
 ddns [id id_num] |
 proxy |
 server-select [domain dom_name]
]
```

### **exec**

```
exec dns
 {
 ddns [id id_num] |
 refresh
 }
```

### **get**

```
get dns
 {
 ddns [id id_num] |
 host { cache | report | server-list | settings } |
 name dom_name |
 proxy |
 server-select
 }
```

### **set**

```
set dns
 {
 ddns
 [
 enable |
 id id_num
 {
 [server name_str] server-type { ddo | dyndns }
 [refresh-interval number]
 [minimum-update-interval number]
 [clear-text]
 src-interface interface [host-name name_str] [service { dyndns | statdns |
 custom }] |
 username name_str password pswd_str [agent name_str]
 }
] |
 host
 {
 dns1 ip_addr | dns2 ip_addr | dns3 ip_addr
 [src-interface interface] |
 name name_str ip_addr |
 schedule time [interval number]
 } |
 proxy [enable] |
```

```

server-select domain dom_name
[
 [outgoing-interface interface]
 failover |
 primary-server ip_addr
 [failover |
 secondary-server ip_addr
 [failover |
 tertiary-server ip_addr
 [failover]
]
]
]
}

```

## Keywords and Variables

---

### **cluster**

```
clear [cluster] dns
```

**cluster** Propagates the **clear** operation to all other devices in an NSRP cluster.

### **ddns**

```

get dns ddns [id id_num] [...]
set dns ddns enable
set dns ddns [id id_num] [...]
unset dns ddns

```

**ddns** Initiates or deletes the DDNS (Dynamic DNS) entry in the DDNS Entries table. Each entry represents a module that allocates all resources needed for DDNS. Deleting an entry frees the resources allocated for the module.

Dynamic DNS (DDNS) is a mechanism that allows clients to dynamically update IP addresses for registered domain names. This is useful when an ISP uses PPP, DHCP, or XAuth to dynamically change the IP address for a CPE router (such as a security device) that protects a Web server. Thus, any clients from the internet can access the Web server using a domain name, even if the IP address of the CPE router previously changed dynamically.

This is made possible by a DDNS server such as [dyndns.org](http://dyndns.org) or [ddo.jp](http://ddo.jp), which contains the dynamically changed addresses and their associated domain names. The CPE updates these DDNS servers with this information, periodically or in response to IP address changes.

- **enable**—Enables the DDNS module.

- **id** *id\_num*—Identifies a DDNS entry in the DDNS Entries table. If an entry already exists with this ID number, the **set dns ddns id** *id\_num* command updates the server information for that entry. If not, the command creates a new entry.
- **server** *name\_str* The fully qualified domain name (FQDN) of the DDNS server. The maximum length is 63 characters.
- **server-type** { **ddo** | **dyndns** } The type (DDO or DYNDNS) of DDNS server.
  - **clear-text**—Disables HTTPS. The default is to use HTTPS encryption, for both servers.
  - **refresh-interval** *number*—The time interval (expressed in hours) between refreshing of the DDNS entry. The default is 168 hours, and the allowable range is 1-8760 hours.
  - **minimum-update-interval** *number*—The minimum period (expressed in minutes) between updates. The default is 10 minutes, and the allowable range is 1-1440 minutes.
  - **src-interface** *interface* The interface through which the device communicates with the DDNS server. The optional **host-name** *name\_str* parameter identifies a hostname for the security device.  
**Note:** This value is necessary only if the DDNS server is of type DYNDNS, not DDO.
  - **service** { *dyndns* | *statdns* | *custom* }—Identifies the service type of a DDNS server. The service option can be *dyndns*, *statdns*, or *custom*. The default service type is *dyndns*.  
**Note:** This option is necessary only if the DDNS server is of type DYNDNS, not DDO.
- **username** *name\_str* **password** *pswd\_str* [ **agent** *name\_str* ]—Identifies the username and password for the DDNS account. The maximum length for each of these settings is 63 characters.
  - **agent** *name\_str*—Specifies the name of the agent. The default value is:  
*string1-string2-id\_num*, where:
    - *string1* the company name
    - *string2* the software version
    - *id\_num* the serial number
 The maximum length of the total agent string is 63 characters.

## host

```
get dns host { ... }
set dns host { ... }
unset dns host { ... }
```

host

- **cache**—Displays the DNS cache table.
- **dns1** *ip\_addr*—Specifies the primary DNS server.
- **dns2** *ip\_addr*—Specifies the backup DNS server.
- **src-interface** *interface*—Specifies an interface so that DNS requests packets, although initiated from within the system by the DNS module, are treated as if received externally from the source interface you set. When you specify a *src-interface*, DNS request packets, like all user data packets, trigger firewall policy lookup and are handled according to the rules of the policy. The source interface can be any interface that matches the zone.

- **name** The domain name of the host, listed in the DNS table.

Using the **name** option with **set** places an entry in the DNS table, representing a host device with a hostname and IP address. This allows you to reach the host from the security device using the hostname. For example, executing **set dns hostname acme 2.2.2.25** creates a DNS table entry for a host at address *2.2.2.25*, with a hostname of *acme*. This allows you to reach the host from the security device, as with the command **ping acme**.

**Note:** The DNS table is local to the security device, and functions only as a proxy for the actual DNS server. Consequently, other network nodes cannot query the listed names using the security device. The main purpose of the table is to let you create an alias for an external host and to access that host from the security device.

- **report**—Displays the DNS lookup table.
- **schedule** *time*—Specifies the time of day to refresh DNS entries. The format of this parameter is hh:mm. The interval number parameter specifies a 4-, 6-, 8-, or 12-hour interval between DNS table refresh operations. The default interval is 24 hours; that is, once a day at the scheduled DNS lookup time. Use this option to refresh the DNS table more frequently.
- **server-list**—Displays the IP addresses of hosts currently designated as DNS servers.
- **settings**—Displays DNS settings, including IP addresses, refresh setting, and the number of UDP sessions.

**Example 1:** The following command sets up a host as the primary DNS server at IP address **1.2.2.45**:

```
set dns host dns1 1.2.2.45
```

**Example 2:** The following command schedules a refresh time at **23:59** each day and a DNS table refresh interval of 12 hours:

```
set dns host schedule 23:59 interval 12
```

## proxy

```
get dns proxy
set dns proxy [enable]
unset dns proxy [enable]
```

**proxy** Initializes or deletes the DNS proxy. Initialization allocates all resources needed for the proxy. The **enable** switch enables or disables the DNS proxy itself.

The DNS proxy feature provides a transparent mechanism that allows clients to make split DNS queries. The proxy redirects the DNS queries selectively to specific DNS servers, according to partial or complete domain specifications. This is useful when VPN tunnels or PPPoE virtual links provide multiple network connectivity, and it is necessary to direct some DNS queries to one network and other queries to another network.

The most important advantages of a DNS proxy are as follows.

- Domain lookups are usually more efficient. For example, DNS queries meant for the corporate domain (such as marketing.acme.com) could go to the corporate DNS server, while all others go to the ISP DNS server, thus reducing the load on the corporate server.
- DNS proxy can prevent domain information from leaking into the internet, thus preventing malicious users from learning about internal network configuration.

## refresh

```
exec dns refresh
```

**refresh** Refreshes all DNS entries. Using the option directs the security device to perform a manual DNS lookup.

## server-select

```
clear [cluster] dns server-select domain dom_name
get dns server-select
set dns server-select domain dom_name [outgoing-interface interface { ... }]
```

**server-select** Identifies external DNS servers according to all or part of the fully qualified domain name (FQDN) contained in each DNS query. This process is called *proxy DNS*.

- **primary-server** *ip\_addr*
- **secondary-server** *ip\_addr*
- **tertiary-server** *ip\_addr*

The **failover** switch directs the DNS to fail over to another server if the currently active server fails.

Use the **set dns server-select** commands to create a partially filled or fully filled entry for a DNS proxy domain lookup. Such entries allow the security device to selectively direct DNS queries to different DNS servers. For example, you can direct all DNS queries with FQDNs containing a particular domain name to a corporate server, and direct all other DNS queries to an ISP server. To denote these other, unspecified queries, use the asterisk symbol (see example below).

The optional **outgoing-interface** parameter specifies the interface through which the security device transmits the DNS query.

**Note:** You can make such queries secure by specifying a tunnel interface.

**Note:** Before you can use the server-select options, you must enable DNS proxy using the **set dns proxy** and **set dns proxy enable** commands. For more information, see “proxy” on page 221.

**Example:** The following commands create two proxy-DNS entries that selectively forward DNS queries to different servers.

- All DNS queries for FQDNs containing the domain name acme.com go through interface tunnel.1, to the DNS server at IP address 2.2.2.2. For example, the DNS proxy could query this server for the FQDN intranet.acme.com.
- All other DNS queries go out through interface ethernet3 to the DNS server at IPv4 address 1.1.1.23.

```
set dns proxy
set dns proxy enable
set dns server-select domain .acme.com outgoing-interface tunnel.1 primary-server
2.2.2.2
set dns server-select domain * outgoing-interface ethernet3 primary-server 1.1.1.23
```



# domain

Use the **domain** commands to set or display the domain name of the security device.

A domain name is a character string that identifies the security device. This name allows other devices to access the security device through a Domain Name System (DNS) server, thus identifying the device without using an explicit Internet Protocol (IP) address.

## Syntax

---

### *get*

```
get domain
```

### *set*

```
set domain name_str
```

## Keywords and Variables

---

### *Variable Parameter*

*name\_str* Defines the domain name of the security device.

**Example:** The following command sets the domain of the security device to **acme**:

```
set domain acme
```



# dot1x

Use the **dot1x** commands to review 802.1X session information and clear 802.1X sessions. You can also clear 802.1X statistics.

Use the **get dot1x** command to review 802.1X configured parameters for all interfaces.

## Syntax

---

### *clear*

```
clear dot1x { session [id number] | statistics }
```

### *get*

```
get dot1x [session [id number] | statistics]
```

## Keywords and Variables

---

### *session*

```
clear dot1x session [id number]
get dot1x [session [id number]]
```

**session** Specifies all 802.1X sessions or detailed information about a specific 802.1X session. Use the **get dot1x session** command to see a list of session IDs. Use a session ID and the optional **id** keyword to see details for a particular session or to clear it.

**Example:** The following command clears the 802.1X session with an ID of 54:

```
clear dot1x session id 54
```

## ***statistics***

```
clear dot1x statistics
get dot1x statistics
```

**statistics**                      Displays all 802.1X-enabled interface statistics or clears all 802.1X statistics.

**Example:** The following command clears all 802.1X statistics:

```
clear dot1x statistics
```

# envar

Use the **envar** commands to define system-wide environment variables. Environment variables take effect on startup.

## Syntax

---

### **get**

```
get envar [resource]
```

### **set**

```
set envar
{
 string |
 fcb-pool-multiple=number |
 ipsec-dscp-mark=yes |
 max-frame-size=frame_size / max_sip_call_num=number /
 no-reroute-tunnel-physical=yes |
 nsrp-max-cluster= num1 |
 nsrp-max-vsd=num2
}
```

## Keywords and Variables

---

### **Variable Parameter**

```
set envar string
unset envar string
```

*string* Specifies the location of the environment variable files.

**Example:** The following command defines the location of the system configuration as **file2.cfg** in **slot2**:

```
set envar config=slot2:file2.cfg
save
```

## *fcf-pool-multiple*

```
set envvar fcf-pool-multiple
```

fcf-pool-multiple ScreenOS uses Fragment Control Blocks (FCBs) to forward and reassemble fragments into normal packets. All FCBs are stored in an FCB pool on the device. The size of the FCB pool varies for different devices. You can use the **get session fragment** command to get the current FCB pool size.

Using this environment variable, you can increase the FCB pool size. Use the following command to change the FCB pool size: **set envvar fcf-pool-multiple= number**. The range is from 1 through 5. You can set this variable only through the CLI. Use the **unset envvar fcf-pool-multiple** command to reset the FCB pool size to the system default.

You must restart the device for changes to environment variables to take effect.

---

**NOTE:** This feature is not supported on all Juniper Networks security devices.

---

**Example:** The following command sets the FCB pool to three times the default:

```
set envvar fcf-pool-multiple=3
save
```

## *ipsec-dscp-mark*

```
set envvar ipsec-dscp-mark
```

ipsec-dscp-mark Some devices require that you explicitly enable DSCP marking by setting this system-wide environment variable. See your hardware manual to find out if your device requires that you explicitly enable DSCP marking before using it in policies. If your device requires it, use the following command to enable DSCP marking system wide: **set envvar ipsec-dscp-mark= yes**. This variable cannot be set using the WebUI. Use the **unset envvar ipsec-dscp-mark** to disable DSCP marking system wide. You must restart the system for changes to environment variables to take effect.

---

**NOTE:** You cannot use the DSCP marking feature if you have enabled IDP on the security device. For information about IDP-capable security devices, see *Volume 4: Attack Detection and Defense Mechanisms* in the *Concepts & Examples ScreenOS Reference Guide*.

---

**Example:** The following command enables DSCP marking on the device:

```
set envvar ipsec-dscp-mark=yes
save
```

## max-frame-size

```
set envar max-frame-size
```

**max-frame-size** On devices that support jumbo frames, this parameter specifies the maximum packet size, or message transmission unit (MTU), the security device can process. See your hardware manual to find out if your device supports jumbo frames.

The range is 1514 through 9830 bytes. To put the device in jumbo frame mode, set the maximum frame size to a value from 1515 through 9830 inclusive. Use the **unset envar max-frame-size** command to return the device to normal maximum frame size, which is 1514 bytes (alternatively, you can use the command: **set envar max-frame-size= 1514**). The maximum frame size does not include the 4-byte frame check sequence at the end of the frame. You must restart the system for changes to environmental variables to take effect.

This feature is available only on devices and modules that support jumbo frames.

In jumbo frame mode, the following apply:

- Deep inspection (DI) is not supported.
- Packets sent through aggregate interfaces might be out of order.
- NSRP forwarding is not supported.
- Maximum firewall or VPN throughput requires at least four sessions (for firewall) or tunnels (for VPN).

**Example:** The following command enables jumbo frame mode and sets the packet size to 4,545 bytes:

```
set envar max-frame-size=4545
save
```

## max\_sip\_call\_num

```
set envar max_sip_call_num =number
unset envar max_sip_call_num =number
```

**max\_sip\_call\_num = number** Sets the maximum number of concurrent calls possible on the security device for a given platform.

*number*—Specifies the maximum permissible concurrent calls that can be made in the security device. Calls exceeding the maximum allowed are set back to the maximum limit, and those below the default value are set to default.

***no-reroute-tunnel-physical***

```
set envvar no-reroute-tunnel-physical
```

`no-reroute-tunnel-physical` The **set envvar no-reroute-tunnel-physical=no** command enables rerouting of sessions between tunnel and physical (Ethernet) interfaces in the same zone. The default is *no* to support rerouting traffic between tunnel and physical interfaces.

Use the following command to disable rerouting of sessions between tunnel and physical interfaces: **set envvar no-reroute-tunnel-physical=yes**. Use the **unset envvar no-reroute-tunnel-physical** CLI command to disable this restriction and enable rerouting again. You must restart the system for changes to environmental variables to take effect.

**Example:** The following command enables rerouting of session between tunnel and Ethernet interfaces:

```
set envvar no-reroute-tunnel-physical=no
save
```

***nsrp-max-cluster***

```
set envvar nsrp-max-cluster
```

`nsrp-max-cluster` This parameter specifies the range of NSRP cluster IDs the security device supports. The valid range is 1–63, inclusive.

**Example:** The following command sets the range of the NSRP clusters supported by the device to 16:

```
set envvar nsrp-max-cluster=16
save
```

***nsrp-max-vsdl***

```
set envvar nsrp-max-vsdl
```

`nsrp-max-vsdl` This parameter specifies the range of VSD IDs the security device supports. The valid range is 0–64, inclusive. However, the product of NSRP cluster ID and VSD ID must be 512.

**Example:** The following command sets the range of VSD IDs supported by the device to 16:

```
set envvar nsrp-max-vsdl=16
save
```

***resource***

```
get envvar resource
```

`resource` Displays the following information:

- (max-session) Maximum number of sessions
- (max-sa) Maximum number of security associations (SAs)
- (max-l2tp-tunnel) Maximum number of L2TP tunnels
- (max-frame-size) Maximum size of frames

# event

Use the **event** commands to display or clear event-log messages.

The event log monitors and records system events and network traffic. The security device categorizes logged system events by the following severity levels:

- **Alert:** Messages for multiple user-authentication failures and other firewall attacks not included in the Emergency category.
- **Critical:** Messages for URL blocks, traffic alarms, high availability (HA) status changes, and global communications.
- **Debugging:** All messages.
- **Emergency:** Messages concerning SYN, Tear Drop, and Ping of Death attacks.
- **Error:** Messages for admin login failures.
- **Information:** Any kind of message not specified in other categories.
- **Notification:** Messages concerning traffic logs and link-status and configuration changes.
- **Warning:** Messages for admin logins and logouts; failures to log in and log out; and user authentication failures, successes, and timeouts.

The event log displays the date, time, level, and description of each system event.

## Syntax

---

### **clear**

```
clear [cluster] event [end-time time]
```

### **get**

```
get event [module name_str]
 [level
 {
 alert |
 critical |
 debug |
 emergency |
 error |
 information |
 notification |
 warning
 }
]
 [type [id_num_high [-id_num_low]]]
 [start-date date [time]]
 [end-date date [time]]
 [start-time time]
 [end-time time]
 [include string]
 [exclude string]
 [src-ip ip_addr1 [-ip_addr2 | src_netmask mask]]
 [dst-ip ip_addr1 [-ip_addr2 | dst_netmask mask]]
 [sort-by
 {
 date [[start-date date_string] end-date date_string] |
 dst-ip [ip_addr [-ip_addr | dst-netmask mask]] |
 src-ip [ip_addr [-ip_addr | src-netmask mask]] |
 time [[start-time time] end-time time]]
 }
]
```

## Keywords and Variables

---

### **cluster**

clear cluster event [ ... ]

cluster            Propagates the **clear** operation to all other devices in an NSRP cluster.

### **dst-ip**

get event dst-ip *ip\_addr* [ ... ]  
get event sort-by dst-ip [ ... ]

dst-ip            Directs the device to display event logs with the specified destination IP address or address range. The device can also sort event logs by destination IP address.

### **include | exclude**

get event [ ... ] [ include *string* ] [ exclude *string* ] [ ... ]

include           Directs the device to exclude or include events containing a specifies string of characters (*string*).  
exclude

### **level**

get event module *name\_str* level { ... }

level            Specifies the priority level of the event message. The priority levels are as follows:

- **emergency** (Level 0) The system is unusable.
- **alert** (Level 1) Immediate action is necessary.
- **critical** (Level 2) The event affects functionality.
- **error** (Level 3) Error condition exists.
- **warning** (Level 4) The event might affect functionality.
- **notification** (Level 5) The event is a normal occurrence.
- **information** (Level 6) The event generates general information about normal operation.
- **debug** (Level 7) The event generates detailed information for troubleshooting purposes.

### **module**

get event module *name\_str* [ ... ]

module           Specifies the name of the system module that generated the event.

**sort-by**

```
get event sort-by { ... }
```

**sort-by** Directs the device to sort event logs by date, source IP address, destination IP address, or time.

**src-ip**

```
get event src-ip ip_addr1 [...]
get event sort-by src-ip ip_addr1 [...]
```

**src-ip** Directs the device to sort event logs by source IP address. The device can also display event logs with the specified source IP address or address range.

**start-time | end-time**

```
clear [cluster] event end-time time
get event [...] [start-time time] [end-time time] [...]
```

**end-time** Specifies the lower and upper ends of a range of times for an event. When you specify a start-time and/or end-time, the device sorts or filters the event logs based on the specified times, regardless of the date. The format is: hh:mm:ss.

**start-time** When you use the **end-time** option with the **clear event** command, you specify the date and optionally the time in the following format: mm/dd/yy-hh:mm:ss.

**Example:** The following command clears all events generated before May 1, 2002 at 11:30 am:

```
get event end-time 05/01/02-11:30:00
```

**start-date | end-date**

```
get event [start-date date_string] [end-date date_string]
get event sort-by date [start-date date_string] [end-date date_string]
```

**start-date** Specifies the lower and upper ends of a range of times for an event. The format is:

**end-date** mm/dd/yy-hh:mm:ss

You can omit the year (the current year is the default) or express the year using the last two digits or all four digits. The hour, minute, and second are optional. The delimiter between the date and the time can be a dash or an underscore:

```
12/31/2001-23:59:00
```

```
12/31/2001_23:59:00
```

**type**

```
get event module name_str level { ... } type id_num1 [...]
```

**type** Specifies a priority level or a range of priority levels.

# exit

Use the **exit** command to exit a command context or a virtual system or to terminate and log out from a CLI session.

## Syntax

---

exit

## Keywords and Variables

---

None.

**Example:** The following **exit** command exits the context of policy ID 1 and returns the command context to the top command level:

```
device-> set policy id 1
device(policy:1)-> set dst-addr 2.2.2.5/32
device(policy:1)-> exit
device->
```

## Notes

When issuing the **exit** command at the top command level (that is, not from within a command context), you must log back into the console to configure a security device.



# failover

Use the **failover** commands to configure failover settings on the security device. The **get failover** command allows you to view the status of the failover settings.

## Syntax

---

### **get**

```
get failover
```

### **set**

```
set failover
{
 auto |
 enable |
 holddown number [recover number] |
 type { route vrouter vrouter ip_addr/mask | track-ip | tunnel-if }
}
```

### **exec**

```
exec failover
{
 force |
 revert
}
```

## Keywords and Variables

---

### **auto**

```
set failover auto
unset failover auto
```

**auto** Directs the security device to automatically fail over from the primary interface to the backup and from the backup interface to the primary. By default, failover is manual (the administrator must use the CLI or WebUI to switch from the primary interface to the backup and from the backup interface to the primary).

**enable**

set failover enable  
unset failover enable

enable Enables failover mode on the security device.

**force**

exec failover force

force Forces traffic to be switched to the backup interface.

**holddown**

set failover holddown *number*  
unset failover holddown

holddown Specifies the time interval (*number*), in seconds, the security device delays failover actions. This value has an effect in the following situations:

- The security device switches traffic to the backup interface.
- The security device switches traffic from the backup interface to the primary interface, when the primary interface becomes available again.

The default hold-down interval is 30 seconds. The range is 1–32767 seconds.

**Example:** The following command sets a failover delay of 45 seconds:

**set failover holddown 45**

**revert**

exec failover revert

revert Forces traffic to be switched from the backup interface to the primary interface.

**type**

set failover type { track-ip | tunnel-if }  
set failover type route vrouter *vrouter ip\_addr/mask*

type Specifies the type of event that determines interface failover. You can specify the following types:

- **route** Monitors a known route's status. The route entry can be propagated by a dynamic routing protocol, such as BGP or OSPF. If a BGP adjacency is lost, the security device removes all routes learned from that BGP peer. If the route entry is not active for a period of time that exceeds the hold-down time, the security device triggers an interface failover. This feature requires an exact address match in the specified vrouter and the route must be active to avoid failover.
- **track-ip**—Instructs ScreenOS to use IP tracking to determine failover.
- **tunnel-if**—Instructs ScreenOS to use VPN tunnel status to determine failover.

# file

Use the **file** commands to clear or display information for files stored in the flash memory or USB storage device.

## Syntax

---

### **get**

```
get file [filename | info]
```

## Keywords and Variables

---

### **Variable Parameters**

```
delete file dev_name:/filename
get file filename
```

*dev\_name:/filename* Deletes the file with the name *filename* from the flash card memory (*dev\_name* = flash) or the USB storage device (*dev\_name* = usb).

*filename* Defines the filename stored in the flash card memory or USB storage device.

**Example:** The following command displays information for the file named **corpnet** from the flash card memory:

```
get file corpnet
```

### **cluster**

```
clear cluster file dev_name:filename
```

cluster Propagates the **clear** operation to all other devices in an NSRP cluster.

### **info**

```
get file info
```

info Displays the base sector and address.



# fips-mode

Use the **fips-mode** commands to configure or display settings for the performing the Federal Information Processing Standards (FIPS) self test on the security device. Use these commands to configure the following parameters:

- FIPS self-test after key generation
- Interval for periodic FIPS self-test
- Admin-initiated FIPS self-test

## Syntax

---

### **exec**

```
exec fips-mode self-test
```

### **get**

```
get fips-mode self-test
```

### **set**

```
set fips-mode self-test [afterkeygen] | [interval interval]
```

## Keywords and Variables

---

### **self-test**

```
get fips-mode self-test
set fips-mode self-test{...}
unset fips-mode self-test{...}
```

**self-test**

Configures the FIPS self-test parameters for the security device.

- **afterkeygen**—Enables or disables the execution of the FIPS self-test functions after the system generates the RSA or DSA key. By default, the system does not run FIPS self-test after the key generation.
- **interval**—Sets or unsets the periodical self-test.
  - *interval*—Interval in which the self-test will run periodically. The interval value can range from 1 to 24 in an hour.

Administrators can use the **exec fips-mode self-test** command to invoke the self-test at run time.

**Note:** If the periodical self-test is running when the administrator invokes the self-test at run time, the system prompts the administrator to try again later. To unset the periodical running of the self-test, administrators can use the **unset fips-mode self-test interval *interval*** command.

# firewall

Use the **firewall** commands to enable or disable logging of dropped packets targeting an interface address on the security device or to specify thresholds for packets sent to the CPU by a Packet Process Unit (PPU).

---

**NOTE:** Security devices perform most firewall services at the security-zone level. You configure individual zones to perform these services. For more information, see “zone” on page 761.

---

## Syntax

---

### *get*

```
get firewall
 [
 ppp-threshold packet-drop { non-ip | other-ip | system-critical }
]
```

### *set*

```
set firewall
 {
 log-self
 {
 [exclude] [icmp | ike | multicast | snmp] |
 [telnet | ssh | web | nsm]
 } |
 }
```

## Keywords and Variables

---

### **firewall**

get firewall

firewall      Displays the settings for logging dropped ICMP, IKE, multicast, and SNMP packets destined for the security device. Log entries appear in the self log.

### **log-self**

```
set firewall log-self [exclude] [icmp | ike | multicast | snmp]
set firewall log-self [telnet | ssh | web | nsm]
unset firewall log-self [exclude] [icmp | ike | multicast | snmp]
unset firewall log-self [telnet | ssh | web | nsm]
```

log-self      Directs the security device to log or not log dropped packets and pings in the self log. Using the **exclude** switch directs the device not to perform logging at all or for specified traffic types.

- **icmp**—Enables or disables Internet Control Message Protocol (ICMP) packet logging
- **ike**—Enables or disables dropped Internet Key Exchange (IKE) packet logging
- **multicast**—Enables or disables multicast packet logging
- **snmp**—Enables or disables dropped Simple Network Management Protocol (SNMP) packet logging
- **telnet**—Enables or disables Telnet logging
- **ssh**—Enables or disables Secure Shell (SSH) logging
- **web**—Enables or disables Internet logging
- **nsm**—Enables or disables Network and Security Manager (NSM) logging

Entering the **set firewall log-self** command without any other keywords enables logging to the self log. (By default, logging to the self log is enabled.) Entering the **unset firewall log-self** command without any other keywords disables the self log.

# flow

Use the **flow** commands to determine how the security device manages packet flow. The device can regulate packet flow in the following ways:

- Enable or disable DNS replies when there is no matching DNS request
- Pass or block packets containing destination MAC addresses that are not in the MAC learning table
- Set or display the initial session-timeout values
- Control or prevent packet fragmentation

## Syntax

---

### *get*

```
get flow [perf | syn-proxy syn-cookie| tcpmss]
```

### *set*

```
set flow
{
 aging { early-ageout number | high-watermark number | low-watermark number }
 all-tcp-mss [number] |
 allow-dns-reply |
 check tcp-rst-sequence |
 force-ip-reassembly |
 gre-in-tcp-mss |
 gre-out-tcp-mss |
 hub-n-spoke-mip |
 initial-timeout number |
 icmp-ur-session-close |
 icmp-ur-msg-filter |
 mac-cache mgt |
 mac-flooding |
 max-frag-pkt-size number |
 multicast |
 no-tcp-seq-check |
 path-mtu |
 reverse-route
 {
 clear-text { always | prefer } |
 tunnel { always | prefer }
```

```

 }
 route-change-timeout |
 syn-proxy syn-cookie |
 tcp-mss [number] |
 tcp-rst-invalid-session |
 tcp-syn-bit-check
 tcp-syn-check |
 tcp-syn-check-in-tunnel |
 vpn-tcp-mss [number]
 }

```

## Keywords and Variables

---

### **aging**

```

set flow aging early-ageout number
set flow aging { high-watermark number | low-watermark number }
unset flow aging { early-ageout | high-watermark | low-watermark }

```

**aging** Directs the security device to begin aggressively aging out sessions when the number of entries in the session table exceeds the high-watermark setting and then stop when the number of sessions falls below the low-watermark setting. When the session table is in any other state, the normal session timeout value is applied—for TCP, session timeout is 30 minutes; for HTTP, it is 5 minutes; and for UDP, it is 1 minute. During the time when the aggressive aging-out process is in effect, the security device ages out sessions—beginning with the oldest sessions first—at the rate you specify.

- **early-ageout** *number*—Defines the ageout value before the security device aggressively ages out a session from its session table. The value you enter can be from 2 to 10 units, each unit representing a 10-second interval. The default early-ageout value is 2 (20 seconds).
- **high-watermark** *number*—Sets the point at which the aggressive aging-out process begins. The number you enter can be from 1 to 100 and indicates a percentage of the session-table capacity in 1-percent units. The default is 100 (100 percent).
- **low-watermark** *number*—Sets the point at which the aggressive aging-out process ends. The number you enter can be from 1 to 10 and indicates a percentage of the session-table capacity in 10-percent units. The default is 10 (100 percent).

**Example:** The following commands activate the aggressive aging-out process when the session table reaches 70 percent of capacity and deactivate the process when it drops below 60 percent, then set the aggressive ageout value at 30 seconds:

```

set flow aging low-watermark 60
set flow aging high-watermark 70
set flow aging early-ageout 3

```

## *allow-dns-reply*

set flow allow-dns-reply  
unset flow allow-dns-reply

**allow-dns-reply** Allows an incoming DNS reply packet without a matched request. If **allow-dns-reply** is disabled and an incoming UDP first-packet has dst-port 53, the device checks the DNS message packet header to verify that the query (QR) bit is 0—which denotes a query message. If the QR bit is 1—which denotes a response message—the device drops the packet, does not create a session, and increments the illegal packet flow counter for the interface. By default, **allow-dns-reply** is disabled. Enabling **allow-dns-reply** directs the security device to skip the check.

## *all-tcp-mss*

set flow all-tcp-mss *number*  
unset flow all-tcp-mss

**all-tcp-mss** Sets the TCP-maximum segment size (TCP-MSS) value for all TCP packets for network traffic. This also sets the TCP-MSS for VPN traffic if the **tcp-mss** and **vpn-tcp-mss** options (described below) are not set. If you enter the **set flow tcp-mss** command, that setting overrides the **all-tcp-mss** option for VPN traffic. The **set flow tcp-mss** command is in turn overridden when **set flow vpn-tcp-mss** is used. The TCP-MSS range can be from 0 to 65,535 bytes. By default, the **all-tcp-mss** option is unset.

## *check tcp-rst-sequence*

set flow check tcp-rst-sequence  
unset flow check tcp-rst-sequence

**check tcp-rst-sequence** Checks that the TCP sequence number in a TCP segment with the RST bit enabled matches the previous sequence number for a packet in that session or is the next higher number incrementally. If the sequence number does not match either of these expected numbers, the security device drops the packet and sends the host a TCP ACK segment with the correct sequence number. By default, this check is disabled.

## *force-ip-reassembly*

set flow force-ip-reassembly  
unset flow force-ip-reassembly

**force-ip-reassembly** Directs the fragments of a packet entering the security device, to a queue. The security device merges the fragments of the same packet and determines the need for packet re-fragmentation. If the merged packet exceeds the available MTU, the packet is subjected to re-fragmentation. By default, the **force-ip-reassembly** behavior remains disabled on the security device, which enables the security device to merge the packet fragments, based on the traffic entering the device.

**Note:** if you enable **force-ip-reassembly**, the security device merges all the packet fragments irrespective of the traffic type entering the security device.

### ***gre-in-tcp-mss***

```
set flow gre-in-tcp-mss [number]
unset flow gre-in-tcp-mss
```

**gre-in-tcp-mss** Enables and specifies the TCP-Maximum Segment Size (TCP-MSS) for Generic Routing Encapsulation (GRE) packets that are about to go into an IPsec VPN tunnel. If the security device receives a GRE-encapsulated TCP packet with the SYN bit and TCP-MSS option set and the TCP-MSS option specified in the packet exceeds the TCP-MSS specified by the security device, then the security device modifies the TCP-MSS value accordingly.

By default, a TCP-MSS for GRE packets is not set. When it is enabled, the default TCP-MSS is 1320 bytes. The TCP-MSS can be between 64 and 1420 bytes inclusive.

### ***gre-out-tcp-mss***

```
set flow gre-out-tcp-mss [number]
unset flow gre-out-tcp-mss
```

**gre-out-tcp-mss** Enables and specifies the TCP-Maximum Segment Size (TCP-MSS) for Generic Routing Encapsulation (GRE) packets that are leaving an IPsec VPN tunnel. If the security device receives a GRE-encapsulated TCP packet with the SYN bit and TCP-MSS option set and the TCP-MSS option specified in the packet exceeds the TCP-MSS specified by the security device, then the security device modifies the TCP-MSS value accordingly.

By default, a TCP-MSS for GRE packets is not set. When it is enabled, the default TCP-MSS is 1320 bytes. The TCP-MSS can be between 64 and 1420 bytes inclusive.

### ***hub-n-spoke-mip***

```
set flow hub-n-spoke-mip
unset flow hub-n-spoke-mip
```

**hub-n-spoke-mip** Permits the security device to forward traffic arriving through a VPN tunnel to a mapped IP (MIP) address on one tunnel interface to the MIP host at the end of another VPN tunnel. The two tunnels form a hub-and-spoke configuration, with the traffic looping back on the same outgoing interface. This option only has an effect when the outgoing interface is bound to the Untrust zone.

## ***initial-timeout***

set flow initial-timeout *number*  
unset flow initial-timeout

**initial-timeout** Defines the length of time in seconds (*number*) that the security device keeps an initial TCP session in the session table before dropping it, or until the device receives a FIN or RST packet. When *number* is less than or equal to 5, the range of time is in 60-second intervals, from 60 seconds to 300 seconds; otherwise the range of time is in 20-second intervals, from 20 seconds to 300 seconds.

**Example:** The following command sets the **initial-timeout** value to 300 seconds:

**set flow initial-timeout 5**

**Example:** The following command sets the **initial-timeout** value to 280 seconds:

**set flow initial-timeout 280**

## ***i***

### ***icmp-ur-msg-filter***

set flow icmp-ur-msg-filter  
unset flow icmp-ur-msg-filter

**icmp-ur-msg-filter** Restricts the number of ICMP unreachable message that can flow through a session. Enabling the **icmp-ur-msg-filter** allows only one ICMP unreachable message to flow through the session.

Note: This command functions only when **icmp-ur-session-close** behavior is disabled.

### ***icmp-ur-session-close***

set flow icmp-ur-session-close  
unset flow icmp-ur-session-close

**icmp-ur-session-close** Enables a session close upon receipt of an ICMP unreachable message

### ***mac-cache***

set flow mac-cache mgt  
unset flow mac-cache mgt

**mac-cache mgt** Caches the source MAC address from incoming administrative traffic for use when replying. This option might be necessary when the security device uses source-based routing. By default, this option is unset.

### ***mac-flooding***

set flow mac-flooding  
unset flow mac-flooding

**mac-flooding** Enables the security device to pass a packet across the firewall even if its destination MAC address is not in the MAC learning table. By default, this option is enabled.

### ***max-frag-pkt-size***

set flow max-frag-pkt-size *number*  
unset flow max-frag-pkt-size

**max-frag-pkt-size** The maximum allowable size for a packet fragment generated by the security device. You can set the *number* value between 1024 and 1500 bytes inclusive.

For example, if a received packet is 1500 bytes and **max-frag-pkt-size** is 1460 bytes, the device generates two fragment packets. The first is 1460 bytes and the second is 40 bytes. If you reset **max-frag-pkt-size** to 1024, the first fragment packet is 1024 bytes and the second is 476 bytes.

**Example:** The following command sets the maximum size of a packet generated by the security device to 1024 bytes:

```
set flow max-frag-pkt-size 1024
```

### ***multicast install-hw-session***

set flow multicast install-hw-session  
unset flow multicast install-hw-session

**multicast** Enables and disables the hardware install multicast session.

### ***no-tcp-seq-check***

set flow no-tcp-seq-check  
unset flow no-tcp-seq-check

**no-tcp-seq-check** When this command is set, the security device does not check sequence numbers in TCP segments during stateful inspection. When unset, TCP sequence number checking is enabled. The security device detects the window scale specified by both source and destination hosts in a session and adjusts a window for an acceptable range of sequence numbers according to their specified parameters. The security device then monitors the sequence numbers in packets sent between these hosts. If the security device detects a sequence number outside this range, it drops the packet.

Starting with ScreenOS 5.1.0, the default behavior of security devices is to monitor sequence numbers in TCP segments. However, when upgrading from an earlier ScreenOS release, the security device maintains the existing setting for TCP sequence number checking. Therefore, if it was disabled before upgrading, it remains disabled after upgrading.

## *path-mtu*

```
set flow path-mtu
unset flow path-mtu
```

**path-mtu** Determines whether the security device sends the source host an ICMP message that a packet size is too large (ICMP type 3, code 4 “Fragmentation needed and DF set”) when it receives a packet meeting the following conditions:

- The Don’t Fragment (DF) bit is set in the IP header.
- The size of the packet after encapsulation exceeds the maximum transfer unit (MTU) of the egress interface, which is 1500 bytes.

When you enable (set) the path-mtu option, the security device sends the source host the above ICMP message. When you disable (unset) this option, the security device ignores the DF bit, fragments the packet so that none of the fragmented packets exceeds the MTU of the egress interface, and forwards them through the appropriate VPN tunnel. By default, this option is disabled.

## *perf*

```
get flow perf
```

**perf** Displays performance information.

## *reverse-route*

```
set reverse-route { clear-text { always | prefer } | tunnel { always | prefer }
unset flow reverse-route { clear-text | tunnel }
```

**reverse-route** Determines reverse route lookup behavior during session creation.

- **clear text**— Used with the **unset** command, specifies that reverse route lookup during session creation is not performed. Instead, traffic arriving in the reverse direction is sent back using the cached MAC address.
- **clear text always**—Perform reverse route lookup during session creation. If no route is found, traffic arriving in the reverse direction is dropped.
- **clear text prefer**—Perform reverse route lookup during session creation. If a route is found, use that route. If no route is found, traffic arriving in the reverse direction is sent back using the cached MAC address. This is the default.
- **tunnel**—Used with the **unset** command, specifies that reverse route lookup is not performed during session creation. Instead, traffic arriving in the reverse direction is sent back using the same tunnel used by the first packet.
- **tunnel always**—Perform reverse route lookup during session creation. If no route is found, traffic arriving in the reverse direction is dropped. This is the default.
- **tunnel prefer**—Perform reverse route lookup during session creation. If a route is found, use that route. If no route is found, traffic arriving in the reverse direction is sent back using the same tunnel used by the first packet.

### ***route-change-timeout***

```
set flow route-change-timeout number
unset flow rout-change-timeout number
```

**route-change-timeout** Sets and unsets the session timeout value on a route change to a nonexistent route. You can set *number* between 6 and 1800 seconds inclusive. Unsetting this keyword removes the route-change-timeout value, causing sessions to time out based on their original timeout, if a route change occurs and no new route is found.

If not set, the current behavior is maintained, and sessions discovered to have no route are aged out using their current session timeout values.

### ***syn-proxy syn-cookie***

```
get flow syn-proxy syn-cookie
set flow syn-proxy syn-cookie
unset syn-proxy syn-cookie
```

**syn-proxy syn-cookie** Sets the flow from traditional SYN Proxy mode to SYN Cookie mode. SYN Cookie is enabled globally on the security device, and is activated when the configured **syn-flood attack-threshold** is exceeded.

### ***tcp-mss***

```
get flow tcp-mss
set flow tcp-mss [number]
unset flow tcp-mss
```

**tcp-mss** Sets the TCP-maximum segment size (TCP-MSS) value for all TCP SYN packets for outbound VPN traffic only. The security device modifies the MSS value in the TCP packet to avoid fragmentation caused by the IPsec operation. The value set using **set flow vpn-tcp-mss** command takes precedence over the one set by **set flow tcp-mss**.

### ***tcp-rst-invalid-session***

```
set flow tcp-rst-invalid-session
unset flow tcp-rst-invalid-session
```

**tcp-rst-invalid-session** Marks a session for immediate termination when it receives a TCP reset (RST) segment. By default, this command is unset. When unset, the security device applies the normal session timeout interval—for TCP, session timeout is 30 minutes; for HTTP, it is 5 minutes; and for UDP, it is 1 minute.

## **tcp-syn-bit-check**

set flow tcp-syn-bit-check  
unset flow tcp-syn-bit-check

**tcp-syn-bit-check** Checks the TCP SYN bit before forwarding the packet to the CPU for session creation. SYN bit check is done in the ASIC, and the packet is forwarded to the CPU for session creation. This improves throughput performance. If the SYN bit is not set in the first packet received, the security device drops the packet. This is the default.

The **tcp-syn-bit-check** feature is a subset of **tcp-syn-check**; therefore if you want to enable just **tcp-syn-bit-check**, you must disable **tcp-syn-check**, which is disabled by default.

The Resulting Behavior column in the following table shows the effect or effects of various combinations of TCP SYN bit screening configuration.

1. Check the TCP SYN bit before creating a session in the CPU.
2. Check the TCP SYN bit before creating a session is in the ASIC.
3. Refresh the session after the three-way handshake.
4. Check the TCP SYN bit on traffic from the tunnel

TCP SYN configuration is the same on all security devices, whether ASIC-based or not.

| <b>tcp-syn-check</b> | <b>tcp-syn-bit-check</b> | <b>tcp-syn-check-in-tunnel</b> | <b>Resulting Behavior</b> |
|----------------------|--------------------------|--------------------------------|---------------------------|
| enable               | n/a                      | enable                         | 2,3,4                     |
| enabled              | n/a                      | disabled                       | 1,3                       |
| disabled             | enabled                  | enabled                        | 2,4                       |
| disabled             | enabled                  | disabled                       | 1                         |
| disabled             | disabled                 | enabled                        | none                      |
| disabled             | disabled                 | disabled                       | none                      |

## **tcp-syn-check**

set flow tcp-syn-check  
unset flow tcp-syn-check

**tcp-syn-check** Checks the TCP SYN bit before creating a session, and refreshes the session after the TCP three-way handshake. If the SYN bit is not set, the security device drops the packet.

The **tcp-syn-check** feature is a superset of **tcp-syn-bit-check**; therefore enabling **tcp-syn-check** enables **tcp-syn-bit-check** as well. If you want to enable just **tcp-syn-bit-check**, you must disable **tcp-syn-check**.

### ***tcp-syn-check-in-tunnel***

```
set flow tcp-syn-check-in-tunnel
unset flow tcp-syn-check-in-tunnel
```

**tcp-syn-check-in-tunnel** Checks the TCP SYN bit before creating a session for tunneled packets. By default, the security device checks that the SYN bit is set in the first packet of a VPN session. If it is not set, the security device drops it.

### ***vpn-tcp-mss***

```
set flow vpn-tcp-mss [number]
unset flow vpn-tcp-mss
```

**vpn-tcp-mss** Sets the TCP-maximum segment size (TCP-MSS) value for all TCP SYN packets for both outbound and inbound VPN traffic.

**Note:** For VPN traffic, the **tcp-mss** or **vpn-tcp-mss** command can be used. If both commands are set, the latter command has precedence over the former. If both commands are not set, **all-tcp-mss** is used. You need to unset the **vpn-tcp-mss** command to make the device use the **tcp-mss** command. When the **vpn-tcp-mss** command is used, an MSS value configured by the **tcp-mss** command will not be valid even if the **tcp-mss** command is run again.

# group

Use the **group** commands to group several addresses or several services under a single name.

A *group* allows you to reference a group of addresses or services by a single name in a policy. This eliminates the need for a separate policy for each address or service. For example, you can create a service group that includes FTP, HTTP, and HTTPS services and then reference that group in a policy.

---

**NOTE:** Although a single policy might reference a service group with three members, the security device generates multiple internal rules from that policy. Overusing address and service groups with high member counts can unexpectedly consume internal resources.

---

## Syntax

---

### *get*

```
get group { address zone [grp_name] | service [grp_name] }
```

### *set*

```
set group
{
 address zone grp_name [add name_str] [comment string] [hidden]
 [ipv6 [add name_str] [comment string] [hidden]] |
 service grp_name [add name_str] [comment string] [hidden]
}
```

## Keywords and Variables

---

### ***add***

```
set group address zone grp_name [add mbr_name] [comment string]
set group service grp_name [add mbr_name [comment string]]
```

*add name\_str* Adds an address or a service named **mbr\_name**.

**Example 1:** The following command creates an address group named **engineering** for the Trust zone and adds the address **hw-eng** to the group:

```
set group address trust engineering add hw-eng
```

**Example 2:** The following command creates a service group named **inside-sales** and adds the service **AOL** to the group:

```
set group service inside-sales add AOL
```

### ***address***

```
get group address zone [...]
set group address zone grp_name [...]
unset group address zone grp_name [...]
```

*address* Performs the operation on an address group. The *zone* value specifies the zone to which the address group is bound. This zone is either a default security zone or a user-defined zone. For more information, see “Zones” on page 773.

**Example:** The following command creates an empty address group (named **headquarters**) for the Trust zone:

```
set group address trust headquarters
```

### ***clear***

```
unset group address zone grp_name clear
unset group service grp_name clear
```

*clear* Removes all the members of an address or service group.

**Example:** The following command removes all members from the address group *engineering* bound to the Trust zone:

```
unset group address trust engineering clear
```

## comment

```
set group address zone grp_name [...] [comment string]
set group service grp_name [...] [comment string]
```

**comment**            Adds a comment *string* to the service group or address group entry.

**Example:** The following command creates an address group named **engineering** for the Trust zone, adds the address **hw-eng** to the group, and includes a comment about the group:

```
set group address trust engineering add hw-eng comment "Engineering Group"
```

## hidden

```
set group address zone grp_name [hidden]
set group service grp_name [hidden]
```

**hidden**            Specifies that the service group or address group is a hidden service or group. We strongly recommend that you do not hide service groups or address groups.

## ipv6

```
set group address zone grp_name [...] [ipv6] [...]
```

**ipv6**              Specifies that the address group is an IPv6 group.

**Example:** The following command creates an address group named **engineering** for the Trust zone and specifies that it is a hidden group:

```
set group address trust engineering ipv6
```

## remove

```
unset group address zone grp_name remove name_str
unset group service grp_name remove name_str
```

**remove**            Removes the address (or service) named **name\_str**. If you do not specify an address (or service) group member, the **unset group { address | service }** command deletes the entire address group or service group.

**Example:** The following command removes the address **admin-pc** from the **engineering** address group:

```
unset group address trust engineering remove admin-pc
```

## **service**

```
get group service grp_name
set group service grp_name [...]
unset group service grp_name [...]
```

*service grp\_name* Performs the operation on a service group.

**Example:** The following command creates an empty service group and names it *web\_browsing*:

```
set group service web_browsing
```

## **Notes**

Each address group and service group you create must have a unique name. You cannot use the same address group name as a service group name.

You cannot add the predefined address or service named **any** to a group.

While a policy references a group, you cannot remove the group, although you can modify it.

From the console, you can add only one member to a group at a time.

# group-expression

Use the **group-expression** commands to set up or display group expressions for use in security policies.

A *group expression* allows you to include or exclude users or user groups, according to NOT, AND, or OR operators. Such expressions are only usable for external users and user groups.

## Syntax

---

### **get**

```
get group-expression
{
 name_str |
 all |
 id number
}
```

### **set**

```
set group-expression name_str
{
 not name_str |
 name_str { and | or } name_str |
 id number |
}
```

## Keywords and Variables

---

### **Variable Parameters**

```
get group-expression name_str
set group-expression name_str
unset group-expression name_str
```

*name\_str*      The name of the group expression.

**all**

```
get group-expression all
```

all                    Specifies all group expressions.

**and | or**

```
set group-expression name_str name_str and name_str
set group-expression name_str name_str or name_str
```

and | or              Specifies AND or OR relationship between users, user groups, and group expressions.

**Example:** The following commands create group expressions *SalesM* and *SM\_Group*, place them in an OR relationship, and then place *SM\_Group* and *Office\_1* in an AND relationship:

```
set user-group Sales_Group location external
set user-group Marketing_Group location external
set group-expression SalesM Sales_Group or Marketing_Group
set group-expression SM_Group Office_1 and SalesM
```

**id**

```
get group-expression id number
set group-expression name_str id number
unset group-expression id number
```

id *number*            Specifies an identification number for the group expression.

**not**

```
set group-expression name_str not name_str
```

not                    Specifies negation.

**Example:** The following command creates a NOT group expression that does not allow the **Office\_1** user:

```
set group-expression Total_Users not Office_1
```

# gtp

Use the **gtp** commands to delete existing GTP tunnels on the security device, remove GTP inspection-object configurations, obtain configuration information, or configure a GTP object.

## Syntax

---

### **clear**

```
clear gtp tunnel { number | all }
```

### **get**

```
get gtp { configuration [name_str] | tunnels }
```

### **set**

```
set gtp configuration name_str
```

### **get (Within an Object Context)**

```
get configuration
```

### **set (Within an Object Context)**

```
set gtp configuration name_str
set
{
 apn { string { drop | pass | select [ms | net | vrf] } } |
 drop
 {
 create-pdp |
 crt-aa-pdp |
 data-record |
 del-aa-pdp |
 delete-pdp |
 echo |
 error-indication |
 failure-report |
 fwd-relocation |
 fwd-srns-context |
 g-pdu |
 identification |
```

```

node-alive |
note-ms-present |
pdu-notification |
ran-info |
redirection |
relocation-cancel |
send-route |
sgsn-context |
supported-extension |
update-pdp |
ver-not-supported
}
[number]
} |
gtp-in-gtp-denied |
imei-sv string
{
 apn string { drop | pass | select { ms | net | vrf } } |
 mcc-mnc string { apn string { drop | pass | select { ms | net | vrf } } }
} |
limit { rate number | tunnel number } |
log
{
 forwarded { basic [number] | extended [number] } |
 prohibited { basic [number] | extended [number] } |
 rate-limited { basic [number] | extended [number] } |
 state-invalid { basic [number] | extended [number] } |
 |traffic-counters [byte-counts] |
 tunnel-limited { [number] | extended [number] }
} |
max-message-length number |
min-message-length number |
notify ip_addr
{
 [port port_num]
 src-interface interface context id_num [md5-authentication password]
} |
rai string
{
 apn string { drop | pass | select { ms | net | vrf } } |
 imei-sv string
 {
 apn string { drop | pass | select { ms | net | vrf } } |
 mcc-mnc string { apn string { drop | pass | select { ms | net | vrf } } }
 } |
 mcc-mnc string { apn string { drop | pass | select { ms | net | vrf } } } |
 uli string
 {
 apn string { drop | pass | select { ms | net | vrf } } |
 imei-sv string
 {
 apn string { drop | pass | select { ms | net | vrf } } |
 mcc-mnc string { apn string { drop | pass | select { ms | net | vrf } } }
 }
 } |
}
} |
rat string

```

```

{
 apn string { drop | pass | select { ms | net | vrf } } |
 imei-sv string
 {
 apn string { drop | pass | select { ms | net | vrf } } |
 mcc-mnc string { apn string { drop | pass | select { ms | net | vrf } } }
 } |
 mcc-mnc string { apn string { drop | pass | select { ms | net | vrf } } } |
 rai string
 {
 apn string { drop | pass | select { ms | net | vrf } } |
 imei-sv string { apn string { drop | pass | select { ms | net | vrf } } } |
 mcc-mnc string { apn string { drop | pass | select { ms | net | vrf } } } |
 uli string
 {
 apn string { drop | pass | select { ms | net | vrf } } |
 imei-sv string
 {
 apn string { drop | pass | select { ms | net | vrf } } |
 mcc-mnc string { apn string { drop | pass | select { ms | net | vrf } } }
 }
 mcc-mnc string { apn string { drop | pass | select { ms | net | vrf } } }
 } |
 } |
 uli string
 {
 apn string { drop | pass | select { ms | net | vrf } } |
 imei-sv string
 {
 apn string { drop | pass | select { ms | net | vrf } } |
 mcc-mnc string { apn string { drop | pass | select { ms | net | vrf } } } |
 }
 mcc-mnc string { apn string { drop | pass | select { ms | net | vrf } } }
 }
} |
remove-r6 |
seq-number-validated |
teid-di |
timeout number |
trace
{
 imsi number |
 max-active number [save-length number] |
 msisdn number
}
uli string
{
 apn string { drop | pass | select { ms | net | vrf } } |
 imei-sv string
 {
 apn string { drop | pass | select { ms | net | vrf } } |
 mcc-mnc string { apn string { drop | pass | select { ms | net | vrf } } } |
 }
 mcc-mnc string { apn string { drop | pass | select { ms | net | vrf } } }
}
}

```

## Keywords and Variables

---

### **apn**

```
set apn string { drop | pass | selection }
unset apn string
```

**apn** The **set** and **unset** commands allow access or deny access to specific Access Point Names (APNs).

- **string**—Sets an APN suffix such as “netscreen.com.mcc123.mnc456.gprs”.
- **drop**—Specifies to deny GTP packets from all Selection Modes for this APN.
- **pass**—Specifies to permit GTP packets from all Selection Modes for this APN.
- **selection**—Specifies one of the following Selection Modes for the APN:
  - **ms** The APN is provided by a mobile station (MS) and the user-subscription is not verified.
  - **net** The APN is provided by a network and the user-subscription is not verified.
  - **vrf** The APN is provided by a network or an MS and the user-subscription is verified.

**Note:** Because APN filtering is based on a perfect match, using the wildcard \* when setting an APN suffix can prevent the inadvertent exclusion of APNs you would otherwise authorize. The security device automatically permits all other APNs that do not match.

### **configuration**

```
get gtp configuration
```

**configuration** Displays information about the configuration of the current GTP inspection.

**drop**

```
set drop message_type [version number]
unset drop message_type [version number]
```

**drop** Displays information about the configuration of the current GTP inspection.

- **number**—Specifies the GTP release version number for the specified message type. The possible versions are **0** (for GTP 97) or **1** (GTP 99). If you do not set a version number, the device drops all packets of the specified message type for both GTP release versions.

The following lists CLI keywords that each represent a GTP message type. A GTP message type includes one or many messages. When you set or unset a message type, you automatically permit or deny access to all messages of the specified type.

- **create-pdp** Represents Create PDP Context Request and Create PDP Context Response messages.
- **crt-aa-pdp** Represents Create AA PDP Context Request and Create AA PDP Context Response messages.
- **del-aa-pdp** Represents Delete AA PDP Context Request and Delete AA PDP Context Response messages.
- **delete-pdp** Represents Delete PDP Context Request and Delete PDP Context Response messages.
- **echo** Represents Echo Request and Echo Response messages.
- **error-indication** Represents Error Indication messages.
- **failure-report** Represents Failure Report Request and Failure Report Response messages.
- **fwd-relocation** Represents Forward Relocation Request, Forward Relocation Response, Forward Relocation Complete, and Forward Relocation Complete Acknowledge messages.
- **fwd-srns-context** Represents Forward SRNS Context Request and Forward SRNS Context Response messages.
- **g-pdu** Represents G-PDU and T-PDU messages.
- **identification** Represents Identification Request and Identification Response messages.
- **node-alive** Represents Node Alive Request and Node Alive Response messages.
- **note-ms-present** Represents Note MS GPRS Present Request and Note MS GPRS Present Response messages.

***gtp-in-gtp-denied***

```
set gtp-in-gtp-denied
unset gtp-in-gtp-denied
```

**gtp-in-gtp-denied** Enables the security device to detect and drop GTP packets that contain another GTP packet in its message body.

**imei-sv**

```
set imei-sv string apn string { ... }
un set imei-sv string apn string { ... }
```

|         |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
|---------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| imei-sv | <p>Enables the security device to detect and drop GTP packets that contain International Mobile Equipment Identity-Software Version (IMEI-SV) information element.</p> <ul style="list-style-type: none"> <li>■ <b>number</b>—Specifies an IMEI-SV name.</li> <li>■ <b>string</b>—Specifies an APN.</li> <li>■ <b>pass</b>—Enables the security device to permit GTP packets from all Selection Modes for the specified APN.</li> <li>■ <b>drop</b>—Enables the security device to deny GTP packets from all Selection Modes for the specified APN.</li> <li>■ <b>selection</b>—Specifies one of the following Selection Modes for the APN: <ul style="list-style-type: none"> <li>■ <b>ms</b> The APN is provided by a mobile station (MS) and the user-subscription is not verified.</li> <li>■ <b>net</b> The APN is provided by a network and the user-subscription is not verified.</li> <li>■ <b>vrf</b> The APN is provided by a network or an MS and the user-subscription is verified.</li> </ul> </li> </ul> |
|---------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

**limit**

```
set limit { rate number | tunnel number }
unset limit { rate | tunnel }
```

|       |                                                                                                                                                                                                                                                                                                                                                                                                      |
|-------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| limit | <p>The <b>set</b> or <b>unset</b> command configures or removes the following types of limits:</p> <ul style="list-style-type: none"> <li>■ <b>rate <i>number</i></b>—Specifies a limit in packets per second for GTP-C messages.</li> <li>■ <b>tunnel <i>number</i></b>—Specifies a limit in the number of GTP tunnels that can be created in the current GTP inspection object per GSN.</li> </ul> |
|-------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

## log

```
set log { ... }
unset log { ... }
```

**log** Instructs the security device to log or cease logging the following information:

- **forwarded** A packet that the security device transmitted because it was valid.
- **prohibited** A packet that the security device dropped because it was invalid.
- **rate-limited** A packet that the security device dropped because it exceeded the maximum rate limit of the destination GSN.
- **state-invalid** A packet that the security device dropped because it failed stateful inspection.
- **traffic-counters** The number of user data and control messages the security device received from and forwarded to the GGSNs and SGSNs it protects.
  - **byte-counts** The number of bytes the security device received from and forwarded to the GGSNs and SGSNs it protects instead of the number of messages.
- **tunnel-limited** A packet that the security device dropped because the maximum limit of tunnels for the destination GSN was reached, thus a tunnel could not be established.

The following options apply to all the **set log** commands listed above except **traffic-counters**:

- **basic**—Specifies to log the basic Information Elements (IEs) of the GTP message.
- **extended**—Specifies to log other IEs in addition to the basic IEs of the GTP message.

## max-message-length

```
set max-message-length number
unset max-message-length
```

**max-message-length** Sets the maximum message payload length (in bytes) the security device accepts for a GTP message. The default maximum message length is 65,535 bytes.

## mcc-mnc

```
set mcc-mnc string apn string { ... }
unset mcc-mnc string apn string
```

**mcc-mnc** By default, the security device grants access to any International Mobile Station Identity (IMSI) prefix. An IMSI prefix consists of a Mobile Country Code (MCC) and a Mobile Network Code (MNC). The **set** and **unset** commands allow or deny specific IMSI prefixes. These commands only apply to create pdp context request GTP messages. The MCC-MNC pair can be five or six digits.

You can filter GTP packets based on the combination of an IMSI prefix and an APN.

- *number*—Specifies an IMSI prefix.
- *string*—Specifies an APN.
- **pass**—Enables the security device to permit GTP packets from all Selection Modes for the specified APN.
- **drop**—Enables the security device to deny GTP packets from all Selection Modes for the specified APN.
- **selection**—Specifies one of the following Selection Modes for the APN:
  - **ms** The APN is provided by a mobile station (MS) and the user-subscription is not verified.
  - **net** The APN is provided by a network and the user-subscription is not verified.
  - **vrf** The APN is provided by a network or an MS and the user-subscription is verified.

### ***min-message-length***

```
set min-message-length number
unset min-message-length
```

*min-message-length* Sets the minimum message payload length (in bytes) the security device accepts for a GTP message. The default minimum message length is 0 bytes.

### ***notify***

```
set notify ip_addr { ... }
unset notify
```

*notify* The set command enables the GTP firewall (the client) to notify the Gi firewall (the server) of the overbilling attack. Such notification directs the server to drop the unwanted traffic. The unset command disables the notification feature on the GTP firewall.

- *ip\_addr* The IP address of the Gi firewall (server).
- **port** *port\_num* The port number on which the Gi firewall receives notification messages.
- **src-interface** *interface* The interface from which the GTP firewall sends Overbilling Attack notification to the Gi firewall.
- **context** *id\_num* The number that identifies the context. Note that the same context must exist on the Gi firewall.
- **md5-authentication** *password* The MD5 authentication password.

**rai**

```
set rai string apn string { ... }
unset rai string apn string { ... }
```

|     |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|-----|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| rai | <p>Enables the security device to detect and drop GTP packets that contain the RAI Information Element.</p> <ul style="list-style-type: none"> <li>■ <i>number</i>—Specifies an RAI value.</li> <li>■ <i>string</i>—Specifies an APN.</li> <li>■ <b>pass</b>—Enables the security device to permit GTP packets from all Selection Modes for the specified APN.</li> <li>■ <b>drop</b>—Enables the security device to deny GTP packets from all Selection Modes for the specified APN.</li> <li>■ <b>selection</b>—Specifies one of the following Selection Modes for the APN: <ul style="list-style-type: none"> <li>■ <b>ms</b> The APN is provided by a mobile station (MS) and the user-subscription is not verified.</li> <li>■ <b>net</b> The APN is provided by a network and the user-subscription is not verified.</li> <li>■ <b>vrf</b> The APN is provided by a network or an MS and the user-subscription is verified.</li> </ul> </li> </ul> |
|-----|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

**rat**

```
set rat string apn string { ... }
unset rat string apn string { ... }
```

|     |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|-----|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| rat | <p>Enables the security device to detect and drop GTP packets that contain the RAT Information Element.</p> <ul style="list-style-type: none"> <li>■ <i>number</i>—Specifies an RAT value.</li> <li>■ <i>string</i>—Specifies an APN.</li> <li>■ <b>pass</b>—Enables the security device to permit GTP packets from all Selection Modes for the specified APN.</li> <li>■ <b>drop</b>—Enables the security device to deny GTP packets from all Selection Modes for the specified APN.</li> <li>■ <b>selection</b>—Specifies one of the following Selection Modes for the APN: <ul style="list-style-type: none"> <li>■ <b>ms</b> The APN is provided by a mobile station (MS) and the user-subscription is not verified.</li> <li>■ <b>net</b> The APN is provided by a network and the user-subscription is not verified.</li> <li>■ <b>vrf</b> The APN is provided by a network or an MS and the user-subscription is verified.</li> </ul> </li> </ul> |
|-----|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

**remove-r6**

```
set remove-r6
unset remove-r6
```

|           |                                                                                                                                                                                                                                               |
|-----------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| remove-r6 | <p>Enables the security device to detect and remove 3GPP-specific attributes from the GTP packet header when the packet passes into a 2GPP network. This allows you to retain interoperability in roaming between 2GPP and 3GPP networks.</p> |
|-----------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

**seq-number-validated**

```
set seq-number-validated
unset seq-number-validated
```

**seq-number-validated** Enables or disables the GTP Sequence Number Validation feature.

**teid-di**

```
set teid-di number
unset teid-di number
```

**teid-di** Enables the security device to perform deep inspection on the tunnel endpoint ID (TEID) in G-PDU data messages.

**timeout**

```
set timeout number
unset timeout
```

**timeout** Sets the tunnel timeout value in hours. The default is 24 hours. Via the process of stateful inspection, if a security device detects no activity in a tunnel for a specified period of time (timeout), it removes the tunnel from the state table.

**trace**

```
set trace { ... }
unset trace { ... }
```

**trace** Enables the security device to identify and log the contents of GTP-U or GTP-C messages based on IMSI prefixes or Mobile Station-Integrated Services Data Network (MS-ISDN) identification.

- **imsi number**—Indicates the IMSI prefix for which you want the security device to trace GTP packets.
- **max-active number**—Specifies the maximum number of subscribers that the security device can trace concurrently for the current GTP inspection object. The default value is 3 and the range is 1 to 20.
- **save-length number**—Specifies the number of bytes of data to log for GTP packets containing user data. You can log partial or complete packets. The default value is 0, which means that the security device does not log any of the content from a GTP-U packet.
- **msisdn number**—Indicates the MS-ISDN for which you want the security device to trace GTP packets.

**tunnel**

```
clear gtp tunnel { number | all }
get gtp tunnel
```

**tunnel** The `get` command displays information about active tunnels on the security device.

The **clear** command deletes tunnels, thus terminating the connection between the communicating parties. The following specifies which tunnels are deleted:

- **number** Tunnel index (or tunnel ID number)—specifies which tunnel to delete. The security device assigns an index to each tunnel and uses this number internally.
- **all**—Specifies to delete all tunnels on the security device.

**uli**

```
set uli string apn string { ... }
unset uli string apn string { ... }
```

**uli** Enables the security device to screen subscriber's requested content, before allowing a content download, based on the User Location Information (ULI) IE.

- **number**—Specifies an ULI value.
- **string**—Specifies an APN.
- **pass**—Enables the security device to permit GTP packets from all Selection Modes for the specified APN.
- **drop**—Enables the security device to deny GTP packets from all Selection Modes for the specified APN.
- **selection**—Specifies one of the following Selection Modes for the APN:
  - **ms** The APN is provided by a mobile station (MS) and the user-subscription is not verified.
  - **net** The APN is provided by a network and the user-subscription is not verified.
  - **vrf** The APN is provided by a network or an MS and the user-subscription is verified.



# hostname

Use the **hostname** commands to define the security device name. This name always appears in the console command prompt.

The hostname is a character string that identifies the security device. If you define a hostname such as ns500gate and a domain name such as juniper (see “domain” on page 225), you can use the hostname and domain name (ssg140gate.juniper) as a gateway for a VPN tunnel.

## Syntax

---

### *get*

get hostname

### *set*

set hostname *string*

## Keywords and Variables

---

### *Variable Parameters*

string            Sets the name of the security device.

**Example:** The following command changes the security device hostname to *acme*:

```
set hostname acme
```



# icap

Use the **icap** command to configure your security device to support an external antivirus (AV) scan engine. Your security device communicates with the external AV scan engine using the Internet Content Adaptation Protocol (ICAP).

---

**NOTE:** The **set icap** commands are supported at the root level only. The **exec** and **get** commands, however, are supported at both the root and vsys levels.

---

External AV scanning is supported for HTTP and SMTP. To configure your device to support external AV, in addition to the **icap** commands in this section, you must configure global AV commands and profiles. For more information, see “av” on page 97.

## Syntax

---

### **exec**

```
exec icap server name_str probe |
```

### **get**

```
get icap
{
 server [name_str] |
 server-group [name_str]
}
```

### **set**

```
set icap
{
 server name_str
 {
 enable |
 host { ip_addr | name_str } [port number] |
 max-connections number |
 probe-interval number |
 probe-url url_str |
 } |
 server-group name_str [server name_str] |
}
```

## Keywords and Variables

---

### Variable Parameters

*name\_str* Specifies an ICAP server or a group of ICAP servers.

### server

```
exec icap server name_str probe
get icap server
get icap server name_str
set icap server name_str { . . . }
unset icap server name_str { . . . }
```

**server** Displays, sets, or performs actions on an ICAP scan-engine server for external AV scanning.

- **enable**—Enables the configured ICAP server.
- **host *IP address***—Specifies the IP address or hostname of an ICAP server. The maximum string length of an ICAP AV hostname is 255 characters.
  - **port *number*** You may configure a different port from the default 1344 port. The valid range of port numbers is 1024 to 65535.
- **max-connections *number***—Configures the maximum connections to the ICAP server. The upper limit and default values are platform-dependent.
- **probe**—Verifies the health of the ICAP server. The device performs a Layer 7 protocol request to verify if the ICAP server is up and displays the result at the console.
- **probe-interval *number***—Configures the ICAP server probe interval in multiples of five seconds. The range of the interval is 0 to 3000 seconds. The default is 10 seconds; zero (0) indicates that the command is disabled.
- **probe-url *url\_str***—Configures a URL string to probe the ICAP server. The maximum string length of an ICAP AV probe URL string is 255 characters.

**Example:** The following command configures an ICAP server, *sales\_svr*, with host IP address 1.1.1.1 and default port 1344. The same ICAP server is configured with a probe interval of 20 seconds and av scan url to /scan. The maximum number of connections to the ICAP server is set to 128:

```
set icap server sales_svr host 1.1.1.1
set icap server sales_svr probe-interval 20
set icap server sales_svr probe-url /scan
set icap server sales_svr max-connections 128
```

## **server-group**

```
get icap server-group
get icap server-group name_str
set icap server-group name_str server name_str
unset icap server-group name_str server name_str
unset icap server-group name_str
```

**server-group**      Displays or sets ICAP server group information. Configures an ICAP server group and adds or removes servers from the group. You may also add an ICAP server group to an AV profile.

**Example 1:** The following commands configure an ICAP server group named **juniper-gp** and adds ICAP servers (**sales\_svr**, **mktg\_svr**, and **eng\_svr**) to the server group:

```
set icap server-group juniper-gp server sales-svr
set icap server-group juniper-gp server mktg-svr
set icap server-group juniper-gp server eng-svr
```

**Example 2:** The following command removes the ICAP server, **eng-svr**, from the ICAP server group, **juniper-gp**:

```
unset icap server-group juniper-gp server eng-svr
```



# igmp

Use the **igmp** commands to send Internet Group Management Protocol (IGMP) messages, display IGMP settings, monitor IGMP states on a security device, and clear IGMP information.

## Syntax

---

### **exec**

```
exec igmp interface interface
{
 query [mcst_addr [s_bit] [ip_addr]] |
 report mcst_addr |
 leave mcst_addr
}
```

### **get**

```
get igmp
{
 config
 group [ip_addr [source]] [all] |
 interface [all] |
 source ip_addr |
 statistic [all]
}
```

### **clear**

```
clear igmp interface interface { statistic | group mcast_addr | all }
```

## Keywords and Variables

---

### **config**

get igmp config

config            Displays the configuration settings for IGMP.

### **group**

get igmp group [ *mcast\_addr* | all ]

group            Displays information for the multicast group specified. Specify **all** to display information for all multicast groups.

### **interface**

exec igmp interface *interface* { . . . }  
 get igmp interface [ all ]  
 clear igmp interface *interface* statistic  
 clear igmp interface *interface* group *mcast\_addr* | all

interface        Displays and clears statistics or multicast groups. You can also send IGMP messages for the specified interface.

### **leave**

exec igmp interface *interface* leave *mcast\_addr*

leave            Sends a leave message for the specified multicast group. You can execute this command if the interface is in host mode only.

### **query**

exec igmp interface *interface* query [ *mcast\_addr* [ *s\_bit* ] [ *ip\_addr* ] ]

query            Sends an IGMP query message. If you specify a multicast group address, the interface sends a group-specific query to the specified multicast group. If you do not specify a multicast group address, then the interface sends a general query to the “all hosts” group (224.0.0.1).

For IGMPv3, you can specify the following:

- **s\_bit**: Specify this keyword to indicate to other multicast routers that they are to suppress the normal timer updates they perform when they hear a query.
- **ip\_addr**: You can specify a source address.

Enter this command only if the interface is in router mode.

**Example:** The following command sends a general query to the “all hosts” group from interface *ethernet4*:

```
exec igmp interface ethernet4 query
```

## **report**

```
exec igmp interface interface report mcst_addr
```

**report**                Sends an IGMP membership report to the specified group. Enter this command if the interface is in host mode.

**Example:** The following command sends a membership report to the specified multicast group:

```
exec igmp interface ethernet4 report 224.2.1.1
```

## **source**

```
get igmp source ip_addr
```

**source**                Displays an IGMP source address.

## **statistic**

```
get igmp statistic [all]
clear igmp interface interface statistic
```

**statistic**            Displays or clears IGMP statistics. Enter this command if the interface is in router mode.



# ike

Use the **ike** commands to define the Phase 1 and Phase 2 proposals and the gateway for an AutoKey Internet Key Exchange (IKE) VPN tunnel, as well as to specify other IKE parameters.

To establish an AutoKey IKE IPsec tunnel between peer devices, two phases of negotiation are required:

- In Phase 1, the peer devices establish a secure channel in which to negotiate the IPsec SAs.
- In Phase 2, the peer devices negotiate the IPsec SAs for encrypting and authenticating the ensuing exchanges of user data.

The gateway definition identifies the devices or remote users with which the security device establishes the VPN tunnel.

## Syntax

---

### **exec**

```
exec ike preshare-gen name_str usr_str
```

### **get**

```
get ike
{
 accept-all-proposal |
 ca-and-type |
 cert |
 conn-entry |
 cookies |
 gateway [name_str] |
 heartbeat |
 id-mode |
 ikev2 { eap active | ike-sa-soft-lifetime | initiator-send-dummy-ipsec |
 stateless-cookie-threshold } |
 ikeid-enumeration [table [detail src_ip]]
 initial-contact [all-peers | single-gateway [name_str]] |
 initiator-set-commit |
 member-sa-hold-time |
 p1-max-dialgrp-sessions |
 p1-proposal name_str |
```

```

p1-sec-level |
p2-proposal name_str |
p2-sec-level |
policy-checking |
respond-bad-spi |
responder-set-commit |
soft-lifetime-buffer
}

```

## set

### Phase 1 Proposal

```

set ike p1-proposal name_str
 [dsa-sig | rsa-sig | preshare]
 [group1 | group2 | group5 | group14]
 { esp
 { 3des | des | aes128 | aes192 | aes256
 { md5 | sha-1 | sha2-256
 [
 days number |
 hours number |
 minutes number |
 seconds number
]
 }
 }
 }
}

```

### Phase 2 Proposal

```

set ike p2-proposal name_str
 [group1 | group2 | group5 | group14 | no-pfs]
 {
 esp [3des | des | aes128 | aes196 | aes256 | null] |
 ah
 }
 [md5 | null | sha-1 | sha2-256
 [
 days number |
 hours number |
 minutes number |
 seconds number]
 [kbyte number]
]
}

```

### Gateway Tunnel

```

set ike gateway name_str
 {
 acvpn-dynamic [local-id string]
 acvpn-profile { proposal name_string } { sec-level { basic | compatible | standard } } |
 address { ip_addr | hostname[.dom_name] [id] }
 dialup { usr_str | grp_name } |
 dpd
 {
 always-send |

```

```

 hub-override |
 interval number1 |
 retry number2
 } |
dynamic
{
 string |
 asn1-dn { [container string] [wildcard string] } |
 fqdn string |
 ip-addr string |
 u-fqdn string
} |
}
 [aggressive | main] [local-id id_str]
 [outgoing-interface interface
 [outgoing-zone zone]
]
 [preshare key_str | seed-preshare key_str]
 {
 sec-level { basic | compatible | standard } |
 proposal name_str1
 [name_str2] [name_str3] [name_str4]
 }

```

### **IKE Heartbeat**

```

set ike gateway name_str heartbeat
{
 hello number |
 hub-override |
 threshold number |
 reconnect number
}

```

### **Certificates**

```

set ike gateway name_str cert
{
 my-ca-hash string |
 my-cert id_num |
 peer-ca [id_num | all] |
 peer-ca-hash string |
 peer-cert-type { pkcs7 | x509-sig }
}

```

### **NAT-Traversal**

```

set ike gateway name_str nat-traversal
[
 keepalive-frequency number |
 udp-checksum
]

```

**XAuth**

```

set ike gateway name_str xauth
[
 bypass-auth |
 client { any | chap | securid } username name_str password name_str |
 do-edipi-auth |
 server name_str
 [chap] [query-config] [user name_str | user-group name_str]
]

```

**gateway ikev2**

```

set ike gateway ikev2 name_str
{
 auth-method
 self { preshare | rsa-sig | dsa-sig | eap }
 peer { preshare | rsa-sig | dsa-sig | eap } |
 eap
 {
 supplicant md5 username name_str password password |
 authenticator passthrough auth-server [user name_str] [send-id-req]
 } |
 xauth { accounting off | accounting server name_str }
}

```

**Other IKE Command Switches**

```

set ike
{
 accept-all-proposal |
 id-mode { ip | subnet } |
 ikeid-enumeration [threshold_number [interval_number]]
 initial-contact
 [
 all-peers |
 single-gateway name_str
] |
 ikev2
 {
 stateless-cookie-threshold number |
 initiator-send-dummy-ipsec |
 ike-sa-soft-lifetime number
 }
 initiator-set-commit |
 member-sa-hold-time number |
 p1-max-dialgrp-sessions { count number | percentage number } |
 policy-checking |
 respond-bad-spi spi_num |
 responder-set-commit | responder-mode |
 single-ike-tunnel name_str |
 soft-lifetime-buffer number
}

```

## Keywords and Variables

---

### ***accept-all-proposal***

```
get ike accept-all-proposal
set ike accept-all-proposal
unset ike accept-all-proposal
```

**accept-all-proposal** Directs the security device to accept all incoming proposals. By default, the device accepts only those proposals matching predefined or user-defined proposals. This command is primarily useful when troubleshooting AutoKey IKE tunnels.

### ***acvpn-dynamic***

```
set ike gateway name_str
```

**acvpn-dynamic** Configured on the Next Hop Resolution Protocol (NHRP) client, called the Next Hop Client (NHC), **acvpn-dynamic** acts as a placeholder to receive information from the Next Hop Server (NHS) configured in the **acvpn-profile**.

### ***acvpn-profile***

```
set ike gateway name_str
```

**acvpn-profile** Configured on the Next Hop Resolution Protocol (NHRP) server, called the Next Hop Server (NHS), the AC-VPN profile contains information the NHS pushes to the Next Hop Client (NHC) to enable it to set up a dynamic tunnel with another NHC. Mode must be aggressive. You attach the AC-VPN profile to the NHRP configuration using the **set vrouter *name\_str* portocol nhrp** command.

### ***address***

```
set ike gateway name_str address { ip_addr | name_str } { ... }
```

**address** Defines the remote IKE gateway address either as an IP address, or as a hostname, or a fully qualified domain name (FQDN, which is a hostname + domain name). Use this option to set up a site-to-site VPN.

**Note:** If you specify a hostname or an FQDN that the security device cannot resolve to an IP address, the IKE gateway is classified as disabled.

**Example:** The following command specifies **www.juniper.net** as the address of a remote IKE gateway named **ns1**, defines the preshared key as **7a850wq**, and specifies the Phase 1 security level as **compatible**:

```
set ike gateway ns1 address www.juniper.net preshare 7a850wq sec-level
compatible
```

### ***aggressive* | *main***

```
set ike gateway name_str { ... } aggressive [...]
set ike gateway name_str { ... } main [...]
```

**aggressive** Defines the mode used for Phase 1 negotiations. Use aggressive mode only when you need to initiate an IKE key exchange without ID protection, as when a peer unit has a dynamically assigned IP address. Main mode is the recommended key-exchange method because it conceals the identities of the parties during the key exchange.

**main** The *compatible* security level for Phase 1 negotiations includes the following four proposals: pre-g2-3des-sha, pre-g2-3des-md5, pre-g2-des-sha, and pre-g2-des-md5.

## ca-and-type

get ike ca-and-type

**ca-and-type** Displays the supported certificate authorities (CAs) and certificate types.

## cert

```
get ike cert
set ike gateway name_str cert my-cert id_num
set ike gateway name_str cert peer-ca [id_num | all]
set ike gateway name_str cert peer-cert-type { pkcs7 | 509-sig }
```

**cert** Uses a digital certificate to authenticate the VPN initiator and recipient.

**gateway**  
***name\_str* cert** Specifies which certificates to use.

- **my-ca-hash** *name\_str*—Specifies the certificate authority (CA) DN hash.
- **my-cert** *name\_str*—Specifies a particular certificate when the local security device has multiple loaded certificates.
- **peer-ca** *name\_str*—Specifies a preferred certificate authority (CA).
- **peer-ca-hash** *name\_str*—Specifies the certificate authority (CA) distinguished name (DN) to be sent to the IKE peer in the certificate request (CERT REQ) payload. It can be followed by one of the following:
  - SHA-hash of a CA DN—used in place of the actual name of a DN, which can exceed the CLI length limit.
  - all—a CERT REQ payload is sent to the IKE peer for each CA in the trust store.
- **peer-cert-type** { **pkcs7** | **x509** }—Specifies a preferred type of certificate (PKCS7 or X509).

If you set the **peer-ca** and **peer-cert-type** values, the device inserts them in any certificate request it sends to the peer. If the peer has multiple local certificates, these values help the peer select a certificate.

**Note:** The security device does *not* use the **peer-ca** or **peer-cert-type** settings to check certificates received from the peer.

If possible, the peer should send a certificate issued by the **peer-ca** CA. However, if the peer sends a certificate issued by a different CA, the security device searches local memory for the certificate of the issuing CA; if the search is successful, the device accepts the peer certificate. If the search is unsuccessful, the device uses a certificate issued by a different CA.

**conn-entry**

get ike conn-entry

conn-entry      Displays the Connection Entry Table.

**cookies**

get ike cookies

cookies          Displays the cookie table and the total number of dead and active cookies.

**dialup**

set ike gateway *name\_str* dialup { *usr\_str* | *grp\_name* } [ ... ]

dialup            Identifies an IKE dialup user (*usr\_str*) or dialup group (*grp\_name*). Use this option to set up a dialup VPN. To specify a user's attributes, use the **set user** command. (To specify dialup group attributes, use the **set user-group** command.)

## dpd-liveness

```
get ike gateway name_str dpd-liveness
set ike gateway name_str dpd-liveness { always-send | hub-override | interval number1 |
 retry number2 }
unset ike gateway name_str dpd-liveness { always-send | interval | retry }
```

**dpd-liveness** Configures the device to use dead peer detection (DPD), a protocol used by security devices to verify the current existence and availability of IPsec peer devices. A device performs this verification by sending encrypted IKE Phase 1 notification payloads (R-U-THERE) to peers and waiting for DPD acknowledgements (R-U-THERE-ACK). (Note, if you set DPD in an AC-VPN profile and enable IKE heartbeat globally on the spoke, DPD does not take effect on the spoke.)

- **always-send**—Instructs the device to send DPD requests regardless of whether there is outgoing IPsec traffic to the peer.
- **hub-override** (AC-VPN only)—Specifies that all monitoring parameters configured locally take precedence over any monitoring parameters for that VPN coming from the hub in an AC-VPN profile. Monitoring parameters coming from the hub are overridden. When unset, locally configured monitoring parameters are saved in the local configuration, but ignored, and monitoring parameters from the hub are applied.
 

When you set **hub-override**, locally configured monitoring takes effect immediately. When you unset **hub-override**, the spoke requests a new profile from the hub and, upon receiving it, immediately applies any monitoring parameters in the profile.
- **interval *number1***—Specifies the DPD interval. This interval is the amount of time (expressed in seconds) the device allows to pass before considering a peer to be dead. The device considers the peer dead when all of the following conditions apply after the DPD interval expires:
  - The device received no matching R-U-THERE-ACK response after sending the configured number of transmitted R-U-THERE requests to the peer.
  - There was no incoming IPsec traffic from the peer on any of the IPsec SAs.
  - The device received no R-U-THERE request from DPD peer.
- **retry *number2*** The maximum number of times to send the R-U-THERE request before considering the peer to be dead.

## dynamic

```
set ike gateway name_str dynamic { ... } [...]
```

**dynamic** Specifies the identifier for the remote gateway with a dynamic IP address. Use this option to set up a VPN with a gateway that has an unspecified IP address.

- ***string*** A string you can use as a peer ID.
- **asn1-dn [ *container* ] [ *wildcard* ] *string*** The ASN1 domain name. The **container** switch treats *string* as a container. The **wildcard** switch treats *string* as a wild card.
- **fqdn** The fully qualified domain name (such as www.acme.com).
- **ip\_addr *string*** The IP address of the remote gateway interface.
- **u-fqdn *string*** The user fully qualified domain name (such as admin@acme.com).

## gateway

```
get ike gateway [name_str]
set ike gateway name_str { ... } [...]
unset ike gateway name_str { ... }
```

gateway Configures or displays settings for a remote tunnel gateway.

## heartbeat

```
get ike heartbeat
set ike gateway name_str heartbeat { ... }
unset ike gateway name_str heartbeat { ... }
```

heartbeat Specifies the IKE heartbeat protocol parameters. (Note, if Dead-Peer Detection (DPD) is set in an AC-VPN profile and you enable IKE heartbeat globally on the spoke, DPD does not take effect on the spoke.)

- **hello number**—Sets the IKE heartbeat protocol interval (in seconds).
- **hub-override** (AC-VPN only)—Specifies that all monitoring parameters configured locally take precedence over any monitoring parameters for that VPN coming from the hub in an AC-VPN profile. Monitoring parameters coming from the hub are overridden. When unset, locally configured monitoring parameters are saved in the local configuration, but ignored, and monitoring parameters from the hub are applied.  
When you set **hub-override**, locally configured monitoring takes effect immediately. When you unset **hub-override**, the spoke requests a new profile from the hub and, upon receiving it, immediately applies any monitoring parameters in the profile.
- **reconnect number**—Sets the quiet interval (in seconds) that elapses before the security device reconnects a failed tunnel.
- **threshold number**—Sets the number of retries before the security device considers the connection lost and removes all Phase 1 and Phase 2 keys related to this gateway.

## id-mode

```
get ike id-mode
set ike id-mode ip
set ike id-mode subnet
```

id-mode Defines the IKE ID mode in the Phase 2 exchange as either a host (IP) address or a gateway (subnet). If you use the **ip switch**, the device sends no Phase 2 ID. If you choose the **subnet switch**, the device sends proxy Phase 2 IDs. (Use the **ip switch** when setting up a VPN tunnel between a security device and a CheckPoint 4.0 device. Otherwise, use the **subnet switch**.)

## *ikeid-enumerator*

```
get ike ikeid-enumeration [table [detail src_ip]]
set ike ikeid-enumeration [threshold_number [interval_number]]
unset ike ikeid-enumeration
```

- ikeid-enumeration** Enables, disables, or displays anti-IKE ID enumeration information for IKE aggressive mode.
- ***threshold\_number***—Specifies the number of attack packets (first messages with an unknown IKE ID) in the specified interval before IKE starts to block the first IKE messages from this IP address. The range is 1 to 65535; the default is 30 packets.
  - ***interval\_number***—Specifies the period of time during which the first messages of IKE aggressive mode are blocked after an attack is detected. When the interval expires, the counter is reset and counting restarts. Interval is 10 to 65535 seconds; the default is 10 seconds.
  - ***table***—Displays the number of first messages with unknown IKE IDs.
  - ***detail***—Lists source IP address and interface name of blocked first messages with unknown IKE IDs.

## *initial-contact*

```
get ike initial-contact
set ike initial-contact [all-peers | single-gateway name_str]
unset ike initial-contact
```

- initial-contact** Determines how the security device performs initial contact with an IKE peer.
- Specifying **all-peers instructs** the security device to delete all SAs, then send an initial contact notification to each IKE peer.
  - Specifying **single-gateway *name\_str*** instructs the security device to delete all SAs associated with the specified IKE gateway, then send an initial contact notification.
- If you specify none of the above options, the security device sends an initial contact notification to all peers during the first IKE single-user session after a system reset.

## *initiator-set-commit*

```
get ike initiator-set-commit
set ike initiator-set-commit
unset ike initiator-set-commit
```

- initiator-set-commit** When the security device performs as an IKE initiator, sets the commit bit in the ISAKMP header. The party who sends the last message in the exchange does not use the new IPsec SA until it receives confirmation from the other party.

## local-id

```
set ike gateway name_str { ... } local-id id_str [...] { ... }
```

**local-id** Defines the IKE security identity of the local device. The device sends this ID to the remote gateway during IKE negotiation.

To instruct the security device to derive the IKE identity from the distinguished name in the local certificate, specify the following for **local-id** (including square brackets):

```
[DistinguishedName]
```

If there is more than one certificate on your security device, you may need to specify which certificate to use (for more information, see “cert” on page 290).

## member-sa-hold-time

```
get ike member-sa-hold-time
set ike member-sa-hold-time number
unset ike member-sa-hold-time
```

**member-sa-hold-time** The length of time (in minutes) the device keeps an unused SA allocated for a dialup user.

## nat-traversal

```
set ike gateway name_str nat-traversal udp-checksum
set ike gateway name_str nat-traversal keepalive-frequency number
unset ike gateway name_str nat-traversal [...]
```

**nat-traversal** Enables or disables IPsec NAT Traversal, a feature that allows transmission of encrypted traffic through a security device configured for NAT. The NAT Traversal feature encapsulates ESP packets into UDP packets. This prevents the NAT device from altering ESP packet headers in transit, thus preventing authentication failure on the peer security device.

- **udp-checksum**—Enables the NAT-Traversal UDP checksum operation (used for UDP packet authentication).
- **keepalive-frequency**—Specifies the frequency (in seconds) with which the security device sends NAT-traversal keepalive messages.

**Example 1:** The following command enables NAT traversal for a gateway named **mktg**:

```
set ike gateway mktg nat-traversal
```

**Example 2:** The following command sets the Keepalive setting to 25 seconds:

```
set ike gateway mktg nat-traversal keepalive-frequency 25
```

## ***outgoing-interface***

```
set ike gateway name_str { ... } outgoing-interface interface [...]
```

**outgoing-interface** Defines the interface through which the security device sends IKE traffic for this gateway.

**Example:** The following command specifies ethernet3 as the outgoing interface for an IKE gateway named **Paris\_Gateway** at IP address **2.2.2.2**. (Authentication uses a preshared key based on the word “scramble”, and the Phase 1 proposals are those for the “compatible” security level for Phase 1 negotiations.)

```
set ike gateway Paris_Gateway ip 2.2.2.2 outgoing-interface ethernet3 preshare
scramble sec-level compatible
```

## ***p1-max-dialgrp-sessions***

```
get ike p1-max-dialgrp-sessions
set ike p1-max-dialgrp-sessions count number
set ike p1-max-dialgrp-sessions percentage number
unset ike p1-max-dialgrp-sessions
```

**p1-max-dialgrp-sessions** Specifies or displays the allowed concurrent Phase 1 negotiations for dialup groups.

## ***p1-proposal***

```
get ike p1-proposal name_str [...]
set ike p1-proposal name_str [...] { ... }
unset ike p1-proposal name_str
```

**p1-proposal** Names the IKE Phase 1 proposal, which contains parameters for creating and exchanging session keys and establishing Phase 1 security associations (SAs).

- **dsa-sig** | **rsa-sig** | **preshare**—Specifies the method for authenticating the source of IKE messages. **preshare** refers to a preshared key, which is a key for encryption and decryption that both participants possess before beginning tunnel negotiations. **rsa-sig** and **dsa-sig** refer to two kinds of digital signatures, which are certificates that confirm the identity of the certificate holder. (The default method is **preshare**.)
- **group1** | **group2** | **group5** | **group14**—Identifies the Diffie-Hellman group, a technique that allows two parties to negotiate encryption keys over an insecure medium such as the Internet. The default group is **group2**.
- **esp**—Specifies Encapsulating Security Payload protocol, which provides encryption and authentication.
- **des** | **3des** | **aes128** | **aes192** | **aes256**—Specifies the encryption algorithm.

- **md5 | sha-1 | sha2-256**—Specifies the authentication (hashing) algorithm used in the ESP protocol. The default algorithm is SHA-1.
- The following parameters define the elapsed time between each attempt to renegotiate a Phase 1 security association. The minimum allowable lifetime is 180 seconds. The default lifetime is 28800 seconds.
  - **days** *number*
  - **hours** *number*
  - **minutes** *number*
  - **seconds** *number*

**Example:** The following command defines a Phase 1 proposal named **sf1** and includes the following configuration:

- Preshared key and a group 1 Diffie-Hellman exchange
- Encapsulating Security Payload (ESP) protocol using the 3DES and MD5 algorithms
- Lifetime of 3 minutes

```
set ike p1-proposal sf1 preshare group1 esp 3des md5 minutes 3
```

### ***p1-sec-level***

```
get ike p1-sec-level
```

p1-sec-level      Displays the predefined IKE Phase 1 proposals in descending order of security level.

### ***p2-sec-level***

```
get ike p2-sec-level
```

p2-sec-level      Displays the predefined IKE Phase 2 proposals in descending order of security level.

### ***p2-proposal***

```
get ike p2-proposal name_str [...]
set ike p2-proposal name_str [...] { ... }
set ike p2-proposal name_str
```

p2-proposal      Names the IKE Phase 2 proposal. This proposal defines parameters for creating and exchanging a session key to establish a security association (SA).

- **group1 | group2 | group5 | group14 | no-pfs**—Defines how the security device generates the encryption key. Perfect Forward Secrecy (PFS) is a method for generating each new encryption key independently from the previous key. Selecting **no-pfs** turns this feature off, so IKE generates the Phase 2 key from the key generated in the Phase 1 exchange. If you specify one of the Diffie-Hellman groups, IKE automatically uses PFS when generating the encryption key. The default is **group2**.

- **ah | esp**—In a Phase 2 proposal, identifies the IPsec protocol.
  - **esp [ des | 3des | aes128 | aes192 | aes256 ]**—Specifies Encapsulating Security Payload (ESP) protocol, which provides both encryption and authentication. Specifies the encryption algorithm used in ESP. (The default protocol is **des**.)
  - **ah**—Specifies Authentication Header (AH) protocol, which provides authentication only.
- **md5 | null | sha-1 | sha2-256**—Specifies the authentication (hashing) algorithm used in ESP or AH. The default algorithm is MD5 for non-FIPS mode, and SHA-1 is the default for FIPS mode. The **null** switch specifies no authentication.
 

**Note:** When configuring ESP, it is not advisable to set the **null** switch. Such a configuration may leave IPsec vulnerable to attack.
- The following parameters define the elapsed time between each attempt to renegotiate an SA. The minimum allowable lifetime is 180 seconds. The default lifetime is 28800 seconds.
  - **days** *number*
  - **hours** *number*
  - **minutes** *number*
  - **seconds** *number*
- **kbytes** *number*—Indicates the maximum allowable data flow in kilobytes before security renegotiates another SA. The default value is **0** (infinity).

**Example:** The following command specifies Phase 2 proposal **g2-esp-3des-null**.

- Group 2 Diffie-Hellman exchange
- ESP using 3DES without authentication
- Lifetime of 15 minutes

```
set ike p2-proposal g2-esp-3des-null group2 esp 3des null minutes 15
```

## *policy-checking*

```
get ike policy-checking
set ike policy-checking
unset ike policy-checking
```

**policy-checking** Checks to see if the policies of the two peers match before establishing a connection. Use policy checking when configuration on the peer gateways support multiple tunnels. Otherwise, the IKE session fails. You can disable policy checking when only one policy is configured between two peers.

## **preshare**

```
set ike p1-proposal name_str preshare { ... }
```

**preshare** Directs the device to use preshared key authentication for IKE Phase 1 negotiation. In this mode, both peer devices use a shared password to generate an encryption and decryption key.

```
set ike gateway name_str { ... } [...] preshare key_str
```

**preshare** Specifies the Preshared key (*key\_str*) used in the Phase 1 proposal. (If you use an RSA or DSA signature in the Phase 1 proposal, do not use this option).

**Example:** For an example of this option, see “Setting Up a Policy-Based VPN Tunnel” on page 304.

## **preshare-gen**

```
exec ike preshare-gen name_str usr_str
```

**preshare-gen** Generates an individual preshared key for a remote dialup user associated with a Group IKE ID user. The security device generates each preshared key from a seed value (specified in the command **set ike gateway**). After the device generates the preshared key, you can use it to set up a configuration for the remote user. (Remove any spaces.)

- *name\_str* is the IKE gateway name. To create such a gateway, use the **set ike gateway *name\_str*** command.
- *usr\_str* is the full IKE ID of an individual user, which belongs to a Group IKE ID user. To create such a user, use the **set user *name\_str* ike-id** command. The Group IKE ID user must be associated with a dialup user group to support a group of users.

**Example:** The following commands create a single group IKE ID user and assign the user to a dialup user group. Then they create VPNs and policies that allow dialup users with matching partial IKE ID values to establish secure communication through the security device.

- The name of the group IKE ID user is User1, with partial IKE identity of acme.com.
- The number of dialup users that can share this user’s IKE identity is 10.
- The dialup user group is Office\_1.
- The seed value for creating the preshared key is jk930k.
- The Phase 1 IKE gateway defined for the server side is Corp\_GW.
- The Phase 2 VPN defined for the server side is Corp\_VPN.
- The Phase 1 IKE gateway defined for the client side is Office\_GW.
- The Phase 2 VPN defined for the client side is Office\_VPN.
- The individual user’s full IKE identity is chris@acme.com.

- The trusted server that dialup users access from the outside is a Web server with IP address 1.1.110.200.

```
set user User1 ike-id u-fqdn acme.com share-limit 10
set user-group Office_1 user User1
set ike gateway Corp_GW dialup Office_1 aggressive seed-preshare jk930k
proposal pre-g2-3des-md5
set vpn Corp_VPN gateway Corp_GW tunnel proposal g2-esp-3des-md5
set address trust http_server 1.1.110.200/32
set policy incoming "dial-up vpn" http_server any tunnel vpn Corp_VPN
```

To generate the preshared key for chris@acme.com:

```
exec ike preshare-gen Corp_GW chris@acme.com
```

---

**NOTE:** For this example, assume that this command generates c5d7f7c1806567bc57d3d30d7bf9b93baa2adcc6.

---

***On the client side:***

```
set ike gateway Office_GW address 10.1.10.10 aggressive local-id chris@acme.com
preshare c5d7f7c1806567bc57d3d30d7bf9b93baa2adcc6 proposal
pre-g2-3des-md5
set vpn Office_VPN gateway Office_GW tunnel proposal g2-esp-3des-md5
set address untrust http_server 1.1.110.200/24
set address trust "inside any" 2.2.2.2/24
set policy outgoing "inside any" http_server any tunnel vpn Office_VPN
```

## ***proposal***

```
set ike gateway name_str { ... } [...] proposal name_str1 [name_str2] [name_str3] [name_str4]
```

**proposal** Specifies the name (*name\_str*) of a proposal. You can specify up to four Phase 1 proposals.

**Example:** For an example of this option, see “Setting Up a Policy-Based VPN Tunnel” on page 304.

## ***respond-bad-spi***

```
get ike respond-bad-spi
set ike respond-bad-spi [number]
unset ike respond-bad-spi
```

**respond-bad-spi** Responds to packets with bad security parameter index (SPI) values. The specified *number* value is the number of times to respond to bad SPIs per gateway.

### **responder-set-commit**

```
get ike responder-set-commit
set ike responder-set-commit
unset ike responder-set-commit
```

**responder-set-commit** Directs the security device to set the commit bit in the ISAKMP header when the device acts as an IKE responder. The peer that sends the last message in the exchange does not use the new IPsec SA until it receives information from the other peer.

### **responder-mode**

```
set ike responder-mode
unset ike responder-mode
```

**responder-mode** Enables the security device to act as a responder but not as an initiator, when performing IKE negotiation.

### **sec-level**

```
set ike gateway name_str { ... } [...] sec-level { ... }
```

**sec-level** Specifies which predefined security proposal to use for IKE. The **basic** proposal provides basic-level security settings. The **compatible** proposal provides the most widely used settings. The **standard** proposal provides settings recommended by Juniper Networks.

**Example:** The following command specifies the predefined security proposal *compatible*:

```
set vpn Corp_VPN gateway Corp_GW sec-level compatible
```

### **seed-preshare**

```
set ike gateway name_str { ... } [...] seed-preshare key_str
```

**seed-preshare** Specifies a seed value (*key\_str*) for a user group with Preshared Key configurations. Such a configuration performs IKE authentication for multiple dialup users, each with an individual preshared key, without having a separate configuration for each user. Instead, use the seed to generate the preshared key with the **exec ike preshare-gen** command.

**Example:** The following commands configure IKE authentication for multiple dialup users in a user group:

- Interface **ethernet1** bound to the **Trust** zone and interface **ethernet3** bound to the **Untrust** zone
- Dialup user named **User2**, placed in a user group named **office\_2**
- Gateway configuration for **office\_2**, with a preshared key seed value of **jk930k**
- Security policy for all dialup users with the partial IKE identity specified for **User2**

```

set interface ethernet1 zone trust
set interface ethernet1 ip 10.1.1.1/24
set interface ethernet3 zone untrust
set interface ethernet3 ip 1.1.1.1/24
set address trust web1 10.1.1.5/32
set user User2 ike-id u-fqdn juniper.net share-limit 10
set user-group office_2 user User2
set ike gateway Corp_GW dialup office_2 aggressive seed-preshare jk930k
 sec-level compatible
set vpn Corp_VPN gateway Corp_GW sec-level compatible
set policy top from untrust to trust "dial-up vpn" web1 http tunnel vpn Corp_VPN
save

```

### ***single-ike-tunnel***

```

set ike single-ike-tunnel name_str
unset ike single-ike-tunnel name_str

```

`single-ike-tunnel` Specifies a single Phase 2 SA for all policies to a particular remote peer gateway.

**Example:** The following command specifies a Phase 2 SA for all policies to the peer gateway gw1:

```
set ike single-ike-tunnel gw1
```

### ***soft-lifetime-buffer***

```

get ike soft-lifetime-buffer
set ike soft-lifetime-buffer number

```

`soft-lifetime-buffer` Sets a time interval (in seconds) before the current IPsec SA key lifetime expires. When this interval is reached, the device initiates the rekeying operation.

### ***xauth***

```

set ike gateway name_str xauth [...]
set ike gateway ikev2 name_str xauth [...]
unset ike gateway name_str xauth [...]
unset ike gateway ikev2 name_str xauth [...]

```

- xauth** Enables XAuth authentication for the specified IKE gateway configuration.
- **bypass-auth**—Instructs the security device (acting as an XAuth server) to perform only XAuth mode-config (which assigns the XAuth client an IP address) DNS, and WINS server settings. XAuth clients are not required to authenticate themselves.
  - **client**—Specifies that the security device is an XAuth client. You can specify the following authentication types:
    - **any**—Instructs the device to allow any authentication type.
    - **chap**—Instructs the device to allow Challenge Handshake Authentication Protocol (CHAP) only.
    - **securid**—Instructs the device to allow authentication via SecurID only.
  - **username**—Specifies the username for the XAuth client to use on the XAuth server.
  - **password** setting specifies the password for the XAuth client to use on the XAuth server.
  - **do-edipi-auth**—Enables RADIUS authentication based on Electronic Data Interexchange Personal Identifier (EDIPI). With this form of authentication, a user inserts a Common Access Card (CAC) that contains a PKI certificate. Each PKI certificate has an EDIPI ID, which identifies the user.
  - **server**—Specifies the object name of the external server that performs the XAuth authentication.
    - **chap**—Instructs the device to use Challenge Handshake Authentication Protocol (CHAP).
    - **query-config**—Instructs the device to query the client configuration from the server.
  - **accounting**—Specifies the accounting details for the specific IKE gateway.
    - **off**—Disables accounting for the specific IKE gateway. By default, accounting for the specific IKE gateway is enabled. If there is no specified accounting server, the accounting request is sent to the authentication server.
    - **server name\_str**—Specifies an accounting server for the specific IKEv2 gateway. By default, no separate accounting server is configured.

**Example:** The following example configures an XAuth client.

- Gateway *kg1*
- Any authentication type allowed
- Username *kgreen* and password *pubs123*

```
set ike gateway kg1 xauth client any username kgreen password pubs123
```

## Defaults

*Main mode* is the default method for Phase 1 negotiations.

The default time intervals before the device renegotiates another security association are *28,800* seconds in a Phase 1 proposal, and *3600* seconds in a Phase 2 proposal.

The default ID mode is *subnet*. (Changing the ID mode to IP is only necessary if the data traffic is between two security gateways, one of which is a CheckPoint 4.0 device.)

The default soft-lifetime-buffer size is *10* seconds.

By default, the single-ike-tunnel flag is *not* set.

## Setting Up a Policy-Based VPN Tunnel

To create a policy-based VPN tunnel for a remote gateway with a static IP address:

1. Bind interfaces to zones and assign them IP addresses:

```
set interface ethernet1 zone trust
set interface ethernet1 ip 10.1.1.1/24
set interface ethernet3 zone untrust
set interface ethernet3 ip 1.1.1.1/24
```

2. Set the addresses for the end entities beyond the two ends of the VPN tunnel:

```
set address trust host1 10.1.1.5/32
set address untrust host2 10.2.2.5/32
```

3. Define the IKE Phase 1 proposal and Phase 2 proposal. If you use the default proposals, you do not need to define Phase 1 and Phase 2 proposals.

4. Define the remote gateway:

```
set ike gateway gw1 address 2.2.2.2 main outgoing-interface ethernet3
preshare screen proposal pre-g2-3des-sha
```

5. Define the VPN tunnel as AutoKey IKE:

```
set vpn vpn1 gateway gw1 proposal g2-esp-des-md5
```

6. Set a default route (both the Trust and Untrust zones are in the trust-vr routing domain):

```
set vrouter trust-vr route 0.0.0.0/0 interface ethernet3 gateway 1.1.1.250
```

7. Set outbound and inbound policies:

```
set policy from trust to untrust host1 host2 any tunnel vpn vpn1
set policy from untrust to trust host2 host1 any tunnel vpn vpn1
```

To set up a VPN tunnel for a dialup user with IKE:

1. Bind interfaces to zones and assign them IP addresses.
2. Define the protected address that you want the dialup user to be able to access through the tunnel. (See **set address** in “address” on page 23.)
3. Define the user as an IKE user. (See **set user** in “user” on page 685.)

4. Define the IKE Phase 1 proposal, Phase 2 proposal, and remote gateway. (**Note:** If you use the default proposals, you do not need to define a Phase 1 or Phase 2 proposal.)
5. Define the VPN tunnel as AutoKey IKE. (See **set vpn** in “vpn” on page 701.)
6. Set a default route (both the Trust and Untrust zones are in the trust-vr routing domain).
7. Define an incoming policy, with *dial-up vpn* as the source address and the VPN tunnel you configured in step 5.



# ike-cookie

Use the **ike-cookie** commands to remove Internet Key Exchange (IKE)-related cookies from the security device.

## Syntax

---

### **clear**

```
clear [cluster] |
 ike-cookie
 {
 ip_addr |
 all |
 ikeid-enumeration table [ip_addr] |
 }
```

## Keywords and Variables

---

### **Variable Parameter**

```
clear cluster ike-cookie ip_addr
clear ike-cookie ip_addr
```

*ip\_addr* Directs the security device to remove cookies based on a IP address (*ip\_addr*).

**Example:** The following command removes all cookies based on the IP address 10.1.10.10:

```
clear ike-cookie 10.1.10.10
```

### **all**

```
clear cluster ike-cookie all
clear ike-cookie all
```

**all** Specifies all cookies for IKE Phase 1 Security Associations (SAs).

### ***cluster***

```
clear cluster ike-cookie all
clear cluster ike-cookie ip_addr
```

**cluster** Propagates the **clear** operation to all other devices in an NSRP cluster.

### ***ikeid-enumeration***

```
clear ike-cookie ikeid-enumeration table [ip_addr]
```

**ikeid-enumeration table** Clears the table, or a specified entry in the table, of anti-IKE ID enumeration information for IKE aggressive mode.

- **table**—Maintains the current status. Each entry in the table contains the source IP address of an attack message and indicates the total number of attacks from that source.
- ***ip\_addr***—Specifies an entry in the IKE ID enumeration table.

### ***ip\_addr***

```
clear ike-cookie ip_addr
```

***ip\_addr*** Specifies an IKE Phase 1 Security Association (SA).

# infranet

Use the **infranet** commands to set up a security device (Infranet Enforcer) to work with an Infranet Controller in a Unified Access Control (UAC) deployment.

For more information about deploying UAC, see the *Unified Access Control Administration Guide*.

## Syntax

---

### **exec**

```
exec infranet controller
{
 connect | disconnect | IP ip_addr keepalive;
 check-sessions;
 enforcer-id string;
 notify-prefix string;
 notify | unnotify
 {
 auth-expire | deny | drop
 }
}
```

---

**NOTE:** If you run an **exec infranet controller disconnect** command, the Infranet Enforcer does not attempt to automatically connect with the Infranet Controller. To reconnect, you must run an **exec infranet controller connect** command or restart the Infranet Enforcer.

---

### **get**

```
get infranet { controller [name string] | enforcer }
```

### **set**

```
set infranet
{
 controller
 {
 contact-interval number |
 name string
 }
 [
```

```

 ca-idx number |
 cert-subj string |
 host-name string [port number] |
 password string |
 src-interface interface |
 timeout number
 url string
] |
 timeout action { close | no-change | open } |
} |
enforcer mode test |
policy command string
}

```

## Keywords and Variables

|                      |                                                                                                                                                     |
|----------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------|
| <i>interface</i>     | Specifies the name of the interface.                                                                                                                |
| <i>number</i>        | Defines the port number or number of seconds for a particular argument.                                                                             |
| <i>string</i>        | Specifies the name of the Infranet Enforcer or a policy command.                                                                                    |
| <i>enforcer-id</i>   | Specifies the ID assigns to the Infranet Enforcer during the connection between session. The Infranet Enforcer ID is valid only during the session. |
| <i>notify-prefix</i> | Specifies the prefix for notifications that the Infranet Enforcer sends.                                                                            |
| <i>auth-expire</i>   | Sets the Infranet Enforcer to send a notification when an auth table entry expires.                                                                 |
| <i>deny</i>          | Sets the Infranet Enforcer to send a notification when a packet is denied because of an infranet auth policy failure.                               |
| <i>drop</i>          | Sets the Infranet Enforcer to send a notification when a packet is dropped.                                                                         |

## policy

set infranet policy command *string*

command *string* The policy command pushes the access policies from the Infranet Controller to the security device (Infranet Enforcer).

- *string*—Specifies the policy name.

**Example** Use the dynamic command designator (**-n**) command to view the access policies in the Infranet Enforcer. For example:

**set -n infranet policy command "get all"**

Infranet policy command: received, calling jps\_exec:

```
get all
```

```
id=1 192.168.2.0/24:* * allow
```

```
id=2 10.25.25.2:*;10.25.25.5:* * allow
```

## controller

get infranet controller name *string*  
 set infranet controller name *string* [ ... ]  
 unset infranet controller name *string* [ ... ]

|                    |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
|--------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| connect            | Reestablishes a connection with the Infranet Controller.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| disconnect         | Removes the connection to the currently connected Infranet Controller.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| contact-interval   | Specifies how often the Infranet Enforcer pings the Infranet Controller for connectivity. The default value is 10 seconds; the range is 3-300 seconds.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| IP <i>ip_addr</i>  | Specifies the Infranet Controller.<br>The Infranet Controller periodically issues <code>keepalive</code> command to the Infranet Enforcer. If the Infranet Enforcer does not receive a <b>keepalive</b> command within the timeout period, the Infranet Enforcer considers the connection to be down.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| name <i>string</i> | Specifies the name of the Infranet Controller and must be fewer than 32 characters in length. <ul style="list-style-type: none"> <li>■ <code>ca-idx</code> number is the number for the certificate authority (CA) certificate index.</li> <li>■ <code>cert-subj</code> <i>string</i> is the string subject that matches the certificate.</li> <li>■ <code>host-name</code> <i>string</i> [ <i>port number</i> ] is the hostname or IP address of the Infranet Controller. The port number must be <b>11122</b>.</li> <li>■ <code>password</code> <i>string</i> is the NetScreen Address Change Notification (NACN) password of the Infranet Controller.</li> <li>■ <code>src-interface</code> <i>interface</i> identifies the outgoing interface.</li> <li>■ <code>timeout</code> <i>number</i> defines the timeout limit for idle Infranet Controller links. The default timeout is 60 seconds; the range is 1-10,000 seconds.</li> <li>■ <code>url</code> <i>string</i> is the redirect URL (1-512 characters) to which you want the security policy to redirect HTTP traffic. If you do not specify a URL, the security device defaults to the currently connected Infranet Controller (the default redirect URL is not displayed).<br/>Use the following format for the URL within double quotes:<br/>           “<b>http://IP or domain_name/url_path/?target= %dest-url%</b>”<br/>           If you specified <code>url</code> <i>string</i>, configure a redirect <code>infranet-auth</code> policy (see “policy” on page 539). The security device redirects HTTP traffic to an external Web server instead of to the Infranet Controller. For more information about using the URL string to redirect HTTP traffic, see the <i>Unified Access Control Administration Guide</i>.</li> </ul> |
| timeout action     | Specifies what action to take when the Infranet Controller times out: <ul style="list-style-type: none"> <li>■ <b>open</b> allows existing and new session traffic as allowed by infranet policies.</li> <li>■ <b>no-change</b> preserves existing connections and dynamic configurations such as tunnels, but new sessions require authentication.</li> <li>■ <b>close</b> removes existing sessions and dynamic configuration and blocks further traffic.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| check-sessions     | Configures the security device to reevaluate <code>infranet-auth</code> policies on all sessions associated with <code>infranet-auth</code> table entries. Any sessions no longer valid are terminated.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |

**Example:** The following command displays information about the Infranet Controller:

**get infranet controller name juniper-ic**

Name: juniper-ic  
 Host: 10.150.43.126  
 Connected to Infranet Controller 0 times  
 Infranet Controller Connection State:  
 SSL: Closed  
 SSH: Closed  
 (No Keepalives received from Infranet Controller via SSH)  
 (SSH V2 is active, enabled, and not ready for connections)  
 Port: 11122  
 Interface:  
 Timeout: 60 seconds  
 Full Subject Name of IC Cert:  
 CA Hash:  
 Selected CA:  
 Redirect URL:

## ***enforcer***

```
get infranet enforcer
set infranet enforcer mode test
unset infranet enforcer mode test
```

**mode test**            Places the Infranet Enforcer in Test mode, where traffic is always allowed and policies are not enforced. However, the permit or deny decision associated with the infranet-auth policies is logged.

The **unset** command turns off the Test mode and places the Infranet Enforcer in Regular mode. In this default mode, the infranet-auth policies are applied and logged based on the auth table entries.

**Example:** The following command displays information about the Infranet Enforcer:

**get infranet enforcer**

**Mode: Regular**

In this mode, the infranet-auth policies are enforced and logged based on the auth table entries.

# interface

Use the **interface** commands to define or display interface settings for a security device.

Interfaces are physical or logical connections that handle network, virtual private network (VPN), high availability (HA), and administrative traffic. For a description of the interfaces you can configure on a security device, see “Interfaces” on page 771.

## Syntax

---

### *clear*

```
clear interface interface
{
 dot1x statistics |
 extensive |
 frame-relay stats |
 mlfr-uni-nni stats |
 status-change
}
```

### *exec*

```
exec
{
 backup interface interface { failover | revert } |
 dhcp client interface renew |
 interface
 {
 bert-test [start | stop] |
 ext-loop-back-test [interval number | round number [interval | number]] |
 all | interface
 {
 phy setting force-sync |
 bert-test [start | stop]
 }
 }
}
```

**get**

```

get interface
{
 all |
 interface
 [
 association [mac_addr] |
 basic |
 bri-options |
 clocking |
 counter |
 dhcp
 {
 client |
 relay |
 server { ip { allocate | idle } | option }
 } |
 dip { detail } |
 dot1x [statistics] |
 e1-options |
 e3-options |
 extensive |
 hold-time
 isdn [q921 { statistics | status } q931 { statistics | status }] |
 mac-table |
 monitor track-ip [ip] |
 mip |
 ppp |
 protocol
 {
 ospf |
 rip [neighbor ip_addr] |
 igmp
 [
 config |
 group [ip_addr [source] [all]] |
 source |
 statistic [all] |
]
 pim [statistics] |
 vrrp
 }
 frame-relay { lmi | pvc | statistics | ndp } |
 mlfr-uni-nni { config | members | statistics } |
 screen |
 secondary [ip_addr] |
 serial-options |
 shdsl-options { basic | statistics | training-status } |
 statistics |
 t1-options |
 t3-options |
 track-ip [ip]
 training-status |
]
}

```

**set**

The **set interface** command varies on different platforms. Table 1 lists the supported interfaces:

**Table 1: Supported Interfaces**

| <b>Interface</b>         | <b>See</b> |
|--------------------------|------------|
| Layer 3                  | page 316   |
| ADSL                     | page 318   |
| ISDN                     | page 319   |
| Cisco HDLC encapsulation | page 320   |
| Dot1x                    | page 320   |
| E1                       | page 320   |
| E3                       | page 321   |
| Frame Relay              | page 321   |
| SHDSL                    | page 322   |
| PPP                      | page 323   |
| Multilink Frame Relay    | page 323   |
| Multilink PPP            | page 324   |
| Serial Interfaces        | page 324   |
| T1 Interface             | page 325   |
| T3 Interface             | page 326   |
| Subinterfaces            | page 326   |
| V.92 Modem               | page 324   |
| Wireless                 | page 326   |
| DHCP Relay/Server        | page 327   |
| DHCP Client              | page 327   |
| IP tracking              | page 328   |
| Loopback                 | page 328   |
| Monitoring               | page 328   |
| High Availability        | page 328   |
| OSPF                     | page 329   |
| RIP                      | page 329   |
| BGP                      | page 328   |
| IGMP router              | page 330   |
| IRDP                     | page 330   |
| Policy based routing     | page 331   |
| Tunnel                   | page 331   |
| VLAN                     | page 332   |
| VRRP                     | page 332   |

**set (Layer 3 Interfaces)**

```

set interface interface
{
 backup
 {
 activation-delay number |
 auto |
 deactivation-delay number |
 interface interface type { route vrouter string ip_add/mask | track-ip | tunnel-if }
 } |
 bandwidth { egress mbw number | ingress mbw number } |
 description string |
 dhcp client
 [enable |
 settings
 {
 admin-preference number |
 autoconfig |
 client-id string |
 lease number |
 server ip_addr |
 update-dhcpserver |
 vendor string
 }
] |
 dhcp server
 {
 auto |
 config
 { next-server-ip [ip ip_addr | option66] | updatable [src-interface] } |
 disable |
 enable |
 ip ip_addr [mac mac_addr | to ip_addr] |
 option
 {
 custom number { integer number | ip ip_addr | string string } |
 dns1 | dns2 | dns3 | gateway | netmask | news | nis1 | nis2 | pop3 | smtp |
 wins1 | wins2 { ip_addr } |
 domainname | nistag { string } |
 lease number
 } |
 service
 }
 [ext ip ip_addr/mask] dip
 {
 interface-ip incoming |
 id_num
 {
 ip_addr1 [ip_addr2] |
 shift-from ip_addr3 [to ip_addr4 [ip_addr5]]
 }
 [fix-port | incoming]
 }
 }
 g-arp |
 gateway ip_addr [no-default-route] |
 group |

```

```

ip { ip_addr/mask | manageable } |
manage
 { ident-reset | nsmgmt | mtrace | ping | snmp | ssh | ssl | telnet | web } |
manage-ip ip_addr |
mip ip_addr host ip_addr [netmask mask] [vrouter name_str] |
modem
 {
 idle-time number |
 interval number |
 isp string
 {
 account login string password string |
 primary-number number_string [alternative-number number_string] |
 priority number
 } |
 isp-failover
 {
 holddown number |
 type route vrouter vrouter_string ip_add/mask
 } |
 retry number |
 settings string { active | init-strings string }
 speed number
 }
monitor track-ip
 [
 dynamic | ip | ip ip_addr
 [interval number | threshold number | weight number]
]
mtrace |
mtu number |
nat |
nsgp [enforce-ipsec] |
ntp-server |
pbr [string] |
phy
 {
 auto |
 full { 10mb | 100mb } |
 half { 10mb | 100mb } |
 holddown number |
 link-down
 } |
port port_name |
pmtu ipv4 |
protocol
 {
 ospf |
 rip [neighbor ip_addr] |
 igmp
 [
 config |
 group [ip_addr [source] [all]] |
 source |
 statistic [all] |
]
]
pim [statistics]

```

```

 } |
 proxy dns |
 route |
 route-deny |
 tag id_num zone zone |
 vip ip_addr | interface-ip [+] port_num [name_str ip_addr [manual]] |
 webauth [ssl-only] |
 webauth-ip ip_addr |
 xg-round-robin |
 zone zone |
 }

```

### set (Layer 2 Interfaces)

```

set interface interface
{
 description string |
 manage { ident-reset | nsmgmt | ping | snmp | ssh | ssl | telnet | web } |
 phy
 {
 auto |
 full { 10mb | 100mb } |
 half { 10mb | 100mb } |
 holddown number |
 link-down
 } |
 webauth
}

```

### set (ADSL Interface)

```

set interface interface
{
 description string |
 phy operating-mode
 {
 adsl2 |
 adsl2plus |
 annex-b-non-ur2 |
 annex-b-ur2 |
 ansi |
 auto |
 etsi |
 gdmtd |
 gdmtdbis |
 itu-dmt |
 t1.413
 }
 pvc vpi_num vci_num
 [mux { vc | llc }]
 [protocol { routed | bridged }]
 [zone zone_name]
}

```

**set (bri0/0, bri1/0, or bri2/0)**

```

set interface interface
{
 alternative-number string |
 backup
 {
 activation-delay number |
 auto |
 deactivation-delay number |
 interface interface type{ route vrouter string ip_add/mask | track-ip | tunnel-if }
 } |
 bri-options
 {
 idle-cycle-flag { flags | ones } |
 loopback { local | remote }
 } |
 description string |
 dialer-enable |
 disable |
 encaps { mlppp | ppp } |
 hold-time { down | up } |
 idle-time number |
 interval number |
 isdn
 {
 calling-number string |
 leased-line 128Kbps |
 send-complete |
 spid1 string |
 spid2 string |
 switch-type { att5e | etsi | ins-net | ni1 | ntdms100 } |
 t310-value number |
 tei-negotiation { first-call | power-up }
 } |
 load-threshold number |
 monitor track-ip
 [
 dynamic |
 ip [ip_addr [interval number | threshold number | weight number]]
 threshold number |
 weight number |
]
 mtu number |
 pmtu ipv4 |
 primary-number string |
 proxy dns |
 retry number |
 zone zone |
}

```

**set (Cisco HDLC Encapsulation for WAN Interfaces)**

```

set interface interface
{
 description string |
 encaps cisco-hdlc |
 ip unnumbered interface src interface |
 ip { ip_add mask | manageable } |
 keepalives
 {
 interval seconds |
 down-count number |
 up-count number
 }
}

```

**set (dot1x)**

```

set interface interface dot1x
[
 auth-server string |
 control-mode { virtual | interface } |
 max-user number |
 port-control { force-unauthorized | auto } |
 reauth-period number |
 retry [count | period] |
 silent-period number
]

```

**set (E1 Interfaces)**

```

set interface interface
{
 bandwidth { egress mbw number | ingress mbw number } |
 bundle bundle
 clocking { external | internal } |
 description string |
 disable
 e1-options
 {
 bert-algorithm name_str |
 bert-error-rate rate |
 bert-period seconds |
 fcs { 16 | 32 } |
 framing { g704 | g704-no-crc4 | unframed } |
 idle-cycle-flag { flags | ones } |
 invert-data |
 loopback { local | remote } |
 start-end-flag { filler | shared } |
 timeslots timeslots 2-32
 } |
 encaps { cisco-hdlc | frame-relay | ppp }
 hold-time { down milliseconds | up milliseconds }
 monitor track-ip
 [
 dynamic |
 ip [ip_addr [interval number | threshold number | weight number]]
 threshold number |

```

```

 weight number |
]
 mtu size
 pmtu ipv4
 zone zone
}

```

### set (E3 Interfaces)

```

set interface interface
{
 bandwidth { egress mbw number | ingress mbw number } |
 bundle bundle |
 clocking { external | internal } |
 description string |
 disable
 e3-options
 {
 bert-algorithm name_str |
 bert-error-rate rate |
 bert-period seconds |
 compatibility-mode { digital-link subrate rate | kentrox subrate rate } |
 fcs { 16 | 32 } |
 framing { g751 | unframed } |
 idle-cycle-flag { flags | ones } |
 loopback { local | remote } |
 payload-scrambler |
 start-end-flag { filler | shared } |
 } |
 encaps { cisco-hdlc | frame-relay | ppp }
 hold-time { down milliseconds | up milliseconds }
 monitor track-ip
 [
 dynamic |
 ip [ip_addr [interval number | threshold number | weight number]]
 threshold number |
 weight number |
]
 mtu size
 pmtu ipv4
 zone zone
}

```

### set (Frame Relay)

```

set interface interface
{
 encaps frame-relay |
 description string |
 ip unnumbered interface src interface /
 frame-relay
 {
 lmi
 {
 n391-dte number |
 n392-dte number |
 n393-dte number |
 }
 }
}

```

```

 t391-dte seconds |
 no-keepalive |
 type { ansi | itu }
 }
}
set interface subinterface
{
 frame-relay
 {
 dlci id_num |
 inverse-arp |
 } |
 zone zone |
 ip ip_add
}

```

### **set (SHDSL Interface)**

```

set interface interface
{
 bandwidth { egress mbw number | ingress mbw number } |
 description string |
 phy operating-mode
 {
 annex { annex-a | annex-b } |
 line-rate { options } |
 loopback { local | remote } |
 oam-liveness { down-count-cells number | up-count-cells number } |
 oam-period number |
 snr-margin { current number | snext number } |
 }
 pvc vpi_num vci_num
 [mux { vc | llc }]
 [protocol { routed | bridged }]
 [zone zone_name]
}

```

**set (Multilink Frame Relay)**

```

set interface bundle
{
 bundle-ID string |
 drop-timeout milliseconds |
 encapsulation mlfr-uni-nni |
 frame-relay lmi
 {
 n391-dte number | n392-dte number | n393-dte number | t391-dte seconds |
 no-keepalive |
 type { ansi | itu }
 } |
 minimum-links number |
 zone zone /
 ip ip_add
}
set interface bundle_subinterface
{
 frame-relay
 {
 dlci id_num |
 inverse-arp |
 } |
 zone zone
}
set interface interface
{
 bundle bundle |
 mlfr-uni-nni
 {
 acknowledge-retries number |
 acknowledge-timer milliseconds |
 fragment-threshold bytes |
 hello-time milliseconds
 }
}

```

**set (PPP)**

```

set interface interface
{
 description string |
 encapsulation ppp |
 ip { manageable | ip_add | unnumbered interface src interface }
 keepalives
 {
 interval seconds |
 down-count number |
 }
}

```

**set (Multilink PPP)**

```

set interface bundle
{
 drop-timeout milliseconds |
 encap mlppp |
 fragment-threshold bytes |
 minimum-links number |
 mrru bytes |
 short-sequence |
 zone zone
}

set interface interface
{
 bundle bundle |
 encap ppp |
 ip unnumbered interface src interface |
 keepalives
 {
 interval seconds |
 down-count number |
 }
}

```

**set (V.92 Modem Interface)**

```

set interface interface
{
 description string |
 modem aux enable
 modem idle-time number |
 modem interval number |
 modem retry number |
 modem settings name_str { active | init-strings name_str }
 modem speed number |
 modem isp-failover
 { holddown number | type { route | track-ip | vpn } vrouter name_str } |
 modem isp name_str
 {
 account login name_str password pass_str |
 primary-number string [alternative-number string]
 priority number
 }
}

```

**set (Serial Interfaces)**

```

set interface interface
{
 description string |
 disable |
 hold-time { down milliseconds | up milliseconds } |
 encapsulation frame-relay |
 serial-options
 {
 clock-rate rate |
 clocking-mode { dce | internal | loop } |
 }
}

```

```

dce-options
{
 cts { assert | de-assert | normal } |
 dcd { assert | de-assert | normal } |
 dce-loopback-override |
 dsr { assert | de-assert | normal } |
 dtr { ignore | normal | require } |
 ignore-all |
 rts { ignore | normal | require } |
 tm { ignore | normal | require }
} |
dte-options
{
 cts { ignore | normal | require } |
 dcd { ignore | normal | require } |
 dsr { ignore | normal | require } |
 dtr { assert | auto-synchronize | de-assert | normal } |
 ignore-all |
 rts { assert | de-assert | normal } |
 tm { ignore | normal | require }
} |
encoding { nrz | nrzi } |
loopback { dce-local | local | remote } |
transmit-clock [invert]
}

```

## set (T1 Interfaces)

```

set interface interface
{
 backup
 {
 activation-delay number |
 auto |
 deactivation-delay number |
 interface interface type{ route vrouter string ip_add/mask | track-ip | tunnel-if }
 } |
 description string |
 disable |
 clocking { external | internal } |
 hold-time { down milliseconds | up milliseconds } |
 t1-options
 {
 bert-algorithm name_str |
 bert-error-rate rate |
 bert-period seconds |
 buildout { 0-132 | 133-265 | 266-398 | 399-531 | 532-655 } |
 byte-encoding { nx56 | nx64 } |
 fcs { 16 | 32 } |
 framing { esf | sf } |
 idle-cycle-flag { flags | ones } |
 invert-data |
 line-encoding { ami | b8zs } |
 loopback { local | payload | remote } |
 remote-loopback-respond |
 start-end-flag { filler | shared } |

```

```

 timeslots timeslots
 }

```

### **set (T3 Interfaces)**

```

set interface interface
{
 description string |
 disable |
 clocking { external | internal } |
 hold-time { down milliseconds | up milliseconds } |
 t3-options
 {
 bert-algorithm name_str |
 bert-error-rate rate |
 bert-period seconds |
 cbit-parity |
 compatibility-mode
 {
 adtran subrate rate |
 digital-link subrate rate |
 kentrox subrate rate |
 larscom subrate rate |
 verilink subrate rate
 } |
 fcs { 16 | 32 } |
 feac-loop-respond
 idle-cycle-flag { flags | ones } |
 long-buildout
 loopback { local | payload | remote } |
 payload-scrambler |
 start-end-flag { filler | shared }
 }
}

```

### **set (Wireless Interfaces)**

```

set interface interface
{
 description string |
 shutdown
 wlan { 0 | 1 | both }
}

```

### **set (Subinterfaces)**

```

set interface interface.id_num
{
 encaps pppoe |
 tag number zone zone
}

```

**set (DHCP Relay/Server)**

```

set interface interface dhcp
{
 relay { server-name { name_str | ip_addr } | service | vpn } |
 server
 {
 enable | auto | disable |
 ip ip_addr { mac mac_addr | to ip_addr } |
 option
 {
 custom id_num { integer number | ip ip_addr | string string } |
 dns1 | dns2 | dns3 | gateway | news | nis1 | nis2 | pop3 | smtp
 { ip_addr } |
 domainname name_str |
 lease number |
 netmask mask |
 nistag name_str |
 wins1 ip_addr |
 wins2 ip_addr |
 } |
 service
 }
}

```

**set (DHCP Client)**

```

set interface interface dhcp client
{
 enable |
 settings
 {
 autoconfig |
 client-id string |
 lease number |
 server ip_addr |
 update-dhcpserver |
 vendor id_str
 }
}

```

**set (High Availability)**

```

set interface { ha | ha1 | ha2 }
{
 bandwidth number |
 phy
 {
 auto |
 full { 10mb | 100mb } |
 half { 10mb | 100mb } |
 holddown number |
 link-down
 } |
}

```

**set (IP Tracking)**

```

set interface interface track-ip
[
 dynamic |
 ip ip_addr
 [
 interval number |
 threshold number |
 weight number
] |
 threshold number
]

```

**set (Loopback Interface)**

```

set interface interface loopback-group interface

```

**set (Monitoring)**

```

set interface interface monitor
{
 interface interface [weight number] |
 threshold number [action { down | up } { logically | physically }] |
 track-ip
 [
 dynamic |
 ip [ip_addr] |
 threshold number |
 weight number
] |
 zone zone [weight number]
}

```

**set (BGP)**

```

set interface interface protocol bgp

```

**set (OSPF)**

```

set interface interface protocol ospf
{
 area { ip_addr | number } |
 authentication
 {
 active-md5-key-id id_num |
 md5 key_str [key-id id_num] |
 password pswd_str
 } |
 cost number |
 dead-interval number |
 enable |
 hello-interval number |
 ignore-mtu |
 link-type { p2mp | p2p } |
 neighbor-list number |
 passive |
 priority number |
 reduce-flooding |
 retransmit-interval number |
 transit-delay number
}

```

**set (RIP)**

```

set interface interface protocol rip
[
 authentication
 {
 active-md5-key-id id_num |
 md5 key_str [key-id id_num] |
 password pswd_str
 } |
 enable |
 metric number |
 neighbor { ip_addr } |
 passive-mode |
 receive-version { v1 | v1v2 | v2 } |
 route-map name_str |
 send-version { v1 | v1v2 | v2 } |
 split-horizon [poison-reverse]
 summary-enable
]

```

**set (IGMP Host)**

```

set interface interface protocol igmp host
set interface interface protocol igmp
{
 enable |
 host |
 join-group ip_addr |
 no-check-router-alert |
 no-check-subnet |
 router |
 static-group ip_addr
}

```

**set (IGMP Router)**

```

set interface interface protocol igmp router
set interface interface protocol igmp
{
 accept { hosts id_num | groups id_num | routers id_num } |
 enable |
 join-group ip_addr |
 last-member-query-interval number |
 leave-interval number |
 no-check-router-alert |
 no-check-subnet |
 proxy [always] |
 query-interval number |
 query-max-response-time number |
 static-group ip_addr |
 version { 1 | 2 }
}

```

**set (IRDP)**

```

set interface interface protocol irdp
{
 ip_addr { advertise | preference number }
 accept-anonymous-solicitation
 broadcast-address
 enable
 init-adv-interval seconds
 init-adv-packet seconds
 lifetime seconds
 max-adv-interval upper_limit
 min-adv-interval lower_limit
 response-delay seconds
}

```

**set (PIM)**

```

set interface interface protocol pim
[
 boot-strap-border |
 dr-priority number |
 enable |
 hello-interval number |
 join-prune-interval number |
 neighbor-policy number
]

```

**set (Policy Based Routing)**

```

set interface interface pbr pbr_policy_name

```

**set (Tunnel)**

```

set interface tunnel.number
{
 dip id_num
 {
 ip_addr1
 [ip_addr2] [fix-port] |
 shift-from ip_addr3
 } |
 [ext ip ip_addr/mask] dip id_num
 {
 ip_addr1 [ip_addr2] [fix-port] |
 shift-from ip_addr3
 } |
 ip { ip_addr/mask | unnumbered interface interface } |
 loopback-group |
 manage-ip ip_addr |
 mip ip_addr host ip_addr
 [netmask mask [vrouter name_str]] |
 mtrace |
 mtu number |
 nhtb ip_addr vpn tunn_str |
 protocol
 {
 bgp |
 ospf [demand-circuit] |
 rip [demand-circuit] |
 igmp |
 pim
 } |
 proxy dns |
 route-deny |
 tunnel
 {
 encaps gre [key] |
 keep-alive [interval number | threshold number] |
 local-if interface dst-ip ip_addr
 } |
 zone name_str
}

```

---

**NOTE:** Use the IP option only after adding the tunnel to a specific zone.

---

### set (VLAN)

```
set interface interface
{
 [ext ip ip_add/mask] dip id_num
 {
 ip_add1 [ip_add2] [fix-port] |
 shift-from ip_add3 to ip_add1 [ip_add2]
 }
}
```

### set (VRRP)

```
set interface interface protocol vrrp enable
```

### set (VRRP group)

```
set interface grp_name protocol vrrp
{
 preempt [hold-down seconds] |
 advertise-interval seconds |
 priority number |
}
```

## Keywords and Variables

---

### Variable Parameters

```
get interface interface | subinterface | bundle | bundle_subinterface ...
set interface interface | subinterface | bundle | bundle_subinterface ...
```

|                      |                                                                                                                                                                                                                                                                                                                                                                                                 |
|----------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <i>interface</i>     | The name of the interface. All WAN interfaces on security devices, including serial, T1/E1, and T3, are named <b>serial</b> <i>n1/n2</i> , where <i>n1</i> is the slot number in the SSG chassis that is occupied by the Physical Interface Module (PIM), and <i>n2</i> is the physical port on the PIM. For MLFR and MLPPP, you configure and add physical interfaces to the bundle interface. |
| <i>src interface</i> | The name of the source interface to which an unnumbered interface is assigned an IP address. You can configure an unnumbered interface to use a source interface when the unnumbered interface does not work.                                                                                                                                                                                   |
| <i>subinterface</i>  | (Frame Relay only) The name of a virtual interface that is associated with a physical interface. You can create multiple subinterfaces on a physical interface. Subinterface names consist of the physical interface name, followed by a subinterface identification number, for example, serial1/1.1 or serial1/1.2.                                                                           |
| <i>bundle</i>        | (MLFR and MLPPP only) The name of the bundle interface. Bundle interface names consists of ml, followed by an identification number. For example, bundle interface names can be ml1, ml2, and so on.                                                                                                                                                                                            |

*bundle\_subinterface* (MLFR only) The name of a virtual interface that is associated with a bundle interface. You can create multiple subinterfaces on a bundle interface. Subinterface names consist of the bundle interface name, followed by a subinterface identification number, for example, ml1.1 or ml1.2.

**Example:** The following command specifies the IP address of a remote gateway peer (1.1.1.25) for the serial interface in port 0 of the PIM in slot 1:

```
set interface serial1/0 gateway 1.1.1.25
```

## ***account login***

```
set interface interface modem isp name_str account login string password pswd_str
```

*account login* Specifies the login name (*string*) and account password (*pswd\_str*) for the ISP account.

**Example:** The following command configures the login juniper and the password bodie45 for the ISP account *isp1*:

```
set interface serial1/0 modem isp isp1 account login juniper password bodie45
```

## ***alternative-number***

```
set interface interface alternative-number string
unset interface interface alternative-number string
```

*alternative-number string* Specifies the remote destination to call. If the primary number is not connected, **alternative-number** is used. The **alternative-number** is a string from 1 to 15 characters.

## ***association***

```
set interface interface association [mac_addr]
```

*association* Displays wireless clients associated with the wireless interface. To see more information about a particular client, specify its MAC address with the optional *mac\_addr*.

## ***aux enable***

```
set interface interface modem aux enable
```

*aux enable* Enables dial-in console management via the v.92 modem.

## backup

```
set interface interface backup { ... }
unset interface interface backup { ... }
exec backup interface interface { failover | revert }
```

|        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|--------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| backup | <p>Specifies the settings for the backup interface.</p> <ul style="list-style-type: none"> <li>■ <b>activation-delay</b> <i>number</i>—Specifies the number of seconds to wait after the primary interface goes down and the backup interface is activated. The range is 1-60 and the default is 30.</li> <li>■ <b>auto</b>—Configures the backup interface to fail over or revert to the primary interface automatically.</li> <li>■ <b>deactivation-delay</b> <i>number</i>—Specifies the number of seconds to wait to bring down the backup interface after the primary interface is up. The range is 1-60 and the default is 30.</li> <li>■ <b>interface</b> <i>interface</i>—Specifies the interface that acts as backup interface. Select the method to determine if the primary interface is unavailable. <ul style="list-style-type: none"> <li>■ <b>type</b>—Specifies the type of event to trigger failover or recover. <ul style="list-style-type: none"> <li>■ <b>route vrouter</b> <i>string ip_add/mask</i>—Enables the backup interface if the preconfigured route becomes unreachable through the interface.</li> <li>■ <b>track-ip</b>—Enables the backup interface when certain IP addresses become unreachable through the interface.</li> <li>■ <b>tunnel-if</b>—Enables the backup interface when certain VPN tunnels on the interface become unreachable through VPN tunnel monitoring.</li> </ul> </li> <li>■ <b>failover</b>—Forces the interface to failover to the backup interface.</li> <li>■ <b>revert</b>—Forces the interface to revert to the primary interface.</li> </ul> </li> </ul> |
|--------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

**Example:** The following command specifies the serial2/0 as backup interface for bri1/0. Once the route 10.10.10.10/24 in vrouter trust-vr is deactivated, the failover takes place.

```
set interface bri1/0 backup interface serial2/0 type route vrouter trust-vr
10.10.10.10/24
```

## bandwidth

```
set interface interface bandwidth { egress mbw number | ingress mbw number }
unset interface interface bandwidth
```

|           |                                                                                                                                                                                                                                                                                          |
|-----------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| bandwidth | <ul style="list-style-type: none"> <li>■ <b>egress</b>—The maximum bandwidth in kilobits per second for all traffic traversing the egress interface.</li> <li>■ <b>ingress</b>—The maximum bandwidth in kilobits per second for all traffic traversing the ingress interface.</li> </ul> |
|-----------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

**Example:** The following command specifies bandwidth of 10,000 kilobits per second for interface *ethernet4*:

```
set interface ethernet4 bandwidth egress mbw 10000
set interface ethernet4 bandwidth ingress mbw 10000
```

## bert-test

```
exec interface interface bert-test [start | stop]
```

bert-test            Starts or stops bit error rate testing on the specified interface.

## bri-options

```
get interface interface bri-options
set interface interface bri-options { ... }
unset interface interface bri-options { ... }
```

bri-options            ■ **idle-cycle-flag**—Specifies the value the BRI interface transmits during its idle cycles. Select **ones** (0xFF) or **flags** (0x7E) to configure the value the BRI interface transmits during idle-cycles in order to keep the line up. The default is **ones** (0xFF).

                         ■ **loopback**—Specifies the maximum bandwidth in kilobits per second for all traffic traversing the ingress interface. Loopback mode is disabled by default.

                         ■ **remote**—Received data is looped back to the S interface. The D-channel information received from the line card is output to the S interface transparently.

                         ■ **local**—Performs complete system diagnostics. The transmitted data is looped back to the receiver through the S interface. (The pin-out of the external loop cable is pin 3< -> pin 4 and pin 5< -> pin 6).

**Example:** The following command specifies remote loopback mode:

```
set interface bri1/0 bri-options loopback remote
```

## broadcast

```
set interface interface broadcast { flood | arp [trace-route] }
unset interface interface broadcast [arp [trace-route]]
```

broadcast            (**vlan1** interface only.) Controls how the security device determines reachability of other devices while the device is in transparent (Layer 2) mode.

                         ■ **flood**—Instructs the security device to flood frames received from an unknown host out to all interfaces that are in transparent mode. In the process, the device might attempt to copy frames out of ports that cannot access the destination address, thus consuming network bandwidth.

                         ■ **arp [ trace-route ]**—Instructs the security device to generate an Address Resolution Protocol (ARP) broadcast. If the broadcast finds the unknown destination IP address, the device loads its ARP table with the appropriate MAC address and interface. The device uses this entry to reach the destination device directly, and only sends frames through the correct port, thus saving bandwidth. Generating the initial ARP can cause delay, but only for the first frame.

**Example:** The following command instructs the security device to generate an Address Resolution Protocol (ARP) broadcast:

```
set interface vlan1 broadcast arp
```

**bundle**

set interface *interface* bundle *bundle*

bundle (For multilink interfaces only) Adds the physical link *interface* to the multilink interface *bundle*.

**bundle-ID**

set interface *bundle* bundle-ID *string*

bundle-ID Specifies an identifier for the bundle interface. If you do not specify a bundle ID, the bundle interface name is used.

**bypass-non-ip**

set interface *interface* bypass-non-ip  
unset interface *interface* bypass-non-ip

bypass-non-ip (**vlan1** interface only.) Allows non-IP traffic (such as IPX) with a unicast MAC destination address to pass through a security device running in transparent mode. (ARP is a special case for non-IP traffic. It is always passed even if this feature is disabled.)

Executing the **unset interface *interface* bypass-non-ip** command drops all the non-IP packet with unicast MAC destination addresses, but non-IP packets with multicast MAC addresses are still passed through.

**bypass-non-ip-all**

set interface *interface* bypass-non-ip-all  
unset interface *interface* bypass-non-ip-all

bypass-non-ip-all (**vlan1** interface only.) Allows nonbroadcast, nonmulticast, and non-IP traffic to pass through a security device running in transparent mode. (ARP is a special case for non-IP traffic. It is always passed even if this feature is disabled.)

Executing the **unset interface *interface* bypass-non-ip-all** drops all non-IP packets, regardless of the MAC destination address.

**bypass-others-ipsec**

set interface *interface* bypass-others-ipsec  
unset interface *interface* bypass-others-ipsec

bypass-others-ipsec (**vlan1** interface only.) Openly passes all IPsec traffic through a security device in transparent mode. The security device does not act as a VPN tunnel gateway but passes the IPsec packets onward to other gateways.

**counter**

get interface *interface* counter

|         |                                                                                                                                                                                                                                                                                                                               |
|---------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| counter | Shows some or all of the following counters for each member of a bgroup interface:                                                                                                                                                                                                                                            |
|         | <ul style="list-style-type: none"> <li>■ InUnicasts</li> <li>■ InBroadcasts</li> <li>■ InMulticasts</li> <li>■ InFC</li> <li>■ InOverRun</li> <li>■ in bad CRC</li> <li>■ InRxErr</li> <li>■ OutUnicast</li> <li>■ OutBroadcasts</li> <li>■ OutMulticasts</li> <li>■ OutFC</li> <li>■ BadCRC</li> <li>■ Collisions</li> </ul> |

**Example:** The following command displays the statistics counters for every member of bgroup4/1

get interface bgroup4/1 counter

**cisco-hdlc**

get interface *interface* cisco-hdlc

|            |                                                                                                                                 |
|------------|---------------------------------------------------------------------------------------------------------------------------------|
| cisco-hdlc | Shows the statistics and configuration information for an interface configured for Cisco High-Level Data Link Control protocol. |
|------------|---------------------------------------------------------------------------------------------------------------------------------|

**clocking**

set interface *interface* clocking external | internal

|          |                                                                                                                                                                                                                                                             |
|----------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| clocking | Specifies the clocking source for T1/E1 or T3 lines. You can specify one of the following options:                                                                                                                                                          |
|          | <ul style="list-style-type: none"> <li>■ <b>external</b>—Specifies that clocking is provided by the DCE (loop timing).</li> <li>■ <b>internal</b>—Specifies that clocking is provided by the SSG device's own system clock. This is the default.</li> </ul> |

**description**

set interface *interface* description *string*  
unset interface *interface* description

|             |                                                                          |
|-------------|--------------------------------------------------------------------------|
| description | Adds a description ( <i>string</i> ) of 1-31 characters to an interface. |
|-------------|--------------------------------------------------------------------------|

## *dhcp client*

```

set interface interface dhcp client
{
 enable |
 settings
 {
 admin-preference number |
 autoconfig |
 client-id string |
 lease number |
 server ip_addr |
 update-dhcpserver | vendor id_str } }
exec dhcp client interface renew

```

|             |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
|-------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| dhcp client | <p>Configures an interface for DHCP client services.</p> <ul style="list-style-type: none"> <li>■ <b>enable</b>—Enables DHCP client services for the interface.</li> <li>■ <b>settings</b>—Configures DHCP parameters for the interface. <ul style="list-style-type: none"> <li>■ <b>admin-preference</b> <i>number</i></li> <li>■ <b>autoconfig</b>—Enables automatic configuration after device powers on.</li> <li>■ <b>client-id</b> <i>string</i>—Specifies the ID of the DHCP client. The maximum length for <b>client-id</b> is six characters. Use the <b>unset</b> command to remove the DHCP client ID.</li> <li>■ <b>lease</b> <i>number</i>—Sets the default lease time (in minutes).</li> <li>■ <b>server</b> <i>ip_addr</i>—Specifies the IP address of the DHCP server.</li> <li>■ <b>update-dhcpserver</b>—Forwards TCP/IP settings from the DHCP client module on the specified interface to the DHCP server module on the default interface in the Trust zone. <b>Note:</b> On devices that can have multiple interfaces bound to the Trust zone, the default interface is the first interface bound to that zone and assigned an IP address.</li> <li>■ <b>vendor</b> <i>id_str</i>—Specifies the DHCP vendor by ID.</li> <li>■ <b>renew</b>—Renews the length of time, in minutes, for which an IP address is leased to the DHCP client.</li> </ul> </li> </ul> |
|-------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

**Example 1:**The following command configures interface *ethernet3* to perform automatic DHCP configuration after device powers on:

```
set interface ethernet3 dhcp client settings autoconfig
```

**Example 2:** The following command enables the forwarding of TCP/IP settings from the DHCP client module on the Untrust interface to the DHCP server module on the Trust zone interface:

```
set interface untrust dhcp client settings update-dhcpserver
```

## dhcp relay

```
get interface interface dhcp relay
set interface interface dhcp relay
 { server-name name_str | service | vpn }
unset interface interface dhcp relay { server-name { name_str | ip_addr } | service | vpn }
```

- dhcp relay** Configures the security interface such that the security device can serve as a DHCP relay agent.
- **server-name** *name\_str*—Defines the domain name of the external DHCP server from which the security device receives the IP addresses and TCP/IP settings that it relays to hosts on the LAN.
  - **service**—Enables the security device to act as a DHCP server agent through the interface.
  - **vpn**—Allows the DHCP communications to pass through a VPN tunnel. You must first set up a VPN tunnel between the security device and the external DHCP server.

The relay does not coexist with the DHCP server (OK with the client).

**Example:** The following configures interface *ethernet4* to use an external DHCP server at IP address 1.1.1.10:

```
set interface ethernet4 dhcp relay server-name 1.1.1.10
```

## dhcp server

```
set interface interface dhcp server { ... }
unset interface interface dhcp server { ... }
```

- dhcp server** Makes the security interface work as a DHCP server.
- **auto**—Instructs the security device to check to see if there is a DHCP server already running on the network. If there is such a server, the DHCP server on the security device is disabled. If there is no DHCP server running on the network, the DHCP server on the security device is enabled. This is the default mode.
  - **disable**—Causes the DHCP server to always be off.
  - **enable**—Causes the DHCP server to always be on. The DHCP server on the security device always starts when the device is powered on.
  - **ip** *ip\_addr* { **mac** *mac\_addr* | **to** *ip\_addr* }—Specifies either a specific IP address that is assigned to a host or the lower end of a range of IP addresses to use when the DHCP server is filling client requests.
    - **mac** This option allows you to statically assign an IP address to the host that is identified by the specified MAC address. The host is always assigned the specified IP address.
    - **to**—Defines the upper end of a range of IP addresses to use when the DHCP server is filling client requests. The IP pool can support up to 255 IP addresses. The IP address must be in the same subnet as the interface IP or the DHCP gateway.
  - **option**—Specifies the DHCP server options for which you can define settings.

- **custom** *id\_num* Creates a user-defined value for configurations where the predefined server options (listed below) do not suffice, and you need to define custom DHCP server options. For example, certain voice over IP (VoIP) configurations require transmission of extra configuration information, which is not currently supported by predefined server options. In such cases, you must define suitable custom options.
  - **string** *string*—Specifies a character string.
  - **ip** *ip\_addr*—Specifies an IP address.
  - **integer** *number*—Specifies an integer value.
- **dns1** *ip\_addr* | **dns2** *ip\_addr* | **dns3** *ip\_addr*—Defines the IP addresses of the primary, secondary, and tertiary Domain Name System (DNS) servers.
- **gateway** *ip\_addr*—Defines the IP address of the gateway to be used by the clients. The IP address must be in the same subnet as the interface IP or the DHCP gateway.
- **news** *ip\_addr*—Specifies the IP address of a news server to be used for receiving and storing postings for news groups.
- **nis1** *ip\_addr* | **nis2** *ip\_addr*—Defines the IP addresses of the primary and secondary NetInfo<sup>®</sup> servers, which provide the distribution of administrative data within a LAN.
- **pop3** *ip\_addr*—Specifies the IP address of a Post Office Protocol version 3 (POP3) mail server.
- **smtp** *ip\_addr*—Defines the IP address of a Simple Mail Transfer Protocol (SMTP) mail server.
- **domainname** *name\_str*—Defines the registered domain name of the network.
- **lease** *number*—Defines the length of time, in minutes, for which an IP address supplied by the DHCP server is leased. For an unlimited lease, enter *0*.
- **netmask** *ip\_addr*—Defines the netmask of the gateway. The IP address must be in the same subnet as the interface IP or the DHCP gateway.
- **nistag** *string*—Defines the identifying tag used by the Apple<sup>®</sup> NetInfo database.
- **wins1** *ip\_addr* | **wins2** *ip\_addr*—Specifies the IP address of the primary and secondary Windows Internet Naming Service (WINS) servers.
- **service**—Enables the security device to act as a DHCP server agent through the interface.

The server does not coexist with the DHCP relay (OK with the client).

**Example:** The following command configures the security device to act as a DHCP server agent through the interface *ethernet4*:

```
set interface ethernet4 dhcp server service
```

## dialer-enable

```
set interface interface dialer-enable
unset interface interface dialer-enable
```

**dialer-enable** Sets the ISDN BRI interface to enable dialing. The BRI interface acts as a dialer interface. It has two dialer-pool members by default, the two B-channels. The BRI interface does not enable dialing by default.

## dip

```
set interface interface [ext ip ip_addr/mask] dip id_num ip_addr1 [ip_addr2] [fix-port
| incoming]
set interface interface [ext ip ip_addr/mask] dip id_num shift-from ip_addr3
unset interface interface dip id_num
unset interface interface dip id_num ip_addr1 [ip_addr2] fix-port
unset interface interface ext ip ip_addr/mask dip id_num
unset interface interface ext ip ip_addr/mask dip id_num ip_addr1 [ip_addr2] fix-port
```

**dip** Sets a dynamic IP (DIP) pool. Each DIP pool consists of a range of addresses. You can add a maximum of three IP address ranges for a fixed-port DIP pool. The security device can use the pool to dynamically or deterministically allocate source addresses when the device applies Source Network Address Translation (NAT-src) to packets traversing the specified interface. This is useful when you need to translate nonroutable local IP source addresses into routable addresses for outgoing packet. The keywords and variables for the **dip** option are as follows:

- ***id\_num***—Identifies the DIP pool. The range is 4—1023.
- The first IP address *ip\_addr1* represents the start of the IP address range. (A DIP pool can consist of a single IP address, or range of addresses.) The second IP address *ip\_addr2* represents the end of the IP address range.
- [ ext ip *ip\_addr/mask* ] is the extended interface IP address.

**Note:** In transparent mode, you must define a DIP pool on an extended VLAN interface to support policy based NAT-src.

- **shift-from *ip\_addr3***—Defines a one-to-one mapping from an original source IP address to a translated source IP address for a range of IP addresses starting from *ip\_addr3*. Such a mapping ensures that the security device always translates a particular source IP address from within that range to the same translated address within a DIP pool.
- **incoming**—Creates a DIP address pool for dynamically allocating destination addresses. The name of the DIP pool can be DIP (*id\_num*) for a user-defined DIP, or DIP (*interface*) for an interface DIP. The DIP address pool resides in the Global security zone. You can use such address entries as destination addresses in policies, together with the services H.323, SIP, or voice over IP (VoIP), to support incoming calls.

Be sure to exclude the following IP addresses from a DIP pool:

- The WebUI management IP address
- The interface and gateway IP addresses
- Any virtual IP (VIP) and mapped IP (MIP) addresses

**interface-ip incoming**—Designates addresses derived from the interface IP address range for dynamically allocating destination addresses to incoming packets.

**Example 1:** The following commands allow local hosts in a nonroutable subnet to communicate over a public WAN infrastructure. The security device uses a DIP pool to dynamically allocate routable source addresses to packets sent from the local hosts to remote hosts.

- Local unroutable subnet 10.1.23.1/24
- Remote unroutable subnet 10.100.2.75/24
- DIP ID number 10, with address range from 2.1.10.2 through 2.1.10.36

```
unset interface ethernet2 ip
unset interface ethernet2 zone
unset interface ethernet3 ip
unset interface ethernet3 zone
```

```
set interface ethernet2 zone trust
set interface ethernet2 ip 10.1.23.1/24
set interface ethernet3 zone untrust
set interface ethernet3 ip 2.1.10.1/24
set interface ethernet3 dip 10 2.1.10.2 2.1.10.36
set address trust Local_Hosts 10.1.23.1/24
set address untrust Remote_Hosts 10.100.2.75/24
set policy from trust to untrust Local_Hosts Remote_Hosts http nat dip 10 permit
```

**Example 2:** The following commands use DIP in an H.323 VoIP configuration.

- Creates a pool of DIP addresses (identified by ID 5) containing addresses 1.1.1.12 through 1.1.1.150 inclusive. The device can use addresses in this DIP pool as incoming destination addresses (or as outgoing source addresses).
- Creates a policy that allows outgoing H.323 requests, using DIP addresses for source addresses.
- Creates a policy that allows incoming H.323 requests, using DIP addresses for destination addresses.

```
set interface ethernet7 ip 1.1.1.1/24
set interface ethernet7 dip 5 1.1.1.12 1.1.1.150 incoming
set policy from trust to untrust any any h.323 nat src dip 5 permit
set policy from untrust to trust any dip(5) h.323 permit
```

**disable**

set interface *interface* disable

disable                    Disables the interface. WAN interfaces are enabled by default.

**dot1x**

clear interface *interface* dot1x statistics

get interface *interface* dot1x [ ... ]

set interface *interface* dot1x [ ... ]

unset interface *interface* dot1x [ ... ]

**auth-server**            Specifies a predefined server as the authentication server for the interface.  
*string*

**control-mode**           Specifies whether MAC address-based authentication is performed on devices connected to the interface.

- **interface**—MAC addresses of devices connected to the interface are not authenticated. Use this option if only one trusted device is connected to the interface.
- **virtual**—MAC addresses of devices connected to the interface are authenticated. Packets from devices with unauthorized MAC addresses are dropped. This mode is the default for an interface. Wireless interfaces use only virtual mode.

**max-user**                Maximum number of users that require 802.1X authentication on an interface. This option is available only if virtual mode (using the **set interface interface dot1x control-mode** command) is configured. The maximum number of users is 1 through 256. By default, the maximum number of users is 16 for wired interfaces and 256 for wireless interfaces.  
*number*

**port-control**           Specifies the 802.1X authentication state of the interface:

- **auto**—Allows authentication to proceed normally, as defined by 802.1X. This option is the default for an interface.
- **force-unauthorized**—Forces the interface to block all traffic and ignore all attempts by clients to authenticate.

**reauth-period**         Amount of time the security device waits before attempting reauthentication of clients. By default, the security device waits 3600 seconds (1 hour) before attempting client reauthentication. The value range is 0 through 86400 seconds (24 hours). Setting the value to 0 disables reauthentication.  
*number*

Use the unset interface *interface\_name* dot1x reauth-period to revert to the default value.

**retry**                    Enables retransmission of EAP requests to a client if it does not respond. By default, retransmission is enabled. If the maximum number of retransmissions is reached, the client's authenticated session is terminated, and authentication fails.

Optionally, set the maximum number of EAP requests that are retransmitted and the time that elapses between retransmissions to the client if it does not respond.

- **count** *number*—Maximum number of EAP requests from 1 through 16. The default value is 3.
- **period** *number*—Period between retransmissions in the value range of 1 through 120 seconds. The default value is 3 seconds.

Use the **unset interface interface\_name dot1x retry [ count | period ]** to revert to the default value.

|                                       |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
|---------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>silent-period<br/>number</code> | <p>Amount of time the security device remains silent after authentication has failed. During the silent period, the security device does not initiate or respond to any client authentication requests.</p> <p>By default, when authentication fails, the security device is silent for 5 seconds. The authentication retry count resets to zero (0).</p> <p>The silent period is a value from 0 through 3600 seconds (1 hour). If you specify a zero value, the 802.1X authentication state remains unauthorized after the retry fails.</p> <p>Use the <b>unset interface <i>interface_name</i> dot1x silent-period</b> to revert to the default value.</p> |
| <code>statistics</code>               | Displays or clears statistics for an interface on which 802.1X is enabled.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |

**Example:** The following configuration scenario illustrates a network setup for a hub with attached clients connected to the security device with the following parameters:

- Hub connected to Ethernet2 interface
- Ethernet3/1 interface bound to Trust zone with an IP address of 10.1.40.3/24
- RADIUS server named **radius1** (10.1.1.200) connected to Ethernet3 interface to authenticate users with 802.1X, using port 1812 as the authentication port and secret of mysecret

```
set interface ethernet2 dot1x
set interface ethernet2 dot1x control-mode virtual

set interface ethernet3 zone trust
set interface ethernet3 ip 10.1.1.10/24

set auth-server radius1 account-type 802.1x
set auth-server radius1 type radius
set auth-server radius1 radius port 1812
set auth-server radius1 radius secret mysecret
set auth-server radius1 server-name 10.1.1.200

set interface ethernet2 dot1x auth-server radius1
```

## ***drop-timeout***

```
set interface bundle drop-timeout milliseconds
```

|                           |                                                                                                                                                                                                                                                                                                                   |
|---------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>drop-timeout</code> | (For multilink bundle interfaces only). Specifies the drop timeout in milliseconds. The drop timeout provides a recovery mechanism if individual links in the multilink bundle drop one or more packets. The default is 0, which means that drop timeout is disabled. Specify a value between 0-127 milliseconds. |
|---------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

## e1-options

set interface *interface* e1-options ...

- e1-options Specifies options for an E1 interface. You can specify the following:
- **bert-algorithm**—Sets the bit error rate testing (BERT) algorithm for the interface. The algorithm is the pattern to send in the bitstream. You can specify one of the following options:
    - **all-ones-repeating**—Repeating one bits.
    - **all-zeros-repeating**—Repeating zero bits.
    - **alternating-double-ones-zeros**—Alternating pairs of ones and zeroes.
    - **alternating-ones-zeros**—Alternating ones and zeroes.
    - **pseudo-2e10**—Pattern is  $2^{10}-1$ .
    - **pseudo-2e11-o152**—Pattern is  $2^{11}-1$  (per O.152 standard).
    - **pseudo-2e15-o151**—Pattern is  $2^{15}-1$  (per O.152 standard). This is the default.
    - **pseudo-2e17**—Pattern is  $2^{17}-1$ .
    - **pseudo-2e18**—Pattern is  $2^{18}-1$ .
    - **pseudo-2e20-o151**—Pattern is  $2^{20}-1$  (per O.151 standard).
    - **pseudo-2e20-o153**—Pattern is  $2^{20}-1$  (per O.153 standard).
    - **pseudo-2e21**—Pattern is  $2^{21}-1$ .
    - **pseudo-2e22**—Pattern is  $2^{22}-1$ .
    - **pseudo-2e23-o151**—Pattern is  $2^{23}$  (per O.151 standard).
    - **pseudo-2e25**—Pattern is  $2^{25}-1$ .
    - **pseudo-2e28**—Pattern is  $2^{28}-1$ .
    - **pseudo-2e29**—Pattern is  $2^{29}-1$ .
    - **pseudo-2e3**—Pattern is  $2^3-1$ .
    - **pseudo-2e31**—Pattern is  $2^{31}-1$ .
    - **pseudo-2e32**—Pattern is  $2^{32}-1$ .
    - **pseudo-2e4**—Pattern is  $2^4-1$ .
    - **pseudo-2e5**—Pattern is  $2^5-1$ .
    - **pseudo-2e6**—Pattern is  $2^6-1$ .
    - **pseudo-2e7**—Pattern is  $2^7-1$ .
    - **pseudo-2e9-o153**—Pattern is  $2^9-1$  (per O.153 standard).
    - **repeating-1-in-4** One bit in 4 is set.
    - **repeating-1-in-8** One bit in 8 is set.
    - **repeating-3-in-24** Three bits in 24 are set.
  - **bert-error-rate**—Sets the bit error rate (BER) to use in BERT. This can be an integer from 0 to 7, which corresponds to a BER from  $10^0$  (1 error per bit) to  $10^{-7}$ . The default is 0.
  - **bert-period**—Sets the length of the BERT, in seconds. The default is 10. Specify a value between 1 and 240 seconds.
  - **fcs**—Specifies the number of bits in the frame checksum. You can specify one of the following:
    - **16**—16 bits. This is the default.
    - **32**—32 bits.

- **framing**—Sets the framing mode for the E1 line. You can specify the following:
  - **g704**—G704 mode with cyclic redundancy check 4 (CRC 4). This is the default.
  - **g704-no-crc4**—G704 mode without CRC4.
- **idle-cycle-flag**—Sets the value to transmit in idle cycles. You can specify one of the following:
  - **flags**—Transmit 0x7E in idle cycles. This is the default.
  - **ones**—Transmit 0xFF (all ones) in idle cycles.
- **invert-data**—Specifies data inversion. Data inversion is normally used only in alternate mark inversion (AMI) mode. By default, this is not set.
- **loopback**—Specifies loopback mode. By default, no loopback mode is set. You can specify one of the following:
  - **local**—Local loopback.
  - **remote**—Remote loopback.
- **start-end-flag**—Sets the start and end flags on transmission. You can specify one of the following:
  - **filler**—Send two idle cycles between start/end flags. This is the default.
  - **shared**—Share start/end flags on transmit.
- **timeslots** *timeslots*—Specifies the number of time slots allocated to a fractional E1 interface. By default, all time slots are active. Specify values from 2 to 32. Use hyphens to specify a range. Use commas (with no spaces before or after) to separate individual time slots or ranges. For example, you can specify the following: 3-5,9,22-24,28.

## e3-options

set interface *interface* e3-options ...

e3-options

Specifies options for an E3 interface. You can specify the following:

- **bert-algorithm**—Sets the bit error rate testing (BERT) algorithm for the interface. The algorithm is the pattern to send in the bitstream. You can specify one of the following options:
  - **all-ones-repeating**—Repeating one bits.
  - **all-zeros-repeating**—Repeating zero bits.
  - **alternating-ones-zeros**—Alternating ones and zeroes.
  - **pseudo-2e11-o152**—Pattern is  $2^{11}-1$  (per O.152 standard).
  - **pseudo-2e15-o151**—Pattern is  $2^{15}-1$  (per O.152 standard). This is the default.
  - **pseudo-2e20-o151**—Pattern is  $2^{20}-1$  (per O.151 standard).
  - **pseudo-2e20-o153**—Pattern is  $2^{20}-1$  (per O.153 standard).
  - **pseudo-2e23-o151**—Pattern is  $2^{23}$  (per O.151 standard).
  - **pseudo-2e29**—Pattern is  $2^{29}-1$ .
  - **pseudo-2e31**—Pattern is  $2^{31}-1$ .
  - **pseudo-2e9-o153**—Pattern is  $2^9-1$  (per O.153 standard).
- **bert-error-rate**—Sets the bit error rate (BER) to use in BERT. This can be an integer from 0 to 7, which corresponds to a BER from  $10^0$  (1 error per bit) to  $10^{-7}$ . The default is 0.

- **bert-period**—Sets the length of the BERT, in seconds. The default is 10. Specify a value between 1 and 240 seconds.
- **compatibility-mode**—Sets the E3 interface to be compatible with the channel service unit (CSU) at the remote end of the line. By default, no compatibility mode is set. You can specify one of the following:
  - **digital-link subrate**—Sets the interface to be compatible with Digital Link CSUs. Specify one of the following bits-per-second values:
 

|          |           |           |           |
|----------|-----------|-----------|-----------|
| ■ 358 Kb | ■ 9.0 Mb  | ■ 17.5 Mb | ■ 26.1 Mb |
| ■ 716 Kb | ■ 9.3 Mb  | ■ 17.9 Mb | ■ 26.5 Mb |
| ■ 1.1 Mb | ■ 9.7 Mb  | ■ 18.3 Mb | ■ 26.9 Mb |
| ■ 1.4 Mb | ■ 10.0 Mb | ■ 18.6 Mb | ■ 27.2 Mb |
| ■ 1.8 Mb | ■ 10.4 Mb | ■ 19.0 Mb | ■ 27.6 Mb |
| ■ 2.1 Mb | ■ 10.7 Mb | ■ 19.3 Mb | ■ 27.9 Mb |
| ■ 2.5 Mb | ■ 11.1 Mb | ■ 19.7 Mb | ■ 28.3 Mb |
| ■ 2.9 Mb | ■ 11.5 Mb | ■ 20.0 Mb | ■ 28.6 Mb |
| ■ 3.2 Mb | ■ 11.8 Mb | ■ 20.4 Mb | ■ 29.0 Mb |
| ■ 3.6 Mb | ■ 12.2 Mb | ■ 20.8 Mb | ■ 29.4 Mb |
| ■ 3.9 Mb | ■ 12.5 Mb | ■ 21.1 Mb | ■ 29.7 Mb |
| ■ 4.3 Mb | ■ 12.9 Mb | ■ 21.5 Mb | ■ 30.1 Mb |
| ■ 4.7 Mb | ■ 13.2 Mb | ■ 21.8 Mb | ■ 30.4 Mb |
| ■ 5.0 Mb | ■ 13.6 Mb | ■ 22.2 Mb | ■ 30.8 Mb |
| ■ 5.4 Mb | ■ 14.0 Mb | ■ 22.6 Mb | ■ 31.1 Mb |
| ■ 5.7 Mb | ■ 14.3 Mb | ■ 22.9 Mb | ■ 31.5 Mb |
| ■ 6.1 Mb | ■ 14.7 Mb | ■ 23.3 Mb | ■ 31.9 Mb |
| ■ 6.4 Mb | ■ 15.0 Mb | ■ 23.6 Mb | ■ 32.2 Mb |
| ■ 6.8 Mb | ■ 15.4 Mb | ■ 24.0 Mb | ■ 32.6 Mb |
| ■ 7.2 Mb | ■ 15.8 Mb | ■ 24.3 Mb | ■ 32.9 Mb |
| ■ 7.5 Mb | ■ 16.1 Mb | ■ 24.7 Mb | ■ 33.3 Mb |
| ■ 7.9 Mb | ■ 16.5 Mb | ■ 25.1 Mb | ■ 33.7 Mb |
| ■ 8.2 Mb | ■ 16.8 Mb | ■ 25.4 Mb | ■ 34.0 Mb |
| ■ 8.6 Mb | ■ 17.2 Mb | ■ 25.8 Mb |           |
- **kentrox subrate**—For IQ channels only. Sets the interface to be compatible with Kentrox CSUs. Specify a value between 1 and 48.
- **fcs**—Specifies the number of bits in the frame checksum. You can specify one of the following:
  - **16**—16 bits. This is the default.
  - **32**—32 bits.
- **framing**—Sets the framing mode for the E1 line. You can specify the following:
  - **g751**—G751 mode. This is the default.
  - **unframed**—No framing.

- **idle-cycle-flag**—Sets the value to transmit in idle cycles. You can specify one of the following:
  - **flags**—Transmit 0x7E in idle cycles. This is the default.
  - **ones**—Transmit 0xFF (all ones) in idle cycles.
- **loopback**—Specifies loopback mode. By default, no loopback mode is set. You can specify one of the following:
  - **local**—Local loopback.
  - **remote**—Remote loopback.
- **payload-scrambler**—Enables High-Level Data Link Control (HDLC) payload scrambling on the interface. This type of scrambling provides better link stability, but both sides of the connection must either use or not use scrambling. By default, this is not set.
- **start-end-flag**—Sets the start and end flags on transmission. You can specify one of the following:
  - **filler**—Send two idle cycles between start/end flags. This is the default.
  - **shared**—Share start/end flags on transmit.

## encap

```
set interface interface encap { cisco-hdlc | frame-relay | mlfr-uni-nni | mlppp | ppp }
set interface bundle encap { mlfr-uni-nni | mlppp }
```

|              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
|--------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| encap        | Specifies the type of encapsulation to perform when the subinterface is untagged. An untagged interface does not use a VLAN tag to identify a VLAN for a subinterface. Instead, it binds the subinterface to a particular defined PPPoE instance. Thus, by hosting multiple subinterfaces, a single physical interface can host multiple PPPoE instances. You can configure each instance to go to a specified Access Concentrator (AC), thus allowing separate entities such as ISPs to manage the PPPoE sessions. |
| cisco-hdlc   | Sets Cisco High-Level Data Link Control (Cisco HDLC) encapsulation on the specified interface.                                                                                                                                                                                                                                                                                                                                                                                                                      |
| frame-relay  | Sets Frame Relay encapsulation on the specified interface.                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| mlfr-uni-nni | (For Frame Relay multilink bundle interfaces only)—Sets Multilink Frame Relay User-to-Network Interface (UNI) encapsulation, based on Frame Relay Forum Multilink Implementation Agreement FRF.16, on the specified interface.                                                                                                                                                                                                                                                                                      |
| mlppp        | (For MLPPP bundle interfaces only)—Sets Multilink Point-to-Point Protocol on the specified interface.                                                                                                                                                                                                                                                                                                                                                                                                               |
| ppp          | Sets Point-to-Point Protocol (PPP) encapsulation on the specified interface.                                                                                                                                                                                                                                                                                                                                                                                                                                        |

## ext ip

```
set interface interface ext ip ip_addr/mask dip number { ... }
unset interface interface ext ip ip_addr/mask dip number
```

|        |                                                                                                                                                                                                                                                                                                                                                                |
|--------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ext ip | The <b>ext ip</b> <i>ip_addr</i> option configures a DIP in a different subnet from the interface's subnet. For example, an interface could have IP address 1.2.10.1/24, and the extended DIP could be 2.2.3.1/24. <ul style="list-style-type: none"> <li>■ <b>dip <i>id_num</i></b>—Sets a dynamic IP (DIP) pool. See “dialer-enable” on page 341.</li> </ul> |
|--------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

- **fix-port** Keeps the original source port number in the packet header. Does not apply Port Address Translation (PAT).

**Example:** The following command creates an address (1.1.100.110) in a DIP (ID 10) for interface *ethernet3* (IP address 10.1.10.10):

```
set interface ethernet3 ext ip 10.1.10.10/24 dip 10 10.1.10.110
```

## fragment-threshold

```
set interface bundle fragment-threshold bytes
```

**fragment-threshold** (For MLPPP bundle interfaces only)—Specifies the maximum size, in bytes, for packet payloads transmitted across the individual links within the multilink circuit. The threshold value affects the payload only; it does not affect the MLPPP header. The default value is 0 bytes (disabled). Specify a value between 128-16320 bytes.

## frame-relay

```
get interface interface frame-relay
set interface interface frame-relay ...
```

**frame-relay** For the **get** command, shows the statistics and configuration information for an interface configured for Frame Relay or Multilink Frame Relay. The interface can be a WAN interface, a WAN subinterface, a bundle interface, or a bundle subinterface.

**dcli id\_num** (For Frame Relay subinterfaces only)—Configures the data link connection identifier (DLCI) for a permanent virtual circuit (PVC) for Frame Relay and Multilink Frame Relay user-to-network interface (UNI) encapsulations. Specify a value between 16 and 1022.

**inverse-arp** (For Frame Relay subinterfaces only)—Configures the router to respond to inverse Frame Relay Address Resolution Protocol (ARP) requests by providing IP address information to the requesting router at the other end of the Frame Relay PVC.

**lmi** Sets the type of Local Management Interface (LMI) packets used for keepalives and keepalive settings. You can specify the following:

- **n391-dte number**—Specifies the data terminal equipment (DTE) full status polling interval. The DTE sends a status inquiry to the data circuit-terminating equipment (DCE) at the interval specified by **t391-dte**. **n391-dte** specifies the frequency at which these inquiries expect a full status report; for example, an **n391-dte** value of 10 would specify a full status report in response to every tenth inquiry. The intermediate inquiries ask for a keepalive exchange only. The range is from 1 through 255, with a default value of 6.
- **t391-dte seconds**—Specifies the DTE keepalive timer, which is the period at which the DTE sends out a keepalive response request to the DCE and updates status depending on the DTE error-threshold value. The range is from 5 through 30 seconds, with a default value of 10 seconds.
- **n392-dte number**—Specifies the DTE error threshold, which is the number of errors required to bring down the link, within the event-count specified by **n393-dte**. The range is from 1 through 10, with a default value of 3.
- **n393-dte number**—Specifies the DTE monitored event-count. The range is from 1 through 10, with a default value of 4.

- **no-keepalive**—Disables the sending of keepalives on the interface.
- **type**—Specifies the type of LMI packets for keepalives. You can specify one of the following:
  - **ansi**—Specifies ANSI T1.617 Annex D LMIs.
  - **itu**—Specifies ITU Q933 Annex A LMIs.

## gateway

```
set interface interface gateway ip_addr [no-default-route]
unset interface interface gateway
```

**gateway** The IP address for the default gateway to which the security device forwards packets that are destined for networks beyond the immediate subnet of the specified interface. The **no-default-route** switch specifies that there is no default route for this gateway.

**Example:** The following command specifies the IP address of a remote gateway peer (1.1.10.10) for the *ethernet4* interface:

```
set interface ethernet4 gateway 1.1.10.10
```

## g-arp

```
set interface interface g-arp
unset interface interface g-arp
```

**g-arp** Allows the specified interface to accept incoming Gratuitous-Address Resolution Protocol (G-ARP) packets. By default, the device accepts incoming G-ARP packets on all interfaces except vlan interface on L2 mode.

## hold-time

```
get interface interface hold-time
set interface interface hold-time { down | up }
unset interface interface hold-time { down | up }
```

**hold-time** Specifies the link state hold time or how much time can pass before the device considers the interface connection to be up or down. The range is 0—65534 (milliseconds). The default value for **up/down** time is 0 (no damp).

- **up**—Configures the hold-time period when an interface goes from up to down, it is not advertised as being down until it has remained down for the specified **up** period.
- **down**—Configure the hold-time period when an interface goes from down to up, it is not advertised as being up until it has remained up for the specified **down** period.

**idle-time**

```
set interface interface modem idle-time number
set interface interface idle-time number
unset interface interface modem idle-time number
unset interface interface idle-time number
```

**idle-time** Specifies the number of seconds that elapse with no traffic on the dial-up connection before the security device disconnects the modem. The default is 1 minute. A value of 0 means the modem never disconnects, even if there is no traffic on the dial-up connection.

**Example:** The following command sets an idle time of 12 seconds:

```
set interface serial1/0 modem idle-time 12
```

**Example:** The following command sets an idle time of 12 seconds for the basic rate interface (BRI):

```
set interface bri1/0 idle-time 12
```

**interval**

```
set interface interface modem interval number
set interface interface interval number
unset interface interface modem interval number
unset interface interface interval number
```

**interval** Specifies the seconds (*number*) between dial-up retries. Valid interval range is 1-60 seconds and the default is 60 seconds.

**Example:** The following command sets a dial-up interval of 45 seconds:

```
set interface serial1/0 modem interval 45
```

**Example:** The following command sets a dial-up interval of 45 seconds for the basic rate interface (ISDN):

```
set interface bri1/0 interval 45
```

## ip

```
set interface [interface | grp_name] ip ip_addr/mask [secondary]
set interface interface ip unnumbered interface interface2
unset interface [interface | grp_name] ip ip_addr
```

**ip** The IP address *ip\_addr* and netmask *mask* for the specified interface or subinterface. Use this command to add a virtual IP to a VRRP interface. Each interface can support one virtual IP only. The **secondary** switch specifies that the IP address is a secondary address.

Use the **unnumbered** option if the tunnel interface does not need to support policy-based NAT and if your configuration does not require the tunnel interface to be bound to a tunnel zone.

The **unnumbered** option specifies that the tunnel interface is unnumbered. It does not have an IP address, but instead borrows the IP address from another interface (*interface2*). The other interface is bound to the same security zone.

**Warning:** RIP is *not* supported over unnumbered tunnel interfaces. All interfaces that use RIP protocol must be numbered. Any attempt to configure and run an unnumbered interface using RIP may lead to unpredictable routing failure.

**Example:** The following commands create logical interface ethernet3/1.2, bind it to the Trust zone, and assign it IP address 10.1.40.3/24:

```
set interface ethernet3/1.2 zone trust
set interface ethernet3/1.2 ip 10.1.40.3/24
```

## ip unnumbered interface

```
set interface interface ip unnumbered interface src interface
```

**ip unnumbered interface** Enables the local address to be derived from a source interface (*src interface*) that has been configured with an IP address.

## isdn

```
get interface interface isdn { ... }
set interface interface isdn { ... }
unset interface interface isdn { ... }
```

**q921** Displays information about the Q921 protocol or responses exchanged during peer-to-peer communication carried over the D channel.

- **statistics**—Shows the number of transmitted and received frame types.

- **status**—Displays the Layer 2 status, TEI state and the TEI assigned value.

**q931** Displays information about the Q931 protocol.

- **statistics**—Shows the number of transmitted and received message types.

- **status**—Displays the number of Active calls.

**calling-number string** Supplies the ISDN network with a billing number for outgoing calls. The device dials the number, and the switch selects the route. Some networks offer better pricing on calls where the number is presented. When configured, this information is included in the outgoing call setup message.

|                                            |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|--------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| leased-line<br>128Kbps                     | Specifies a Layer 3 interface and is predefined for a data rate of 128 Kbps. There is no signaling on the D channel, and the leased line is used to deliver data only.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| send-complete                              | Includes send-complete information in the outgoing setup message to indicate that the entire number is included. ISDN switches require this information in certain geographic locations, such as Hong Kong and Taiwan. This information element is generally not required in other locations. The default is not set.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| spid1 <i>string</i><br>spid2 <i>string</i> | <p>Specifies the service available to you on the ISDN switch that defines the feature set ordered when you provisioned for the ISDN service. A Service Profile Identifier (SPID) number is usually a seven-digit telephone number with some optional numbers. However, service providers may use different numbering schemes.</p> <p>If you are using a service provider that requires an SPID, your device cannot place or receive calls until it sends a valid, assigned SPID to the service provider when it accesses the ISDN switch to initialize the connection.</p> <p><b>Note:</b> Currently, only the DMS-100 and ni1 ISDN switch types require SPIDs. For the DMS-100 switch type, two SPIDs are assigned, one for each B-channel. Do not specify SPID numbers, if you selected the AT&amp;T 5ESS ISDN switch type. In addition, SPIDs are important at the local access ISDN interface only. Remote routers never receive the SPID number.</p> |
| switch-type                                | <p>Specifies the ISDN switch type:</p> <ul style="list-style-type: none"> <li>■ <b>att5e</b>—AT&amp;T 5ESS</li> <li>■ <b>etsi</b>—European variant</li> <li>■ <b>ins-net</b>—NTT INS-NET</li> <li>■ <b>ni1</b>—National ISDN-1</li> <li>■ <b>ntdms100</b>—Nortel DMS100</li> </ul> <p>Choose the switch with the help of your ISP. Do not change the switch type during operation. The updated switch type will take effect after the device reboots.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| t310-value<br><i>number</i>                | <p>Sets the timeout value in seconds if ALERT, CONNECT, DISC, or PROGRESS is not received after a CALL PROC. Then, a DISC is sent to the network side for the duration of the T310 timeout value.</p> <p>The range is 5-100 and the default is 10.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| tei-negotiation                            | <p>Identifies the Terminal Endpoint Identifier (TEI) that connects to the ISDN switch. It is always dynamically assigned by the ISDN switch. Both settings conform to different standards, ANSI &amp; ETSI. The default is <b>first-call</b>.</p> <ul style="list-style-type: none"> <li>■ <b>first-call</b>—Enables the device to activate the TEI negotiation when the first call is made.</li> <li>■ <b>power-up</b>—Allows the switch to assign TEI once the device boots up.</li> </ul> <p>TEI negotiation is useful for switches that may deactivate Layers 1 or 2 when there are no active calls. Typically, this setting is used for ISDN service offerings in Europe and connections to DMS-100 ISDN switches that are designed to initiate TEI negotiation.</p>                                                                                                                                                                                 |

## isp

```
set interface interface modem isp name_str { ... }
unset interface interface modem isp name_str
```

isp Specifies the ISP.

**Example:** The following command configures the login *juniper* and the password *bodie45* for the ISP *isp1*:

```
set interface serial1/0 modem isp isp1 account login juniper password bodie45
```

## isp-failover

```
set interface interface modem isp-failover holddown number
set interface interface modem isp-failover type { route | track-ip | vpn } vrouter vr_name
ipaddr/mask
unset interface interface modem isp-failover holddown
unset interface interface modem isp-failover type
```

isp-failover Allows you to configure up to four ISPs for failover and dial-up connections. The holddown timer and type arguments can be configured as follows:

- **holddown** *number*—Specifies the number of seconds to wait before initiating failover. The default value is 30 seconds; however, the valid range is between 1 and 300 seconds. The **unset** command returns the holddown value to the default. Using the **set** command twice overwrites the previous value.
- **type { ... } vrouter** *vr\_name ip\_addr/mask*—Specifies a route generated by a dynamic routing protocol such as OSPF or BGP. The security device monitors the status of the interface in the virtual router. this feature is disabled by default.

## keepalives

```
set interface interface keepalives { interval seconds | down-count number / up-count
number }
```

keepalives By default, physical interfaces configured with Cisco-HDLC or PPP encapsulation send keepalive packets at 10-second intervals. You can configure the following keepalive parameters:

- **interval**—Specifies the interval at which the interface sends keepalive packets on a link. The default is 10 seconds. Specify a value between 1-32767 seconds.
- **down-count**—Specifies the number of successive times that a destination fails to receive keepalive packets before it considers the link to be down. The default is 3 times. Specify a value between 1-255.
- **up-count** (Cisco HDLC encapsulation only)—Specifies the number of times that a destination must receive a keepalive packet before it considers the link to be up. The default is 0 (disabled). Specify a value between 1-255.

## load-threshold

```
set interface interface load-threshold number
unset interface interface load-threshold number
```

load-threshold Sets up the second B channel for bandwidth on demand and if the traffic is greater than the load-threshold (in percentage). The range is from 1-100 and the default is 80.

## loopback-group

```
set interface interface1 loopback-group loopback.n
unset interface interface1 loopback-group loopback.n
```

**loopback-group** Adds a specified interface (*interface1*) to the loopback group for a designated loopback interface (loopback.*n*). All members in the loopback group can share the mapped IP (MIP) and dynamic IP (DIP) definitions assigned to the loopback interface itself.

**Example:** The following commands add interfaces ethernet1 and ethernet2 to the loopback group for loopback.1, and then assign a MIP to loopback.1. This allows both ethernet1 and ethernet2 to use the assigned MIP.

```
set interface ethernet1 loopback-group loopback.1
set interface ethernet2 loopback-group loopback.1
set int loopback.1 mip 1.1.1.1 host 10.1.1.8 netmask 255.255.255.0
```

## mac-table

```
get interface interface mac-table
```

**mac-table** Displays the MAC addresses learned by each member of a bgroup interface.

**Example:** The following command displays the MAC address learning tables for every member of bgroup4/1

```
get interface bgroup4/1 mac-table
```

## manage

```
set interface interface manage
{ ident-reset | mtrace | nsmgmt | ping | snmp | ssh | ssl | telnet | web }
unset interface interface manage
{ ident-reset | mtrace | nsmgmt | ping | snmp | ssh | ssl | telnet | web }
```

**manage** Enables or disables monitoring and management capability through the interface.

- **ident-reset**—Directs the security device to send a TCP Reset announcement, in response to an IDENT request, to port 113.
- **nsmgmt**—Enables or disables Network and Security Manager (NSM) on the interface. NSM is an enterprise-level management application that configures security devices from remote hosts. For more information, see “nsmgmt” on page 457.
- **mtrace**—Enables (or disables) mtrace manageability on the interface. (Mtrace traces a route to the source device using a multicast address.)
- **ping**—Enables (or disables) pinging through the interface.
- **snmp**—Enables (or disables) SNMP management through the interface.
- **ssh**—Enables (or disables) SSH management through the interface.
- **ssl**—Enables (or disables) SSL management through the interface.
- **telnet**—Enables (or disables) telnet management through the interface.
- **web**—Enables (or disables) Web management through the interface.

**Example:** The following command enables management of SSH through interface *ethernet3*:

```
set interface ethernet3 manage ssh
```

## **manage-ip**

```
set interface interface manage-ip ip_addr
unset interface interface manage-ip
```

**manage-ip** Defines the Manage IP address for the specified physical interface. External applications such as Telnet or WebUI can use this address to configure and monitor the security device. (This address must be in the same subnet as the interface IP address.)

**Example:** The following commands bind interface *ethernet4/1* to the Trust zone, then set the Manage IP address to 10.1.10.10:

```
set interface ethernet4/1 zone trust
set interface ethernet4/1 manage-ip 10.1.10.10
```

## **minimum-links**

```
set interface bundle minimum-links number
```

**minimum-links** (For multilink bundle interfaces only)—Sets the minimum number of bundle links that must be up for the bundle to be considered up. The default is 1. You can specify a value between 1-8.

## **mip**

```
set interface interface mip ip_addr1 host ip_addr2 [vrouter vrouter] [netmask mask]
unset interface interface mip ip_addr1 [netmask mask]
```

**mip** Defines a mapped IP (MIP) address for the security interface. The device directs traffic sent to the MIP (*ip\_addr1*) to the host with the IP address *ip\_addr2*. Setting a MIP for an interface in any zone generates a book entry for the MIP in the Global zone address book. The Global zone address book keeps all the MIPs of all interfaces, regardless of the zone to which the interfaces belong.

You can use these MIP addresses as the destination addresses in policies between any two zones, and as the source addresses when defining a policy from the Global zone to any other zone.

- **host *ip\_addr2***—Specifies the IP address of a host device that uses IPv4 addressing. The netmask value specifies either a single one-to-one mapping or a mapping of one IP address range to another.  
**Note:** Be careful to exclude the interface and gateway IP addresses, and any virtual IP addresses in the subnet from the MIP address range.)
- **vrouter *vrouter***—Identifies the virtual router containing a route to the host device.
- **netmask**—Specifies the range of host IP addresses.

**Example:** The following commands use a MIP to allow remote hosts to request HTTP services from a local HTTP server, located in a nonroutable subnet, over a public WAN infrastructure. The MIP directly translates all outgoing source IP addresses into public addresses.

1. Set up Ethernet interfaces.

```
unset interface ethernet2 ip
unset interface ethernet2 zone
unset interface ethernet3 ip
unset interface ethernet3 zone

set interface ethernet2 zone trust
set interface ethernet2 ip 10.100.2.1/24
set interface ethernet3 zone untrust
set interface ethernet3 ip 1.1.12.1/24
```

2. Create a MIP definition for the interface bound to the Untrust zone.

```
set interface ethernet3 mip 2.2.22.5 host 10.100.2.5 vrouter trust-vr
```

3. Create a policy definition that invokes the MIP.

```
set policy from untrust to trust any mip(2.2.22.5) http nat permit
save
```

## ***mlfr-uni-nni***

set interface *interface* mlfr-uni-nni ...

- mlfr-uni-nni (For multilink bundle links only)—Configures options for Multilink Frame Relay FRF.16 operations. You can configure the following:
- **acknowledge-retries** *number*—Specifies the number of retransmission attempts to be made for consecutive hello or remove-link messages after the expiration of the acknowledgement timer. The default is 2. Specify a value between 1-5.
  - **acknowledge-timer** *milliseconds*—Specifies the maximum period, in milliseconds, to wait for an add-link, hello, or remove-link acknowledgement. The default is 4 milliseconds. Specify a value between 1-10.
  - **fragment-threshold** *bytes*—Specifies the maximum size for packet payloads transmitted across bundle links within a multilink circuit. The default is the maximum transmission unit (MTU) of the physical link. Specify a multiple of 64 bytes.
  - **hello-timer** *milliseconds*—Specifies the rate, in milliseconds, at which hello messages are sent. The default is 10 milliseconds. Specify a value between 1-180.

**modem**

```
set interface interface modem { ... }
unset interface interface modem { ... }
```

**modem**

Configures modem settings for the specified interface.

The modem keyword options are as follows.

- **aux enable**—Enables dial-in console management via the v.92 modem.
- **idle-time *number***—Specifies the number of minutes allowed to elapse with no traffic on the dial-up connection before the security device disconnects the modem. The default is 1 minute. A value of 0 means the modem never disconnects, even if there is no traffic on the dial-up connection.
- **interval *number***—Specifies the seconds (*number*) between dial-up retries. The default is 60 seconds. The range is 3-60 seconds.
- **retry *number***—Specifies the number of times ScreenOS dials the primary number, and then the alternative-number, if the line is busy or there is no answer from the ISP. The default is 3 times. The range is 0-10 times.
- **settings *name\_str* { active | init-strings *name\_str* }**—Configures settings for the specified modem or ISP.
- **speed *number***—Specifies the maximum baud rate for the serial link between the device and the modem. The baud rate can be 9600, 19200, 38400, 57600, or 115200 bps. The default is 115200 bps.
- **isp *name\_str* { account login *name\_str* password *pass\_str* | priority *number* }**—Configures ISP information.
- **isp-failover { holddown *number* | type { route | track-ip | vpn } vroute *name\_str* }**—Allows you to configure up to four ISPs for failover and dial-up connections. The holddown timer and type arguments can be configured as follows:
  - **holddown *number***—Specifies the number of seconds to wait before initiating failover. The default value is 30 seconds; however, the valid range is between 1 and 300 seconds. The **unset** command returns the holddown value to the default. Using the **set** command twice overwrites the previous value.
  - **type { ... } vrouter *vr\_name ip\_addr/mask***—Specifies a route generated by a dynamic routing protocol such as OSPF or BGP. The security device monitors the status of the interface in the virtual router. this feature is disabled by default.

**monitor**

```
set interface interface monitor { ... }
unset interface interface monitor { ... }
```

**monitor**

Configures monitoring for the specified interface.

An interface can monitor objects for any of the following events. Each of these events by itself or in combination can cause the state of the monitoring interface to change from up to down or from down to up.

- Physical disconnection or reconnection
- IP tracking failure or success

When the tracking of an IP address fails, the device compares the weight assigned to the tracked IP address with the failure threshold for tracked objects. If the number of failures exceed the threshold, the device compares the weight for tracked objects with the failure threshold. If the number of failures exceeds the threshold, the interface changes its state (from up to down, or down to up).

- Failure or success of a monitored interface

When a monitored interface changes state, the device compares the weight assigned to the monitored interface with the failure threshold for interface monitoring. If the number of failures exceeds the threshold, the interface changes its state (from up to down, or down to up).

- Failure or success of a monitored security zone

An interface can monitor all the interfaces in any security zone other than its own. For an entire security zone to fail, every interface bound to that zone must fail. As long as one interface bound to a monitored zone is up, the device considers the entire zone to be up. When a monitored zone changes state, the security device compares the weight assigned to the monitored zone with the failure threshold.

The security device uses ping requests to poll the remote device.

The monitoring keyword options are as follows.

- **interface** *interface* [ **weight** *number* ]—Identifies the interface from which the device sends the ping requests, and the relative weight assigned to the interface.
- **threshold** *number* [ action { down | up } { logically | physically } ]—The failure rate at which the interface goes from up to down or down to up.
- **track-ip**—Configures the Track IP feature.
  - **dynamic**—Configures tracking of the IP address (only for IPv4) of the default gateway for the interface.
  - **ip** [ *ip\_addr* ]—Identifies the tracked IP address (for both IPv4 and IPv6).
  - **interval** *number*—Specifies the interval, in seconds, that ping requests are sent to the tracked IP address. If you are unsetting the interval for the tracked IP address, the interval is changed to the default value of 1.
  - **threshold** *number*—Indicates the number of consecutive failures required to elicit a ping response from a specific IP address required to be considered a failed attempt.
  - **weight** *number*—Indicates the weight of the IP address. The weight is the amount that the tracked object failure contributes toward the monitored object failure threshold.
- **zone** *zone* [ **weight** *number* ]—Indicates the weight of the zone.

**mrru**

set interface *bundle* mrru *bytes*

mrru (For MLPPP bundle interfaces only)—Specifies the maximum packet size, in bytes, that the multilink interface can process. The default is 1500 bytes. Specify a value between 1500-4500.

**mtrace**

set interface *interface* mtrace  
unset interface *interface* mtrace

mtrace Allows you to do packet tracing from a multicast receiver to a source.

**mtu**

set interface *interface* mtu *number*  
unset interface *interface* mtu

mtu Sets the Maximum Transmission Unit (MTU) for the interface. The MTU is the largest physical packet size (in octets) that the device can transmit on the interface. The security device must fragment any messages larger than the MTU before sending them. The default MTU size is 1500 octets. Enter a value between 1280 and 8192.

**nat**

set interface *interface* nat

nat Directs the device to perform Network Address Translation (NAT) on outbound traffic from the trusted LAN. This option is only available when the device is in route mode, in which the interfaces have assigned IP addresses.

**nhtb**

set interface *interface.number* nhtb *ip\_addr* vpn *tunn\_str*  
unset interface *interface.number* nhtb *ip\_addr*

nhtb Binds the specified VPN tunnel (**vpn** *tunn\_str*) to the tunnel interface and manually maps the specified VPN tunnel to the IP address of a remote peer's tunnel interface (*ip\_addr*) in the next-hop tunnel binding (NHTP) table. After that, you can enter a static route in the route table that uses that tunnel interface IP address as the gateway.

**Example:** With the following commands, you first bind vpn1 to tunnel.1 and map vpn1 to 10.2.3.1, which is the IP address of the remote peer's tunnel interface. Then you define a static route to 10.2.2.0/24, which is the address of the remote peer's internal LAN, through tunnel.1 in the trust-vr routing domain, using the remote peer's tunnel interface IP address (10.2.3.1) as the next-hop gateway:

```
set interface tunnel.1 nhtb 10.2.3.1 vpn vpn1
set vrouter trust-vr route 10.2.2.0/24 interface tunnel.1 gateway 10.2.3.1
```

**nsgp**

```
set interface interface nsgp [enforce-ipsec]
```

**nsgp** For GPRS systems, enables or disables the exchange of Overbilling Attack information through the specified interface on the security device. You must set an interface on both security devices: the GTP firewall (client) and the Gi firewall (server). The interface for the client and server must have different IP addresses. Also, you can enable NSGP on a physical Ethernet interface only.

The **enforce-ipsec** switch sets the interface to only accept incoming connections from an IPsec tunnel.

**ntp-server**

```
set interface interface ntp-server
unset interface interface ntp-server
```

**ntp-server** Enables NTP service on a specified Layer 3 interface with an IP address. If this option is set, the security device acts as an NTP server serving requests from the subnet peers.

**Note:** Currently, ScreenOS supports only unicast mode.

**pbr**

```
set interface interface pbr pbr_policy_name
unset interface interface pbr pbr_policy_name
```

**pbr** Enables a policy based routing (PBR) policy to be bound to the specified interface. If a PBR policy name is not specified, then any declared policy will be used. If no PBR policies exist at the zone or virtual router level, then normal route lookup is performed even though PBR is enabled on the interface. A lack of a PBR policy does not prevent the device from performing packet forwarding.

## phy

```
set interface interface phy { ... }
unset interface interface phy { ... }
```

**phy** Defines the physical connection mode on the specified interface.

- **auto** The security device automatically decides whether to operate at full-duplex or half-duplex (as required by the network device to which it is connected).
- **full**—Forces the security device to operate at full-duplex. Specify either 100Mbps or 10Mbps.
- **half**—Forces the security device to operate at half-duplex. Specify either 100Mbps or 10Mbps.
- **holddown** *number*—Sets the hold-down time for the link, in increments of 100 milliseconds.
- **link-down**—Forces the physical link down.
- **manual**—Specifies manual mode for a gigabit interface. Setting the gigabit interface to **manual** disables auto-negotiation.

**Note:** You must configure both sides in the same negotiation mode, or the link does not initiate.

## phy operating-mode

```
set interface interface phy operating-mode { ... }
unset interface interface phy operating-mode { ... }
```

**phy operating-mode** Sets the physical operating mode for the ADSL or SHDSL interface.

- **ADSL Options**
  - **adsl2**—Specifies—Specifies ITU G.992.3 (G.dmt.bis) mode
  - **adsl2plus**—Specifies ITU G.992.5 mode.
  - **annex-b-non-ur2** (Annex B interfaces only)—Specifies ITU G.992.1 non-UR-2 mode.
  - **annex-b-ur2** (Annex B interfaces only)—Specifies ITU G.992.1 Deutsche Telekom UR-2 mode.
  - **ansi**—Specifies ANSI T1.413 Issue 2 mode.
  - **auto**—Automatically negotiates the operating mode to match the setting of the DSLAM located at the central office.
  - **etsi**—Specifies ETSI TS 101 388 V1.3.1 mode.
  - **gdmt**—Specifies ITU G.992.1 mode.
  - **gdmtbis**—Specifies ITU G.992.3 mode.
  - **itu-dmt**—Specifies ITU G.992.1 mode.
  - **t1.413** (Annex A interfaces only)—Specifies ANSI T1.413 mode.

- phy  
operating-mode
- SHDSL Options
    - **annex**—Sets the annex type for the interface.
      - **annex-a**—Used in North American network implementations.
      - **annex-b**—Used in European network implementations. This is the default.
    - **line-rate** *option*—Specifies the available line rates, in kilobits per second, to use on the interface. Select the appropriate value.
    - **loopback**—Specifies the type of loopback testing for the interface.
      - **local**—Tests the G.SHDSL equipment with local network devices.
      - **remote**—Tests the G.SHDSL equipment with a remote network configuration.
    - **oam-liveness** { **down-count-cell** *number* | **up-count-cell** *number* } —Specifies the operation, administration, and maintenance (OAM) F5 loopback thresholds on ATM virtual circuits.
      - **down-count-cell** *number*—Specifies the number of consecutive OAM loopback cells an ATM virtual circuit must lose to be identified as unavailable. The default is 5.
      - **up-count-cell** *number*—Specifies the number of consecutive OAM loopback cells an ATM virtual interface must receive to be identified as operational. The default is 5.
    - **oam-period** *number*—Specifies the interval, in seconds, at which OAM cells are transmitted on ATM virtual circuits. The range is between 1 and 900 seconds. The default is 0, which disables OAM.
    - **snr-margin**—Sets the signal-to-noise ratio (SNR).
      - **current** *number*—Specifies the SNR margin or disables SNR. The default is 0.
      - **snext** *number*—Specifies a value, from -10 dB to 10 dB, for the self-near-crosstalk (SNEXT) SNR margin, or disables SNEXT. The default is 0.

**Example:** The following command sets the adsl1 interface to use the ADSL2 operating mode:

```
set interface adsl1 phy operating-mode adsl2
save
```

**Example:** The following command sets the shdsl1/0 interface:

```
set interface shdsl1/0 phy operating-mode 1-port-atm
set interface shdsl1/0 phy operating-mode loopback remote
set interface shdsl1/0 phy operating-mode snr margin current 2
save
```

## ***pmtu ipv4***

```
set interface interface pmtu ipv4
unset interface interface pmtu ipv4
```

**pmtu ipv4** Determines whether the interface sends the source host an ICMP message stating that a packet size is too large (ICMP type 3, code 4 "Fragmentation needed and DF set") when it receives a packet meeting the following conditions:

- The Don't Fragment (DF) bit is set in the IP header.
- The size of the packet after encapsulation exceeds the maximum transfer unit (MTU) of the egress interface.

When you enable (set) the pmtu option, the interface sends the source host the above ICMP message. When you disable (unset) this option, the interface ignores the DF bit, fragments the packet so that none of the fragmented packets exceeds the MTU of the egress interface, and forwards them. By default, this option is disabled.

**Note:** This option is equivalent to "set flow path-mtu," but specific for the interface.

## ***port***

```
set interface interface port port_num
```

**port** Binds a port to the bridge group (bgroup) interface specified by *interface*.

**Note:** Different types of security devices have different systems for numbering bgroups. Use "set interface ?" to determine the bgroup numbering system that applies to your device.

**Example:** The following command binds port ethernet0/2 to the bridge group 1 (bgroup1) interface:

```
set interface bgroup1 port ethernet0/2
```

**Example:** The following command binds port ethernet0/2 to the bridge group 0/1 (bgroup0/1) interface:

```
set interface bgroup0/1 port ethernet0/2
```

## ***ppp***

```
get interface interface ppp
```

**ppp** Shows the statistics and configuration information for an interface configured for Point-to-Point Protocol (PPP) or Multilink PPP (MLPPP). The interface can be a WAN interface, a bundle interface, or a WAN interface that is a member of a MLPPP bundle interface.

## ***ppp profile***

```
set interface interface ppp profile profile
```

**ppp profile** Binds the Point-to-Point Protocol (PPP) profile to the specified interface. You configure PPP profiles with the **set ppp profile** command.

**primary-number**

```
set interface interface primary-number string
unset interface interface primary-number string
```

**primary-number** *string* Specifies the remote destination to call. If the primary number is not connected, **alternative-number** is used. **primary-number** is a string from 1 to 15 characters.

**priority**

```
set interface interface modem isp name_str priority number
```

**priority** Specifies the priority of this ISP for dial-up backup, relative to other ISPs that may be configured. A value of 1 is the highest priority. *number* can be 0 or 1-4.

**Example:** The following command configures the ISP *isp1* as the highest priority for dial-up backup:

```
set interface serial1/0 modem isp isp1 priority 1
```

**protocol**

```
set interface interface protocol igmp host
set interface interface protocol igmp router
set interface interface protocol igmp { host { ... } | router { ... } }
set interface interface protocol ospf
set interface interface protocol ospf { ... }
set interface interface protocol irdp { ... }
set interface interface protocol pim
set interface interface protocol pim { ... }
set interface interface protocol rip
set interface interface protocol rip { ... }
set interface interface protocol vrrp
set interface interface protocol vrrp { ... }
set interface grp_name protocol vrrp { ... }
```

```
unset interface interface protocol bgp
unset interface interface protocol bgp { ... }
unset interface interface protocol ospf
unset interface interface protocol ospf { ... }
unset interface interface protocol rip
unset interface interface protocol rip { ... }
unset interface interface protocol igmp
unset interface interface protocol igmp { ... }
unset interface interface protocol irdp { ... }
unset interface interface protocol pim
unset interface interface protocol pim { ... }
unset interface interface protocol irdp { ... }
unset interface interface protocol vrrp
unset interface interface protocol vrrp { ... }
unset interface grp_name protocol vrrp { ... }
```

## protocol rip

Sets, unsets, or displays the current RIP settings for the interface.

**Note:** RIP is *not* supported over unnumbered tunnel interfaces. All interfaces that use RIP protocol must be numbered. Any attempt to configure and run an unnumbered interface using RIP may lead to unpredictable routing failure.

- **authentication** { **password** *pswd\_str* | **md5** *key\_str* **key-id** *id\_num* }  
—Specifies the authentication method used to verify RIP neighbors.
  - **password**—Specifies a clear-text password used for verification. If you specify password authentication, you must also specify an 8-byte password.
  - **md5**—Directs the security device to use the Message Digest version 5 (MD5) authentication algorithm for verification. If you specify MD5 authentication, you must also specify a 16-byte key and, optionally, a key identifier (the default identifier is 0). You can specify more than one MD5 key with different key identifier numbers (between 0-255). If there are multiple MD5 keys configured, you can use the **active-md5-key-id** option to select the key identifier of the key to be used for authentication.
- **demand-circuit** (For tunnel interfaces only)—Enables the demand circuit feature (RFC 2091) on the specified interface.
- **enable**—Enables RIP on the specified interface.
- **metric** *number*—Configures the RIP metric for the specified interface. The default metric is 1.
- **neighbor** *ip\_addr*—Configures a static RIP neighbor on the specified interface. This can be used when configuring point-to-multipoint RIP interfaces.
- **passive-mode**—Specifies that the interface is to receive but not transmit RIP packets.
- **receive-version** *v1* | *v1v2* | *v2*—Specifies the RIP protocol version for updates that the specified interface receives. The default version is the version that is configured for the virtual router.
- **route-map** *name\_str*—Specifies the route-map on which to filter incoming routes (routes learned by RIP) or outgoing routes (routes advertised by RIP).
  - **in**—Specifies the route map is to be used for incoming routes.
  - **out**—Specifies the route map is to be used for outgoing routes.
- **send-version** *v1* | *v1v2* | *v2*—Specifies the RIP protocol version for updates that the specified interface sends. The default version is the version that is configured for the virtual router.
- **split-horizon**—Enables the split-horizon function on the specified interface. If **split-horizon** is enabled, RIP does not advertise routes learned from a neighbor back to the same neighbor. This avoids the routing-loop problem that occurs in some routing situations. If **split-horizon** is disabled, RIP advertises routes learned from a neighbor as they exist in the RIP database. By default, **split-horizon** is enabled.

When you enable the poison-reverse switch, RIP still advertises routes learned from a neighbor back to the same neighbor, but defines the metric for those routes as infinity (16). This causes the neighbor to immediately remove the route, thus breaking a potential routing loop faster than with split-horizon alone. When you disable this switch, RIP advertises routes learned from a neighbor back to the same neighbor with the correct metric.



- **retransmit-interval** *number*—Specifies the amount of time (in seconds) that elapses before the interface resends a packet to a neighbor that did not acknowledge a previous transmission attempt for the same packet.
  - **transit-delay** *number*—Specifies the amount of time (in seconds) that elapses before the security device advertises a packet received on the interface.
- protocol igmp Sets, unsets, or displays the current IGMP settings for the interface.
  - **accept groups**—Specifies the access list that identifies the multicast groups the hosts on the specified interface can join. Enter this command only if the interface is in router mode.
  - **accept hosts**—Specifies the access list that identifies from which hosts the interface can receive Join and Leave messages. After you have set this command, the interface accepts Join and Leave messages only from the hosts in the access list. Enter this command only if the interface is in router mode.
  - **accept routers**—Specifies the access list that identifies the routers that are eligible for Querier selection. Only the routers in this list can be elected as Querier. Enter this command only if the interface is in router mode.
  - **always**—Enables the interface to forward IGMP messages even if it is a non-Querier. Enter this command only if the interface is in router mode and IGMP proxy is enabled.
  - **enable**—Enables or disables the IGMP protocol on the interface.
  - **host**—Creates an IGMP host instance on the specified interface.
  - **join-group**—Enables the interface to join the specified multicast group. Enter this command only if the interface is in router mode.
  - **last-member-query-interval**—Sets the interval (in seconds) the Querier waits for a response to a group-specific query before it stops sending multicast traffic for that particular group on the specified interface (range 1 - 25 inclusive). Enter this command if the interface is in router mode and is running IGMP version 2.
  - **leave-interval**—Sets the interval (in seconds) between group-specific-queries (range 1 - 255 inclusive). Enter this command if the interface is in router mode.
  - **no-check-router-alert**—IGMP packets contain a router-alert IP option. By default, an IGMP-enabled device checks IGMP packets for this option and drops packets without it. Enter this command to accept all IGMP packets without checking for the router-alert option.
  - **no-check-subnet**—By default, an IGMP interface accepts IGMP packets only from its own subnet. Enter this command to allow the interface to accept IGMP packets (queries, membership reports, and Leave messages) from any subnet.
  - **proxy**—When the interface is in router mode, enables IGMP proxy mode.
  - **query-interval**—Specifies the interval (in seconds) between General Queries (range 1 - 255, inclusive). Enter this command if the interface is set to router mode and is the Querier for a multicast group.
  - **query-max-response-time**—Sets the maximum number of seconds that elapses between the time a Querier sends a general query and the time a host responds to it (range 1 - 25, inclusive). Enter this command if the interface is in router mode.
  - **router**—Sets the specified interface to router mode.

- **static-group**—Manually adds the multicast group to the specified interface. Enter this command only if the interface is in router mode.
  - **version**—Specifies the IGMP version. When an interface is in Host mode, the device automatically sets the IGMP version. When an interface is in router mode, it runs IGMP version 2 by default. Enter this command to change the IGMP version of a router interface. Security devices support IGMP versions 1, 2, and 3.
- protocol irdp Sets or unsets the current ICMP Router Discovery Protocol (IRDP) settings for an interface. **Note:** This feature is available only on certain platforms.
- **ip\_addr { advertise | preference number }**
    - **advertise**—Indicates that you want to advertise one of the interface's IP addresses to the network.
    - **preference**—Indicates the preference status of this device. The value range is -1 to 2147483647. Higher numbers have greater preference.
  - **broadcast-address**—Enables sending of broadcast advertisements. The default address is 224.0.0.1 (all hosts on the network).
  - **enable**—Enables or disables IRDP on the interface. IRDP is disabled by default. Enabling this feature initiates an immediate advertisement to the network. Disabling this feature causes all IRDP-related memory for this interface to be removed. To disable this feature, use the **unset interface interface\_name protocol irdp enable** command.
  - **init-adv-interval seconds**—The number of seconds during the IRDP startup period allocated for advertisement. The range is 1 through 32 seconds. By default, the period is 16 seconds.
  - **init-adv-packet seconds**—By default, the device sends three advertisement packets during the specified startup period (init-adv-interval). Use this command to change this setting to a number from 1 through 5.
  - **lifetime seconds**—The lifetime of the advertisement. By default, the lifetime value is three times the max-adv-interval value. The range is the maximum advertisement interval (4 through 1800 seconds) through 9000 seconds.
  - **max-adv-interval upper\_limit**—Configures the upper limit in seconds. When you change this value, the min-adv-interval and lifetime automatically update to reflect the new upper limit. The default value is 600 seconds. The upper limit can be from 4 through 1800 seconds.
  - **min-adv-interval lower\_limit**—The lower limit of the advertisement period, which is 75 percent of the max-adv-interval value. You can change this value to a number between 3 and the max-adv-interval value. When you change the max-adv-interval value, the min-adv-interval value is automatically calculated.
  - **response-delay seconds**—By default, the device waits 0 to 2 seconds before responding to a client-solicitation request. You can change the response delay setting to no delay (0 seconds) to up to a 4-second delay.
- protocol pim Sets, unsets, or displays the current PIM settings for the interface.
- **boot-strap border**—Configures the interface as a border for bootstrap (BSR) messages. The interface receives and processes BSR messages, but does not forward these messages to other interfaces even if there is a multicast group policy that allows BSR messages between zones.
  - **dr-priority**—Configures the priority of the interface during the designated router election.
  - **enable**—Enables or disables the PIM-SM protocol on the interface.

- **hello-interval**—Specifies the interval (expressed in seconds) at which the interface sends hello messages to its neighbors.
- **join-prune-interval**—Sets the interval (expressed in seconds) at which the interface sends join-prune messages.
- **neighbor-policy**—Identifies the access list that allows or disallows certain neighbor adjacencies.

Sets or unsets aVRRP instance on the specified interface.

- **enable**—Enables or disables VRRP on the interface. The default option is disable. If you select disable, the interface will not disable the VRRP configuration but will ignore all VRRP packets.
- **preempt [hold-down *seconds*]**—Defines the preempt hold-down time for VRRP on the interface. By default, the preempt option is disabled. When the preempt option is enabled, the default hold-down time is 3 seconds. The hold-down time ranges from 0–255.
- **advertise-interval *seconds***—Defines the advertise interval for the VRRP group. The default interval time is 1 second. The interval time ranges from 0–255.
- **priority *number***—Sets VRRP group priority. The default value is 100 and the valid range is 1–254.

**proxy dns**

```
set interface interface proxy dns
```

- proxy dns** Directs the device to use proxy DNS feature.
- The proxy DNS feature provides a transparent mechanism that allows clients to make split DNS queries. Using this technique, the proxy selectively redirects the DNS queries to specific DNS servers, according to partial or complete domain names. This is useful when VPN tunnels or PPPoE virtual links provide multiple network connectivity, and it is necessary to direct some DNS queries to one network, and other queries to another network.
- The most important advantages of a DNS proxy are as follows.
- Domain lookups are usually more efficient. For example, DNS queries meant for the corporate domain (such as acme.com) could go to the corporate DNS server exclusively, while all others go to the ISP DNS server, thus reducing the load on the corporate server. In addition, this can prevent corporate domain information from leaking into the internet.
  - DNS proxy allows you to transmit selected DNS queries through a tunnel interface, thus preventing malicious users from learning about internal network configuration. For example, DNS queries bound for the corporate server can pass through a tunnel interface, and use security features such as authentication, encryption, and anti-replay.

**pvc**

```
set interface interface pvc pvc_num [mux { vc | llc }] [qos { ... } [protocol { routed | bridged }]] zone zone_name
unset interface interface pvc pvc_num
```

- pvc** Specifies the VPI and VCI numbers for an ADSL interface. Valid VPI range is 0-255, default is 8. Valid VCI range is 32-65535, default is 35.
- mux** Sets the encapsulating method for carrying network traffic for an ADSL interface. The default mux is LLC.
- qos** Sets the ATM QoS type. The qos keyword options are as follows:
- **cbr** specifies the CBR service class.
  - **ubr** specifies the UBR service class.
  - **vbr-nrt** specifies the VBR-NRT service class.
- protocol** Sets the protocol type for an ADSL interface. The default protocol is bridged.

**Example:** The following command sets the adsl1 interface to have a pvc of 1/35, the mux as vc, and binds the interface to the DMZ security zone:

```
set interface adsl1 pvc 1/35 mux vc zone dmz
```

**retry**

```
set interface interface modem retry number
set interface interface retry number
unset interface interface modem retry number
unset interface interface retry number
```

**retry** Specifies the number of times ScreenOS dials the primary number, and then the alternative-number, if the line is busy or there is no answer from the ISP. The default is 3 times. The range is 0-10 times.

**Example1:** The following command sets the number of dial-up retries to 4:

```
set interface serial1/0 modem retry 4
```

**Example2:** The following command sets the number of dial-up retries to 4 for the basic rate interface (ISDN):

```
set interface bri1/0 retry 4
```

**route-deny**

```
set interface interface route-deny
unset interface interface route-deny
```

**route-deny** Enabling this flag blocks all traffic in or out of the same interface. This includes traffic between the primary subnet and any secondary subnet, and one secondary subnet to another secondary subnet.

**screen**

```
get interface interface screen
```

**screen** Displays the current firewall (screen) counters.

**secondary**

```
set interface interface ip ip_addr/mask secondary
get interface interface secondary [ip_addr]
```

**secondary** Sets or displays the secondary address configured for the interface.

## serial-options

set interface *interface* serial-options ...

serial-options Specifies options for a serial interface. You can specify the following:

- **clock-rate**—Sets the clock rate for the interface, in Kilohertz (KHz) or Megahertz (MHz), for EIA-530 and V.35 interfaces (for X.21 interfaces, you must specify **loop** for the **clocking-mode** option). The default is 8.0 MHz. You can specify one of the following options:

- |           |            |            |          |
|-----------|------------|------------|----------|
| ■ 1.2khz  | ■ 56.0khz  | ■ 250.0khz | ■ 1.3mhz |
| ■ 2.4khz  | ■ 64.0khz  | ■ 500.0khz | ■ 2.0mhz |
| ■ 9.6khz  | ■ 72.0khz  | ■ 800.0khz | ■ 4.0mhz |
| ■ 19.2khz | ■ 125.0khz | ■ 1.0mhz   | ■ 8.0mhz |
| ■ 38.4khz | ■ 148.0khz |            |          |

- **clocking-mode**—Specifies the clock source to determine the timing on serial interfaces. You can specify one of the following:
  - **dce**—Uses a transmit clock generated by the data circuit-terminating equipment (DCE) for the SSG device's DTE. When the device is functioning as a DTE, you must use this clocking mode for all interfaces except X.21 serial interfaces.
  - **internal**—Uses the SSG device's internal clock. When the device is functioning as a DCE, we recommend that you use this clocking mode for all interfaces. You can configure the speed of the clock with the **clock-rate** option.
  - **loop**—Uses the DCE's or DTE's receive clock. For X.21 serial interfaces, you must use this clocking mode. This is the default.

- **dte-options**—Sets data terminal equipment (DTE) options/control leads. You can specify the following:
  - **cts**—Specifies the from-DCE clear to send (CTS) signal handling for EIA-530 and V.35 interfaces. You can specify one of the following:
    - **ignore**—Ignores CTS signal.
    - **normal**—Normal CTS signal, as defined by TIA/EIA Standard 530. This is the default.
    - **require**—The from-DCE CTS signal must be asserted.
  - **dcd**—Specifies the from-DCE data carrier detect (DCD) signal handling for EIA-530 and V.35 interfaces. You can specify one of the following:
    - **ignore**—Ignores DCD signal.
    - **normal**—Normal DCD signal, as defined by TIA/EIA Standard 530. This is the default.
    - **require**—The from-DCE DCD signal must be asserted.
  - **dsr**—Specifies the from-DCE data set ready (DSR) signal handling for EAI-530 and V.35 interfaces. You can specify one of the following:
    - **ignore**—Ignores DSR signal.
    - **normal**—Normal DSR signal, as defined by TIA/EIA Standard 530. This is the default.
    - **require**—The from-DCE DSR signal must be asserted.
  - **dtr**—Specifies data transmit ready (DTR) signal handling for EIA-530 and V.35 interfaces. You can specify one of the following:
    - **assert**—Asserts the DTR signal.
    - **auto-synchronize**—Normal DTR signal, with automatic resynchronization.
    - **de-assert**—Deasserts the DTR signal.
    - **normal**—Normal DTR signal, as defined by TIA/EIA Standard 530. This is the default.
  - **ignore-all**—Specifies that all control leads are ignored. By default, this is not set.
  - **rts**—Specifies the to-DCE request to send (RTS) signal handling for EIA-530 and V.35 interfaces. You can specify one of the following:
    - **assert**—Asserts the RTS signal.
    - **de-assert**—Deasserts the RTS signal.
    - **normal**—Normal RTS signal, as defined by TIA/EIA Standard 530. This is the default.
  - **tm**—Specifies the test mode (TM) signal for EIA-530 interfaces. You can specify one of the following:
    - **ignore**—Ignores TM signal.
    - **normal**—Normal TM signal. This is the default.
    - **require**—The from-DCE TM signal must be asserted.
- **encoding**—Sets line encoding. You can specify one of the following:
  - **nrz**—Nonreturn-to-zero. This is the default.
  - **nrzi**—Nonreturn-to-zero-inverted.

- **loopback**—Sets loopback mode. By default, no loopback mode is specified. You can specify one of the following:
  - **dce-local**—DCE local loopback (DTE mode only).
  - **local**—Local loopback.
  - **remote**—Remote/line interface unit (LIU) loopback.
- **transmit-clock**—Sets the transmit-clock phase. By default, this is not set. You can specify the following:
  - **invert**—Shift clock phase 180 degrees.

## settings

```
set interface interface modem settings name_str active | init-strings string
unset interface interface modem settings name_str
get interface interface modem settings
```

settings            Configures settings for the specified modem or ISP.

**Example:** The following command activates settings for the modem *usr14400*:

```
set interface serial1/0 modem settings usr14400 active
```

## shdsl-options

```
get interface interface shdsl-options { basic | statistics | training-status }
```

shdsl-options      Displays any of three types of information for the specified SHDSL interface:

- **basic**—Shows basic information for the SHDSL interface:
  - PIC mode
  - Annex type (A or B)
  - VPI and VCI
  - Line rate
  - Loopback status
  - SNR margin and snext settings
  - OAM period
  - Down- and up-count cell values
  - OAM link status
- **statistics**—Shows operating statistics for the SHDSL interface.
- **training**—Shows training status information for the SHDSL interface.

## short-sequence

```
set interface bundle short-sequence
```

short-sequence    (For MLPPP bundle interfaces only)—Specifies a sequence-header format of 12 bits. The default is 24 bits.

## **shutdown**

```
set interface interface shutdown
unset interface interface shutdown
```

shutdown            Disables a wireless interface. Also disables 802.1X on the interface.

## **speed**

```
set interface interface modem speed number
unset interface interface modem speed
```

speed                Specifies the maximum baud rate for the serial link between the device and the modem. The baud rate can be 9600, 19200, 38400, 57600, or 115200 bps. The default is 115200 bps.

**Example:** The following command sets a maximum baud rate of 56 Kbps for the serial link:

```
set interface serial1/0 modem speed 57600
```

## **status-change**

```
clear interface interface status-change
```

status-change        Specifies the number of times an interface has changed its status.  
Resets the interface counter value to zero for all physical interfaces.

**Example:** The following command resets the interface counter for physical interface serial2/1:

```
clear interface serial2/1 status-change
```

## **t1-options**

```
set interface interface t1-options ...
```

t1-options            Specifies options for a T1 interface. You can specify the following:

- **bert-algorithm**—Sets the bit error rate testing (BERT) algorithm for the interface. The algorithm is the pattern to send in the bitstream. You can specify one of the following options:
  - **all-ones-repeating**—Repeating one bits.
  - **all-zeros-repeating**—Repeating zero bits.
  - **alternating-double-ones-zeros**—Alternating pairs of ones and zeroes.
  - **alternating-ones-zeros**—Alternating ones and zeroes.
  - **pseudo-2e10**—Pattern is 2<sup>10</sup>-1.
  - **pseudo-2e11-o152**—Pattern is 2<sup>11</sup>-1 (per O.152 standard).
  - **pseudo-2e15-o151**—Pattern is 2<sup>15</sup>-1 (per O.152 standard). This is the default.

- **pseudo-2e17**—Pattern is  $2^{17-1}$ .
- **pseudo-2e18**—Pattern is  $2^{18-1}$ .
- **pseudo-2e20-o151**—Pattern is  $2^{20-1}$  (per O.151 standard).
- **pseudo-2e20-o153**—Pattern is  $2^{20-1}$  (per O.153 standard).
- **pseudo-2e21**—Pattern is  $2^{21-1}$ .
- **pseudo-2e22**—Pattern is  $2^{22-1}$ .
- **pseudo-2e23-o151**—Pattern is  $2^{23}$  (per O.151 standard).
- **pseudo-2e25**—Pattern is  $2^{25-1}$ .
- **pseudo-2e28**—Pattern is  $2^{28-1}$ .
- **pseudo-2e29**—Pattern is  $2^{29-1}$ .
- **pseudo-2e3**—Pattern is  $2^{3-1}$ .
- **pseudo-2e31**—Pattern is  $2^{31-1}$ .
- **pseudo-2e32**—Pattern is  $2^{32-1}$ .
- **pseudo-2e4**—Pattern is  $2^{4-1}$ .
- **pseudo-2e5**—Pattern is  $2^{5-1}$ .
- **pseudo-2e6**—Pattern is  $2^{6-1}$ .
- **pseudo-2e7**—Pattern is  $2^{7-1}$ .
- **pseudo-2e9-o153**—Pattern is  $2^{9-1}$  (per O.153 standard).
- **repeating-1-in-4**—1 bit in 4 is set.
- **repeating-1-in-8**—1 bit in 8 is set.
- **repeating-3-in-24**—3 bits in 24 are set.
- **bert-error-rate**—Sets the bit error rate (BER) to use in BERT. This can be an integer from 0 to 7, which corresponds to a BER from  $10^0$  (1 error per bit) to  $10^{-7}$ . The default is 0.
- **bert-period**—Sets the length of the BERT, in seconds. The range is 1 -240. The default is 10.
- **buildout**—Sets the T1 cable length in feet. You can specify the following:
  - **0-132**—0-40 meters. This is the default.
  - **133-265**—40-81 meters.
  - **266-398**—81-121 meters.
  - **399-531**—121-162 meters.
  - **532-655**—162-200 meters.
- **byte-encoding**—Sets the byte-encoding method. You can specify one of the following:
  - **nx56**—7 bits per byte.
  - **nx64**—8 bits per byte. This is the default.
- **fcs**—Specifies the number of bits in the frame checksum. You can specify one of the following:
  - **16**—16 bits. This is the default.
  - **32**—32 bits.
- **framing**—Sets the framing mode for the T1 line. You can specify the following:
  - **esf**—Extended superframe. This is the default.
  - **sf**—Superframe.

- **idle-cycle-flag**—Sets the value to transmit in idle cycles. You can specify one of the following:
  - **flags**—Transmit 0x7E in idle cycles. This is the default.
  - **ones**—Transmit 0xFF (all ones) in idle cycles.
- **invert-data**—Specifies data inversion. Data inversion is normally used only in alternate mark inversion (AMI) mode. By default, this is not set.
- **line-encoding**—Specifies the line-encoding method. You can specify one of the following:
  - **ami**—Alternate mark inversion.
  - **b8zs**—Binary 8 zero substitution. This is the default.
- **loopback**—Specifies loopback mode. By default, no loopback mode is set. You can specify one of the following:
  - **local**—Local loopback.
  - **payload**—Payload loopback.
  - **remote**—Remote loopback.
- **remote-loopback-respond**—Specifies that the interface responds to loop requests from the remote end. By default, this is not set.
- **start-end-flag**—Sets the start and end flags on transmission. You can specify one of the following:
  - **filler**—Sends two idle cycles between start/end flags. This is the default.
  - **shared**—Shares start/end flags on transmit.
- **timeslots timeslots**—Specifies the number of timeslots allocated to a fractional T1 interface. By default, all timeslots are active. Specify values from 1 to 24. Use hyphens to specify a range. Use commas (with no spaces before or after) to separate individual time slots or ranges. For example, you can specify the following: 1-3,4,9,22-24.

## t3-options

set interface *interface* t3-options ...

t3-options

Specifies options for a T3 interface. You can specify the following:

- **bert-algorithm**—Sets the bit error rate testing (BERT) algorithm for the interface. The algorithm is the pattern to send in the bitstream. You can specify one of the following options:
  - **all-ones-repeating**—Repeating one bits.
  - **all-zeros-repeating**—Repeating zero bits.
  - **alternating-double-ones-zeros**—Alternating pairs of ones and zeroes.
  - **alternating-ones-zeros**—Alternating ones and zeroes.
  - **pseudo-2e10**—Pattern is  $2^{10}-1$ .
  - **pseudo-2e11-o152**—Pattern is  $2^{11}-1$  (per O.152 standard).
  - **pseudo-2e15-o151**—Pattern is  $2^{15}-1$  (per O.152 standard). This is the default.

- **pseudo-2e17**—Pattern is  $2^{17-1}$ .
- **pseudo-2e18**—Pattern is  $2^{18-1}$ .
- **pseudo-2e20-o151**—Pattern is  $2^{20-1}$  (per O.151 standard).
- **pseudo-2e20-o153**—Pattern is  $2^{20-1}$  (per O.153 standard).
- **pseudo-2e21**—Pattern is  $2^{21-1}$ .
- **pseudo-2e22**—Pattern is  $2^{22-1}$ .
- **pseudo-2e23-o151**—Pattern is  $2^{23}$  (per O.151 standard).
- **pseudo-2e25**—Pattern is  $2^{25-1}$ .
- **pseudo-2e28**—Pattern is  $2^{28-1}$ .
- **pseudo-2e29**—Pattern is  $2^{29-1}$ .
- **pseudo-2e3**—Pattern is  $2^{3-1}$ .
- **pseudo-2e31**—Pattern is  $2^{31-1}$ .
- **pseudo-2e32**—Pattern is  $2^{32-1}$ .
- **pseudo-2e4**—Pattern is  $2^{4-1}$ .
- **pseudo-2e5**—Pattern is  $2^{5-1}$ .
- **pseudo-2e6**—Pattern is  $2^{6-1}$ .
- **pseudo-2e7**—Pattern is  $2^{7-1}$ .
- **pseudo-2e9-o153**—Pattern is  $2^{9-1}$  (per O.153 standard).
- **repeating-1-in-4**—1 bit in 4 is set.
- **repeating-1-in-8**—1 bit in 8 is set.
- **repeating-3-in-24**—3 bits in 24 are set.
- **bert-error-rate**—Sets the bit error rate (BER) to use in BERT. This can be an integer from 0 to 7, which corresponds to a BER from  $10^0$  (1 error per bit) to  $10^{-7}$ . The default is 0.
- **bert-period**—Sets the length of the BERT in seconds. The default is 10. Specify a value between 1 and 240 seconds.
- **cbit-parity**—Disables or enables C-bit parity mode, which controls the type of framing that is present on the transmitted T3 signal. By default, C-bit parity mode is enabled. When C-bit parity mode is enabled, the C-bit positions are used for the FEBE, FEAC, terminal-data-link, path-parity, and mode-indicator bits, as defined in ANSI T1.107a-1989. When C-bit parity mode is disabled, the basic T3 framing mode (M13) is used.
- **compatibility-mode**—Sets the T3 interface to be compatible with the channel service unit (CSU) at the remote end of the line. By default, no compatibility mode is set. You can specify one of the following:
  - **adtran subrate**—For intelligent-queuing (IQ) channels only. Sets the interface to be compatible with Adtran Channel Service Units (CSUs). Specify a value between 1 and 588.

- **digital-link subrate**—Sets the interface to be compatible with Digital Link CSUs. Specify one of the following bits-per-second values:

|           |           |           |           |
|-----------|-----------|-----------|-----------|
| ■ 301 Kb  | ■ 11.4 Mb | ■ 22.6 Mb | ■ 33.7 Mb |
| ■ 601 Kb  | ■ 11.7 Mb | ■ 22.9 Mb | ■ 34.0 Mb |
| ■ 902 Kb  | ■ 12.0 Mb | ■ 23.2 Mb | ■ 34.3 Mb |
| ■ 1.2 Mb  | ■ 12.3 Mb | ■ 23.5 Mb | ■ 34.6 Mb |
| ■ 1.5 Mb  | ■ 12.6 Mb | ■ 23.8 Mb | ■ 34.9 Mb |
| ■ 1.8 Mb  | ■ 12.9 Mb | ■ 24.1 Mb | ■ 35.2 Mb |
| ■ 2.1 Mb  | ■ 13.2 Mb | ■ 24.4 Mb | ■ 35.5 Mb |
| ■ 2.4 Mb  | ■ 13.5 Mb | ■ 24.7 Mb | ■ 35.8 Mb |
| ■ 2.7 Mb  | ■ 13.8 Mb | ■ 25.0 Mb | ■ 36.1 Mb |
| ■ 3.0 Mb  | ■ 14.1 Mb | ■ 25.3 Mb | ■ 36.4 Mb |
| ■ 3.3 Mb  | ■ 14.4 Mb | ■ 25.6 Mb | ■ 36.7 Mb |
| ■ 3.6 Mb  | ■ 14.7 Mb | ■ 25.9 Mb | ■ 37.0 Mb |
| ■ 3.9 Mb  | ■ 15.0 Mb | ■ 26.2 Mb | ■ 37.3 Mb |
| ■ 4.2 Mb  | ■ 15.3 Mb | ■ 26.5 Mb | ■ 37.6 Mb |
| ■ 4.5 Mb  | ■ 15.6 Mb | ■ 26.8 Mb | ■ 37.9 Mb |
| ■ 4.8 Mb  | ■ 15.9 Mb | ■ 27.1 Mb | ■ 38.2 Mb |
| ■ 5.1 Mb  | ■ 16.2 Mb | ■ 27.4 Mb | ■ 38.5 Mb |
| ■ 5.4 Mb  | ■ 16.5 Mb | ■ 27.7 Mb | ■ 38.8 Mb |
| ■ 5.7 Mb  | ■ 16.8 Mb | ■ 28.0 Mb | ■ 39.1 Mb |
| ■ 6.0 Mb  | ■ 17.1 Mb | ■ 28.3 Mb | ■ 39.4 Mb |
| ■ 6.3 Mb  | ■ 17.4 Mb | ■ 28.6 Mb | ■ 39.7 Mb |
| ■ 6.6 Mb  | ■ 17.7 Mb | ■ 28.9 Mb | ■ 40.0 Mb |
| ■ 6.9 Mb  | ■ 18.0 Mb | ■ 29.2 Mb | ■ 40.3 Mb |
| ■ 7.2 Mb  | ■ 18.3 Mb | ■ 29.5 Mb | ■ 40.6 Mb |
| ■ 7.5 Mb  | ■ 18.6 Mb | ■ 29.8 Mb | ■ 40.9 Mb |
| ■ 7.8 Mb  | ■ 18.9 Mb | ■ 30.1 Mb | ■ 41.2 Mb |
| ■ 8.1 Mb  | ■ 19.2 Mb | ■ 30.4 Mb | ■ 41.5 Mb |
| ■ 8.4 Mb  | ■ 19.5 Mb | ■ 30.7 Mb | ■ 41.8 Mb |
| ■ 8.7 Mb  | ■ 19.8 Mb | ■ 31.0 Mb | ■ 42.1 Mb |
| ■ 9.0 Mb  | ■ 20.1 Mb | ■ 31.3 Mb | ■ 42.4 Mb |
| ■ 9.3 Mb  | ■ 20.5 Mb | ■ 31.6 Mb | ■ 42.7 Mb |
| ■ 9.6 Mb  | ■ 20.8 Mb | ■ 31.9 Mb | ■ 43.0 Mb |
| ■ 9.9 Mb  | ■ 21.1 Mb | ■ 32.2 Mb | ■ 43.3 Mb |
| ■ 10.2 Mb | ■ 21.4 Mb | ■ 32.5 Mb | ■ 43.6 Mb |
| ■ 10.5 Mb | ■ 21.7 Mb | ■ 32.8 Mb | ■ 43.9 Mb |
| ■ 10.8 Mb | ■ 22.0 Mb | ■ 33.1 Mb | ■ 44.2 Mb |
| ■ 11.1 Mb | ■ 22.3 Mb | ■ 33.4 Mb |           |

- **kentrox subrate**—For IQ channels only. Sets the interface to be compatible with Kentrox CSUs. Specify a value between 1 and 69.
- **larscom subrate**—For IQ channels only. Sets the interface to be compatible with Larscom CSUs. Specify a value between 1 and 14.

- **verilink subrate**—For IQ channels only. Sets the interface to be compatible with Verilink CSUs. Specify a value between 1 and 28.
- **fcs**—Specifies the number of bits in the frame checksum. The checksum must be the same on both ends of the link. You can specify one of the following:
  - **16**—16 bits. This is the default.
  - **32**—32 bits.
- **feac-loop-respond**—Sets the interface to respond to far-end alarm and control (FEAC) loop requests. By default, this is not set.
- **idle-cycle-flag**—Sets the value to transmit in idle cycles. You can specify one of the following:
  - **flags**—Transmit 0x7E in idle cycles. This is the default.
  - **ones**—Transmit 0xFF (all ones) in idle cycles.
- **long-buildout**—Specifies a long cable length (longer than 225 feet or 68.6 meters) for copper-cable-based T3 interfaces. By default, this is not set.
- **loopback**—Specifies loopback mode. By default, no loopback mode is set. You can specify one of the following:
  - **local**—Local loopback.
  - **payload**—Payload loopback.
  - **remote**—Remote loopback.
- **payload-scrambler**—Enables High-Level Data Link Control (HDLC) payload scrambling on the interface. This type of scrambling provides better link stability, but both sides of the connection must either use or not use scrambling. By default, this is not set.
- **start-end-flag**—Sets the start and end flags on transmission. You can specify one of the following:
  - **filler**—Sends two idle cycles between start/end flags. This is the default.
  - **shared**—Shares start/end flags on transmit.

## tag

```
set interface interface.n tag id_num zone zone
```

**tag** Specifies a VLAN tag (*id\_num*) for a virtual (logical) subinterface. The interface name is *interface.n*, where *n* is an ID number that identifies the subinterface. For information about interface names, see “Interfaces” on page 771.

**Example:** The following command creates a subinterface for physical interface ethernet3/1, assigns it VLAN tag 300, and binds it to the Untrust zone:

```
set interface ethernet3/1.2 tag 300 zone untrust
```

## track-ip

```
get interface interface track-ip
set interface interface track-ip { ... }
```

track-ip Sets, unsets, or displays the tracking of IP addresses for the specified interface.

- **dynamic**—Configures tracking of the IP address of the default gateway for the interface.
- **threshold *number***—Specifies the failure threshold for IP tracking on the interface. If the weighted sum of all tracked IP failures on the interface is equal to or greater than the threshold, IP tracking on the interface is considered to be failed and the routes associated with the interface are deactivated on the security device. On some security devices, failover to the backup interface occurs. Unsetting the tracked IP threshold on the interface sets the threshold to the default value of 1.
- **ip *ip\_addr***—Configures tracking for the specified IP address. You can specify the following options:
  - **interval *number***—Specifies the interval, in seconds, that ping requests are sent to the tracked IP address. If you are unsetting the interval for the tracked IP address, the interval is changed to the default value of 1.
  - **threshold *number***—Specifies the failure threshold for the tracked IP address. If the number of consecutive ping failures to the tracked IP address is equal to or greater than the threshold, the tracked IP address is considered failed. If you are unsetting the threshold for the tracked IP address, the device changes the threshold to the default value (3).
  - **weight *number***—Specifies the weight associated with the failure of the tracked IP address. If a tracked IP address fails, its weight is used to calculate the weighted sum of all tracked IP failures on the interface. If you are unsetting the weight for the tracked IP address, the weight is changed to the default value of 1.

**Example 1:** The following command defines IP tracking for an interface:

- IP address 1.1.1.1 on the ethernet3 interface
- Ping interval of 10 seconds
- Tracked IP address failure threshold of 5

```
set interface ethernet3 track-ip ip 1.1.1.1 interval 10 threshold 5
```

**Example 2:** The following command sets the tracking threshold for the ethernet3 interface to 3:

```
set interface ethernet3 track-ip threshold 3
```

## tunnel

```

set interface tunnel.n { zone name_str | protocol { bgp | ospf [demand-circuit] | rip [
 demand-circuit] } { ... } }
set interface tunnel.n tunnel encap gre [key]
set interface tunnel.n tunnel keep-alive interval number
set interface tunnel.n tunnel keep-alive threshold number
set interface tunnel.n tunnel local-if interface dst-ip ip_addr
unset interface tunnel.n tunnel
unset interface tunnel.n tunnel [keep-alive]
unset interface tunnel.n

```

|            |                                                                                                                                                                                                                                                                                                           |
|------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| tunnel.n   | Specifies a tunnel interface. The <i>n</i> parameter is an ID number that identifies the tunnel interface.                                                                                                                                                                                                |
| tunnel     | Specifies parameters for the tunnel interface.                                                                                                                                                                                                                                                            |
| encap gre  | Specifies that all traffic in the tunnel is encapsulated using the Generic Routing Encapsulation protocol.                                                                                                                                                                                                |
| keep-alive | The tunnel interface sends keep-alive messages to monitor the status of the connection. You can specify the interval (in seconds) between keep-alive messages, and the number of times the local tunnel interface sends keep-live messages without receiving a reply before it terminates the connection. |
| local-if   | Specifies the local interface and the destination IP address of a GRE tunnel.                                                                                                                                                                                                                             |

**Example:** The following commands create a tunnel interface named **tunnel.2** with IP address *172.10.10.5/24*:

```

set interface tunnel.2 zone untrust
set interface tunnel.2 ip 172.10.10.5/24

```

## protocol

```

set interface tunnel.n protocol { bgp | ospf [demand-circuit] |
 rip [demand-circuit] } { ... } }
unset set interface tunnel.n protocol { bgp | ospf [demand-circuit] |
 rip [demand-circuit] } { ... } }

```

|          |                                                                                                                                                                                               |
|----------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| protocol | Specifies the routing protocol that the device uses on a specified tunnel interface. security devices support BGP, OSPF, RIP, IGMP, and PIM. These commands set or unset protocol parameters. |
|----------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

**Example:** The following command enables the RIP-specific route summary feature for the *tunnel.1* interface:

```

set interface tunnel.1 protocol rip summary-enable

```

## vip

```
set interface interface vip [ip_addr | interface-ip]
 [+] port_num [name_str ip_addr [manual]]
```

**vip** Defines a virtual IP (VIP) address for the interface by using the IP address of the interface (*interface-ip*) or any IP address (*ip\_addr*) on the interface so you can map routable IP addresses to internal servers and access their services. The *port\_num* parameter is the port number, which specifies which service to access. The *name\_str* and *ip\_addr* parameters specify the service name and the IP address of the server providing the service, respectively. The **manual** switch turns off server auto detection. Using the + operator adds another service to the VIP.

**Example:** The following command creates a VIP for interface *ethernet3*, specifying the MAIL service (ID 25):

```
set interface ethernet3 vip Interface-IP 25 MAIL 10.1.10.10
```

## vlan trunk

```
set interface vlan1 vlan trunk
unset interface vlan1 vlan trunk
```

**vlan trunk** (**vlan1** interface only.)—Determines whether the security device accepts or drops Layer 2 frames. The device makes this decision only when the following conditions apply:

- The security device is in transparent mode.
- The device receives VLAN tagged frames on an interface.

The device then performs one of two actions:

- Drops the frames because they have tags.
- Ignores the tags and forward the frames according to MAC addresses.

The **vlan trunk interface** switch determines which action the device performs. For example, the command **set interface vlan1 vlan trunk** instructs the security device to ignore the tags and forward the frames. This action closely follows that of a Layer 2 switch trunk port.

## webauth

```
set interface interface webauth [ssl-only]
```

**webauth** Enables WebAuth user authentication. Enabling the **ssl-only** switch allows only SSL-based (HTTPS) user authentication.

## webauth-ip

```
set interface interface webauth-ip ip_addr
```

**webauth-ip** Specifies the WebAuth server IP address for user authentication. Before sending service requests (such as MAIL) through the interface, the user must first browse the WebAuth address. The security device presents a login screen, prompting for username and password. After successfully entering the username and password, the user can send service requests through the interface.

To protect an interface with the WebAuth feature, you must create a security policy with the **set policy** command, specifying the **webauth** switch. To specify the WebAuth server, use the **set webauth** command.

## wlan

```
set interface interface wlan { 0 | 1 | both }
unset interface interface wlan
```

## xg-round-robin

```
set interface interface xg-round-robin
unset interface interface xg-round-robin
```

xg-round-robin      Enables the round-robin mode of packet distribution on an interface. The default packet distribution mode is hashing mode.

**Note:** Only an 2XGE interface on Netscreen-5000 series platforms supports this configuration.

## zone

```
set interface interface zone zone
unset interface interface zone
```

zone                      Binds the interface to a security zone.  
You can bind a management (MGT) interface to a zone other than MGT (the MGT interface is bound to the MGT zone by default).

**Example:** To bind interface **ethernet2/2** to the Trust zone:

```
set interface ethernet2/2 zone trust
```



# ip

Use the **ip** commands to set or display Internet Protocol (IP) parameters for communication with a Trivial File Transfer Protocol (TFTP) server.

A security device can use TFTP servers to save or import external files. These files can contain configuration settings, software versions, public keys, error messages, certificates, and other items.

## Syntax

---

### *get*

```
get ip tftp
```

### *set*

```
set ip tftp
{
 retry number |
 timeout number
}
```

## Keywords and Variables

---

### *retry*

```
set ip tftp retry number
```

**retry**            The number of times to retry a TFTP communication before the security device ends the attempt and generates an error message. The default is 10.

**Example:** The following command sets the number of retries to 7:

```
set ip tftp retry 7
```

## ***timeout***

set ip tftp timeout *number*

**timeout** Determines how the long (in seconds) the security device waits before terminating an inactive TFTP connection. The default is 2 seconds.

**Example:** The following command sets the timeout period to 15 seconds:

**set ip tftp timeout 15**

# ip-classification

Use the **ip-classification** command to display the current Internet Protocol (IP)-based traffic classification.

IP-based traffic classification allows you to use virtual systems without VLANs. Instead of VLAN tags, the security device uses IP addresses to sort traffic, associating a subnet or range of IP addresses with a particular system (root or vsys).

Using IP-based traffic classification exclusively to sort traffic, all systems share the following:

- The untrust-vr and a user-defined internal-vr
- The Untrust zone and a user-defined internal zone
- An Untrust zone interface and a user-defined internal zone interface

To designate a subnet or range of IP addresses to the root system or to a previously created virtual system, you must issue one of the following CLI commands at the root level:

```
set zone zone ip-classification net ip_addr/mask { root | vsys name_str }
set zone zone ip-classification range ip_addr1-ip_addr2 { root | vsys name_str }
```

For more information, see “zone” on page 761.

## Syntax

---

```
get ip-classification [zone zone]
```

## Keywords and Variables

---

### **zone**

```
get ip-classification zone zone [ip ip_addr]
```

**zone** The name of the security zone. It has to be a shared zone in a shared virtual router. A virtual system (vsys) must also be enabled. This command is only available in root vsys.

**ip ip\_addr** specifies a specific address in a specific zone.



# ippool

Use the **ippool** commands to associate the name of an Internet Protocol (IP) pool with a range of IP addresses. The security device uses IP pools when it assigns addresses to dialup users using Layer 2 Tunneling Protocol (L2TP).

## Syntax

---

### *clear*

```
clear ippool name_str [ip_addr1 ip_addr2]
```

### *get*

```
get ippool [name_str]
```

### *set*

```
set ippool name_str ip_addr1 ip_addr2
set ippool name_str ip_addr3 ip_addr4
```

## Keywords and Variables

---

### **Variable Parameters**

```
clear ippool name_str [ip_addr1 ip_addr2]
get ippool name_str
set ippool name_str ip_addr1 ip_addr2
set ippool name_str ip_addr3 ip_addr4
unset ippool name_str
```

*name\_str*            Defines the name of the IP pool.

*ip\_addr1*  
*ip\_addr2*            Starting and ending IP addresses in the IP pool.

*ip\_addr3*  
*ip\_addr4*            A second set of starting and ending IP addresses in the same IP pool.

**Example:** To configure the IP pool named **office** with the IP addresses **172.16.10.100** through **172.16.10.200**:

```
set ippool office 172.16.10.100 172.16.10.200
```



# irdp

Use the **irdp** commands to view a configured ICMP Router Discovery Protocol (IRDP) instance for an interface of your security device.

---

**NOTE:** This protocol is not available on all platforms. See your product datasheet for a list of features available for your particular platform.

---

To configure an IRDP instance, see “interface” on page 313 for command syntax and explanations for using the commands.

## Syntax

---

### **get**

```
get irdp [interface]
```

## Keywords and Variables

---

### **Variable Parameter**

```
get irdp interface
```

*interface* The name of the interface. For more information, see “Interfaces” on page 771.



# key

Use the **key** commands to protect system keys from unauthorized access and modification.

## Syntax

---

### **set**

```
set key
{
 protection enable
}
```

## Keywords and Variables

---

### **protection**

```
set key protection enable
unset key protection
```

|            |                                                                                                                                                                                                                                                                                                                                                      |
|------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| protection | Protects VPN private keys against unauthorized access and key modification. By enabling the key protection feature, the security device encrypts VPN persistent private keys, checks integrity of key when the key is in use, and destroys key memory with different key patterns in the system. By default, the key protection feature is disabled. |
|------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|



# I2tp

Use the **I2tp** commands to configure or remove Layer 2 Tunneling Protocol (L2TP) tunnels and L2TP settings from the security device.

L2TP is an extension to Point-to-Point Protocol (PPP) that allows Internet Service Providers (ISPs) to operate virtual private networks (VPNs). L2TP allows dial-up users to make virtual PPP connections to an L2TP network server (LNS). The security device can operate as such a server.

## Syntax

---

### **clear**

```
clear [cluster] I2tp { all | ip ip_addr }
```

### **get**

```
get I2tp
{
 all [active] | tunn_str [active] |
 default
}
```

### **set (default)**

```
set I2tp default
{
 accounting off |
 accounting server name_str |
 auth server name_str [query-config] |
 ippool string |
 dns1 ip_addr | dns2 ip_addr |
 wins1 ip_addr | wins2 ip_addr |
 ppp-auth { any | chap | pap } |
}
```

### **set (*tunn\_str*)**

```
set I2tp tunn_str
[
 accounting off |
 accounting server name_str |
 auth server name_str
 [query-config] [user usr_name | user-group grp_name] |
 [peer-ip ip_addr]
```

```

 [host name_str]
 [outgoing-interface interface]
 [secret string]
 [keepalive number] |
remote-setting
{ [ippool string]
 [dns1 ip_addr]
 [dns2 ip_addr]
 [wins1 ip_addr]
 [wins2 ip_addr]
}
]

```

## Keywords and Variables

---

### Variable Parameter

```

get l2tp tunn_str
get l2tp tunn_str [...]
set l2tp tunn_str [...]
unset l2tp tunn_str { ... }

```

*tunn\_str*            The name or IP address of the L2TP tunnel.

**Example:** The following command identifies the RADIUS authentication server (Rad\_Serv) for an L2TP tunnel (Mkt\_Tun).

```
set l2tp Mkt_Tun auth server Rad_Serv
```

### *accounting*

```

set l2tp default accounting off
set l2tp default accounting server name_str
set l2tp tunn_str accounting off
set l2tp tunn_str accounting server name_str

```

*accounting*            Specifies the accounting details of the currently active L2TP.

- **accounting off**—Disables the accounting server for L2TP. By default, the accounting server is enabled. The **unset** command enables accounting for L2TP. If the accounting server is not specified, an Accounting-Request message is sent to the authentication server.
- **accounting server *name\_str***—Specifies a default or separated accounting server for L2TP. The **unset** command resets the default or separated accounting server to No Configuration.

**active**

```
get l2tp all active
get l2tp tunn_str active
```

**active** Displays the currently active L2TP connections for tunnels.

**Example:** The following command displays the current active/inactive status of the L2TP connection for a tunnel (**home2work**):

```
get l2tp home2work active
```

**all**

```
clear cluster l2tp all
clear l2tp all
get l2tp all
```

**all** Displays or clears the ID number, tunnel name, user, peer IP address, peer hostname, L2TP tunnel shared secret, and keepalive value for every L2TP tunnel (**all**) or a specified L2TP tunnel (*string*).

**auth server**

```
set l2tp tunn_str auth server name_str [...]
set l2tp default auth server name_str [...]
unset l2tp tunn_str auth
```

**auth server** Specifies the object name (*name\_str*) of the authentication server containing the authentication database.

- **query-config**—Directs the security device to query the authentication server for IP, DNS, and WINS information.
- **user** *usr\_name*—Restricts the L2TP tunnel to a specified user (*usr\_name*).
- **user-group** *grp\_name*—Restricts the L2TP tunnel to a specified user group (*grp\_name*).

**Example:** The following command directs the device to query the RADIUS authentication server (Rad\_Serv) for IP, DNS, and WINS information:

```
set l2tp Mkt_Tun auth server Rad_Serv query-config
```

**cluster**

```
clear cluster l2tp { ... }
```

**cluster** Propagates the **clear** operation to all other devices in an NSRP cluster.

**default**

```
get l2tp default
set l2tp default { ... }
unset l2tp tunn_str [...]
unset l2tp default { ... }
```

- default** Defines or displays the default L2TP settings.
- **auth server** *name\_str* specifies the name of the authentication server.
  - **dns1** *ip\_addr* specifies the IP address of the primary DNS server.
  - **dns2** *ip\_addr* specifies the IP address of the secondary DNS server.
  - **ippool** *string* specifies the name of the L2TP IP pool, from which IP addresses are drawn to be assigned to L2TP users.
  - **ppp-auth** { **any** [ **chap** | **pap** ] } specifies the authentication type in response to a dialup user's request to make a Point-to-Point Protocol (PPP) link. (The **any** switch instructs the security device to negotiate CHAP and then, if that attempt fails, PAP.)
    - **chap** specifies Challenge Handshake Authentication Protocol (CHAP), which does not transmit the password across the network.
    - **pap** specifies Password Authentication Protocol (PAP), which does not use encryption.
  - **radius-port** *port\_num* specifies the port number of the default L2TP server. The number can be between 1024 and 65,535.
  - **wins1** *ip\_addr* specifies the IP address of the primary WINS server.
  - **wins2** *ip\_addr* specifies the IP address of the secondary WINS server.

**Example:** The following commands create a set of default L2TP settings:

- IP pool (chiba)
- Use of the local database
- CHAP for PPP authentication
- Primary and secondary DNS servers at 192.168.2.1 and 192.168.4.71, respectively
- Primary and secondary WINS servers at 10.20.1.16 and 10.20.5.101, respectively

```
set l2tp default ippool chiba
set l2tp default auth local
set l2tp default ppp-auth chap
set l2tp default dns1 192.168.2.1
set l2tp default dns2 192.168.4.71
set l2tp default wins1 10.20.1.16
set l2tp default wins2 10.20.5.101
```

**host**

```
set l2tp tunn_str [...] host name_str [...]
unset l2tp tunn_str host
```

host                    Adds a restriction that allows only a client with the specified client hostname (*name\_str*) to establish the L2TP tunnel.

**keepalive**

```
set l2tp tunn_str [...] keepalive number
```

keepalive              Defines how many seconds of inactivity, the security device (LNS) waits before sending a hello message to the dialup client (LAC).

**Example:** The following command specifies a keepalive value of 120 for an L2TP tunnel (west\_coast):

```
set l2tp west_coast keepalive 120
```

**outgoing-interface**

```
set l2tp tunn_str [...] outgoing-interface interface
```

outgoing-interface    Specifies the outgoing interface for the L2TP tunnel.  
**Note:** This setting may be mandatory on your security device.

**Example:** The following command specifies interface *ethernet4* as the outgoing interface for L2TP tunnel (east\_coast):

```
set l2tp east_coast outgoing-interface ethernet4
```

**peer-ip**

```
set l2tp tunn_str [...] peer-ip ip_addr [...]
```

peer-ip                Adds a restriction that allows only a client host with the specified IP address (*ip\_addr*) to establish the L2TP tunnel.

**Example:** The following command specifies the IP address of the LAC (172.16.100.19):

```
set l2tp east_coast peer-ip 172.16.100.19
```

**secret**

```
set l2tp tunn_str [...] secret string [...]
```

secret                 Defines a shared secret used for authentication between the security device (which acts as the L2TP Network Server, or LNS) and the L2TP access concentrator (LAC).

**Example:** The following command specifies a shared secret (94j9387):

```
set l2tp east_coast secret 94j9387
```

**user**

```
set l2tp tunn_str auth server name_str [...] user usr_name
```

**user** Restricts the L2TP tunnel to a L2TP user (*usr\_name*). (Not specifying *name\_str* enables any L2TP user.)

**Example:** The following command adds a restriction that allows only a specified L2TP user (jking) to establish a L2TP tunnel (west\_coast).

```
set l2tp west_coast auth server Our_Auth user jking
```

**Defaults**

The default L2TP UDP port number is 1701.

By default, the security device uses no L2TP tunnel secret to authenticate the LAC-LNS pair. This is not a problem, because the device performs IKE authentication when it uses L2TP over IPsec.

The default interval for sending a keepalive message is 60 seconds.

PPP-auth type is *any*.

# Lcd

Use the **lcd** commands to activate or inactivate the LCD on the front panel of a security device or to display the current **lcd** setting.

## Syntax

---

### **get**

```
get lcd
```

### **set**

```
set lcd
{
 display |
 key-in
}
```

## Keywords and Variables

---

### **display**

```
set lcd display
unset lcd display
```

**display**            Turns the LCD off or on and locks the control keys.

### **key-in**

```
set lcd key-in
unset lcd key-in
```

**key-in**            Locks and unlocks the control keys but does not affect the LCD display.



# led

When either an event alarm or a firewall attack occurs, the LED glows red to signal the attack. Use the **clear led** commands to return an ALARM or firewall (FW) LED to green after such an attack occurs.

## Syntax

---

```
clear [cluster] led { alarm | firewall }
```

## Keywords and Variables

---

### **alarm**

```
clear [cluster] led alarm
```

alarm            Specifies the ALARM LED.

### **cluster**

```
clear cluster led alarm
clear cluster led firewall
```

cluster           Propagates the **clear** operation to all other devices in a NetScreen Redundancy Protocol (NSRP) cluster.

### **firewall**

```
clear [cluster] led firewall
```

firewall           Specifies the FW LED.



# license-key

Use the **license-key** command to upgrade or display the current software license.

The license key feature allows you to expand the capabilities of your security device without having to upgrade to a different device or system image. You can purchase a key that unlocks specified features already loaded in the software, such as the following:

- User capacity
- NetScreen Redundancy Protocol (NSRP)
- Virtual systems
- Virtual private networks (VPNs)
- Zones
- Virtual routers
- High availability (HA)

---

**NOTE:** Not all keys are available for all products.

---

## Syntax

---

### **exec**

```
exec license-key
{
 capacity key_str |
 delete key_str |
 key_str /
 nsrp key_str /
 update [trial] |
 virtualization key_str |
 vpn key_str |
 vrouter key_str |
 vsys key_str |
 zone key_str
}
```

**get**

get license-key

**set**

set license-key update-url *url\_str*

## Keywords and Variables

---

**Variable Parameters**

exec license-key *key\_str*  
 set license-key update-url *url\_str*

*key\_str*            The provided license key string.  
*url\_str*            The URL of the license key server.

**capacity**

exec license-key capacity *key\_str*

capacity            Allows you to expand the user capacity of the security device with your given license-key (*key\_str*).

**delete**

exec license-key delete *key\_str*

delete            Deletes the license key (*key\_str*).

**nsrp**

exec license-key nsrp *key\_str*

nsrp                Specifies a NetScreen Redundancy Protocol (NSRP) license key (*key\_str*).

**update**

exec license-key update [ trial ]

update            Before your security device can receive regular update service for Deep Inspection (DI) signatures, you must purchase a subscription to the service, register your device, and then retrieve the subscription. You retrieve the subscription and activate it on your device by executing the command **exec license-key update**. Use the trial command to try service temporarily.

- **trial** Updates the trial license-key.

For more information, see the *Concepts & Examples ScreenOS Reference Guide*.

**update-url**

```
set license-key update-url url_str
```

**update-url** Specifies the URL of the license key server from which the security device loads license key updates.

**virtualization**

```
exec license-key virtualization key_str
```

**virtualization** Specifies a virtualization license key (*key\_str*). Virtualization key is used to control VLAN support on some devices. Security devices with VSYS support by default have VLAN support.

**vpn**

```
exec license-key vpn key_str
```

**vpn** Specifies a Virtual Private Network (VPN) license key (*key\_str*).

**vrouter**

```
exec license-key vrouter key_str
```

**vrouter** Specifies a virtual router license key (*key\_str*).

**vsys**

```
exec license-key vsys key_str
```

**vsys** Specifies a virtual system (vsys) license key (*key\_str*).

**zone**

```
exec license-key zone key_str
```

**zone** Specifies a security zone license key (*key\_str*).



# log

Use the log commands to configure the security device for message logging. The log commands allow you to perform the following tasks:

- Configure the security device for message logging
- Configure the security device to log CLI commands to a TFTP server
- Display the current log status according to severity level, policy, service, ScreenOS module, source, destination, or duration
- Determine which log information to display or omit
- Display asset-recovery information
- Configure logging to mitigate message loss caused by memory limitations
- Enable and configure logging to a USB flash drive

## Syntax

---

### **clear**

```
clear [cluster] log
{
 self [end-time string] |
 system [saved] |
 traffic [policy id_num [-id_num]] [end-time string]]
}
```

### **exec**

```
exec log cli tftp file-name filename ip-addr ip_address
```

### **get**

```
get log
{
 asset-recovery |
 audit-loss-mitigation |
 cli file |
 exclude |
 event
 [dst-ip ip_addr [-ip_addr | dst-netmask mask]]
```

```

[dst-port port_num [-port_num]]
[end-date date]
[end-time string]
[exclude string]
[include string]
[interface interface]
[level
 {
 alert | critical | debug |
 emergency | error | information |
 notification | warning
 }]
[module name_str]
[policy { pol_num1 [-pol_num2] }]
[protocol protocol 1 [-protocol2]]
[sort-by
 {
 date | dst-ip | dst-port |
 interface | policy | src-ip |
 user-name | time
 }]
[src-ip ip_addr [-ip_addr | src-netmask mask]]
[start-date string]
[start-time string]
[type id_num [-id_num]] |
self
 [detail level 0 | 1]
 [dst-ip ip_addr [-ip_addr | dst-netmask mask]]
 [dst-port port_num [-port_num]]
 [end-date date]
 [end-time string]
 [max-duration string]
 [min-duration string]
 [no-rule-displayed]
 [service name_str]
 [sort-by
 {
 date [[end-date date [time]] [start-date date [time]]] |
 dst-ip [ip_addr [-ip_addr | dst-netmask mask]] |
 src-ip [ip_addr [-ip_addr | src-netmask mask]] |
 time [end-time time] [start-time time]
 }]
 [src-ip ip_addr [-ip_addr | src-netmask mask]]
 [src-port port_num [-port_num]]
 [start-date string]
 [start-time string]
setting [module { system | all }]
traffic
 [detail level 0 | 1]
 [dst-ip ip_addr [-ip_addr | dst-netmask mask]]
 [dst-port port_num [-port_num]]
 [end-date date]
 [end-time string]
 [max-duration string]
 [min-duration string]
 [no-rule-displayed]
 [policy { pol_num1 [-pol_num2] }]

```

```

 [service name_str]
 [src-ip ip_addr [-ip_addr | src-netmask mask]]
 [src-port port_num [-port_num]]
 [start-date string]
 [start-time string]
usb info
}

```

## set

```

set log
{
 audit-loss-mitigation |
 cli { enable | file-size bytes } |
 exclude-id number [user-id name_str] [event-type number] [src-ip ip_str] [dst-ip
ip_str] [dst-port number] [success | failure] |
 module system level string destination string
 traffic detail level { 0 | 1 }
 usb { enable | filesize megabytes }
}

```

## Keywords and Variables

---

### ***asset-recovery***

get log asset-recovery

asset-recovery      Displays the asset recovery log, which contains information about each time the device is returned to its default settings using the asset recovery procedure.

### ***audit-loss-mitigation***

get log audit-loss-mitigation

set log audit-loss-mitigation

unset log audit-loss-mitigation

audit-loss-mitigation      Stops generation of auditable events when the number of such events exceeds the capacity of the security device. Enabling this feature reduces the loss of event logs due to log overloads.

On some security devices, you must connect the syslog server to the management interface on the Management Module. This ensures that the syslog server is available if the audit trail fills up and network traffic stops.

### ***cli***

set log cli { enable | file-size *number* }

get log cli file *filename*

exec log cli tftp file-name *filename* ip-addr *ip\_address*

Enables logging CLI activity, displays CLI log entries, or sends CLI log entries to a TFTP server.

file                      Specifies a log filename when displaying CLI log entries

file-name                Specifies the filename when logging to a TFTP server

ip-addr                  Specifies the TFTP server IP address when logging to a TFTP server

**Example:** The following command enables logging of CLI commands to the file `dev_cli_log.txt` on the TFTP server at `192.68.23.3`:

```
exec log cli tftp file-name dev_cli_log.txt ip-addr 192.68.23.3
```

### ***cluster***

clear cluster log { ... }

cluster                  Propagates the **clear** operation to all other devices in an NSRP cluster.

**event**

get log event [... ]

Displays sorts, and searches the event log messages.

|                          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|--------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| dst-ip                   | Directs the device to display event logs with the specified destination IP address or address range. The device can also sort event logs by destination IP address.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| include<br>exclude       | Directs the device to exclude or include events containing a specified string of characters ( <i>string</i> ).                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| Interface                | Specifies the name of the interface that generated the event.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| level                    | Specifies the priority level of the event message. The priority levels are as follows: <ul style="list-style-type: none"> <li>■ <b>emergency</b> (Level 0) —The system is unusable.</li> <li>■ <b>alert</b> (Level 1) —Immediate action is necessary.</li> <li>■ <b>critical</b> (Level 2) —The event affects functionality.</li> <li>■ <b>error</b> (Level 3) —An error condition exists.</li> <li>■ <b>warning</b> (Level 4) —The event might affect functionality.</li> <li>■ <b>notification</b> (Level 5) —The event is a normal occurrence.</li> <li>■ <b>information</b> (Level 6) —The event generates general information about normal operation.</li> <li>■ <b>debug</b> (Level 7) —The event generates detailed information for troubleshooting purposes.</li> </ul> |
| module                   | Specifies the name of the system module that generated the event.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| policy                   | Displays the log events for a policy specified by its ID number or for several policies specified by a range of ID numbers. The ID number can be any value between 0 and the total number of established policies. To define a range, enter the starting and ending ID numbers as follows: <i>pol_num1-pol_num2</i>                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| protocol                 | Specifies the Transport layer protocol with which the event was generated.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| sort-by                  | Sorts event logs by date, source IP address, destination IP address, destination port, policy, protocol, user-name or time.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| src-ip                   | Displays event logs by source IP address. The device can also display event logs with the specified source IP address or address range.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| start-time  <br>end-time | Specifies the lower and upper ends of a range of times for an event. When you specify a start-time and/or an end-time, the device sorts or filters the event logs based on the specified times, regardless of the date. The format is as follows:<br><i>hh:mm:ss</i>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| start-date  <br>end-date | Specifies the lower and upper ends of a range of times for an event. The format is as follows:<br><i>mm/dd/yy-hh:mm:ss</i><br>You can omit the year (the current year is the default) or express the year using the last two digits or all four digits. The hour, minute, and second are optional. The delimiter between the date and the time can be a dash or an underscore:<br>12/31/2001-23:59:00<br>12/31/2001_23:59:00                                                                                                                                                                                                                                                                                                                                                    |

`type` Specifies a priority level or a range of priority levels.

## ***exclude-id***

```
set log exclude-id { ... }
unset log exclude-id number
```

`exclude-id` Enables the security device to configure rules for excluding events from the audit log. You can configure a maximum of 10 exclude rules.

- **user-id**—Indicates the authenticated user’s ID.
- **event-type**—Indicates the event or log type number.
- **src-ip**—Indicates the source IP address of the authenticated user.
- **dst-ip**—Indicates the destination IP address of the authenticated user.
- **dst-port**—Indicates the destination port number of the authenticated user.
- **success**—Indicates the event result as a success.
- **failure**—Indicates the event result as a failure.

**Example:** The following command instructs the security device to create an exclude rule to exclude event with similar fields from being generated in the audit log:

```
set log exclude-id 1 user-id 23 event-type 1 src-ip 10.10.10.10 dst-ip 20.20.20.20
dst-port 24 success
```

## ***module***

```
set log module system level string destination string
unset log module system { ... }
```

Configures the device to send generated log entries of the specified severity level to the specified destinations.

`level` Specifies the minimum urgency level of the generated log messages. Starting with the most urgent, these levels are **emergency**, **alert**, **critical**, **error**, **warning**, **notification**, **information**, and **debugging**. For the **get log** command, the **all-levels** option displays all security levels.

See also “traffic” on page 419 for more options.

`destination` Specifies the destination of the generated log messages. The permissible destinations are:

- **console**
- **internal**
- **email**
- **snmp**
- **syslog**
- **webtrends**
- **NSM**
- **pcmcia**
- **USB**

**Example:** The following command instructs the security device to direct all system module messages at the **critical** level (or higher) to the WebTrends server:

**set log module system level critical destination webtrends**

## self

```
clear [cluster] log self [...]
get log self [...]
```

Displays or clears the device self log.

|                                                                                      |                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|--------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| detail level                                                                         | Queries the device for the current self log detail level.                                                                                                                                                                                                                                                                                                                                                                                 |
| dst-ip                                                                               | Displays self log entries for a specified destination IP address or range of destination IP addresses. You can specify the subnet mask for a destination IP address, but you cannot specify a destination IP range and destination subnet mask simultaneously. You can also direct the device to sort event logs by destination IP address.                                                                                               |
| dst-netmask                                                                          | Displays self log entries for a specified destination subnet mask.                                                                                                                                                                                                                                                                                                                                                                        |
| dst-port                                                                             | Displays self log entries for a specified destination port number or range of destination port numbers.                                                                                                                                                                                                                                                                                                                                   |
| end-date <i>date</i><br>[ <i>time</i> ]<br>start-date <i>date</i><br>[ <i>time</i> ] | Specifies the lower and upper ends of a range of dates for self logs. You can omit the year (the current year is the default), or express the year using the last two digits or all four digits. The hour, minute, and second are optional. The delimiter between the date and the time can be a dash or an underscore:<br><b>12/31/2001-23:59:00</b><br><b>12/31/2001_23:59:00</b>                                                       |
| end-time <i>time</i><br>start-time <i>time</i>                                       | Specifies the lower and upper ends of a range of times for self logs. When you specify a start-time and/or end-time, the device sorts or filters the logs based on the specified times, regardless of the date. Specify the time in the following format: <i>hh:mm:ss</i>                                                                                                                                                                 |
| min-duration                                                                         | Displays self log entries for traffic whose duration was longer than or equal to the minimum duration specified.                                                                                                                                                                                                                                                                                                                          |
| max-duration                                                                         | Displays self log entries for traffic whose duration was shorter than or equal to the maximum duration specified.                                                                                                                                                                                                                                                                                                                         |
| no-rule-<br>displayed                                                                | Displays self log entries but does not display policy information.                                                                                                                                                                                                                                                                                                                                                                        |
| service                                                                              | Displays self log entries for a specified Service, such as <b>TCP</b> , <b>ICMP</b> , <b>FTP</b> , or <b>Any</b> . The name does not have to be complete; for example, both <b>TC</b> and <b>CP</b> are recognized as <b>TCP</b> . Although you cannot specify a Service group, note that because <b>TP</b> is recognized as <b>FTP</b> , <b>HTTP</b> , and <b>TFTP</b> , entering <b>TP</b> displays log entries for all three services. |
| src-ip                                                                               | Displays self log entries for a specified source IP address or range of source IP addresses. Include the subnet mask for a source IP address to display traffic entries for all IP addresses in the same subnet as the specified source IP address. You cannot specify a source IP range and a source subnet mask simultaneously. You can also direct the device to sort event logs by source IP address.                                 |
| src-netmask                                                                          | Displays self log entries for a specified source subnet mask.                                                                                                                                                                                                                                                                                                                                                                             |

`src-port` Displays self log entries for a specified source port number or range of source port numbers.

**Example:** The following command displays traffic log table entries for any policy with a source IP address of 172.16.10.1 and a destination address of 172.16.10.100:

```
get log self src-ip 172.16.10.1 dst-ip 172.16.10.100
```

## setting

```
get log setting [...]
```

Displays log setting information for the specified module.

`setting` Displays log setting information. The **module** *string* value specifies the name of the module for which the log settings apply:

- **system**—Displays log settings for the system module
- **all**—Displays log settings for all modules

**Example:** The following command displays traffic log settings for the system module:

```
get log setting module system
```

## system

```
clear log system [saved]
```

Clears the system log.

`saved` Clears saved log information in addition to the system log.

**Example:** The following command displays traffic log settings for the system module:

```
clear log system saved
```

## sort-by

```
get log { ... } sort-by date [[start-date date] [end-date date]] [time]
get log { ... } sort-by dst-ip [ip_addr [-ip_addr | dst-netmask mask]]
get log { ... } sort-by src-ip [ip_addr [-ip_addr | src-netmask mask]]
get log { ... } sort-by time [start-time time] [end-time time]
```

Sorts the log by the specified criteria.

|                                                |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
|------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| date   time                                    | Sorts the logs by date, time, or both.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| end-date <i>date</i><br>[ <i>time</i> ]        | The <b>start-date</b> option displays logs that occurred at or before the time specified. The <b>end-date</b> option displays logs that occurred at or after the time specified. The format for <b>start-date</b> and <b>end-date</b> <i>date</i> is <i>mm/dd/[yy-hh:mm:ss]</i> . The format for <b>start-time</b> and <b>end-time</b> is <i>hh:mm:ss</i> .<br><br>You can omit the year (the current year is the default), or express the year using the last two digits or all four digits. The hour, minute, and second are optional. The delimiter between the date and the time can be a dash or an underscore:<br><br><b>12/31/2002-23:59:00</b><br><b>12/31/2002_23:59:00</b> |
| start-date <i>date</i><br>[ <i>time</i> ]      |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| end-time <i>time</i><br>start-time <i>time</i> | Specifies the lower and upper ends of a range of times for self logs. When you specify a start-time and/or end-time, the device sorts or filters the logs based on the specified times, regardless of the date. Specify the time in the following format: <i>hh:mm:ss</i>                                                                                                                                                                                                                                                                                                                                                                                                            |
| dst-ip                                         | Sorts the self log by destination IP address. You can specify the subnet mask for a destination IP address, but you cannot specify a destination IP range and destination subnet mask simultaneously. You can also direct the device to sort event logs by destination IP address.                                                                                                                                                                                                                                                                                                                                                                                                   |
| src-ip                                         | Sorts the self log by source IP address. Include the subnet mask for a source IP address to display traffic entries for all IP addresses in the same subnet as the specified source IP address. You cannot specify a source IP range and a source subnet mask simultaneously. You can also direct the device to sort event logs by source IP address.                                                                                                                                                                                                                                                                                                                                |

**Example:** The following command displays traffic log settings sorted by date and time:

```
get log traffic sort-by date start-date 11/21/2003-22:24:00
```

## traffic

```
clear [cluster] log traffic [...]
get log traffic [...]
set log traffic detail level { 0 | 1 }
unset log traffic detail level
```

Displays, configures, or clears the traffic log.

|              |                                                                                                                                                                                                                                                                                                                                                                                                                     |
|--------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| detail level | Queries or configures the device for the current self log detail level. By default, the security device shows the reason for each log entry. If you do not want to view the reason for each log entry, you can disable this feature by entering the <b>set log traffic detail level 0</b> command. To return the security device default behavior, you can enter the <b>unset log traffic detail level</b> command. |
| dst-ip       | Displays traffic log entries for a specified destination IP address or range of destination IP addresses. You can specify the subnet mask for a destination IP address, but you cannot specify a destination IP range and destination subnet mask simultaneously. You can also direct the device to sort event logs by destination IP address.                                                                      |

|                                                                                                  |                                                                                                                                                                                                                                                                                                                                                                                                                                              |
|--------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>dst-netmask</code>                                                                         | Displays traffic log entries for a specified destination subnet mask.                                                                                                                                                                                                                                                                                                                                                                        |
| <code>dst-port</code>                                                                            | Displays traffic log entries for a specified destination port number or range of destination port numbers.                                                                                                                                                                                                                                                                                                                                   |
| <code>end-date date</code><br>[ <i>time</i> ]<br><code>start-date date</code><br>[ <i>time</i> ] | Specifies the lower and upper ends of a range of dates for traffic logs. You can omit the year (the current year is the default), or express the year using the last two digits or all four digits. The hour, minute, and second are optional. The delimiter between the date and the time can be a dash or an underscore:<br><b>12/31/2001-23:59:00</b><br><b>12/31/2001_23:59:00</b>                                                       |
| <code>end-time time</code><br><code>start-time time</code>                                       | Specifies the lower and upper ends of a range of times for traffic logs. When you specify a start-time and/or end-time, the device sorts or filters the logs based on the specified times, regardless of the date. Specify the time in the following format: <i>hh:mm:ss</i>                                                                                                                                                                 |
| <code>min-duration</code>                                                                        | Displays traffic log entries for traffic whose duration was longer than or equal to the minimum duration specified.                                                                                                                                                                                                                                                                                                                          |
| <code>max-duration</code>                                                                        | Displays traffic log entries for traffic whose duration was shorter than or equal to the maximum duration specified.                                                                                                                                                                                                                                                                                                                         |
| <code>no-rule-displayed</code>                                                                   | Displays traffic log entries but does not display policy information.                                                                                                                                                                                                                                                                                                                                                                        |
| <code>policy</code>                                                                              | Displays traffic log entries for a policy (specified by its ID number) or for several policies (specified by a range of ID numbers). The ID number can be any value between 0 and the total number of established policies. To define a range, enter the starting and ending ID numbers using this syntax:<br><i>pol_num [- pol_num ]</i>                                                                                                    |
| <code>service</code>                                                                             | Displays traffic log entries for a specified Service, such as <b>TCP</b> , <b>ICMP</b> , <b>FTP</b> , or <b>Any</b> . The name does not have to be complete; for example, both <b>TC</b> and <b>CP</b> are recognized as <b>TCP</b> . Although you cannot specify a Service group, note that because <b>TP</b> is recognized as <b>FTP</b> , <b>HTTP</b> , and <b>TFTP</b> , entering <b>TP</b> displays log entries for all three services. |
| <code>src-ip</code>                                                                              | Displays traffic log entries for a specified source IP address or range of source IP addresses. Include the subnet mask for a source IP address to display traffic entries for all IP addresses in the same subnet as the specified source IP address. You cannot specify a source IP range and a source subnet mask simultaneously. You can also direct the device to sort event logs by source IP address.                                 |
| <code>src-netmask</code>                                                                         | Displays traffic log entries for a specified source subnet mask.                                                                                                                                                                                                                                                                                                                                                                             |
| <code>src-port</code>                                                                            | Displays traffic log entries for a specified source port number or range of source port numbers.                                                                                                                                                                                                                                                                                                                                             |

**Example:** The following command displays traffic log entries from the source port 8081:

```
get log traffic src-port 8081
```

## usb

```
get log usb info
set log usb filesize megabytes
set log usb enable
```

Configures the device for logging to a USB flash drive or queries the device for the USB logging configuration.

|          |                                                                                                                                                                       |
|----------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| enable   | Enables logging to a file on a USB flash drive.                                                                                                                       |
| filesize | Sets the maximum size, in megabytes, for a log file on a USB flash drive.                                                                                             |
| info     | Queries whether USB logging is enabled and also the maximum log file size.                                                                                            |
| usb      | Specifies a USB flash drive as the target of a log operation. Use <b>get log usb info</b> to query whether USB logging is enabled and also the maximum log file size. |



# mac

Use the **mac** commands to configure a static Media Access Control (MAC) address for a physical security interface or to display information about the current MAC configurations.

---

**NOTE:** You can only execute the **mac** commands when the device is configured in transparent mode.

---

## Syntax

---

### **get**

get mac [ *interface* ]

### **set**

set mac *mac\_addr* *interface*

## Keywords and Variables

---

### **Variable Parameters**

*mac\_addr* Specifies the MAC address.

*interface* Specifies the name of the interface, as with *ethernet1*.

**Example:** The following command sets the MAC address on an security device to 111144446666 for the *ethernet7* interface:

```
set mac 111144446666 ethernet7
```



# mac-learn

Use the **mac-learn** commands to clear the entries in the Media Access Control (MAC) learning table or to display information about the current MAC configurations.

**mac-learn** functions only when an interface is in transparent mode. When interfaces are in transparent mode, the security device operates at Layer 2. The security zone interfaces do not have IP addresses, and the security device forwards traffic like a Layer 2 switch.

## Syntax

---

### *clear*

```
clear [cluster] mac-learn [stats]
```

### *get*

```
get mac-learn [interface]
```

### *set*

```
set mac-learn
```

## Keywords and Variables

---

### **Variable Parameter**

get mac-learn *interface*

*interface*      Identifies the interface.

### **cluster**

clear cluster mac-learn [ ... ]

cluster      Propagates the **clear** operation to all other devices in an NSRP cluster.

### **stats**

clear [ cluster ] mac-learn stats

stats      Clears the MAC learning table statistics.

# mac-learn-sticky

Use the **mac-learn-sticky** commands to retain Media Access Control (MAC) address learnt from an interface for a set interval in the MAC learning table even when the interface state goes down.

**mac-learn-sticky** functions only in transparent mode. When interfaces are in transparent mode, the security device operates at Layer 2. The security zone interfaces do not have IP addresses, and the security device forwards traffic in the same manner as a Layer 2 switch.

## Syntax

---

### **set**

```
set mac-learn-sticky
```

## Keywords and Variables

---

### **mac-learn-sticky**

```
set mac-learn-sticky
unset mac-learn-sticky
```

**mac-learn-sticky** Retains the MAC address learnt from an interface for a set interval in the MAC learning table, even when the interface link goes down. By default, **mac-learn-sticky** is disabled, meaning that once an interface's link status changes to down, the MAC address learnt from the interface is cleared from the MAC learning table.



# match-group

Use the **match-group** commands to configure the security device for setting policy based routing (PBR).

## Syntax

---

### set

```
set match-group { name match_group_name |
 match_group_name ext-acl ext_acl_id match-entry group-entry-id }
```

## Keywords and Variables

---

### **match-group**

```
set match-group name match_group_name
set match-group match_group_name ext-acl ext_acl_id match-entry group-entry-id
unset match-group match_group_name ext-acl ext_acl_id match-entry group-entry-id
```

#### match-group

Specifies the name of a match group. Each match-group name must be a unique alphanumeric string and must be between 1 and 28 characters in length. Once a match-group name is defined, then you can associate or remove an extended access-list.

You can use match groups to group multiple extended access-lists. Match group entries are evaluated sequentially by group entry id number. You can combine multiple extended access-lists to a single match group and then assign the single match group to an action group. An action group can have multiple forwarding solutions and an associated lookup sequence number.

To configure an action group, see the *Concepts & Examples ScreenOS Reference Guide*.

To remove an access-list, enter **unset match-group** *match\_group\_name* **match-entry** *group\_entry\_id*.



# memory

Use the **memory** commands to set or display memory-allocation settings.

## Syntax

---

### **get**

```
get memory
 [kernel | task_id | module { all | id_num }]
 [all | bin | error | free | used]
 [{ chunk | pool } [name [name_str] | task [id_num]]]
```

## Keywords and Variables

---

### **Variable Parameters**

get memory *task\_id*

*task\_id*            The task ID number.

### **all**

get memory all

all                Displays all memory fragments in the device.

### **bin**

get memory bin

bin                Displays the task memory bin.

### **chunk**

get memory chunk [ ... ]

chunk             Displays the object pool (*name\_str*) memory.

**error**

get memory error

error            Displays erroneous memory fragments.

**free**

get memory free

free            Displays free memory.

**kernel**

get memory kernel [ ... ]

kernel           Displays memory statistics about the kernel heap.

**module**

get memory module { ... }

module           Displays all or a single memory module (*id\_num*).

**pool**

get memory pool [ ... ]

pool            Displays pooled memory.

**used**

get memory used

used            Displays used memory.

# management-vroute

Use the **management-vroute** command to create a virtual router (VR) dedicated to management.

A management (MGT) VR supports the out-of-band management infrastructure and segments firewall management traffic away from production traffic. By default, the ScreenOS TCP/IP stack first looks up routes for the self-initiated traffic in the default VR, and if routes are not found, it searches the route table in untrust-vr. When you designate a VR as a MGT VR, the TCP/IP stack looks up the routes in the MGT VR.

A MGT VR is valid in the root virtual system (vsys) only. A MGT VR is also not valid at Layer 2, because a virtual local area network (VLAN) interface at Layer 2 cannot be moved to another VR other than the trust-VR.

## Syntax

---

```
set management-vroute vr_name
```

## Keywords and Variables

---

### *Variable Parameter*

```
set management-vroute vr_name
unset management-vroute
```

*vr\_name* Specifies the virtual router to be set as the MGT VR.

**Example:** The following command sets a VR named **trust2-vr** as the management VR:

```
set management-vroute trust2-vr
```



# mip

Use the **mip** command to show all mapped IPs (MIPs) in a specified virtual system (vsys) or root system.

## Syntax

---

```
get mip [all]
```

## Keywords and Variables

---

### *all*

```
get mip all
```

**all**            Displays all MIPs in a specified vsys or root.



# mirror

Use the **mirror** commands to mirror all traffic for at least one source interface to a destination interface. This command is useful for debugging and monitoring network traffic. For example, you can connect a sniffer to a destination interface to monitor traffic passing through multiple source interfaces.

---

**NOTE:** When a destination interface mirrors multiple source interfaces, the device may drop some frames as a result of a bandwidth mismatch.

---

## Syntax

---

### *get*

get mirror port

### *set*

set mirror port source *interface1* destination *interface2*

## Keywords and Variables

---

### *destination | source*

set mirror port source *interface1* destination *interface2*

**destination**      Specifies the source and destination interfaces.



# modem

Use the **modem** commands to configure modem and dial-up settings for the serial link.

## Syntax

---

### **exec**

```
exec modem { 0 | 1/0 | 2/0 }
 [
 command string |
 dialup |
 stop |
 connect isp_name_str |
 disconnect
]
```

### **get**

```
get modem { 0 | 1/0 | 2/0 }
 [
 config |
 queue { rcv-q | xmt-q } |
 settings |
 state |
 stats
]
```

### **set**

```
set modem { 0 | 1/0 | 2/0 }
 {
 idle-time number |
 interval number |
 isp name_str
 {
 account login string password pswd_str |
 primary-number string [alternative-number string] |
 priority number
 }
 isp-failover
 {
 holddown number |
```

```

 type { route | track-ip | vpn } vrouter vr_name ipaddr/mask
 } |
 retry number |
 settings name_str { active | init-strings string } |
 speed number
}

```

## Keywords and Variables

---

### ***account login***

```
set modem isp name_str account login string password pswd_str
```

**account login** Specifies the login name (*string*) and account password (*pswd\_str*) for the ISP account.

**Example:** The following command configures the login *kgreen* and the password *bodie45* for the ISP account *isp1*:

```
set modem isp isp1 account login kgreen password bodie45
```

### ***active***

```
set modem settings name_str active
unset modem settings name_str
```

**active** Activates the specified modem settings and deactivates any other configured settings.

**Example:** The following command activates settings for the modem *usr14400*:

```
set modem settings usr14400 active
```

### ***alternative-number***

```
set modem isp name_str primary-number string alternative-number string
```

**alternative-number** Specifies an alternate phone number to access the ISP.

**Example:** The following command configures primary and alternate phone numbers to access the ISP 'isp1':

```
set modem isp isp1 primary-number 4085551212 alternative-number 4085551313
```

### ***command***

```
exec modem command string
```

**command** Sends Hayes AT commands to the modem.

**config**

get modem config

config            Displays HDLC/PPP parameters for a current session.

**connect**

exec modem connect

connect           Connects the device to a specific ISP for testing.

**dialup**

exec modem dialup

dialup            Enables dialup to start. If the first ISP fails, the device will try other ISPs. Traffic is monitored on the serial interface.

**disconnect**

exec modem disconnect

disconnect        Disconnects the current connection.

**idle-time**

set modem idle-time *number*  
unset modem idle-time *number*

idle-time         Specifies the number of minutes that elapse with no traffic on the dial-up connection before the security device disconnects the modem. The default is 1 minute. A value of 0 means the modem never disconnects, even if there is no traffic on the dial-up connection.

**Example:** The following command sets an idle time of 12 minutes:

**set modem idle-time 12**

**init-strings**

set modem settings *name\_str* init-strings *string*  
unset modem settings *name\_str*

init-strings       Specifies the initialization string for the specified modem. AT string command that is recognized by the modem.

**Example:** The following command sets an initialization string for the modem usr14400:

**set modem settings usr14400 init-strings  
AT&FX4&A3&B1&D2&H1&I0&K1&M4&R2S7=60**

## *interval*

```
set modem interval number
unset modem interval number
```

**interval** Specifies the seconds (*number*) between dial-up retries. The default is 60 seconds. Range is 3-60 seconds.

**Example:** The following command sets a dial-up interval of 45 seconds:

```
set modem interval 45
```

## *isp*

```
set modem isp name_str { ... }
unset modem isp name_str
```

**isp** Specifies the ISP.

**Example:** The following command configures the login *juniper* and the password *bodie45* for the ISP *isp1*:

```
set modem isp isp1 account login juniper password bodie45
```

## *isp-failover*

```
set modem isp-failover holddown number
set modem isp-failover type { route | track-ip | vpn } vrouter vr_name ipaddr/mask
unset modem isp-failover holddown
unset modem isp-failover type
```

**isp-failover** Allows you to configure up to four ISPs for failover and dial-up connections. The holddown timer and type arguments can be configured as follows:

- **holddown** *number* specifies the number of seconds to wait before initiating failover. The default value is 30 seconds; however, the valid range is between 1 and 300 seconds. The **unset** command returns the holddown value to the default. Using the **set** command twice overwrites the previous value.
- **type** { ... } **vrouter** *vr\_name ip\_addr/mask* specifies a route generated by a dynamic routing protocol, such as OSPF or BGP. The security device monitors the status of the interface in the virtual router. this feature is disabled by default.

## *primary-number*

```
set modem isp name_str primary-number string
```

**primary-number** Specifies the primary phone number to access the ISP. If your modem uses tone dial by default, but you want to use pulse dial, precede the phone number with a **P**. If your modem uses pulse dial by default, but you want to use tone dial, precede the phone number with a **T**.

**Example:** The following command configures the primary phone number to access the ISP *isp1* and specifies tone dial:

```
set modem isp isp1 primary-number T4085551212
```

## priority

```
set modem isp name_str priority number
```

**priority** Specifies the priority of this ISP for dial-up backup, relative to other ISPs that may be configured. A value of 1 is the highest priority. The *number* can be 0 or 1-4.

**Example:** The following command configures the ISP *isp1* as the highest priority for dial-up backup:

```
set modem isp isp1 priority 1
```

## queue

```
set modem queue {...}
get modem queue {...}
```

**rcv-q** Displays contents for the HDLC rcv queue. Used for debugging only.

**xmt-q** Displays contents for the HDLC xmt queue. Used for debugging only.

**Example:** The following command displays the content of the HDLC rcv queue:

```
set modem queue rcv-q
```

## retry

```
set modem retry number
unset modem retry number
```

**retry** Specifies the number of times ScreenOS dials the primary number, and then the alternative-number, if the line is busy or there is no answer from the ISP. The default is 3 times. The range is 0-10 times.

**Example:** The following command sets the number of dial-up retries to 4:

```
set modem retry 4
```

## settings

```
set modem settings name_str active | init-strings string
unset modem settings name_str
get modem settings
```

**settings** Configures settings for the specified modem or ISP.

**Example:** The following command activates settings for the modem *usr14400*:

```
set modem settings usr14400 active
```

## *speed*

set modem speed *number*  
unset modem speed

**speed** Specifies the maximum baud rate for the serial link between the device and the modem. The baud rate can be 9600, 19200, 38400, 57600, or 115200 bps. The default is 115200 bps.

**Example:** The following command sets a maximum baud rate of 56Kbps for the serial link:

**set modem speed 57600**

## *state*

get modem state

**state** Shows modem control state, machine state, and HDLC status.

## *stats*

get modem stats

**stats** Shows modem status. Displays modem and HDLC layer statistics and the IN table and OUT table statistics.

## *stop*

exec modem stop

**stop** Disconnects the current connections and brings down the serial interface.

# multicast-group-policy

Use the **multicast-group-policy** commands to define a policy that allows multicast control traffic to cross the security device.

## Syntax

---

### **get**

```
get multicast-group-policy between zone1 zone2
```

### **set**

```
set multicast-group-policy
 from zone1
 {
 mgroup { mcst_addr1/mask | any }
 to zone2 [mgroup]
 [
 igmp-message |
 pim-message
 {
 bsr-static-rp [join-prune] |
 join-prune
 }
] [bi-directional]
] |
 mgroup-list id_num
 to zone2
 {
 igmp-message |
 pim-message
 {
 bsr-static-rp [join-prune] |
 join-prune
 }
] [bi-directional]]
```

## Keywords and Variables

---

### **between**

```
get multicast-group policy between zone1 zone2
```

between            Displays the multicast policy configured between the specified zones.

### **bi-directional**

```
set multicast-group policy from { ... } to { ... } bi-directional
unset multicast-group policy from { ... } to { ... } bi-directional
```

bi-directional    Specifies that the policy applies to both directions of multicast traffic.

**Example:** The following command defines a bi-directional multicast group policy that allows PIM messages between the trust and untrust zones:

```
set multicast-group-policy from trust mgroup any to untrust pim-message
bsr-static-rp join-prune bi-directional
```

### **from ... to**

```
set multicast-group policy from zone1 mgroup mcst_addr1 to zone2
mgroup mcst_addr2 { ... }
set multicast-group policy from zone1 mgroup any to zone2 { ... }
set multicast-group policy from zone1 mgroup-list id_num to zone2
unset multicast-group policy from zone1 mgroup mcst_addr1 to zone2 { ... }
unset multicast-group policy from zone1 mgroup any to zone2
unset multicast-group policy from zone1 mgroup-list id_num to zone2
```

from { ... } to    Specifies the two zones between which the policy applies.

- *zone1* is the name of the source security zone.
- *zone2* is the name of the destination security zone.
- *mcst\_addr1* is the multicast IP address of the multicast group from which the zone accepts multicast packets
- *mcst\_addr2* is the translated multicast group address, if you are translating a multicast group address from one zone to another
- *id\_num* is the ID number of the access list that specifies the multicast groups from which the zone accepts multicast packets

**Example:** The following command creates a multicast policy allowing IGMP messages from the Trust zone to the Untrust zone:

```
set multicast-group-policy from trust mgroup-list 12 to untrust igmp-message
```

### ***igmp-message***

set multicast-group policy from { ... } to { ... } igmp-message  
unset multicast-group policy from { ... } to { ... } igmp-message

igmp-message Specifies a multicast group policy that allows IGMP messages between the specified zones.

### ***pim-message***

set multicast-group policy from { ... } to { ... } pim-message  
  { bsr-static-rp | join-prune }  
unset multicast-group policy from { ... } to { ... } pim-message  
  { bsr-static-rp | join-prune }

pim-message Specifies a multicast group policy that allows PIM BSR and/or join-prune messages between the specified zones.



# NHRP Commands

Use the **nhrp** context to configure Next Hop Resolution Protocol (NHRP) for a virtual router.

## Context Initiation

---

Initiate the **nhrp** context by entering the following commands:

1. Enter the vrouter context by executing the `set vrouter` command.

```
set vrouter vrouter
```

For example:

```
set vrouter trust-vr
```

2. Configure **nhrp** parameters by executing the **set protocol nhrp** command.

```
device(trust-vr)-> set protocol nhrp { . . . }
```

## NHRP Command List

---

The following commands are executable in the **nhrp** context. Click on a keyword in the table to go to complete syntax and usage information.

|                |                                                      |
|----------------|------------------------------------------------------|
| acvpn-profile  | AC-VPN IKE gateway.                                  |
| cache          | Cache entries in the NHRP module.                    |
| holdtime       | Length of time the NHS NHRP cache default hold time. |
| max-query      | Number of times the NHS queries the NHC.             |
| nhs            | Private IP address of the NHRP server.               |
| peer           | Private IP address of the NHRP peer.                 |
| retry-interval | request retry interval                               |

## ***acvpn-profile***

Use the **acvpn-profile** command on the NHRP Next Hop Server (NHS) to attach an AC-VPN profile to the NHRP context. You create the **acvpn-profile** on the hub with the **set vpn** command. This profile is pushed to the NHRP Next Hop Client (NHC) in the Registration Reply message, and is used by the NHC to set up dynamic tunnel with another NHC.

### **Syntax**

#### **set**

```
set vrouter name_str acvpn-profile string
```

### **Keywords and Variables**

#### **string**

```
set vrouter name_str acvpn-profile string
```

*string* Specifies the acvpn-profile.

## ***cache***

Use the **cache** command on the NHC to provide the NHS with information about your subnetwork. The subnet you set with this command is sent to the NHS in the Resolution Request message. The NHS caches this information and provides it to any NHC attempting to communicate with hosts in your subnetwork. To purge cached NHRP information about the NHS, use the **unset** command. When you **unset cache**, the NHS updates all NHCs you have communicated with in the past.

### **Syntax**

#### **Get**

```
get vrouter name_str protocol nhrp cache [ip_addr/mask]
```

#### **Set**

```
set vrouter name_str protocol nhrp cache [ip_addr/mask]
unset vrouter name_str protocol nhrp cache [ip_addr/mask]
```

### **Keywords and Variables**

*ip\_addr/mask* Specifies the subnet on the NSC.

## ***holdtime***

Use the **holdtime** command on the NHS to set the length of time the NHS retains cached information about NHCs in the network. Use the **unset** command to return **holdtime** to the default.

## Syntax

### Set

```
set vrouter name_str protocol nhrp holdtime number
unset vrouter name_str protocol nhrp holdtime number
```

## Keywords and Variables

```
set vrouter name_str protocol nhrp holdtime number
```

*number* Length of time, in seconds, the NHS retains cache information about NHCs. The range is 30 to 65535; the default is 300 seconds.

## *max-query*

Use the **max-query** command to set the maximum number of times the NHC sends a Resolution Request message to the NHS in the event of an interruption in network connectivity. Use the **unset** command to return max-query to the default.

## Syntax

### set

```
set vrouter name_str protocol nhrp max-query number
unset vrouter name_str protocol nhrp max-query number
```

## Keywords and Variables

*number* Specifies the maximum number of time the NHC queries the NHS. The range is 1 to 12, the default is 6.

## *nhs*

Use the **nhs** command to set the NHS for your NHC

## Syntax

### Set

```
set vrouter name_str protocol nhrp nhs ip_addr
unset vrouter name_str protocol nhrp nhs ip_addr
```

## Keywords and Variables

*ip\_addr*/

*ip\_addr* Specifies the private IP address of the NHRP server.

## *peer*

Use the **peer** command to display information about all NHRP peers. When entered on the NHS, this command displays all registered peers; on the NHC, this command displays all the learned peers. The display also includes VPN information for each peer entry that was learned through NHRP interactions. Additionally, if a peer IP address is specified, a list of cache entries from that peer is also displayed.

### Syntax

#### Get

```
get vr vr-name protocol nhrp peer [peer-ip-addr]
```

### Keywords and Variables

```
get vr vr-name protocol nhrp peer [peer-ip-addr]
```

*peer-ip-addr*      The private IP address of the NHRP peer.

## *retry-interval*

Use the **retry-interval** command to set the frequency with which the NHC sends Resolution Request messages to the NHS in the event of an interruption in network connectivity. Use the **unset** command to return **retry-interval** to the default value.

### Syntax

#### Set

```
set vrouter name_str protocol nhrp retry-interval number
unset vrouter name_str protocol nhrp retry-interval number
```

### Keywords and Variables

#### Variable Parameter

*number*

*number*      Specifies the interval, in seconds, between NHC Resolution Request messages to the NHS. The range is 1 to 60; the default is 3.

# nrtip

Use the **nrtip** commands to clear all NetScreen Reliable Transfer Protocol (NRTIP) packet queues.

NRTIP is for multicasting NetScreen Redundancy Protocol (NSRP) control messages to multiple receivers when security devices are in a redundancy cluster (interconnected through the High Availability, or HA, ports). NRTIP ensures that the primary security device always forwards configuration and policy messages to the backup devices.

## Syntax

---

### *clear*

```
clear [cluster] nrtip queues
```

### *get*

```
get nrtip
{
 counters (all | receive [number] | send) |
 group |
 xmtq
}
```

## Keywords and Variables

---

### *cluster*

```
clear cluster nrtip queues
```

**cluster** Propagates the **clear** operation to all other devices in an NSRP cluster.

**counters**

get nrtп counters ( all | receive *number* | send }

counters            Displays statistical information tracked by counters.

- **all**—Displays all counter statistics.
- **receive** [ *number* ]—Displays only counter statistics for information that the device receives from other devices in the cluster. The optional *number* parameter is an ID number that identifies a particular device in the cluster.
- **send**—Displays only counter statistics for information that the device sends to other devices.

**groups**

get nrtп group

group                Displays the ID numbers of devices belonging to the group, and a count of the devices in the group.

**queues**

clear nrtп queues

queues                Clears the NRTP packet queues.

**xmtq**

get nrtп xmtq

xmtq                  Displays the length of the queue containing packets awaiting ACK responses from other devices.

# nsgp

Use the **nsgp** commands to configure the General Packet Radio Service (GPRS) Overbilling Attack notification feature on the Gi firewall (the server).

An Overbilling attack can occur in various ways. It can occur when a legitimate subscriber returns his or her IP address to the IP pool, at which point an attacker can hijack the IP address, which is vulnerable because the session is still open. When the attacker takes control of the IP address without being detected and reported, the attacker can download data for free (or, more accurately, at the expense of the legitimate subscriber) or send data to other subscribers.

An Overbilling attack can also occur when an IP address becomes available and gets reassigned to another Mobile Station (MS). Traffic initiated by the previous MS might be forwarded to the new MS, causing the new MS to be billed for unsolicited traffic.

## Syntax

---

### **clear**

```
clear nsgp { ip_addr | all }
```

### **get**

```
get nsgp [detail]
```

### **set**

```
set nsgp
 {
 context id_num type session zone zone hold-off number |
 md5-authentication password |
 port port_num
 }
```

## Keywords and Variables

---

### ***all***

clear nsgp all

**all** Closes all active connections on the security device. You can also close active connections on a per IP address basis by entering a specific IP address instead of the keyword **all**.

### ***context***

set nsgp context *id\_num* type *string* zone *zone*  
unset nsgp context *id\_num*

**context** Creates or deletes a context of a specific type for the specified zone.

- **type *string***—Identifies the type of context. Currently, ScreenOS only supports the session type.
- **zone *name***—Identifies the zone for which you are creating the context.
- **hold-off *number***—Specifies the time, in seconds, during which an IP address cannot be reused. This option also denies the unintended traffic from the server within the specified time. The range is 10—600 seconds.

The same context must exist on both the client and the server.

### ***detail***

get nsgp [ detail ]

**detail** Displays NetScreen Gatekeeper Protocol (NSGP) settings and the status of contexts within the current root system or virtual system (vsys). At the root level, this command also displays information for all vsys.

### ***md5-authentication***

set nsgp md5-authentication *password*  
unset nsgp md5-authentication

**md5-authentication** Directs the Gi firewall to enforce the MD5 authentication option specified in the TCP header. You can only specify one MD5 auth password per security device.

This command is only available at the root level and not at the vsys level.

### ***port***

set nsgp port *port\_num*  
unset nsgp port

**port** Identifies the port number used by the Gi firewall to receive Overbilling Attack notifications. The default is 12521.

This command is only available at the root level and not at the vsys level.

# nsmgmt

Use the **nsmgmt** commands to set up a security device for configuration and monitoring by Network and Security Manager (NSM), an enterprise-level management application that configures multiple security devices from remote hosts.

The **nsmgmt** command can modify settings for the NSM Agent, which resides on the security device. The NSM Agent receives configuration parameters from the management system and pushes it to ScreenOS. The NSM Agent also monitors the device and transmits reports back to the management system.

For more information, see the information about adding devices in the Network and Security Manager documentation at <http://www.juniper.net/techpubs/software/management/security-manager>.

## Syntax

---

### get

```
get nsmgmt
{
 proto-dist
 {
 table { bytes | packets } |
 user-service
 }
}
```

### set

```
set nsmgmt
{
 bulkcli reboot-timeout { number | disable } |
 enable
 init
 {
 id string |
 installer name name_str password pswd_str |
 otp string
 } |
 report
 {
 alarm { attack | di | other | traffic } enable |
 log { config | info | self | traffic } enable |
 proto-dist
 {
 enable |
 user-service svc_name { ah | esp | gre | icmp | ospf | tcp | udp }
 { port_num1-port_num2 }
 }
 }
}
```

```

 } |
 statistics { attack | ethernet | flow | policy } enable
 }
server
 primary | secondary
 { name_str | ip_addr } [port number | src-interface interface]
}

```

## Keywords and Variables

---

### **all**

```
unset nsmgmt all
```

**all**                      Unsets all Network and Security Manager management configurations.

### **bulkcli**

```
set nsmgmt bulkcli reboot-timeout { number | disable }
unset nsmgmt bulkcli reboot-timeout { number | disable }
```

**bulkcli**                      Enables, disables or sets the bulk-CLI reboot timeout value (expressed in seconds). This setting determines how the device performs rollback when a NSM connection drops during an update session. When this happens, the Agent iterates through all the configured NSM servers once to see if it can establish another connection. If not, the agent waits for the specified time period before it reboots the device to roll back the configuration.

The range for the reboot-timeout value is 60 through 86400.

### **enable**

```
get nsmgmt enable
set nsmgmt enable
unset nsmgmt enable
```

**enable**                      Enables remote management by initiating contact with the management server.

**init**

```

get nsmgmt init
set nsmgmt init id string
set nsmgmt init installer name name_str password pswd_str
set nsmgmt init otp string
unset nsmgmt init {...}

```

**init** Sets initialization parameters for interaction with the management server.

- **id *string*** An ID used (only once) during initiation of the connection between the security device and the management server. The security device passes the ID to the Management System to look up the One-Time Password in the management database.
- **installer name *name\_str* password *pswd\_str***—Specifies an installer name and password, used (only once) during initiation of the connection between the security device and the management server.
- **otp *string***—Sets the One-Time Password (OTP). The security device uses this password one time to contact the Security Management system. After initiation of contact between the device and the management database, the device executes an **unset** command to erase the OTP.

**report**

```

set nsmgmt report { alarm | log | proto-dist | statistics } { ... }
unset nsmgmt report { alarm | log | proto-dist | statistics } { ... }

```

**report** Specifies which event messages the security device transmits to the **server**.

**alarm**—Enables the transmission of alarm events. The categories of alarms are as follows:

- **attack**—Transmits attack alarms such as syn-flag or syn-flood. For more information about such attacks, see “zone” on page 761.
- **di**—Transmits attack alarms generated during Deep Inspection.
- **traffic**—Transmits traffic alarms.
- **other**—Transmits alarms other than attack, Deep Inspection, or traffic alarms.

The **enable** switch enables messaging for the specified alarm message.

**log**—Enables the transmission of log events. The categories of logs are as follows:

- **config**—Transmits log messages for events triggered by changes in device configuration.
- **info**—Transmits low-level notification log messages about noncritical changes that occur on the device, as when an authentication procedure fails.
- **self**—Transmits log messages concerning dropped packets (such as those denied by a policy) and traffic that terminates at the security device (such as administrative traffic). The self log displays the date, time, source address/port, destination address/port, duration, and service for each dropped packet or session terminating at the security device.

- **user-service** *svc\_name*—Specifies messages generated by the following services:
  - **ah** AH (Authentication Header) service.
  - **esp** ESP (Encapsulating Security Payload) service.
  - **gre** GRE (Generic Routing Encapsulation).
  - **icmp** ICMP (Internet Control Message Protocol).
  - **ospf** OSPF (Open Shortest Path First).
  - **tcp** TCP (Transmission Control Protocol).
  - **udp** UDP (User Datagram Protocol).

The *port\_num1-port\_num2* setting specifies a range of port numbers.

- **traffic**—Transmits alarms generated while the device monitors and records the traffic permitted by policies. A traffic log notes the following elements for each session:
  - Date and time that the connection started
  - Source address and port number
  - Translated source address and port number
  - Destination address and port number
  - The duration of the session
  - The service used in the session

The **enable** switch enables messaging for the specified log message.

**statistics**—Enables the security device for reporting statistical information to the server:

- **attack**—Enables transmission of messages containing attack statistics.
- **ethernet**—Enables transmission of messages containing Ethernet statistics.
- **flow**—Enables transmission of messages containing traffic flow statistics.
- **policy**—Enables transmission of messages containing policy statistics.

The **enable** switch enables messaging for the specified statistical message.

## ***proto-dist***

```
get nsmgmt proto-dist { table { bytes | packets } | user-service }
set nsmgmt report proto-dist { ... }
unset nsmgmt report proto-dist { string }
```

**proto-dist** Sets or displays parameters for transmission of messages concerning protocol distribution parameters. The categories of protocol distribution are as follows:

- **enable**—Enables transmission of protocol distribution messages to the server.
- **table**—Displays the number of bytes or packets transmitted to the protocol distribution table.
- **user-service**—Displays the user services that are configured on each protocol.

**server**

```
set nsmgmt server { primary | secondary }
 { name_str | ip_addr } [port number | src-interface]
unset nsmgmt server { primary | secondary } { name_str | ip_addr }
```

server            Identifies the Security Management system server.



# nsrp

Use the **nsrp** commands to assign a security device to a failover cluster and to create and configure a virtual security device (VSD) group for the cluster.

The purpose of a VSD group is to allow failover between two or more security devices within a defined cluster. Each VSD group represents a group of devices in a cluster, elects a primary device from the cluster, and provides a virtual security interface (VSI) that external devices use to reference the devices in the cluster.

A group may contain every device in the cluster. For example, if you give three devices the same cluster ID, you can create a VSD group containing all three devices. A device can be in more than one VSD group at a time. For example, a device can be the primary in one VSD group while serving as a backup in another.

To set up a failover VSD group, perform the following steps:

1. Set up a cluster of devices using the **set nsrp cluster** command. This command assigns an identical cluster ID to each device.
2. Set up a VSD group for the cluster using the **set nsrp vsd-group** command.
3. Set up a VSI for the VSD group using the **set interface** command.

## Syntax

---

### **clear**

```
clear [cluster] nsrp counter
 [
 packet-fwd |
 protocol |
 rto
]
```

### **exec**

```
exec nsrp
 {
 probe interface [mac_addr] [count number] |
 sync
 {
 file [name filename] from peer |
 global-config [check-sum | save] |
```

```

 rto
 {
 all |
 arp |
 attack-db |
 auth-table |
 dhcp |
 dip-in |
 dns |
 h323 |
 l2tp |
 phase1-SA |
 pki |
 rm |
 route |
 rpc |
 session |
 vpn |
 infranet
 }
 { from peer }
} |
vsd-group grp_num mode { backup | ineligible | init | pb }
}

```

**get**

```

get nsrp
[
cluster |
counter [packet-fwd | protocol | rto] |
group |
ha-link |
monitor [all | interface | track-ip | zone] |
rto-mirror |
track-ip [ip ip_addr] |
vsd-group [id id_num | all]
]

```

**set**

```

set nsrp
{
arp number |
auth password pswd_str |
cluster [id number | name name_str] |
config sync |
data-forwarding |
encrypt password pswd_str |
ha-link probe [interval number] [threshold number] |
interface interface |
link-hold-time number |
link-up-on-backup |
monitor
{
interface interface [weight number] |
sm number [weight number] |
}
}

```

```

threshold number |
track-ip
{
 ip
 [ip_addr
 [
 interface interface |
 interval number |
 method { arp | ping } |
 threshold number |
 weight number
]
] |
 threshold number |
 weight number |
 } |
zone zone [weight number]
} |
rto-mirror
{
 hb-interval number |
 hb-threshold number |
 id id_num { direction { in | out } } |
 route [threshold number] |
 session [ageout-ack | non-vsi | off] |
 sync
}
secondary-path interface |
track-ip
[
 ip
 [ip_addr
 [
 interface interface |
 interval number |
 method { arp | ping } |
 threshold number |
 weight number
]
]
 threshold number
] |
vsd-group
{
 id id_num
 [
 mode ineligible |
 monitor sm number [weight number] |
 preempt [hold-down number] |
 priority number
] |
 hb-interval number |
 hb-threshold number |
 init-hold number |
 master-always-exist
}
}

```

## Keywords and Variables

---

### *arp*

set nsrp arp *number*  
unset nsrp arp *number*

*arp* Sets the number of gratuitous Address Resolution Protocol (ARP) requests that a newly elected primary unit sends out, notifying other network devices of its presence. The default is 4.

**Example:** The following command instructs the security device to send out seven ARP requests:

**set nsrp arp 7**

### *auth*

set nsrp auth password *pswd\_str*  
unset nsrp auth

*auth* Instructs the security device to authenticate NetScreen Redundancy Protocol (NSRP) communications using the specified password. Valid passwords contain from 1 to 15 characters.

**Example:** The following command sets the NSRP authentication password to **swordfish**:

**set nsrp auth password swordfish**

### *cluster*

get nsrp cluster  
set nsrp cluster id *number*

*cluster id* Assigns the security device to a cluster, expressed as an integer (from 1 to 7, inclusive) to identify the cluster.

**Example:** The following command assigns the security device to cluster 2:

**set nsrp cluster id 2**

### *cluster (clear)*

clear cluster nsrp counter [ ... ]

*cluster* Propagates the **clear** operation to all other devices in an NSRP cluster.

## **config sync**

```
set nsrp config sync
unset nsrp config sync
```

**config sync** Enables or disables synchronization of device configurations between members of the NSRP cluster. After you enable this setting, any configuration change automatically propagates to the other devices in the cluster.

## **counter**

```
clear [cluster] nsrp counter [packet-fwd | protocol | rto]
get nsrp counter [packet-fwd | protocol | rto]
```

**counter** Clears or displays the NSRP counter values.

- **packet-fwd**—Clears or displays packet-forwarding counters only.
- **protocol**—Clears or displays NSRP protocol counters only.
- **rto**—Clears or displays Run Time Objects(RTO) message counters only.

## **data-forwarding**

```
set nsrp data-forwarding
unset nsrp data-forwarding
```

**data-forwarding** Enables or disables packet forwarding. The default is enabled.

## **encrypt password**

```
set nsrp encrypt password pswd_str
unset nsrp encrypt
```

**encrypt password** Specifies that NSRP communications be encrypted using the specified password. Valid passwords contain from 1 to 15 characters.

**Example:** The following command sets the NSRP encryption password to **manta**:

```
set nsrp encrypt password manta
```

## **group**

```
get nsrp group
```

**group** Displays information about the VSD group.

## ha-link probe

```
set nsrp ha-link probe [interval number] [threshold number]
unset nsrp ha-link probe [interval] [threshold]
```

ha-link probe Specifies the automatic sending of NSRP probe requests on all interfaces that are bound to the high availability (HA) zone. If a reply is received from the peer within the threshold, the HA link is considered to be up. If the number of consecutive probe requests sent without receiving a reply from the peer reaches or exceeds the threshold, the HA link is considered to be down. You can specify the following optional parameters:

- **interval *number***—Specifies the interval, in seconds, at which probe requests are sent. Enter a number between 0 and 255. If you do not specify an interval, probe requests are sent every second.
- **threshold *number***—Specifies the failure threshold for the HA link. If the number of consecutive probe requests sent without receiving a reply from the peer reaches or exceeds the threshold, the HA link is considered to be down. Enter a value between 0 and 255. The default threshold is 5.

## interface

```
set nsrp interface interface
```

interface The name of the interface to serve as the high-availability port. For more information, see “Interfaces” on page 771.

**Example:** The following command specifies that the NSRP interface is ethernet4:

```
set nsrp interface ethernet4
```

## link

```
get nsrp link
```

link Displays HA link information

## link-hold-time

```
set nsrp link-hold-time number
unset nsrp link-hold-time
```

link-hold-time The delay time (in seconds) before the security device brings up the link with the peer device.

## link-up-on-backup

```
set nsrp link-up-on-backup
unset nsrp link-up-on-backup
```

link-up-on-backup Specifies that the link is always up on the backup device.

## monitor

```
get nsrp monitor [zone | interface | track-ip] [all]
set nsrp [vsd-group id id_num] monitor { ... }
unset nsrp [vsd-group id id_num] monitor { ... }
```

**monitor** Specifies monitoring of NSRP objects (a physical interface, a zone, or tracked IP addresses) to determine VSD or device failure. You can specify the following parameters:

- **vsd-group id** *id\_num*—Identifies the virtual security device (VSD) to which the threshold or monitored objects you configure applies. If you do not specify a VSD, the threshold or monitored objects you configure apply to the entire device.
- **all**—Displays monitoring information for the device and all VSDs. If you specify **vsd-group id**, only monitoring information for the VSD is displayed.
- **interface** *interface* [ **weight** *number* ]—Identifies the interface to be monitored and the weight that failure of the interface contributes to the failover threshold. The default weight is 255.
- **sm** *number* [ **weight** *number* ]—Adds a security module to the NSRP monitored objects. The value of **sm** is 1–3. The default weight is 255.
- **threshold** *number*—Specifies a failover threshold that determines the failure of a specific VSD (if a VSD is specified) or failure of the device (if no VSD is specified). If the cumulative weight of the failure of all monitored objects (a physical interface, a zone, or tracked IP addresses) exceeds the threshold, the VSD or the device fails. The default threshold value is 255.
- **track-ip weight** *number* [ **threshold** *number* ] [ **ip** *ip\_addr* ]—Enables tracked IP object monitoring and the weight that failure of the tracked IP object (all tracked IP addresses) contributes to the device or VSD failover threshold. The default **weight** value is 255. The **threshold** value is the total weight of failed tracked IP addresses that determines failure of the tracked IP object. The default **threshold** value is 255. Specifies monitoring of tracked IP addresses to determine VSD or device failure. For each IP *ip\_addr* (for both IPv4 and IPv6), you can configure the following:
  - **interface** *interface*—Specifies the outgoing interface through which the security device performs tracking for the specified IP address. If you do not specify an interface, ping tries to find an outgoing interface from routing table entries and ARP tries to find an outgoing interface within the same subnet. If an interface is not found, the tracking attempt fails.
  - **interval** *number*—Specifies the interval, in seconds, between ping or ARP attempts to the specified IP address. Enter a value between 1 and 200. The default is 1.
  - **method** { **arp** | **ping** }—Specifies the method used for tracking the specified IP address. The default is ping. For IPv6 address, only the ping method is used.
  - **threshold** *number*—Defines the number of failed tracking attempts that can occur before the tracking of the specified IP address is considered failed. The default is 3.
  - **weight** *number*—Defines the weight of the failed tracking of the specified IP address. The default is 1.
- **zone** *zone* [ **weight** *number* ]—Identifies the zone to be monitored and the weight that failure of all physical interfaces in the zone contributes to the failover threshold. The default weight is 255.

## probe

```
exec nsrp probe interface [mac_addr] [count number]
```

- probe** Directs the device to immediately begin sending an NSRP probe request every second on an HA zone interface, for the number of times specified by **count**. If the peer receives a reply, the HA link is considered to be up. (If the request times out before the peer receives a reply, the HA link is considered to be down.) The device takes no action if there is no reply. (See "ha-link probe" on page 400.)
- **interface**—Identifies the HA zone interface on which probe requests are sent. You must specify an interface that is bound to the HA zone.
  - **mac\_addr**—Identifies the destination MAC address of an HA interface on a peer device. If you do not specify a destination MAC address, the device uses the default NSRP MAC address to send the probe request.
  - **count number**—Specifies the number of times that the device sends the probe request. Enter a number greater than or equal to 1. (The default is 1.)

## rto-mirror

```
get nsrp rto-mirror
set nsrp rto-mirror { ... }
unset nsrp rto-mirror { ... }
```

- rto-mirror** Creates an optional Run Time Objects(RTO) mirror between two devices in a VSD group to back up RTOs
- In most cases, using this option is not necessary. Normally, RTOs synchronize after execution of the **set nsrp rto sync** command.
- A security device can belong to only one RTO mirror group at a time.
- **id id\_num**—Identifies the VSD group using its identification number *id\_num*, an integer value between 1 and 127 inclusive. The **direction** setting determines if the RTO mirror group direction is inbound or outbound.
  - **hb-interval number**—Specifies the heartbeat interval in seconds.
  - **hb-threshold number**—Specifies the heartbeat-lost threshold. The minimum threshold value is 16 heartbeats.
  - **route [ threshold number ]**—Enables route synchronization between devices in an active-passive NSRP cluster. The threshold *number* value sets the time to clean the synchronized routes on the passive device once it becomes the active.
  - **session ageout-ack**—Specifies a time value based on which the backup device sends an acknowledgement to the primary device to refresh its sessions or time them out. The session age-out value of a backup device is eight times that of the primary device.
  - **session non-vsi**—Enables the synchronization of non-VSI sessions.
  - **session off**—Disables the RTO session.
  - **sync**—Enables RTO synchronization.

**Example:** The following command specifies that the RTO mirror group (10) direction is inbound:

```
set nsrp rto-mirror id 10 direction in
```

## secondary-path

```
set nsrp secondary-path interface
unset nsrp secondary-path
```

secondary-path Specifies a secondary NSRP link interface.

**Example:** The following command specifies that the secondary NSRP link interface is *ethernet5*:

```
set nsrp secondary-path ethernet5
```

## sync

```
exec nsrp sync { ... }
```

sync Specifies the name of a particular configuration, file, or RTO to copy from one unit to the other.

- **file**—Specifies synchronization of the files in flash memory.
  - **name filename**—Specifies a particular file in flash memory. (Executing the **file** option without specifying a filename copies all the files.)
  - **from peer**—Specifies all files from the peer device.
- **global-config**—Specifies synchronization of the current device configurations. The check-sum switch compares the checksum after synchronization. The save switch synchronizes the public key infrastructure (PKI) configuration and saves the synchronization configuration to flash memory.
- **rto**—Specifies synchronization of the current runtime objects (RTOs) in the RTO mirror.
  - **all**—Specifies all possible RTOs.
  - **arp**—Specifies Address Resolution Protocol (ARP) information.
  - **attack-db**—Specifies the Deep Inspection (DI) attack database table information.
  - **auth-table**—Specifies the authentication table information.
  - **dhcp**—Specifies Dynamic Host Configuration Protocol (DHCP) information.
  - **dip-in**—Specifies information about the incoming dynamic Internet Protocol (DIP) addresses table.
  - **dns**—Specifies the Domain Name System (DNS) information.
  - **h323**—Specifies H.323 information.
  - **infranet** Starts a cold synchronization of infranet objects from a peer.
  - **pki**—Specifies certificate information.
  - **phase1-sa**—Specifies information about IKE Phase 1 security associations (SAs).

- **rm**—Specifies Resource Manager information.
- **route**—Specifies all possible routes.
- **rpc**—Specifies information about Remote Procedure Call (RPC) mapping.
- **session**—Specifies the session information.
- **vpn**—Specifies virtual private network (VPN) information.

**Example:** The following command instructs the security device to synchronize all RTOs:

```
exec nsrp sync rto all from peer
```

## track-ip

```
get nsrp track-ip [ip ip_addr]
set nsrp track-ip [...]
unset nsrp track-ip [...]
```

**track-ip** Enables path tracking, which is a means for checking the network connection between an interface and that of another device. The IP address *ip\_addr* identifies the other network device to check.

Executing **unset nsrp track ip** resets the track options to their default values.

- **ip *ip\_addr***
  - **interface *interface***—Specifies the interface through which the security device performs the path tracking. If you do not specify an interface, the device automatically chooses the interface for IP tracking using either the ping or ARP method. If ping is used, the device tries to find an outgoing interface from entries in the routing table. If ARP is used, the device tries to find an outgoing interface within the same subnet. If an interface is not found, the tracking attempt fails.
  - **interval *number***—Specifies the interval in seconds between path tracking attempts. Required value is between 1 and 200. The default is 1.
  - **method { arp | ping }**—Specifies the method used for path tracking. The default is *ping*.
  - **threshold *number***—Defines the number of failed tracking attempts that can occur before the tracking of the IP address is considered failed. The default is 3.
  - **weight *number***—Defines the path weight. Valid weights are between 1 and 255 inclusive. The default weight is 1.
  - **threshold *number***—Defines the number of failed tracking attempts that can occur before the device fails over. The default is 255.
  - **weight *number***—Defines the sum of the weights of the tracked IP addresses that determine failover. The default is 255.

**Example:** The following command enables path tracking through interface **ethernet4** to a device at IP address **172.16.10.10**:

```
set nsrp track-ip ip 172.16.10.10 interface ethernet4
```

## vsd-group

```
get nsrp vsd-group [id id_num | all]
set nsrp vsd-group [...]
unset nsrp vsd-group [...]
```

vsd-group      Configures a VSD group for a cluster.

**id** *id\_num*

Creates a VSD group, identified by *id\_num* (from 1 to 8, inclusive), that contains all members belonging to a single cluster of devices. Once created, a VSD group elects a primary unit from the cluster it contains. Other devices reference the device cluster in the VSD group through the group's virtual security interface (VSI).

- **mode ineligible**—Determines the running mode of the security device. The **ineligible** switch specifies that the local device is not intended for failover, even after system restart. (This may be necessary for administrative reasons.) Executing **unset nsrp vsd-group id number mode ineligible** specifies that the device is eligible again.
- **monitor sm number [ weight number ]**—Enables NSRP to monitor a security module in a specified VSD-group. The value of *sm* is 1–3. The default weight is 255.
- **preempt [ hold-down number ]**—Determines if the primary unit keeps its primary status until the unit itself relinquishes that status. To prevent rapid failovers, the primary device waits for the specified hold-down interval, expressed as a number between 0 and 600 seconds, inclusive. The default is 3.
- **priority number** The priority level of the device, expressed as an integer from 1 to 254, inclusive. The priority level determines the failover order for the device. The failover order determines which unit is the primary unit when two security devices in a redundant group power up simultaneously, and which backup unit becomes the next primary during a failover. (The unit with the number closer to 1 becomes the primary unit.)
- **init-hold** The number of heartbeats that occurs before the system exits the initial state (Init mode). This value can be an integer from 5 to 255. The default is 5.
- **hb-interval number**—Specifies the heartbeat interval, expressed in milliseconds. This value can be an integer from 200 to 1000. The default is 1000.
- **hb-threshold number**—Specifies the heartbeat-lost threshold, the number of lost heartbeats allowed before failure. This value can be an integer from 3 to 255. The default is 3.
- **master-always-exist**—Directs the system to elect a primary unit and keep it operative even if all units in the NSRP cluster fail (by monitoring result). For example, if you disable **master-always-exist**, and two units tracking an IP later fail due to monitoring results, both units become inoperable and traffic cannot go through. If you enable **master-always-exist**, and both units fail, the cluster still elects a primary unit, which remains operable, thus allowing traffic through.

**Example 1:** The following command disables the local device for failover:

```
set nsrp vsd-group id 2 mode ineligible
```

**Example 2:** The following command specifies that 10 heartbeats must occur before the device exits the Init state:

```
set nsrp vsd-group init-hold 10
```

### *vsd-group (exec)*

```
exec nsrp vsd-group grp_num mode { ... }
```

|                     |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|---------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <i>vsd-group</i>    | Specifies a VSD group and the security device's new mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| <i>grp_num</i> mode | <ul style="list-style-type: none"> <li>■ In <b>Backup</b> mode, the device works for the primary device when the primary device fails.</li> <li>■ In <b>Ineligible</b> mode, the device is unavailable as a backup for the primary device.</li> <li>■ In <b>Init</b> mode, the device is in the transient state that occurs when it joins the VSD group. (At the end of this initial hold up time, the device transitions to another state, such as primary, backup, or primary backup.)</li> <li>■ In <b>PB</b> (primary backup) mode, the unit is the first to take over when the primary unit fails.</li> </ul> |

**Example:** The following command instructs the security device to take over when the primary unit fails:

```
exec nsrp vsd-group 2 mode pb
```

### *Defaults*

The default value of **preempt** [ **hold-down** *number* ] is *zero*.

The default value of **vsd-group id** *id\_num* **priority** *number* is *100*.

The default value of **vsd-group id** *id\_num* **hb-interval** *number* is *1000* (1,000 milliseconds, or 1 second).

### *Creating an NSRP Cluster*

The following commands set up an NSRP cluster consisting of two security devices

- Two VSD groups for the cluster
- VSI for the VSD group
- RTO synchronization enabled, including session synchronization

**On Device A****Trust Zone Redundant Interface and Manage IP**

```
set interface redundant2 zone trust
set interface ethernet2/1 group redundant2
set interface ethernet2/2 group redundant2
set interface redundant2 manage-ip 10.1.1.3
```

**Cluster and VSD Groups**

```
set nsrp cluster id 1
set nsrp vsd-group id 0 preempt hold-down 10
set nsrp vsd-group id 0 preempt
set nsrp vsd-group id 0 priority 1
set nsrp vsd-group id 1
set nsrp monitor interface redundant2
set nsrp rto-mirror sync
save
```

**On Device B****Trust Zone Redundant Interface and Manage IP**

```
set interface redundant2 zone trust
set interface ethernet2/1 group redundant2
set interface ethernet2/2 group redundant2
set interface redundant2 manage-ip 10.1.1.4
```

**Cluster and VSD Groups**

```
set nsrp cluster id 1
set nsrp rto-mirror sync
set nsrp vsd-group id 1 priority 1
set nsrp vsd-group id 1 preempt hold-down 10
set nsrp vsd-group id 1 preempt
set nsrp monitor interface redundant2
set nsrp arp 4
set arp always-on-dest
```

**Untrust Zone Redundant Interface**

```
set interface redundant1 zone untrust
set interface ethernet1/1 group redundant1
set interface ethernet1/2 group redundant1
```

**Virtual Security Interfaces**

```
set interface redundant1 ip 210.1.1.1/24
set interface redundant2 ip 10.1.1.1/24
set interface redundant1:1 ip 210.1.1.2/24
set interface redundant2:1 ip 10.1.1.2/24
```

**Routes**

```
set vrouter untrust-vr route 0.0.0.0/0 interface redundant1 gateway 210.1.1.250
set vrouter untrust-vr route 0.0.0.0/0 interface redundant1:1 gateway 210.1.1.250
save
```



# ntp

Use the **ntp** commands to configure the security device for Simple Network Time Protocol (SNTP).

As its name implies, SNTP is a simplified version of Network Time Protocol (NTP), which is a protocol used for synchronizing computer clocks in the Internet. This version is adequate for devices that do not require a high level of synchronization and accuracy. To enable the SNTP feature, use the **set clock ntp** command.

## Syntax

---

### **exec**

```
exec ntp [server { backup1 | backup2 | primary }] update
```

### **get**

```
get ntp
```

### **set**

```
set ntp
{
 auth { preferred | required } |
 interval number |
 max-adjustment number |
 no-ha-sync |
 server
 {
 ip_addr | dom_name |
 backup1
 {
 ip_addr | dom_name |
 src-interface interface |
 key-id number preshare-key string
 } |
 backup2
 {
 ip_addr | dom_name |
 src-interface interface |
 key-id number preshare-key string
 } |
 key-id number preshare-key string |
 src-interface interface
 }
}
```

```

 }
 timezone number1 number2
 }

```

## Keywords and Variables

---

### *auth*

```
set ntp auth { preferred | required }
```

**auth** Configures an authentication mode to secure NTP traffic between the security device and the NTP server.

- **required** Required mode specifies that the security device must authenticate all NTP packets using the key ID and preshared key information that the security device and the NTP server previously exchanged out-of-band (the device does not exchange the preshared key over the network).
- **preferred** Preferred mode specifies that the security device first must try to authenticate all NTP packets by sending out an update request that includes authentication information—key ID and checksum—the same as for Required mode. If authentication fails, the security device then sends out another update request without the authentication information.

**Note:** Before you can set an authentication mode, you must assign a key ID and preshared key to at least one of the NTP servers configured on the security device.

### *interval*

```
set ntp interval number
unset ntp interval
```

**interval** Defines in minutes how often the security device updates its clock time by synchronizing with the NTP server. The range for the synchronization interval is from 1 to 1440 minutes (24 hours).

**Example:** The following command configures the security device to synchronize its clock time every 20 minutes:

```
set ntp interval 20
```

### *max-adjustment*

```
set ntp max-adjustment number
unset ntp max-adjustment
```

**max-adjustment** Configures a maximum time adjustment value. This value represents the maximum acceptable time difference between the security device system clock and the time received from an NTP server. When receiving a reply from an NTP server, the security device calculates the time difference between its system clock and the NTP server and updates its clock only if the time difference between the two is within the maximum time adjustment value that you set.

## no-ha-sync

```
set ntp no-ha-sync
unset ntp no-ha-sync
```

**no-ha-sync** In a high-availability configuration, instructs the security device not to synchronize its peer device with the NTP time update.

## server

```
set ntp server { ip_addr | dom_name }
set ntp server key-id number preshare-key string
set ntp server { backup1 | backup2 } { ip_addr | dom_name }
set ntp server { backup1 | backup2 } key-id number preshare-key string
set ntp server { backup1 | backup2 } src-interface interface
unset ntp server { ... }
```

**server**

- ***ip\_addr*** The IP address of the primary NTP server with which the security device can synchronize its system clock time.
- ***dom\_name*** The domain name of the primary NTP server with which the security device can synchronize its system clock time.
- **backup1 | backup2**
  - ***ip\_addr*** The IP address of the first (or second) backup NTP server with which the security device can synchronize its system clock time in case the primary server is not available.
  - ***dom\_name*** The domain name of the first (or second) backup NTP server with which the security device can synchronize its system clock time in case the primary server is not available.
  - **key-id *number***—Assigns a key id to the backup server for authentication purposes.
  - **preshare key**—Assigns a preshared key to the backup server for authentication purposes.
  - **src-interface *interface***—Indicates the source interface the device uses to send NTP requests to the backup server.
- **key-id *number***—Assigns a key id to the current server for authentication purposes.
- **preshare key**—Assigns a preshared key to the current server for authentication purposes.
- **src-interface *interface***—Indicates the source interface the device uses to send NTP requests.

## timezone

```
set ntp timezone number1 number2
unset ntp timezone
```

**timezone** Defines the Time Zone, expressed as an integer *number1* between -12 and 12 inclusive. A value of zero denotes Greenwich Mean Time (GMT). *number2* expresses minutes.

**Example:** The following command sets the time zone to GMT:

```
set ntp timezone 0
```

## ***update***

exec ntp update

**update** Updates the time setting on a security device to synchronize it with the time setting on an NTP server.

# OS

Use the **os** commands to display kernel and task information for the operating system of the security device.

## Syntax

---

### **get**

```
get os { cost | flow | kernel | misc | task [name_str / id_num] }
```

## Keywords and Variables

---

### **cost**

```
get os cost
```

**cost** Displays the amount of processor time used by elements of the operating system.

### **flow**

```
get os flow
```

**flow** Displays flow statistics.

### **kernel**

```
get os kernel
```

**kernel** Displays kernel statistics.

### **misc**

```
get os misc
```

**misc** Displays miscellaneous information.

## ***task***

get os task [ *name\_str* | *id\_num* ]

task                    Displays information about a specified task (*name\_str*) or task id (*id\_num*).

# OSPF Commands

Use the **ospf** context to begin configuring Open Shortest Path First (OSPF) routing protocol for a virtual router.

## Context Initiation

---

Initiating the **ospf** context can take up to four steps.

1. Enter the vrouter context by executing the **set vrouter** command.

```
set vrouter vrouter
```

For example:

```
set vrouter trust-vr
```

2. Set the router ID for this virtual routing instance.

```
set router-id { id_num | ip_addr }
```

For example:

```
device(trust-vr)-> set router-id 172.16.10.10
```

3. Enter the **ospf** context by executing the **set protocol ospf** command.

```
device(trust-vr)-> set protocol ospf
```

4. Enable OSPF protocol (it is *disabled* by default).

```
device(trust-vr/ospf)-> set enable
```

## OSPF Command List

---

The following commands are executable in the **ospf** context. Click on a keyword in the table to go to complete syntax and usage information.

|                     |                                                                                                                                                                                                                                                                                                                                                                                                                               |
|---------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| advertise-def-route | <p>Use the <b>advertise-def-route</b> commands to advertise or display the default route of the current virtual routing instance (0.0.0.0/0) in all areas.</p> <p>Every router has a default route entry, which matches every destination. (Any entry with a more specific prefix overrides the default route entry.)</p> <p>Command options: <b>get, set, unset</b></p>                                                      |
| area                | <p>Use the <b>area</b> commands to configure an area for an OSPF virtual routing instance.</p> <p>An OSPF area is a region that contains a collection of routers or virtual routing instances.</p> <p>Command options: <b>get, set, unset</b></p>                                                                                                                                                                             |
| authentication      | <p>Use the <b>authentication</b> command to display authentication for the OSPF virtual routing instance.</p> <p>Command options: <b>get</b></p>                                                                                                                                                                                                                                                                              |
| auto-vlink          | <p>Use the <b>auto-vlink</b> commands to direct the local virtual router to automatically create virtual links.</p> <p>Using automatic virtual links replaces the more time-consuming process of creating each virtual link manually. A virtual link is a conveyance that enables two unconnected segments that cannot reach a backbone router to connect with each other.</p> <p>Command options: <b>get, set, unset</b></p> |
| config              | <p>Use the <b>config</b> command to display all commands executed to configure the OSPF local virtual routing instance.</p> <p>Command options: <b>get</b></p>                                                                                                                                                                                                                                                                |
| database            | <p>Use the <b>database</b> command to display details about the current OSPF link state database.</p> <p>Command options: <b>get</b></p>                                                                                                                                                                                                                                                                                      |
| enable              | <p>Use the <b>enable</b> commands to enable or disable OSPF from the current routing instance.</p> <p>Command options: <b>set, unset</b></p>                                                                                                                                                                                                                                                                                  |
| hello-threshold     | <p>Use the <b>hello-threshold</b> commands to set or display the hello threshold. When a neighbor device exceeds this threshold by flooding the virtual router with hello packets, the virtual router drops the extra packets.</p> <p>A Hello packet is a broadcast message that announces the presence of a routing instance on the network.</p> <p>Command options: <b>get, set, unset</b></p>                              |
| interface           | <p>Use the <b>interface</b> command to display all OSPF interfaces on the virtual router.</p> <p>Command options: <b>get</b></p>                                                                                                                                                                                                                                                                                              |

|                      |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|----------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| lsa-threshold        | <p>Use the <b>lsa-threshold</b> commands to set or display the Link State Advertisement (LSA) threshold. When a neighbor device exceeds this threshold by flooding the virtual router with LSA packets, the virtual router drops the extra packets.</p> <p>Link State Advertisements (LSAs) enable OSPF routers to make device, network, and routing information available for the link state database.</p> <p>Command options: <b>get, set, unset</b></p>                                                                                                                                 |
| neighbor             | <p>Use the <b>neighbor</b> command to display details about neighbor devices.</p> <p>Command options: <b>get</b></p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| redistribute         | <p>Use the <b>redistribute</b> commands to import routes from a different protocol than the one used by the current virtual routing instance.</p> <p>The types of routing protocols from which to import routes include</p> <ul style="list-style-type: none"> <li>■ Manually created routes (static)</li> <li>■ Routes from BGP (bgp)</li> <li>■ Routes that have at least one interface with an IP address assigned to it (connected)</li> <li>■ Routes from RIP (rip)</li> <li>■ Routes that have already been imported (imported)</li> </ul> <p>Command options: <b>set, unset</b></p> |
| reject-default-route | <p>Use the <b>reject-default-route</b> commands to reject or restore the default route learned from OSPF (0.0.0.0/0) in the current routing instance.</p> <p>Every router has a default route entry in its routing table. This default route matches every destination. (Any entry with a more specific prefix overrides the default route entry.)</p> <p>Command options: <b>get, set, unset</b></p>                                                                                                                                                                                      |
| retransmit           | <p>Use the <b>retransmit</b> commands to retransmit packets before adjacency ends.</p> <p>Command options: <b>set, unset</b></p>                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| rfc-1583             | <p>Use the <b>rfc-1583</b> commands to use routing table calculation methods consistent with standards specified in the Request For Comments 1583 document.</p> <p>Command options: <b>get, set, unset</b></p>                                                                                                                                                                                                                                                                                                                                                                             |
| routes-redistribute  | <p>Use the <b>routes-redistribute</b> command to display details about routes imported from a protocol other than OSPF.</p> <p>Command options: <b>get</b></p>                                                                                                                                                                                                                                                                                                                                                                                                                             |
| rules-redistribute   | <p>Use the <b>rules-redistribute</b> command to display conditions set for routes imported from a protocol other than OSPF.</p> <p>Command options: <b>get</b></p>                                                                                                                                                                                                                                                                                                                                                                                                                         |
| statistics           | <p>Use the <b>statistics</b> command to display information about Hello packets, link state packets, database descriptions, Shortest Path First (SPF) packets, packets dropped, errors, and other traffic statistics related to the current OSPF virtual routing instance.</p> <p>Command options: <b>get</b></p>                                                                                                                                                                                                                                                                          |
| stub                 | <p>Use the <b>stub</b> command to display details about a stub area created in the current OSPF virtual routing instance.</p> <p>Command options: <b>get</b></p>                                                                                                                                                                                                                                                                                                                                                                                                                           |

|                |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|----------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| summary-import | <p>Use the <b>summary-import</b> commands to summarize a route redistribution.</p> <p>After importing a series of routes to the current OSPF routing instance from a router running a different protocol, you can bundle the routes into one generalized (or summarized) address that uses the same network stem of the prefix address. By summarizing multiple addresses, you allow the OSPF routing instance to treat a series of routes as one route, thus simplifying the process.</p> <p>Command options: <b>get, set, unset</b></p> |
| vlink          | <p>Use the <b>vlink</b> commands to create a virtual link for the current routing instance.</p> <p>A virtual link is a conveyance that allows two segments to connect when the backbone router bridging them cannot reach either segment.</p> <p>Command options: <b>get, set, unset</b></p>                                                                                                                                                                                                                                              |
| vneighbor      | <p>Use the <b>vneighbor</b> command to display information about a virtual routing instance neighbor.</p> <p>Command options: <b>get</b></p>                                                                                                                                                                                                                                                                                                                                                                                              |

### **advertise-def-route**

Use the **advertise-def-route** commands to advertise or display the default route of the current virtual routing instance (0.0.0.0/0) in all areas.

Every router has a default route entry, which matches every destination. Any route entry with a more specific prefix than the default route entry overrides the default entry.

Before you can execute the **advertise-def-route** commands, you must initiate the **ospf** context. (See “Context Initiation” on page 483.)

### **Syntax**

#### **get**

```
get advertise-def-route
```

#### **set**

```
set advertise-def-route
{
 always metric number [preserve-metric] |
 metric number | preserve-metric
}
metric-type { 1 | 2 }
```

## Keywords and Variables

### **always**

set advertise-def-route always { ... }

**always** Directs the routing instance to advertise the default route under all conditions, even if there is no default route in the routing table. If you specify **always**, you must also specify the **metric** parameter; you can optionally specify the **preserve-metric** parameter. If you do not specify **always**, only a non-OSPF active default route is advertised. If you do not specify **always**, you must specify either the **metric** or **preserve-metric** option.

### **metric**

set advertise-def-route always metric *number* metric-type { 1 | 2 }

**metric** Specifies the metric (cost), which indicates the overhead associated with the default route. Enter a number between 1-15. You must specify this parameter if you specify the **always** option.

### **metric-type**

set advertise-def-route [ always ] metric *number* metric-type { 1 | 2 }

**metric-type** Specifies the external route type to determine path preference.

- **1**—Directs the routing instance to use a Type 1 route to evaluate the default route. A type 1 route is a comparable route, with a lower cost than a type 2 route.
- **2**—Directs the routing instance to use a Type 2 route to evaluate the default route. A type 2 route is a noncomparable route, with a higher cost than a type 1 route.

### **preserve-metric**

set advertise-def-route [ always ] preserve-metric metric-type { 1 | 2 }

**preserve-metric** Instructs the security device to use the original (source) route metric when the route is redistributed.

## **area**

Use the **area** commands to configure an area for an OSPF virtual routing instance.

An OSPF area is a region that contains a collection of routers or virtual routing instances.

Before you can execute the **area** commands, you must initiate the **ospf** context. (See “Context Initiation” on page 483.)

## Syntax

### **get**

get area [ *id\_num* | *ip\_addr* ]

**set**

```

set area { id_num | ip_addr }
 [
 metric-default-route number |
 no-summary |
 nssa |
 range ip_addr/mask { advertise | no-advertise } |
 stub |
 type-default-route { 1 | 2 }
]

```

**Keywords and Variables****Variable Parameters**

```

get area [id_num | ip_addr]
set area { id_num | ip_addr }
unset area { id_num | ip_addr }

```

*ip\_addr*            The IP address that identifies the area.

*id\_num*             The OSPF area ID that identifies the area.

**metric-default-route**

```

set area id_num metric-default-route number
unset area id_num metric-default-route number

```

metric-default-  
route            (NSSA and stub areas only)—Specifies the metric for the advertised default route. The default metric is 1. Enter a number between 1-65535.

**no-summary**

```

set area id_num no-summary
unset area id_num no-summary

```

no-summary        (NSSA and stub areas only)—Prevents summary LSAs from being advertised into the area. By default, summary LSAs are advertised into the area.

**nssa**

```

set area id_num nssa
unset area id_num nssa

```

nssa                Specifies that the area is a “not so stubby area.”

**range**

```

set area id_num range ip_addr/mask { advertise | no-advertise }
unset area id_num range ip_addr/mask

```

range              (All areas) Summarizes a specified range of IP addresses in summary LSAs. You can specify multiple ranges for the area. You can specify whether the summarized addresses are advertised inside the area or not with the **advertise** and **no-advertise** keywords.

**stub**

```
set area id_num stub
unset area id_num stub
```

stub                      Specifies the area is a stub area.

**type-default-route**

```
set area id_num type-default-route { 1 | 2 }
unset area id_num type-default-route { 1 | 2 }
```

type-default-  
route                      (NSSA area only)—Specifies the external metric type for the default route. The default metric type is 1. Specify either **1** or **2**.

**authentication**

Use the **authentication** command to display authentication information for the OSPF virtual routing instance.

Before you can execute the **authentication** command, you must initiate the **ospf** context. (See “Context Initiation” on page 483.)

**Syntax**

```
get authentication
```

**Keywords and Variables**

None.

**auto-vlink**

Use the **auto-vlink** commands to automatically create or display details about virtual links.

Using automatic virtual links replaces the more time-consuming process of creating each virtual link manually. A virtual link is a conveyance that enables two unconnected segments that cannot reach a backbone router to connect with each other.

Before you can execute the **auto-vlink** commands, you must initiate the **ospf** context. (See “Context Initiation” on page 483.)

**Syntax**

```
get
get auto-vlink
```

```
set
set auto-vlink
```

**Keywords and Variables**

None.

## **config**

Use the **config** command to display all commands executed to configure the OSPF local virtual routing instance.

Before you can execute the **config** command, you must initiate the **ospf** context. (See “Context Initiation” on page 483.)

### **Syntax**

```
get config
```

### **Keywords and Variables**

None.

## **database**

Use the **database** command to display details about the current OSPF database.

Before you can execute the **database** command, you must initiate the **ospf** context. (See “Context Initiation” on page 483.)

### **Syntax**

```
get database
 [detail] [area [number | ip_addr]]
 [asbr-summary | external | network | nssa-external | router | summary
 [
 adv-router ip_addr |
 self-originate
]
 [link-state-id ip_addr]
]
```

### **Keywords and Variables**

#### **adv-router**

```
get database [...] adv-router ip_addr [...]
```

**adv-router**      Displays the LSAs (Link State Advertisements) from the specified advertising router (*ip\_addr*).

**Example:** The following command displays the LSAs from a router with router ID 172.16.10.10:

```
get database adv-router 172.16.10.10
```

#### **area**

```
get database [...] area [number | ip_addr] [...]
```

**area**            Displays the LSAs in the current area.

**Example:** The following command displays the LSAs from an area (4):

```
get database area 4
```

**detail**

```
get database detail [...]
```

detail            Displays detailed information.

**Example:** The following command generates a detailed display of LSAs from an area (4):

```
get database detail area 4
```

**external**

```
get database [...] external [...]
```

external            Displays external LSAs.

**Example:** The following command displays external LSAs:

```
get database external
```

**link-state-id**

```
get database { ... } link-state-id ip_addr
```

link-state-id      Displays the LSA with a specified link-state ID (*ip\_addr*).

**Example:** The following command generates a detailed display of external LSAs with link-state ID *172.16.1.1*:

```
get database detail external link-state-id 172.16.1.1
```

**network**

```
get database [...] network [...]
```

network            Displays the network LSAs.

**Example:** The following command displays network LSAs:

```
get database network
```

**nssa-external**

```
get database [...] nssa-external [...]
```

nssa-external      Displays the not-so-stubby areas (NSSAs) external LSAs.

**Example:** The following command displays external LSAs for not-so-stubby areas:

```
get database nssa-external
```

**router**

```
get database [...] router [...]
```

router            Displays router LSAs.

**Example:** The following command displays router LSAs:

**get database router**

**self-originate**

get database [ ... ] self-originate [ ... ]

self-originate      Displays self-originated LSAs.

**Example:** The following command displays self-originated LSAs:

**get database self-originate**

**summary**

get database [ ... ] summary [ ... ]

summary            Displays summary LSAs.

**Example:** The following command displays summary LSAs:

**get database summary**

## **enable**

Use the enable commands to enable or disable OSPF from the current routing instance.

Before you can execute the **set enable** command, you must initiate the **ospf** context. (See “Context Initiation” on page 483.)

### **Syntax**

set enable

### **Keywords and Variables**

None.

## **hello-threshold**

Use the **hello-threshold** commands to set or display the hello threshold. When a neighbor device exceeds this threshold by flooding the virtual router with hello packets, the virtual router drops the extra packets. A hello packet is a broadcast message that announces the presence of a routing instance on the network.

Before you can execute the **hello-threshold** commands, you must initiate the **ospf** context. (See “Context Initiation” on page 483.)

### **Syntax**

**get**

get hello-threshold

**set**

set hello-threshold *number*

## Keywords and Variables

### Variable Parameter

set hello-threshold *number*

**number**            The maximum number of hello packets the virtual router accepts from a neighbor in the hello interval.

**Example:** The following command sets the maximum number of packets to allow in the hello interval to 1000:

```
device(trust-vr/ospf)-> set hello-threshold 1000
```

## interface

Use the **interface** command to display all OSPF interfaces on the virtual router.

Before you can execute the **interface** command, you must initiate the **ospf** context. (See “Context Initiation” on page 483.)

### Syntax

get interface

## Keywords and Variables

None.

## lsa-threshold

Use the **lsa-threshold** commands to set or display the Link State Advertisement (LSA) threshold. When a neighbor device exceeds this threshold by flooding the virtual router with LSA packets, the virtual router drops the extra packets.

Link State Advertisements (LSAs) enable OSPF routers to make device, network, and routing information available for the link state database.

Before you can execute the **lsa-threshold** commands, you must initiate the **ospf** context. (See “Context Initiation” on page 483.)

### Syntax

#### get

get lsa-threshold

#### set

set lsa-threshold *number1 number2*

## Keywords and Variables

### Variable Parameters

set lsa-threshold *number1 number2*

*number1*      The LSA time interval (in seconds).

*number2*      The maximum number of LSAs that the virtual router accepts within the time interval expressed by *number1*.

**Example:** The following command creates an OSPF LSA threshold:

```
set lsa-threshold 10 30
```

## *neighbor*

Use the **neighbor** command to display details about neighbor devices.

Before you can execute the **neighbor** command, you must initiate the **ospf** context. (See “Context Initiation” on page 483.)

### Syntax

```
get neighbor
```

### Keywords and Variables

None.

## *redistribute*

Use the **redistribute** commands to import known routes from a router running a different protocol than the current virtual routing instance.

The types of routers from which to import routes include:

- Routers with manually created routes (**static**)
- Routers running BGP (**bgp**)
- Routers that have at least one interface with an IP address assigned to it (**connected**)
- Routers with routes that have already been imported (**imported**)
- Routers running RIP (**rip**)

Before you can execute the **redistribute** commands, you must initiate the **ospf** context. (See “Context Initiation” on page 483.)

### Syntax

*get*

```
get routes-redistribute [summary]
get rules-redistribute
```

**set**

```
set redistribute route-map string protocol
 { bgp | connected | discovered | imported | rip | static }
```

**Keywords and Variables****protocol**

```
set redistribute route-map string protocol { ... }
unset redistribute route-map name_str protocol { ... }
```

|          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|----------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| protocol | Specifies routing protocol. The route map can use the protocol type to determine whether to forward or deny an incoming packet. <ul style="list-style-type: none"> <li>■ <b>bgp</b> specifies that the route map performs an action only on BGP routes in the subnetwork.</li> <li>■ <b>connected</b> specifies that the route map performs an action only on routes sent from a router that has at least one interface with an IP address assigned to it.</li> <li>■ <b>discovered</b> specifies that the route map performs an action only on routes discovered by the device.</li> <li>■ <b>imported</b> specifies that the route map performs an action only on imported routes in the subnetwork.</li> <li>■ <b>rip</b> specifies that the route map performs an action only on RIP routes in the subnetwork.</li> <li>■ <b>static</b> specifies that the route map performs an action only on static routes in the subnetwork.</li> </ul> |
|----------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

**Example:** The following command redistributes a route that originated on a router that has at least one interface with an IP address assigned to it:

```
device(trust-vr/ospf)-> set redistribute route-map map1 protocol connected
```

**route-map**

```
set redistribute route-map string protocol { ... }
unset redistribute route-map string protocol { ... }
```

|           |                                                                                          |
|-----------|------------------------------------------------------------------------------------------|
| route-map | Identifies the route map that indicates the path for which the route should be imported. |
|-----------|------------------------------------------------------------------------------------------|

**Example:** The following command redistributes a route that originated from a BGP routing domain into the current OSPF routing domain:

```
device(trust-vr/ospf)-> set redistribute route-map map1 protocol bgp
```

**reject-default-route**

Use the **reject-default-route** commands to reject or restore the default route learned from OSPF (0.0.0.0/0).

Every router has a default route entry in its routing table. This default route matches every destination. (Any entry with a more specific prefix overrides the default route entry.)

Before you can execute the **reject-default-route** commands, you must initiate the **ospf** context. (See “Context Initiation” on page 483.)

## Syntax

### *get*

get reject-default-route

### *set*

set reject-default-route

## Keywords and Variables

None.

## *retransmit*

Use the **retransmit** command to set the number of packets to resend before adjacency ends.

Before you can execute the **retransmit** command, you must initiate the **ospf** context. (See “Context Initiation” on page 483.)

## Syntax

set retransmit { dc *number* | non-dc *number* }

## Keywords and Variables

### *Variable Parameters*

set retransmit dc *number*

*number*                Sets the number of packets to resend before adjacency ends. The retransmit range is between 2 and 240 packets.

**Example:** The following command shows setting a demand circuit to resend 10 packets prior to the end of the adjacency:

```
device(trust-vr/ospf)-> set retransmit dc 10
```

### *dc*

set retransmit dc *number*  
unset retransmit dc

dc                      Indicates that the type of connection is a demand circuit.

### *non-dc*

set retransmit non-dc *number*  
unset retransmit non-dc

non-dc                 Indicates that the type of connection is not a demand circuit.

## *rfc-1583*

Use the **rfc-1583** commands to use routing table calculation methods consistent with standards specified in RFC 1583.

Before you can execute the **rfc-1583** commands, you must initiate the **ospf** context. (See “Context Initiation” on page 483.)

### Syntax

#### *get*

get rfc-1583

#### *set*

set rfc-1583

### Keywords and Variables

None.

## *routes- redistribute*

Use the **routes- redistribute** command to display details about routes imported from a protocol other than OSPF.

Before you can execute the **routes- redistribute** command, you must initiate the **ospf** context. (See “Context Initiation” on page 483.)

### Syntax

get routes- redistribute [ summary ]

### Keywords and Variables

#### *summary*

get routes- redistribute [ summary ]

summary                      Shows the number of redistributed routes.

## *rules- redistribute*

Use the **rules- redistribute** command to display conditions set for routes imported from a protocol other than OSPF.

Before you can execute the **rules- redistribute** command, you must initiate the **ospf** context. (See “Context Initiation” on page 483.)

### Syntax

get rules- redistribute

### Keywords and Variables

None.

## **statistics**

Use the **statistics** command to display information about the following objects associated with an OSPF virtual routing instance:

- Hello Packets
- Link State Requests
- Link State Acknowledgments
- Link State Updates
- Database Descriptions
- Areas Created
- Shorted Path First Runs
- Packets Dropped
- Errors Received
- Bad Link State Requests

Before you can execute the **statistics** command, you must initiate the **ospf** context. (See “Context Initiation” on page 483.)

### **Syntax**

get statistics

### **Keywords and Variables**

None.

## **stub**

Use the **stub** command to display details about a stub area created for the current OSPF virtual routing instance.

Before you can execute the **stub** command, you must initiate the **ospf** context. (See “Context Initiation” on page 483.)

### **Syntax**

get stub [ *ip\_addr* ]

### **Keywords and Variables**

#### **Variable Parameters**

get stub *ip\_addr*

*ip\_addr*                      Identifies the stub area.

**Example:** The following command displays details about a stub area created on the current OSPF virtual routing instance:

```
device(trust-vr/ospf)-> get stub 192.168.20.20
```

## summary-import

Use the **summary-import** commands to summarize a route redistribution.

After importing a series of routes to the current OSPF routing instance from a router running a different protocol, you can bundle the routes into one generalized (or *summarized*) address that uses the same network stem of the prefix address. By summarizing multiple addresses, you allow the OSPF routing instance to treat a series of routes as one route, thus simplifying the process.

Before you can execute the **summary-import** commands, you must initiate the **ospf** context. (See “Context Initiation” on page 483.)

### Syntax

#### get

```
get summary-import
```

#### set

```
set summary-import ip ip_addr/mask [tag { ip_addr | id_num }]
```

### Keywords and Variables

#### ip

```
set summary-import ip ip_addr/mask [...]
unset summary-import ip ip_addr/mask
```

*ip*                    The summarized prefix, consisting of an address (*ip\_addr*) and network mask (*mask*) encompassing all the imported routes.

#### tag

```
set summary-import ip ip_addr/mask tag { ip_addr | id_num }
```

*tag*                    A value that acts as an identifier for the summarized prefix. The virtual router uses this identifier when advertising a new external LSA.

**Example:** The following command summarizes a set of imported routes under one route (20):

```
device(trust-vr/ospf)-> set summary-import ip 2.1.1.0/24 tag 20
```

## vlink

Use the **vlink** commands to create a virtual link for the current routing instance.

A virtual link is a conveyance that allows two segments to connect when the backbone router bridging them cannot reach either segment.

Before you can execute the **vlink** command, you must initiate the **ospf** context. (See “Context Initiation” on page 483.)

## Syntax

### **get**

get vlink

### **set**

```
set vlink area-id { id_num1 | ip_addr } router-id { id_num2 | ip_addr }
 [
 authentication
 {
 active-md5-key-id id_num |
 md5 key_str [key-id id_num] |
 password pswd_str
 } |
 dead-interval number |
 hello-interval number |
 retransmit-interval number |
 transit-delay number
]
```

## Keywords and Variables

### **area-id**

```
set vlink area-id id_num1 { ... }
unset vlink area-id id_num1 { ... }
```

**area-id** Specifies the ID or IP address of the area through which the virtual link is connected.

### **authentication**

```
set vlink { ... } authentication { active-md5-key-id | md5 key_str [key-id id_num] |
 password pswd_str }
unset vlink { ... } authentication [active-md5-key-id | md5 [key-id id_num]]
```

**authentication** Specifies the authentication method, including MD5 key string, the key identifier number (the default is 0), and password. You can specify more than one MD5 key with different key identifier numbers (between 0-255). If there are multiple MD5 keys configured, you can use the **active-md5-key-id** option to select the key identifier of the key to be used for authentication.

### **dead-interval**

```
set vlink { ... } dead-interval number
unset vlink { ... } dead-interval number
```

**dead-interval** Specifies the maximum amount of time that the security device waits, after it stops receiving packets from the neighbor, before classifying the neighbor as offline.

**hello-interval**

```
set vlink { ... } hello-interval number
unset vlink { ... } hello-interval number
```

hello-interval      Specifies the amount of time in seconds that elapse between instances of the interface sending Hello packets to the network announcing the presence of the interface.

**retransmit-interval**

```
set vlink { ... } retransmit-interval number
unset vlink { ... } retransmit-interval number
```

retransmit-interval      Specifies the amount of time (in seconds) that elapses before the interface resends a packet to a neighbor that did not acknowledge a previous transmission attempt for the same packet.

**router-id**

```
set vlink area-id id_num1 router-id id_num2
unset vlink area-id id_num1 router-id id_num2
```

router-id              Specifies the ID or IP address of the router at the other end of the virtual link.

**Example:** The following command creates a virtual link using an area of 0.0.0.1 for router with an ID of 10.10.10.20:

```
device(trust-vr/ospf)-> set vlink area-id 0.0.0.1 router-id 10.10.10.20
```

**transit-delay**

```
set vlink { ... } transit-delay number
unset vlink { ... } transit-delay number
```

transit-delay          Specifies the amount of time (in seconds) that elapses before the security device advertises a packet received on the interface.

**vneighbor**

Use the **vneighbor** command to display information about a neighbor on the virtual link.

Before you can execute the **vneighbor** command, you must initiate the **ospf** context. (See “Context Initiation” on page 483.)

**Syntax**

```
get vneighbor
```

**Keywords and Parameters**

None.



# override

Use the **override** commands to override the following vsys parameters (which are defined using the **vsys-profile** commands):

- CPU weight
- Sessions (maximum and reserved values and alarm threshold)

The override commands are only available after you enter a vsys. By default, no override values exist.

## Syntax

---

### **get**

```
get override [cpu-weight | session-limit]
```

### **set**

```
set override
{
 cpu-weight number |
 session-limit { alarm number | max number | reserve number }
}
```

## Keywords and Variables

---

### **cpu-weight**

```
get override [cpu-weight]
set override cpu-weight number
unset override cpu-weight
```

|            |                                                                                                                                                                                                                                                                        |
|------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| cpu-weight | CPU weight for the vsys. After entering the vsys, you can set an override value for the CPU weight defined in the vsys profile.<br>Use the <b>unset override cpu-weight</b> command to remove the override. The CPU weight configured in the vsys profile is now used. |
|------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

**Example:** The following commands first enter the vsys named **hr** and then override the CPU weight to **30**.

```
device-> enter vsys hr
device(hr)-> set override cpu-weight 30
device(hr)->
```

## **session-limit**

```
get override [session-limit]
set override session-limit { alarm number | max number | reserve number }
unset override session-limit { alarm | max | reserve }
```

session-limit Specifies session-limit override for the vsys:

- **alarm**—Specifies the percentage of the session limit at which an alarm is triggered. The alarm value is from 1 through 100 percent.
- **max**—Maximum number of sessions for the vsys. The configured maximum session value cannot exceed the absolute maximum value for the security device.
- **reserve**—Number of reserved sessions for the vsys when the security device becomes oversubscribed. The reserved session value cannot exceed the maximum session value.

Use the **unset override session-limit** command to remove the override. The session-limit values configured in the vsys profile are now used.

**Example:** The following commands first enter the vsys named **hr** and then override the maximum number of sessions to **4000**.

```
device-> enter vsys hr
device(hr)-> set override session-limit max 4000
device(hr)->
```

# password-policy

Use the **password-policy** command to enforce a minimum length and complexity requirement for administrator and authenticated user passwords.

## Syntax

---

### **get**

```
get password-policy
```

### **set**

```
set password-policy user-type
 {
 admin { complexity-scheme scheme_id | minimum-length number } |
 auth { complexity-scheme scheme_id | minimum-length number }
 }
```

## Arguments

---

### **complexity-scheme**

```
set password-policy user-type admin complexity-scheme scheme_id
```

complexity-scheme

Specify one of the following:

- 0 (zero)—No complexity scheme required. Passwords can contain any combination of alphanumeric characters and are constrained only by `minimum-length`, if set.
- 1—Passwords must contain at least two of the following:
  - Uppercase letters
  - Lowercase letters
  - Numbers
  - Nonalphanumeric characters (!@#\$%^&\*())

A password using the complexity scheme, for example, might be the following: `ABcd12&%`.

***minimum-length***

```
set password-policy user type auth minimum-length number
unset password-policy user type auth minimum-length
```

**minimum-length** Specify a minimum length for passwords. The range is 1 to 32, the default is 1.

***password-policy***

```
get password-policy
set password-policy { ... }
unset password-policy { ... }
```

**password-policy** A password policy provides centralized password policy enforcement in network environments where a mechanism such as RADIUS authentication is not available or not practical.

To view the current password-policy for admin or auth users, enter the **get password-policy** command.

To return the security device to the default password settings, use the keyword **unset**.

***user-type***

```
set password-policy user-type admin { ... }
unset password-policy user-type admin { ... }
set password-policy user-type auth { ... }
unset password-policy user-type auth { ... }
```

**admin | auth** Specifies whether the password policy applies to a system administrator, or authenticated user.

# pattern-update

Specifies the address of the proxy server from which the security device updates the AV/DI pattern files if access through a proxy server is enabled.

## Syntax

---

### **set**

```
set pattern-update proxy { http | ssl } <host> <port>
```

### **get**

```
get pattern-update proxy
```

## Keywords and Variables

---

### **proxy**

```
set pattern-update proxy { http | ssl } <host> <port>
unset pattern-update proxy { http | ssl }
```

proxy            The **set pattern-update proxy {...}** command sets the HTTP/SSL proxy. Use the **unset** command to remove the proxy configuration.

- **http**—Sets the proxy server as HTTP.
- **ssl**—Sets the proxy server as SSL.
- **host**—Specifies the proxy server IP address.
- **port**—Specifies the proxy server port number.



# pbr

Use the **pbr** commands to configure the security device for policy based routing (PBR). **get** commands allow you to view PBR settings, **set** commands allow you to configure PBR, and **unset** commands allow you to delete or undo a PBR configuration.

See the following keywords for other PBR-related syntax and keywords:

- “access-list” on page 17
- “action-group” on page 19
- “match-group” on page 429
- “policy” on page 539

## Syntax

---

### **get**

```
get pbr
{
 access-list [ext_acl_id | configuration] |
 action-group [name action_group_name | configuration] |
 configuration |
 match-group [name match_group_name | configuration] |
 policy [name policy_name | configuration]
}
```

### **set**

```
set pbr policy
{
 name pbr_policy_name |
 policy pbr_policy_name [match match_group_name] action action_group_name
 entry_id
}
```

## Keywords and Variables

---

### ***access-list***

```
get pbr access-list [ext_acl_id | configuration]
```

**access-list** Shows access-list information. Two keywords allow you to limit or retrieve more information:

- ***ext\_acl\_id*** shows information limited to the specified extended access-list.
- **configuration** shows the complete extended access-list configuration in the virtual router.

To configure an extended access-list, see the *Concepts & Examples ScreenOS Reference Guide*.

### ***action-group***

```
get pbr action-group [name action_group_name | configuration]
```

**action-group** Shows action group information. Two keywords allow you to limit or retrieve more information:

- **name *action\_group\_name*** shows information limited to the named action group.
- **configuration** shows the complete action group configuration in the virtual router.

To configure an action group, see the *Concepts & Examples ScreenOS Reference Guide*.

### ***configuration***

```
get pbr configuration
```

**configuration** Shows the complete PBR configuration within a virtual router.

### ***match-group***

```
get pbr match-group [name match_group_name | configuration]
```

**match-group** Shows match group information. Two keywords allow you to limit or retrieve more information:

- **name *match\_group\_name*** shows information limited to the specified match group.
- **configuration** shows the complete match group configuration in the virtual router.

To configure a match group, see the *Concepts & Examples ScreenOS Reference Guide*.

## ***policy***

```
get pbr policy [name policy_name | configuration]
set pbr policy name pbr_policy_name
set pbr policy pbr_policy_name [match match_group_name] action action_group_name
 entry_id
```

**policy** Shows access-list information. Two keywords allow you to limit or retrieve more information:

- **name *policy\_name*** shows information limited to the specified policy based routing (PBR) policy.
- **configuration** shows all of the PBR policies in the virtual router.

A PBR policy name can be an alphanumeric string of up to 128 characters in length.



# performance

Use the **performance** commands to retrieve performance information for a security device.

You can display information for CPU usage or session ramp-up rate.

## Syntax

---

```
get performance
{
 cpu [detail] |
 cpu-limit [detail [vsys { vsys | all }]] |
 session [detail]
}
```

## Keywords and Variables

---

### *cpu*

```
get performance cpu [detail]
```

**cpu** Displays the current CPU utilization rate for the last minute, the last 5 minutes, and the last fifteen minutes.

- **detail** displays the CPU utilization for the last 60 seconds, the last 60 minutes, and the last 24 hours.

### *cpu-limit*

```
get performance cpu-limit [detail [vsys { name | all }]]
```

**cpu-limit** If the CPU limit feature is enabled, displays the CPU weights and configured CPU quota percentage for all virtual systems. Also displays percentage of CPU quota used for the last minute, the last 5 minutes, and the last fifteen minutes.

- **all** displays detailed CPU limit performance information for all virtual systems.
- **detail** displays CPU limit performance information for the last 60 seconds, the last 60 minutes, and the last 24 hours.
- **vsys** displays detailed CPU limit performance information for the specified vsys.

## *session*

get performance session [ detail ]

**session** Displays the number of sessions added (ramp-up rate) for the last minute, the last 5 minutes, and the last fifteen minutes. It does not display the total number of sessions or the number of deleted sessions.

- **detail** displays session ramp-up rate for the last 60 seconds, the last 60 minutes, and the last 24 hours.

# PIM Commands

Use the **pim** context to begin configuring either Protocol Independent Multicast-Sparse Mode (PIM-SM) or Protocol Independent Multicast-Source-Specific Mode (PIM-SSM) for a virtual router.

## Context Initiation

---

Initiating the **pim** context can take up to four steps.

1. Enter the vrouter context by executing the **set vrouter** command.

```
set vrouter vrouter
```

For example:

```
set vrouter trust-vr
```

2. Enter the **pim** context by executing the **set protocol pim** command.

```
device(trust-vr)-> set protocol pim
```

3. Enable PIM (it is disabled by default).

```
device(trust-vr/pim)-> set enable
```

4. To exit each context, enter **exit**.

## PIM Command List

---

The following commands are executable in the **pim** context:

|              |                                                                                                                                                                                                  |
|--------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| accept-group | Use the <b>accept-group</b> command to specify the access list that identifies the multicast group(s) for which the virtual router processes PIM messages.<br>Command options: <b>set, unset</b> |
| bsr          | Use the <b>bsr</b> command to display information about the bootstrap router.<br>Command options: <b>get</b>                                                                                     |
| config       | Use the <b>config</b> command to display all commands executed to configure the PIM routing instance.<br>Command options: <b>get</b>                                                             |

|               |                                                                                                                                                                                                                                         |
|---------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| enable        | Use the <b>enable</b> command to enable or disable the PIM-SM instance on the virtual router.<br>Command options: <b>set, unset</b>                                                                                                     |
| igmp-members  | Use the <b>igmp-members</b> command to display IGMP membership reports.<br>Command options: <b>get</b>                                                                                                                                  |
| interface     | Use the <b>interface</b> command to display all interfaces running PIM-SM.<br>Command options: <b>get</b>                                                                                                                               |
| join-prune    | Use the <b>join-prune</b> command to display join-prune messages sent to each neighbor.<br>Command options: <b>get</b>                                                                                                                  |
| mgroup        | Use the <b>mgroup</b> command to specify from which source(s) and/or RP the multicast group accepts traffic.<br>Command options: <b>set, unset</b>                                                                                      |
| mroute        | Use the <b>mroute</b> commands to display PIM multicast route table entries.<br>Command options: <b>get</b>                                                                                                                             |
| neighbor      | Use the <b>neighbor</b> command to display information about all neighbors discovered for each interface.<br>Command options: <b>get</b>                                                                                                |
| rp            | Use the <b>rp</b> command to display the status of the RP (rendezvous point).<br>Command options: <b>get</b>                                                                                                                            |
| rpf           | Use the <b>rpf</b> command to display RPF information for a particular source or RP.<br>Command options: <b>get</b>                                                                                                                     |
| spt-threshold | Use the <b>spt-threshold</b> command to specify the data rate in bytes per second that triggers the device to switch from the shared distribution tree to the source-specific distribution tree.<br>Command options: <b>set, unset</b>  |
| statistics    | Use the <b>statistics</b> command to display PIM statics for the virtual router.<br>Command options: <b>get</b>                                                                                                                         |
| zone          | Configures the following: <ul style="list-style-type: none"> <li>■ an RP candidate in the specified zone</li> <li>■ a static RP for the specified multicast groups in the named zone</li> </ul> Command options: <b>get, set, unset</b> |

### ***accept-group***

Use the **accept-group** command to specify the access list that identifies the multicast group(s) for which the virtual router processes PIM messages.

Before you can execute the **accept-group** command, you must initiate the **pim** context. (See “Context Initiation” on page 515.)

### **Syntax**

set accept-group *number*

## Keywords and Variables

### Variable Parameter

set accept-group *number*

*number* Specifies the access list that identifies the multicast group(s) for which the virtual router accepts PIM messages.

## *bsr*

Use the **bsr** command to display information about the elected bootstrap router.

Before you can execute the **bsr** command, you must initiate the **pim** context. (See “Context Initiation” on page 515.)

### Syntax

get bsr

## Keywords and Variables

None.

## *config*

Use the **config** command to display all commands executed to configure the PIM routing instance.

Before you can execute the **config** command, you must initiate the **pim** context. (See “Context Initiation” on page 515.)

### Syntax

get config

## Keywords and Variables

None.

## *enable*

Use the **enable** command to enable or disable the PIM-SM instance on the virtual router.

Before you can execute the **enable** command, you must initiate the **pim** context. (See “Context Initiation” on page 515.)

### Syntax

set enable

## Keywords and Variables

None.

### *igmp-members*

Use the **igmp-members** command to display local membership information sent by IGMP.

Before you can execute the **igmp-members** command, you must initiate the **pim** context. (See “Context Initiation” on page 515.)

#### **Syntax**

```
get igmp-members
```

#### **Keywords and Variables**

None.

### *interface*

Use the **interface** command to display all interfaces running PIM-SM.

Before you can execute the **interface** command, you must initiate the **pim** context. (See “Context Initiation” on page 515.)

#### **Syntax**

```
get interface
```

#### **Keywords and Variables**

None.

### *join-prune*

Use the **join-prune** command to display join-prune messages sent to each neighbor.

Before you can execute the **join-prune** command, you must initiate the **pim** context. (See “Context Initiation” on page 515.)

#### **Syntax**

```
get join-prune
```

#### **Keywords and Variables**

None.

## **mgroup**

Use the **mgroup** command to specify from which source(s) and/or RP the multicast group accepts traffic.

Before you can execute the **mgroup** command, you must initiate the **pim** context. (See “Context Initiation” on page 515.)

### **Syntax**

```
set mgroup mcst_addr { accept-rp number | accept-source number }
```

### **Keywords and Variables**

#### **Variable Parameter**

```
set mgroup mcst_addr
```

*ip\_addr* Specifies the IP address of the multicast group.

#### **accept-rp**

```
set mgroup mcst_addr accept-rp number
unset mgroup mcst_addr accept-rp
```

**accept-rp** Specifies the access list that identifies the RP(s) from which the device forwards traffic to the multicast group. The device drops traffic for the multicast group if the traffic is from an RP that is not on the specified access list.

#### **accept-source**

```
set mgroup mcst_addr accept-source number
unset mgroup mcst_addr accept-source
```

**accept-source** Specifies the access list that identifies the source(s) from which the device forwards traffic to the multicast group. The device drops traffic for the multicast group if the traffic is from a source that is not on the specified access list.

## **mroute**

Use the **mroute** command to display PIM route-table entries.

Before you can execute the **mroute** command, you must initiate the **pim** context. (See “Context Initiation” on page 515.)

### **Syntax**

```
get mroute
 [
 brief |
 mgroup mcst_addr [detail | brief] [source ip_addr [detail | brief]]
]
```

### **Keywords and Variables**

#### **brief**

```
get mroute brief
get mroute mgroup mcst_addr brief
get mroute mgroup mcst_addr source ip_addr brief
```

**brief** Displays summary information about the multicast routes. Displays the source address, multicast group address, and the list of incoming and outgoing interfaces.

#### **detail**

```
get mroute mgroup mcst_addr detail
get mroute mgroup mcst_addr source ip_addr detail
```

**detail** Displays information about the multicast route, including the RPF and type of route. It also provides details on the input and output interfaces.

#### **mgroup**

```
get mroute mgroup mcst_addr brief
get mroute mgroup mcst_addr detail
get mroute mgroup mcst_addr source ip_addr [brief | detail]
```

**mgroup** Displays multicast route table entries for the specified multicast group or defines a multicast route for a particular multicast group.

#### **source**

```
get mroute mgroup ip_addr source ip_addr
```

**source** Specifies the IP address of the source of the multicast traffic.

## **neighbor**

Use the **neighbor** command to display information about all neighbors discovered for each interface.

Before you can execute the **neighbor** command, you must initiate the **pim** context. (See “Context Initiation” on page 515.)

### **Syntax**

```
get neighbor
```

### **Keywords and Variables**

None.

## **rp**

Use the **rp** command to display the status of the RP (rendezvous point).

Before you can execute the **rp** command, you must initiate the **pim** context. (See “Context Initiation” on page 515.)

### **Syntax**

```
get rp
 [
 active |
 all |
 candidate |
 mgroup ip_addr [active] |
 proxy
]
```

### **Keywords and Variables**

#### **active**

```
get rp active
```

**active**                    Displays the RP that is actively sending multicast traffic to the multicast groups.

#### **all**

```
get rp all
```

**all**                        Displays information about all candidate and static RPs. It displays the (\*, G) and (S, G) mappings for each RP.

#### **candidate**

```
get rp candidate
```

**candidate**                Displays the status of the RP candidates that you configured for each zone on the virtual router.

**mgroup**

```
get rp mgroup ip_addr [active]
```

**mgroup** Displays information about the group-RP set for the specified multicast group. Specify **active** to display the RP for the specified multicast group.

**proxy**

```
get rp proxy
```

**proxy** Displays the proxy-RP status for each zone in the PIM instance of the virtual router.

**rpf**

Use the **rpf** command to display RPF (reverse path forwarding) information for a particular source or RP.

Before you can execute the **rpf** command, you must initiate the **pim** context. (See “Context Initiation” on page 515.)

**Syntax**

```
get rpf
```

**Keywords and Variables**

None.

**spt-threshold**

Use the **spt-threshold** command to specify the threshold that triggers the virtual router to switch from the shared distribution tree to the source-based tree.

Before you can execute the **spt-threshold** command, you must initiate the **pim** context. (See “Context Initiation” on page 515.)

**Syntax**

```
set spt-threshold { number | infinity }
```

**Keywords and Variables****Variable Parameter**

```
set spt-threshold number
```

**number** Specifies the data rate in bytes per second that triggers the device to switch from the shared distribution tree to the source-specific distribution tree. If you specify **infinity**, the device never switches to a source-specific distribution tree.

## zone

Use the **zone** command to configure the following for the specified zone:

- An RP candidate
- A static RP for the specified multicast groups in the named zone
- A proxy-RP

Before you can execute the **zone** command, you must initiate the **pim** context. (See “Context Initiation” on page 515.)

### Syntax

#### get

```
get zone
 [
 zone
 [
 bsr |
 rp { active | all | candidate | mgroup ip_addr [active] | proxy }
]
]
```

#### set

```
set zone zone rp
 {
 address ip_addr mgroup-list number [always] |
 candidate interface interface
 [mgroup-list number [holdtime number | priority number]] |
 proxy
 }
```

### Keywords and Variables

#### address

```
set zone zone rp address ip_addr mgroup-list number [always]
unset zone zone rp address ip_addr
```

|         |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|---------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| address | <p>Configures a static RP for the multicast groups specified in the access list. If no group is specified, then this RP is used for any multicast group that has no RP.</p> <ul style="list-style-type: none"> <li>■ <b>zone</b> <i>zone</i>—Specifies the zone of the RP.</li> <li>■ <b>address</b> <i>ip_addr</i>—Specifies the IP address of the RP. This IP address can also be the IP address an interfaces on the device.</li> <li>■ <b>mgroup-list</b> <i>number</i>—Specifies the access list that identifies the multicast group(s) mapped to the RP.</li> <li>■ <b>always</b>—Specifies that this RP should always be used for the specified multicast group even if there is a dynamic group-RP mapping for the same group.</li> </ul> |
|---------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

**bsr**

get zone *zone* bsr

bsr                      Displays information about the bootstrap router in the zone.

**candidate**

set zone *zone* rp candidate interface *interface*  
 set zone *zone* rp candidate interface *interface* mgroup-list *number* holdtime *number*  
 set zone *zone* rp candidate interface *interface* mgroup-list *number* priority *number*  
 unset zone *zone* rp candidate

candidate              Configures an RP candidate in the specified zone.

- **zone** *zone*—Specifies the zone of the RP.
- **interface** *interface*—Specifies the interface that is advertised as the RP candidate.
- **mgroup-list** *number*—Specifies the access list which identifies the multicast group(s) for which the interface is the RP candidate.
- **holdtime** *number*—Specifies the holdtime advertised to the bootstrap router.
- **priority** *number*—Specifies the priority of the interface as the RP candidate.

When you configure proxy RP, you must configure an RP candidate without a multicast group.

**proxy**

set zone *zone* rp proxy

proxy                    Enables proxy RP in the specified zone.

**rp**

get zone *zone* rp {...}

rp                        Displays information about the RP in the specified zone.

- **active**—Displays information about the RP that is sending multicast traffic to the multicast group in the specified zone.
- **all**—Displays all RPs, including candidate RPs, in the specified zone.
- **candidate**—Displays the configured RP in the zone.
- **mgroup** *ip\_addr*—Displays the RP for the specifies multicast group.
- **proxy**—Displays the proxy-RP for the specified zone.

# ping

Use the **ping** commands to check a network connection to another system.

---

**NOTE:** An extended ping (using the **from** option) pings a host on the untrusted network from any existing MIP or from the trusted interface IP address. The syntax for specifying a MIP is **mip** *ip\_addr* (see example in the **from** keyword description).

---

## Syntax

---

```
ping ip_addr
 [count number [size number [time-out number]]] [from interface] |
 [name-lookup [outgoing-interface]]
```

## Keywords and Variables

---

### Variable Parameters

```
ping ip_addr [...]
```

*ip\_addr* Pings the host at address (*ip\_addr*).

**Example:** The following command pings a host with IP address 172.16.11.2:

```
ping 172.16.11.2
```

### *count*

```
ping ip_addr count number [...]
```

*count* The ping count (*number*).

**from**

ping *ip\_addr* from *interface*

from                    The source interface (*interface*) for an extended ping. For more information, see "Interfaces" on page 771.  
 Defines the source IP to which the ping will reply. Because this destination is on the untrusted side, the source IP can only be the mapped IP address or an untrusted interface IP address.

**Example 1:** The following command pings a device at 10.100.2.11 with a ping count of 4 from the ethernet1 interface:

**ping 10.100.2.11 count 4 from ethernet1**

**Example 2:** The following command pings a host with IP address 192.168.11.2 and sends the results to IP address 10.1.1.3:

**ping 192.168.11.2 from mip 10.1.1.3**

**size**

ping *ip\_addr* count *number* size *number* [ ... ]

size                    The packet size (*number*) for each ping.

**time-out**

ping *ip\_addr* count *number* size *number* time-out *number*

time-out                The ping timeout in seconds (*number*).

**Example:** The following command pings a device at 10.100.2.11.

- Ping count of 4
- Packet size 1000
- Ping timeout of three seconds:

**ping 10.100.2.11 count 4 size 1000 time-out 3**

**name-lookup**

ping *ip\_addr* name-lookup [ *outgoing-interface* ]

name-lookup            Uses the ICMP name to do a name lookup instead of using an echo request.  
**outgoing-interface** automatically selects the outgoing interface to do the lookup.

# pki

Use the **pki** commands to manage public key infrastructure (PKI).

PKI refers to the hierarchical structure of trust required for public key cryptography. Using PKI, the security device verifies the trustworthiness of a certificate by tracking a path of certificate authorities (CAs) from the one issuing your local certificate back to a root authority of a CA domain.

The **pki** commands perform the following tasks:

- Manage PKI objects
- Create new RSA, DSA, or ECDSA key pairs and acquire a certificate
- Verify the certificate received from the communication peer
- Acquire certificate revocation lists (CRLs)
- Configure PKI-related operations, such as verification of certificate revocation

## Syntax

---

### **exec**

```
exec pki
{
 convert-cert |
 dsa | rsa | ecdsa
 new-key number [&] |
 x509
 {
 install-factory-certs name_str |
 pkcs10 |
 scep
 {
 cert id_num |
 key { id_num | last-key } |
 renew id_num |
 } |
 self-signed-cert key-pair id_num |
 tftp ip_addr { cert-name name_str | crl-name name_str }
 }
}
```

**get**

```

get pki
{
 authority { id_num | default }
 {
 cert-path |
 cert-status |
 scep
 } |
 ldap |
 pre-prime |
 src-interface |
 x509
 {
 cert { id_num | system } |
 cert-fqdn |
 cert-path |
 crl-refresh |
 dn |
 list { ca-cert | cert | crl | key-pair | local-cert | pending-cert } |
 pkcs10 |
 raw-cn |
 send-to
 }
}

```

**set (authority)**

```

set pki authority { id_num | default }
{
 cert-path { full | partial } |
 cert-status
 {
 crl
 {
 refresh { daily | default | monthly | weekly } |
 server-name { ip_addr | dom_name } |
 url url_str
 }
 oosp
 {
 cert-verify id id_num |
 not-verify-revoke |
 url url_str
 } |
 revocation-check { crl [best-effort] | oosp [best-effort] | none }
 }
 scep
 {
 authentication { failed | passed } |
 ca-cgi string |
 ca-id name_str |
 challenge pswd_str |
 current |
 mode { auto | manual } |
 polling-int number |
 ra-cgi string |
 renew-start number
 }
}

```

**set (ldap)**

```
set pki ldap
{
 crl-url url_str |
 server-name { name_str | ip_addr }
}
```

**set (pre-prime)**

```
set pki pre-prime number
```

**set (src-interface)**

```
set pki src-interface interface
```

**set (x509)**

```
set pki x509
{
 cert-fqdn string |
 default
 {
 cert-path { full | partial }
 crl-refresh { daily | default | monthly | weekly } |
 no-preload-ca |
 send-to string
 } |
 dn
 {
 country-name name_str |
 domain-component string |
 email string |
 ip ip_addr |
 local-name name_str |
 name name_str |
 org-name name_str |
 org-unit-name name_str |
 phone string |
 state-name name_str
 } |
 friendly-name string id_num |
 raw-cn enable |
 renew id_num
}
```

## Keywords and Variables

---

### **authentication**

```
set pki authority { ... } scep authentication { failed | passed } [id_num]
```

**authentication** Sets the result of the CA certificate authentication, **failed** or **passed**. The *id\_num* value identifies a pending certificate created during a SCEP operation.

**Example:** The following command sets the result of a CA certificate authentication to *passed*:

```
set pki authority default scep authentication passed
```

### **authority**

```
get pki authority { id_num | default } { ... }
set pki authority { id_num | default } { ... }
unset pki authority { id_num | default } { ... }
```

**authority** Defines how the security device uses the CA's authorization services. The *id\_num* parameter is the identification number of the CA certificate. The **default** switch directs the device to use the authority configuration (used when the CA certificate does not reside locally).

**Example:** The following command instructs the security device to check for certificate revocation daily:

```
set pki authority default cert-status crl refresh daily
```

### **cert-path**

```
get pki authority { id_num | default } cert-path
set pki authority { id_num | default } cert-path { full | partial }
unset pki authority id_num cert-path
```

**cert-path** Defines the X509 certificate path validation level. When the device verifies a certificate, it builds a certificate chain from certificates received from the peer and the certificate stored locally. Certificates loaded locally are considered "trusted."

- **full**—Directs the security device to validate the certificate chain to the root. (The last certificate in the certificate chain must be a self-signed CA certificate.)
- **partial**—Specifies partial path validation. (The last certificate in the certificate chain may be any locally stored certificate.)

In either case, the last certificate in the chain must come from local storage. You can set this certificate path validation level for a CA.

**Example:** The following command defines the certificate path validation level as *full*:

```
set pki authority default cert-path full
```

## cert-status

```
get pki authority { id_num | default } cert-status
set pki authority { id_num | default } cert-status { ... }
unset pki authority { id_num | default } cert-status { ... }
```

cert-status Defines how the security device verifies the revocation status of a certificate.

- **crl**—Configures certificate revocation list (CRL) parameters.
  - **refresh**—Determines how often (daily, monthly, or weekly) the security device updates the CRL before the CRL expires. The default option uses the validation date decided by the CRL.
  - **server-name** { *ip\_addr:port\_num* | **dom\_name** }—Specifies the server by IP address and port number, or by domain name.
  - **url** *url\_str*—Specifies the URL for accessing the CRL.
- **ocsp**—Configures Online Certificate Status Protocol (OCSP) parameters.
  - **cert-verify id number**—Identifies the certificate to use when verifying the OCSP response.
  - **not-verify-revoke**—Disables verification of revocation status on the OCSP signing certificate.
  - **url** *url\_str*—Specifies the URL for accessing the OCSP responder.
- **revocation-check**—Specifies how the security device checks certificates to see if they are currently revoked.
  - **crl**—Specifies that the device uses CRL to check certificate status.
  - **none**—Specifies that the device does not perform a check of certificate status.
  - **ocsp**—Specifies that the device uses OCSP to check certificate status.
  - **best-effort**—Specifies that the device can use a certificate for which there is no revocation information. This option is useful when CRL retrieval is not practical. For example, in some environments the CRL server is only accessible through a tunnel; however, the CRL information is necessary to build the tunnel originally. When you use the **best-effort** setting, it is advisable to check the event log periodically. The device should accept a certificate without revocation information only when no revocation information is available. Repeatedly failing to get revocation information for a certificate usually indicates improper configuration.

**Example:** The following command directs the security device to use the CRL to check certificate status:

```
set pki authority default cert-status revocation-check crl
```

### ***cert-verify id***

```
set pki authority id_num1 cert-status oosp cert-verify id id_num2
unset pki authority id_num cert-status oosp cert-verify
```

**cert-verify id** Identifies a locally stored certificate the security device uses to verify the signature on an OCSP responder.

- **id\_num1**—Identifies the CA certificate that issued the certificate being verified.
- **id\_num2**—Identifies the locally stored certificate the device uses to verify the signature on the OCSP response.

### ***convert-cert***

```
exec pki convert-cert
```

**convert-cert** For ScreenOS versions earlier than 3.0.0, moves a local vsys certificate, which has an assigned vsys identifier, from the root to a specific vsys environment.

### ***dsa new-key***

```
exec pki dsa new-key number [&]
```

**dsa new-key** Generates a new DSA public/private key pair with a specified bit length (*number*). Key length is 512, 786, 1024, or 2048.

The **&** option directs the device to perform key generation in the background, without waiting for the result. Without this option, the device can wait up to 100 seconds.

### ***ecdsa new-key***

```
exec pki ecdsa new-key name_str
```

**ecdsa new-key** Generates a new Elliptic Curve Digital Signature Algorithm (ECDSA) public/private key pair with the specified parameter *secp256r1*. The key length is 256 bits.

Example: The following command generates an ECDSA key pair for the parameter *secp256r1*:

```
exec pki ecdsa new-key secp256r1
```

### ***ldap***

```
get pki ldap
set pki ldap { ... }
unset pki ldap { ... }
```

**ldap** Specifies settings for the LDAP server, when the CA certificate associated with the server is not in the device.

- **crl-url** *url\_str*—Sets the default LDAP URL for retrieving the certificate revocation list (CRL).
- **server-name** { *name\_str* | *ip\_addr:port\_num* }—Defines the fully qualified domain name or IP address and port number of the server.

Example: The following command assigns 162.128.20.12 as the server's IP address:

```
set pki ldap server-name 162.128.20.12
```

## pre-prime

```
get pki pre-prime
set pki pre-prime number
unset pki pre-prime
```

**pre-prime**      The **get** command displays:

- The number of precalculated primes for every key-type and key-length combination. The key type can be DSA or RSA, and the key length can be 1024 or 2048 bits depending on the platform of the security device.

**Note:** Security appliances generate 1024-bit primes. Security systems generate 1024- and 2048-bit primes. For more information, see your product datasheet.

- The number of currently available pairs of prime numbers for every key type and key length combination.
- Ongoing prime calculation for a key type and key length combination and the number of attempts already made.

The **set** command instructs the security device to generate a specific number of precalculated primes to store in memory.

The **unset** command reverts the security device to the default number of precalculated primes. The default number of precalculated primes is platform specific. For more information, see your product datasheet.

## rsa new-key

```
exec pki rsa new-key number [&]
```

**rsa new-key**      Generates a new RSA public/private key pair with a specified bit length (*number*). Key length is 512, 768, 1024, or 2048.

The **&** option directs the device to perform key generation in the background, without waiting for the result. Without this option, the device can wait up to 100 seconds.

## scep

```
exec pki x509 scep { cert id_num | key { id_num | last-key } | renew }
get pki authority { id_num | default } scep
set pki authority { id_num | default } scep { ... }
unset pki authority { id_num | default } scep { ... }
```

**scep**              Defines Simple Certificate Enrollment Protocol (SCEP) parameters.

- **authentication { passed | failed } [ *id\_num* ]** sets the result of the CA authentication, failed or passed. The *id\_num* value identifies a defined key pair.
- **ca-cgi *url\_str***—Specifies the path to the CA's SCEP server.
- **ca-id *string***—Specifies the identity of the CA's SCEP server.

- **cert-id** *id\_num*—Directs the security device to retrieve the final certificate for a pending certification.
- **challenge** *pswd\_str*—Specifies the challenge password.
- **current**—Directs the security device to use the SCEP associated with a CA as the default.
- **key** *id\_num*—Directs the device to acquire a certificate for the specified key pair. The *id\_num* parameter specifies the ID of a specific key pair. The **last\_key** parameter specifies the most recently created key pair.
- **mode** { **auto** | **manual** }—Specifies the authentication mode to use to authenticate the certificate.
- **polling-int** *number*—Determines the retrieval polling interval (in minutes). The default value is 0 (none).
- **ra-cgi** *url\_str*—Specifies the CGI path to the RA's SCEP server.
- **renew** *id\_num*—Directs the device to renew the specified certificate (*id\_num*).
- **renew-start**—Sets the number of days before the certificate expiration date when you want the security device to request the renewal of the certificate.

**Example:** The following command sets the SCEP challenge password to *swordfish*:

```
set pki authority default scep challenge swordfish
```

**Example:** The following command uses the SCEP setting for CA 123 as the default:

```
set pki authority 123 scep current
```

## *self-signed-cert*

```
exec pki x509 self-signed-cert key-pair id_num
```

**self-signed-cert** Generates a self-signed certificate using the specified (previously generated) key pair. To learn the ID number for a key pair to use when generating the self-signed certificate, enter the following command: **get pki x509 list key-pair**. The output lists the ID number under the *ID num* heading (not the ID number under *IDX*).

**Example:** The following command generates a self-signed certificate using the key pair with ID number 70320131:

```
exec pki x509 self-signed-cert key-pair 70320131
```

## *send-to*

```
get pki x509 send-to
set pki x509 default send-to string
unset pki x509 default send-to
```

**send-to** Specifies or displays the email destination (*string*) to send the x509 certificate request file.

## src-interface

```
get pki src-interface
set pki src-interface
unset pki src-interface
```

src-interface      Displays, configures, or removes the source interface the security device uses to send PKI traffic.

## x509

```
exec pki x509 { ... }
get pki x509 { ... }
set pki x509 { ... }
unset pki x509 { ... }
```

x509                Specifies settings for x509 certificates, displays certificate information, and performs various operations related to x509 PKI object.

- **cert** { *id\_num* | **system** }—Displays information about the specified certificate. The keyword **system** refers to the self-signed certificate that the security device automatically generates during bootup.
- **cert-fqdn** *string*—Configures the fully qualified domain name (FQDN). PKI uses this value in the certificate subject alt name extension.
- **default**—Specifies settings for the CA whose certificate is not locally configured.
  - **crl-refresh**—Sets or displays the refreshment frequency (**daily**, **monthly**, or **weekly**) of the X.509 CRL. The default option uses the expiration date in each CRL.
  - **no-preload-ca**—Prevents automatic installation of CA certificate (currently a CA certificate from Verisign).
  - **send-to** *string*—Assigns the email address to which the security device sends the PKCS10 certificate request file.
- **dn**—Specifies or displays the name that uniquely identifies a requesting certificate.
  - **country-name** *name\_str*—Sets the country name.
  - **domain-component** *name\_str*—Sets the domain component value. Devices can use this value in certificates for IPsec login to VPN gateways. For example, the device could use this as a Group IKE ID, accepting ASN1\_DN type IKE identities containing "DC= Engineering, DC= NewYork".
  - **email** *string*—Sets the email address.
  - **ip** *ip\_addr*—Sets the IP address.
  - **local-name** *string*—Sets the locality.
  - **name** *string*—Sets the name in a common name field.
  - **org-name** *string*—Sets the organization name.
  - **org-unit-name** *string*—Sets the organization unit name.
  - **phone** *string*—Sets a contact phone number as the X.509 certificate subject name of the security device.
  - **state-name** *string*—Sets the state name as the X.509 certificate subject name.

- **friendly-name** *name\_str id\_num* A friendly name (*name\_str*) for the certificate (*id\_num*).
- **install-factory-certs** *name\_str* Loads a specified factory predefined certificate.
- **list**—Displays the X.509 object list.
  - **ca-cert**—Displays all CA certificates.
  - **cert**—Displays all X.509 certificates.
  - **key-pair**—Displays all key pairs for which there is no certificate.
  - **crl**—Displays all Certificate Revocation Lists (CRLs).
  - **local-cert**—Displays all local certificates.
  - **pending-cert**—Displays all pending certificates.
- **pkcs10**—Displays a PKCS10 file (an X.509 certificate request) for a key pair.
- **raw-cn enable**—Enables the raw common name (CN) or displays its current status.
- **scep**
  - **cert** *id\_num*—Initiates a Simple Certificate Enrollment Protocol (SCEP) operation to retrieve certificates from a certificate authority (CA) server. The *id\_num* parameter is the identification number of the pending certificate.
  - **key** { *id\_num* | **last-key** }—Initiates SCEP operation to obtain a certificate for a key pair. The variable *id\_num* identifies the key pair and **last-key** specifies to obtain a certificate for the most recently created key pair.
  - **renew** *id\_num*—Initiates SCEP operation to renew an existing certificate. The variable *id\_num* identifies the existing certificate to renew.
  - **tftp** *ip\_addr*—Uploads the specified certificate (**cert-name** *name\_str*) or CRL file (**crl-name** *name\_str*) for the specified TFTP server at IP address *ip\_addr*.

**Example 1:** The following command specifies the destination email address where the security device sends the PKCS10 certificate request:

```
set pki x509 default send-to caServer@somewhere.com
```

**Example 2:** The following command refreshes the certificate revocation list daily:

```
set pki x509 default crl-refresh daily
```

**Example 3:** The following command defines a distinguished name for *Ed Jones*, who works in marketing at Juniper Networks in Sunnyvale, California:

```
set pki x509 dn country-name US
set pki x509 dn state-name CA
set pki x509 dn local-name sunnyvale
set pki x509 dn org-name "juniper networks"
set pki x509 dn org-unit-name marketing
set pki x509 dn name "ed jones"
```

## Defaults

The RSA key length is set to *1024* bits.

## Requesting a CA Certificate

You use the **set pki**, **get pki**, and **exec pki** commands to request an x509 CA certificate from a certificate authority (CA). The following commands provide a typical example:

1. Specify a CA CGI path.

```
set pki auth default scep ca-cgi "http://pilotsiteipsec.verisign.com/cgi-bin/pkiclient.exe"
```

---

**NOTE:** The Common Gateway Interface (CGI) is a standard way for a Web server to pass a user request to an application program and to receive data back. CGI is part of the Hypertext Transfer Protocol (HTTP).

---

2. Specify a registration authority RA CGI path.

```
set pki auth default scep ra-cgi "http://pilotsiteipsec.verisign.com/cgi-bin/pkiclient.exe"
```

3. Generate an RSA key pair, specifying a key length of 1024 bits.

```
exec pki rsa new 1024
```

4. Initiate the SCEP operation to request a local certificate.

```
exec pki x509 scep key last-key
```

5. If this is the first attempt to apply for a certificate from this CA, a prompt appears presenting a fingerprint value for the certificate. (Otherwise, go on to step 6.)

After verification of the fingerprint, allow the operation to continue by executing the following command:

```
set pki auth default scep auth passed
```

You must specify an RA CGI path even if the RA does not exist. If the RA does not exist, use the value specified for the CA CGI.

6. If the device does not approve the certificate automatically, contact your CA administrator to approve the local certificate request.

7. (Optional) Display a list of pending certificates. This allows you to see and record the ID number identifying the pending certificate.

```
get pki x509 list pending-cert
```

8. (Optional) Obtain the local certificate from the CA (using the ID number obtained in step 7) to identify the certificate. In this example, the certificate number is 1001.

```
exec pki x509 scep cert 1001
```



# policy

Use the **policy** commands to define policies to control network and virtual private network (VPN) traffic.

A *policy* is a set of rules that determines how traffic passes between security zones (interzone policy), between interfaces bound to the same zone (intrazone policy), and between addresses in the Global zone (global policy). When a security device attempts to pass a packet from one zone to another, between two interfaces bound to the same zone, or between two addresses in the Global zone, the security device checks its policy lists for a policy to permit such traffic. For example, to allow traffic to pass from one security zone to another, you must configure a policy that permits zone A to send traffic to zone B. To allow traffic originating in zone B to flow to zone A, you must configure another policy permitting traffic from zone B to zone A.

Executing the **set policy id** *pol\_num* command without specifying further options places the CLI within the context of an existing policy. For example, the following commands define a policy with ID number **1** and then enter the **policy:1** context to add a second service:

```
device-> set policy id 1 from trust to untrust host1 host2 HTTP permit
device-> set policy id 1
device(policy:1)-> set service FTP
```

After you enter a policy context, all subsequent command executions modify the specified policy (policy:1 in this example). To save your changes, you must first exit the policy context, then enter the **save** command:

```
device(policy:1)-> exit
device-> save
```

You can also use the **set policy id** *pol\_num* command with additional options to modify an existing policy. For example, the following commands add a deep inspection(DI) extension to policy 1:

```
device-> set policy id 1 from trust to untrust host1 host2 HTTP permit
device-> set policy id 1 attack HIGH:HTTP:SIGS action close
```

---

**NOTE:** The above example adds a deep inspection (DI) extension that was not present in the original policy. After you enter a policy context, you cannot add a DI extension if one does not already exist in the original policy.

---

## Syntax

---

### **exec**

```
exec policy verify [from zone [to zone] | global | to zone]
```

### **get**

```
get policy
[
 disabled |
 [from zone1] |
 [to zone2] |
 [[src-ip ip_addr] | [src-address addr_name]] |
 [[dst-ip ip_addr] | [dst-address addr_name]] |
 [service svc_name] |
 [action { deny | permit | reject | tunnel | av | idp | uf }] |
 [id pol_num [sess-limit count [src-ip ip_addr]]] |
 [all] |
 [global [id pol_num [sess-limit count [src-ip ip_addr]]]]
]
```

### **get (Within a Policy Context)**

```
get configuration
```

### **set**

```
set policy
[global]
[id pol_num1]
[top | before pol_num2]
[name name_str]
[from zone1 to zone2]
src_addr dst_addr svc_name
[
 nat
 [src [dip-id id_num]]
 [dst ip addr1 [addr2 | port port_num]]
]
{
 deny |
 permit |
 reject |
 tunnel { l2tp tunn_str | vpn-group id_num } |
 tunnel vpn tunn_str [l2tp tunn_str | pair-policy pol_num]
}
[no-hw-sess]
[auth [server name_str] | webauth]
[sess-limit per-src-ip session-count [alarm-no-drop]
 [
 group-expression string |
 user name_str | user-group name_str
]
]|
[schedule name_str]
[log [alert]]
```

```

 [count [alarm id_num1 id_num2]]
 [no-session-backup]
 [url-filter]
 [traffic] [gbw number]
 [priority number]
 [mbw number] | pbw [number]
 dscp { disable | enable [value dscp-byte] }
 [
 [infranet-auth
 [redirect-all | redirect-unauthenticated { redirect-url string }]] |
 [webauth [redirect-unauthenticated]] |
 [attack string
 { action { close | close-client | close-server |
 drop | drop-packet | ignore | none } |
 logging
 }
 [ip-action { block | close | notify }
 [target { dst-ip | serv | src-ip | zone |
 zone-serv }]
 [timeout value]
]
] |
 av name_str]
set policy move pol_num1 { before pol_num2 | after pol_num3 }
set policy default-permit-all

```

### set policy id number

```

set policy [global] id pol_num anti-spam name_str
set policy [global] id pol_num application svc_name
set policy [global] id pol_num attack string action string
set policy [global] id pol_num av name_str
set policy [global] id pol_num disable
set policy [global] id pol_num gtp name_str
set policy [global] id pol_num idp

```

### set (Within a Policy Context)

```

set
{
 attack string
 { action { close | close-client | close-server | drop | drop-packet | ignore
 | none } |
 logging
 }
 [ip-action { block | close | notify }
 [target { dst-ip | serv | src-ip | zone | zone-serv }]
 [timeout value]
] |
 av name_str |
 count [alarm number1 number2] |
 di-alert-disable |
 di-severity { info | low | medium | high | critical } |
 dst-address | src-address
 { name_str | negate } |
 idp
 log [alert | session-init] |
 name name_str |
 no-hw-sess |
 service svc_name |

```

```

src-address { name_str | negate }
url protocol sc-cpa profile { name_str | ns-profile }
sess-limit per-src-ip session-count [alarm-no-drop]
}

```

## Keywords and Variables

---

### **action**

```
get policy [action { deny | permit | reject | tunnel | av | idp | uf }]
```

**action** Displays information about security policies set to the specified action (**deny**, **permit**, **reject**, **tunnel**, **av**, **idp**, or **uf**).

### **all**

```
get policy [all]
```

**all** Displays information about all security policies, including global policies.

### **anti-spam**

```
set policy [global] id pol_num anti-spam name_str
unset policy [global] id pol_num anti-spam
```

**anti-spam** Applies an anti-spam profile to an existing policy.

### **application**

```
set policy [global] id pol_num application svc_name
```

**application** Defines the type of Layer 7 application associated with a Layer 3 service and Layer 4 port number. This is particularly important for defining the Layer 7 application for custom services so that the security device can properly inspect such traffic for attack signatures and anomalies.

The **ignore** option, which appears near the end of the list of application choices, instructs the security device to ignore the application type typically associated with a predefined service and port number. Using the **ignore** option instructs the security device not to scan the packet payload and can prevent the security device from attempting to parse one type of traffic when it is actually another type—such as the case with LDAP and H.323 traffic, both of which use TCP port 389.

The **none** option, which also appears near the end of the list of application choices, instructs the security device to use the default setting. Choosing **none** is equivalent to entering the **unset policy id *pol\_num* application** command.

**Example:** The following command identifies the Layer 7 application for policy ID **1** as **FTP**:

```
set policy id 1 application FTP
```

## attack

```

set policy { ... } attack string action { close | close-client | close-server | drop |
 drop-packet | ignore | none }
set policy { ... } attack string logging
set attack string
unset policy { pol_num | id pol_num } attack
unset attack string

```

**attack *string*** Inspects traffic to which the policy applies for attack objects in the specified attack object group. Attack objects can be stateful signatures or protocol anomalies. If the security device detects an attack object, it then performs one of the following specified actions:

- **action**

- **close**—Logs the event, severs the connection, and sends TCP RST packets to both the client and server.
- **close client**—Logs the event, severs the connection, and sends a TCP RST packet to the client.
- **close server**—Logs the event, severs the connection, and sends a TCP RST to the server.
- **drop**—Logs the event and severs the connection without sending either the client or the server TCP RST packets.
- **drop packet**—Logs the event and drops the packet containing the attack object, but it does not sever the connection.
- **ignore**—Logs the event and stops checking—or ignores—the remainder of the connection.
- **none**—Logs the event but takes no action.

**logging**—By default, the security device logs attacks that it detects through Deep Inspection. To disable logging, enter the policy context and use the **unset attack *string* logging** command.

**Example:** The following commands define a policy to check for attack objects in the CRITICAL:HTTP:ANOM, CRITICAL:HTTP:SIGS, HIGH:HTTP:ANOM, and HIGH:HTTP:SIGS attack object groups in HTTP traffic from any host in the Untrust zone to webserver1 in the DMZ zone. If the security device detects any attack objects, it then severs the connection and sends webserver1 a TCP RST to webserver1 server so it can clear its resources:

```

device-> set policy id 1 from untrust to dmz any webserver1 http permit attack
 CRITICAL:HTTP:ANOM action close-server
device-> set policy id 1
device(policy:1)-> set attack CRITICAL:HTTP:SIGS action close-server
device(policy:1)-> set attack HIGH:HTTP:ANOM action close-server
device(policy:1)-> set attack HIGH:HTTP:SIGS action close-server

```

## auth

```
set policy { ... } auth [...]
```

**auth** Requires the user to provide a login name and password to authenticate identity before accessing the device and crossing the firewall.

- **server *name\_str***—Identifies the authentication server (*name\_str*).
- **group-expression *string***—Identifies users according to an expression (*string*).

- **user** *name\_str*—Identifies a user (*name\_str*).
- **user-group** *name\_str*—Identifies a user group (*name\_str*).

**Example:** The following command invokes user authentication.

- Permits **any** kind of traffic from **any** address in the **Trust** zone to **any** address in the **Untrust** zone
- Uses an authentication server named **wc-server**

```
set policy from trust to untrust any any any permit auth server wc-server
```

## **av**

```
set policy { ... } av name_str
set av name_str
unset policy { pol_num | id pol_num } av name_str
unset av name_str
```

*av name\_str* Sends FTP, HTTP, POP3, or SMTP traffic to which the policy applies to the specified antivirus (AV) scanner (the internal AV scanner is called **scan-mgr**), which examines the data for viruses. If it finds a virus, the security device drops the data and sends a virus notification message to the client.

**Note:** The external antivirus feature was first supported in ScreenOS 5.4.0.

**Example:** The following command instructs the security device to forward **SMTP** traffic originating from the remote mail server **r-mail1** in the **Untrust** zone and destined for the local mail server **mail1** in the **DMZ** zone to the internal AV scanner **scan-mgr**:

```
set policy id 1 from untrust to dmz r-mail1 mail1 smtp permit av scan-mgr
```

## **before**

```
set policy before pol_num1 { ... }
```

*before* Specifies the position of the policy before another policy (*pol\_num*) in the access control list (ACL).

**Example:** The following command creates a new policy with ID number **3** and positions it before the policy with ID number **2**:

```
set policy id 3 before 2 from trust to untrust any any any permit
```

## **configuration**

```
get configuration
```

*configuration* Displays the configuration details for the policy in whose context you issue the **get configuration** command.

## **count**

```
set policy { ... } [count [alarm { id_num1 id_num2 }]] { ... }
```

**count** Maintains a count, in bytes, of all the network traffic the policy allows to pass through the security device.

The **alarm** *number1 number2* parameter enables the alarm feature so that you can view alarms. You must enter the number of bytes per second (*number1*) and the number of bytes per minute (*number2*) required to trigger an alarm.

**Example:** The following command permits **any** kind of traffic from **any** address in the **Trust** zone to **any** address in the **Untrust** zone and maintains a **count** of all network traffic to which the policy applies:

```
set policy from trust to untrust any any any permit count
```

### **default-permit-all**

```
set policy default-permit-all
```

**default-permit-all** Allows access without checking the access control list (ACL) for a matching policy.

### **deny | nat | permit | reject | tunnel**

```
set policy [global] { ... } | deny | nat | permit | reject | tunnel | [...]
```

**deny | nat | permit | reject | tunnel**

- **deny**—Blocks the service at the firewall. The security device simply drops the packet.
- **nat**—Enables Network Address Translation.
- **permit**—Allows the specified service to pass from the source address across the firewall to the destination address.
- **reject**—Blocks the service at the firewall. The security device drops the packet and sends a TCP reset (RST) segment to the source host for TCP traffic and an ICMP “destination unreachable, port unreachable” message (type 3, code 3) for UDP traffic. For types of traffic other than TCP and UDP, the security device drops the packet without notifying the source host, which is also what occurs when the action is **deny**.
- **tunnel**—Allows you to use VPN or IPsec tunnel.

**Example:** The following command:

- Defines a policy from the **Trust** zone to the **Untrust** zone
- Uses **any** source or destination IP address
- Permits **any** kind of service

```
set policy from trust to untrust any any any permit
```

### **disable**

```
set policy [global] id pol_num disable
get policy disabled
```

**disable** Disables a policy without removing it from the configuration. The **get** command displays all disabled policies.

**di-severity (Within a Policy Context)**

```
set di-severity { info | low | medium | high | critical }
```

**di-severity** Specifies the severity of events that generate error messages. The possible event levels are **info**, **low**, **medium**, **high**, and **critical**.

**dst-ip | dst-address**

```
get policy [to zone2] [[dst-ip ip_addr] | [dst-address addr_name]]
```

**dst-ip ip\_addr / dst-address addr\_name** Displays information about security policies that match an IP packet with the specified destination IP or policies that reference the specified destination address as their destination address directly or indirectly. You cannot use **dst-ip** and **dst-address** in the same command. When using **dst-address**, you must first specify **to zone2**.

- *ip\_addr* is the destination IP address.
- *addr\_name* is the name of the destination address.

**Example 1:** The following command displays policies that match an IP packet with a destination IP address of **172.16.10.100**:

```
get policy dst-ip 172.16.10.100
```

**Example 2:** The following commands create an address (**10.1.15/32**) named **addr2** in the **untrust** zone and display the policies that reference the destination address of **addr2**:

```
set address trust addr2 10.1.1.5/32
get policy to untrust dst-address addr2
```

**from | to (get)**

```
get policy [from zone1] | [to zone2]
```

**from zone1 | to zone2** Displays information about security policies applied between the two specified zones or about policies either from a zone that references the specified source address or to a zone that references the specified destination address.

- *zone1* is the name of the source security zone.
- *zone2* is the name of the destination security zone.

**from ... to (set)**

```
set policy { ... } from zone1 to zone2 src_addr dst_addr svc_name { ... } [...]
```

**from zone1 to zone2 src\_addr dst\_addr svc\_name** Specifies two zones between which a policy controls traffic.

- *zone1* is the name of the source security or function zone.
- *zone2* is the name of the destination security or function zone.

**Note:** For management traffic, you must specify *zone1* as **self**.

- *src\_addr* is the name of the source address. Specifying **any** allows all source IP addresses. You must specify *src\_addr* as **any** if *zone1* is a **Self** zone.

- *dst\_addr* is the name of the destination address. Specifying **any** allows all destination IP addresses. You must specify *dst\_addr* as **any** if zone2 is a **MGT** zone.
- *svc\_name* is the name of the service. Specifying **any** identifies all available services.

For more information, see “Zones” on page 773.

**Example:** The following command permits **HTTP** traffic from **any** address in the **Trust** zone to **any** address in the **Untrust** zone:

```
set policy from trust to untrust any any HTTP permit
```

## global

```
get policy [global [id pol_num [sess-limit count [src-ip ip_addr]]]]
set policy global before { ... }
set policy global id pol_num disable
set policy global move pol_num1 { before pol_num2 | after pol_num3 }
set policy global name name_str { ... }
set policy global top
```

**global** Creates policies or displays information about policies that use the Global zone. The Global zone address book keeps all the VIPs of all interfaces, regardless of the zone to which the interface belongs. You can use these VIP addresses as destination addresses in policies between any two security zones.

## gtp

```
set policy { pol_num | id pol_num } gtp name_str
unset policy { pol_num | id pol_num } gtp name_str
```

**gtp** Identifies the name of the GTP Inspection Object you are assigning to the policy. Before you can assign a GTP Inspection Object to a policy, you must first create the GTP configuration.

## id

```
get policy [id pol_num [sess-limit count [src-ip ip_addr]]]
set policy [global] id pol_num1 { ... }
unset policy id pol_num [disable]
```

**id pol\_num** Specifies a policy ID number or displays information about the policy with the specified ID number. (The **disable** switch disables the policy.)

**Example:** The following command assigns the policy an ID value of **10** and permits **FTP-GET** traffic from any address in the **Trust** zone to any address in the **Untrust** zone:

```
set policy id 10 from trust to untrust any any ftp-get permit
```

## idp

```
set idp [mode tap]
unset idp [mode]
```

**idp** Enables or disables IDP for the traffic to which the policy applies. By default, IDP is disabled for policies.

**mode**—Sets or unsets tap (passive) mode. By default, IDP is in active mode.

In active mode, the security device forwards packets to a security module for inspection. If the security device does not detect an attack, it forwards the packet to its destination. If it does detect an attack, the security device performs an IDP action, such as drop, close-server, close-client, and so on.

In tap mode, the security device copies packets, forwarding the original packet to its destination and forwarding the copy to a security module for inspection. If the security device detects an attack, it makes an event log entry but does not perform any IDP action.

**Example:** The following commands create a **policy**, enter the context of that policy, and then apply **IDP** in **tap** mode:

```
device-> set policy id 1 from trust to untrust any any any permit
device-> set policy id 1
device(policy:1)-> set idp mode tap
```

## *infranet-auth*

```
set policy { ... } from zone1 to zone2 src_addr dst_addr svc_name { ... } [infranet-auth
[redirect-all | redirect-unauthenticated { redirect-url string }]]
```

**infranet-auth** Configures an infranet-auth policy and connects to the Infranet Controller via HTTPS.

The default infranet-auth policy is for source IP-based enforcement. Before defining this policy, you must create address-book entries for the destination and source addresses.

There can be multiple infranet-auth policies. Infranet-auth policies work with both tunnel and firewall traffic. For user traffic that does not pass through a tunnel, the incoming interface binds to the src-zone.

The security device uses the IP address or domain name that you specified when you configured the Infranet Controller instance (see “infranet” on page 309) on the security device.

ScreenOS 5.4 and higher enables you to configure the captive portal feature, which allows you to automatically *redirect* users to the Infranet Controller or to a preconfigured URL (see “infranet” on page 309). (The default infranet-auth policy does not support redirection.)

The following two ways of redirection are supported:

- **redirect-all**—Redirects all cleartext traffic to the Infranet Controller or to the URL specified in the Redirect URL field.

Use this command if your deployment uses IPsec only.

After a user signs into the Infranet Controller or the specified URL, the Infranet Agent on the client establishes a tunnel between the user and the security device based on the key information received from the Infranet Controller. The security device then applies the VPN policy allowing the encrypted traffic to pass through.

**Note:** This option does not allow cleartext traffic to pass through the device protecting your network from IP spoofing.

- **redirect-unauthenticated**—Redirects cleartext traffic from unauthenticated users to the Infranet Controller or to the URL specified in the Redirect URL field.

Use this command if your deployment uses source IP only or a combination of source IP and IPsec.

After a user signs into the Infranet Controller or the specified URL, the security device allows the user's cleartext traffic to pass through in source IP deployments. For IPsec deployments, the Infranet Agent creates a tunnel between the user and the security device. The security device then applies the VPN policy allowing the encrypted traffic to pass through.

- **redirect-url *string***—Specifies the redirect URL (1 to 512 characters) to which you want the security policy to redirect HTTP traffic. If you do not specify a URL, the security device defaults to the currently connected Infranet Controller (the default redirect URL is not displayed).

Use the following format for the URL within double quotes:

**"http://IP or domain\_name/url\_path/?target= %dest-url%"**

The security device redirects HTTP traffic to an external Web server instead of to the Infranet Controller. For more information about using the URL string to redirect HTTP traffic, see the *Unified Access Control Administration Guide*.

For more information about deploying an infranet-authentication server, see the *Unified Access Control Administration Guide*.

**Example 1:** Configure a redirect infranet-auth policy for deployments that use source IP only or a combination of source IP and IPsec.

```
set policy from source-zone to dest-zone src_addr dst_addr any permit infranet-auth
 redirect-unauthenticated
set infranet controller name controller1 url "http://10.64.12.1/?target=%dest-url%"
```

---

**NOTE:** In examples 1 and 2, the security device replaces the **?target=%dest-url%** parameter with the protected resource URL and then forwards the protected resource URL in encrypted form to the Infranet Controller.

---

**Example 2:** Configure a redirect infranet-auth policy for deployments that use IPsec only.

```
set policy from source-zone to dest-zone src_addr dst_addr any permit infranet-auth
 redirect-all
set infranet controller name controller1 url "http://10.64.12.1/?target=%dest-url%"
```

**Example 3:** Configure an infranet-auth policy without redirection.

```
set policy from source-zone to dest-zone src_addr dst_addr any permit infranet-auth
```

## ip-action

```
set policy { ... } permit attack string action string ip-action string [target string [timeout
 value]]
```

- ip-action *string*** Activates additional brute-force attack defenses to Deep Inspection (DI) detection. A brute-force attack occurs when an attacker barrages a target with every possible combination of attacks until one succeeds. Attackers might use brute-force attacks when attempting to log in, discover protected resources, or break encryption keys. If the security device detects a brute-force attack, it applies the specified IP action for a certain period to other packets with a set of elements that match a defined target.
- **ip-action**—Specifies one of the following actions that the security device performs when it detects a brute-force attack:
    - **block**—The security device logs the event and drops all further traffic matching the target definition for the period specified in the timeout setting.
    - **close**—The security device logs the event and drops all further traffic matching the target definition for the period specified in the timeout setting, then sends a Reset (RST) for TCP traffic to the source and destination addresses.
    - **notify**—The security device logs the event but does not take any action against further traffic matching the target definition for the period specified in the timeout setting.
  - **target**—Specifies a set of elements that must match for the security device to consider a packet to be part of a brute-force attack. The specified set of elements in an IP packet arriving during a specified timeout period must match that in the packet that the security device detected as part of a brute-force attack in order for the subsequent packet to be considered part of the same attack. The default is **serv**.
    - **dst-ip**—The destination IP address.
    - **serv**—The source and destination IP addresses, destination port number, and protocol.
    - **src-ip**—The source IP address.
    - **zone**—The security zone to which the ingress interface is bound; that is, the source security zone from which the attacking packets originate.
    - **zone-serv**—The source security zone, source and destination IP addresses, destination port number, and protocol.
  - **timeout**—A period following brute-force attack detection during which the security device performs an IP action on packets matching specified target parameters. The default is 60 seconds.

**Example:** The following command applies Deep Inspection to HTTP traffic from any host in the Untrust zone to an HTTP server (“hpp1”) in the DMZ. It searches for attacks in the attack group “HIGH:HTTP:ANOM”, which contains two brute force attack objects. If the security device detects any attack included in that group, it drops the traffic and sends a TCP RST to the Web server. If the security device detects either of the two brute force attacks, it also drops further HTTP traffic (using TCP to port 80) to that server from any host in the Untrust zone for the next 30 seconds:

```
set policy from untrust to dmz any http1 http permit attack HIGH:HTTP:ANOM action
close ip-action close target zone-serv timeout 30
```

## ***l2tp***

```
set policy [global] { ... } tunnel l2tp tunn_str { ... }
set policy [global] { ... } tunnel vpn tunn_str l2tp tunn_str
```

`l2tp` Specifies a Layer 2 Tunneling Protocol (L2TP) tunnel.

**Example:** The following command defines an inbound policy for an L2TP tunnel.

- VPN tunnel named **home2office**
- L2TP tunnel named **home-office**
- Dialup VPN group named **home\_office**

```
set policy from untrust to trust dialup_vpn our_side any tunnel vpn home2office l2tp
home_office
```

## log

```
set policy [global] { ... } log [alert] [session-init] { ... }
```

`log` Enables logging when a session ends.

`alert` Enables the syslog alert feature.

`session-init` Enables logging when a session starts.

**Example:** The following command creates a policy and directs the security device to log the traffic to which the policy applies.

- Permits HTTP traffic from **any** address in the **Trust** zone to **any** address in the **Untrust** zone
- Directs the security device to log the traffic to which the policy applies. The security device generates logs when sessions end.
- Enables the syslog alert feature

```
set policy from trust to untrust any any HTTP permit log alert
```

## move

```
set policy [global] move pol_num1 { before pol_num2 | after pol_num3 }
```

`move` Repositions a policy (*pol\_num1*) before another policy (*pol\_num2*) or after a policy (*pol\_num3*) in the access control list (ACL). When one policy comes before another policy in the ACL, it has higher precedence.

**Example:** The following command positions a global policy with ID number **4** before the policy with ID number **2**:

```
set policy global move 4 before 2
```

## name

```
set policy [global] [...] name name_str { ... }
```

`name name_str` Identifies the policy by name. (Assigning a name to an policy is optional.)

**Example:** The following command creates a new policy named **outbound**:

```
set policy name outbound from trust to untrust any any permit
```

## nat

```
set policy [global] { ... } nat src [dip-id id_num] { ... }
set policy [global] { ... } nat dst ip addr1 [addr2 | port port_num] { ... }
```

|     |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|-----|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| nat | <p>Enables or disables source and destination Network Address Translation (NAT-src and NAT-dst). This feature translates the original source or destination IP address in an IP packet header to another address.</p> <ul style="list-style-type: none"> <li>■ <b>src</b>—Performs NAT-src on traffic to which the policy applies. The security device can perform NAT-src using the egress interface IP address (in which case, you do not specify a DIP pool) or with addresses from a dynamic IP (DIP) pool: <ul style="list-style-type: none"> <li>■ <b>dip-id id_num</b>—Specifies the ID number of a DIP pool. This number can be between 4 and 255.</li> </ul> </li> <li>■ <b>dst</b>—Performs NAT-dst on traffic to which the policy applies. ScreenOS supports the following three options for NAT-dst: <ul style="list-style-type: none"> <li>■ <b>ip addr</b>—Translates the original destination address to the address specified in the policy. The security device does not translate the original port number.</li> <li>■ <b>ip addr1 addr2</b>—Translates the original destination IP address from one range of addresses to an address in another range of addresses. The security device maintains a consistent mapping of an original destination address to a translated address within the specified range using a technique called address shifting.</li> <li>■ <b>ip addr1 port port_num</b>—Translates the original destination address and port number to the address and port number specified in the policy.</li> </ul> </li> </ul> |
|-----|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

**Example 1:** The following command creates a policy that applies NAT-src on all traffic from **any** address in the **Trust** zone to **any** address in the **Untrust** zone and specifies DIP pool **8**:

```
set policy from trust to untrust any any nat src dip-id 8 permit
```

**Example 2:** The following commands create an address (1.1.1.5/32) named **v-addr1** in the DMZ zone and a policy that applies NAT-dst on HTTP traffic from any address in the Untrust zone to the virtual destination address **v-addr1** in the DMZ zone. The security device translates the destination address from **1.1.1.5** to **10.2.2.5**:

```
set address dmz v-addr1 1.1.1.5/32
set policy from untrust to dmz any v-addr1 http nat dst ip 10.2.2.5 permit
```

**Example 3:** The following command combines NAT-src (source) and NAT-dst (destination):

```
set policy from trust to untrust any any any nat src dip-id 8 dst ip 10.2.2.5 permit
```

## negate

```
set { dst-address | src-address } negate
```

**negate** Applies the policy in the context of which you issue this command to all addresses except those specified as either the destination (**dst-address**) or source (**src-address**). The **negate** option takes effect at the policy component level, applying to all items in the negated component.

**Example:** The following commands permit HTTP traffic to the Untrust zone from all addresses in the Trust zone except from **addr1**:

```
device-> set policy id 1 from trust to untrust any any http permit
device-> set policy id 2 from trust to untrust addr1 any http permit
device-> set policy id 2
device(policy:2)-> set src-address negate
```

### **no-hw-sess**

```
set policy [global] { ... } no-hw-sess { ... }
set no-hw-sess
unset no-hw-sess
```

**no-hw-sess** Disables the security device from creating a hardware session for a specific traffic. This is useful when some traffic could not be handled efficiently by ASIC and for debug operation.

---

**NOTE:** For TCP traffic, you must create a dummy hardware session to pass the traffic to the CPU.

---

### **no-session-backup**

```
set policy [global] { ... } no-session-backup { ... }
```

**no-session-backup** Disables backing up the sessions to which the policy applies when the security device is in a high availability (HA) configuration. By default, a security device operating in HA backs up sessions.

### **pair-policy**

```
set policy [global] { ... } pair-policy pol_num [...]
```

**pair-policy pol\_num** Links the policy that you are configuring with another policy that references the same VPN tunnel so that both policies share one proxy ID and one security association (SA). This is useful when you want to allow bidirectional traffic over a policy-based VPN and there is source destination address translation using a DIP pool or destination address translation using a MIP or VIP. Without policy pairing, the security device derives a different proxy ID from both the outbound and inbound policies. This causes a problem for the remote peer if it has only a single proxy ID for the VPN tunnel. By pairing both policies together, they share a single proxy ID (derived from the policy that you configured last), which solves the proxy ID problem for the remote peer, and they share a single SA, which conserves SA resources.

**Example:** The following commands create two policies sharing the same VPN tunnel and then bind them into a policy pair. (You have previously created on the tunnel interface subnet a DIP pool with ID 4 and addresses 1.1.1.10 to 1.1.1.20, and a MIP from 1.1.1.5 to host 10.1.1.5.):

```
set policy id 1 from trust to untrust addr1 addr2 any nat src dip-id 4 tunnel vpn vpn1
set policy id 2 from untrust to trust addr2 mip(1.1.1.5) MAIL tunnel vpn vpn1
pair-policy 1
```

The proxy ID for both of these policies is as follows:

```
local 1.1.1.5/255.255.255.255, remote 10.2.2.0/255.255.255.0, proto 6, port 25
```

Because the local address in the above proxy ID does not include the addresses in the DIP pool or any service other than SMTP (or MAIL), you must also set a proxy ID with an address range that encompasses both the MIP (1.1.1.5) and DIP pool (1.1.1.10 to 1.1.1.20) and change the service to **ANY**:

```
set vpn vpn1 proxy-id local-ip 1.1.1.0/24 remote-ip 10.2.2.0/24 ANY
```

## schedule

```
set policy [global] { ... } schedule name_str [...]
```

schedule Applies the policy only at times defined in the specified schedule.

**Example:** With the following commands, you first create a schedule named **Mkt\_Sched** and then reference it in a policy permitting any kind of traffic from any address in the Trust zone to any address in the Untrust zone:

```
set schedule Mkt_Sched recurrent monday start 09:00 stop 12:00
set policy from trust to untrust any any any permit schedule Mkt_Sched
```

## service

```
get policy [service svc_name]
```

service Displays information about security policies that reference the named service.

## sess-limit (get)

```
get policy [id pol_num [sess-limit count [src-ip ip_addr]]]
get policy [global [id pol_num [sess-limit count [src-ip ip_addr]]]]
```

sess-limit count Displays information about security policies set to the specified session limitation.

src-ip ip\_addr Further delineates the policies to be displayed by specifying the source IP that is affected.

## sess-limit (set)

```
set policy [global] { ... } sess-limit per-src-ip session-count [alarm-no-drop] [...]
set sess-limit per-src-ip session-count [alarm-no-drop]
unset sess-limit per-src-ip [alarm-no-drop]
```

`sess-limit` Limits the session number on any source IP to the specified limitation. If the limit reaches the session's threshold, the traffic on the source IP address drops. If the **alarm-no-drop** option is enabled, the packet will not be dropped. The system continues processing and alerts you with a message. The *session-count* can take any value between 1 and *max-nat-session*.

## **src-ip | src-address**

```
get policy [from zone1] [[src-ip ip_addr] | src-address addr_name]]
```

`src-ip ip_addr /  
src-address  
addr_name` Displays information about security policies that match an IP packet with the specified source IP or policies that reference the specified source address as their source address directly or indirectly. You cannot use **src-ip** and **src-address** in the same command. When using **src-address**, you must first specify **from zone1**.

- *ip\_addr* is the source IP address.
- *addr\_name* is the name of the source address.

**Example 1:** The following command displays policies that match an IP packet with a source IP address of **172.16.10.1**:

```
get policy src-ip 172.16.10.1
```

**Example 2:** The following commands create an address (**10.1.1.0/24**) named **addr1** in the trust zone and display the policies that reference the destination address of `addr1`:

```
set address trust addr1 10.1.1.0/24
get policy from trust src-address addr1
```

## **top**

```
set policy [global] [...] top
```

`top` Places the policy at the top of the access control list (ACL). The policy at the top of the ACL has the highest precedence.

**Example:** The following command:

- Permits **any** kind of service from **any** address in the **Trust** zone to **any** address in the **Untrust** zone
- Assigns to the policy an ID value of **30**
- Places the policy at the **top** of the ACL

```
set policy id 30 top from trust to untrust any any any permit
```

## **traffic gbw**

```
set policy [global] [...] traffic
 gbw number priority number mbw [number] | pbw [number]
 dscp { disable | enable [value dscp-byte] }
```

|             |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
|-------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| traffic gbw | <p>Defines the guaranteed bandwidth in kilobits per second. The security device passes traffic below this threshold with the highest priority, without performing traffic shaping.</p> <ul style="list-style-type: none"> <li>■ <b>priority number</b>—Specifies one of the eight traffic priority levels. When traffic falls between the guaranteed and maximum bandwidth settings, the security device passes traffic with higher priority first. Lower priority traffic is passed only if there is no higher priority traffic.</li> <li>■ <b>mbw number</b>—Defines the maximum bandwidth in kilobits per second. Traffic beyond this limit is throttled and dropped.</li> <li>■ <b>pbw number</b>—Defines the policing bandwidth in kilobits per second on the ingress side of the security device. Traffic beyond this limit is dropped.</li> <li>■ <b>dscp { enable [ value dscp-byte ]   disable }</b>—Enables or disables a mapping of the eight ScreenOS priority levels to the Differentiated Services—DiffServ—Codepoint (DSCP) marking system, or optionally specifies a DSCP value independent of a ScreenOS priority setting.</li> </ul> <p>In the ScreenOS system, 0 is the highest priority and seven is the lowest. When you enable DSCP and do not specify a value, ScreenOS overwrites the first 3 bits in the DiffServ field (see RFC 2474), or the IP precedence field in the TOS byte (see RFC 1349), in the IP packet header. When you set a dscp-byte value (0-63), ScreenOS overwrites the first 6 bits of the TOS field to specify the class or type of network service.</p> |
|-------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

**Example:** The following command:

- Permits **HTTP** traffic from **any** address in the **Trust** zone to **any** address in the **Untrust** zone
- Guarantees bandwidth of **3,000** kilobits per second
- Assigns a priority value of **2**
- Sets the maximum bandwidth to **10,000** kilobits per second
- Enables mapping of the eight ScreenOS priority levels to the DiffServ Codepoint (DSCP) marking system

**set policy from trust to untrust any any HTTP permit traffic gbw 3000 priority 2 mbw 10000 dscp enable**

## tunnel

```
set policy [global] { ... } tunnel
 { l2tp tunn_str | vpn-group id_num }
set policy [global] { ... } tunnel vpn tunn_str
 [l2tp tunn_str | pair-policy pol_num]
```

|        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|--------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| tunnel | <p>Encrypts outgoing IP packets, and decrypts incoming IP packets.</p> <ul style="list-style-type: none"> <li>■ <b>vpn [ l2tp <i>tunn_str</i> ]</b>—Identifies a VPN tunnel. For an IPsec VPN tunnel, specify <b>vpn</b> and the name of the VPN tunnel. For L2TP, specify <b>vpn</b> (with the name of the VPN tunnel) and <b>l2tp</b> (with the name of the L2TP tunnel).</li> <li>■ <b>vpn [ pair-policy <i>id_num</i> ]</b>—Links this policy with an existing policy also referencing the same VPN. The VPN uses the proxy-id derived from the policy whose configuration includes the <b>pair-policy</b> keyword.</li> </ul> |
|--------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

- **vpn-group** *id\_num*—Identifies a VPN group (*id\_num*). A VPN group consists of multiple VPNs, which you can specify in a single policy.
- **vpn-tunnel**—Identifies an active tunnel.

**Example:** The following command defines a policy that uses a defined VPN tunnel.

- Encrypts traffic exchanged with the corporate headquarters (denoted by address book entry Headquarters)
- Uses a VPN named **To\_HQ**:

```
set policy from trust to untrust any Headquarters any tunnel vpn To_HQ
```

## url

```
set url protocol sc-cpa profile { name_str | ns-profile }
```

**profile** Specifies the Web-filtering profile that you are binding to the specified policy. Only one URL profile can be linked to a policy. Use this command when configuring the integrated Web-filtering feature. For information about this feature, see the *Concepts & Examples ScreenOS Reference Guide*.

## url-filter

```
set policy { ... } url-filter
```

**url-filter** Enables Web filtering on the security device.

## verify

```
exec policy verify [from zone [to zone] | global | to zone]
```

**verify** Verifies that the order of policies in a policy list is valid so that a policy higher in the list does not eclipse, or “shadow,” another policy lower in the list. If the verification check discovers policy shadowing, the command output explains which policies are shadowing which. You can define the scope of the verification as follows:

- Not setting any further options instructs the security device to verify the ordering of policies in all policy sets.
- **from zone**—Checks the ordering of policies from the specified zone to any zone.
- **from zone to zone**—Checks the ordering of policies between the specified zones.
- **global**—Checks the ordering of policies in the global policy set.
- **to zone**—Checks the ordering of policies from any zone to the specified zone.

**Example:** The following command verifies the ordering of policies from the Trust zone to the Untrust zone:

```
exec policy verify from trust to untrust
```

## **webauth**

```
set policy from zone1 to zone2 src_addr dst_addr any permit webauth
[redirect-unauthenticated]
```

**webauth** Configures a WebAuth policy and authenticates the auth user before sending traffic that requires authentication via WebAuth to an intended destination. When validation succeeds, any other traffic initiated by the same user will be allowed to pass.

- **redirect-unauthenticated**—Enables the WebAuth captive portal feature for the specified policy. If the service is not standard HTTP (port: 80), the device alerts the user with a prompt. Redirection is triggered only by http traffic.

# ppp

Point-to-Point Protocol (PPP) provides a standard method for encapsulating Network Layer protocol information over point-to-point links. PPP encapsulation is defined in RFC 1661, *The Point-to-Point Protocol (PPP)*.

Use the **ppp** commands to configure PPP or to display current PPP configuration parameters.

## Syntax

---

### *clear*

```
clear ppp [name profile_name]
```

### *get*

```
get ppp profile { profile_name | all }
```

### *set*

```
set ppp profile profile_name
{
 auth
 {
 local-name name_str
 secret string
 type { any | chap | none | pap }
 }
 ncp { ipcp ipv6cp } | { ipv6cp ipcp }
 netmask netmask |
 passive |
 static-ip
}
```

## Keywords and Variables

---

### **profile**

```
set ppp profile profile_name { ... }
get ppp profile { all | profile_name }
```

#### profile

Creates and configures a PPP access profile, which specifies authentication parameters for the PPP link. You bind the PPP access profile to an interface with the **set interface** command. You can configure the following parameters in the PPP access profile:

- **auth**—Specifies the authentication method to be used when establishing the link or the hostname to be used in Challenge Handshake Authentication Protocol (CHAP) requests and responses. Specify one of the following values:

- **local-name** *name\_str*—Specifies the local client name.

- **secret** *string*—Specifies the local client secret.

- **type**—Specifies the PPP authentication type:

- any**—Sets the PPP profile to negotiate any type of the supported PPP authentication.

- chap**—Sets the PPP profile to use Challenge Handshake Authentication Protocol.

- none**—Sets the PPP profile to not use any authentication type.

- pap**—Sets the PPP profile to use Password Authentication Protocol.

- **ncp ipcp ipv6cp**—Supports IPCP and IPv6CP on WAN interfaces that use PPP/MLPPP encapsulation.

- **netmask**—Specifies the netmask for the interface. The default is 255.255.255.255.

- **passive**—Directs the interface not to challenge its peer and to respond only when challenged. This is disabled by default.

- **static-ip**—Directs the interface to use an IP address that you have manually configured for the interface.

For the **get** command, you can show information either for a specified profile or for all configured profiles.

The **clear** command allows you to clear all parameters for a specified profile.

# pppoa

Use the **pppoa** commands to configure PPPoA or to display current PPPoA configuration parameters.

Point-to-Point Protocol over ATM (PPPoA) is usually used for PPP sessions that are to be terminated on a security device with an ADSL interface. PPPoA is primarily used for business class services because it does not require a desktop client (which is required for PPPoE termination).

## Syntax

---

### **clear**

```
clear [cluster] pppoa [name name_str]
```

### **exec**

```
exec pppoa [name name_str] { connect | disconnect }
```

### **get**

```
get pppoa { all | name name_str }
```

### **set**

```
set pppoa [name name_str]
 {
 authentication { CHAP | PAP | any } |
 auto-connect number |
 clear-on-disconnect |
 idle-interval number |
 interface [interface] |
 netmask [mask] |
 ppp
 {
 lcp-echo-retries number |
 lcp-echo-timeout number
 } |
 static-ip |
 update-dhcpserver |
 username name_str password pswd_str
 }
```

## Keywords and Variables

---

### ***all***

```
get pppoa all
```

**all** Displays information for all PPPoA instances.

### ***authentication***

```
set pppoa authentication { CHAP | PAP | any }
unset pppoa authentication { CHAP | PAP }
```

**authentication** Sets the authentication methods to **CHAP**, **PAP**, or **any**. (The **any** option gives preference to CHAP.) The default authentication is **any** (both CHAP and PAP). To set authentication to CHAP only, first execute **unset pppoa authentication PAP**.

### ***auto-connect***

```
set pppoa auto-connect number
unset pppoa auto-connect
```

**auto-connect** Specifies the number of seconds that elapse before automatic re-initiation of a previously closed connection occurs. The valid range is 0–10000 (0 to disable). This is disabled by default.

### ***clear-on-disconnect***

```
set pppoa [name name_str] clear-on-disconnect
unset pppoa clear-on-disconnect
```

**clear-on-disconnect** Directs the security device to clear the IP address and the gateway for the interface once PPPoA disconnects. By default, this is disabled; that is, the IP address and gateway for the interface remain when PPPoA disconnects.

If you do not specify **name**, ScreenOS sets the parameter for the default instance untrust.

### ***connect | disconnect***

```
exec pppoa [name name_str] { connect | disconnect }
```

**connect** Starts a PPPoA connection for an instance. (Each instance can be bound to an interface.)

**disconnect** Takes down a PPPoA connection.

## idle-interval

```
set pppoa idle-interval number
unset pppoa idle-interval
```

**idle-interval** Sets the idle timeout, which is time elapsed (in minutes) before the security device terminates a PPPoA connection due to inactivity. The valid range is 0–10000 minutes. Specifying 0 turns off the idle timeout and the device never terminates the connection. The default is 30 minutes.

## interface

```
set pppoa interface [name_str]
unset pppoa interface
```

**interface** Specifies the ADSL interface for PPPoA encapsulation.

## name

```
exec pppoa [name name_str] { connect | disconnect }
get pppoa [name name_str | all]
set pppoa [name name_str] ...
unset pppoa [name name_str]
```

**name** Specifies or defines the name for a specific PPPoA instance. You can assign a username and password, an interface, and other PPP/PPPoA parameters to the instance.

If you do not specify **name**, ScreenOS automatically configures the parameters for the default instance `untrust`.

**Example:** The following commands define a name for a PPPoA instance.

- Username `user1` and password `123456`
- PPPoA instance `pppoa-user-1` bound to the `ethernet2` interface

```
set pppoa name pppoa-user-1 username user1 password 123456
set pppoa name pppoa-user-1 interface ethernet2
```

## netmask

```
set pppoa netmask mask
unset pppoa netmask
```

**netmask** Specifies a PPPoA subnet mask that the device assigns to the interface bound to the PPPoA instance (after establishment of the connection). The default netmask is `255.255.255.0`.

When it is necessary for two or more interfaces to have overlapping subnets, use the following command:

```
set vrouter vrouter ignore-subnet-conflict
```

**ppp**

```
set pppoa ppp { ... }
unset pppoa ppp { ... }
```

**ppp** Specifies PPP parameters.

- **lcp-echo-retries** the number of unacknowledged LCP Echo requests before connection is terminated. The valid range is 1–30. The default is 10.
- **lcp-echo-timeout** the time that elapses between transmission of two LCP Echo requests. The valid range is 1–1000 seconds. The default is 180 seconds.

**static-ip**

```
set pppoa static-ip
unset pppoa static-ip
```

**static-ip** Specifies that your connection uses the static IP address assigned to your device's interface. This is disabled by default.

**update-dhcpserver**

```
set pppoa update-dhcpserver
unset pppoa update-dhcpserver
```

**update-dhcpserver** Specifies that the DHCP server (on the device) automatically updates DNS parameters received through the PPPoA connection. This is enabled by default.

**username**

```
set pppoa username name_str password pswd_str
```

**username** Sets the username and password for authentication.

# pppoe

Use the **pppoe** commands to configure PPPoE or to display current PPPoE configuration parameters.

Point-to-Point Protocol over Ethernet (PPPoE) is a protocol that allows the members of an Ethernet LAN to make individual PPP connections with their ISP by encapsulating the IP packet within the PPP payload, which is encapsulated inside the PPPoE payload. Some security devices support PPPoE, which allows them to operate compatibly on DSL, Ethernet Direct, and cable networks run by ISPs that use PPPoE to give their clients Internet access.

## Syntax

---

### **clear**

```
clear [cluster] pppoe [name name_str]
```

### **exec**

```
exec pppoe [name name_str] { connect | disconnect }
```

### **get**

```
get pppoe
[
 all |
 name name_str | id id_num
 [configuration | statistics]
]
```

### **set**

```
set pppoe [name name_str]
{
 ac name_str |
 authentication { CHAP | PAP | any } |
 auto-connect number |
 clear-on-disconnect |
 default-route-metric number |
 enable |
 idle-interval number |
 interface [name_str] |
 name-server admin-preference |
 netmask mask |
 ppp
 {
 lcp-echo-retries number |
```

```

 lcp-echo-timeout number
 } |
 service name_str |
 static-ip |
 update-dhcpserver |
 username name_str password pswd_str
}

```

## Keywords and Variables

---

### **ac**

```

set pppoe ac name_str
unset pppoe ac

```

**ac** Allows the interface to connect only to the specified AC (access concentrator).

### **all**

```
get pppoe all
```

**all** Displays information for all PPPoE instances.

### **authentication**

```

set pppoe authentication { CHAP | PAP | any }
unset pppoe authentication { CHAP | PAP }

```

**authentication** Sets the authentication methods to **CHAP**, **PAP**, or **any**. (The **any** option gives preference to CHAP.) The default of authentication is any (both CHAP and PAP). To set authentication to CHAP only, first execute **unset pppoe authentication PAP**.

### **auto-connect**

```

set pppoe auto-connect number
unset pppoe auto-connect

```

**auto-connect** Specifies the number of seconds that elapse before automatic re-initiation of a previously closed connection occurs. The valid range is 0–10000 (0 to disable).

### **clear-on-disconnect**

```
set pppoe [name name_str] clear-on-disconnect
unset pppoe clear-on-disconnect
```

**clear-on-disconnect** Directs the security device to clear the IP address and the gateway for the interface once PPPoE disconnects. By default, this is disabled; that is, the IP address and gateway for the interface remain when PPPoE disconnects.

If you do not specify **name**, ScreenOS sets the parameter for the default instance untrust.

### **cluster**

```
clear cluster pppoe
```

**cluster** Propagates the **clear** operation to all other devices in an NSRP cluster.

### **configuration**

```
get pppoe [name name_str] configuration
```

**configuration** Displays the configuration options.

If you do not specify **name**, ScreenOS displays the parameters for the default instance untrust.

### **connect | disconnect**

```
exec pppoe [name name_str] { connect | disconnect }
```

**connect** Starts a PPPoE connection for an instance. (Each instance can be bound to an interface.)

**disconnect** Takes down a PPPoE connection.

### **default-route-metric**

```
set pppoe default-route-metric number
unset pppoe default-route-metric
```

**default-route-metric** Sets the metric for the default route for the current instance.

### **enable**

```
set pppoe [name name_str] enable
unset pppoe [name name_str] enable
```

**enable** Enables or disables a PPPoE instance, without removing the object that defines the instance. This allows you to temporarily disable the instance, and enable it later without redefining it.

**idle-interval**

```
set pppoe idle-interval number
unset pppoe idle-interval
```

**idle-interval** Sets the idle timeout, which is time elapsed (in minutes) before the security device terminates a PPPoE connection due to inactivity. Specifying 0 turns off the idle timeout and the device never terminates the connection.

**id**

```
get pppoe id id_num
```

**id** Specifies a PPPoE instance by ID number.

**interface**

```
set pppoe interface [name_str]
unset pppoe interface
```

**interface** Specifies the interface for PPPoE encapsulation.

**name**

```
exec pppoe [name name_str] { connect | disconnect }
get pppoe [name name_str | all]
set pppoe [name name_str] ...
unset pppoe [name name_str]
```

**name** Specifies or defines the name for a specific PPPoE instance. You can assign a username and password, interface, and other PPP/PPPoE parameters to the instance.

If you do not specify **name**, ScreenOS automatically configures the parameters for the default instance `untrust`.

**Example:** The following commands define a name for a PPPoE instance.

- Username `user1` and password `123456`
- PPPoE instance `pppoe-user-1` bound to the `ethernet2` interface

```
set pppoe name pppoe-user-1 username user1 password 123456
set pppoe name pppoe-user-1 interface ethernet2
```

## name-server

```
set pppoe name-server admin-preference number
unset pppoe name-server admin-preference
```

**name-server** Specifies the preference level for DNS addresses learned from the PPPoE server.

The device can learn DNS server addresses statically (from the CLI or WebUI), or it can learn them dynamically (from PPPoE, DHCP, DHCP or XAuth). The device stores these learned addresses in the DNS server list. It then selects the best two addresses from this list, and designates them as the primary and secondary DNS server addresses. The admin-preference number setting specifies how much preference the device gives to addresses learned through one source or protocol, in comparison with another source or protocol. To do this, it uses an election protocol.

First, the device compares the admin-preference values. If the values differ, it selects the address with the highest value. If the values are identical, it uses the highest protocol. (The protocol levels, from highest to lowest, are PPPoE, XAuth, DHCP, and CLI respectively.) If the protocols are identical, it chooses the address with the greatest numerical value.

## netmask

```
set pppoe netmask mask
unset pppoe netmask
```

**netmask** Specifies a PPPoE subnet mask that the device assigns to the interface bound to the PPPoE instance (after establishment of the connection).

When it is necessary for two or more interfaces to have overlapping subnets, use the following command:

**set vrouter *vrouter* ignore-subnet-conflict**

## ppp

```
set pppoe ppp { ... }
unset pppoe ppp { ... }
```

**ppp** Specifies PPP parameters.

- **lcp-echo-retries** the number of unacknowledged Lcp Echo requests before connection is terminated. The valid range is 1–30.
- **lcp-echo-timeout** the time that elapses between transmission of two Lcp Echo requests. The valid range is 1–1000 seconds.

## service

```
set pppoe service name_str
unset pppoe service
```

**service** Allows only the specified service (*name\_str*). This feature uses service tags to enable a PPP over Ethernet (PPPoE) server to offer PPPoE clients a selection of services during call setup. The user can choose an offered service, and the security device provides the service when the PPPoE session becomes active. This allows service providers to offer services and to charge customers according to the service chosen.

## ***static-ip***

```
set pppoe static-ip
unset pppoe static-ip
```

**static-ip** Specifies that your connection uses the IP address assigned to your device's interface.

## ***statistics***

```
get pppoe statistics
```

**statistics** Specifies the statistics information.

## ***update-dhcpserver***

```
set pppoe update-dhcpserver
unset pppoe update-dhcpserver
```

**update-dhcpserver** Specifies that the DHCP server (on the device) automatically updates DNS parameters received through the PPPoE connection.

## ***user-name***

```
set pppoe username name_str password pswd_str
```

**username** Sets the username and password.

**Example:** The following command sets the username to *Phred*, and Phred's password to *!@%)&&*:

```
set pppoe username Phred password !@%)&&
```

## ***Defaults***

The defaults for this command are as follows:

- Feature *disabled*
- Authentication method *any*
- Timeout *30* minutes
- auto-connect setting *disabled*
- lcp-echo-timeout value *180* seconds
- retries value *10*
- netmask value *255.255.255.255*
- update-dhcpserver setting *enabled*
- static-ip setting *disabled*
- clear-on-disconnect setting *disabled*

# proxy-id

Use the **proxy-id** commands to set device behavior for processing proxy ID updates. A proxy ID is a three-part tuple consisting of local IP address, remote IP address, and service. The proxy ID for both peers must match, which means that the service specified in the proxy ID for both peers must be the same, and the local IP address specified for one peer must be the same as the remote IP address specified for the other peer. The peers exchange proxy IDs during IKE Phase 2 negotiations.

During the startup process, the security device loads its configuration file. While loading this file, the security device reads the policies before the routes. Because of this, routing information that involves MIPs or VIPs can result in the security device deriving incorrect proxy-IDs from the policy information in the file. To resolve this problem, you can use the **unset proxy-id manual-update** command to change the default behavior of the device to update proxy IDs after the configuration file finishes loading. However, if you have a large number of policies, the update procedure can take a very long time to complete.

By default, the device behavior does not update proxy IDs automatically during startup. Instead, you must manually update proxy IDs by entering the **exec proxy-id update** command. For VPN traffic that uses source or destination address translation, we recommend either of the following approaches:

- Use routing-based VPNs and separate the VPN and its manually defined proxy ID from the policy that enforces address translation.
- Use policy-based VPNs and assign proxy IDs to the VPN tunnels referenced by the policies rather than allow the security device to automatically derive the proxy IDs from the policies.

## Syntax

---

### **exec**

exec proxy-id update

### **get**

get proxy-id

### **set**

set proxy-id manual-update

## Keywords and Variables

---

### **update**

exec proxy-id update

update           Instructs the security device to update all VPN proxy IDs.

### **manual-update**

set proxy-id manual-update  
unset proxy-id manual-update

manual-update   When set, instructs the security device to update all VPN proxy IDs only in response to the **exec proxy-id update** command. When unset, instructs the security device to update the proxy IDs automatically during route change.

### **Defaults**

By default, the security device does not update proxy IDs automatically.

# reset

Use the **reset** commands to restart the security device.

## Syntax

---

```
reset
 [
 no-prompt |
 save-config [no | yes] [no-prompt]
]
```

## Keywords and Variables

---

### *no-prompt*

```
reset no-prompt
```

**no-prompt**      Indicates no confirmation.

### *save-config*

```
reset save-config [no | yes] [no-prompt]
```

**save-config**

- **no**—Directs the security device to not save the current configuration before resetting.
- **yes**—Directs the security device to save the current configuration before resetting.
- **no-prompt** Does not display a confirmation prompt.



# RIP Commands

Use the **rip** context to begin configuring Routing Information Protocol (RIP) for a virtual router.



**CAUTION:** RIP is *not* supported over unnumbered tunnel interfaces. All interfaces that use RIP must be numbered. Any attempt to configure and run an unnumbered interface using RIP can lead to an unpredictable routing failure.

---

## Context Initiation

---

Initiating the **rip** context can take up to four steps.

1. Enter the vrouter context by executing the `set vrouter` command.

```
set vrouter vrouter
```

For example:

```
set vrouter trust-vr
```

2. Enter the **rip** context by executing the **set protocol rip** command.

```
device(trust-vr)-> set protocol rip
```

3. Enable RIP (it is disabled by default).

```
device(trust-vr/rip)-> set enable
```

## RIP Command List

---

The following commands are executable in the **rip** context. Click on a keyword in the table to go to complete syntax and usage information.

|                     |                                                                                                                                                                                                                                                                                                                                                                                                    |
|---------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| advertise-def-route | <p>Use the <b>advertise-def-route</b> commands to advertise the default route (0.0.0.0/0) of the current virtual router in the RIP routing domain.</p> <p>Every virtual router can have a default route entry, which matches every destination. (Any entry with a more specific prefix overrides the default route entry.)</p> <p>Command options: <b>get, set, unset</b></p>                      |
| alt-route           | <p>Use the <b>alt-route</b> commands to set the maximum number of alternate routes in the RIP database for a network prefix.</p> <p>Command options: <b>set, unset</b></p>                                                                                                                                                                                                                         |
| config              | <p>Use the <b>config</b> command to display all commands executed to configure the RIP routing instance.</p> <p>Command options: <b>get</b></p>                                                                                                                                                                                                                                                    |
| database            | <p>Use the <b>database</b> command to display the RIP database in the virtual router.</p> <p>Command options: <b>get</b></p>                                                                                                                                                                                                                                                                       |
| default-metric      | <p>Use the <b>default-metric</b> commands to set the RIP metric for redistributed routes. The default value is 10.</p> <p>Command options: <b>set, unset</b></p>                                                                                                                                                                                                                                   |
| enable              | <p>Use the <b>enable</b> commands to enable or disable RIP in the virtual router.</p> <p>Command options: <b>set, unset</b></p>                                                                                                                                                                                                                                                                    |
| flush-timer         | <p>Use the <b>flush-timer</b> commands to configure the number of seconds that elapse before the virtual router automatically removes an invalidated route. The default is 120 seconds.</p> <p>Command options: <b>set, unset</b></p>                                                                                                                                                              |
| garbage-list        | <p>Displays all routes currently contained in the RIP garbage list. This list contains routes automatically removed from the routing table because the device did not obtain the routes in the time interval specified by the Invalid Timer setting. When the Flush Timer interval elapses for an entry, the device purges the entry from the garbage list.</p> <p>Command options: <b>get</b></p> |
| hold-timer          | <p>Use the <b>hold-timer</b> commands to configure the number of seconds that elapse before the virtual router updates the routing table when RIP detects a route with a high metric.</p> <p>Command options: <b>set, unset</b></p>                                                                                                                                                                |
| interface           | <p>Use the <b>interface</b> command to display all RIP interfaces in the virtual router.</p> <p>Command options: <b>get</b></p>                                                                                                                                                                                                                                                                    |
| invalid-timer       | <p>Use the <b>invalid-timer</b> commands to configure the number of seconds that elapse after a neighbor stops advertising a route before the route becomes invalid. The default is 180 seconds.</p> <p>Command options: <b>set, unset</b></p>                                                                                                                                                     |

|                      |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|----------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| max-neighbor-count   | Use the <b>max-neighbor-count</b> commands to set the maximum number of RIP neighbors allowed. The default is 16.<br>Command options: <b>set, unset</b>                                                                                                                                                                                                                                                                                                                                                                         |
| neighbors            | Use the <b>neighbors</b> command to display the status of RIP neighbors.<br>Command options: <b>get</b>                                                                                                                                                                                                                                                                                                                                                                                                                         |
| no-source-validation | Use the <b>no-source-validation</b> commands to accept responses from RIP neighbors in other subnets or to reject such responses. The default action is to reject the responses.<br>Command options: <b>set, unset</b>                                                                                                                                                                                                                                                                                                          |
| poll-timer           | Use the <b>poll-timer</b> commands to set the interval and number of times that triggered requests are sent over the demand circuit to check if the other end of the demand circuit has come up.<br>Command options: <b>set, unset</b>                                                                                                                                                                                                                                                                                          |
| redistribute         | Use the <b>redistribute</b> commands to import known routes from a router running a different protocol into the current routing instance.<br>You can import the following types of routes: <ul style="list-style-type: none"> <li>■ Manually created (static) routes</li> <li>■ BGP routes</li> <li>■ OSPF routes</li> <li>■ Routes created by an external router, due to an interface with an IP address becoming available</li> <li>■ Routes imported from other virtual routes</li> </ul> Command options: <b>set, unset</b> |
| reject-default-route | Use the <b>reject-default-route</b> commands to cause RIP to reject a default route learned from a neighbor.<br>Command options: <b>get, set, unset</b>                                                                                                                                                                                                                                                                                                                                                                         |
| retransmit-timer     | Use the <b>retransmit-timer</b> commands to set the interval and number of times that triggered messages waiting for acknowledgement or a response are retransmitted over the demand circuit.<br>Command options: <b>set, unset</b>                                                                                                                                                                                                                                                                                             |
| route-map            | Use the <b>route-map</b> commands to filter routes and offset the metric to a RIP route matrix.<br>Command options: <b>get, set, unset</b>                                                                                                                                                                                                                                                                                                                                                                                      |
| routes-redistribute  | Use the <b>routes-redistribute</b> command to display redistributed routes.<br>Command options: <b>get</b>                                                                                                                                                                                                                                                                                                                                                                                                                      |
| rules-redistribute   | Use the <b>rules-redistribute</b> command to display redistribution rules.<br>Command options: <b>get</b>                                                                                                                                                                                                                                                                                                                                                                                                                       |
| summary              | Use the <b>summary</b> command to display summary routes.<br>Command options: <b>get</b>                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| summary-ip           | Use the <b>summary-ip</b> command to create a summary route that corresponds to a summary range.<br>Command options: <b>set, unset</b>                                                                                                                                                                                                                                                                                                                                                                                          |
| threshold-update     | Use the <b>threshold-update</b> commands to set the maximum number of routing packets allowed per update interval.<br>Command options: <b>set, unset</b>                                                                                                                                                                                                                                                                                                                                                                        |

|                   |                                                                                                                                                             |
|-------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------|
| timer             | Use the <b>timer</b> command to display RIP timers.<br>Command options: <b>get</b>                                                                          |
| trusted-neighbors | Use the <b>trusted-neighbors</b> commands to set an access list that defines RIP neighbors.<br>Command options: <b>get, set, unset</b>                      |
| update-timer      | Use the <b>update-timer</b> commands to set the interval, in seconds, when route updates are issued to RIP neighbors.<br>Command options: <b>set, unset</b> |
| update-threshold  | Use the <b>update-threshold</b> command to display the number of routing packets per update interval.<br>Command options: <b>get</b>                        |
| version           | Use the <b>version</b> command to set the RIP protocol version for the virtual router.<br>Command options: <b>set, unset</b>                                |

### **advertise-def-route**

Use the **advertise-def-route** commands to advertise the default route (0.0.0.0/0) of the current virtual router. The default route is a non-RIP route.

Every router might have a default route entry, which matches every destination. (Any entry with a more specific prefix overrides the default route entry.)

Before you can execute the **advertise-def-route** commands, you must initiate the **rip** context. (See “Context Initiation” on page 575.)

### **Syntax**

#### **get**

```
get advertise-def-route
```

#### **set**

```
set advertise-def-route [always] { metric number | preserve-metric }
```

### **Keywords and Variables**

#### **always**

```
set advertise-def-route always ...
```

|        |                                                                                                                                                                                                                                                                                                                                                                                                                        |
|--------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| always | Directs the routing instance to advertise the non-RIP default route under all conditions, even if there is no default route in the routing table. If you specify <b>always</b> , you must also specify the <b>metric</b> parameter; you can optionally specify the <b>preserve-metric</b> parameter. If you do not specify <b>always</b> , you must specify either the <b>metric</b> or <b>preserve-metric</b> option. |
|--------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

**metric**

set advertise-def-route always metric *number*

**metric** Specifies the metric (cost), which indicates the overhead associated with the default route, which is a route redistributed from a protocol other than RIP. Enter a number between 1 and 15. You must specify this parameter if you specify the **always** option.

**preserve-metric**

set advertise-def-route ... [ preserve-metric ]

**preserve-metric** Instructs the virtual router to use the original (source) route's metric for advertisement when the route is redistributed. When you execute a **preserve-metric** command, in conjunction with a value specified by the **metric** command, the **preserve-metric** parameter takes precedence over the metric value when a route is redistributed.

**alt-route**

Use the **alt-route** commands to set the maximum number of alternate routes that the security device maintains in the RIP database for a network prefix.

Before you can execute the **alt-route** commands, you must initiate the **rip** context. (See "Context Initiation" on page 575.)

**Syntax**

set alt-route *number*

**Keywords and Variables****number**

set alt-route *number*

**number** Sets the maximum number of alternate routes in the RIP database for a network prefix. Enter a value between 0 and 3. The default value is 0, which means that there are no alternate routes in the database for a network prefix.

**config**

Use the **config** command to display all commands executed to configure the RIP local virtual router.

Before you can execute the **config** command, you must initiate the **rip** context. (See "Context Initiation" on page 575.)

**Syntax**

get config

**Keywords and Variables**

None.

## **database**

Use the **database** command to display the RIP database in the local virtual router.

Before you can execute the **database** command, you must initiate the **rip** context. (See “Context Initiation” on page 575.)

### **Syntax**

```
get database [prefix ip_addr/mask]
```

### **Keywords and Variables**

#### **prefix**

```
get database prefix ip_addr/mask
```

prefix                      Shows specific RIP entries in detail.

## **default-metric**

Use the **default-metric** commands to set the RIP metric for redistributed routes.

Before you can execute the **default-metric** commands, you must initiate the **rip** context. (See “Context Initiation” on page 575.)

### **Syntax**

```
set default-metric number
```

### **Keywords and Variables**

#### **Variable Parameter**

```
set default-metric number
```

number                      The metric for the routes redistributed into RIP. This metric value can be from 1 to 15.

## **enable**

Use the **enable** commands to enable or disable RIP from the current virtual router.

Before you can execute the **enable** commands, you must initiate the **rip** context. (See “Context Initiation” on page 575.)

### **Syntax**

```
set enable
```

### **Keywords and Variables**

None.

## ***flush-timer***

Use the **flush-timer** commands to configure the time that elapses before an invalid route is removed.

Before you can execute the **flush-timer** commands, you must initiate the **rip** context. (See “Context Initiation” on page 575.)

### **Syntax**

set flush-timer *number*

### **Keywords and Variables**

#### ***Variable Parameter***

set flush-timer *number*

|               |                                                                                                                                                                                 |
|---------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <i>number</i> | The number of seconds that elapses before an invalid route is removed. This value must be greater than the current <b>update-timer</b> value. The default value is 120 seconds. |
|---------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

## ***garbage-list***

Use the **garbage-list** commands to display all routes currently contained in the RIP garbage list. The garbage list contains routes automatically removed from the routing table because the device did not obtain the routes in the time interval specified by the Invalid Timer setting. When the Flush Timer interval elapses for an entry, the device automatically purges the entry from the garbage list.

Before you can execute the **garbage-list** commands, you must initiate the **rip** context. (See “Context Initiation” on page 575.)

### **Syntax**

get garbage-list

### **Keywords and Variables**

None.

## ***hold-timer***

Use the **hold-timer** commands to configure the time that elapses before the virtual router makes any updates into the routing table whenever RIP detects unreachable routes and higher metric routes. This minimizes the effects of route flapping to the routing table.

Before you can execute the **hold-timer** commands, you must initiate the **rip** context. (See “Context Initiation” on page 575.)

### **Syntax**

set hold-timer *number*

## Keywords and Variables

### *Variable Parameter*

set hold-timer *number*

**number**            The number of seconds that elapses before the virtual router updates the routing table when RIP detects a route with a high metric. The minimum value should be three times the **update-timer** value. The sum of the **update-timer** and the **hold-timer** values should not exceed the **flush-timer** value. The default value is 90 seconds.

## *interface*

Use the **interface** command to display all RIP interfaces on the current virtual router.

Before you can execute the **interface** command, you must initiate the **rip** context. (See “Context Initiation” on page 575.)

### **Syntax**

get interface

## Keywords and Variables

None.

## *invalid-timer*

Use the **invalid-timer** commands to configure the time that elapses after a neighbor stops advertising a route before the route becomes invalid.

Before you can execute the **invalid-timer** commands, you must initiate the **rip** context. (See “Context Initiation” on page 575.)

### **Syntax**

set invalid-timer *number*

## Keywords and Variables

### *Variable Parameter*

set invalid-timer *number*

**number**            The number of seconds after a neighbor stops advertising a route that the route becomes invalid. This value must be greater than the current **update-timer** value. The default value is 180 seconds.

## ***max-neighbor-count***

Use the **max-neighbor-count** commands to set the maximum number of RIP neighbors, which belong to the specified virtual router, allowed on an interface.

Before you can execute the **max-neighbor-count** commands, you must initiate the **rip** context. (See “Context Initiation” on page 575.)

### **Syntax**

```
set max-neighbor-count number
```

### **Keywords and Variables**

#### ***Variable Parameter***

```
set max-neighbor-count number
```

|        |                                                                                                                                                                                                                                              |
|--------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| number | The maximum number of RIP neighbors allowed. This value can be from one to the maximum value possible for your security device. The default is platform-dependent. See your product datasheet for the maximum limit for a particular device. |
|--------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

## ***neighbors***

Use the **neighbors** command to display the status of all RIP neighbors.

Before you can execute the **neighbors** command, you must initiate the **rip** context. (See “Context Initiation” on page 575.)

### **Syntax**

```
get neighbors
```

### **Keywords and Variables**

None.

## ***no-source-validation***

Use the **no-source-validation** commands to accept responses from RIP neighbors in different subnets. If you do not set this switch, the virtual router does not process responses from neighbors in other subnets.

Before you can execute the **no-source-validation** commands, you must initiate the **rip** context. (See “Context Initiation” on page 575.)

### **Syntax**

```
set no-source-validation
```

### **Keywords and Variables**

None.

## *poll-timer*

Use the **poll-timer** commands to configure the interval at which triggered requests are sent over a demand circuit to check if the other end of the circuit has come up.

Before you can execute the **poll-timer** commands, you must initiate the **rip** context. (See “Context Initiation” on page 575.)

### Syntax

```
set poll-timer number [retry-count number]
```

### Keywords and Variables

#### *Variable Parameter*

```
set poll-timer number
```

|               |                                                                                                                                                                                                      |
|---------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <i>number</i> | The interval, in number of seconds, at which triggered requests are sent over the demand circuit to check if the other end of the circuit has come up. The default value is 180 seconds (3 minutes). |
|---------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

#### *retry-count*

```
set poll-timer number retry-count number
```

|                    |                                                                                                                                                                                             |
|--------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <i>retry-count</i> | The number of times that the triggered requests are sent before the demand circuit is declared to be down. The default is 0, which means that the triggered requests are sent indefinitely. |
|--------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

## *redistribute*

Use the **redistribute** commands to import known routes from a router running a different protocol into the current RIP routing instance.

You can import the following types of routes:

- Manually created routes (**static**)
- BGP routes (**bgp**)
- OSPF routes (**ospf**)
- Directly connected interface with an IP address assigned to it (**connected**)
- Routes that have already been imported (**imported**)

Before you can execute the **redistribute** commands, you must initiate the **rip** context. (See “Context Initiation” on page 575.)

### Syntax

#### *get*

```
get routes-redistribute
get rules-redistribute
```

**set**

```
set redistribute route-map name_str protocol
 { bgp | connected | discovered | imported | ospf | static }
```

**Keywords and Variables*****protocol***

```
set redistribute route-map name_str protocol { ... }
```

|          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|----------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| protocol | Specifies the routing protocol type. The route map can use the protocol type to the determine whether to permit or deny a route. <ul style="list-style-type: none"> <li>■ <b>bgp</b> specifies that the route map performs an action only on BGP routes in the subnetwork.</li> <li>■ <b>connected</b> specifies that the route map performs an action only on routes sent from an external router that has at least one interface with an IP address assigned to it.</li> <li>■ <b>discovered</b> specifies that the route map performs an action only on discovered routes in the subnetwork.</li> <li>■ <b>imported</b> specifies that the route map performs an action only on imported routes in the subnetwork.</li> <li>■ <b>ospf</b> specifies that the route map performs an action only on OSPF routes in the subnetwork.</li> <li>■ <b>static</b> specifies that the route map performs an action only on static routes in the subnetwork.</li> </ul> |
|----------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

***route-map***

```
set redistribute route-map name_str protocol { ... }
```

route-map      Identifies the route map that specifies the routes to be imported.

**Example:** The following command redistributes a route that originated from a BGP routing domain into the current RIP routing instance:

```
device(trust-vr/rip)-> set redistribute route-map map1 protocol bgp
```

## ***reject-default-route***

Use the **reject-default-route** commands to cause RIP to reject default routes learned from a neighbor in the RIP domain.

Before you can execute the **reject-default-route** commands, you must initiate the **rip** context. (See “Context Initiation” on page 575.)

### **Syntax**

#### ***get***

get reject-default-route

#### ***set***

set reject-default-route

### **Keywords and Variables**

None.

## ***retransmit-timer***

Use the **retransmit-timer** command to configure the interval at which triggered responses are retransmitted over a demand circuit.

Before you can execute the **retransmit-timer** command, you must initiate the **rip** context. (See “Context Initiation” on page 575.)

### **Syntax**

set retransmit-timer *number* [ retry-count *number* ]

### **Keywords and Variables**

#### ***Variable Parameter***

set retransmit-timer *number*

**number**                    The interval, in number of seconds, at which triggered responses are retransmitted over a demand circuit. The default is 5 seconds.

#### ***retry-count***

set retransmit-timer *number* retry-count *number*

**retry-count**              The number of times any response is retransmitted before the demand circuit is placed into POLL state. The default is 10 times.

## *route-map*

Use the **route-map** commands to filter incoming or outgoing routes.

Before you can execute the **route-map** commands, you must initiate the **rip** context. (See “Context Initiation” on page 575.)

### Syntax

#### *get*

```
get route-map
```

#### *set*

```
set route-map name_str { in | out }
```

### Keywords and Variables

#### *Variable Parameter*

```
set route-map name_str
```

*name\_str*            The name of the route map to filter routes.

#### *in*

```
set route-map name_str in
unset route-map name_str in
```

*in*                    Specifies the route map is applied to routes to be learned by RIP.

#### *out*

```
set route-map name_str out
unset route-map name_str out
```

*out*                    Specifies the route map is applied to routes to be advertised by RIP.

**Example:** The following command applies the route map `map1` to routes to be advertised by RIP:

```
device(trust-vr/rip)-> set route-map map1 out
```

## *routes-redistribute*

Use the **routes-redistribute** command to display details about routes imported from other protocols into RIP.

Before you can execute the **routes-redistribute** command, you must initiate the **rip** context. (See “Context Initiation” on page 575.)

### Syntax

```
get routes-redistribute
```

### Keywords and Variables

None.

## ***rules-redistribute***

Use the **rules-redistribute** command to display conditions set for routes imported from other protocols into RIP.

Before you can execute the **rules-redistribute** command, you must initiate the **rip** context. (See “Context Initiation” on page 575.)

### **Syntax**

```
get rules-redistribute
```

### **Keywords and Variables**

None.

## ***summary***

Use the **summary** command to display summary routes configured with the **summary-ip** command.

Before you can execute the **summary** command, you must initiate the **rip** context. (See “Context Initiation” on page 575.)

### **Syntax**

```
get summary
```

### **Keywords and Variables**

None.

## ***summary-ip***

Use the **summary-ip** commands to summarize the routes that are advertised by RIP. You enable the advertising of summary routes on a per-interface basis.

Before you can execute the **summary-ip** commands, you must initiate the **rip** context. (See “Context Initiation” on page 575.)

### **Syntax**

```
set summary-ip ip_addr/mask [metric number]
```

### **Keywords and Variables**

#### ***Variable Parameter***

```
set summary-ip ip_addr/mask
unset summary-ip ip_addr/mask
```

*ip\_addr/mask*    The summary range that encompasses constituent routes.

**metric**

set summary-ip *ip\_addr/mask* [ *metric number* ]

**metric** Specifies the metric for the summary route. If no metric is specified, the largest metric for a constituent route is used.

**threshold-update**

Use the **threshold-update** commands to set the maximum number of routing packets received and processed per update interval, per neighbor.

Before you can execute the **threshold-update** commands, you must initiate the **rip** context. (See “Context Initiation” on page 575.)

**Syntax**

set threshold-update *number*

**Keywords and Variables****Variable Parameter**

set threshold-update *number*

**number** The maximum number of routing packets allowed per update interval. This value must be greater than zero.

**timer**

Use the **timer** command to display information about various RIP timers.

Before you can execute the **timer** command, you must initiate the **rip** context. (See “Context Initiation” on page 575.)

**Syntax**

get timer

**Keywords and Variables**

None.

## *trusted-neighbors*

Use the **trusted-neighbors** commands to specify an access list that defines allowed RIP neighbors.

Before you can execute the **trusted-neighbors** commands, you must initiate the **rip** context. (See “Context Initiation” on page 575.)

### Syntax

#### *get*

get trusted-neighbors

#### *set*

set trusted-neighbors *id\_num*

### Keywords and Variables

#### *Variable Parameter*

set trusted-neighbors *id\_num*

*id\_num*            The number of the access list that defines the allowed RIP neighbors.

## *update-timer*

Use the **update-timer** commands to set the interval that RIP sends route updates to neighbors.

Before you can execute the **update-timer** commands, you must initiate the **rip** context. (See “Context Initiation” on page 575.)

### Syntax

set update-timer *number*

### Keywords and Variables

#### *Variable Parameter*

set update-timer *number*

*number*            The interval, in seconds, that RIP sends route updates to neighbors. This value must be at least one, and no greater than the current **invalid-timer** value. The default is 30 seconds.

## ***update-threshold***

Use the **update-threshold** command to display the number of routing packets per update interval.

Before you can execute the **update-threshold** command, you must initiate the **rip** context. (See “Context Initiation” on page 575.)

### **Syntax**

```
get update-threshold
```

### **Keywords and Variables**

None.

## ***version***

Use the **version** commands to set the RIP protocol version in the virtual router.

Before you can execute the **version** commands, you must initiate the **rip** context. (See “Context Initiation” on page 575.)

### **Syntax**

```
set version { v1 | v2 }
```

### **Keywords and Variables**

**v1 | v2**

```
set version v1 | v2
```

v1 | v2

Sets the RIP protocol version in the virtual router and on all RIP interfaces to either version 1 or version 2. The default is version 2. You can override the protocol version on a per-interface basis.



# route

Use the **route** commands to display entries in the static route table.

The **get route** command displays the IP address, netmask, interface, gateway, protocol, preference, metric, owner vsys, and description.

The value of **protocol** can be any of the following:

- **C**—Connected
- **S**—Static
- **A**—Auto Exported
- **D**—Auto Discovered
- **I**—Imported from another virtual router
- **iB**—internal BGP
- **eB**—external BGP
- **H**—Host
- **N**—NHRP
- **O**—OSPF
- **P**—Permanent
- **R**—RIP
- **E1**—OSPF external type 1
- **E2**—OSPF external type 2

Use the **get route** command to see if the security device has a route to the IP address on the correct interface.

## Syntax

---

### *get*

```
get route
 [
 id id_num |
 ip [ip_addr] |
 prefix ip_addr/mask |
 protocol { bgp | connected | discovered | imported | nhrp | ospf | rip | static [
 description] } |
 source [description | id number | in-interface | ip ip_addr | prefix ip_addr/mask] |
 summary
]
```

## Keywords and Variables

---

### *id*

```
get route id id_num
```

*id*                      Displays a specific route for the ID number *id\_num*.

**Example:** The following command displays the route information for a route with ID number 477:

```
get route id 477
```

### *in-interface*

```
get route source in-interface
```

*in-interface*            Displays Source Interface-Based Routes (SIBR) routes.

### *ip*

```
get route ip ip_addr
```

*ip*                        Displays a specific route for the target IP address (*ip\_addr*).

**Example:** The following command displays the route information to a machine with the IP address 172.16.60.1:

```
get route ip 172.16.60.1
```

### *prefix*

```
get route prefix ip_addr/mask
```

*prefix*                    Displays routes within a specified subnet (*ip\_addr/mask*).

**Example:** The following command displays the routes within the subnet 1.1.1.1/24:

```
get route prefix 1.1.1.1/24
```

## **protocol**

```
get route protocol { bgp | connected | discovered | imported | ospf | rip | static [
 description] }
```

|          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
|----------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| protocol | Specifies the routing protocol and directs the security device to display the routes derived from that protocol. <ul style="list-style-type: none"> <li>■ <b>bgp</b>—Directs the device to display Border Gateway Protocol (BGP) routes.</li> <li>■ <b>connected</b>—Directs the device to display only routes sent from an external router that has at least one interface with an IP address assigned to it.</li> <li>■ <b>discovered</b>—Directs the device to display discovered routes.</li> <li>■ <b>imported</b>—Directs the device to display imported routes.</li> <li>■ <b>nhpp</b>—Directs the device to display Next Hop Resolution Protocol (NHRP) routes.</li> <li>■ <b>rip</b>—Directs the device to display Routing Information Protocol (RIP) routes.</li> <li>■ <b>ospf</b>—Directs the device to display only Open Shortest Path First (OSPF) routes.</li> <li>■ <b>static</b>—Directs the device to display only static routes. <ul style="list-style-type: none"> <li>■ <b>description</b>—Displays destination static routes with descriptions.</li> </ul> </li> </ul> |
|----------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

## **source**

```
get route source [description | id number | in-interface | ip ip_addr | prefix
 ip_addr/mask]
```

|        |                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|--------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| source | Displays source routes. <ul style="list-style-type: none"> <li>■ <b>description</b>—Displays source static routes with descriptions.</li> <li>■ <b>id <i>number</i></b>—Shows a particular source route.</li> <li>■ <b>in-interface</b>—Shows source interface-based routes (SIBR).</li> <li>■ <b>ip <i>ip_addr</i></b>—Shows a route for a particular IP address.</li> <li>■ <b>prefix <i>ip_addr/mask</i></b>—Shows routes within a subnet.</li> </ul> |
|--------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

## **summary**

```
get route summary
```

|         |                                                                              |
|---------|------------------------------------------------------------------------------|
| summary | Displays summary information, including number of routes, for each protocol. |
|---------|------------------------------------------------------------------------------|

## **Defaults**

The **get route** command displays all entries in the route table unless a particular target IP address is specified.



# sa

Use the **sa** commands to display active or inactive security associations (SAs) or to clear a specified SA. Each SA has a unique ID. The security device saves and displays the SA IDs in hexadecimal format.

A SA is a unidirectional agreement between virtual private network (VPN) participants describing the methods and parameters the participants will use to secure a communications channel. Full bidirectional communication requires at least two SAs, one for each direction.

An SA groups together the following components for securing communications:

- Security algorithms and keys
- Protocol mode (Transport or Tunnel)
- Key management method Manual Key or AutoKey Internet Key Exchange (IKE)
- SA lifetime

For outbound VPN traffic, a security policy invokes the SA associated with the VPN tunnel. For inbound traffic, the security device looks up the SA by using the following triplet: destination IP, security protocol (AH or ESP), and security parameter index (SPI) value, which are sent to the peer in the first message of a Phase 1 IKE exchange.

## Syntax

---

### **clear**

```
clear [cluster] sa id_num
```

### **get**

```
get sa
 [
 id id_num |
 active | inactive
 [stat] |
 stat
]
```

## Keywords and Variables

---

### **Variable Parameter**

clear [ cluster ] sa *id\_num*

*id\_num* Specifies a security association (SA) ID number.

### **active**

get sa active [ stat ]

active Displays the active SA(s).

### **cluster**

clear cluster sa *id\_num*

cluster Propagates the **clear** operation to all other devices in an NSRP cluster.

### **id**

get sa id *id\_num*

id Displays an SA entry for the specified ID number (*id\_num*).

### **inactive**

get sa inactive [ stat ]

inactive Displays the inactive SA(s).

### **stat**

get sa [ active | inactive ] stat

stat Shows the SA statistics for the device. Also displays active or inactive SA statistics.

Displays these statistics for all incoming or outgoing SA pairs:

- **Fragment:** The total number of fragmented incoming and outgoing packets.
- **Auth-fail:** The total number of packets for which authentication has failed.
- **Other:** The total number of miscellaneous internal error conditions other than those listed in the auth-fail category.
- **Total Bytes:** The amount of active incoming and outgoing traffic

# sa-filter

Use the **sa-filter** commands to debug messages for each Security Association (SA) filter.

## Syntax

---

### **get**

```
get sa-filter
```

### **set**

```
set sa-filter ip_addr
```

### **unset**

```
unset sa-filter { ip_addr | all }
```

## Keywords and Variables

---

### **Variable Parameter**

```
set sa-filter ip_addr
unset sa-filter ip_addr
```

*ip\_addr* Specifies an Internet Protocol address (IP Address) for the SA to filter.

### **all**

```
unset sa-filter all
```

**all** Unsets all SA filters.



# sa-statistics

Use the **sa-statistics** command to clear all statistical information (such as the number of fragmentations and total bytes through the tunnel) in a security association (SA) for an AutoKey Internet Key Exchange virtual private network (IKE VPN) tunnel.

## Syntax

---

### **clear**

```
clear [cluster] sa-statistics [id id_num]
```

## Keywords and Variables

---

### **cluster**

```
clear cluster sa-statistics [id id_num]
```

**cluster**            If the security device is in a high availability (HA) configuration, propagates the **clear** operation to all other devices in the NetScreen Redundancy Protocol (NSRP) cluster.

### **id**

```
clear [cluster] sa-statistics id id_num
```

**id**                Clears the statistics for a particular SA (*id\_num*).



# sat

Use the **sat** commands to display the counter information of ASICs used in high-end platforms. These commands provide details about ASIC counters such as Q pointers, buffers, and number of packets forwarded to the CPU.

## Syntax

---

### **get**

```
get sat number
{
 counters |
 demux-counter |
 frq1 |
 session |
 x-context |
}
```

## Keywords and Variables

---

### **Variable Parameter**

```
get sat number
```

*number* Specifies the ASIC identified by the Saturn ID.

### **counters**

```
get sat number counter
```

counter Displays information about the read-write pointers and the full counters of each queue in an ASIC.

### **demux-counter**

```
get sat number demux-counter
```

demux-counter Specifies the number of unique demux packets forwarded to the CPU.

### **frq1**

get sat *number* frq1

frq1                      Displays the status of free buffer queue. Use the command to check for presence of leak in the buffer queue.

### **session**

get sat *number* session

session                      Displays the total number of allocated Hardware sessions.

### **x-context**

get sat *number* x-context

x-context                      Displays records of various memory tables, table addresses, and reset counters in an ASIC.

# save

Use the **save** commands to save ScreenOS images to a security device and to save device configuration settings to or from a security device. You can also use this command to save the authentication certificate to the security device for authenticating ScreenOS images, transfer files to or from a security device, and attack object database downloads for Deep Inspection (DI).

## Syntax

---

### save

```
save
[
 attack-db from tftp ip_addr filename to flash [from interface] |
 config
 [
 all-virtual-system |
 to
 {
 flash [merge] |
 last-known-good |
 slot1 filename |
 tftp ip_addr filename |
 usb filename
 }
]
 from
 {
 flash |
 slot1 filename |
 tftp ip_addr filename
 {
 merge |
 to
 {
 flash [from interface] |
 last-known-good |
 slot1 filename |
 tftp ip_addr filename [from interface]
 }
 }
]
 [from interface] |
 usb filename |
] |
```

```

file filename
from
{
 slot1 filename |
 tftp ip_addr filename [from interface] |
 usb filename
}
to
{
 slot1 filename |
 tftp ip_addr filename [from interface] |
 usb filename
} |
image-key
{ tftp ip_addr filename [from interface] |
 usb filename } |
software from
{
 flash |
 slot1 filename |
 tftp ip_addr filename |
 usb filename
}
to
{
 flash |
 slot1 filename |
 tftp ip_addr filename |
 usb filename
}
[from interface]
]

```

## Keywords and Variables

---

### ***all-virtual-system***

save config all-virtual-system

all-virtual-system      Saves all virtual system configurations.

### ***attack-db***

save attack-db from tftp *ip\_addr filename* to flash [ from *interface* ]

attack-db              Saves the attack database to the security device.

### ***flash***

save config from { ... } to flash [ from *interface* ]  
 save config from flash to { ... } [ from *interface* ]  
 save software from flash to { ... } [ from *interface* ]

save software from { ... } flash to [ from *interface* ]

**flash** Saves from (or to) flash memory. The **from** *interface* option specifies the source interface if you specify TFTP.

**Example:** The following command saves the current configuration from flash memory to a file (output.txt) on a TFTP server (172.16.10.10):

**save config from flash to tftp 172.16.10.10 output.txt**

### **from { ... } to**

save config from { ... } to { ... }  
 save software from { ... } to { ... }  
 save file *filename* from { ... } to { ... }

**from** Saves from the specified source.

**to** Saves to the specified destination.

**Example:** The following command saves the current configuration from flash memory to a file (output.txt) on a TFTP server (IP address 172.16.10.10):

**save config from flash to tftp 172.16.10.10 output.txt**

### **image-key**

save image-key from tftp *ip\_addr filename*

**image-key** Saves the authentication certificate (imagekey.cer) to the security device. After you save this certificate onto the security device, the device uses it to verify the integrity of ScreenOS images when you save them to the device and when it reboots. The security device also uses this certificate to verify the integrity of Deep Inspection (DI) attack object database files during the download process.

The authentication certificate is available on the Documentation CD-ROM that ships with each security device. It is also available online at the Juniper Networks Web site. Log in at [www.juniper.net/support/](http://www.juniper.net/support/), click **ScreenOS Software** in the Download Software section, and click **Download the Authentication Certificate** at the top of the page.

Saving this certificate onto a security device automatically causes the device to perform authentication checks on ScreenOS images and DI attack object database downloads. To stop these checks, you must remove the authentication certificate, using the **delete crypto auth-key** command.

### **last-known-good**

save config to last-known-good

**last-known-good** Saves the current configuration to flash memory as the LKG (last-known-good) configuration. The security device can revert to this LKG file by doing a configuration rollback. The security device automatically names the LKG file *SLKGS.cfg*. You cannot rename the LKG file or give it a different name upon saving it.

## merge

```
save config from { ... } merge [from interface]
```

**merge** Merges the saved configuration with the current configuration. The **from *interface*** option specifies the source interface.

**Example:** The following command merges the current configuration with the configuration in a file (input.txt) on a TFTP server (IP address 172.16.10.10):

```
save config from tftp 172.16.10.10 input.txt merge
```

## slot1

```
save config from { ... } to slot1 [...]
save config from slot1 to { ... }
save file filename from { ... } to slot [...]
save file filename slot1 to { ... }
save software from slot1 to { ... }
save software from { ... } to slot1 [...]
```

**slot1** Saves from (or to) a file in the memory card slot.

**Example:** The following commands saves the current configuration from a file (input.txt) in the slot1 memory card to flash memory:

```
save config from slot1 input.txt to flash
```

## tftp

```
save config from tftp filename to { ... } [from interface]
save file filename from tftp ip_addr filename [from interface] to { ... }
save image-key tftp ip_addr filename
save software from tftp filename to { ... } [from interface]
```

**tftp** Saves from (or to) a file on a TFTP server.

**Example:** The following command saves an authentication certificate onto a security device from a file named **imagekey.cer** on a TFTP server at **10.10.1.2**:

```
save image-key tftp 10.10.1.2 nskey.cer
```

## usb

```
save config from usb filename to { ... }
save file filename usb filename to { ... }
save image-key usb filename
save software from usb filename to { ... }
```

**usb** Saves from (or to) a file on a USB key using the USB host module.

**Example:** The following command saves the file named **nskey.txt** to the USB storage device:

```
save image-key usb nskey.txt
```

# scheduler

Use the **scheduler** commands to create or modify a schedule or to display the settings in a schedule.

A *schedule* is a configurable object that you can use to define when policies are in effect. Security devices use schedules to enforce the policies at specified times or intervals. Through the application of schedules, you can control network traffic flow and enforce network security.

## Syntax

---

### **get**

```
get scheduler [name name_str | once | recurrent]
```

### **set**

```
set scheduler name_str
[
 once start date time stop date time [comment string] |
 recurrent
 { monday | tuesday | wednesday | thursday | friday | saturday | sunday
 start time stop time
 }
 [start time stop time]
 [comment string]
]
```

## Keywords and Variables

---

### **name**

```
get scheduler name name_str
```

name *name\_str* Defines a name for the schedule.

**once**

```
get scheduler once
set scheduler name_str once start date time stop date time [...]
```

once                    Apply the schedule once, starting on the day, month, year, hour, and minute defined, and stopping on the month, day, year, hour, and minute defined.

**recurrent**

```
get scheduler recurrent
set scheduler name_str recurrent { ... } [...]
```

recurrent              Directs the security device to repeat the schedule according to the defined day of the week, hour, and minutes.

- **monday** Repeats every Monday.
- **tuesday** Repeat every Tuesday.
- **wednesday** Repeat every Wednesday.
- **thursday** Repeat every Thursday.
- **friday** Repeat every Friday.
- **saturday** Repeat every Saturday.
- **sunday** Repeat every Sunday.
- **start**—Defines when to start the schedule.
- **stop**—Defines when to stop the schedule.
- **comment**—Defines a descriptive character string.

**start | stop**

```
set scheduler name_str once start date time stop date time [...]
set scheduler name_str recurrent { ... } start time stop time [...]
```

start | stop            Defines the day, month, and year (*date*) in USA format (mm/dd/yyyy).  
                           Defines the hour and minutes (*time*) in the 24-hour clock format (hh:mm).

**Example 1:** The following command creates a schedule definition named **mytime**, which starts on 1/10/2003 at 11:00 AM and ends on 2/12/2003 at 7:00 PM:

```
set scheduler mytime once start 1/10/2003 11:00 stop 2/12/2003 19:00
```

**Example 2:** The following command creates a schedule definition named **weekend**, which starts at 8:00 AM and ends at 5:00 PM and repeats every Saturday and Sunday:

```
set scheduler weekend recurrent saturday start 8:00 stop 17:00
set scheduler weekend recurrent sunday start 8:00 stop 17:00
```

# scp

Use the **scp** commands to configure the Secure Copy (SCP) client/server on security devices. SCP provides a way of transferring files to or from the security device using the SSH protocol.

---

**NOTE:** It is possible to initiate file transfer from an external host, not from the security device itself.

---

## Syntax

---

### *get*

get scp

### *set*

set scp enable

## Keywords and Variables

---

### *enable*

set scp enable  
unset scp enable

enable      Enables the Secure Copy (SCP) task. When SCP is enabled, the SSH task is activated if it is not already active.



# service

Use the **service** commands to create custom service definitions, modify existing service definitions, or display the current entries in the service definition list.

Use service definitions in policies to specify how the security device provides a service during a secure session. For example, a custom service definition might permit sessions using TCP protocol to exchange traffic between specified source and destination ports. Any policy that uses this definition conforms to these specifications.

## Syntax

---

### *get*

```
get service
 [
 svc_name |
 group [name_str] |
 pre-defined |
 timeout { other | tcp | udp } [port number1 [number2]] |
 user
]
```

### *set*

```
set service svc_name
 {
 +
 {
 icmp type number code number |
 ptcl_num | tcp | udp
 { src-port number-number dst-port number-number }
 ms-rpc uuid UUID_string |
 sun-rpc { program id_num1-id_num2 }
 } |
 protocol
 {
 { ptcl_num | tcp | udp }
 [src-port number-number]
 [dst-port number-number [timeout { number | never }]]
 icmp type number code number |
 ms-rpc { uuid UUID_string [timeout { number | never }] } |
 sun-rpc
 { program id_num1-id_num2 }
```

```

 [timeout { number | never }]
 } |
 timeout { number | never | unit 10sec }
}

```

## Keywords and Variables

---

### Variable Parameters

```

get service svc_name
set service svc_name [...]
unset service svc_name

```

*svc\_name*            Identifies a service by name.

+

```
set service svc_name + { ... }
```

+                    Appends a service entry to the custom services list.

### pre-defined

```
get service pre-defined
```

pre-defined        Displays all the predefined services.

### protocol

```
set service svc_name protocol { ... } [...]
```

protocol            Defines the service by IP protocol.

                    Defines a protocol for the specified service.

- **ptcl\_num** specifies the protocol by protocol number.

- **icmp** specifies a ICMP-based service.

- **type** identifies the ICMP message type, for example, "Destination Unreachable".

- **code** identifies a specific message from a ICMP message type group. For example, from the Destination Unreachable type group, there are various more specific messages identified by code such as Net Unreachable, Host Unreachable, Protocol Unreachable, and so on.

- **ms-rpc** specifies a Microsoft RPC service.

- **uuid** specifies the interface (16 bytes).

- **sun-rpc** specifies a Sun RPC service

- **program** specifies the program (32 bit integer).

- **tcp** specifies a TCP-based service.

- **udp** specifies a UDP-based service.

**Example:** The following command sets a service named **ipsec** that uses protocol 50:

```
set service ipsec protocol 50
```

### *src-port / dst-port*

```
set service svc_name protocol { ... }
 [src-port number-number] [dst-port number-number]
```

src-port            Defines a range of source port numbers valid for the service and protocol.

dst-port            Defines a range of destination port numbers valid for the service and protocol.

**Example:** The following command sets a service named **test1** that uses destination TCP port 1001:

```
set service test1 protocol tcp src-port 0-65535 dst-port 1001-1001
```

### *timeout*

```
get service timeout { other | tcp | udp } [port number1 [number2]]
set service svc_name timeout { number | never | unit 10sec }
unset service svc_name timeout unit
```

timeout            Sets or displays the timeout value for sessions created on a port for TCP, UDP, or other protocols. You can set a service to timeout in minutes (*number*) or in ten-second units (**unit 10sec**), or **never**. Note, however, that the **10sec** timeout setting is supported only in single-service policies. In policies with more than one service, the 10sec timeout setting is ignored.

**Example 1:** The following commands set the session timeout for BGP to 30 seconds:

```
set service bgp timeout unit 10sec
```

```
set service bgp timeout 3
```

**Example 2:** The following command is a service named **telnet** with a timeout value of **10** minutes:

```
set service telnet timeout 10
```

**Example 3:** The following command displays timeouts for *UDP* from port *1720* to *1800*:

```
get service timeout udp port 1720 1800
```

### *user*

```
get service user
```

user                Displays all user-defined services.

## **Defaults**

The default timeout for TCP connections is *30* minutes.

The default timeout for UDP connections is *1* minute.

---

**NOTE:** The maximum timeout value for TCP connections and UDP connections is 2160 minutes.

---

Using the **get service** command without any arguments displays all predefined, user-defined, and service-group information in the service book.

# session

Use the **session** commands to clear or display entries in the session table of the security device.

The *session table* contains information about individual sessions between hosts that communicate through the security device. Because each session entry uniquely identifies two communicating hosts, it contains a unique combination of the following criteria:

- Individual IP address for the source host (no subnets with multiple addresses)
- Individual IP address for the destination host (no subnets with multiple addresses)
- Individual port number for the source host (not a range of ports)
- Individual port number for the destination host (not a range of ports)

Every time the security device initiates a new session, it creates a session entry and uses the information in the entry while processing subsequent traffic between the hosts.

The kind of session information listed by the **get session** command depends upon the platform. (For example, on a platform with a management module in slot 1, the **get session** command lists currently active sessions on that module.) Such sessions include management, log, and other administrative traffic. On any security device with one or more Secure Port Modules (SPMs), the **get session** command lists sessions that are active on the ASIC for each module. If a session crosses two ASICs, it counts as two sessions, one for each ASIC.

## Syntax

---

### *clear*

```
clear [cluster] session
 [
 all |
 id id_num |
 [src-ip ip_addr [netmask mask]]
 [dst-ip ip_addr [netmask mask]]
 [src-mac mac_addr] [dst-mac mac_addr]
 [policy id pol-num]
 [protocol ptcl_num [ptcl_num]]
```

```

 [src-port port_num [port_num]]
 [dst-port port_num [port_num]]
 [vsd-id id_num] [[vsys-name name_str] | [vsys-id id_num]]
]

```

**get**

```

get session
 [
 id id_num |
 ike-nat |
 info |
 rm |
 service name_str | [tunnel]
 [hardware [0 | 1 | 2 | 3 | 4 | 5]] |
 [policy id pol-num]
 [src-ip ip_addr [netmask mask]]
 [dst-ip ip_addr [netmask mask]]
 [src-mac mac_addr] [dst-mac mac_addr]
 [protocol ptcl_num [ptcl_num]]
 [src-port port_num [port_num]]
 [dst-port port_num [port_num]]
 [vsd-id number] [hardware] [0 | 1 | 2 | 3 | 4 | 5]]
]

```

## Keywords and Variables

---

**all**

```
clear [cluster] session all
```

**all** Specifies all sessions.

**cluster**

```
clear cluster session [...]
```

**cluster** Propagates the **clear** operation to all other devices in an NSRP cluster.

**id**

```
clear [cluster] session id id_num
get session id id_num
```

**id** *id\_num* Identifies a specific session with Session Identification number *id\_num*.

**Example:** The following command displays the session table entry for the session with ID 5116:

```
get session id 5116
```



```
get session [...] [src-ip ip_addr [netmask mask]]
 [dst-ip ip_addr [netmask mask]] [...]
```

**src-ip *ip\_addr*** Identifies all sessions initiated by packets containing source IP address *ip\_addr*. For example, *ip\_addr* could be the source IP address in the first TCP SYN packet.

**dst-ip *ip\_addr*** Identifies all sessions initiated by packets containing destination IP address *ip\_addr*.

**Example:** The following command displays all the entries in the session table for a specific source IP address:

```
get session src-ip 172.16.10.92
```

### ***src-mac / dst-mac***

```
clear [cluster] session [...] [dst-ip ip_addr [netmask mask]]
 [src-mac mac_addr] [dst-mac mac_addr]
get session [...] [src-ip ip_addr [netmask mask]]
 [dst-ip ip_addr [netmask mask]]
```

**src-mac** Identifies all sessions initiated by packets containing source MAC address *mac\_addr*.

**dst-mac** Identifies all sessions initiated by packets containing destination MAC address *mac\_addr*.

### ***protocol***

```
clear [cluster] session [...] protocol ptcl_num [ptcl_num] [...]
get session [...] protocol ptcl_num [ptcl_num] [...]
```

**protocol** Identifies all sessions that use protocol *ptcl\_num*.  
You can also specify any protocol within a range (*ptcl\_num ptcl\_num*).

### ***src-port / dst-port***

```
clear [cluster] session [...] [src-port port_num [port_num]]
 [dst-port port_num [port_num]] [...]
get session [...] [src-port port_num [port_num]]
 [dst-port port_num [port_num]]
```

**src-port** Identifies all sessions initiated by packets that contain the Layer 4 source port *port\_num* in the Layer 4 protocol header.  
You can also specify any Layer 4 destination port within a range (*port\_num port\_num*).

**dst-port** Identifies all sessions initiated by packets that contain the Layer 4 destination port *port\_num* in the Layer 4 protocol header.  
You can also specify any Layer 4 destination port within a range (*port\_num port\_num*).

**Example:** The following command displays all the entries in the session table for protocol 5 and for source ports 2 through 5:

```
get session protocol 5 src-port 2 5
```

**tunnel**

```
get session tunnel [...]
```

tunnel            Directs the security device to display tunnel sessions.

**vsd-id**

```
clear [cluster] session [...] vsd-id id_num
clear [cluster] session [...]
get session [...] vsd-id id_num [hardware] [0 | 1 | 2 | 3 | 4 | 5]
```

*vsd-id id\_num*            Identifies all sessions that belong to the VSD group *id\_num*. The keyword **hardware** displays hardware sessions and, optionally, information about sessions on specific hardware acceleration chips, as follows:

- 0—Shows asic 0 sessions.
- 1—Shows asic 1 sessions.
- 2—Shows asic 2 sessions.
- 3—Shows asic 3 sessions.
- 4—Shows asic 4 sessions.
- 5—Shows asic 5 sessions.

**Example:** The following command clears all sessions belonging to VSD group 2001, and initiated from the host at IP address 172.16.10.12:

```
clear session src-ip 172.16.10.12 vsd-id 2001
```

**vsys-name**

```
clear [cluster] session [...] vsys-name name_str
```

*vsys-name*            Identifies all sessions that belong to a specified vsys.

**vsys-id**

```
clear [cluster] session [...] vsys-id id_num
```

*vsys-id*            Identifies all sessions of a vsys with the vsys identification number *id\_num*.



# shdsl

Use the **shdsl** commands to set the mode and query VPI statistics for an SHDSL interface.

## Syntax

---

### **exec**

```
exec shdsl slot slot_num pic-mode { 1-port-atm | 2-port-atm }
```

### **get**

```
get shdsl slot_num port_num vc-info
```

## Keywords and Variables

---

### **pic-mode**

```
exec shdsl slot slot_num pic-mode { 1-port-atm | 2-port-atm }
```

pic-mode            Specifies the pic mode:

- **1-port-atm**—Specifies single-port ATM, 4-wire mode.
- **2-port-atm**—Specifies two-port ATM, 2-wire mode.

**Example:** The following command configures the SHDSL interface for two-port ATM, two-wire mode:

```
exec shdsl slot 1 pic-mode 2-port-atm
```

### **vc-info**

```
get shdsl slot_num port_num vc-info
```

vc-info            ■ Displays a table of PVC information for the selected SHDSL interface.

**Example:** The following command displays pvc information for the shdsl1/1 interface:

```
exec shdsl 1 1 pic-mode 2-port-atm
```



# sm-ctx

Use the **sm-ctx** commands to view the status of security modules (SM) on your security device.

## Syntax

---

### *get*

```
get sm-ctx { pkt | status }
```

## Keywords and Variables

---

### *sm-ctx*

get sm-ctx status

pkt

Displays security module's packet counts in the following four columns of output:

- **SM**—Security module number.
- **TX**—Packet number sent to the security module (16 bits counter).
- **RX**—Packet number received from the security module (16 bits counter).
- **SN**—Security module's engine start number. Typically, it is **1** (initial start). Each time you restart the engine restart (crash), this counter is incremented by 1.

sm-ctx status

Displays information about the security modules in your security device in the following four columns of output:

- **SM CPU**—Displays the CPU numbers for each security module. CPU 1 and 2 are in security module 1, CPU 3 and 4 are in security module 2, and CPU 5 and 6 are in security module 3.
- **aval**—If a security module is functioning properly, **1** appears in this column. If a security module does not occupy one of the security module slots or if it is malfunctioning, column 2 shows **0**.
- **ena**—Always shows the number 1.
- **Sess\_cnt**—Lists the number of sessions running on the CPUs on each security module.



# sm-ksh

Use the **sm-ksh** commands to configure commands that run using the k-shell (**ksh**) of the QNX operating system on the security module.

## Syntax

---

### set

```
exec sm num ksh "scio const set sc_debug_services_counter value"
exec sm num ksh "scio const set sc_gre_decapsulation value"
exec sm num ksh "scio const set sc_gtp_decapsulation value"
exec sm num ksh "scio const set sc_gtp_session_timeout value"
exec sm num ksh "scio const set sc_log_all_attack_matches value"
exec sm num ksh "scio const set sc_log_include_rule_action value"
exec sm num ksh "scio const set sc_log_drop_pkt_for_tcp value"
exec sm num ksh "scio const set sc_pcomp_unload_cur_on_low_mem value"
exec sm num ksh "scio const set sc_policy_size_multiplier value"
exec sm num ksh "scio const set sc_ppp_in_gre_timeout value"
exec sm num ksh "scio const set sc_tcpdecomp_timeout value"
```

### get

```
exec sm num ksh "scio const get sc_gre_decapsulation"
exec sm num ksh "scio const get sc_gtp_decapsulation"
exec sm num ksh "scio const get sc_gtp_session_timeout"
exec sm num ksh "scio const get sc_log_all_attack_matches"
exec sm num ksh "scio const get sc_log_include_rule_action"
exec sm num ksh "scio const get sc_log_drop_pkt_for_tcp"
exec sm num ksh "scio const get sc_pcomp_unload_cur_on_low_mem"
exec sm num ksh "scio const get sc_policy_size_multiplier"
exec sm num ksh "scio const get sc_ppp_in_gre_timeout"
exec sm num ksh "scio const get sc_tcpdecomp_timeout"
```

### ffilter

```
exec sm num ksh "scio ffilter {
 add {
 [src-ip ip_addr] |
 [src-port num] |
 [dst-ip ip_addr] |
 [dst-port num] |
 [proto protocol]
 } |
 del [id num] |
}
```

```
list |
clear }"
```

## **subs**

```
exec sm num ksh "scio subs status number"
exec sm num ksh "scio subs service detail number"
exec sm num ksh "scio subs service reset number"
```

## Keywords and Variables

---

### **ffilter**

|              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|--------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <i>add</i>   | Creates a flow debug filter for the IDP traffic with the following parameters: <ul style="list-style-type: none"> <li>■ <i>src-ip ip_addr</i>—Specifies the source address of the IDP traffic.</li> <li>■ <i>src-port num</i>—Specifies the source port of the IDP traffic.</li> <li>■ <i>dst-ip ip_addr</i>—Specifies the destination address of the IDP traffic.</li> <li>■ <i>dst-port num</i>—Specifies the destination port of the IDP traffic.</li> <li>■ <i>protocol protocol</i>—Specifies the protocol number of the IDP traffic.</li> </ul> |
| <i>del</i>   | Deletes a specific flow debug filter rule for IDP traffic <ul style="list-style-type: none"> <li>■ <b>id num</b>—Specifies the flow filter rule ID for the IDP traffic</li> </ul>                                                                                                                                                                                                                                                                                                                                                                     |
| <i>list</i>  | Lists all flow debug filter rules for IDP traffic                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| <i>clear</i> | Clears all flow debug filter rules for IDP traffic                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |

### **sc\_debug\_services\_counter**

|              |                                                                                                                                                                                   |
|--------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <i>num</i>   | Security module number.                                                                                                                                                           |
| <i>value</i> | Initiates the session counter for the security module. The security module turns on the count session per protocol if the value is 1 and off if the value is 0. The default is 1. |

**Example:** The following command configures the policy size multiplier value of security module 2 to 200.

```
exec sm 1 ksh "scio const set sc_debug_services_counter 1"
For cpu 0
scio: setting sc_debug_services_counter to 0x1
For cpu 1
scio: setting sc_debug_services_counter to 0x1
```

### **sc\_gre\_decapsulation**

|              |                                                                                                                                                                         |
|--------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <i>num</i>   | Security module number.                                                                                                                                                 |
| <i>value</i> | Enables or disables the <b>sc_gre_decapsulation</b> feature. When the value is 1, the security module enables GRE inspection. By default, this feature is disabled (0). |

**sc\_gtp\_decapsulation**

|              |                                                                                                                                                                         |
|--------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <i>num</i>   | Security module number.                                                                                                                                                 |
| <i>value</i> | Enables or disables the <b>sc_gtp_decapsulation</b> feature. When the value is 1, the security module enables GTP inspection. By default, this feature is disabled (0). |

**sc\_gtp\_session\_timeout**

|              |                                                                                                                                               |
|--------------|-----------------------------------------------------------------------------------------------------------------------------------------------|
| <i>num</i>   | Security module number.                                                                                                                       |
| <i>value</i> | Specifies the timeout value in seconds for entries in the GTP session table. The default timeout value is 3600; the range is 1 to 0xffffffff. |

**sc\_log\_all\_attack\_matches**

|              |                                                                                                                                                                                                                                                                                                                                                |
|--------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <i>num</i>   | Security module number.                                                                                                                                                                                                                                                                                                                        |
| <i>value</i> | Enables or disables the <b>sc_log_all_attack_matches</b> feature. When the value is 1, the security module logs all the attack matches that were found during packet inspection. When the value is 0, the security module logs only the attack match with the most severe action. By default, this feature is enabled (the value is set to 1). |

**sc\_log\_include\_rule\_action**

|              |                                                                                                                                                                                                                                                                                                                                                          |
|--------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <i>num</i>   | Security module number.                                                                                                                                                                                                                                                                                                                                  |
| <i>value</i> | Enables or disables the <b>sc_log_include_rule_action</b> feature. When the value is 1, the security module sets the action field of the attack modules to the rule action. When the value is 0, the security module sets the action field of all attack modules to the most severe action. By default, this feature is enabled (the value is set to 1). |

**sc\_log\_drop\_pkt\_for\_tcp**

|              |                                                                                                                                                                                                                                                                              |
|--------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <i>num</i>   | Security module number.                                                                                                                                                                                                                                                      |
| <i>value</i> | Enables or disables the <b>sc_log_drop_pkt_for_tcp</b> feature. When the value is 0, IDP promotes the drop packet option to DROP. When the value is 1, the IDP does not promote the drop packet option to DROP. By default, this feature is enabled (the value is set to 1). |

**sc\_pcomp\_unload\_cur\_on\_low\_mem**

|            |                         |
|------------|-------------------------|
| <i>num</i> | Security module number. |
|------------|-------------------------|

*value* Enables or disables the **sc\_pcomp\_unload\_cur\_on\_low\_mem** feature. When the value is 1, the security module unloads the current active policy when it loads a new policy. By default, this feature is disabled (the value is set to 0).

**Example:** The following command displays the **sc\_pcomp\_unload\_cur\_on\_low\_mem** value of security module 2.

```
exec sm 2 ksh "scio const get sc_pcomp_unload_cur_on_low_mem"
For cpu 0
scio: sc_pcomp_unload_cur_on_low_mem = 0x0
For cpu 1
scio: sc_pcomp_unload_cur_on_low_mem = 0x0
```

### ***sc\_policy\_size\_multiplier***

*num* Security module number.

*value* Sets the policy-size multiplier value for the security module. The security module estimates the memory required to compile a policy file by multiplying the size of the policy by the policy-size multiplier value. The default value is 300.

**Example:** The following command configures the policy-size multiplier value of security module 2 to 200.

```
exec sm 2 ksh "scio const set sc_policy_size_multiplier 200"
For cpu 0
scio: setting sc_policy_size_multiplier to 0xc8
For cpu 1
scio: setting sc_policy_size_multiplier to 0xc8
```

### ***sc\_ppp\_in\_gre\_timeout***

*num* Security module number.

*value* Specifies the timeout value, in minutes, for entries in the PPP decapsulation hash table. The default timeout value is 30; the range is 1 to 60.

### ***sc\_tcpdecomp\_timeout***

*num* Security module number.

*value* Specifies the timeout value, in minutes, for entries in the Van Jacobson TCP decompression hash table. The default timeout value is 30; the range is 1 to 60.

# snmp

Use the **snmp** commands to configure the security device for Simple Network Management Protocol (SNMP), to gather statistical information from the security device, and receive notification snmp of significant system events.

## Syntax

---

### **clear**

```
clear snmp statistics
```

### **get**

```
get snmp [auth-trap | community name_str | mib-filter | settings | statistics]
```

### **set**

```
set snmp
{
 auth-trap enable |
 community name_str
 { read-only | read-write }
 [
 mib-filter filter_name
 trap-off] |
 trap-on [traffic] |
 version { any | v1 | v2 }
] |
contact name_str |
host comm_name ip_addr[/mask]
[
 src-interface interface |
 trap { v1 | v2c }
] |
location string |
mib-filter
[
 [name name_str [type ip action { include | exclude }] |
 [name_str ip ip_addr network_mask]
]
name name_str |
port { listen [port_num] | trap [port_num] }
}
```

## Keywords and Variables

---

### ***auth-trap enable***

```
get snmp auth-trap
set snmp auth-trap enable
unset snmp auth-trap enable
```

**auth-trap enable** Enables Simple Network Management Protocol (SNMP) authentication traps.

### ***community***

```
get snmp community name_str
set snmp community name_str { ... }
unset snmp community name_str
```

**community** Defines the name for the SNMP community. It supports maximum 3 communities in all products.

- **read-only**—Defines the permission for the community as “read-only.”
- **read-write**—Defines the permission for the community as “read-write.”
  - **trap-off**—Disables SNMP traps for the community.
  - **trap-on**—Enables SNMP traps for the community. The **traffic** switch includes traffic alarms as SNMP traps.

**Example 1:** The following command configures a community named **public**.

- Allows hosts to read MIB data from the SNMP agent
- Enables SNMP traps for the community

```
set snmp community public read-only trap-on
```

**Example 2:** The following command configures an SNMP host with IP address *10.20.25.30* for the community named **public**:

```
set snmp host public 10.20.25.30
```

### ***contact***

```
set snmp contact name_str
unset snmp contact
```

**contact** Defines the system contact.

## host

```
set snmp host comm_name ip_addr[/mask] [...]
unset snmp host comm_name ip_addr [...]
```

host Defines the community name string and the IP address of the SNMP management host. The *mask* value defines a SNMP community member as a subnet.

---

**NOTE:** When you define an SNMP community member as a subnet, that member can poll the security device but it cannot receive SNMP traps. To receive SNMP traps, the community member must be a single host.

---

**Example:** The following commands configure a community named **juniper**.

- Specifies read and write permission
- Allows the security device to send traps to all hosts in the community
- Assigns the community to an **SNMP** host with IP address **10.40.40.15**

```
set snmp community juniper read-write trap-on
set snmp host juniper 10.40.40.15
```

**Example:** The following command defines the subnet **10.5.1.0/24** as a member of the SNMP community named **olympia**:

```
set snmp host olympia 10.5.1.0/24
```

## location

```
set snmp location string
unset snmp location
```

location Defines the physical location of the system.

## mib-filter

```
get snmp mib-filter name name_str
set snmp mib-filter name name_str...
unset snmp mib-filter name name_str
```

mib-filter Indicates the MIB filter, that the root -admin configures to filter conflicting IP addresses existing in the same domain.

- **action**—Specifies the activity triggered on the filtered IP address. The action is to either include or exclude the IP address from the MIB table.
  - **exclude**—Specifies that the filtered IP address is excluded from the MIB table.
  - **include**—Specifies that the filtered IP address is included in the MIB table.
- **type**—Indicates the filtering type . The default is IP.

**name**

```
set snmp name name_str
unset snmp name
```

name            Defines the name of the system.

**port**

```
set snmp port { ... }
unset snmp port { ... }
```

port            Specifies the SNMP listen and trap port ( **listen** | **trap** ).

**settings**

```
get snmp settings
```

settings        Displays the name of the contact person, and the name and physical location of the security device.

**src-interface**

```
set snmp host comm_name ip_addr[/mask] src-interface interface
unset snmp host comm_name ip_addr[/mask] src-interface
```

src-interface   Specifies the source interface.

**statistics**

```
clear snmp statistics
get snmp statistics
```

statistics      Displays or clears SNMP statistics.

**trap**

```
set snmp host comm_name ip_addr[/mask] trap v1 | v2c
```

trap            If an SNMP community supports both SNMP versions (SNMPv1 (**v1**) and SNMPv2c (**v2c**), you must specify a trap version for each community member.

**version**

```
set snmp community { ... } version { any | v1 | v2c }
```

version         When you create an SNMP community, you can specify whether the community supports SNMPv1 (**v1**), SNMPv2c (**v2c**), or both SNMP versions, as required by the SNMP management stations. For backward compatibility with earlier ScreenOS releases that only support SNMPv1, security devices support SNMPv1 by default.

# socket

Use the **socket** commands to display socket information about a security device.

A socket is a software object that serves as a connection to a network protocol. A security device can send and receive TCP/IP or UDP traffic by opening a socket and reading and writing data to and from the socket.

## Syntax

---

### **clear**

```
clear socket id id_num
```

### **get**

```
get socket [id id_num]
```

## Keywords and Variables

---

### **id**

```
clear socket id id_num
get socket id id_num
```

**id**                      Clears or displays the information for an identified socket (*id\_num*).

**Example:** The following command displays the information concerning socket 5:

```
get socket id 5
```



# ssh

Use the **ssh** commands to configure the Secure Shell (SSH) server task.

The SSH server task is an SSH-compatible server application that resides on the security device. When you enable the SSH server task, SSH client applications can manage the device through a secure connection. (The look and feel of a SSH client session is identical to a Telnet session.) You can run either SSH version 1 (SSHv1) or SSH version 2 (SSHv2) on the security device; the commands available depend on the SSH version that you activate.

## Syntax

---

### **clear**

```
clear ssh
{
 all |
 enables |
 host-key |
 pka-key |
 sessions
}
```

### **exec (SSHv1)**

```
exec ssh tftp pka-rsa [user-name name_str] file-name filename ip-addr ip_addr
[from interface]
```

### **exec (SSHv2)**

```
exec ssh tftp pka-dsa [user-name name_str] file-name filename ip-addr ip_addr
[from interface]
```

### **get (SSHv1)**

```
get ssh
[
 host-key |
 pka-rsa [all | [username name_str] [index number]] |
 report
]
```

**get (SSHv2)**

```
get ssh
 [
 host-identity |
 host-key |
 pka-dsa [all | cert] [user-name name_str] [index number]] |
 report
]
```

**set (SSHv1)**

```
set ssh
 {
 enable |
 key-gen-time number |
 pka-rsa [username name_str] key number1 number2 number3
 }
```

**set (SSHv2)**

```
set ssh
 {
 enable |
 host-identity { cert-dsa cert-id }
 pka-dsa
 {
 cert-id cert-id /key pka-key | user-name name_str { cert-id cert-id | key pka-key } |
 } |
 version { v1 | v2 }
 }
```

## Keywords and Variables

---

**all**

```
clear ssh all
```

**all**                      Clears all SSH sessions, enables, Public Key Authentication (PKA) keys, and host keys on the device.

**enable**

```
set ssh enable
unset ssh enable
```

**enable**                    Enables the Secure Shell (SSH) task. When issued from a virtual system (vsys), enables SSH for the vsys.

## host-key

```
get ssh host-key
unset ssh host-key
```

host-key      The **get** command shows the SSH host key (RSA public key for SSHv1 and DSA public key for SSHv2) for the root or current vsys, including the fingerprint of the host key. The **clear** command deletes the SSH host key for the root or current vsys; SSH must be disabled first before you can delete the host key.

## host-identity

```
get ssh host-identity
set ssh host-identity
unset ssh host-identity
```

host-identity      Sets the host device to use host certificates for device identification.

- **cert-dsa** *cert-id*—Forces the device to use the specified host certificate when authenticating itself to an SSH client application. In case of Use with the **get** command to it displays the details of the certificate -idID associated with that particular device. Only root- admins can execute this option.

## key-gen-time

```
set ssh key-gen-time number
unset ssh key-gen-time
```

key-gen-time      Specifies the SSHv1 server-key-regenerating time (in minutes).

## pka-dsa

```
get ssh pka-dsa [...]
set ssh pka-dsa [...]
unset ssh pka-dsa { ... }
```

pka-dsa      Binds the administrator to a PKA certificate for admin authentication in SSHv2. An administrator can have up to four PKA certificates bound to the account.

- **cert-id** *cert-id*—Binds a PKA certificate identified by the certificate ID to the current user.
- **user-name** *login-id* **cert-id** *cert-id*—Binds the certificate associated with the certificate ID to the administrator executing the command. Only root- admins can execute this option.
  - *login-id*—Login ID of the administrator executing the command

**Example:** The following command binds a hypothetical key to a user named **chris**:

```
set ssh pka-dsa user-name chris key
AAAAB3NzaC1kc3MAAABBAPrdVkvpsilMT7NfZJm24pqMU2
FFpO49+LFmbOipljEYeIWTA4J5...
```

The following command:

- Loads a key contained in a file named **key\_file**
- Takes the file from a server at IP address **172.16.10.11**
- Binds the key to a user named **chris**

```
exec ssh tftp pka-dsa user-name chris file-name key_file ip-addr 172.16.10.11
```

## **pka-key**

```
clear ssh pka-key
```

**pka-key**           Deletes all SSH PKA keys on the device.

## **pka-rsa**

```
get ssh pka-rsa [...]
set ssh pka-rsa [...]
unset ssh pka-rsa { ... }
```

**pka-rsa**           Public Key Authentication (PKA) using RSA for SSHv1.

- **all**—Shows all PKA public keys bound to all users. You must be the root user to execute this option; admin users and read-only users cannot execute this command.
- **index number**—Allows the admin user and read-only user to view the details of a key bound to the active admin. It also allows the root user to view the details of a key bound to the specified user.
- **key number1 number2 number3**—Binds a PKA key to the current user. The *number1*, *number2*, and *number3* values represent the key length, the exponent, and the modulus, respectively. Read-only users cannot execute this option.
- **username name\_str**—Specifies the name of the user to bind the PKA key.
- **file-name filename**—Specifies the file containing the key to bind to the user. For the get command, **username** displays all PKA public keys bound to a specified user *name\_str*. Admin users and read-only users can execute this option only if *name\_str* identifies the current admin user or read-only user.

**Example:** The following command binds a hypothetical key to a user named **chris**:

```
set ssh pka-rsa username chris key 512
655376875272488448958071956054093391935
033213724615582796813757422715643970626128793365599992658289
80111611537652715077837089019119296718115311887359071551679
```

The following command loads a key:

- Key contained in a file named **key\_file**
- File taken from a server at IP address **172.16.10.11**
- Key bound to a user named **chris**

```
exec ssh tftp pka-rsa username chris file-name key_file ip-addr 172.16.10.11
```

### **pub-key**

```
set ssh pub-key string
unset ssh pub-key string
```

pub-key            Sets the public key for SSHv2.

### **report**

```
get ssh report
```

report            Displays SSHv1 (or SSHv2) key, session, and vsys information for the device on which SSH is currently enabled.

### **sessions**

```
clear ssh sessions
```

sessions           Logs out all administrators that currently have active SSH sessions.

### **version**

```
set ssh version v1 | v2
```

version           (Available only at the root level.) Sets the version of SSH on the security device. Specify either SSH version 1 or version 2. Before you can set an SSH version, make sure that all keys created with the previous version are removed by executing the **delete ssh device all** command. To clear SSHv2 keys; issue the **clear scs all** command to clear SSHv1 keys.

### **Defaults**

This feature is *disabled* by default. The default key generation time for SSHv1 is 60 minutes.



# ssid

Use the **ssid** commands to configure the wireless service set identifier (SSID). You must create an SSID instance before you can configure its parameters.

## Syntax

---

### **get**

```
get ssid [name_str]
```

### **set (SSID Instance)**

```
set ssid name name_str
```

### **set (SSID Authentication)**

```
set ssid name_str authentication
{
 802.1x auth-server name_str |
 auto |
 open encryption
 {
 none |
 wep
 [
 key-source { local | server auth-server name_str | both auth-server name_str }
]
 } |
 shared-key |
 wpa
 [rekey-interval { disable | number }]
 encryption { aes | auto | tkip } auth-server name_str |
 wpa-auto
 [rekey-interval { disable | number }]
 encryption { aes | auto | tkip } auth-server name_str |
 wpa-auto-psk
 {
 passphrase string |
 psk key_str |
 }
 [rekey-interval { disable | number }] encryption { aes | auto | tkip } |
 wpa-psk
 {
 passphrase string |
```

```

 psk key_str |
 }
 [rekey-interval { disable | number }]
 encryption { aes | auto | tkip } |
wpa2
 [rekey-interval { disable | number }]
 encryption { aes | auto | tkip } auth-server name_str |
wpa2-psk
 {
 passphrase string |
 psk key_str |
 }
 [rekey-interval { disable | number } encryption { aes | auto | tkip }]
}

```

**set (SSID Client Isolation)**

```
set ssid name_str client-isolation
```

**set (SSID Interface)**

```
set ssid name_str interface { wireless_interface }
```

**set (SSID WEP Key Configuration)**

```
set ssid name_str key-id
 { 1 | 2 | 3 | 4
 length { 104 | 40 }
 [method { asciitext string | hexadecimal string [default] }]
}

```

**set (SSID Broadcast)**

```
set ssid name_str ssid-suppression
```

## Keywords and Variables

---

**Variable Parameter**

```
get ssid name_str
set ssid name name_str
unset ssid name name_str
```

|      |                                                                                                                                                                |
|------|----------------------------------------------------------------------------------------------------------------------------------------------------------------|
| name | Assigns a name to the SSID. The <i>name_str</i> can be a maximum of 32 characters. If the name includes a space, the name must be enclosed by quotation marks. |
|------|----------------------------------------------------------------------------------------------------------------------------------------------------------------|

## authentication

set ssid *name\_str* authentication {...}

authentication Allows you to set authentication and encryption options for a specific SSID.

- **802.1x auth-server**—Specifies the name of the RADIUS server from which the encryption key is retrieved.
- **auto**—Specifies that the security device accepts open encryption with Wired Equivalent Privacy (WEP) or shared-key authentication.
- **open encryption**—Specifies whether no encryption is performed or WEP encryption is used. In either case, no authentication is performed. You can specify the following options:
  - **none**—Specifies that no encryption is performed.
  - **wep**—Specifies that WEP encryption is to be used. *key-source* allows you to select where the WEP key is to be read from; *local* (from the security device), *server* (RADIUS server), or both. If you do not specify a *key-source*, *local* is selected by default. If the *key-source* is *local* or both, you must select a default key. If the *key-source* is *server*, the key does not need to exist on the security device.
- **shared-key**—Enables shared-key for both authentication and encryption. When this option is specified, the encryption method can only be WEP and you must select a default key.
- **wpa**—Enables Wi-Fi Protected Access (WPA) authentication when a RADIUS server is used and sets an optional *rekey-interval*. If you enable WPA authentication, you also need to configure the RADIUS server.
  - **rekey-interval**—Sets the group key update interval, which can range from 30 to 4,294,967,295 seconds. The default value is 1800 seconds. You can also specify **disable** if you are not using key updates.
  - **encryption**—Specifies the encryption used between the security device and wireless clients in the subnetwork. You can specify the following options:
    - **aes**—Specifies Advanced Encryption Standard (AES), used by WPA2 devices.
    - **auto**—Specifies either AES or TKIP encryption.
    - **tkip**—Specifies Temporal Key Integrity Protocol (TKIP), used by WPA devices.
- **auth-server *name\_str***—Specifies the RADIUS server that stores authentication information.
- **wpa-auto**—Allows WPA or WPA2 as the authentication type.
  - **rekey-interval**—Sets the group key update interval, which can range from 30 to 4,294,967,295 seconds. The default value is 1800 seconds. You can also specify **disable** if you are not using key updates.
  - **encryption**—Specifies the encryption used between the security device and wireless clients in the subnetwork. You can specify the following options:
    - **aes**—Specifies Advanced Encryption Standard (AES), used by WPA2 devices.
    - **tkip**—Specifies Temporal Key Integrity Protocol (TKIP), used by WPA devices.
    - **auto**—Specifies either AES or TKIP encryption.
  - **auth-server *name\_str***—Specifies the RADIUS server that stores authentication information.

- **wpa-auto-psk**—Allows you to configure the WPA or WPA2 pre-shared key.
  - **passphrase**—Sets a passphrase to access the SSID. The string should contain 8 to 63 ASCII characters.
  - **psk**—Sets a pre-shared key to access the SSID. The key must be a 256-bit (64 characters) hexadecimal value.
  - **rekey-interval**—Sets the group key update interval, which can range from 30 to 4,294,967,295 seconds. The default value is 1800 seconds. You can also specify **disable** if you are not using key updates.
  - **encryption**—Specifies the encryption used between the security device and wireless clients in the subnetwork. You can specify the following options:
    - **aes**—Specifies Advanced Encryption Standard (AES), used by WPA2 devices.
    - **tkip**—Specifies Temporal Key Integrity Protocol (TKIP), used by WPA devices.
    - **auto**—Specifies either AES or TKIP encryption.
- **wpa-psk**—Allows you to configure the WPA pre-shared key on the security device.
  - **passphrase**—Sets a passphrase to access the SSID. The string should contain 8 to 63 ASCII characters.
  - **psk**—Sets a pre-shared key to access the SSID. The key must be a 256-bit (64 characters) hexadecimal value.
  - **rekey-interval**—Sets the group key update interval, which can range from 30 to 4,294,967,295 seconds. The default value is 1800 seconds. You can also specify **disable** if you are not using key updates.
  - **encryption**—Specifies the encryption used between the security device and wireless clients in the subnetwork. You can specify the following options:
    - **aes**—Specifies Advanced Encryption Standard (AES), used by WPA2 devices.
    - **tkip**—Specifies Temporal Key Integrity Protocol (TKIP), used by WPA devices.
    - **auto**—Specifies either AES or TKIP encryption.
- **wpa2**—Enables Wi-Fi Protected Access 2 (WPA2) authentication when a RADIUS server is used and sets an optional rekey-interval. If you enable WPA authentication, you also need to configure the RADIUS server.
  - **rekey-interval**—Sets the group key update interval, which can range from 30 to 4,294,967,295 seconds. The default value is 1800 seconds. You can also specify **disable** if you are not using key updates.
  - **encryption**—Specifies the encryption used between the security device and wireless clients in the subnetwork. You can specify the following options:
    - **aes**—Specifies Advanced Encryption Standard (AES), used by WPA2 devices.
    - **tkip**—Specifies Temporal Key Integrity Protocol (TKIP), used by WPA devices.
    - **auto**—Specifies either AES or TKIP encryption.
- **auth-server name\_str**—Specifies the RADIUS server that stores authentication information.

- **wpa2-psk**—Allows you to configure the WPA2 pre-shared key on the security device.
- **passphrase**—Sets a passphrase to access the SSID. The string should contain 8 to 63 ASCII characters.
- **psk**—Sets a pre-shared key to access the SSID. The key must be a 256-bit (64 characters) hexadecimal value.
- **rekey-interval**—Sets the group key update interval, which can range from 30 to 4,294,967,295 seconds. The default value is 1800 seconds. You can also specify **disable** if you are not using key updates.
- **encryption**—Specifies the encryption used between the security device and wireless clients in the subnetwork. You can specify the following options:
  - **aes**—Specifies Advanced Encryption Standard (AES), used by WPA2 devices.
  - **tkip**—Specifies Temporal Key Integrity Protocol (TKIP), used by WPA devices.
  - **auto**—Specifies either AES or TKIP encryption.

**Example:** The following examples set different types of authentication and encryption methods for the SSID named **example1**.

```
set ssid example1 authentication auto
set ssid example1 authentication open encryption wep
```

## *client-isolation*

```
set ssid name_str client-isolation
unset ssid name_str client-isolation
```

**client-isolation** Prevents wireless clients on the same subnetwork of the SSID from accessing each other. Note that intrazone blocking, which you can configure with the **set zone** command, blocks traffic between an SSID and a wired or wireless subnetwork.

## *interface*

```
set ssid name_str interface { wireless_interface }
unset ssid name_str interface
```

**interface** Binds a wireless interface to an SSID and activates the SSID. The number of wireless interfaces you can bind and activate depends on the security device.

**key-id**

```
set ssid name_str key-id { 1 | 2 | 3 | 4 } ...
unset ssid name_str key-id { 1 | 2 | 3 | 4 }
```

|        |                                                                                                                                                                                                                                                                      |
|--------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| key-id | Enables WEP key configuration and sets the WEP key value. The value range is 1 through 4.                                                                                                                                                                            |
| length | Specifies the length of the encryption key (in bits): <ul style="list-style-type: none"> <li>■ <b>40-bit</b> Enter 10 hexadecimal digits or 5 ASCII characters.</li> <li>■ <b>104-bit</b> Enter 26 hexadecimal digits or 13 ASCII characters.</li> </ul>             |
| method | Sets the string type: <b>asciitext</b> <i>string</i> or <b>hexadecimal</b> <i>string</i> . The default method is hexadecimal. Use the default keyword to specify the default key. If you do not specify a default key, the key that is entered first is the default. |

**Example:** This examples sets the SSID example with a key-id of 1, key length of 40 bits, and ASCII password abcde.

```
set ssid example key-id 1 length 40 method asciitext abcde
```

**ssid-suppression**

```
set ssid name_str ssid-suppression
unset ssid name_str ssid-suppression
```

|                  |                                                                                                                                                                                                                                        |
|------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ssid-suppression | Disables broadcasting of SSIDs in beacons that are advertised by the security device. If SSID broadcasting is disabled, only wireless clients that know of the SSID are able to associate. By default, SSIDs are broadcast in beacons. |
|------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

# ssl

Use the **ssl** commands to configure a Secure Sockets Layer (SSL) connection, or to display the SSL configuration on a security device.

*Secure Sockets Layer (SSL)* is a set of protocols that can provide a secure connection between a Web client and a Web server communicating over a TCP/IP network.

## Syntax

---

### **get**

```
get ssl [ca-list | cert-list]
```

### **set**

```
set ssl
{
 cert number |
 enable |
 encrypt { { 3des | des } sha-1 | { rc4 | rc4-40 } md5 }
 port port_num
}
```

## Keywords and Variables

---

### ***ca-list* | *cert-list***

```
get ssl ca-list
get ssl cert-list
```

*ca-list* | *cert-list* Displays currently configured Certificate Authorities (**ca-list**) or currently available certificates (**cert-list**).

**Example:** The following command displays the SSL certificate list:

```
get ssl cert-list
```

**cert**

```
set ssl cert number
unset ssl cert
```

**cert** Specifies that the named certificate is required.

**enable**

```
set ssl enable
set ssl enable
unset ssl enable
```

**enable** Turns on SSL.

**encrypt**

```
set ssl encrypt
{ 3des | des } sha-1 |
{ rc4 | rc4-40 } md5
unset ssl encrypt
```

**encrypt** Enables encryption over the SSL connection.

n **3des**—Sets the 3DES security level.

n **des**—Sets the DES security level.

n **rc4 md5**—Sets the RC4 MD3 security level.

n **rc4-40 md5**—Sets the RC4-40 MD3 security level.

**Example:** The following command specifies triple-DES encryption with SHA-1 authentication hashing:

```
set ssl encrypt 3des sha-1
```

**port**

```
set ssl port port_num
unset ssl port
```

**port** Specifies the SSL port number.

**Example:** The following command changes the SSL port to 11533:

```
set ssl port 11533
```

**Defaults**

The default SSL port is 443.

# switch

Use the **switch** commands to test the switch module on some devices.

## Syntax

---

```
exec switch
{
 reset-counter |
 reset-statistic |
 snoop { rx number | tx number }
}
```

## Keywords and Variables

---

### **switch**

```
exec switch { ... }
```

**switch**            Executes switch module testing.

### **reset-counter**

```
exec switch reset-counter
```

**reset-counter**    Resets the rx and tx counters.

### **reset-statistic**

```
exec switch reset-statistic
```

**reset-statistic**   Clears all statistics.

### **snoop**

```
exec switch snoop { rx number | tx number }
```

**snoop**             Sets the memory rx and tx dump size.



# syslog

Use the **syslog** commands to configure the security device to send traffic and event messages to up to four syslog hosts or to display the current syslog configuration.

---

**NOTE:** The syslog host must be enabled before you can enable syslog.

---

## Syntax

---

### **get**

```
get syslog
```

### **set**

```
set syslog
{
 config { hostname | ip_addr }
 [
 facilities
 { AUTH/SEC | local0 | local1 | local2 | local3 | local4 | local5 | local6 | local7
 {
 AUTH/SEC | local0 | local1 | local2 | local3 | local4 | local5 | local6 | local7
 }
 } |
 log { all | event | traffic } |
 port number |
 transport tcp
] |
 enable |
 src-interface interface
}
```

## Keywords and Variables

---

### **config**

```
set syslog config { name_str | ip_addr } { ... }
unset syslog config [ip_addr | name_str]
```

**config** Defines the configuration settings for the syslog utility. The { **name\_str** | **ip\_addr** } parameters define the hose name or the IP address of the syslog host device. You can define up to four syslog hosts.

Specifying an IP address with the unset syslog config command removes the configuration for the specified syslog host. Otherwise, this command removes the configuration for all syslog hosts.

### **enable**

```
set syslog enable
unset syslog enable
```

**enable** Enables the security device to send messages to the syslog host(s).

### **facilities**

```
set syslog config { name_str | ip_addr } facilities { ... { ... } }
```

**facilities** Defines the *security facility level* and the *regular facility level* for each syslog host that you specify. The security facility classifies and sends messages to the syslog host for security-related actions such as attacks. The regular facility classifies and sends messages for events unrelated to security, such as user logins and logouts, and system status reports.

**Example:** The following command sets the syslog host configuration to report all logs:

```
set syslog config 172.16.20.249 facilities local0 local1
```

### **log**

```
set syslog config { name_str | ip_addr } log { all | event | traffic }
unset syslog config { name_str | ip_addr } log { all | event | traffic }
```

**log** Directs the security device to send traffic log entries, event log entries or all log entries to the syslog host.

**port**

```
set syslog config { name_str | ip_addr } port port_num
unset syslog config { name_str | ip_addr } port
```

**port** Defines the port number (*port\_num*) on the syslog host that receives the User Datagram Protocol (UDP) packets from the security device.

**Example:** The following command changes the syslog port number to 911:

```
set syslog config port 911
```

**src-interface**

```
set syslog config { name_str | ip_addr } src-interface interface
unset syslog config { name_str | ip_addr } src-interface
```

**src-interface** Specifies the source interface.

**transport**

```
set syslog config { ip_addr | name_str } transport tcp
unset syslog config { ip_addr | name_str } transport
```

**transport (tcp)** Directs the device to use TCP protocol instead of UDP protocol.

**Defaults**

This feature is disabled by default. The default syslog port number is 514, and the default WebTrends port number is 514.



# system

Use the **get system** command to display general system information.

The information displayed by the **get system** command includes the following:

- Descriptive indices of the ScreenOS operating system, including serial number, control number, software number, and image-source filename
- Descriptive indices of the hardware platform, including hardware version, MAC address, and type
- Chronological and timekeeping information
- Current operational mode (transparent, NAT, or route)
- Configuration port and user IP
- Interface settings

## Syntax

---

```
get system [version]
```

## Keywords and Variables

---

### **version**

```
get system version
```

version            Displays the version information for the ScreenOS operating system.



# task

Use the set task debug and get task commands to display session scan details as statistics for sub-tasks. These commands requires the root admin privileges.

## Syntax

---

```
set task task-name | task-id debug
unset task task-name | task-id debug
get task task-name | task-id
```

## Keywords and Variables

---

### ***task-name***

```
set task task-name | task-id debug
```

task-name |      Specifies the task to be debugged.  
task-id



# tech-support

Use the **tech-support** command to display system information.

The information displayed by the **get tech-support** command is useful for troubleshooting the security device. Most of this information consists of the current authentication and routing settings.

## Syntax

---

### *get*

get tech-support

## Keywords and Variables

---

None.



# telnet

Use the **telnet** commands to connect to and remotely configure other security devices over a TCP/IP network.

## Syntax

---

```
telnet string port port_num src-interface interface
```

### set

```
set telnet client enable
```

## Keywords and Variables

---

### enable

```
set telnet client enable
unset telnet client enable
```

**enable** Enables the Telnet client feature on a security device. The **unset** command disables this feature.

### telnet

```
telnet string port number src-interface interface
```

**port** Specifies the port number used to connect to the remote device. Use any number between 0 and 65535, or use the default port number (23).

**src-interface** Allows you to select an interface address as the source address for a Telnet connection. The sequence for choosing the interface address is management IP, interface IP, and secondary IP.

**Note:** If the source address is not specified, then the outgoing interface is used as the source address for the Telnet connection.

**string** Defines the security device, either as an IP address or as a hostname.



# tftp

Use the **tftp** commands to specify the interface the device uses to communicate via TFTP sessions.

## Syntax

---

### **get**

```
get tftp ip_addr filename
```

### **set**

```
unset tftp source-interface ip_addr
```

## Keywords and Variables

---

### **Variable Parameters**

```
get tftp ip_addr filename
set tftp source-interface ip_addr
```

*ip\_addr* Specifies the IP address of the TFTP interface.

*filename* Specifies the name of the file to access with the TFTP service.

### **action**

source-interface Specifies the IP address of the interface through which the device communicates using TFTP.



# timer

Use the **timer** commands to display timer settings, or to configure the security device to automatically execute management or diagnosis at a specified time.

All timer settings remain in the configuration script after the specified time has expired.

## Syntax

---

### **get**

```
get timer
```

### **set**

```
set timer date time action reset
```

## Keywords and Variables

---

### **Variable Parameters**

```
set timer date time action reset
unset timer id_num
```

*date* Specifies the date when the security device executes the defined action. Date is in *mm/dd/yyyy* format.

*time* Specifies the time when the security device executes the defined action. Time is in *hh:mm* format.

*id\_num* Identifies a specific action by ID number in the list of timer settings (generated by the **set timer** command.) For example, **unset timer 1**.

## ***action***

```
set timer date time action reset
unset timer id_num
```

action reset      Automatically resets the device at the configured time.

**Example:** The following command configures the security device to reset at a given time and date:

```
set timer 1/31/2007 19:00 action reset
```

# trace-route

Use the **trace-route** commands to display the route to a specified host.

## Syntax

---

```
trace-route string
 [
 from interface |
 hop number
 [
 from interface |
 time-out number [from interface]
]
]
```

## Keywords

### Variable Parameters

#### *from*

```
trace-route string [from interface | hop number [from interface | time-out number
[from interface]]]
```

**from** Specifies the name of the interface from which to initiate the route trace. If the system is in route mode, *interface* must have an IP address configured and must be active. If the system is in transparent mode, the IP address of VLAN 1 is used as the source address. The interface cannot be a loopback, null, HA, or tunnel interface and cannot be in the Null zone or be a bgroup member.

**Example:** The following command performs a trace-route operation from interface ethernet0/0 to host www.juniperdomain.com:

```
trace-route www.juniperdomain.com from ethernet0/0
```

## **hop**

```
trace-route string [from interface | hop number [from interface | time-out number [from interface]]]
```

**hop**                    The maximum number of route hops to evaluate and display.

**Example:** The following command sets a hop count of 4 in a trace-route operation from ethernet0/0 to the host at IP address 1.1.1.1:

```
trace-route 1.1.1.1 hop 4 from ethernet0/0
```

## **string**

```
trace-route string [...]
```

**string**                    The name or IP address of the host.

## **time-out**

```
trace-route string [from interface | hop number [from interface | time-out number [from interface]]]
```

**time-out**                    The maximum amount of time in seconds before abandoning the route trace.

**Example:** The following command sets a hop count of 20 and a time-out of 20 seconds in a trace-route operation to the host at IP address 1.1.1.1:

```
trace-route 1.1.1.1 hop 20 time-out 20
```

# traffic-shaping

Use the **traffic-shaping** commands to determine the settings for the system with the traffic-shaping function, or to display information about traffic management device interfaces.

*Traffic shaping* is the allocation of the appropriate amount of network bandwidth to every user and application on an interface. The appropriate amount of bandwidth is defined as cost-effective carrying capacity at a guaranteed Quality of Service (QoS). You can use a security device to shape traffic by creating policies and by applying appropriate rate controls to each class of traffic going through the device.

## Syntax

---

### **get**

```
get traffic-shaping
 [
 dscp-class-selector |
 interface [interface] |
 ip_precedence |
 mode |
 statistics
]
```

### **set**

```
set traffic-shaping
 {
 dscp-class-selector |
 ip_precedence
 { number1 number2 number3 number4 number5 number6 number7 number8 |
 mode { auto | off | on }
 }
```

## Keywords and Variables

---

### **dscp-class-selector**

```
get traffic-shaping dscp-class-selector
set traffic-shaping dscp-class-selector
unset traffic-shaping dscp-class-selector
```

**dscp-class-selector** Subsumes IP precedence into class selector codepoints, ensuring that priority levels set with **ip\_precedence** are preserved and handled correctly by downstream routers.

### **interface**

```
get traffic-shaping interface [interface]
```

**interface** Displays the traffic shaping information for an interface.

### **ip\_precedence**

```
get traffic-shaping ip_precedence
set traffic-shaping ip_precedence
 { number1 number2 number3 number4 number5 number6 number7 number8 }
unset traffic-shaping mode ip_precedence
```

**ip\_precedence** Specifies the Priorities 0 through 7 for IP precedence (TOS) mapping. Each setting should be a single-digit value.

### **mode**

```
get traffic-shaping mode
set traffic-shaping mode { auto | off | on }
unset traffic-shaping mode
```

**mode** Defines the traffic shaping mode function for the system. The default mode is **auto**.

- **auto**—Specifies that traffic shaping be enabled automatically only when there is a policy that has either ingress policing or traffic shaping enabled.
- **off**—Specifies that shaping is not enabled even if there is a policy that has either ingress policing or traffic shaping enabled.
- **on**—Specifies that shaping is enabled regardless of the presence of a policy that has ingress policing or shaping enabled.

### **statistics**

```
get traffic-shaping statistics
```

**statistics** Displays statistical information about traffic shaping and traffic policing.

# url

Use the **url** commands to enable or disable Web filtering for use in policies and to configure and display Web-filtering settings.

ScreenOS supports two types of Web filtering:

- Integrated

Some security devices support an integrated Web-filtering solution that employs Content Portal Authority (CPA) servers from SurfControl.

---

**NOTE:** Integrated Web filtering requires you to install a license key on your security device.

---

- Redirect

Some security devices support a Web-filtering solution that employs SurfControl or Websense services to a SurfControl or Websense server.

To run either of the Web-filtering features on the security device, perform the following steps:

1. Select the protocol.

For example, the **set url protocol type { sc-cpa | scfp | websense }** command selects the protocol.

2. Initiate the Web-filtering context.

Executing the **set url protocol { sc-cpa | scfp | websense }** command places the CLI in the Web-filtering routing context and redirects Web filtering to the SurfControl or Websense servers. Once you initiate the Web-filtering context, all subsequent command executions apply to the Web-filtering feature.

For more information and examples, see the *Concepts & Examples ScreenOS Reference Guide*.

## Syntax

---

### **get**

```
get url [all | vsys-name vsys_name]
```

### **get (Within the Protocol Context, SC-CPA)**

```
get url
{
 category { pre | user } |
 ns-profile |
 profile name_string |
 server
}
```

### **set (Root and Vsys Level)**

```
set url protocol
{
 type { sc-cpa | scfp | websense }
 sc-cpa |
 scfp |
 websense
}
```

### **set (Within the Protocol Context)**

```
set {
 account name_string |
 cache { enable | size number | timeout number } |
 cache-list-query-interval number |
 category name url url_str |
 config { disable | enable } |
 deny-message { string | use-server } |
 enable |
 fail-mode { block | permit } |
 log all |
 server {
 { ip_addr | dom_name } |
 host string |
 port_num |
 timeout_num |
 src-interface interface |
 } |
 use-root |
 use-vsys
}
```

## Integrated Web-Filtering (SC-CPA) Commands

---

To run the integrated Web-filtering feature (SurfControl Content Portal Authority, or SC-CPA) on the security device, you must select the protocol and initiate the Web-filtering context as follows:

```
set url protocol type sc-cpa
set url protocol sc-cpa
(url:sc-cpa)->
```

The following **set** commands are executable in this Web-filtering context (url:sc-cpa):

|                                   |                                                                                                                                                                |
|-----------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------|
| cache                             | Use the <b>set cache</b> command to enable caching. You can also change the cache size or timeout value.                                                       |
| cate-list-query-interval          | Use the <b>set cate-list-query-interval</b> command to specify the interval at which the device queries the SurfControl CPA server for categorization updates. |
| category                          | Use the <b>set category</b> command to create a category or to add a URL to a category. You can add up to 20 URLs to a category.                               |
| enable                            | Use the <b>set enable</b> command to enable Web filtering using the SurfControl Content Portal Authority (CPA) servers.                                        |
| fail-mode                         | Use the <b>set fail-mode</b> command to block or permit all requests when the Web-filtering server fails.                                                      |
| log                               | Use the <b>set log</b> command to enable logging of both permitted and blocked URLs.                                                                           |
| profile                           | Use the <b>set profile</b> command to create a new Web-filtering profile or to add a category to a profile.                                                    |
| server (Integrated Web Filtering) | Use the <b>set server</b> command to define the primary Web-filtering server.                                                                                  |

---

**NOTE:** The **enable**, **fail-mode**, and **profile** commands can be set in vsys mode. The rest of the commands in integrated Web filtering are read-only.

---

The following **get** commands are executable in the Web-filtering context (url:sc-cpa):

|                                   |                                                                                                 |
|-----------------------------------|-------------------------------------------------------------------------------------------------|
| category                          | Use the <b>get category</b> command to display the URL categories.                              |
| ns-profile                        | Use the <b>get ns-profile</b> command to display the default Web-filtering profile.             |
| profile                           | Use the <b>get profile</b> command to display all Web-filtering profiles.                       |
| server (Integrated Web Filtering) | Use the <b>get server</b> command to display information from the primary Web-filtering server. |

## Redirect Web-Filtering (SCFP and Websense) Commands

To run the redirect Web-filtering feature on the security device, you must select the protocol and initiate the Web-filtering context as follows:

| Redirecting to SurfControl Servers                                  | Redirecting to Websense Servers                                                 |
|---------------------------------------------------------------------|---------------------------------------------------------------------------------|
| set url protocol type scfp<br>set url protocol scfp<br>(url:scfp)-> | set url protocol type websense<br>set url protocol websense<br>(url:websense)-> |

Security devices with virtual systems support up to eight different URL-filtering servers—one server reserved for the root system, which can be shared with an unrestricted number of virtual systems; and seven URL-filtering servers for private use by the virtual systems. A root-level administrator can configure the URL-filtering module at the root and virtual system (vsys) levels. A vsys-level administrator can configure the URL module for his or her own vsys if that vsys has its own dedicated URL-filtering server. If the vsys-level administrator uses the root URL-filtering server settings, that admin can see—but not modify—the root-level URL-filtering settings.

The following **set** commands are executable in the redirect Web-filtering context (**root and vsys**):

|                                 |                                                                                                                                                                                                                                                                                                               |
|---------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| account                         | Use the <b>set account</b> command to set the Web-filtering account.                                                                                                                                                                                                                                          |
| config                          | Use the <b>set config</b> command to enable or disable Web filtering at the device level for use in policies. By itself, enabling Web filtering at the device level does not activate it. You must enable Web filtering at both the device and the policy levels in order to apply filtering to URL requests. |
| deny-message                    | Use the <b>set deny-message</b> command to customize the blocked URL message. Specify the message source that the device delivers to the clients when URLs are blocked.                                                                                                                                       |
| fail-mode                       | Use the <b>set fail-mode</b> command to block or permit all requests when the Web-filtering server fails.                                                                                                                                                                                                     |
| server (Redirect Web Filtering) | Use the <b>set server</b> command to define the primary Web-filtering server. Use the <b>set url src-interface</b> command to define to which server the devices sends the URLs to be categorized.                                                                                                            |
| use-root                        | Use the <b>set use-root</b> command to instruct a vsys to share a Web-filtering server that was defined at the root level.                                                                                                                                                                                    |
| use-vsys                        | Use the <b>set use-vsys</b> command to instruct the vsys to use the Web-filtering server that was defined for that vsys.                                                                                                                                                                                      |

## Keywords and Variables

---

### **account**

```
set account name_str
```

*name-str* Sets a name for the Web-filtering server account. You must be in the vsys level to execute this command.

**Example:** Set up a Web-filtering server account for the marketing department.

```
set url protocol type scfp
set url protocol scfp
(url:scfp) -> set account mtg-server
```

### **cache**

```
set cache { enable | size number | timeout number }
unset cache { enable | size | timeout }
```

enable Enables the device to cache the categorization of URLs.

size Specifies the memory size of the categorization cache.

timeout Specifies the number of hours the device stores entries in the categorization cache.

**Example:** Set up the device to cache the URL categorization in a 10 MB cache size, and store the URLs in the cache for 24 hours.

```
set url protocol type sc-cpa
set url protocol sc-cpa
(url:sc-cpa) -> set cache enable
(url:sc-cpa) -> set cache size 20
(url:sc-cpa) -> set cache timeout 24
(url:sc-cpa) -> exit
```

### **cate-list-query-interval**

```
set cate-list-query-interval number
unset cate-list-query-interval
```

cate-list-query-interval Specifies the interval at which the device queries the SurfControl CPA server for categorization updates.

**Example:** Set up the device to query the Websense server every 60 minutes for categorization updates.

```
set url protocol type sc-cpa
set url protocol sc-cpa
(url:sc-cpa) -> set cate-list-query-interval 60
(url:sc-cpa) -> exit
```

## category

```
set category name url url_str
get category [name | pre | user]
unset category name [url url_str]
```

|          |                                                                           |
|----------|---------------------------------------------------------------------------|
| category | Specifies the category you are creating or to which you are adding a URL. |
| pre      | Displays the predefined categories.                                       |
| url      | Specifies the URL you are adding.                                         |
| user     | Displays the user-defined categories.                                     |

**Example:** Configure a customized URL category and add URLs to it.

```
set url protocol type sc-cpa
set url protocol sc-cpa
(url:sc-cpa) -> set category name banks url mybank.com
(url:sc-cpa) -> set category name banks url yourbank.com
(url:sc-cpa) -> exit
```

## config

```
set config { disable | enable }
unset config
```

|                                |                                                                                                                                                                                                                                                                            |
|--------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| config<br>{ disable   enable } | Disables or enables Web filtering at the device level for use in policies. By itself, enabling Web filtering at the device level does not activate it. You must enable Web filtering at both the device and the policy levels in order to apply filtering to URL requests. |
|--------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

**Example:** Enable Web filtering at the policy level.

```
set url protocol type scfp
set url protocol scfp
(url:scfp) -> set config enable
```

## deny-message

```
set deny-message { string | use-svr }
unset deny-message
```

|         |                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|---------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| message | Specifies the source of the message that the device delivers to clients when URLs are blocked—the device or the Websense server. <ul style="list-style-type: none"> <li>■ <i>string</i>—Defines a custom message from the device, 1 to 500 characters in length to be sent to the client that is blocked from reaching a URL.</li> <li>■ <i>use-svr</i>—Defines a message from the server to be sent to the client that is blocked from reaching a URL.</li> </ul> |
|---------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

**Example:** The following command defines the URL blocking message “This site is blocked.”

```
set url protocol type scfp
set url protocol scfp
(url:scfp) -> set deny-message “This site is blocked.”
```

## **enable**

```
set enable
unset enable
```

enable                    Enables Web filtering using the SurfControl CPA servers.

**Example:** Enable integrated Web filtering.

```
set url protocol type sc-cpa
set url protocol sc-cpa
(url:sc-cpa) -> set enable
```

## **fail-mode**

```
set fail-mode { block | permit }
unset fail-mode
```

fail-mode                    If the connection between the device and the Websense server is lost, the device either blocks or permits all HTTP/HTTPS requests to which a policy requiring Web filtering applies. The default fail-mode behavior is to block HTTP/HTTPS requests.

**Example:** Enable redirect Web filtering to block HTTP/HTTPS requests when the connection to the Websense server goes down.

```
set url protocol type websense
set url protocol websense
(url:websense) -> set failmode block
(url:websense) -> exit
```

## **log**

```
set log all
unset log all
```

log all                    Enable or disable the logging option for sc-cpa context only. The log all command logs both blocked and permitted URLs accesses.

**Example:** Enable logging for both permitted and blocked URL accesses.

```
set url protocol type sc-cpa
set url protocol sc-cpa
(url:sc-cpa)-> set log all
(url:sc-cpa)-> exit
```

## **ns-profile**

```
get ns-profile
```

ns-profile                    Displays the predefined profile.  
You must initiate the Web-filtering context before you can execute this command.

## profile

```
set profile string1 { other block | permit } | string2 { block | permit | black-list | white-list }
unset profile string1 [other | string2 | black-list | white-list]
get profile [string]
```

|                        |                                                                                                                                                                                           |
|------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| profile <i>string1</i> | Specifies the profile you are creating or updating. The default <i>string1</i> is <b>ns-profile</b> .<br>You must initiate the Web-filtering context before you can execute this command. |
| other                  | Specifies the Other category. Use this keyword to define the action for this category.                                                                                                    |
| block                  | The device blocks access to URLs in the specified category.                                                                                                                               |
| permit                 | The device permits access to URLs in the specified category.                                                                                                                              |
| <i>string2</i>         | Specifies the category for which you are defining an action.                                                                                                                              |
| black-list             | The device blocks access to URLs in this category.                                                                                                                                        |
| white-list             | The device permits access to URLs in this category.                                                                                                                                       |

## protocol

```
set url protocol type { sc-cpa | scfp | websense }
set url protocol { sc-cpa | scfp | websense }
unset url protocol type
```

|                                         |                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
|-----------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| type<br>sc-cpa   scfp  <br>websense     | Indicates which Web-filtering protocol you are configuring: <ul style="list-style-type: none"> <li>■ <b>sc-cpa</b>—Integrated Web filtering with the SurfControl servers.</li> <li>■ <b>scfp</b>—Redirect Web filtering with the SurfControl servers.</li> <li>■ <b>websense</b>—Redirect Web filtering with the Websense servers.</li> </ul> For more information about Web-filtering protocols, see the <i>Concepts &amp; Examples ScreenOS Reference Guide</i> . |
| protocol<br>sc-cpa   scfp  <br>websense | Initiates the following Web-filtering context: <pre>(url: sc-cpa) -&gt; (url: scfp) -&gt; (url: websense) -&gt;</pre>                                                                                                                                                                                                                                                                                                                                               |

## server (Redirect Web Filtering)

```
set server { { ip_addr | dom_name } port_num number | src-interface interface }
set src-interface interface
unset server
unset src-interface
```

|                                     |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|-------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| server<br>{ ip_addr  <br>dom_name } | <p>Defines the following connection parameters for the Web-filtering server:</p> <ul style="list-style-type: none"> <li>■ <i>ip_addr</i>   <i>dom_name</i>—Sets the IP address or DNS name of the Web-filtering server.</li> <li>■ <i>port_num</i>—Sets the port number on which the device communicates with the Web-filtering server. The default port number is 15868.</li> <li>■ <i>number</i>—Sets the timeout interval, in seconds, that the device waits for a response from the Websense filter. If Websense does not respond within the time interval, the device either blocks the request or allows it, as you choose. The default is 10 seconds.</li> </ul> |
| src-interface<br><i>interface</i>   | Specifies the source interface that the device uses when communicating with the Websense server. If you specify a source interface, the device enforces use of that interface without consulting the routing table. If you do not specify an interface, the device picks an interface according to entries in the routing table.                                                                                                                                                                                                                                                                                                                                        |

**Example:** The following command sets the IP address, port number, and timeout value for the Web-filtering server (the port number and timeout interval use the default values):

```
set url protocol type scfp
set url protocol scfp
(url:scfp) -> set url server 1.2.2.20 15868 10
(url:scfp) -> exit
```

## server (Integrated Web Filtering)

```
set server { america | asia | europe }
unset server { america | asia | europe }
get server
```

|        |                                                                                                                                                                    |
|--------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| server | Defines the primary CPA server to which the device sends URLs for categorization. You must initiate the Web-filtering context before you can execute this command. |
|--------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------|

**Example:** The following commands define the asia server to be the primary CPA server for Web filtering:

```
set url protocol type sc-cpa
set url protocol sc-cpa
(url:sc-cpa) -> set server asia
```

### ***use-root***

```
set url use-root
```

**use-root**            When this command is entered in a virtual system (vsys), it instructs the vsys to share the Web-filtering server defined at the root level.

**Example:** Configure a vsys to use the Web-filtering settings of the root-vsys.

```
device-> set vsys v1
device(v1)-> set url protocol type websense
device(v1)-> set url protocol websense
device(v1/url:websense) -> set use-root
device(v1/url:websense) -> exit
```

### ***use-vsys***

```
set url use-vsys
```

**use-vsys**            When this command is entered in a virtual system (vsys), it instructs the vsys to use the Web-filtering server defined for that vsys.

# usb-device

Use the **usb-device** commands to execute a USB storage device inserted in the USB host module found on some devices.

## Syntax

---

```
exec usb-device [stop]
```

## Keywords and Variables

---

### ***usb-device***

```
exec usb-device
exec usb-device stop
```

usb-device      Executes or stops the use of a USB storage device.



# user

Use the **user** commands to create, remove, or display entries in the internal user-authentication database.

The basic user categories are as follows:

- Authentication users (for using network connections)
- IKE users (for using AutoKey IKE VPNs)
- L2TP users (for using L2TP tunnels)
- XAuth users

## Syntax

---

### **get**

```
get user { name_str | all | id id_num }
```

### **set**

```
set user name_str
{
 disable |
 enable |
 hash-password string |
 ike-id
 {
 asn1-dn { [container string] wildcard string } [share-limit number] |
 fqdn name_str [share-limit number] |
 ip string [share-limit number] |
 u-fqdn name_str [share-limit number]
 } |
 password pswd_str |
 remote-settings
 {
 dns1 ip_addr |
 dns2 ip_addr |
 ipaddr ip_addr |
 ippool name_str |
 wins1 ip_addr |
 wins2 ip_addr
 } |
}
```

```

type { [auth] [ike] [l2tp] [wan] [xauth] } |
uid id_num
}

```

## Keywords and Variables

---

### Variable Parameters

```

get user name_str
set user name_str { ... }
unset user name_str [...]

```

*user* Defines the user's name (*name\_str*).

### *all*

```
get user all
```

*all* Displays the following information for all the entries in the internal user database:

- User ID number
- Username
- Status (enabled or disabled)
- User type
- IKE ID types—email address, IP address, or domain name—and IKE identity
- Groups to which a user belongs

### *disable | enable*

```

set user name_str disable
set user name_str enable

```

*disable | enable* Disables or enables the user in the internal database. By default, the user is disabled. If you set a password for an auth user or an IKE ID for an IKE user, the user becomes enabled automatically.

### *id*

```
get user id id_num
```

*id* Displays information about the user, identified by *id\_num*. This option displays the same information as **get user *name\_str*** option.

## hash-password

set user *name\_str* hash-password *string*

**hash-password** Creates a hashed password for the specified user and stores it in the configuration. Only an auth user can have a hashed password. The security device generates a hashed password randomly using either the crypt () or SHA-1 algorithm.

## ike-id

set user *name\_str* ike-id { ... }

ike-id { *string* | *name\_str* } Adds and defines an AutoKey IKE dialup user.

- **asn1-dn**—Specifies the user certificate distinguished name fields, and field values that define user identity.
- **container string**—Specifies a container identity. This identity allows multiple identity fields for each type (CN, OU, O, L, ST, C, and E). To match a local ASN1\_DN identity, the peer IKE identity fields must match all identity fields specified in the container identity. The security device does not check any undefined container fields. Field sequence must be identical.
- **wildcard string**—Specifies a wildcard identity. This identity allows only one identity field for each type (CN, OU, O, L, ST, C, and E). To match a local ASN1\_DN identity configuration, the peer IKE identity must contain fields matching all nonempty identity fields specified in the wildcard identity. For example, the wildcard identity **o= ACME,ou= Marketing** allows tunnel communication with any user whose certificate contains these field values. The security device does not check any undefined wildcard fields. Field sequence is not important.
- **share-limit number**—Specifies the number of users that can establish tunnels concurrently using this identity. When this number is larger than 1, the security device treats it as a Group IKE ID user. With Group IKE ID, multiple dialup users can establish tunnels using partial IKE identities.
- **fqdn name\_str** The fully qualified domain name, the complete string, such as www.juniper.net.
- **ip string** The IP address of the dialup user, such as 192.168.1.1.
- **u-fqdn name\_str**—Specifies the dialup user identity, usually equivalent to an email address such as admin@acme.com.

**Example 1:** The following command creates an IKE user named **branchsf** with the IKE-ID number **2.2.2.2**:

```
set user branchsf ike-id ip 2.2.2.2
```

**Example 2:** The following command creates a new user definition named **market**:

- Configures the user definition to recognize up to 10 hosts
- Specifies that the hosts must possess certificates containing “ACME” in the O field, and “Marketing” in the OU field

**set user market ike-id asn1-dn wildcard “o=ACME,ou=Marketing” share-limit 10**

(This command uses Group IKE ID, which allows multiple hosts to use a single user definition. For more information about Group IKE ID, see the *Concepts & Examples ScreenOS Reference Guide*.)

## **password**

```
set user name_str password pswd_str
```

**password** Defines a top-level password, used to authenticate the auth, L2TP, IKE, or XAuth user.

**Example:** The following command creates an authentication user in the internal database for user *guest* with the password *JnPc3g12*:

```
set user guest password JnPc3g12
```

## **remote-settings**

```
set user name_str remote-settings
```

```
{
 dns1 ip_addr |
 dns2 ip_addr |
 ipaddr ip_addr |
 ippool name_str |
 wins1 ip_addr |
 wins2 ip_addr
}
```

```
unset user name_str remote-settings { dns1 | dns2 | ipaddr | ippool | wins1 | wins2 }
```

**remote-settings** Sets the remote settings for the user.

- **dns1** | **dns2**—Specifies the IP address (*ip\_addr*) of the primary and secondary DNS servers.
- **ipaddr**—Specifies the static IP address (*ip\_addr*) for the user.
- **ippool**—Specifies the named L2TP IP pool (*name\_str*), which contains a range of IP addresses. The security device uses IP pools when it assigns addresses to dialup users using L2TP. (To define a L2TP pool, use the **set ippool** command.)
- **wins1** | **wins2**—Specifies primary and secondary servers (*ip\_addr*) that provide WINS (Windows Internet Naming Service). WINS is a service for mapping IP addresses to NetBIOS computer names on Windows NT server-based networks. A WINS server maps a NetBIOS name used in a Windows network environment to an IP address used on an IP-based network.

**Example:** The following command directs the device to obtain an IP address from an L2TP ippool named **NY\_Pool** for a dialup user named **John\_Doe**:

```
set user John_Doe remote-settings ippool NY_Pool
```

## type

```
set user name_str type { [auth] [ike] [l2tp] [wan] [xauth] }
unset user name_str type {...}
```

**type** Sets the user type, in any of the following combinations:  
**auth, ike, l2tp, xauth, auth ike l2tp xauth, auth ike, auth l2tp, auth xauth, ike l2tp, ike xauth, l2tp xauth, auth ike l2tp, auth l2tp xauth, or ike l2tp xauth.**

Type **wan** is used for PPP and MLPPP encapsulated data links only. The **type wan** command, defines the user as a WAN user. If CHAP or PAP authentication is configured for the PPP data link, the username and password for the peer device must be configured as a WAN user type.

**Example:** The following command changes the user *guest* to an authentication/L2TP user:

```
set user guest type auth l2tp
```



# user-group

Use the **user-group** commands to create or delete a user group, to modify it, or to add or remove a user from it.

User groups allow policies to treat multiple users in the same way, thus avoiding individual configurations for individual users. For example, even though you can configure dialup VPN tunnels for IKE users on a per-user basis, it is often more efficient to aggregate the users into a group, for which only one tunnel configuration is necessary.

Any policy that references a user group applies to all the members in the group. An authentication user can be a member of up to four different user groups.

---

**NOTE:** Different platforms allow a different number of members in a user group.

---

## Syntax

---

### **get**

```
get user-group { name_str | all | external | id id_num | local }
```

### **set**

```
set user-group name_str
{
 id id_num |
 location { external | local } |
 type { [auth] [l2tp] [xauth] } |
 user name_str
}
```

## Variable Parameters

---

```
get user-group name_str
set user-group name_str { ... }
unset user-group name_str [...]
```

*name\_str* Specifies the name of the user group.

### ***all***

```
get user-group all
```

all Displays all existing user groups.

### ***external***

```
get user-group external
set user-group name_str location external
```

external Defines a user group as external. You can store user definitions in groups on an external RADIUS server. You can then define a user group on the security device, define the type of user it contains, leave it unpopulated of users, and define the user group as external. Defining an external user group on the security device allows you to reference that group in policies requiring authentication. When the policy requires an authentication check, the security device then contacts the RADIUS server, which performs the authentication check.

### ***id***

```
get user-group id id_num
set user-group name_str id id_num
unset user-group name_str [...]
```

id Identifies the user group with an identification number *id\_num*.

**Example:** The following command creates a user group named **Corp\_Dial** and assigns the group an ID of **10**:

```
set user-group Corp_Dial id 10
```

### ***local***

```
get user-group local
```

local Displays all local user groups.

## location

```
set user-group name_str location { external | local }
unset user-group name_str location
```

location Specifies the location of the user group:

- **external**—Indicates that the user group is stored on an external authentication server. (ScreenOS supports user groups on RADIUS servers.)
- **local**—Indicates that the user group is stored in the local database on the security device.

## type

```
set user-group name_str type {...}
unset user-group name_str type {...}
```

type Specifies the type of user group when that group is stored on an external RADIUS server. (When the user-group is stored in the local database, the user types determine the type of user group.) The following are the possible user group types:

- **auth**—Specifies that the group is comprised of authentication users.
- **l2tp**—Specifies L2TP users.
- **xauth**—Specifies XAuth users.

## user

```
set user-group name_str user name_str
unset user-group name_str user name_str
```

user Adds or removes the named user (*name\_str*) to the specified user group.

**Example:** The following example does the following:

- Creates a new authentication user named **guest**
- Authenticates user group named **Corp\_Dial** with ID **1010**
- Adds a user to the user group

```
set user guest password JnPc3g12
set user-group Corp_Dial location local
set user-group Corp_Dial user guest
```



# vip

Use the **vip** commands to display the virtual IP (VIP) address configuration settings and to enable all VIPs to support multi-port services.

A VIP address maps traffic received at one IP address to another address based on the destination port number in the TCP or UDP segment header.

## Syntax

---

### **get**

```
get vip
[
 ip_addr { port port_num | port-status } |
 server |
 session timeout
]
```

### **set**

```
set vip
{
 multi-port |
 session timeout number
}
```

## Keywords and Variables

---

### Variable Parameters

get vip *ip\_addr* { port *port\_num* | port-status }

|                      |                                                                                                                                           |
|----------------------|-------------------------------------------------------------------------------------------------------------------------------------------|
| <i>ip_addr</i>       | Identifies the VIP address.                                                                                                               |
| port <i>port_num</i> | Identifies the destination port, so that the security device can display information about the specified virtual port defined on the VIP. |
| port-status          | Displays information about port allocation on the specified VIP.                                                                          |

### **multi-port**

set vip multi-port

|            |                                                                                                                  |
|------------|------------------------------------------------------------------------------------------------------------------|
| multi-port | Enables the support of multiple virtual ports per custom service. By default, VIPs support single-port services. |
|------------|------------------------------------------------------------------------------------------------------------------|



**CAUTION:** After you execute this command, you must restart the device. This command changes the functionality of the VIP. Switching back and forth between enabling and disabling the **multi-port** modes is not recommended.

---

### **server**

get vip server

|        |                                                                         |
|--------|-------------------------------------------------------------------------|
| server | Displays the connectivity status of servers receiving traffic via VIPs. |
|--------|-------------------------------------------------------------------------|

### **session**

get vip session

|                 |                                                         |
|-----------------|---------------------------------------------------------|
| session timeout | Displays the outstanding session timeout value for VIP. |
|-----------------|---------------------------------------------------------|

# vlan

Use the **vlan** commands to create and configure virtual local area networks (VLANs) and create VLAN retagging pairs. You can create a VLAN both at the root and under an already configured virtual system (vsys).

## Syntax

---

### get

```
get vlan
 [
 all |
 group [all | string] |
 import [all] |
 port [all] |
 retag [all | name [string]]
]
```

### set

```
set vlan
 {
 group { name name_str } |
 group name_str { vsd-group id number } |
 port interface
 group name_str { zone name_str } |
 retag
 retag { name name_str { number | untag } { number | untag } }
 }
```

## Variable Parameters

### all

```
get vlan all
```

**all**                    Displays information about all root level VLANs when run from the root and all vsys VLANs when run in a vsys.

### group

```
get vlan group [all | string]
set vlan group { name name_str }
set vlan group name_str { vsd-group id number }
set vlan group name_str { vlan_low, vlan_high }
unset vlan group { string }
unset vlan group name_str { vsd-group id number }
```

**group** Specifies an existing VLAN group or a VLAN group that you want to create.

- **vsd-group id**—Specifies a collection of VLANs grouped together. You can select or assign any value from 2 to 4094.

## **import**

```
get vlan import [all]
set vlan import { vlan ID low | vlan ID high }
```

**import** Assigns or imports VLAN information to the current vsys. When a VLAN is assigned to a vsys, it cannot be shared with another vsys and remains assigned until the system admin unsets it.

**Note:** The **set vlan import** command works only under a vsys.

## **port**

```
get vlan port [all]
set vlan port interface { group name_str zone zone }
unset vlan port { interface group name_str }
```

**port** Binds the VLAN group to the specified interface. You must also bind the group to a zone.

**Example:** The following command binds the VLAN group `secure_vlan` to interface `ethernet2/1` in the **v1-trust** zone:

```
set vlan port ethernet2/1 group secure_vlan zone v1-trust
```

## **retag**

```
get vlan retag [name string]
set vlan retag { name name_str number number }
unset vlan retag { name name_str }
```

**retag** Specifies that VLAN tags on traffic for the named VLAN be converted from ID *number* to ID *number*. Retagged traffic is diverted from the Layer 2 switch to the security device using the second tag ID. Retagging permits traffic that would be bound for a particular VLAN to be diverted without having to reconfigure policies or interfaces. Allowed VLAN IDs range from 2 to 4094.

- **untag**—Indicates the removal of the VLAN ID from the packet frame. The **untag** option sets the VLAN ID to zero in the output.

**Note:** The **untag** option is supported only on ISG platforms.

**Example:** The following command creates a retagging pair called `secure_one` that retags traffic on interface `ethernet2/1` with VLAN ID 10 to ID 20 and retags VLAN traffic with ID 20 to ID 10 on interface `ethernet2/1`:

```
set vlan retag secure_one 10 20
set vlan port eth2/1 retag secure_one
```

**zone**

```
set vlan port interface { retag name_str }
```

zone                      Assigns a Layer 2 zone to the VLAN group.

**Example:** The following command binds the VLAN group `secure_vlan` to interface `ethernet2/1` in the **v1-trust** zone:

```
set vlan port ethernet2/1 group secure_vlan zone v1-trust
```



# vpn

Use the **vpn** commands to create or remove a virtual private network (VPN) tunnel or to display current VPN tunnel parameters.

A *tunnel* is a way to secure VPN communication across a WAN. The tunnel consists of a pair of unidirectional security associations (SAs), one at each end of the tunnel, that specify the security parameter index (SPI), destination IP address, and security protocol (Authentication Header or Encapsulating Security Payload) used to exchange packets through the tunnel.

Juniper Networks security devices support two keying methods for establishing VPN tunnels, AutoKey IKE and Manual Key. AutoKey Internet Key Exchange (IKE) is a standard protocol that automatically establishes and maintains encryption keys between the participants. Manual Key VPNs use predefined keys that remain unchanged until the participants change them explicitly.

## Syntax

---

### get

```
get vpn [name_str [detail] | auto | manual | proxy-id |]
```

### set

```
set vpn tunn_str
{
 bind { interface interface | zone name_str } |
 df-bit { clear | copy | set } |
 dscp-mark dscp-value
 failover-weight number
 monitor [hub-override] [source-interface interface [destination-ip ip_addr]]
 [optimized] [rekey] |
 proxy-id local-ip ip_addr/mask remote-ip ip_addr/mask svc_name
}
```

**set (AutoKey IKE)**

```
set vpn tunn_str gateway { ip_addr | name_str }
 [replay | no-replay]
 [transport | tunnel]
 [idletime number]
 {
 proposal [name_str1 [name_str2 [name_str3 [name_str4]]]] |
 sec-level { basic | compatible | standard }
 }
```

**set (Manual Key)**

```
set vpn tunn_str manual spi_num1 spi_num2 gateway ip_addr1
 [outgoing-interface interface [local-address ip_addr2]]
 {
 ah { md5 | sha-1 | sha2-256 }
 { key key_str | password pswd_str } |
 esp
 {
 aes128 | aes192 | aes256 | des | 3des
 { key key_str | password pswd_str } |
 null
 }
 [auth { md5 | sha-1 | sha2-256 }
 { key key_str | password pswd_str }
]
 }
```

Keywords and Variables

---

**Variable Parameters**

```
get vpn tunn_str [...]
```

*name\_str* Defines a name for the VPN.

**Example:** The following command displays a VPN named **branch**:

```
get vpn branch
```

**acvpn-dynamic**

```
set ike gateway name_str
```

acvpn-dynamic Configured on the Next Hop Resolution Protocol (NHRP) client, called the Next Hop Client (NHC), **acvpn-dynamic** acts as a placeholder to receive information from the Next Hop Server (NHS) configured in the **acvpn-profile**.

**acvpn-profile**

```
set ike gateway name_str
```

**acvpn-profile** Configured on the Next Hop Resolution Protocol (NHRP) server, called the Next Hop Server (NHS), the AC-VPN profile contains information the NHS pushes to the Next Hop Client (NHC) to enable it to set up a dynamic tunnel with another NHC. Mode must be aggressive. You attach the AC-VPN profile to the NHRP configuration using the **set vrouter name\_str protocol nhrp** command.

**ah**

```
set vpn tunn_str manual spi_num1 spi_num2 gateway ip_addr [...] ah { ... }
```

**ah** Specifies Authentication Header (AH) protocol to authenticate IP packet content.

- **md5**—Specifies the Message Digest 5 (MD5) hashing algorithm. (128-bit)
- **sha-1**—Specifies the Secure Hash Algorithm version 1 (SHA-1) hashing algorithm. (160-bit)
- **sha2-256**—Specifies the Secure Hash Algorithm version 2 (SHA-2) hashing algorithm. (256-bit)

The **key** *key\_str* value defines a 16-byte (MD5), 20-byte (SHA-1) or 32-byte (SHA2-256) hexadecimal key, which the security device uses to produce a 96-bit message digest (or hash) from the message.

**password** *pswd\_str*—Specifies a password the security device uses to automatically generate an encryption or authentication key.

**Example:** The following command creates a Manual Key VPN tunnel named **Mkt\_vpn**:

- Sets the local and remote SPI values as **2002** and **3003**
- Defines the remote gateway address as **2.2.2.2**
- Specifies Authentication Header (**AH**) protocol for IP packet authentication using the **SHA-1** algorithm, the key for which is generated from the password **swordfish**

```
set vpn Mkt_vpn manual 2002 3003 gateway 2.2.2.2 ah sha-1 password swordfish
```

**auto**

```
get vpn auto
```

**auto** Displays all AutoKey IKE VPNs.

**Example:** The following command displays all AutoKey IKE VPNs:

```
get vpn auto
```

**bind**

```
set vpn tunn_str bind { interface interface | zone name_str }
unset vpn vpn_name bind { interface | zone }
```

**bind** Binds VPN tunnel to a tunnel interface or a security zone.

- **interface** *interface* specifies the tunnel interface to use for VPN binding.
- **zone** *name\_str* specifies the tunnel zone to use for VPN binding.

**Example:** The following command binds the VPN tunnel named **vpn1** to the **tunnel.1** interface:

```
set vpn vpn1 bind interface tunnel.1
```

**Example:** The following command binds the VPN tunnel named **vpn2** to the **untrust-tun** tunnel zone:

```
set vpn vpn2 bind zone untrust-tun
```

**df-bit**

```
set vpn tunn_str df-bit { clear | copy | set }
```

**df-bit** Determines how the security device handles the Don't Fragment (DF) bit in the outer header.

- **clear**—Clears (disables) DF bit from the outer header. This is the default value.
- **copy**—Copies the DF bit to the outer header.
- **set**—Sets (enables) the DF bit in the outer header.

**dscp-mark**

```
set vpn tunn_str dscp-mark dscp-value
unset vpn tunn_str dscp-mark
```

**dscp-mark** Sets the DSCP field of a packet to the specified value. By default, the DSCP field of a packet is not set. The unset command disables the DSCP functionality of the security device.

- *dscp-value*—Specifies the value that will be overwritten on the 6-bit DSCP field. The *dscp-value* can range from 0 through 63.

**esp**

```
set vpn tunn_str manual spi_num1 spi_num2 gateway ip_addr esp { ... }
```

**esp** Specifies the use of the Encapsulating Security Payload (ESP) protocol, which the security device uses to encrypt and authenticate IP packets.

- **aes128**—Specifies Advanced Encryption Standard (AES). The **key** *key\_str* value defines a 128-bit hexadecimal key.
- **aes192**—Specifies Advanced Encryption Standard (AES). The **key** *key\_str* value defines a 192-bit hexadecimal key.

- **aes256**—Specifies Advanced Encryption Standard (AES). The **key** *key\_str* value defines a 256-bit hexadecimal key.
- **des**—Specifies Data Encryption Standard (DES). The **key** *key\_str* value defines a 64-bit hexadecimal key (truncated to 56 bits).
- **3des**—Specifies Triple Data Encryption Standard (3DES). The **key** *key\_str* value defines a 192-bit hexadecimal key (truncated to 168 bits).
- **null**—Specifies no encryption. (When you specify this option, you must specify an authentication algorithm (MD5, SHA-1 or SHA2-256) using the **auth** option.)

**auth**—Specifies the use of an authentication (hashing) method. The available choices are MD5, SHA-1 or SHA2-256. (Some security devices do not support SHA-1.) The **key** *key\_str* value defines a 16-byte (MD5), 20-byte (SHA-1), or 32-byte (SHA2-256) hexadecimal key, which the security device uses to produce a 96-bit message digest (or hash) from the message.

**Note:** When you omit the **auth** keyword, the device automatically uses the **null** switch. We do not recommend omitting this keyword, because it may leave IPsec vulnerable to attack.

**password** *pswd\_str*—Specifies a password the security device uses to automatically generate an encryption or authentication key.

**Example:** The following command creates a Manual Key VPN tunnel named **Mkt\_vpn**:

- Specifies local and remote SPI values **2002** and **3003**
- Specifies the IP address of the remote gateway **2.2.2.2**
- Specifies **ESP** with **3DES** encryption and **SHA-1** authentication
- Generates the encryption and authentication keys from the passwords **swordfish** and **avalanche**

```
set vpn Mkt_vpn manual 2002 3003 gateway 2.2.2.2 esp 3des password swordfish
auth sha-1 password avalanche
```

## *failover-weight*

```
set vpn name_str failover-weight number
```

**failover-weight** Assigns a weight to a VPN tunnel. When the accumulated weight of failed or “down” VPN tunnels bound to the primary Untrust zone interface reaches or exceeds 100 percent, ScreenOS fails over to the backup Untrust zone interface.

---

**NOTE:** This option is available only on devices that support the DIAL-backup feature.

---

**Example:** The following command assigns a failover weight of 50 percent to the VPN *to\_remote1*:

```
set vpn to_remote1 failover-weight 50
```

## gateway

```
set vpn tunn_str gateway ip_addr [...] { ... }
set vpn tunn_str gateway name_str [...] { ... }
get vpn gateway [detail]
```

|         |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|---------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| gateway | Specifies the autokey IKE gateway ( <i>ip_addr</i> or <i>name_str</i> ) to use.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|         | <ul style="list-style-type: none"> <li>■ <b>idletime</b> <i>number</i> The length of time in minutes that a connection can remain inactive before the security device terminates it.</li> <li>■ <b>replay</b>   <b>no-replay</b>—Enables or disables replay protection. The default is no-replay.</li> <li>■ <b>transport</b>   <b>tunnel</b>—Defines the IPsec mode. In tunnel mode, the active IP packet is encapsulated. In transport mode, no encapsulation occurs. Tunnel mode is appropriate when both of end points in an exchange lie beyond gateway devices. Transport mode is appropriate when either end point is a gateway.</li> <li>■ <b>proposal</b> <i>name_str</i>—Defines up to four Phase 2 proposals. A Phase 2 proposal determines how a security device sends VPN session traffic.</li> <li>■ <b>sec_level</b>—Specifies a predefined set of proposals.</li> </ul> |

**Example:** In the following example you define an IKE gateway for a remote site in London. The gateway has the following elements:

- The remote gateway is named **London\_Office**, with IP address **2.2.2.2**.
- The outgoing interface is **ethernet3**.
- The Phase 1 proposal consists of the following components:
  - DSA certificate for data source authentication
  - Diffie-Hellman group 2 to protect the exchange of keying information
  - AES-128 encryption algorithm
  - MD-5 authentication algorithm

You then reference that gateway in a VPN tunnel that has the following elements:

- The tunnel is named **London\_Tunnel**.
- The Phase 2 proposal consists of the following components:
  - Diffie-Hellman group 2 to protect the keying information during Phase 2 key exchanges
  - Encapsulating Security Payload (ESP) to provide both confidentiality through encryption and encapsulation of the original IP packet and integrity through authentication
  - AES-128 encryption algorithm
  - MD-5 authentication algorithm

```
set ike gateway London_Office ip 2.2.2.2 outgoing-interface ethernet3 proposal
dsa-g2-aes128-md5
set vpn London_Tunnel gateway London_Office proposal g2-esp-aes128-sha
```

## manual

```
get vpn tunn_str [detail] manual
set vpn tunn_str manual spi_num1 spi_num2 gateway ip_addr [...] { ... }
```

**manual** Specifies a Manual Key VPN. When the security device is in Manual mode, you can encrypt and authenticate by HEX key or password.

*spi\_num1* and *spi\_num2* are 32-bit *local* and *remote* security parameters index (SPI) numbers. Each SPI number uniquely distinguishes a particular tunnel from any other active tunnel. Each must be a hexadecimal value between 3000 and 2ffffff.

The local SPI corresponds to the remote SPI at the other end of the tunnel, and vice-versa.

## monitor

```
set vpn tunn_str monitor [hub-override] [destination-ip ip_addr] [...]
unset vpn tunn_str monitor
```

**monitor** Directs the security device to send VPN monitor messages to a NetScreen-Remote client or a non-Juniper Networks peer device.

The **source-interface** *interface* option specifies the interface through which the security device sends the monitor messages.

- **destination-ip** specifies the destination IP address for the VPN monitoring feature to ping.
- **hub-override** (AC-VPN only)—Specifies that all monitoring parameters configured locally take precedence over any monitoring parameters for that VPN coming from the hub in an AC-VPN profile. Monitoring parameters coming from the hub are overridden. When unset, locally configured monitoring parameters are saved in the local configuration, but ignored, and monitoring parameters from the hub are applied.

When you set **hub-override**, locally configured monitoring takes effect immediately. When you unset **hub-override**, the spoke requests a new profile from the hub and, upon receiving it, immediately applies any monitoring parameters in the profile.

- **optimized** performs optimization for scalability.
- **rekey** triggers rekey of an autokey VPN if a tunnel is down.

**Example:** The following command uses ethernet3 as the source interface and 10.1.1.5 as the destination IP address for VPN monitoring through a VPN tunnel named **tun1**:

```
set vpn tun1 monitor source-interface ethernet3 destination-ip 10.1.1.5
```

## outgoing-interface

```
set vpn tunn_str manual spi_num1 spi_num2 gateway ip_addr [...]
 outgoing-interface interface [local-address ip_addr] { ... }
```

outgoing-interface Defines the interface through which the security device sends traffic for this Manual Key VPN. The **local-address** *ip\_addr* value specifies the IP address of the outgoing interface for reference by external devices.

For more information, see “Interfaces” on page 771.

**Example:** The following command uses a manual tunnel.

- External gateway device IP address 1.1.1.1
- Ethernet1 as the outgoing interface, identified to outside hosts as IP address 2.2.2.2
- Specified encryption algorithm 3DES
- Password “swordfish”

```
set vpn tun1 manual 20001 20022 gateway 1.1.1.1 outgoing-interface ethernet1
 local-address 2.2.2.2 esp 3des password swordfish
```

## proxy-id

```
get vpn proxy-id
set vpn tunn_str proxy-id local-ip ip_addr/mask remote-ip ip_addr/mask svc_name
unset vpn vpn_name proxy-id
```

proxy-id Specifies the three-part tuple consisting of local IP address–remote IP address–service.

- **local-ip** *ip\_addr/mask* The local IP address that sends and receives traffic through the tunnel.
- **remote-ip** *ip\_addr/mask* The remote IP address that sends and receives traffic through the tunnel.
- *svc\_name* The name of the service, such as FTP, TELNET, DNS or HTTP that passes through the tunnel. (Specifying **any** enables all services.)

**Example:** The following command creates a VPN proxy configuration for a VPN (*Sales*) with the HTTP service:

```
set vpn Sales proxy-id local-ip 10.1.1.0/24 remote-ip 10.2.2.0/24 HTTP
```

## rekey

```
set vpn corp monitor rekey
```

rekey Keeps the SA active even if there is no other VPN traffic.

***sec-level***

```
set vpn tunn_str gateway { name_str | ip_addr } [...] { ... } sec-level
 { basic | compatible | standard }
```

sec-level      Specifies which predefined security proposal to use for IKE. The basic proposal provides basic-level security settings. The compatible proposal provides the most widely used settings. The standard proposal provides settings recommended by Juniper Networks.



# vpn-group

Use the **vpn-group** commands to define or remove VPN groups or to display VPN groups.

A *VPN group* is a collection of defined VPN tunnels. A VPN group allows the security device to perform tunnel failover. Each tunnel in the group has an assigned weight. When the security device invokes a policy that uses a VPN group, the device constructs all tunnels in the group, and the tunnel with the greatest weight becomes active by default. The IKE heartbeat periodically checks to see if this tunnel is working. If it is not, the device uses the tunnel with the next highest weight.

## Syntax

---

### *get*

```
get vpn-group [id id_num]
```

### *set*

```
set vpn-group id id_num [vpn tunn_str [weight number]]
```

## Keywords and Variables

---

### *id*

```
get vpn-group id id_num
set vpn-group id id_num [...]
unset vpn-group id id_num [...]
```

*id*                    Specifies an identification number for a VPN group.

### *vpn*

```
set vpn-group id id_num vpn tunn_str [...]
unset vpn-group id id_num vpn tunn_str
```

*vpn*                    Specifies the name of a VPN to be placed in a VPN group or removed from it.

**weight**

```
set vpn-group id id_num vpn tunn_str weight number
unset vpn-group id id_num vpn tunn_str weight number
```

**weight** Specifies a weight (priority) for the VPN relative to other VPNs in the group. The higher the number, the higher the priority.

**Example:** With the following commands, you create two VPN tunnels (vpn1 and vpn2). You place them in a VPN group with ID 1001, which you then reference in a policy permitting traffic from addr1 in the Trust zone to addr2 in the Untrust zone beyond the remote gateway. You assign vpn1 a greater weight, giving it priority. If traffic cannot pass through vpn1, the security device redirects it through vpn2:

```
set ike gateway gw1 ip 1.1.1.1 preshare bi273T1L proposal pre-g2-3des-md5
set ike gateway gw2 ip 2.2.2.2 preshare r3ix6403 proposal pre-g2-aes128-md5
set vpn vpn1 gateway gw1 replay proposal g2-esp-3des-sha
set vpn vpn2 gateway gw2 replay proposal g2-esp-3des-sha
set vpn-group id 1001 vpn vpn1 weight 1
set vpn-group id 1001 vpn vpn2 weight 2
set policy from trust to untrust addr1 addr2 HTTP tunnel vpn-group 1001
```

# vpnmonitor

Use the **vpnmonitor** commands to set the monitor frequency and threshold.

ScreenOS provides the ability to determine the status and condition of active VPNs through the use of ICMP pings and to report the conditions by using SNMP VPN monitoring objects and traps.

To enable your SNMP manager application to recognize the VPN monitoring MIBs, you must import the ScreenOS-specific MIB extension files into the application. The MIB extension files are on the documentation CD that shipped with the security device.

## Syntax

---

### **get**

```
get vpnmonitor
```

### **set**

```
set vpnmonitor
{
interval number |
threshold number
}
```

## Keywords and Variables

---

### **interval**

```
set vpnmonitor interval number
unset vpnmonitor interval
```

**interval**            Specifies the monitor frequency interval (in seconds).

## ***threshold***

set vpnmonitor threshold *number*  
unset vpnmonitor threshold

**threshold** Specifies the monitor threshold, the number of consecutive times the device can send vpnmonitor requests without getting a response before the device changes the VPN Link-Status to down.

# vrouter

Use the **vrouter** commands to configure a virtual router (VR) on the security device.

Executing the **set vrouter *name\_str*** command without specifying further options places the CLI in the routing context. For example, the following command places the CLI in the *trust-vr* routing context:

```
set vrouter trust-vr
```

To set protocol-specific parameters, see “interface” on page 313. Protocol-specific commands for RIP, OSPF, IGMP, and PIM are listed alphabetically in this reference guide.

## Syntax

---

### **clear**

```
clear vrouter vrouter
{
 mroute { all | mgroup ip_addr [source ip_addr] [iif interface] |
 protocol bgp [ipv4 | ipv6] neighbor ip_addr { soft-in | soft-out | stats }
 statistics
}
```

### **exec**

```
exec vrouter name_str protocol
 bgp neighbor ip_addr
 {
 connect |
 disconnect |
 tcp-connect
 }
```

**get**

```

get vrouter name_str
[
 access-list |
 config |
 default-vrouter |
 interface |
 mcore [cachemiss] |
 mroute [brief]
 [
 mgroup ip_addr brief |
 source ip_addr
 [
 brief |
 iif interface
]
]
 preference |
 protocol
 {
 bgp [ipv4 | ipv6] rib-in [neighbor neighbor_address [received | advertised]] |
 ospf | rip | pim | nhrp
 } |
 route
 [
 backup |
 id id_num |
 ip ip_addr |
 prefix ip_addr/mask |
 protocol { bgp | connected | discovered | imported | ospf | rip | static }
 source
 [ip_addr
 [interface interface [gateway ip_addr] | vrouter vrouter]
]
 [
 id id_num |
 in-interface interface [description] |
 ip ip_addr |
 prefix ip_addr/mask |
] |
 summary
] |
 route-lookup preference |
 route-map [name_str]
 [
 config |
 number [config | match | set]
] |
 router-id |
 rule |
 statistics |
 zone
]

```

---

**NOTE:** For more information about **protocol** { **bgp** | **nhrp** | **ospf** | **pim** | **rip** } options, see the **bgp**, **nhrp**, **ospf**, **pim**, and **rip** command descriptions.

---

**set**

```

set vrouter { name name_str | name_str }
 [
 access-list id_num
 { permit | deny } { ip ip_addr/mask | default-route } number |
 add-default-route vrouter untrust-vr |
 adv-inact-interface
 auto-route-export |
 default-vrouter |
 export-to | import-from
 vrouter name_str route-map name_str protocol
 { bgp | connected | imported | ospf | rip | static }
 ignore-subnet-conflict |
 max-ecmp-routes number |
 max-routes number |
 mroute
 {
 max-entries number |
 mgroup ip_addr source ip_addr iif interface oif interface out-group ip_addr |
 multiple-iif-enable |
 negative-cache [timer number]
 }
 nsrp-config-sync |
 pbr pbr_policy_name /
 preference
 {
 auto-exported number |
 connected number |
 ebgp number |
 ibgp number |
 imported number |
 ospf number |
 ospf-e2 number |
 rip number |
 static number
 } |
 protocol
 {
 bgp | nhrp ospf | pim | rip } |
 route [source] [in-interface interface] ip_addr/mask
 {
 interface interface
 [description] [gateway ip_addr] [metric number] [permanent]
 [preference number] [tag id_num] |
 vrouter name_str
 } |
 route-lookup
 preference
 [
 destination-routing number |
 sibr-routing number |
 source-routing number |
] /
 route-map
 {
 name name_str { permit | deny } number |

```

```

name_str number }
[
 as-path id_num |
 community id_num |
 local-pref number |
 match
 {
 as-path id_num |
 community id_num |
 interface interface |
 ip id_num |
 metric number |
 next-hop id_num |
 route-type
 { internal-ospf | type1-external-ospf | type2-external-ospf } |
 tag { number | ip_addr }
 } |
 metric number |
 metric-type { type-1 | type-2 } |
 next-hop ip_addr |
 offset-metric number |
 origin { igp | incomplete }
 preserve preference |
 preserve metric |
 tag { number | ip_addr } |
 weight number
]
router-id { id_num | ip_addr } |
sharable |
sibr-routing enable |
snmp trap private |
source-routing enable
]

```

---

**NOTE:** For more information about **protocol** { **bgp** | **nhrp** | **ospf** | **pim** | **rip** } options, see the **bgp**, **nhrp**, **ospf**, **pim**, and **rip** command descriptions.

---

## Keywords and Variables

---

### Variable Parameter

```
clear vrouter vrouter protocol bgp [ipv4 | ipv6] neighbor ip_addr soft-out
set vrouter name_str
```

|                 |                                                                                                                                                                                                                                                                 |
|-----------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <i>ip_addr</i>  | Specifies an IPv4 or IPv6 address of a BGP neighbor.                                                                                                                                                                                                            |
| <i>name_str</i> | The name of the VR. The name can be a predefined VR, such as trust-vr or untrust-vr, or it can be a user-defined VR created with the <b>name</b> keyword. (Creating custom VRs is only supported on certain security devices and requires a vsys software key.) |

**Example:** The following commands activate the trust-vr VR context, activate the BGP routing context, and execute the context-dependent command **get config**.

```
set vrouter trust-vr
device(trust-vr)-> set protocol bgp
device(trust-vr/bgp)-> get config
```

### access-list

```
get vrouter name_str access-list
set vrouter name_str access-list id_num
 { permit | deny } { ip ip_addr/mask | default-route } number }
unset vrouter name_str access-list id_num [ip_addr/mask | default-route] number
```

|             |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
|-------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| access-list | Creates or removes an access list, or entries in the access list. Each entry permits (or denies) routes according to IP address and mask, or default route. The <i>id_num</i> value identifies the access list. The <i>number</i> identifies the sequence number for this entry in the access list. <ul style="list-style-type: none"> <li>■ <b>permit</b>—Directs the VR to permit the route.</li> <li>■ <b>deny</b>—Directs the VR to deny the route.</li> <li>■ <b>default-route</b>—Enters the default route for the VR into the access list.</li> </ul> |
|-------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

### add-default-route

```
set vrouter name_str add-default-route vrouter name_str
unset vrouter name_str add-default-route
```

|                   |                                                                                                                                                                      |
|-------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| add-default-route | Adds a default route with the next hop as another VR. (This command is available only in the default VR of the current vsys, and only if this VR is not untrust-vr.) |
|-------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------|

### adv-inact-interface

```
set vrouter name_str adv-inact-interface
unset vrouter name_str adv-inact-interface
```

|                     |                                                                                                                                                                                                                             |
|---------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| adv-inact-interface | Directs the VR to consider active routes on inactive interfaces for redistribution or export. By default, only active routes defined on active interfaces can be redistributed to other protocols or exported to other VRs. |
|---------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

## **auto-route-export**

```
set vrouter name_str auto-route-export
unset vrouter name_str auto-route-export
```

**auto-route-export** Directs the VR to export public interface routes to the untrust-vr vrouter. An interface is public if it is in route mode, and private if it is in NAT mode. For information about route and NAT modes, see the *Concepts & Examples ScreenOS Reference Guide*.

---

**NOTE:** The auto-route-export switch does not take effect if the specified vrouter (*name\_str*) has export or import rules to the untrust-vr VR.

---

## **config**

```
get vrouter name_str config
```

**config** Displays configuration information about the VR.

## **default-vrouter**

```
get vrouter name_str default-vrouter
set vrouter name_str default-vrouter
```

**default-vrouter** Sets the specified VR as the default router for the vsys.

## **export-to | import-from**

```
set vrouter name_str { export-to | import-from } vrouter name_str { ... }
unset vrouter name_str { export-to | import-from } vrouter name_str { ... }
```

**export-to | import-from** Directs the VR to import routes from another VR (source), or to export routes to another VR (destination).

- **vrouter** *name\_str*—Identifies the source or destination VR.
- **route-map** *name\_str*—Identifies the route map that filters the imported or exported routes.
- **protocol**—Specifies the protocol for the imported or exported routes.
  - **bgp**—Directs the VR to import or export Border Gateway Protocol (BGP) routes.
  - **connected**—Directs the VR to import or export connected routes.
  - **imported**—Directs the VR to import or export routes that were redistributed into the VR from another VR.
  - **ospf**—Directs the VR to import or export Open Shortest Path First (OSPF) routes.
  - **rip**—Directs the VR to import or export Routing Information Protocol (RIP) routes.
  - **static**—Directs the VR to import or export static routes.

**ignore-subnet-conflict**

```
set vrouter name_str ignore-subnet-conflict
unset vrouter name_str ignore-subnet-conflict
```

**ignore-subnet-conflict** Directs the VR to ignore overlapping subnet addresses for interfaces in the VR. By default, you cannot configure overlapping subnet IP addresses on interfaces in the same VR.

**interface**

```
get vrouter name_str interface
```

**interface** Displays the interfaces in the VR.

**max-ecmp-routes**

```
set vrouter name_str max-ecmp-routes number
unset vrouter name_str max-ecmp-routes
```

**max-ecmp-routes** Specifies the maximum number of equal cost multipath (ECMP) routes to the same destination network. Enter a value between 1 and 4 (1 is the default).

**max-routes**

```
set vrouter name_str max-routes number
unset vrouter name_str max-routes
```

**max-routes** Specifies the maximum number of routing entries allowed for this VR. By default, the maximum number of entries allowed for a VR depends upon the security device and the number of VRs configured on the device.

**mccore**

```
get vrouter name_str mcore [cachemiss]
```

**mccore** Displays multicast routing information for each interface on which a multicast routing protocol is enabled.

**cachemiss** Displays the current multicast cachemiss data.

**mroute**

```
get vrouter name_str brief
get vrouter name_str mroute mgroup ip_addr1 brief
get {...} mroute mgroup ip_addr1 source ip_addr2 [brief | iif interface1]
set vrouter name_str mroute max-entries number
set {...} mroute mgroup ip_addr1 source ip_addr2 iif interface1 oif interface2
set {...} mroute mgroup ip_addr1 {...} out-group ip_addr3
set vrouter name_str mroute multiple-iif-enable
set vrouter name_str negative-cache [timer number]
unset vrouter name_str mroute max-entries
unset {...} mroute mgroup ip_addr1 source ip_addr2 iif interface1 oif interface2
```

```
unset vrouter name_str mroute multiple-iif-enable
unset vrouter name_str negative-cache [timer number]
```

|                     |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|---------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| brief               | Displays summary information.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| max-entries         | Specifies the maximum number of multicast routes allowed in the multicast routing table.                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| mroute              | Configures a static multicast route in the specified VR. <ul style="list-style-type: none"> <li>■ <i>ip_addr1</i> is the multicast group address of the route</li> <li>■ <i>ip_addr2</i> is the source address of the multicast data</li> <li>■ <i>interface1</i> is the incoming interface of the multicast data</li> <li>■ <i>interface2</i> is the outgoing interface of the multicast data</li> <li>■ <i>ip_addr3</i> is the multicast group address on the outgoing interface</li> </ul>                                               |
| multiple-iif-enable | Permits multiple multicast routes for the same source and group.                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| negative-cache      | Creates negative multicast routes if the protocol that owns the interface on which the packet was received cannot create a forwarding multicast route. The security device drops packets when they need to go on a negative multicast route. You can also set the timer value to specify the duration, in seconds, that the security device maintains the entries in the negative cache. The security device removes the entry in the negative cache when it receives information enabling it to create a forwarding multicast route entry. |

## ***name***

```
set vrouter name name_str
```

|      |                                                                                                                                              |
|------|----------------------------------------------------------------------------------------------------------------------------------------------|
| name | Specifies the name of a user-defined VR. Creating custom VRs is only supported on certain security devices and requires a vsys software key. |
|------|----------------------------------------------------------------------------------------------------------------------------------------------|

## ***nsrp-config-sync***

```
set vrouter name_str nsrp-config-sync
unset vrouter name_str nsrp-config-sync
```

|                  |                                                                                                                                                       |
|------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------|
| nsrp-config-sync | Synchronizes the specified VR ( <i>name_str</i> ) with the same VR on a NetScreen Redundancy Protocol (NSRP) peer. This switch is enabled by default. |
|------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------|

## ***pbr***

```
set vrouter name_str pbr pbr_policy_name
unset vrouter name_str pbr pbr_policy_name
```

|     |                                                                                                                                                                                                                                                   |
|-----|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| pbr | Binds a policy based routing (PBR) policy to the specified VR. The PBR policy bound to the VR is used all PBR-enabled interfaces belonging to that VR. No PBR policy is solely bound at the interface level or at the zone level of an interface. |
|-----|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

For more information about PBR, see “action-group” on page 19, “match-group” on page 429, and “pbr” on page 509.

## preference

```
get vrouter name_str preference
set vrouter name_str preference
unset vrouter name_str preference
```

|            |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
|------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| preference | Specifies route preference level based upon protocol. The lower the value, the more preference given to the route. You can specify a value between 1-255. <ul style="list-style-type: none"> <li>■ <b>auto-exported</b>—Specifies preference levels for routes (defined on public interfaces) that the VR automatically exports to the untrust-vr VR. The default is 30.</li> <li>■ <b>connected</b>—Specifies preference level for connected routes. The default is 0.</li> <li>■ <b>ebgp</b>—Specifies preference level for External Border Gateway Protocol (EBGP) routes. The default is 120.</li> <li>■ <b>ibgp</b>—Specifies preference level for Internal Border Gateway Protocol (IBGP) routes. The default is 40.</li> <li>■ <b>imported</b>—Specifies preference level for preexisting routes exported to another protocol and passed on to other routers. The default is 140.</li> <li>■ <b>ospf</b>—Specifies preference level for Open Shortest Path First (OSPF) routes. The default is 60.</li> <li>■ <b>ospf-e2</b>—Specifies preference level for OSPF External Type 2 routes. The default is 200.</li> <li>■ <b>rip</b>—Specifies preference level for Routing Information Protocol (RIP) routes. The default is 100.</li> <li>■ <b>static</b>—Specifies preference level for static routes. The default is 20.</li> </ul> |
|------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

## protocol

```
exec vrouter name_str protocol { ... }
get vrouter name_str protocol { bgp [ipv4 | ipv6] rib-in [neighbor neighbor_address
[received | advertised]] | nhrp | ospf | pim | rip }
set vrouter name_str protocol { bgp | nhrp | ospf | pim | rip }
unset vrouter name_str protocol { bgp | nhrp | ospf | pim | rip }
```

|          |                                                                                                                                                                                                                                                                                                                 |
|----------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| protocol | Places the security device in the context of the specified protocol: BGP, NHRP, OSPF, PIM, or RIP. (For information about the <b>bgp</b> , <b>nhrp</b> , <b>ospf</b> , <b>pim</b> , or <b>rip</b> contexts, see the <b>bgp</b> , <b>nhrp</b> , <b>ospf</b> , <b>pim</b> , and <b>rip</b> command descriptions.) |
|----------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

In the BGP context, you can use the **get** command to display BGP routes received from a specific neighbor or advertised to a special neighbor.

- **ipv4** | **ipv6**—Indicates that you want to get information for the BGP routes of the IPv4 or IPv6 address family. If you do not use these keywords, the BGP routes of both the IPv4 and IPv6 address families are displayed (the default).
- **rib-in**—Displays the BGP internal routing information base (RIB) for all BGP routes, including local redistributed routes and networking routes.
- **neighbor**—Specifies the address of the neighbor for which you want to display routes. The neighbor can be an IPv4 or IPv6 BGP neighbor. Make sure you use the correct addressing format.
- **received** | **advertised**—Indicates whether BGP routes received from or advertised to a specific neighbor are displayed. The **received** keyword directs the device to list the routes received in the UPDATE messages from the neighbor. The **advertised** keyword directs the device to list only the routes that have been advertised to the neighbor during the current neighbor session. By default, both received and advertised routes for the neighbor are displayed.

The **exec vrouter name\_str protocol bgp neighbor ip\_addr** command has the following options:

- **connect**—Establishes a BGP connection to the specified neighbor.
- **disconnect**—Terminates a BGP connection to the specified neighbor.
- **tcp-connect**—Tests the TCP connection to the neighbor.

**Example 1:** The following command displays the received routes of the IPv4 address family for the specified neighbor (1.1.1.10):

```
get ipv4 rib-in 1.1.1.10 received
```

**Example 2:** The following command displays the advertised routes of the IPv6 address family for the specified neighbor (2008::5):

```
get ipv6 rib-in 2008::5 advertised
```

## route

```
get vrouter name_str route [...]
set vrouter name_str route [source] [in-interface interface] ip_addr/mask [...]
unset vrouter name_str route [source] [in-interface interface] ip_addr/mask
[...]
```

route Configures routes for the VR routing table.

- **backup**—Displays information about the synchronized routes.
- **ip\_addr/mask**—Specifies the IP address that appears in the routing table.
- **description**—Adds a description (string) of 1–32 characters to a route table entry.
- **gateway ip\_addr**—Specifies the gateway for the next hop.
- **id id\_num**—Displays information for the route that matches the ID number. The ID number is a system-assigned number that you can see when you enter the **get vrouter name\_str route** command with no options.

- **in-interface** *interface*—For source interface-based routes, specifies the interface on which a packet arrives on the security device. You can then forward that traffic to either a routed interface or to a VR.
- **description**—Displays source interface-based (SIBR) static routes with descriptions.
- **interface** *interface*—Specifies the interface on which a packet for this route is to be forwarded.
- **ip** *ip\_addr*—Displays the route for the specified IP address.
- **metric** *number*—Specifies the cost of the route. Specify a value between 1 and 65535.
- **permanent**—Specifies that the route is kept active when the interface is down or the IP address is removed from the interface.
- **preference** *number*—Specifies the preference value for the route. Specify a value between 0 and 255.
- **prefix** *ip\_addr/mask*—Displays the routes within the specified subnet address.
- **protocol**—Displays BGP, connected, imported, OSPF, RIP, or static routes.
- **source**—Specifies that the route is a source-based route. When displaying a source-based route, you can optionally specify:
  - **id** *id\_num*
  - **ip** *ip\_addr*
  - **prefix** *ip\_addr/mask*
  - *ip\_addr/netmask* **interface** *interface* **gateway** *ip\_addr* sets a gateway as the next hop.
  - **vrouter** *vrouter* sets a VR as the next hop.
- **summary**—Displays a summary of the routes.
- **tag** *number*—For destination-based routes, specifies the tag for this route. The tag can be used as a filter when redistributing routes (see the **route-map** keyword). Specify a value between 1 and 65535.
- **vrouter** *name\_str*—Specifies a VR as the next hop.

**Example 1:** This example sets a source based route. Traffic enters at ethernet1/1, and the next hop is set to be the VR *untrust-vr*.

```
set vrouter trust-vr route source ethernet1/1 10.2.2.1/24 vrouter untrust-vr
```

**Example 2:** This example sets a source interface-based route (SIBR). Traffic enters at ethernet1/1, and the next hop is set to be the VR *untrust-vr*.

```
set vrouter trust-vr route source in-interface ethernet1/1 10.2.2.1/24 vrouter untrust-vr
```

## route-lookup preference

```
get vrouter name_str route-lookup preference
set vrouter name_str route-lookup preference [destination-routing number]
 [sibr-routing number] [source-routing number]
unset vrouter name_str route-lookup preference
```

|                         |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|-------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| route-lookup preference | <p>Configures the order in which route lookups occur in the VR. The route lookup type that has the highest preference value is performed first, followed by the next highest preference value. The route lookup type that has the lowest preference value is performed last. Enter a number between 1-255 for the preference.</p> <ul style="list-style-type: none"> <li>■ <b>destination-routing</b> <i>number</i>—Specifies the preference for route lookups based on destination IP address. The default value is 1.</li> <li>■ <b>sibr-routing</b> <i>number</i>—Specifies the preference for route lookups based on source interface. The default value is 3.</li> <li>■ <b>source-routing</b> <i>number</i>—Specifies the preference for route lookups based on source IP address. The default value is 2.</li> </ul> |
|-------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

## route-map

```
get vrouter name_str route-map [...]
set vrouter name_str { ... } vrouter name_str route-map
 { name name_str | name_str } [...]
unset vrouter name_str { ... } vrouter name_str route-map name_str [...]
```

|           |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
|-----------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| route-map | <p>Configures a route map for the VR.</p> <p>With the <b>name</b> keyword, the <b>route-map</b> option creates a new route map (<i>name_str</i>). Otherwise, <i>name_str</i> configures an existing route map. Each entry in the route map must have a sequence number (<i>number</i>) that identifies the order in which the route map entries are compared against an incoming or outgoing route. The <b>permit</b> and <b>deny</b> switches determine if the entry allows redistribution of routes to another VR or another protocol.</p> <p>The <b>match</b> keyword directs the VR to match routes to specified parameters. You can match the following parameters:</p> <ul style="list-style-type: none"> <li>■ <b>as-path</b> <i>id_num</i>—Specifies an AS path access list that defines the BGP AS path attribute to be matched.</li> <li>■ <b>community</b> <i>id_num</i>—Specifies a BGP community list (<i>id_num</i>) that defines the community attribute to be matched.</li> <li>■ <b>interface</b> <i>interface</i>—Specifies an interface on the security device.</li> <li>■ <b>ip</b> <i>id_num</i>—Specifies an access list that defines the IP addresses of routes to be matched.</li> <li>■ <b>metric</b> <i>number</i>—Specifies the cost of the route. Enter a number between 1-65535.</li> <li>■ <b>next-hop</b> <i>id_num</i>—Specifies an access list that defines the next-hop for routes to be matched</li> <li>■ <b>route-type</b>—Specifies which kind of OSPF route matches the route map entry. <ul style="list-style-type: none"> <li>■ <b>internal-ospf</b>—Matches only OSPF internal routes.</li> <li>■ <b>type1-external-ospf</b>—Matches only external OSPF Type-1 routes.</li> <li>■ <b>type2-external-ospf</b>—Matches only external OSPF Type-2 routes.</li> </ul> </li> <li>■ <b>tag</b> { <i>number</i>   <i>ip_addr</i> }—Matches either a route tag or an IP address.</li> </ul> <p>Other keywords allow you to optionally set values for parameters on matching routes. You can set the following parameters:</p> <ul style="list-style-type: none"> <li>■ <b>as-path</b> <i>id_num</i>—Specifies the AS path access list values that are prepended to the path list of the matching route.</li> </ul> |
|-----------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

- **community** *id\_num*—Specifies the community list values that are set in the community attribute for the matching route.
- **local-pref** *number*—Specifies the path preference for the matching route.
- **metric** *number*—Specifies the metric for the matching route. Enter a number between 1-65535.
- **metric-type**—Specifies OSPF metric type that is set for the matching route.
  - **type-1**—Specifies OSPF Type-1 route.
  - **type-2**—Specifies OSPF Type-2 route.
- **next-hop** *ip\_addr*—Specifies the next hop IP address for the matching route.
- **offset-metric** *number*—Specifies the value to increment the metric for the matching route. For RIP routes, you can use this option for routes that are advertised or routes that are learned. For other routes, you can use this option to routes that are exported into another VR.
- **origin**—Specifies the origin of a route advertised by BGP
- **preserve metric**—Specifies that the metric value for the matching route is preserved when the route is exported to another VR.
- **preserve preference**—Specifies that the preference value for the matching route is preserved when the route is exported to another VR.
- **tag** { *number* | *ip\_addr* }—Specifies a tag or IP address for the matching route.
- **weight** *number*—Sets the weight of the matching route for BGP.

While configuring a route map, you can use the **get config**, **get match**, and **get set** commands to display route map configuration commands, or match or set conditions.

## router-id

```
get vrouter name_str router-id
set vrouter name_str router-id { id_num | ip_addr }
unset vrouter name_str router-id
```

**router-id** Specifies the router identification that the VR uses to communicate with other routing devices. You can enter the router identification in either a dotted decimal notation (like an IP address) or a decimal number (this is converted to 0.0.0.*number*). If you do not specify a router identification, the device uses the highest IP address of the any interface in the VR as the router identification.

## rule

```
get vrouter name_str rule
```

**rule** Displays import and export rules for the VR.

## sharable

```
set vrouter name_str sharable
unset vrouter name_str sharable
```

`sharable` Makes the root-level VR accessible from any virtual system (vsys) on the device.

### ***sibr-routing enable***

```
set vrouter name_str sibr-routing enable
unset vrouter name_str sibr-routing enable
```

`source- routing enable` Directs the VR to perform routing table lookups based on the source interface.

### ***snmp***

```
set vrouter name_str snmp trap private
unset vrouter name_str snmp trap private
```

`snmp` Makes SNMP traps private for the dynamic routing MIBs under the VR. Private traps include the VR identification. This option is available only for the default root-level VR. (This is usually the trust-vr VR, although you can change the default VR at the root level.)

### ***soft-in***

```
clear vrouter trust-vr protocol bgp [ipv4] neighbor ip_addr soft-in
```

`soft-in` Enables a soft reset and generates an inbound update for the routes of the IPv4 address family from a BGP neighbor. A soft reset allows the application of a new or changed policy without clearing an active BGP session. The route-refresh feature occurs on a per-neighbor basis and does not require preconfiguration or extra memory.

### ***soft-out***

```
clear vrouter trust-vr protocol bgp [ipv4] neighbor ip_addr soft-out
```

`soft-out` Enables a soft reset and sends a new set of updates for the routes of the IPv4 address family to a BGP neighbor. A soft reset allows the application of a new or changed policy without clearing an active BGP session. The route-refresh feature occurs on a per-neighbor basis; and outbound resets don't require preconfiguration or routing table update storage.

### ***source-routing enable***

```
set vrouter name_str source-routing enable
unset vrouter name_str source-routing enable
```

`source-routing enable` Directs the VR to perform routing table lookups based on source IP address.

### ***stats***

```
clear vrouter trust-vr protocol bgp neighbor ip_addr stats
```

`stats` Specifies that the security device clear the neighbor's statistics, including packet number statistics and so on.

## **statistics**

get vrouter *name\_str* statistics

`statistics` Displays statistics for the VR.

## **zone**

get vrouter *name\_str* zone

`zone` Displays the zones bound to the VR.



# vrrp

Use the **vrrp** commands to display Virtual Router Redundancy Protocol (VRRP) information about specified interfaces.

For information about creating a VRRP instance on a specified interface, see “interface” on page 313.

## Syntax

---

### **clear**

```
clear vrrp interface interface statistics
```

### **get**

```
get vrrp
 [
 virtual-group |
 interface |
 statistics
]
```

## Keywords and Variables

---

### **interface**

```
get vrrp interface
```

**interface**      Displays VRRP information for all interfaces.

### **statistics**

```
get vrrp statistics
```

**statistics**      Retrieves VRRP global statistics.

### **virtual-group**

```
get vrrp virtual-group
```

**virtual-group**      Displays VRRP information for the virtual group.



# vsys

Use the **vsys** commands to create and configure a virtual system (vsys) from the root level of a security device.

A vsys allows you to logically partition a single security system to provide multi-tenant services. Each vsys is a unique security domain and can have its own administrators, known as *virtual system administrators* or *vsys admins*. Such administrators can individualize their security domain by setting their own address books, virtual routers, user lists, custom services, VPNs, and policies. (Only a root-level administrator can set firewall security options, create virtual system administrators, and define interfaces and subinterfaces.)

When you execute the **set vsys** command, the command prompt changes to indicate that you are now operating within a virtual system. Use the **unset vsys** command to remove a specific virtual system and all its settings.

## Syntax

---

### **clear**

```
clear session
[
 id id_num |
 [src-ip ip_addr [netmask mask]]
 [dst-ip ip_addr [netmask mask]]
 [src-mac mac_addr] [dst-mac mac_addr]
 [policy id pol_num]
 [protocol ptcl_num [ptcl_num]]
 [src-port port_num [port_num]]
 [dst-port port_num [port_num]]
 [vsd-id id_num]
]
```

### **get**

```
get vsys [name_str | cpu-limit | override | session-limit]
```

**set**

```

set vsys name_str
 [
 shared-dmz zone /
 vrouter
 [
 name [name_str] [id id_num] [vsd number] |
 share [name_str] [vsd number] |
 vsd number
] |
 vsd number /
 vsys-profile name_str
]

```

## Keywords and Variables

---

**Variable Parameters**

```

get vsys [name_str]
set vsys name_str
unset vsys name_str

```

*name\_str* Defines the name of a virtual system (vsys) and automatically places the root level admin within the vsys. Subsequent commands configure the newly created vsys.

**Example:** The following command creates a virtual system named **vsys1** and switches the console to the new virtual system:

```

device-> set vsys vsys1
device(vsys1)->

```

**cpu-limit**

```

get vsys cpu-limit

```

cpu-limit Displays the CPU limit feature parameters for all virtual systems.

**id**

```

clear [cluster] session id id_num

```

id *id\_num* Identifies a specific session with Session Identification number *id\_num*.

**override**

```

get vsys override

```

override Displays the override values for all virtual systems.



**dst-port** Identifies all sessions initiated by packets that contain the Layer 4 destination port *port\_num* in the Layer 4 protocol header.  
You can also specify any Layer 4 destination port within a range (*port\_num port\_num*).

## shared-dmz

```
set vsys name_str shared-dmz zone
unset vsys name_str shared-dmz
```

**shared-dmz** Specifies that the new zone is a shared DMZ zone, a Layer 3 security zone (for running the device in NAT/route mode), which can be bound only to a loopback interface. The default interface is null.

- **zone**—Specifies the name of the shared DMZ zone.

**Example:** The following command subscribes vsys1 to shared DMZ zone **share-v1**:

```
set vsys vsys1 shared-dmz share-v1
```

## vsd-id

```
clear session [...] vsd-id id_num
```

**vsd-id** *id\_num* Clears all sessions that belong to the VSD group *id\_num*.

## vrouter

```
set vsys name_str vrouter [name [name_str] [id id_num] [vsd number]]
set vsys name_str vrouter [share [name_str] [vsd number]]
```

**vrouter** Defines and configures the default virtual router for the vsys.

- **name**—Specifies a name *name\_str* for the virtual router or the nsrp vsd number.
- **id id\_num** Assigns an identification number to the virtual router.
- **vsd number** See “vsd” on page 737.
- **share**—Specifies a shared root-level virtual router to use as a default router for a specified vsys with name *name\_str* or nsrp vsd *number*.
- **vsd number** See “vsd” on page 737.

**Example 1:** The following command creates a vsys named **Acme\_Org**, creates a virtual router named **Acme\_Router** with vsd number **3**, and switches the console to the new virtual system:

```
set vsys Acme_Org vrouter name Acme_Router vsd 3
```

**Example 2:** The following command creates a vsys named **Acme\_Org** and specifies a default, root-level virtual router (**trust-vr**):

```
set vsys Acme_Org vrouter share trust-vr
```

## **vsd**

```
set vsys name_str vrouter [vsd number]
```

**vsd number** Assigns a Virtual Security Device (VSD) group number to the virtual router. The VSD number can be 1 through 8.

A VSD group is a pair of physical security devices (a primary and a backup) that collectively comprise a single VSD. A VSD provides failover capability, allowing the backup device to take over if the primary device fails. For more information about VSD groups, see the *Concepts & Examples ScreenOS Reference Guide*.

**Example:** The following command creates a vsys named **Acme\_Org**, creates a virtual router named **Acme\_Router**, creates a VSD number **5**, and switches the console to the new virtual system:

```
set vsys Acme_Org vrouter vsd 5
```

## **vsys-profile**

```
set vsys name_str vsys-profile name_str
```

**vsys-profile** Assigns an existing vsys profile to the vsys. The vsys profile must be previously defined.



# vsys-profile

Use the **vsys-profile** commands to configure virtual system (vsys) profiles. Vsys profiles allow you to define resource allocation for individual virtual systems by setting a maximum value and reserved value for resources. The absolute maximum value for a resource depends on the security device, and the configured maximum value cannot exceed the device's absolute maximum value. The reserved value cannot be higher than the maximum value.

Use the **get vsys-profile** command to see a list of all vsys profiles and resource allocation information for each vsys profile.

## Syntax

---

### **get**

```
get vsys-profile [name_str | global]
```

### **set**

```
set vsys-profile { name_str | name name_str }
 [cpu-weight number]
 [dips
 {
 max number |
 reserve number
 }
]
 [mips
 {
 max number |
 reserve number
 }
]
 [mpolicies
 {
 max number |
 reserve number
 }
]
 [policies
 {
 max number |
 reserve number
 }
]
```

```

]
[sessions
 {
 alarm number
 max number |
 reserve number
 }
]
[shared-dmz zone]
[user-serv-grps
 {
 max number |
 reserve number
 }
]
[user-servs
 {
 max number |
 reserve number
 }
]
[user-zones
 {
 max number |
 reserve number
 }
]
[zone-addr-grps
 {
 max number |
 reserve number
 }
]
[zone-addr
 {
 max number |
 reserve number
 }
]
]

```

## Keywords and Variables

---

### Variable Parameters

```

get vsys-profile [name_str]
set vsys-profile name_str [...]
unset vsys-profile name_str

```

*name\_str*            Name of an existing virtual system (vsys).

**Example:** The following command configures a session limit of 500 for the existing **vprofile1** profile:

```
set vsys-profile vprofile1 sessions max 500
```

## **cpu-weight**

```
set vsys-profile { name_str | name name_str } cpu-weight weight
```

**cpu-weight** Specifies CPU weight, which is a dimensionless quantity used to calculate the CPU time quota for each vsys. The CPU weight for a vsys is used in combination with the CPU weight for all the other virtual systems in a security device when calculating the time quota.

CPU weight can be a value from 1 through 100. The default value is 50.

**Example:** The following command configures a CPU weight of 30 for the existing **vprofile1** profile:

```
set vsys-profile vprofile1 cpu-weight 30
```

## **dips**

```
set vsys-profile { name_str | name name_str } dips { max number | reserve number }
```

**max** Maximum number of dynamic IP addresses (DIPs) per vsys.

**reserve** Number of DIPs reserved per vsys.

**Example:** The following command configures a maximum value of 200 for the existing **vprofile1** profile:

```
set vsys-profile vprofile1 dips max 200
```

## **global**

```
get vsys-profile [global]
```

**global** Displays summary of global usage for the whole device.

## **mips**

```
set vsys-profile { name_str | name name_str } mips { max number | reserve number }
```

**max** Maximum number of mapped IP addresses (MIPs) per vsys.

**reserve** Number of MIPs reserved per vsys.

**Example:** The following command configures a reserved value of 500 MIPs for the existing **vprofile1** profile:

```
set vsys-profile vprofile1 mips reserve 500
```

## ***mpolicies***

```
set vsys-profile { name_str | name name_str } mpolicies { max number | reserve number
}
```

max                   Maximum number of multicast policies per vsys.

reserve                Number of multicast policies reserved per vsys.

**Example:** The following command configures a maximum value of 300 for the existing **vprofile1** profile:

```
set vsys-profile vprofile1 mpolicies max 300
```

## ***name***

```
set vsys-profile name name_str
```

name                   Name of the vsys profile. The maximum name length is 31 alphanumeric characters, including hyphens (-) and underscores (\_). Spaces and special characters are not permitted.

**Example:** The following command creates a vsys profile named **vprofile1**:

```
set vsys-profile name vprofile1
```

## ***policies***

```
set vsys-profile { name_str | name name_str } policies { max number | reserve number }
```

max                    Maximum number of security policies per vsys.

reserve                Number of security policies reserved per vsys.

**Example:** The following command configures a reserved value of 10000 policies for the existing **vprofile1** profile:

```
set vsys-profile vprofile1 policies max 10000
```

## ***sessions***

```
set vsys-profile { name_str | name name_str } sessions { alarm number | max number |
reserve number }
```

alarm                  Number of sessions reached before an alarm is triggered.

max                    Maximum number of sessions per vsys.

reserve                Number of sessions reserved per vsys.

**Example:** The following command configures a session limit of 500 for the existing **vprofile1** profile:

```
set vsys-profile vprofile1 sessions 500
```

## shared-dmz

```
set vsys-profile { name_str | name name_str } shared-dmz zone
unset vsys-profile { name_str | name name_str } shared-dmz
```

shared-dmz Specifies that the new zone is a shared DMZ zone, a Layer 3 security zone (for running the device in NAT/route mode), which can be bound only to a loopback interface. The default interface is null.

- zone—Specifies the name of the shared DMZ zone.

## user-serv-grps

```
set vsys-profile { name_str | name name_str } user-serv-grps { max number | reserve
 number }
```

max Maximum number of user service groups per vsys.

reserve Number of user service groups reserved per vsys.

**Example:** The following command configures a maximum value of 500 user service groups for the existing **vprofile1** profile:

```
set vsys-profile vprofile1 user-serv-grps max 500
```

## user-servs

```
set vsys-profile { name_str | name name_str } user-servs { max number | reserve
 number }
```

max Maximum number of user services per vsys.

reserve Number of user services reserved per vsys.

**Example:** The following command configures a maximum value of 400 user services for the existing **vprofile1** profile:

```
set vsys-profile vprofile1 user-servs max 400
```

## user-zones

```
set vsys-profile { name_str | name name_str } user-zones { max number | reserve
 number }
```

max Maximum number of zones per vsys.

reserve Number of zones reserved per vsys.

**Example:** The following command configures a maximum value of 450 user service groups for the existing **vprofile1** profile:

```
set vsys-profile vprofile1 user-zones max 450
```

**zone-addr-grps**

```
set vsys-profile { name_str | name name_str } zone-addr-grps { max number | reserve
 number }
```

max                   Maximum number of zone address groups per vsys.

reserve               Number of zone address groups reserved per zone per vsys.

**Example:** The following command configures a reserved value of 1000 zone address groups for the existing **vprofile1** profile:

```
set vsys-profile vprofile1 zone-addr-grps reserve 1000
```

**zone-addr**

```
set vsys-profile { name_str | name name_str } zone-addr { max number | reserve
 number }
```

max                   Maximum number of zone addresses per vsys.

reserve               Number of zone addresses reserved per zone per vsys.

**Example:** The following command configures a maximum value of 15000 user zone addresses for the existing **vprofile1** profile:

```
set vsys-profile vprofile1 zone-addr max 15000
```

# webauth

Use the **webauth** commands to configure the security device to perform Web authentication (WebAuth).

The WebAuth authentication method requires that a user first initiate a Hypertext Transfer Protocol (HTTP) session and provide authentication information before being allowed to send traffic to the destination node.

You specify authentication settings in policy definitions (see “auth” on page 81).

## Syntax

---

### **get**

```
get webauth [banner]
```

### **set**

```
set webauth { banner success string | server name_str }
```

## Keywords and Variables

---

### **banner success**

```
get webauth banner
set webauth banner success string
unset webauth banner success
```

**banner success** Specifies the banner (*string*) displayed in response to WebAuth success.

**Example:** The following command changes the WebAuth success banner to *WebAuth service successful*:

```
set webauth banner success "WebAuth service successful"
```

### **server**

```
set webauth server name_str
unset webauth banner server
```

**server** Specifies the WebAuth server name (*name\_str*). (You can obtain all existing WebAuth server names by executing the command **get auth-server all**.)

**Example:** The following command specifies a WebAuth server named **wa\_serv1**:

```
set webauth server wa_serv1
```

### ***Defaults***

The default banner value is *WebAuth Success*.

# webtrends

Use the **webtrends** commands to configure the security device for WebTrends.

The WebTrends Firewall Suite allows you to customize syslog reports of critical, alert, and emergency events to display the information you want in a graphical format. You can create reports that focus on areas such as firewall attacks (emergency-level events) or on all events with the severity levels of critical, alert, and emergency.

## Syntax

---

### **get**

```
get webtrends
```

### **set**

```
set webtrends
{
 VPN |
 enable |
 host-name name_str |
 port port_num
}
```

## Keywords and Variables

---

### **vpn**

```
set webtrends VPN
unset webtrends VPN
```

**vpn**                    Enables WebTrends VPN encryption.

### **enable**

```
set webtrends enable
unset webtrends enable
```

**enable**                Enables WebTrends.

### ***host-name***

```
set webtrends host-name name_str
unset webtrends host-name
```

*host-name*      Specifies the WebTrends hostname.

### ***port***

```
set webtrends port port_num
unset webtrends port
```

*port port\_num*      Specifies the WebTrends host port.

# wlan

Use the **wlan** commands to configure the wireless local area network (WLAN) features.

## Syntax

---

### **exec**

```
exec wlan { find-channel | reactivate | site-survey }
```

### **get**

```
get wlan [acl]
```

### **set**

```
set wlan { 0 | 1 }
{
 acl { mac_addr { allow | deny } | mode { enable | strict } } |
 advanced
 { aging-interval { disable | number } |
 beacon-interval { number } |
 burst-threshold { number } |
 cts-mode { auto | off | on } |
 cts-rate { 1 | 11 | 2 | 5.5 } |
 cts-type { cts-only | cts-rts } |
 dtim-period { number } |
 fragment-threshold { number } |
 long-preamble |
 rts-threshold { number } |
 slot-time long } |
 antenna { a | b | diversity } |
 channel { auto | number } |
 country-code { name_str } |
 extended-channel
 mode { 11b | 11g [11g-only] | 11a | turbo } |
 super-g |
 transmit { power { eighth | full | half | minimum | quarter } |
 rate
 {
 auto | 0.25 | 0.5 | 1 | 2 | 3 | 5.5 | 11 | 6 | 9 | 12 | 18 | 24 | 36 | 48 | 54
 | 72 | 96 | 108
 }
 }
}
```

```
wmm { ap { 0 | 1 | 2 | 3 } | enable | sta { 0 | 1 | 2 | 3 } }
xr
}
```

## Keywords and Variables

---

### 0 | 1

```
get wlan {0 | 1 } {...}
set wlan {0 | 1 } {...}
unset wlan {0 | 1 } {...}
```

0 | 1

For security devices with two radio transceivers, you must specify which WLAN you are configuring.

- 0: 2.4 GHz radio band
- 1: 5 GHz radio band

When configuring security devices with only one radio transceiver, you do not need specify the WLAN (0 or 1) when using the **wlan** commands.

### **acl**

```
get wlan acl
set wlan acl { mac_addr { allow | deny } | mode { disable | enable | strict } }
unset wlan acl { mac_addr | mode }
```

acl

Allows or denies network access to stations with the specified MAC address (*mac\_addr*). You can specify a maximum of 128 MAC addresses.

mode

Sets the wireless client restriction:

- **enable**: Wireless clients that match the deny list are not allowed. All other clients are allowed.
- **strict**: Wireless clients that match the allow list are allowed. All other clients are denied.

**Example:** The following commands set the WLAN to allow only the wireless client with MAC address 000bdfd781f9 to access the security device:

```
set wlan acl mode strict
set wlan acl 000bdfd781f9 allow
```

### **advanced**

```
set wlan advanced { ... }
unset wlan advanced { ... }
```

## advanced

Allows you to configure the following advanced WLAN settings.

- **aging-interval**—Specifies the amount of time that elapses before a wireless client is disconnected if there is no traffic to or from the client.

After the aging-interval elapses and a client is disconnected, its MAC information is deleted from a MAC table on the security device. The MAC table for each radio can contain up to 60 client MAC addresses. Because new clients are denied connectivity when the MAC table is full, set the aging-interval so that existing clients whose connections are not being used are disconnected and their MAC addresses are removed from the MAC table in a timely manner.

The value range is 60 through 1,000,000 seconds. The default value is 300 seconds. To disable aging, use the **aging-interval disable** command.

- **beacon-interval**—Sets the interval at which beacons are sent. The value range is 20 to 1,000 time units (1 time unit equals 1024  $\mu$ s). The default value is 100 time units.
- **burst-threshold**—Sets the frame burst threshold. The range is 2 to 255 frames. The default value is 3 frames.
- **cts-mode**—Sets the Clear to Send (CTS) control frame protection. Does not work in 802.11b wireless mode. The default value is auto.
  - **on** Always use protection.
  - **off** Never use protection.
  - **auto** Automatically detects the CTS mode.
- **cts-rate**—Sets the rate at which CTS frames are sent, in Mbps. Does not work in 802.11b wireless mode. Valid values are 1, 2, 5.5, and 11 Mbps. The default is 11 Mbps.
- **cts-type**—Sets the CTS protection type. Does not work in 802.11b wireless mode. The default is cts-only.
  - **cts-only** Single, self-directed frame.
  - **cts-rts** Two-frame exchange occurs prior to the actual network transmission.
- **dtim-period**—Sets the number of beacons that are sent before the delivery traffic indication map (DTIM) is sent. Increasing the DTIM period decreases the number of broadcasts sent to clients. Range is 1 to 255. The default value is 1 beacon interval.
- **fragment-threshold**—Sets the maximum length of a frame before it is fragmented into multiple frames before transmission. Value range is even numbers between 256 and 2346. The default value is 2346.
- **long-preamble**—Allows use of long preambles (802.11b and 802.11g wireless mode only). The default is short.
- **rts-threshold**—Sets the maximum length a frame is before using the Request to Send (RTS) method to send the frame. The range is 256 to 2346.
- **slot-time long**—Enables use of long slot time. Used only for 802.11g. The default is short.

**antenna**

```
set wlan antenna { a | b | diversity }
unset wlan antenna
```

**antenna** Selects a specific antenna to be used or enables antenna diversity. The default setting is diversity. For information about antennae, see the hardware installation guide for your security device.

- **a**—Uses antenna A
- **b**—Uses antenna B
- **diversity**—Uses antenna A or B, whichever has the stronger signal

**channel**

```
set wlan channel
unset wlan channel
```

**channel** Sets the channel for the wireless interface radio. The channel range is 1 through 11 and is dependent on the country code and extended channel selections. Channels 12 and 13 are reserved for non-U.S. frequency regulations. The default is automatic channel selection.

**country-code**

```
set wlan country-code { string }
```

**country-code** (This keyword is not available in the United States or Japan.) Defines the country in which the security device is operating. This setting determines the channels and the transmit power level you can configure. If your region code is FCC or TELEC, you cannot set the country code. For a list of country codes, see the *Concepts & Examples ScreenOS Reference Guide*.

**extended-channel**

```
set wlan extended-channel
```

**extended-channel** For the 2.4 GHz radio band, enables use of channels 12 and 13 if the regulatory domain allows the use of these channels. Although enabling extended-channel mode provides better geographic coverage, the data throughput rate for clients might be decreased.

**find-channel**

```
exec wlan find-channel
```

**find-channel** Finds the best radio channel for the device to use for transmission. Use this command if you do not want to use the `auto` keyword to automatically select channels and want to find the channel with the least interference.

**mode**

```
set wlan mode { 11a | 11b | 11g [11g-only] | turbo }
unset wlan mode
```

**mode** Sets the operation mode for the wireless interface.

- **11a**—Allows 802.11a wireless clients to connect to the security device.
- **11b**—Allows 802.11b wireless clients to connect to the security device.
- **11g**—Allows 802.11b and 802.11g wireless clients to connect to the security device. The 11g-only mode allows only 802.11g wireless clients to connect to the security device.
- **turbo**:—Enables static turbo mode for 2.4 GHz and 5 GHz radio bands. Turbo mode allows data transmit rate of up to 108 Mbps.

If you enable turbo mode, wireless clients must also support turbo mode. If wireless clients do not support turbo mode, they cannot connect to the wireless network.

**reactivate**

```
exec wlan reactivate
```

**reactivate** Reboots the wireless interfaces so that the new configurations take effect. Use this command after all wireless configurations are complete. Depending on your network, rebooting the wireless interfaces can take 60 seconds or more. Wireless traffic is disrupted, and all wireless client sessions are terminated.

**site-survey**

```
exec wlan site-survey
```

**site-survey** The security device scans all channels and reports all access points in the surrounding area. Use this command to find rogue access points. Depending on your network, the site survey can take approximately 60 seconds and disrupts wireless network traffic.

## *super-g*

```
set wlan super-g
unset wlan super-g
```

**super-g** Enables the Atheros Super G feature, which can increase user data throughput rate up to 4 Mbps for 802.11a and 802.11g clients by using the following methods:

- **Bursting**—Allows the device to transmit multiple frames in a burst rather than pausing after each frame.
- **Fast frames**—Allows for more information per frame to be transmitted by allowing a larger-than-standard frame size.
- **Compression**: Link-level hardware compression is performed by a built-in data compression engine.

If wireless clients do not support Super G and the security device has Super G enabled, they can still connect to the wireless network, but the Super G feature is not available.

## *transmit*

```
set wlan transmit { power {...} | rate {...} }
unset wlan transmit { power | rate }
```

**transmit** Adjusts the transmission power and rate for the wireless interface.

- **power**—Sets the power transmission and adjusts the radio range. You can set the power level to an eighth, full, half, minimum, or quarter of maximum transmit power, which is the maximum power allowed in the country the security device is operating in. The default is full power.
- **rate**—Sets the minimum data transmit rate in megabits per second (Mbps) for sending frames. The data transmit rate depends on the radio type.
  - 802.11a: 6, 9, 12, 18, 24, 36, 48, 54
  - 802.11a with XR enabled: 0.25, 0.5, 3, 6, 9, 12, 18, 24, 36, 48, 54
  - 802.11b: 1, 2, 5.5, 11
  - 802.11g: 1, 2, 5.5, 6, 9, 11, 12, 18, 24, 36, 48, 54
  - 802.11g with XR enabled: .0.25, 0.5, 1, 2, 3, 5.5, 11, 6, 9, 12, 18, 24, 36, 48, 54
  - If turbo is enable: 12, 18, 24, 36, 48, 72, 96, 108

The **auto** rate, which is the default value, uses the best rate first and then automatically falls back to the next rate if transmission fails.

**wmm**

```
set wlan { 0 | 1 } wmm { ap {...} | enable | sta {...} }
unset wlan { 0 | 1 } wmm { ... }
```

|        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|--------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ap     | <p>Configures Wi-Fi Multimedia (WMM) on the access point (security device) side of the wireless connection. You can set WMM parameters for the following categories:</p> <ul style="list-style-type: none"> <li>■ 0 (Best effort)</li> <li>■ 1 (Background)</li> <li>■ 2 (Video)</li> <li>■ 3 (Voice)</li> </ul> <p>For each category, you can set the following parameters:</p> <ul style="list-style-type: none"> <li>■ Logcwmmin and logcwmax: WMM defines a Contention Window (CW), which is equivalent to a random backoff period. <ul style="list-style-type: none"> <li>The CWmin parameter specifies the minimum number of slots of the contention window used by the security device or client for a particular AC to generate a random number for the backoff. If logcwmmin is <math>x</math>, then CWmin is <math>2^x - 1</math>.</li> <li>The CWmax parameter specifies the maximum number of slots of the window used by the security device or client for a particular AC to generate a random number for the backoff. If logcwmax is <math>x</math>, then CWmax is <math>2^x - 1</math>.</li> </ul> </li> <li>■ Aifs: Arbitrary Inter-Frame Space Number (AIFSN) specifies the number of slots, after a SIFS duration, that the security device or client for an AC will check the medium-idle before transmitting or executing a backoff.</li> <li>■ Txoplimit: Transmit Opportunity specifies the maximum amount of time the security device or client can initiate transmissions. If you set txoplimit to <math>x</math>, the maximum time is <math>32 * x</math> microseconds.</li> <li>■ Acm: Admission Control is an optional feature and is not currently supported.</li> <li>■ Ack Policy: You can enable or disable an acknowledgement policy for a WAP. This parameter does not apply to clients.</li> </ul> |
| enable | Enables WMM.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |

|                  |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>sta</code> | <p>Configures WMM on the station side of the wireless connection. You can set WMM parameters for the following access categories (ACs):</p> <ul style="list-style-type: none"> <li>■ 0 (Best effort)</li> <li>■ 1 (Background)</li> <li>■ 2 (Video)</li> <li>■ 3 (Voice)</li> </ul> <p>For each category, you can set the following parameters:</p> <ul style="list-style-type: none"> <li>■ <code>logcwmmin</code> and <code>logcwmax</code>: WMM defines a Contention Window (CW), which is equivalent to a random backoff period.</li> </ul> <p>The <code>CWmin</code> parameter specifies the minimum number of slots of the contention window used by the security device or client for a particular AC to generate a random number for the backoff. If <code>logcwmmin</code> is <math>x</math>, then <code>CWmin</code> is <math>2^x - 1</math>.</p> <p>The <code>CWmax</code> parameter specifies the maximum number of slots of the window used by the security device or client for a particular AC to generate a random number for the backoff. If <code>logcwmax</code> is <math>x</math>, then <code>CWmax</code> is <math>2^x - 1</math>.</p> <ul style="list-style-type: none"> <li>■ <code>aifs</code>: Arbitrary Inter-Frame Space Number (AIFSN) specifies the number of slots, after a SIFS duration, that the security device or client for an AC will check the medium-idle before transmitting or executing a backoff.</li> <li>■ <code>txoplimit</code>: Transmit Opportunity specifies the maximum amount of time the security device or client can initiate transmissions. If you set <code>txoplimit</code> to <math>x</math>, the maximum time is <math>32 * x</math> microseconds.</li> <li>■ <code>acm</code>: Admission Control is an optional feature and is not currently supported.</li> </ul> |
|------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

**XR**

```
set wlan xr
unset wlan xr
```

|                 |                                                                                                                                                                                                                                                                                                                                                                                                                              |
|-----------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>xr</code> | <p>Enables eXtended Range (XR) technology. XR processes 802.11 signals, defined by IEEE 802.11a and 802.11g standards, so that wireless networks to have fewer “dead spots” and greater range than usual. XR processes weaker signals more effectively and allows greater coverage.</p> <p>Only the first active SSID per radio can support XR. When XR is enabled, the first active SSID per radio uses the XR feature.</p> |
|-----------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

# xauth

Use the **xauth** commands to configure the security device to perform XAuth authentication.

An XAuth user or user group is one or more remote users who authenticate themselves when connecting to the security device through an AutoKey IKE VPN tunnel and optionally receive TCP/IP settings from the security device. Whereas IKE user authentication is actually the authentication of VPN gateways or clients, XAuth user authentication is the authentication of the users themselves. XAuth requires each user to enter information unique to that user (the admin name and password).

## Syntax

---

### *get*

```
get xauth { active | default | lifetime }
```

### *set*

```
set xauth
{
 default
 {
 accounting off |
 accounting server name_str |
 auth server name_str [chap] [query-config] |
 dns1 ip_addr |
 dns2 ip_addr |
 ippool name_str |
 wins1 ip_addr |
 wins2 ip_addr
 } |
 lifetime number
}
```

## Keywords and Variables

---

### **accounting off**

```
set xauth default accounting off
unset xauth default accounting off
```

**accounting off** The **set** command disables accounting for XAuth. The **unset** command enables accounting for XAuth. By default, accounting is enabled for XAuth.

### **accounting server**

```
set xauth default accounting server name_str
unset xauth default accounting server
```

**accounting server** Specifies a default accounting server for XAuth. The **unset** command resets the default accounting to No Configuration.

### **active**

```
get xauth active
```

**active** Displays all currently active XAuth login instances.

### **default**

```
get xauth default
set xauth default { ... }
unset xauth default { ... }
```

**default** Sets or displays default XAuth settings.

- **auth server**—Identifies the XAuth server by object name (*name\_str*).
- **chap**—Directs the security device to use Challenge Handshake Authentication Protocol (CHAP) while performing authentication with the XAuth client.
- **query-config**—Queries client settings (such as IP addresses for XAuth clients and DNS server IP addresses) from an external authentication server.
- **dns1**—Identifies the DNS primary server by IP address (*ip\_addr*).
- **dns2**—Identifies the DNS secondary server by IP address (*ip\_addr*).
- **ippool**—Identifies the pool of IP addresses from which the security device draws when assigning addresses to XAuth clients.
- **wins1**—Identifies the WINS primary server by IP address (*ip\_addr*).
- **wins2**—Identifies the WINS secondary server by IP address (*ip\_addr*).

**Example:** The following command sets up the security device to use a XAuth server (Our\_Auth):

```
set xauth default auth server Our_Auth
```

## *lifetime*

```
get xauth lifetime
set xauth lifetime number
unset xauth lifetime number
```

*lifetime number* Specifies the maximum length of time (in minutes) that the XAuth server holds resources (such as an IP address) on behalf of a client.

**Example:** The following command specifies a maximum XAuth session length of 30 minutes:

```
set xauth lifetime 30
```



# zone

Use the **zone** commands to create, remove, or display a security zone and to set SCREEN options.

Defining a *security zone* is method for sectioning the network into segments to which you can apply various security options. You can configure multiple security zones for individual security devices, thus dividing the network into segments to which you can apply security options. There must be at least two security zones per device, basically to protect one area of the network from the other. On some platforms, you can define many security zones, bringing finer granularity to your network security design without deploying multiple security devices

Each security zone has at least one interface bound to it. For a brief description of the interfaces, see “Interfaces” on page 771. For more information about security zones, see “Zones” on page 773.

## Syntax

---

### get

```
get zone
[
 id id_num |
 all |
 zone [screen [attack | counter | info]]
]
```

### set

```
set zone
{
 name zone [L2 id_num | shared-dmz | tunnel zone] |
 zone
 {
 asymmetric-vpn |
 block |
 g-arp
 no-dhcp-relay
 pbr pbr_policy_name |
 screen
 {
 alarm-without-drop |
 block-frag |
```

```

component-block [activex | java | zip | exe] |
fin-no-ack |
icmp-flood [threshold number] |
icmp-fragment |
icmp-large |
ip-bad-option |
ip-filter-src |
ip-loose-src-route |
ip-record-route |
ip-security-opt |
ip-spoofing [drop-no-rpf-route | zone-based] |
ip-stream-opt |
ip-strict-src-route |
ip-sweep [threshold number] |
ip-timestamp-opt |
land |
limit-session
 [source-ip-based number | destination-ip-based [number]] |
mal-url { string1 string2 number | code-red } |
on-tunnel |
ping-death |
port-scan [threshold number] |
syn-ack-ack-proxy [threshold number] |
syn-fin |
syn-flood
 [
 alarm-threshold number |
 attack-threshold number |
 destination-threshold number |
 drop-unknown-mac |
 queue-size number |
 source-threshold number |
 timeout number
] |
syn-frag |
tcp-no-flag |
tcp-sweep [[threshold number]
tear-drop |
udp-flood [dst-ip ip_addr | threshold number] |
udp-sweep [[threshold number]
unknown-protocol |
winnuke
}
reassembly-for-alg |
tcp-rst |
vrouter name_str
} |
}

```

## Keywords and Variables

---

### Variable Parameters

```
get zone zone [...]
set zone zone { ... }
unset zone zone { ... }
```

**zone** The name of the zone. For more information, see “Zones” on page 773. The **get zone** command displays the details of the zones with identical names across all virtual systems.

### all

```
get zone all [...]
```

**all** Displays information about all existing zones, including zones with identical names.

### asymmetric-vpn

```
set zone asymmetric-vpn
```

**asymmetric-vpn** When enabled, this option allows any incoming VPN traffic in a zone to match any applicable VPN session, regardless of the origin of the original VPN tunnel. For example, traffic coming from VPN A can match a session created by traffic for VPN B. This feature allows free routing of VPN traffic between two or more sites when there are multiple possible paths for VPN traffic.

---

**NOTE:** It is not advisable to mix policy-based and route-based VPNs for asymmetric traffic.

---

### block

```
set zone zone block
unset zone zone block
```

**block** Imposes intrazone traffic blocking.

### g-arp

```
set zone zone g-arp
unset zone zone g-arp
```

**g-arp** Configures the Layer 2 zone (V1-Trust, V1-Untrust, or V1-DMZ) to accept incoming Gratuitous Address Resolution Protocol (G-ARP) packets. By default, the Layer 2 zone accepts the incoming G-ARP packets. Use the **unset** command to configure the Layer 2 zone to ignore the incoming G-ARP packets.

**name**

```
set zone name zone { ... }
```

**name** Creates a new zone with name *zone*.

- **L2 *id\_num***—Specifies that the zone is Layer 2 (for running the device in transparent mode). The ID number (*id\_num*) identifies the VLAN to which the zone is bound. The name you specify (*zone*) must begin with "L2-".
- **tunnel *zone***—Specifies that the new zone is a VPN tunnel zone, and identifies the tunnel-out zone (*zone*).
- **shared-dmz**—Specifies that the new zone is a shared DMZ zone, a Layer 3 security zone (for running the device in NAT/route mode), which can be bound only to a loopback interface. The default interface is null.

**Example 1:** The following command creates a new Layer 2 zone named **L2-Sales** with VLAN ID number **1**:

```
set zone name L2-Sales L2 1
```

**Example 2:** The following command creates a tunnel zone named **Engineering** and specifies **untrust** as the out zone:

```
set zone name Engineering tunnel untrust
```

**Example 3:** The following command creates a shared DMZ zone named **share-v1**:

```
set zone name share-v1 shared-dmz
```

**no-dhcp-relay**

```
set zone zone no-dhcp-relay
unset zone zone no-dhcp-relay
```

**no-dhcp-relay** By default, ScreenOS relays DHCP request packets from all zones except the V1-Untrust zone and V1-DMZ zone. Enable this feature to prevent relay of DHCP request packets from a specified zone.

**pbr**

```
set zone zone pbr pbr_policy_name
unset zone zone pbr pbr_policy_name
```

**pbr** Binds a policy based routing policy to the specified zone. A PBR policy bound to a zone is used by all PBR-enabled interfaces within that zone. In this case, the PBR policy is not bound at the interface level.

**reassembly-for-alg**

```
set zone untrust reassembly-for-alg
```

`reassemble-for-alg` Reassembles all fragmented IP packets and TCP segments for HTTP and FTP traffic that arrives at any interface bound to the zone on which you enable this option. With this option enabled, the security device can better detect malicious URLs that an attacker has deliberately broken into packet or segment fragments. Packet and segment reassembly also improves Application Layer Gateway (ALG) filtering by allowing the security device to examine the complete text within payloads.

## screen

```
set zone zone screen { ... }
set zone zone screen { ... }
```

`screen` Enables or disables firewall services through the interface.

- **alarm-without-drop** Generates an alarm when detecting an attack but does not block the attack. This option is useful if you allow the attack to enter a segment of your network that you have previously prepared to receive it—such as a honeynet, which is essentially a decoy network with extensive monitoring capabilities. It does not apply to traffic affected by the following features when the features have been enabled:
  - SYN-ACK-ACK proxy protection
  - Malicious URL protection
- **block-frag**—Enables IP packet fragmentation blocking.
- **component-block**— Selectively blocks HTTP traffic containing any of the following components:
  - **activex**— ActiveX controls
  - **java**—Java applets
  - **exe**—.EXE files
  - **zip** —ZIP files

An attacker can use any of these components to load an application (a Trojan) onto a protected host and then use the application to gain control of the host. If you enable the blocking of HTTP components without specifying which components, the security device blocks all of them. Alternatively, you can configure the security device to block only specified components.

If you enable ActiveX-blocking, the security device also blocks packets containing Java applets, .exe files, and .zip files because they might be contained within an ActiveX control.

- **fin-no-ack**—Detects an illegal combination of flags, and rejects packets that have them.
- **icmp-flood [ threshold number ]**—Detects and prevents Internet Control Message Protocol (ICMP) Flood attacks. An ICMP Flood occurs when ICMP echo requests are broadcast with the purpose of flooding a system with so much data that it first slows down and then times out and is disconnected. The threshold defines the number of ICMP packets per second allowed to ping the same destination address before the security device rejects further ICMP packets. The range is 1 to 1,000,000.
- **icmp-fragment**—Detects and drops any ICMP frame with the More Fragments flag set or with an offset indicated in the Offset field.
- **icmp-large**—Detects and drops any ICMP frame with an IP length greater than 1024.

- **ip-bad-option**—Detects and drops any packet with an incorrectly formatted IP option in the IP packet header. The security device records the event in the SCREEN counters list for the ingress interface.
- **ip-filter-src**—Detects and drops all packets with the Source Route option enabled. The Source Route option can allow an attacker to use a false IP address to access a network and receive returned traffic addressed to the real IP address of the attacker's host device. The administrator can block all IP source-routed frames having Strict Source Routing (or Loose Source Routing) enabled.
- **ip-loose-src-route**—Detects packets where the IP option is 3 (Loose Source Routing) and records the event in the SCREEN counters list for the ingress interface. This option specifies a partial route list for a packet to take on its journey from source to destination. The packet must proceed in the order of addresses specified, but it is allowed to pass through other routers in between those specified.
- **ip-record-route**—Detects packets where the IP option is 7 (Record Route) and records the event in the SCREEN counters list for the ingress interface.
- **ip-security-opt**—Detects packets where the IP option is 2 (security) and records the event in the SCREEN counters list for the ingress interface.
- **ip-spoofing**—Prevents spoofing attacks. Spoofing attacks occur when unauthorized agents attempt to bypass firewall security by imitating valid client IP addresses. Using the ip-spoofing option invalidates such false source IP address connections.

The **drop-no-rpf-route** option instructs the security device to drop any packet with a source address that is not contained in the route table. For example, the device drops the packet if it does not contain a source route or if the source IP address is reserved (nonroutable, as with 127.0.0.1).

Conversely, the device does not drop the packet if the routing table contains a reverse-path-forwarding route that matches the source IP address on the packet. For example, the device drops an incoming packet with source IP address 10.5.1.5 if the device receives the packet on ethernet1 and there is no reverse-path route for 10.5.1.5 (such as 0.0.0.0/0 or 10.5.1.0/24) on that interface. This is true even if such a reverse path exists on another interface.

The **zone-based** option instructs the security device to base spoofing decisions on zones instead of on individual interfaces. Enabling this setting allows sessions to continue when the device asymmetrically routes traffic between multiple interfaces in the same zone. Thus, the user can specify spoofing decisions based on either the zone or on an exact interface.

The default behavior is to base spoofing decisions on individual interfaces. To restore the default behavior:

**unset zone *zone* screen ip-spoofing zone-based**

- **ip-stream-opt**—Detects packets where the IP option is 8 (Stream ID) and records the event in the SCREEN counters list for the ingress interface.
- **ip-strict-src-route**—Detects packets where the IP option is 9 (Strict Source Routing) and records the event in the SCREEN counters list for the ingress interface. This option specifies the complete route list for a packet to take on its journey from source to destination. The last address in the list replaces the address in the destination field.

- **ip-sweep threshold** *number*—Detects and prevents an IP Sweep attack. An IP Sweep attack occurs when an attacker sends ICMP echo requests (pings) to multiple destination addresses. If a target host replies, it reveals the target's IP address to the attacker. You can set the IP Sweep threshold to a value between 1 and 1,000,000 microseconds. Each time the security device receives 10 ICMP echo requests within this interval, it flags this as an IP Sweep attack, and rejects the 11th and all further ICMP packets from that host for the remainder of the second.
- **ip-timestamp-opt**—Detects packets where the IP option list includes option 4 (Internet Timestamp) and records the event in the SCREEN counters list for the ingress interface.
- **land**—Prevents Land attacks by combining the SYN Flood defense mechanism with IP spoofing protection. Land attacks occur when an attacker sends spoofed IP packets with headers containing the target's IP address for both the source and destination IP addresses. The attacker sends these packets with the SYN flag set to any available port. This induces the target to create empty sessions with itself, filling its session table and overwhelming its resources.
- **limit-session** [ **source-ip-based** *number* | **destination-ip-based** *number* ] Limits the number of concurrent sessions the device can initiate from a single source IP address, or the number of sessions it can direct to a single destination IP address. By default, the limit is 128 sessions. Limit value range is 1 to 49,999.
- **mal-URL** [ *name\_str id\_str number* | **code-red** ]—Sets up a filter that scans HTTP packets for suspect URLs. The security device drops packets that contain such URLs. The **code-red** switch enables blocking of the Code Red worm virus. Using the *name\_str* option works as follows.
  - *name\_str* A user-defined identification name.
  - *id\_str*—Specifies the starting pattern to search for in the HTTP packet. Typically, this starting pattern begins with the HTTP command GET, followed by at least one space, plus the beginning of a URL. (The security device treats multiple spaces between the command "GET" and the character "/" at the start of the URL as a single space.)
  - *number*—Specifies a minimum length for the URL before the CR-LF.
- **on-tunnel**—Enables the configured screen functions on the tunnel in this zone. The default is disabled. Screening applies only to the ingress interface.

On ASIC-based security devices, screen functions performed by the ASIC apply to tunnel traffic automatically if the functions are enabled. However, the screening is based on the physical interface the tunnel is bound to. For route based VPN tunnels, if the tunnel interface and the physical interface are in different zones, the screen functions configured for the zone of physical interface apply.

- **ping-of-death**—Detects and rejects oversized and irregular ICMP packets. Although the TCP/IP specification requires a specific packet size, many ping implementations allow larger packet sizes. This can trigger a range of adverse system reactions including crashing, freezing, and restarting.

- **port-scan threshold *number***—Prevents port scan attacks. A port scan attack occurs when an attacker sends packets with different port numbers to scan available services. The attack succeeds if a port responds. To prevent this attack, the security device internally logs the number of different ports scanned from a single remote source. For example, if a remote host scans 10 ports in 0.005 seconds (equivalent to 5000 microseconds, the default threshold setting), the security device flags this as a port scan attack, and rejects further packets from the remote source. The port-scan threshold *number* value determines the threshold setting, which can be from 1000 to 1,000,000 microseconds.
- **syn-ack-ack-proxy**—Prevents the SYN ACK ACK attack. Such an attack occurs when the attacker establishes multiple Telnet sessions without allowing each session to terminate. This consumes all open slots, generating a denial of service(DOS) condition.
- **syn-fin**—Detects an illegal combination of flags attackers can use to consume sessions on the target device, thus resulting in a denial of service(DOS).
- **syn-flood**—Detects and prevents SYN Flood attacks. Such attacks occur when the connecting host continuously sends TCP SYN requests without replying to the corresponding ACK responses.
  - **alarm-threshold *number***—Defines the number of half-complete proxy connections per second for which the security device makes entries in the event log.
  - **attack-threshold *number***—Defines the number of SYN packets per second required to trigger the SYN Proxy mechanism.
  - **destination-threshold *number***—Specifies the number of SYN segments received per second for a single destination IP address before the security device begins dropping connection requests to that destination. If a protected host runs multiple services, you might want to set a threshold based on destination IP address only, regardless of the destination port number.
  - **drop-unknown-mac**—Drops packets when they contain unknown destination MAC addresses.
  - **queue-size *number***—Defines the number of proxy connection requests held in the proxy connection queue before the system starts rejecting new connection requests.
  - **source-threshold *number***—Specifies the number of SYN segments received per second from a single source IP address (regardless of the destination IP address and port number) before the security device begins dropping connection requests from that source.
  - **timeout *number***—Defines the maximum length of time before a half-completed connection is dropped from the queue. You can set it between 1 and 50 seconds.
- **syn-frag**—Detects a SYN Fragment attack and drops any packet fragments used for the attack. A SYN Fragment attack floods the target host with SYN packet fragments. The host caches these fragments, waiting for the remaining fragments to arrive so it can reassemble them. By flooding a server or host with connections that cannot be completed, the host's memory buffer eventually fills. No further connections are possible, and damage to the host's operating system can occur.
- **tcp-no-flag**—Drops an illegal packet with a missing or malformed flags field.

- **tcp-sweep**—Configures the TCP Sweep Protection SCREEN option for the security device. When the connection rate from a source IP to multiple IPs exceeds a threshold rate, the TCP Sweep Protection SCREEN option is enabled and further packets originating from that source are dropped.
  - **threshold number**—Defines the numbers of destination IPs allowed to be connected by a source IP within one second. If the number of packets exceeds the threshold rate, the connection with the source is dropped. The default threshold rate is 50 packets per second. You can configure a value between 1 to 5000 packets per second.
- **tear-drop**—Blocks the Teardrop attack. Teardrop attacks occur when fragmented IP packets overlap and cause the host attempting to reassemble the packets to crash. The tear-drop option directs the security device to drop any packets that have such a discrepancy.
- **udp-flood dst-ip *ip\_addr***—Enables the feature and specifies the IP address of the system that you want to protect.
- **udp-flood threshold *number***—UDP flooding occurs when an attacker sends UDP packets to slow down the system to the point that it can no longer process valid connection requests.
 

The **threshold *number*** parameter is the number of packets allowed per second to the same destination IP address/port pair. When the number of packets exceeds this value within any one-second period, the security device generates an alarm and drops subsequent packets for the remainder of that second. The valid range is from 1 to 1,000,000.
- **udp-sweep**—Configures the UDP Sweep Protection SCREEN option for the security device. When the connection rate from a source IP to multiple IPs exceeds a threshold rate, the UDP Sweep Protection SCREEN option is enabled and further packets originating from that source are dropped.
  - **threshold number**—Defines the numbers of destination IPs allowed to be connected by a source IP within one second. If the number of packets exceeds the threshold rate, the connection with the source is dropped. The default threshold rate is 50 packets per second. You can configure a value between 1 to 5000 packets per second.
- **unknown-protocol**—Discards all received IP frames with protocol numbers greater than 135. Such protocol numbers are undefined or reserved.
- **winnuke**—Detects attacks on Windows NetBios communications, modifies the packet as necessary, and passes it on. (Each WinNuke attack triggers an attack log entry in the event alarm log.)

**Example 1:** The following command enables the **ip-spoofing** firewall service for the **trust** zone:

```
set zone trust screen ip-spoofing
```

**Example 2:** The following command enables the **ip-spoofing** firewall service for the **untrust** zone, and instructs the device to drop any packet that has no source IP address, or that has a nonroutable source IP address:

```
set zone untrust screen ip-spoofing drop-no-rpf-route
```

**Example 3:** The following command sets up a filter that scans HTTP packets for the **code-red** Code Red worm virus and drops such packets.

```
set zone untrust screen mal-url code-red
```

**Example 4:** The following commands block ActiveX and Java applets in HTTP traffic received on interfaces bound to the Untrust zone:

```
set zone untrust block-component activex
set zone untrust block-component java
```

**Example 5:** The following commands limit the number of sessions from any host in the Trust and Untrust zones to any single IP address to 80 sessions:

```
set zone trust screen limit-session destination-ip-based 80
set zone trust screen limit-session
set zone untrust screen limit-session destination-ip-based 80
set zone untrust screen limit-session
```

### *tcp-rst*

```
set zone zone tcp-rst
unset zone zone tcp-rst
```

tcp-rst                Directs the security device to send back the TCP reset packet when it receives nonsync packets.

### *vrouter*

```
set zone zone vrouter name_str
```

vrouter                Binds the zone to a virtual router (VR).  
You can bind a management (MGT) zone to a VR other than the trust-vr (the MGT zone is bound to the trust-vr by default).

## **Creating Interfaces**

**Example 1:** The following commands:

- Create a new Layer 2 zone named **L2-Marketing** with VLAN ID number **1**
- Assign physical interface **ethernet7** to the zone

```
set zone name L2-Marketing L2 1
set interface ethernet7 zone L2-Marketing
```

**Example2 :** The following commands:

- Create a new Layer 3 zone named **Ext\_Dept**
- Bind the zone to the **untrust-vr** virtual router
- Enable **ip-spoofing** and **tear-drop** screening
- Bind interface **ethernet4** to the zone:

```
set zone name Ext_Dept
set zone Ext_Dept vrouter untrust-vr
set zone Ext_Dept screen ip-spoofing
set zone Ext_Dept screen tear-drop
set interface ethernet4 zone Ext_Dept
```

## Appendix A

# Interfaces

Most security zones exchange traffic with other zones (or with other devices) through physical interfaces or logical subinterfaces. Table 2 lists interface types and their descriptions.

**Table 2: Interface Types**

| Interface Type      | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
|---------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Aggregate</b>    | <b>aggregate</b> <i>n</i> —An aggregate interface, which is a grouping of two physical interfaces. An aggregate interface provides interface redundancy, allowing load sharing and failover.                                                                                                                                                                                                                                                                                                                       |
| <b>Ethernet</b>     | <b>ethernet</b> <i>n</i> —A physical ethernet interface, denoted by an interface port <i>n</i> and no slots.<br><b>ethernet</b> <i>n1/n2</i> —A physical ethernet interface, denoted by an interface slot ( <i>n1</i> ) and a port ( <i>n2</i> ).                                                                                                                                                                                                                                                                  |
| <b>Function</b>     | <b>mgt</b> —An interface bound to the MGT zone.<br><b>ha</b>   <b>ha1</b>   <b>ha2</b> —The name of the dedicated HA port.                                                                                                                                                                                                                                                                                                                                                                                         |
| <b>Layer 2</b>      | <b>vlan1</b> —The interface used for VPNs and management traffic while the device is in transparent mode.                                                                                                                                                                                                                                                                                                                                                                                                          |
| <b>Loopback</b>     | <b>loopback</b> . <i>n</i> —A logical interface that emulates a physical interface on the device. A loopback interface is always in the up state as long as the device on which it resides is up.                                                                                                                                                                                                                                                                                                                  |
| <b>Redundant</b>    | <b>redundant</b> <i>n1</i> —A redundant interface, which is a grouping of physical interfaces (each denoted by <i>n1</i> ). Redundant interfaces perform interface failover.<br><b>redundant</b> <i>n1.n2</i> —A logical redundant subinterface.                                                                                                                                                                                                                                                                   |
| <b>Subinterface</b> | <b>ethernet</b> <i>n1.n2</i> —A logical subinterface, denoted by an interface port ( <i>n1</i> ) with no slots. The <i>.n2</i> parameter identifies the logical interface. You create logical interfaces using the <b>set interface</b> command.<br><b>ethernet</b> <i>n1/n2.n3</i> —A logical subinterface, denoted by an interface slot ( <i>n1</i> ) and a port ( <i>n2</i> ). The <i>.n3</i> parameter identifies the logical interface. You create logical interfaces using the <b>set interface</b> command. |
| <b>Tunnel</b>       | <b>tunnel</b> . <i>n</i> —A tunnel interface, used for VPN traffic.                                                                                                                                                                                                                                                                                                                                                                                                                                                |



## Appendix B Zones

Juniper Networks security devices use zones to host physical and logical interfaces, tunnels, and special-purpose items. Although ScreenOS has a number of default predefined zones, you can create new zones and configure them to meet the requirements of your organization. Table 3 lists zone types and their descriptions.

**Table 3: Zone Types**

| Zone Type       | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
|-----------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Layer 2</b>  | <p>Use Layer 2 security zones when the device operates in transparent mode.</p> <ul style="list-style-type: none"> <li>■ <b>v1-trust</b> The V1-Trust zone, which hosts physical interfaces that communicate with trusted network space.</li> <li>■ <b>v1-untrust</b> The V1-Untrust zone, which hosts physical interfaces that communicate with untrusted network space.</li> <li>■ <b>v1-dmz</b> The DMZ zone, which hosts the DMZ physical interface.</li> <li>■ <b>name</b> <i>name_str</i> A user-defined Layer 2 security zone. (You create such zones using the <b>set zone name name_str L2</b> command.)</li> </ul>                                                                                                                                                                                                                                                                                              |
| <b>Layer 3</b>  | <p>Use Layer 3 security zones when the device operates in NAT or router mode.</p> <ul style="list-style-type: none"> <li>■ <b>trust</b> The Trust zone, which hosts physical interfaces (and logical sub-interfaces) that communicate with trusted network space.</li> <li>■ <b>untrust</b> The Untrust zone, which hosts physical interfaces (and logical sub-interfaces) that communicate with untrusted network space.</li> <li>■ <b>global</b> The Global zone, which serves as a storage area for mapped IP (MIP) and virtual IP (VIP) addresses. Because traffic going to these addresses is mapped to other addresses, the Global zone does not require an interface.</li> <li>■ <b>dmz</b> The DMZ zone, which hosts the DMZ physical interface.</li> <li>■ <b>name</b> <i>name_str</i> A user-defined Layer 2 security zone. (You create such zones using the <b>set zone name name_str</b> command.)</li> </ul> |
| <b>Tunnel</b>   | <p>Use tunnel zones to set up VPN tunnels with other security devices.</p> <ul style="list-style-type: none"> <li>■ <b>untrust-tun</b> The Untrust-Tun zone, which hosts VPN tunnels.</li> <li>■ <b>name</b> <i>name_str</i> A user-defined tunnel zone. You create such zones using the <b>set zone name name_str tunnel</b> command.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| <b>Function</b> | <p>Use function zones as described below:</p> <ul style="list-style-type: none"> <li>■ <b>null</b> The Null zone, which serves as temporary storage for any interfaces that are not currently bound to another zone.</li> <li>■ <b>self</b> The Self zone, which hosts the interface for remote management connections. For example, when you connect to the device via HTTP, SCS, or Telnet, you connect to the Self zone.</li> <li>■ <b>ha</b> The HA zone, which hosts the high-availability interfaces, HA1 and HA2.</li> <li>■ <b>mgt</b> The MGT zone, which hosts the out-of-band management interface, MGT.</li> </ul>                                                                                                                                                                                                                                                                                            |

